

SOLIDWORKS API (NET VBA C#) — Reference

(I62/337): IMirrorComponentFeatureData- IMirrorPartFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IMirrorComponentFeatureData (Type)

IMirrorComponentFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorComponentFeatureData Interface

Allows access to a mirror component feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMirrorComponentFeatureData

Visual Basic (Usage)

Dim instance As [IMirrorComponentFeatureData](#)

C#

public interface IMirrorComponentFeatureData

C++/CLI

public interface class IMirrorComponentFeatureData

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData](#).

Example

[Mirror Components II \(VBA\)](#)
[Mirror Components II \(VB.NET\)](#)
[Mirror Components II \(C#\)](#)

Remarks

Before calling [IFeatureManager::CreateDefinition](#) to access this interface, you can pre-select the entities needed to create the mirror component feature:

To specify...	Call IModelDocExtension::SelectByID2 using selection Mark...
Mirror plane	1
Components to mirror	2
Alignment references	4

To create a basic Mirror Component feature, use at a minimum:

- [IMirrorComponentFeatureData::MirrorPlane](#)
- [IMirrorComponentFeatureData::ComponentsToInstanceAlignToComponentOrigin](#)
- (Optional) [IMirrorComponentFeatureData::MirrorType](#) (if not explicitly set, defaults to [swMirrorComponentMirrorType_e.swMirrorType_CenterOfBoundingBox](#))
- (Optional) [IMirrorComponentFeatureData::ComponentOrientationsAlignToComponentOrigin](#) (if not explicitly set, defaults to [swMirrorComponentOrientation2_e.swOrientation_MirroredX_MirroredY](#))

To create a mirror instance as a copy of the component, positioned symmetrically about a plane in one of four orientations (for fully symmetric components, all four orientations are true mirrors), use:

- [MirrorPlane](#)
- [MirrorType](#)
- [ComponentOrientationsAlignToComponentOrigin](#)
- [ComponentOrientationsAlignToSelection](#)
- [ComponentsToInstanceAlignToComponentOrigin](#)
- [ComponentsToInstanceAlignToSelection](#)
- [AlignmentReferences](#)
- [FlipDirections](#)
- [SyncFlexibleSubAssemblies](#)

To create a new opposite-hand version of the component (a true mirror of a nonsymmetric component), positioned symmetrically about a plane, use:

- [MirrorPlane](#)
- [MirrorType](#)
- [CreateDerivedConfigurations](#)
- [OppositeHandComponents](#)
- [MirrorComponentsFolderLocation](#)
- [PlaceFilesInOneFolder](#)
- [MirroredComponentFileNames](#)

- [NameModifier](#)
- [NameModifierType](#)
- [ReplaceFileLocations](#)
- [MirrorTransferOptions](#)
- [DimXpertScheme](#)
- [BreakLinksToOriginalPart](#)
- [PreserveZAxis](#)
- [PropagateFromOriginalPart](#)

After specifying this interface as needed, call [IFeatureManager::CreateFeature](#) to create the feature.

This interface is analogous in functionality to the Mirror Components PropertyManager. See the following topics in the SOLIDWORKS Design user-interface help for more information:

- [Comparing Types of Mirror Components](#)
- [Mirroring Components](#)

Accessors

[IFeature::GetDefinition](#)

IFeatureManager::CreateDefinition

Access Diagram

[MirrorComponentFeatureData](#)

See Also

[IMirrorComponentFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::IsMirrored Method \(\)](#)
[IPartDoc::IsMirrored Method \(\)](#)

IMirrorComponentFeatureData Interface Members

[See Also](#)
[Properties](#)
[Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMirrorComponentFeatureData Interface

The following tables list the members exposed by [IMirrorComponentFeatureData](#).

Public Properties

Name	Description
 AlignmentReferences	Gets or sets the alignment references for components whose orientation axes align to them.
 BreakLinksToOriginalPart	Gets or sets whether to break links between opposite-hand components and original components.
 ComponentOrientationsAlignToComponentOrigin	Gets or sets the array of orientations for the components whose axes align to origins.
 ComponentOrientationsAlignToSelection	Gets or sets the array of orientations for the components whose axes align to a selected reference.
 ComponentsToInstanceAlignToComponentOrigin	Gets or sets the array of components whose orientation axes align to origins.
 ComponentsToInstanceAlignToSelection	Gets or sets the array of components whose orientation axes align to selected references.
 CreateDerivedConfigurations	Gets or sets whether to create a derived configuration of the opposite-hand components in the original assembly.
 DimXpertScheme	Gets or sets whether to copy the DimXpert scheme of the original components to the opposite-hand versions.
 FlipDirections	Gets or sets whether to reverse the direction of alignment for selected alignment references.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of mirror components with the configuration of the mirrored component in this mirror component feature.
 MirrorComponentsFolderLocation	Gets or sets the existing folder where all opposite-hand versions are saved.
 MirroredComponentFileNames	Gets or sets the file names of the opposite-hand component versions.
 MirrorPlane	Gets or sets the plane about which components are mirrored.
 MirrorTransferOptions	Gets or sets the items to transfer to the opposite-hand versions.
 MirrorType	Gets or sets the mirror position.
 NameModifier	Gets or sets the prefix or suffix to add to the file or configuration names of the components to be mirrored.
 NameModifierType	Gets or sets the type of modifier to apply to the opposite-hand version file name.
 OppositeHandComponents	Gets or sets the array of components for which to create opposite-hand versions.

	PlaceFilesInOneFolder	Gets or sets whether to place the opposite-hand versions in one folder.
	PreserveZAxis	Gets or sets whether to preserve the orientation of the Z-axis in the opposite-hand versions.
	PropagateFromOriginalPart	Gets or sets whether to propagate visual properties from the original part to the opposite-hand versions.
	ReplaceFileLocations	Gets or sets the file locations of existing files that are to be replaced with new opposite-hand versions.
	SyncFlexibleSubAssemblies	Gets or sets whether to synchronize the movement of mirrored components with the movement of seed components in the flexible subassembly.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror component feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this mirror component feature.

[Top](#)

See Also

[IMirrorComponentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::IsMirrored Method \(\)](#)
[IPartDoc::IsMirrored Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorComponentFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IMirrorComponentFeatureData Interface](#)

For a list of all members of this type, see [IMirrorComponentFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror component feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this mirror component feature.

[Top](#)

See Also

[IMirrorComponentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::IsMirrored Method \(\)](#)
[IPartDoc::IsMirrored Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorComponentFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IMirrorComponentFeatureData Interface](#)

For a list of all members of this type, see [IMirrorComponentFeatureData members](#).

Public Properties

Name	Description
 AlignmentReferences	Gets or sets the alignment references for components whose orientation axes align to them.
 BreakLinksToOriginalPart	Gets or sets whether to break links between opposite-hand components and original components.
 ComponentOrientationsAlignToComponentOrigin	Gets or sets the array of orientations for the components whose axes align to origins.
 ComponentOrientationsAlignToSelection	Gets or sets the array of orientations for the components whose axes align to a selected reference.
 ComponentsToInstanceAlignToComponentOrigin	Gets or sets the array of components whose orientation axes align to origins.
 ComponentsToInstanceAlignToSelection	Gets or sets the array of components whose orientation axes align to selected references.
CreateDerivedConfigurations	Gets or sets whether to create a derived configuration of the opposite-hand components in the original assembly.

		
	DimXpertScheme	Gets or sets whether to copy the DimXpert scheme of the original components to the opposite-hand versions.
	FlipDirections	Gets or sets whether to reverse the direction of alignment for selected alignment references.
	ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of mirror components with the configuration of the mirrored component in this mirror component feature.
	MirrorComponentsFolderLocation	Gets or sets the existing folder where all opposite-hand versions are saved.
	MirroredComponentFileNames	Gets or sets the file names of the opposite-hand component versions.
	MirrorPlane	Gets or sets the plane about which components are mirrored.
	MirrorTransferOptions	Gets or sets the items to transfer to the opposite-hand versions.
	MirrorType	Gets or sets the mirror position.
	NameModifier	Gets or sets the prefix or suffix to add to the file or configuration names of the components to be mirrored.
	NameModifierType	Gets or sets the type of modifier to apply to the opposite-hand version file name.
	OppositeHandComponents	Gets or sets the array of components for which to create opposite-hand versions.
	PlaceFilesInOneFolder	Gets or sets whether to place the opposite-hand versions in one folder.
	PreserveZAxis	Gets or sets whether to preserve the orientation of the Z-axis in the opposite-hand versions.
	PropagateFromOriginalPart	Gets or sets whether to propagate visual properties from the original part to the opposite-hand versions.
	ReplaceFileLocations	Gets or sets the file locations of existing files that are to be replaced with new opposite-hand versions.
	SyncFlexibleSubAssemblies	Gets or sets whether to synchronize the movement of mirrored components with the movement of seed components in the flexible subassembly.

[Top](#)

 See Also

[IMirrorComponentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::IsMirrored Method \(\)](#)
[IPartDoc::IsMirrored Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : AccessSelections Method (IMirrorComponentFeatureData)

Gains access to the selections that define the mirror component feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object,   
    ByVal Component As System.Object   
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMirrorComponentFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlignmentReferences Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : AlignmentReferences Property (IMirrorComponentFeatureData)

Gets or sets the alignment references for components whose orientation axes align to them.

.NET Syntax

Visual Basic (Declaration)

Property AlignmentReferences As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object
```

```
instance.AlignmentReferences = value
```

```
value = instance.AlignmentReferences
```

C#

```
System.object AlignmentReferences {get; set;}
```

C++/CLI

```
property System.Object^ AlignmentReferences {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IEdge](#), [IFace2](#), [IRefPlane](#), [ISketchSegment](#) (linear)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::AlignmentReferences](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#) is not null or Nothing.

There is a one-to-one mapping between this property's array and [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#). If the array contains fewer elements than [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#), then the feature will fail to be created.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)
[IMirrorComponentFeatureData::FlipDirections Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakLinksToOriginalPart Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : BreakLinksToOriginalPart Property (IMirrorComponentFeatureData)

Gets or sets whether to break links between opposite-hand components and original components.

.NET Syntax

Visual Basic (Declaration)

```
Property BreakLinksToOriginalPart As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean
```

```
instance.BreakLinksToOriginalPart = value
```

```
value = instance.BreakLinksToOriginalPart
```

C#

```
System.bool BreakLinksToOriginalPart {get; set;}
```

C++/CLI

```
property System.bool BreakLinksToOriginalPart {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to break links, false (default) to not

Visual Basic for Applications (VBA) Syntax

See [IMirrorComponentFeatureData::BreakLinksToOriginalPart](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false.

If you set this property to true, then changes made to the original component do not propagate to the opposite-hand version.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentOrientationsAlignToComponentOrigin Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ComponentOrientationsAlignToComponentOrigin Property (IMirrorComponentFeatureData)

Gets or sets the array of orientations for the components whose axes align to origins.

.NET Syntax

Visual Basic (Declaration)

```
Property ComponentOrientationsAlignToComponentOrigin As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object  
  
instance.ComponentOrientationsAlignToComponentOrigin = value  
  
value = instance.ComponentOrientationsAlignToComponentOrigin
```

C#

```
System.object ComponentOrientationsAlignToComponentOrigin {get; set;}
```

C++/CLI

```
property System.Object^ ComponentOrientationsAlignToComponentOrigin {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [swMirrorComponentOrientation2](#) e values

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ComponentOrientationsAlignToComponentOrigin](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

There is a one-to-one mapping between this array and [IMirrorComponentFeatureData::ComponentsToInstanceAlignToComponentOrigin](#). If there are fewer elements in this array than are in [IMirrorComponentFeatureData::ComponentsToInstanceAlignToComponentOrigin](#), then missing orientations default to [swMirrorComponentOrientation2_e.swOrientation_MirroredX_MirroredY](#).

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentOrientationsAlignToSelection Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ComponentOrientationsAlignToSelection Property (IMirrorComponentFeatureData)

Gets or sets the array of orientations for the components whose axes align to a selected reference.

.NET Syntax

Visual Basic (Declaration)

```
Property ComponentOrientationsAlignToSelection As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object  
  
instance.ComponentOrientationsAlignToSelection = value  
value = instance.ComponentOrientationsAlignToSelection
```

C#

```
System.Object ComponentOrientationsAlignToSelection {get; set;}
```

C++/CLI

```
property System.Object^ ComponentOrientationsAlignToSelection {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [swMirrorComponentOrientation2_e](#) values

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ComponentOrientationsAlignToSelection](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

There is a one-to-one mapping between this array and [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#). If there are fewer elements in this array than are in [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#), then missing orientations default to [swMirrorComponentOrientation2_e.swOrientation_MirroredX_MirroredY](#).

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentsToInstanceAlignToComponentOrigin Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ComponentsToInstanceAlignToComponentOrigin Property (IMirrorComponentFeatureData)

Gets or sets the array of components whose orientation axes align to origins.

.NET Syntax

Visual Basic (Declaration)

Property ComponentsToInstanceAlignToComponentOrigin As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Object

instance.ComponentsToInstanceAlignToComponentOrigin = value
value = instance.ComponentsToInstanceAlignToComponentOrigin
```

C#

```
System.Object ComponentsToInstanceAlignToComponentOrigin {get; set;}
```

C++/CLI

```
property System.Object^ ComponentsToInstanceAlignToComponentOrigin {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IComponent2](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ComponentsToInstanceAlignToComponentOrigin](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only for components for which you are *not* creating opposite-hand versions.

Use [IMirrorComponentFeatureData::OppositeHandComponents](#) to specify components for which you are creating opposite-hand versions.

Use [IMirrorComponentFeatureData::ComponentOrientationsAlignToComponentOrigin](#) to specify the orientation of each component in this array.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentsToInstanceAlignToSelection Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ComponentsToInstanceAlignToSelection Property (IMirrorComponentFeatureData)

Gets or sets the array of components whose orientation axes align to selected references.

.NET Syntax

Visual Basic (Declaration)

```
Property ComponentsToInstanceAlignToSelection As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object
```

```
instance.ComponentsToInstanceAlignToSelection = value
```

```
value = instance.ComponentsToInstanceAlignToSelection
```

C#

```
System.Object ComponentsToInstanceAlignToSelection {get; set;}
```

C++/CLI

```
property System.Object^ ComponentsToInstanceAlignToSelection {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IComponent2](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only for components for which you are *not* creating opposite-hand versions.

Use [IMirrorComponentFeatureData::OppositeHandComponents](#) to specify components for which you are creating opposite-hand versions.

Use [IMirrorComponentFeatureData::ComponentOrientationsAlignToSelection](#) to specify the orientation of each component in this property's array. There is a one-to-one mapping between this property's array and IMirrorComponentFeatureData::ComponentOrientationsAlignToSelection.

Use [IMirrorComponentFeatureData::AlignmentReferences](#) to specify alignment references. There is a one-to-one mapping between this property's array and IMirrorComponentFeatureData::AlignmentReferences. If this property's array contains more elements than IMirrorComponentFeatureData::AlignmentReferences, then the feature will fail to be created.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDerivedConfigurations Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : CreateDerivedConfigurations Property (IMirrorComponentFeatureData)

Gets or sets whether to create a derived configuration of the opposite-hand components in the original assembly.

.NET Syntax

Visual Basic (Declaration)

Property CreateDerivedConfigurations As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean
```

```
instance.CreateDerivedConfigurations = value
```

```
value = instance.CreateDerivedConfigurations
```

C#

```
System.bool CreateDerivedConfigurations {get; set;}
```

C++/CLI

```
property System.bool CreateDerivedConfigurations {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to create a derived configuration of the opposite-hand components in the original assembly, false (default) to create new part files

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::CreateDerivedConfigurations](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only:

- If [IMirrorComponentFeatureData::OppositeHandComponents](#) is not Nothing or null.
- At creation time. You cannot edit this property after it is set.

If this property is...	And IMirrorComponentFeatureData::NameModifierType is...	Then use...
True	• swMirrorComponentName_Prefix - OR - • swMirrorComponentName_Suffix	IMirrorComponentFeatureData::NameModifier to prepend a prefix or append a suffix to the configuration name of the original component to create a derived configuration name for the new opposite-hand versions.
True	swMirrorComponentName_Custom	IMirrorComponentFeatureData::MirroredComponentFileNames to specify the derived configuration name.
False	• swMirrorComponentName_Prefix - OR -	IMirrorComponentFeatureData::NameModifier to prepend a prefix or append a suffix to the original component file name to create a new opposite-hand version file name.

If this property is...	And IMirrorComponentFeatureData::NameModifierType is...	Then use...
	<code>swMirrorComponentName_Suffix</code>	
False	<code>swMirrorComponentName_Custom</code>	<code>IMirrorComponentFeatureData::MirroredComponentFilenames</code> to specify the opposite-hand version file names.

If you set this property to false, you can also specify the following import features:

- [IMirrorComponentFeatureData::BreakLinksToOriginalPart](#) (if set to false, you can also set [IMirrorComponentFeatureData::DimXpertScheme](#) and/or [IMirrorComponentFeatureData::MirrorTransferOptions](#))
- [IMirrorComponentFeatureData::PreserveZAxis](#)
- [IMirrorComponentFeatureData::PropagateFromOriginalPart](#)

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DimXpertScheme Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : DimXpertScheme Property (IMirrorComponentFeatureData)

Gets or sets whether to copy the DimXpert scheme of the original components to the opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

```
Property DimXpertScheme As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Boolean

instance.DimXpertScheme = value

value = instance.DimXpertScheme
```

C#

```
System.bool DimXpertScheme {get; set;}
```

C++/CLI

```
property System.bool DimXpertScheme {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to copy the DimXpert scheme, false (default) to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::DimXpertScheme](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false,
- and -
- [IMirrorComponentFeatureData::BreakLinksToOriginalPart](#) is false.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipDirections Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : FlipDirections Property (IMirrorComponentFeatureData)

Gets or sets whether to reverse the direction of alignment for selected alignment references.

.NET Syntax

Visual Basic (Declaration)

Property FlipDirections As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Object
```

```
instance.FlipDirections = value
```

```
value = instance.FlipDirections
```

C#

```
System.Object FlipDirections {get; set;}
```

C++/CLI

```
property System.Object^ FlipDirections {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of Boolean values; true to flip alignment directions, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::FlipDirections](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::AlignmentReferences](#) is not Nothing or null.

If this property is not explicitly set, it defaults to false.

See Also

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceUseSeedConfiguration Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ForceUseSeedConfiguration Property (IMirrorComponentFeatureData)

Gets or sets whether to synchronize the configuration of mirror components with the configuration of the mirrored component in this mirror component feature.

.NET Syntax

Visual Basic (Declaration)

Property ForceUseSeedConfiguration As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean
```

```
instance.ForceUseSeedConfiguration = value  
value = instance.ForceUseSeedConfiguration
```

C#

```
System.bool ForceUseSeedConfiguration {get; set;}
```

C++/CLI

```
property System.bool ForceUseSeedConfiguration {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the mirrored component configuration for all mirror components, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ForceUseSeedConfiguration](#).

Remarks

If this property is set to true, the **Referenced configuration** section of the Component Properties dialog is disabled, and you cannot use [IComponent2::ReferencedConfiguration](#) to change the pattern instance configuration.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorComponentsFolderLocation Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : MirrorComponentsFolderLocation Property (IMirrorComponentFeatureData)

Gets or sets the existing folder where all opposite-hand versions are saved.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorComponentsFolderLocation As System.String
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.String

instance.MirrorComponentsFolderLocation = value
value = instance.MirrorComponentsFolderLocation
```

C#

```
System.string MirrorComponentsFolderLocation {get; set;}
```

C++/CLI

```
property System.String^ MirrorComponentsFolderLocation {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Existing folder name

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::MirrorComponentsFolderLocation](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::PlaceFilesInOneFolder](#) is true.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirroredComponentFileNames Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : MirroredComponentFileNames Property (IMirrorComponentFeatureData)

Gets or sets the file names of the opposite-hand component versions.

.NET Syntax

Visual Basic (Declaration)

```
Property MirroredComponentFileNames As System.Object
```

```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Object

instance.MirroredComponentFileNames = value

value = instance.MirroredComponentFileNames
```

C#

```
System.Object MirroredComponentFileNames {get; set;}
```

C++/CLI

```
property System.Object^ MirroredComponentFileNames {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of file names

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::MirroredComponentFileNames](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::NameModifierType](#) is set to [swMirrorComponentNameModifier_e.swMirrorComponentName_Custom](#), - and -
- [IMirrorComponentFeatureData::OppositeHandComponents](#) is not Nothing or null.

If [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is:

- True, then use this property to specify the configuration names to be added to the opposite-hand versions.
- False, then use this property to specify file names to use to create the opposite-hand versions.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorPlane Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : MirrorPlane Property (IMirrorComponentFeatureData)

Gets or sets the plane about which components are mirrored.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorPlane As System.Object
```

Visual Basic (Usage)

```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Object

instance.MirrorPlane = value

value = instance.MirrorPlane
```

C#

```
System.Object MirrorPlane {get; set;}
```

C++/CLI

```
property System.Object^ MirrorPlane {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#) or [IRefPlane](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::MirrorPlane](#).

Example

See the [IMirrorComponentFeatureData](#) example.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorTransferOptions Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : MirrorTransferOptions Property (IMirrorComponentFeatureData)

Gets or sets the items to transfer to the opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorTransferOptions As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Integer
```

```
instance.MirrorTransferOptions = value
```

```
value = instance.MirrorTransferOptions
```

C#

```
System.int MirrorTransferOptions {get; set;}
```

C++/CLI

```
property System.int MirrorTransferOptions {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Items to transfer as defined in [swMirrorPartOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [IMirrorComponentFeatureData::MirrorTransferOptions](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false,
- and -
- [IMirrorComponentFeatureData::BreakLinksToOriginalPart](#) is false.

If not set, this property defaults to swMirrorPartOptions_e.swMirrorPartoptions_ImportSolids.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MirrorType Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : MirrorType Property (IMirrorComponentFeatureData)

Gets or sets the mirror position.

.NET Syntax

Visual Basic (Declaration)

Property MirrorType As System.Integer

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Integer

instance.MirrorType = value

value = instance.MirrorType
```

C#

```
System.int MirrorType {get; set;}
```

C++/CLI

```
property System.int MirrorType {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of mirror as defined by [swMirrorComponentMirrorType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::MirrorType](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

If not explicitly set, this property defaults to `swMirrorComponentMirrorType_e.swMirrorType_CenterOfBoundingBox`.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NameModifier Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : NameModifier Property (IMirrorComponentFeatureData)

Gets or sets the prefix or suffix to add to the file or configuration names of the components to be mirrored.

.NET Syntax

Visual Basic (Declaration)

```
Property NameModifier As System.String
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.String
```

```
instance.NameModifier = value
```

```
value = instance.NameModifier
```

C#

```
System.string NameModifier {get; set;}
```

C++/CLI

```
property System.String^ NameModifier {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Prefix or suffix text; "Mirror" by default

Visual Basic for Applications (VBA) Syntax

See [IMirrorComponentFeatureData::NameModifier](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::NameModifierType](#) is either [swMirrorComponentNameModifier_e.swMirrorComponentName_Prefix](#) or [swMirrorComponentNameModifier_e.swMirrorComponentNameName_Suffix](#),
- and -
- [IMirrorComponentFeatureData::OppositeHandComponents](#) is not Nothing or null,
- and -

- [IMirrorComponentFeatureData::MirroredComponentFileNames](#) is not Nothing or null.

If [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is:

- True, then this property prepends a prefix or appends a suffix to the configuration name of the original component to create new opposite-hand version configuration names.
- False, then this property prepends a prefix or appends a suffix to the original component file name to create new opposite-hand version file names.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NameModifierType Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : NameModifierType Property (IMirrorComponentFeatureData)

Gets or sets the type of modifier to apply to the opposite-hand version file name.

.NET Syntax

Visual Basic (Declaration)

```
Property NameModifierType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Integer  
  
instance.NameModifierType = value  
  
value = instance.NameModifierType
```

C#

```
System.int NameModifierType {get; set;}
```

C++/CLI

```
property System.int NameModifierType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of file name modifier as defined in [swMirrorComponentNameModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::NameModifierType](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::OppositeHandComponents](#) is not Nothing or null,
- and -
- [IMirrorComponentFeatureData::MirroredComponentFileNames](#) is not Nothing or null.

If this property is not set, then it defaults to `swMirrorComponentNameModifier_e.swMirrorComponentName_Prefix`.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)
[IMirrorComponentFeatureData::NameModifier Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OppositeHandComponents Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : OppositeHandComponents Property (IMirrorComponentFeatureData)

Gets or sets the array of components for which to create opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

Property OppositeHandComponents As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object
```

```
instance.OppositeHandComponents = value
```

```
value = instance.OppositeHandComponents
```

C#

```
System.object OppositeHandComponents {get; set;}
```

C++/CLI

```
property System.Object^ OppositeHandComponents {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IComponent2](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::OppositeHandComponents](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

Use [IMirrorComponentFeatureData::ComponentsToInstanceAlignToComponentOrigin](#) or [IMirrorComponentFeatureData::ComponentsToInstanceAlignToSelection](#) to create non-opposite-hand versions of selected components.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)
[IMirrorComponentFeatureData::CreateDerivedConfigurations Property \(\)](#)
[IMirrorComponentFeatureData::ReplaceFileLocations Property \(\)](#)
[IMirrorComponentFeatureData::NameModifier Property \(\)](#)
[IMirrorComponentFeatureData::NameModifierType Property \(\)](#)
[IMirrorComponentFeatureData::MirroredComponentFilenames Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PlaceFilesInOneFolder Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : PlaceFilesInOneFolder Property (IMirrorComponentFeatureData)

Gets or sets whether to place the opposite-hand versions in one folder.

.NET Syntax

Visual Basic (Declaration)

Property PlaceFilesInOneFolder As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean
```

```
instance.PlaceFilesInOneFolder = value
```

```
value = instance.PlaceFilesInOneFolder
```

C#

```
System.bool PlaceFilesInOneFolder {get; set;}
```

C++/CLI

```
property System.bool PlaceFilesInOneFolder {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to place the opposite-hand files in one folder, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::PlaceFilesInOneFolder](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PreserveZAxis Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : PreserveZAxis Property (IMirrorComponentFeatureData)

Gets or sets whether to preserve the orientation of the Z-axis in the opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

Property PreserveZAxis As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean
```

```
instance.PreserveZAxis = value
```

```
value = instance.PreserveZAxis
```

C#

```
System.bool PreserveZAxis {get; set;}
```

C++/CLI

```
property System.bool PreserveZAxis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to preserve the orientation of the Z-axis, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::PreserveZAxis](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false.

See Also

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateFromOriginalPart Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : PropagateFromOriginalPart Property (IMirrorComponentFeatureData)

Gets or sets whether to propagate visual properties from the original part to the opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFromOriginalPart As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData
Dim value As System.Boolean

instance.PropagateFromOriginalPart = value
value = instance.PropagateFromOriginalPart
```

C#

```
System.bool PropagateFromOriginalPart {get; set;}
```

C++/CLI

```
property System.bool PropagateFromOriginalPart {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate visual properties from the original part, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::PropagateFromOriginalPart](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ReleaseSelectionAccess Method (IMirrorComponentFeatureData)

Releases access to the selections used to define this mirror component feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::ReleaseSelectionAccess](#).

Remarks

[IMirrorComponentFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplaceFileLocations Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : ReplaceFileLocations Property (IMirrorComponentFeatureData)

Gets or sets the file locations of existing files that are to be replaced with new opposite-hand versions.

.NET Syntax

Visual Basic (Declaration)

```
Property ReplaceFileLocations As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Object
```

```
instance.ReplaceFileLocations = value  
value = instance.ReplaceFileLocations
```

C#

```
System.Object ReplaceFileLocations {get; set;}
```

C++/CLI

```
property System.Object^ ReplaceFileLocations {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of existing file paths

Visual Basic for Applications (VBA) Syntax

See [IMirrorComponentFeatureData::ReplaceFileLocations](#).

Example

See the [IMirrorComponentFeatureData](#) example.

Remarks

This property is valid only if:

- [IMirrorComponentFeatureData::CreateDerivedConfigurations](#) is false,
- and -
- [IMirrorComponentFeatureData::OppositeHandComponents](#) is not Nothing or null. There is a one-to-one mapping between this property's array and [IMirrorComponentFeatureData::OppositeHandComponents](#).

If this property is not set, it defaults to the current assembly's folder.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SyncFlexibleSubAssemblies Property (IMirrorComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorComponentFeatureData Interface](#) : SyncFlexibleSubAssemblies Property (IMirrorComponentFeatureData)

Gets or sets whether to synchronize the movement of mirrored components with the movement of seed components in the flexible subassembly.

.NET Syntax

Visual Basic (Declaration)

```
Property SyncFlexibleSubAssemblies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorComponentFeatureData  
Dim value As System.Boolean  
  
instance.SyncFlexibleSubAssemblies = value
```

```
value = instance.SyncFlexibleSubAssemblies
```

C#

```
System.bool SyncFlexibleSubAssemblies {get; set;}
```

C++/CLI

```
property System.bool SyncFlexibleSubAssemblies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to synchronize movements of mirrored and seed flexible subassembly components, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorComponentFeatureData::SyncFlexibleSubAssemblies](#).

Example

See the [IMirrorComponentFeatureData](#) example.

See Also

[IMirrorComponentFeatureData Interface](#)
[IMirrorComponentFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

IMirrorPartFeatureData (Type)

IMirrorPartFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorPartFeatureData Interface

Allows access to a mirror part feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMirrorPartFeatureData
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData
```

C#

```
public interface IMirrorPartFeatureData
```

C++/CLI

```
public interface class IMirrorPartFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData](#).

Example

[Get Mirror Part Information \(VBA\)](#)
[Get Mirror Part Information \(VB.NET\)](#)
[Get Mirror Part Information \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[MirrorPartFeatureData](#)

See Also

[IMirrorPartFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::MirrorPart2 Method \(\)](#)
[IMirrorSolidFeatureData Interface](#)

IMirrorPartFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorPartFeatureData Interface

For a list of all members of this type, see [IMirrorPartFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that define the mirror part feature.
GetMirrorPlane	Gets the plane about which this part is mirrored.

		
	GetMirrorPlaneType	Gets whether the mirror plane is a face or a reference plane.
	GetModelDoc	Gets the base model document of this mirror part feature.
	GetTransform	Gets the transform of this mirror part feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the mirror part feature.

[Top](#)

See Also

[IMirrorPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks.Namespace](#)
[IPartDoc::MirrorPart2 Method \(\)](#)
[IMirrorSolidFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorPartFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks.Namespace](#) : IMirrorPartFeatureData Interface

The following tables list the members exposed by [IMirrorPartFeatureData](#).

Public Properties

Name	Description
 AbsorbedSketches	Gets or sets whether to import absorbed sketches.
 Axes	Gets or sets whether to import axes.
 CoordinateSystems	Gets or sets whether to import coordinate systems.
 CosmeticThreads	Gets or sets whether to import cosmetic threads.
 CustomProperties	Gets or sets whether to import custom properties.
 CutListProperties	Gets or sets whether to import cut-list properties.
 DimXpertAnnotations	Gets or sets whether to import DimXpert annotations.
 HoleWizardData	Gets or sets whether to import hole wizard data.
 ModelDimensions	Gets or sets whether to import model dimensions.
 PathName	Gets the path and file name of the derived mirror part feature.
 Planes	Gets or sets whether to import planes.
 SheetMetalInformation	Gets or sets whether to transfer the sheet-metal and flat-pattern information from the original sheet-metal part to the mirrored part.
 SolidBodies	Gets or sets whether to import solid bodies.
 SurfaceBodies	Gets or sets whether to import surface bodies.
 UnabsorbedSketches	Gets or sets whether to import unabsorbed sketches.
 UnlockedProperties	Gets or sets whether to enable editing of the sheet-metal definition in this mirrored sheet-metal part.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror part feature.
 GetMirrorPlane	Gets the plane about which this part is mirrored.
 GetMirrorPlaneType	Gets whether the mirror plane is a face or a reference plane.
 GetModelDoc	Gets the base model document of this mirror part feature.
 GetTransform	Gets the transform of this mirror part feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the mirror part feature.

 See Also

[IMirrorPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::MirrorPart2 Method \(\)](#)
[IMirrorSolidFeatureData Interface](#)

IMirrorPartFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorPartFeatureData Interface

For a list of all members of this type, see [IMirrorPartFeatureData members](#).

 Public Properties

Name	Description
 AbsorbedSketches	Gets or sets whether to import absorbed sketches.
 Axes	Gets or sets whether to import axes.
 CoordinateSystems	Gets or sets whether to import coordinate systems.
 CosmeticThreads	Gets or sets whether to import cosmetic threads.
 CustomProperties	Gets or sets whether to import custom properties.
 CutListProperties	Gets or sets whether to import cut-list properties.
 DimXpertAnnotations	Gets or sets whether to import DimXpert annotations.
 HoleWizardData	Gets or sets whether to import hole wizard data.
 ModelDimensions	Gets or sets whether to import model dimensions.
 PathName	Gets the path and file name of the derived mirror part feature.
 Planes	Gets or sets whether to import planes.
 SheetMetalInformation	Gets or sets whether to transfer the sheet-metal and flat-pattern information from the original sheet-metal part to the mirrored part.
 SolidBodies	Gets or sets whether to import solid bodies.
 SurfaceBodies	Gets or sets whether to import surface bodies.
 UnabsorbedSketches	Gets or sets whether to import unabsorbed sketches.
 UnlockedProperties	Gets or sets whether to enable editing of the sheet-metal definition in this mirrored sheet-metal part.

 See Also

[IMirrorPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::MirrorPart2 Method \(\)](#)
[IMirrorSolidFeatureData Interface](#)

AbsorbedSketches Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : AbsorbedSketches Property (IMirrorPartFeatureData)

Gets or sets whether to import absorbed sketches.

 .NET Syntax

Visual Basic (Declaration)

Property AbsorbedSketches As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.AbsorbedSketches = value
```

```
value = instance.AbsorbedSketches
```

C#

```
System.bool AbsorbedSketches {get; set;}
```

C++/CLI

```
property System.bool AbsorbedSketches {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import absorbed sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::AbsorbedSketches](#).

See Also

[IMirrorPartFeatureData Interface](#)

[IMirrorPartFeatureData Members](#)

[IMirrorPartFeatureData::UnabsorbedSketches Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : AccessSelections Method (IMirrorPartFeatureData)

Gains access to the selections that define the mirror part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,
```

```
        Component2 Component
    )
```

C++/CLI

```
System.bool AccessSelections(
&    ModelDoc2^ TopDoc,
&    Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::AccessSelections](#).

Example

See the [IMirrorPartFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the <code>IModelDoc2</code> object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMirrorPartFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorPartFeatureData Interface](#)

[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Axes Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : Axes Property (IMirrorPartFeatureData)

Gets or sets whether to import axes.

.NET Syntax

Visual Basic (Declaration)

Property Axes As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData
Dim value As System.Boolean
```

```
instance.Axes = value  
value = instance.Axes
```

C#

```
System.bool Axes {get; set;}
```

C++/CLI

```
property System.bool Axes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import axes, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::Axes](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CoordinateSystems Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : CoordinateSystems Property (IMirrorPartFeatureData)

Gets or sets whether to import coordinate systems.

.NET Syntax

Visual Basic (Declaration)

```
Property CoordinateSystems As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.CoordinateSystems = value
```

```
value = instance.CoordinateSystems
```

C#

```
System.bool CoordinateSystems {get; set;}
```

C++/CLI

```
property System.bool CoordinateSystems {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import coordinate systems, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::CoordinateSystems](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CosmeticThreads Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : CosmeticThreads Property (IMirrorPartFeatureData)

Gets or sets whether to import cosmetic threads.

.NET Syntax

Visual Basic (Declaration)

```
Property CosmeticThreads As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.CosmeticThreads = value
```

```
value = instance.CosmeticThreads
```

C#

```
System.bool CosmeticThreads {get; set;}
```

C++/CLI

```
property System.bool CosmeticThreads {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import cosmetic threads, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::CosmeticThreads](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

CustomProperties Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : CustomProperties Property (IMirrorPartFeatureData)

Gets or sets whether to import custom properties.

.NET Syntax

Visual Basic (Declaration)

Property CustomProperties As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.CustomProperties = value
```

```
value = instance.CustomProperties
```

C#

```
System.bool CustomProperties {get; set;}
```

C++/CLI

```
property System.bool CustomProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import custom properties, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::CustomProperties](#).

Example

See the [IMirrorPartFeatureData](#) examples.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

CutListProperties Property (IMirrorPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : CutListProperties Property (IMirrorPartFeatureData)

Gets or sets whether to import cut-list properties.

.NET Syntax

Visual Basic (Declaration)

Property CutListProperties As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.CutListProperties = value
```

```
value = instance.CutListProperties
```

C#

```
System.bool CutListProperties {get; set;}
```

C++/CLI

```
property System.bool CutListProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import cut-list properties, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::CutListProperties](#).

Example

[Mirror Sheet-metal Part \(C#\)](#)
[Mirror Sheet-metal Part \(VB.NET\)](#)
[Mirror Sheet-metal Part \(VBA\)](#)

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)
[IMirrorPartFeatureData::UnlockedProperties Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DimXpertAnnotations Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : DimXpertAnnotations Property (IMirrorPartFeatureData)

Gets or sets whether to import DimXpert annotations.

.NET Syntax

Visual Basic (Declaration)

```
Property DimXpertAnnotations As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.DimXpertAnnotations = value
```

```
value = instance.DimXpertAnnotations
```

C#

```
System.bool DimXpertAnnotations {get; set;}
```

C++/CLI

```
property System.bool DimXpertAnnotations {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import DimXpert annotations, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::DimXpertAnnotations](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMirrorPlane Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : GetMirrorPlane Method (IMirrorPartFeatureData)

Gets the plane about which this part is mirrored.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMirrorPlane() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Object  
  
value = instance.GetMirrorPlane()
```

C#

```
System.object GetMirrorPlane()
```

C++/CLI

```
System.Object^ GetMirrorPlane();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRefPlane](#) or [IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::GetMirrorPlane](#).

Example

See the [IMirrorPartFeatureData](#) examples.

Remarks

Before calling this method, call [IMirrorPartFeatureData::GetMirrorPlaneType](#) to determine the type of mirror plane that this method returns.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMirrorPlaneType Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : GetMirrorPlaneType Method (IMirrorPartFeatureData)

Gets whether the mirror plane is a face or a reference plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMirrorPlaneType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Integer  
  
value = instance.GetMirrorPlaneType()
```

C#

```
System.int GetMirrorPlaneType()
```

C++/CLI

```
System.int GetMirrorPlaneType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of mirror plane as defined in [swMirrorPlaneType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::GetMirrorPlaneType](#).

Example

See the [IMirrorPartFeatureData](#) examples.

Remarks

Call this method to determine the type of mirror plane returned by [IMirrorPartFeatureData::GetMirrorPlane](#).

See Also

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModelDoc Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : GetModelDoc Method (IMirrorPartFeatureData)

Gets the base model document of this mirror part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelDoc() As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As ModelDoc2  
  
value = instance.GetModelDoc()
```

C#

```
ModelDoc2 GetModelDoc()
```

C++/CLI

```
ModelDoc2^ GetModelDoc();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IModelDoc2](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData.GetModelDoc](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : GetTransform Method (IMirrorPartFeatureData)

Gets the transform of this mirror part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTransform() As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData
Dim value As MathTransform

value = instance.GetTransform()
```

C#

```
MathTransform GetTransform()
```

C++/CLI

```
MathTransform^ GetTransform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IMathTransform](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::GetTransform](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleWizardData Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : HoleWizardData Property (IMirrorPartFeatureData)

Gets or sets whether to import hole wizard data.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleWizardData As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData
Dim value As System.Boolean

instance.HoleWizardData = value
value = instance.HoleWizardData
```

C#

```
System.bool HoleWizardData {get; set;}
```

C++/CLI

```
property System.bool HoleWizardData {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import hole wizard data, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::HoleWizardData](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ModelDimensions Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : ModelDimensions Property (IMirrorPartFeatureData)

Gets or sets whether to import model dimensions.

.NET Syntax

Visual Basic (Declaration)

```
Property ModelDimensions As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean  
  
instance.ModelDimensions = value  
  
value = instance.ModelDimensions
```

C#

```
System.bool ModelDimensions {get; set;}
```

C++/CLI

```
property System.bool ModelDimensions {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import model dimensions, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::ModelDimensions](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PathName Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : PathName Property (IMirrorPartFeatureData)

Gets the path and file name of the derived mirror part feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PathName As System.String
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.String  
  
value = instance.PathName
```

C#

```
System.string PathName {get;}
```

C++/CLI

```
property System.String^ PathName {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and file name of the derived mirror part feature

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::PathName](#).

Example

See the [IMirrorPartFeatureData](#) examples.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Planes Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : Planes Property (IMirrorPartFeatureData)

Gets or sets whether to import planes.

.NET Syntax

Visual Basic (Declaration)

```
Property Planes As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData
Dim value As System.Boolean

instance.Planes = value

value = instance.Planes
```

C#

```
System.bool Planes {get; set;}
```

C++/CLI

```
property System.bool Planes {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import planes, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::Planes](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : ReleaseSelectionAccess Method (IMirrorPartFeatureData)

Releases access to the selections used to define the mirror part feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::ReleaseSelectionAccess](#).

Example

See the [IMirrorPartFeatureData](#) examples.

Remarks

[IMirrorPartFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SheetMetalInformation Property (IMirrorPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : SheetMetalInformation Property (IMirrorPartFeatureData)

Gets or sets whether to transfer the sheet-metal and flat-pattern information from the original sheet-metal part to the mirrored part.

.NET Syntax

Visual Basic (Declaration)

Property SheetMetalInformation As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.SheetMetalInformation = value
```

```
value = instance.SheetMetalInformation
```

C#

```
System.bool SheetMetalInformation {get; set;}
```

C++/CLI

```
property System.bool SheetMetalInformation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to transfer the sheet-metal and flat-pattern information from the original sheet-metal part to the mirrored part, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::SheetMetalInformation](#).

Example

[Mirror Sheet-metal Part \(C#\)](#)
[Mirror Sheet-metal Part \(VB.NET\)](#)
[Mirror Sheet-metal Part \(VBA\)](#)

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)
[IMirrorPartFeatureData::UnlockedProperties Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SolidBodies Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : SolidBodies Property (IMirrorPartFeatureData)

Gets or sets whether to import solid bodies.

.NET Syntax

Visual Basic (Declaration)

```
Property SolidBodies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.SolidBodies = value
```

```
value = instance.SolidBodies
```

C#

```
System.bool SolidBodies {get; set;}
```

C++/CLI

```
property System.bool SolidBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import solid bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::SolidBodies](#).

Example

See the [IMirrorPartFeatureData](#) examples.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SurfaceBodies Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : SurfaceBodies Property (IMirrorPartFeatureData)

Gets or sets whether to import surface bodies.

.NET Syntax

Visual Basic (Declaration)

Property SurfaceBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.SurfaceBodies = value
```

```
value = instance.SurfaceBodies
```

C#

```
System.bool SurfaceBodies {get; set;}
```

C++/CLI

```
property System.bool SurfaceBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import surface bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::SurfaceBodies](#).

Example

See the [IMirrorPartFeatureData](#) examples.

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

UnabsorbedSketches Property (IMirrorPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : UnabsorbedSketches Property (IMirrorPartFeatureData)

Gets or sets whether to import unabsorbed sketches.

.NET Syntax

Visual Basic (Declaration)

Property UnabsorbedSketches As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.UnabsorbedSketches = value
```

```
value = instance.UnabsorbedSketches
```

C#

```
System.bool UnabsorbedSketches {get; set;}
```

C++/CLI

```
property System.bool UnabsorbedSketches {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import unabsorbed sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::UnabsorbedSketches](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)
[IMirrorPartFeatureData::AbsorbedSketches Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnlockedProperties Property (IMirrorPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPartFeatureData Interface](#) : UnlockedProperties Property (IMirrorPartFeatureData)

Gets or sets whether to enable editing of the sheet-metal definition in this mirrored sheet-metal part.

.NET Syntax

Visual Basic (Declaration)

```
Property UnlockedProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPartFeatureData  
Dim value As System.Boolean
```

```
instance.UnlockedProperties = value
```

```
value = instance.UnlockedProperties
```

C#

```
System.bool UnlockedProperties {get; set;}
```

```
property System.bool UnlockedProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable editing of the sheet-metal definition in this mirrored sheet-metal part, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPartFeatureData::UnlockedProperties](#).

Example

[Mirror Sheet-metal Part \(C#\)](#)
[Mirror Sheet-metal Part \(VB.NET\)](#)
[Mirror Sheet-metal Part \(VBA\)](#)

Remarks

[IMirrorPartFeatureData::SheetMetalInformation](#) must be true to access the sheet-metal definition of the mirrored sheet-metal part. Editing the sheet-metal definition updates [cut-list properties](#).

See Also

[IMirrorPartFeatureData Interface](#)
[IMirrorPartFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0