

SOLIDWORKS API (.NET VBA C#) — Reference

(164/337): IMiterFlangeFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IMiterFlangeFeatureData (Type)

IMiterFlangeFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMiterFlangeFeatureData Interface

Allows access to a miter flange feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMiterFlangeFeatureData
```

Visual Basic (Usage)

```
Dim instance As IMiterFlangeFeatureData
```

C#

```
public interface IMiterFlangeFeatureData
```

C++/CLI

```
public interface class IMiterFlangeFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[MiterFlangeFeatureData](#)

See Also

[IMiterFlangeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalMiterFlange Method](#)
[ISheetMetalFeatureData Interface](#)

IMiterFlangeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMiterFlangeFeatureData Interface

For a list of all members of this type, see [IMiterFlangeFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that define this miter flange feature.
GetCustomBendAllowance	Gets the custom bend allowance for this miter flange feature.

		
	IAccessSelections	Obsolete. Superseded by IMiterFlangeFeatureData.IAccessSelections2 .
	IAccessSelections2	Gains access to the selections that define this miter flange feature.
	IGetEdges	Gets the edges for this miter flange feature.
	IGetEdgesCount	Gets the number of edges for this miter flange feature.
	ISetEdges	Sets the edges for this miter flange feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the miter flange feature.
	SetCustomBendAllowance	Sets the custom bend allowance for this miter flange feature.

[Top](#)

See Also

[IMiterFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetalMiterFlange Method](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMiterFlangeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMiterFlangeFeatureData Interface

The following tables list the members exposed by [IMiterFlangeFeatureData](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius for this miter flange feature.
 Edges	Gets or sets the edges for this miter flange feature.
 EndOffset	Gets or sets the end offset for this miter flange.
 GapDistance	Gets or sets the gap distance of the tear for this miter flange feature.
 PositionType	Gets or sets the position for this miter flange feature.
 ReliefDepth	Gets or sets the relief depth for this miter flange.
 ReliefRatio	gets or sets the relief ratio for this miter flange.
 ReliefType	Gets or sets the relief type for this miter flange.
 ReliefWidth	Gets or sets the relief width for this miter flange.
 StartOffset	Gets or sets the start offset for this miter flange.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this miter flange feature.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius for this miter flange feature.
 UseDefaultBendRelief	Gets or sets whether to use the default bend relief for this miter flange feature.
 UsePositionTrimSideBends	Gets or sets whether to remove extra material in neighboring bends for this miter flange feature.
 UseReliefRatio	Gets or sets whether to use the specified relief ratio for this miter flange.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this miter flange feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this miter flange feature.
 IAccessSelections	Obsolete. Superseded by IMiterFlangeFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that define this miter flange feature.
 IGetEdges	Gets the edges for this miter flange feature.

		
	IGetEdgesCount	Gets the number of edges for this miter flange feature.
	ISetEdges	Sets the edges for this miter flange feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the miter flange feature.
	SetCustomBendAllowance	Sets the custom bend allowance for this miter flange feature.

[Top](#)

See Also

[IMiterFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetalMiterFlange Method](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMiterFlangeFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : [IMiterFlangeFeatureData Interface](#)

For a list of all members of this type, see [IMiterFlangeFeatureData members](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius for this miter flange feature.
 Edges	Gets or sets the edges for this miter flange feature.
 EndOffset	Gets or sets the end offset for this miter flange.
 GapDistance	Gets or sets the gap distance of the tear for this miter flange feature.
 PositionType	Gets or sets the position for this miter flange feature.
 ReliefDepth	Gets or sets the relief depth for this miter flange.
 ReliefRatio	gets or sets the relief ratio for this miter flange.
 ReliefType	Gets or sets the relief type for this miter flange.
 ReliefWidth	Gets or sets the relief width for this miter flange.
 StartOffset	Gets or sets the start offset for this miter flange.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this miter flange feature.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius for this miter flange feature.
 UseDefaultBendRelief	Gets or sets whether to use the default bend relief for this miter flange feature.
 UsePositionTrimSideBends	Gets or sets whether to remove extra material in neighboring bends for this miter flange feature.
 UseReliefRatio	Gets or sets whether to use the specified relief ratio for this miter flange.

[Top](#)

See Also

[IMiterFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetalMiterFlange Method](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : [AccessSelections Method \(IMiterFlangeFeatureData\)](#)

Gains access to the selections that define this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Top-level document (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IMiterFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : BendRadius Property (IMiterFlangeFeatureData)

Gets or sets the bend radius for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

Property BendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Double

instance.BendRadius = value

value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius in meters

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::BendRadius](#).

Example

See [IMiterFlangeFeatureData](#) examples.

Remarks

This property is only used when [IMiterFlangeFeatureData::UseDefaultBendRadius](#) is True.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edges Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : Edges Property (IMiterFlangeFeatureData)

Gets or sets the edges for this miter flange feature.

.NET Syntax

Property Edges As System.Object



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Object

instance.Edges = value

value = instance.Edges
```

```
System.Object Edges {get; set;}
```

```
property System.Object^ Edges {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#) defining this miter flange feature

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::Edges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::IGetEdges Method](#)
[IMiterFlangeFeatureData::IGetEdgesCount Method](#)
[IMiterFlangeFeatureData::ISetEdges Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

EndOffset Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : EndOffset Property (IMiterFlangeFeatureData)

Gets or sets the end offset for this miter flange.

.NET Syntax

Property EndOffset As System.Double



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Double

instance.EndOffset = value
```

```
value = instance.EndOffset
```

C#

```
System.double EndOffset {get; set;}
```

C++/CLI

```
property System.double EndOffset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::EndOffset](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::StartOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GapDistance Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : GapDistance Property (IMiterFlangeFeatureData)

Gets or sets the gap distance of the tear for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property GapDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Double  
  
instance.GapDistance = value  
  
value = instance.GapDistance
```

C#

```
System.double GapDistance {get; set;}
```

C++/CLI

```
property System.double GapDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in meters between edges in the miter flange

Visual Basic for Applications (VBA) Syntax

See [IMiterFlangeFeatureData::GapDistance](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : GetCustomBendAllowance Method (IMiterFlangeFeatureData)

Gets the custom bend allowance for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As CustomBendAllowance
```

```
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::GetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::SetCustomBendAllowance Method](#)
[IMiterFlangeFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : IAccessSelections Method (IMiterFlangeFeatureData)

Obsolete. Superseded by [IMiterFlangeFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::IAccessSelections](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : IAccessSelections2 Method (IMiterFlangeFeatureData)

Gains access to the selections that define this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Top-level document (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData.IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMiterFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : IGetEdges Method (IMiterFlangeFeatureData)

Gets the edges for this miter flange feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Object  
  
value = instance.IGetEdges()
```

C#

```
System.object IGetEdges()
```

C++/CLI

```
System.Object^ IGetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) used to define the miter flange feature
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::IGetEdgesCount Method](#)
[IMiterFlangeFeatureData::ISetEdges Method](#)
[IMiterFlangeFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdgesCount Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : IGetEdgesCount Method (IMiterFlangeFeatureData)

Gets the number of edges for this miter flange feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetEdgesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.IGetEdgesCount()
```

C#

```
System.int IGetEdgesCount()
```

C++/CLI

```
System.int IGetEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges used to define the miter flange feature

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::IGetEdgesCount](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::IGetEdges Method](#)
[IMiterFlangeFeatureData::ISetEdges Method](#)
[IMiterFlangeFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEdges Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ISetEdges Method (IMiterFlangeFeatureData)

Sets the edges for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal EdgeCount As System.Integer, _  
    ByRef EdgeArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim EdgeCount As System.Integer  
Dim EdgeArray As System.Object  
  
instance.ISetEdges(EdgeCount, EdgeArray)
```

C#

```
void ISetEdges(  
    System.int EdgeCount,  
    ref System.object EdgeArray  
)
```

C++/CLI

```
void ISetEdges(  
& System.int EdgeCount,  
& System.Object^% EdgeArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount

Number of edges

EdgeArray

- in-process, unmanaged C++: Pointer to an array of [edges](#) used to define the miter flange feature

- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::IGetEdges Method](#)
[IMiterFlangeFeatureData::IGetEdgesCount Method](#)
[IMiterFlangeFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionType Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : PositionType Property (IMiterFlangeFeatureData)

Gets or sets the position for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

Property PositionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Integer
```

```
instance.PositionType = value
```

```
value = instance.PositionType
```

C#

```
System.int PositionType {get; set;}
```

C++/CLI

```
property System.int PositionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of position for this mitre flange feature as defined by [swFlangePositionTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::PositionType](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ReleaseSelectionAccess Method (IMiterFlangeFeatureData)

Releases access to the selections used to define the miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::ReleaseSelectionAccess](#).

Remarks

[IMiterFlangeFeatureData::AccessSelections](#) and [IMiterFlangeFeatureData::IAccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#) if you did.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefDepth Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ReliefDepth Property (IMiterFlangeFeatureData)

Gets or sets the relief depth for this miter flange.

.NET Syntax

Visual Basic (Declaration)

Property ReliefDepth As System.Double

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Double

instance.ReliefDepth = value

value = instance.ReliefDepth
```

C#

```
System.double ReliefDepth {get; set;}
```

C++/CLI

```
property System.double ReliefDepth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief depth of this miter flange

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::ReliefDepth](#).

Remarks

SOLIDWORKS uses this property with [IMiterFlangeFeatureData::ReliefWidth](#) only if [IMiterMiterFlangeFeatureData::UseReliefRatio](#) is false. If [IMiterMiterFlangeFeatureData::UseReliefRatio](#) is True, then SOLIDWORKS uses [IMiterMiterFlangeFeatureData::ReliefRatio](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::ReliefType Property](#)
[IMiterFlangeFeatureData::UseDefaultBendRelief Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ReliefRatio Property (IMiterFlangeFeatureData)

gets or sets the relief ratio for this miter flange.

.NET Syntax

Visual Basic (Declaration)

Property ReliefRatio As System.Double

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Double

instance.ReliefRatio = value
```

```
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief ratio for rectangular or obround miter flanges

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::ReliefRatio](#).

Remarks

SOLIDWORKS uses this property only if [IMiterMiterFlangeFeatureData::UseReliefRatio](#) is True. If IMiterMiterFlangeFeatureData::UseReliefRatio is false, then SOLIDWORKS uses [IMiterFlangeFeatureData::ReliefDepth](#) with [IMiterFlangeFeatureData::ReliefWidth](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::ReliefType Property](#)
[IMiterFlangeFeatureData::UseDefaultBendRelief Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefType Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ReliefType Property (IMiterFlangeFeatureData)

Gets or sets the relief type for this miter flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Integer
```

```
instance.ReliefType = value
```

```
value = instance.ReliefType
```

C#

```
System.int ReliefType {get; set;}
```

C++/CLI

```
property System.int ReliefType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief type as defined in [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::ReliefType](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::ReliefDepth Property](#)
[IMiterFlangeFeatureData::ReliefRatio Property](#)
[IMiterFlangeFeatureData::ReliefWidth Property](#)
[IMiterFlangeFeatureData::UseReliefRatio Property](#)
[IMiterFlangeFeatureData::UseDefaultBendRelief Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefWidth Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : ReliefWidth Property (IMiterFlangeFeatureData)

Gets or sets the relief width for this miter flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Double
```

```
instance.ReliefWidth = value
```

```
value = instance.ReliefWidth
```

C#

```
System.double ReliefWidth {get; set;}
```

C++/CLI

```
property System.double ReliefWidth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief width for this miter flange

Visual Basic for Applications (VBA) Syntax

See [IMiterFlangeFeatureData::ReliefWidth](#).

Remarks

SOLIDWORKS uses this property with [IMiterFlangeFeatureData::ReliefDepth](#) only if [IMiterMiterFlangeFeatureData::UseReliefRatio](#) is false. If [IMiterMiterFlangeFeatureData::UseReliefRatio](#) is True, then SOLIDWORKS uses [IMiterMiterFlangeFeatureData::ReliefRatio](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::ReliefType Property](#)
[IMiterFlangeFeatureData::UseDefaultBendRelief Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetCustomBendAllowance Method (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : SetCustomBendAllowance Method (IMiterFlangeFeatureData)

Sets the custom bend allowance for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance(  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData
[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData.SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::GetCustomBendAllowance Method](#)
[IMiterFlangeFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartOffset Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : StartOffset Property (IMiterFlangeFeatureData)

Gets or sets the start offset for this miter flange.

.NET Syntax

Visual Basic (Declaration)

```
Property StartOffset As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Double  
  
instance.StartOffset = value  
  
value = instance.StartOffset
```

C#

```
System.double StartOffset {get; set;}
```

C++/CLI

```
property System.double StartOffset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start offset for this miter flange

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::StartOffset](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeautreData::EndOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : UseDefaultBendAllowance Property (IMiterFlangeFeatureData)

Gets or sets whether to use the default bend allowance for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData
Dim value As System.Boolean

instance.UseDefaultBendAllowance = value

value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend allowance, false to not

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::UseDefaultBendAllowance](#).

Example

See [IMiterFlangeFeatureData](#) examples.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::GetCustomBendAllowance Method](#)
[IMiterFlangeFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseDefaultBendRadius Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : UseDefaultBendRadius Property (IMiterFlangeFeatureData)

Gets or sets whether to use the default bend radius for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRadius = value
```

```
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend radius, false to use specified bend radius

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::UseDefaultBendRadius](#).

Example

See [IMiterFlangeFeatureData](#) examples.

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::BendRadius Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseDefaultBendRelief Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : UseDefaultBendRelief Property (IMiterFlangeFeatureData)

Gets or sets whether to use the default bend relief for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendRelief As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRelief = value
```

```
value = instance.UseDefaultBendRelief
```

C#

```
System.bool UseDefaultBendRelief {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRelief {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend relief, false to not

Visual Basic for Applications (VBA) Syntax

See [MiterFlangeFeatureData::UseDefaultBendRelief](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::ReliefDepth Property](#)
[IMiterFlangeFeatureData::ReliefRatio Property](#)
[IMiterFlangeFeatureData::ReliefRatio Property](#)
[IMiterFlangeFeatureData::ReliefType Property](#)
[IMiterFlangeFeatureData::ReliefWidth Property](#)
[IMiterFlangeFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UsePositionTrimSideBends Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : UsePositionTrimSideBends Property (IMiterFlangeFeatureData)

Gets or sets whether to remove extra material in neighboring bends for this miter flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UsePositionTrimSideBends As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Boolean  
  
instance.UsePositionTrimSideBends = value  
  
value = instance.UsePositionTrimSideBends
```

C#

```
System.bool UsePositionTrimSideBends {get; set;}
```

C++/CLI

```
property System.bool UsePositionTrimSideBends {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to remove extra material in neighboring bends, false to not remove material

Visual Basic for Applications (VBA) Syntax

See [IMiterFlangeFeatureData::UsePositionTrimSideBends](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseReliefRatio Property (IMiterFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMiterFlangeFeatureData Interface](#) : UseReliefRatio Property (IMiterFlangeFeatureData)

Gets or sets whether to use the specified relief ratio for this miter flange.

.NET Syntax

Visual Basic (Declaration)

Property UseReliefRatio As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMiterFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseReliefRatio = value
```

```
value = instance.UseReliefRatio
```

C#

```
System.bool UseReliefRatio {get; set;}
```

C++/CLI

```
property System.bool UseReliefRatio {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the specified relief ratio, false to not

Visual Basic for Applications (VBA) Syntax

See [IMiterFlangeFeatureData::UseReliefRatio](#).

Remarks

If this property is True, SOLIDWORKS uses [IMiterMiterFlangeFeatureData::ReliefRatio](#). If it is false, SOLIDWORKS uses [IMiterFlangeFeatureData::ReliefDepth](#) and [IMiterFlangeFeatureData::ReliefWidth](#).

See Also

[IMiterFlangeFeatureData Interface](#)
[IMiterFlangeFeatureData Members](#)
[IMiterFlangeFeatureData::UseDefaultBendRelief Property](#)
[IMiterFlangeFeatureData::ReliefType Property](#)

