

SOLIDWORKS API (.NET VBA C#) — Reference (166/337): IModelDoc (part 2 of 13)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc (part 2 of 13) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ActivateFeatureMgrView Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ActivateFeatureMgrView Method (IModelDoc)

Obsolete. Superseded by [IFeatureMgrView::ActivateView](#) or [IModelDocExtension::ActivateFeatureMgrViewx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

.NET Syntax

Visual Basic (Declaration)

```
Function ActivateFeatureMgrView(  
    ByRef AppView As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim AppView As System.Integer  
Dim value As System.Integer  
  
value = instance.ActivateFeatureMgrView(AppView)
```

C#

```
System.int ActivateFeatureMgrView(  
    ref System.int AppView  
)
```

C++/CLI

```
System.int ActivateFeatureMgrView(  
& System.int% AppView  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppView

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ActivateFeatureMgrView](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ActivateSelectedFeature Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ActivateSelectedFeature Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ActivateSelectedFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ActivateSelectedFeature()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.ActivateSelectedFeature()
```

C#

```
void ActivateSelectedFeature()
```

C++/CLI

```
void ActivateSelectedFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ActivateSelectedFeature](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ActiveView Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ActiveView Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ActiveView](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property ActiveView As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Object  
  
instance.ActiveView = value  
  
value = instance.ActiveView
```

C#

```
System.object ActiveView {get; set;}
```

C++/CLI

```
property System.Object^ ActiveView {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ActiveView](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddConfiguration Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddConfiguration Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddConfiguration](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AddConfiguration( _  
    ByVal Name As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal SuppressByDefault As System.Boolean, _  
    ByVal HideByDefault As System.Boolean, _  
    ByVal MinFeatureManager As System.Boolean, _  
    ByVal InheritProperties As System.Boolean, _  
    ByVal Flags As System.UInteger _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Name As System.String  
Dim Comment As System.String  
Dim AlternateName As System.String  
Dim SuppressByDefault As System.Boolean  
Dim HideByDefault As System.Boolean  
Dim MinFeatureManager As System.Boolean  
Dim InheritProperties As System.Boolean  
Dim Flags As System.UInteger
```

```
instance.AddConfiguration(Name, Comment, AlternateName, SuppressByDefault, HideByDefault,  
MinFeatureManager, InheritProperties, Flags)
```

C#

```
void AddConfiguration(  
    System.string Name,  
    System.string Comment,  
    System.string AlternateName,  
    System.bool SuppressByDefault,  
    System.bool HideByDefault,  
    System.bool MinFeatureManager,  
    System.bool InheritProperties,  
    System.uint Flags  
)
```

C++/CLI

```
void AddConfiguration(  
& System.String^ Name,  
& System.String^ Comment,
```

```

& System.String^ AlternateName,
& System.bool SuppressByDefault,
& System.bool HideByDefault,
& System.bool MinFeatureManager,
& System.bool InheritProperties,
& System.uint Flags
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Comment

AlternateName

SuppressByDefault

HideByDefault

MinFeatureManager

InheritProperties

Flags

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddConfiguration](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddConfiguration2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddConfiguration2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddConfiguration2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function AddConfiguration2( _
    ByVal Name As System.String, _
    ByVal Comment As System.String, _
    ByVal AlternateName As System.String, _
    ByVal SuppressByDefault As System.Boolean, _
    ByVal HideByDefault As System.Boolean, _
    ByVal MinFeatureManager As System.Boolean, _
    ByVal InheritProperties As System.Boolean, _
    ByVal Flags As System.UInteger _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As IModelDoc
Dim Name As System.String
Dim Comment As System.String
Dim AlternateName As System.String
Dim SuppressByDefault As System.Boolean
Dim HideByDefault As System.Boolean
Dim MinFeatureManager As System.Boolean
Dim InheritProperties As System.Boolean
Dim Flags As System.UInteger
Dim value As System.Boolean

```



```
value = instance.AddConfiguration2(Name, Comment, AlternateName, SuppressByDefault, HideByDefault, MinFeatureManager, InheritProperties, Flags)
```

C#

```
System.bool AddConfiguration2(  
    System.string Name,  
    System.string Comment,  
    System.string AlternateName,  
    System.bool SuppressByDefault,  
    System.bool HideByDefault,  
    System.bool MinFeatureManager,  
    System.bool InheritProperties,  
    System.uint Flags  
)
```

C++/CLI

```
System.bool AddConfiguration2(  
& System.String^ Name,  
& System.String^ Comment,  
& System.String^ AlternateName,  
& System.bool SuppressByDefault,  
& System.bool HideByDefault,  
& System.bool MinFeatureManager,  
& System.bool InheritProperties,  
& System.uint Flags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Comment

AlternateName

SuppressByDefault

HideByDefault

MinFeatureManager

InheritProperties

Flags

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddConfiguration2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddCustomInfo Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddCustomInfo Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddCustomInfo](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddCustomInfo( _
    ByVal FieldName As System.String, _
    ByVal FieldType As System.String, _
    ByVal FieldValue As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim FieldName As System.String
Dim FieldType As System.String
Dim FieldValue As System.String
Dim value As System.Boolean
```

```
value = instance.AddCustomInfo(FieldName, FieldType, FieldValue)
```

C#

```
System.bool AddCustomInfo(
    System.string FieldName,
    System.string FieldType,
    System.string FieldValue
)
```

C++/CLI

```
System.bool AddCustomInfo(
    & System.String^ FieldName,
    & System.String^ FieldType,
    & System.String^ FieldValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

FieldType

FieldValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddCustomInfo](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddCustomInfo2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddCustomInfo2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddCustomInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddCustomInfo2( _
    ByVal FieldName As System.String, _
    ByVal FieldType As System.Integer, _
    ByVal FieldValue As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc
Dim fieldName As System.String
Dim fieldType As System.Integer
Dim fieldValue As System.String
Dim value As System.Boolean

value = instance.AddCustomInfo2(fieldName, fieldType, fieldValue)
```

C#

```
System.bool AddCustomInfo2(
    System.string fieldName,
    System.int fieldType,
    System.string fieldValue
)
```

C++/CLI

```
System.bool AddCustomInfo2(
    & System.String^ fieldName,
    & System.int fieldType,
    & System.String^ fieldValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

fieldName

fieldType

fieldValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddCustomInfo2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddCustomInfo3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddCustomInfo3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddCustomInfo3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddCustomInfo3( _
    ByVal configuration As System.String, _
    ByVal fieldName As System.String, _
    ByVal fieldType As System.Integer, _
    ByVal fieldValue As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc
Dim configuration As System.String
Dim fieldName As System.String
Dim fieldType As System.Integer
```



```
Dim FieldValue As System.String
Dim value As System.Boolean

value = instance.AddCustomInfo3(Configuration, FieldName, FieldType, FieldValue)
```

C#

```
System.bool AddCustomInfo3(
    System.string Configuration,
    System.string FieldName,
    System.int FieldType,
    System.string FieldValue
)
```

C++/CLI

```
System.bool AddCustomInfo3(
    & System.String^ Configuration,
    & System.String^ FieldName,
    & System.int FieldType,
    & System.String^ FieldValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

FieldName

FieldType

FieldValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddCustomInfo3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddDiameterDimension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddDiameterDimension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddDiameterDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddDiameterDimension( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean
```

```
value = instance.AddDiameterDimension(X, Y, Z)
```

C#

```
System.bool AddDiameterDimension(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool AddDiameterDimension(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddDiameterDimension](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddDiameterDimension2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddDiameterDimension2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddDiameterDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddDiameterDimension2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object
```

```
value = instance.AddDiameterDimension2(X, Y, Z)
```

C#

```
System.object AddDiameterDimension2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```



C++/CLI

```
System.Object^ AddDiameterDimension2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddDiameterDimension2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddDimension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddDimension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddDimension( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.AddDimension(X, Y, Z)
```

C#

```
System.bool AddDimension(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool AddDimension(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddDimension](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddDimension2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddDimension2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddDimension2(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.AddDimension2(X, Y, Z)
```

C#

```
System.object AddDimension2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ AddDimension2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddDimension2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddFeatureMgrView Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddFeatureMgrView Method (IModelDoc)

Obsolete. Superseded by [IModelDocExtension::AddFeatureMgrView3x64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

.NET Syntax

Visual Basic (Declaration)

```
Function AddFeatureMgrView( _  
    ByRef Bitmap As System.Integer, _  
    ByRef AppView As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Bitmap As System.Integer  
Dim AppView As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddFeatureMgrView(Bitmap, AppView)
```

C#

```
System.bool AddFeatureMgrView(  
    ref System.int Bitmap,  
    ref System.int AppView  
)
```

C++/CLI

```
System.bool AddFeatureMgrView(  
& System.int% Bitmap,  
& System.int% AppView  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bitmap

AppView

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddFeatureMgrView](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddFeatureMgrView2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddFeatureMgrView2 Method (IModelDoc)

Obsolete. Superseded by [IModelDocExtension::AddFeatureMgrView3x64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

.NET Syntax

Visual Basic (Declaration)

```
Function AddFeatureMgrView2( _  
    ByRef Bitmap As System.Integer, _  
    ByRef AppView As System.Integer, _  
    ByVal ToolTip As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Bitmap As System.Integer  
Dim AppView As System.Integer  
Dim ToolTip As System.String  
Dim value As System.Boolean  
  
value = instance.AddFeatureMgrView2(Bitmap, AppView, ToolTip)
```

C#

```
System.bool AddFeatureMgrView2(  
    ref System.int Bitmap,  
    ref System.int AppView,  
    System.string ToolTip  
)
```

C++/CLI

```
System.bool AddFeatureMgrView2(  
& System.int% Bitmap,  
& System.int% AppView,  
& System.String^ ToolTip  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bitmap

AppView

ToolTip

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddFeatureMgrView2](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddFeatureMgrView3 Method (IModelDoc)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IModelDoc Interface](#) : AddFeatureMgrView3 Method (IModelDoc)

Obsolete. Superseded by [IModelDocExtension::AddFeatureMgrView3x64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

.NET Syntax

Visual Basic (Declaration)

```
Function AddFeatureMgrView3( _  
    ByRef Bitmap As System.Integer, _  
    ByRef AppView As System.Integer, _  
    ByVal ToolTip As System.String, _  
    ByVal WhichPane As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Bitmap As System.Integer  
Dim AppView As System.Integer  
Dim ToolTip As System.String  
Dim WhichPane As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddFeatureMgrView3(Bitmap, AppView, ToolTip, WhichPane)
```

C#

```
System.bool AddFeatureMgrView3(  
    ref System.int Bitmap,  
    ref System.int AppView,  
    System.string ToolTip,  
    System.int WhichPane  
)
```

C++/CLI

```
System.bool AddFeatureMgrView3(  
& System.int% Bitmap,  
& System.int% AppView,  
& System.String^ ToolTip,  
& System.int WhichPane  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bitmap

AppView

ToolTip

WhichPane

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddFeatureMgrView3](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddHorizontalDimension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddHorizontalDimension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddHorizontalDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddHorizontalDimension( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.AddHorizontalDimension(X, Y, Z)
```

C#

```
System.bool AddHorizontalDimension(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool AddHorizontalDimension(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddHorizontalDimension](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddHorizontalDimension2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddHorizontalDimension2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddHorizontalDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddHorizontalDimension2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.AddHorizontalDimension2(X, Y, Z)
```

C#

```
System.object AddHorizontalDimension2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ AddHorizontalDimension2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddHorizontalDimension2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddIns Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddIns Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddIns](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AddIns()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.AddIns()
```

C#

```
void AddIns()
```

C++/CLI

```
void AddIns();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddIns](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddLightSource Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddLightSource Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddLightSource](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddLightSource( _  
    ByVal IdName As System.String, _  
    ByVal LTyp As System.Integer, _  
    ByVal UserName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim IdName As System.String  
Dim LTyp As System.Integer  
Dim UserName As System.String
```

```
Dim value As System.Boolean

value = instance.AddLightSource(IdName, LTyp, UserName)
```

C#

```
System.bool AddLightSource(
    System.string IdName,
    System.int LTyp,
    System.string UserName
)
```

C++/CLI

```
System.bool AddLightSource(
    & System.String^ IdName,
    & System.int LTyp,
    & System.String^ UserName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdName

LTyp

UserName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddLightSource](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddLightSourceExtProperty Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddLightSourceExtProperty Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddLightSourceExtProperty](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddLightSourceExtProperty( _
    ByVal ID As System.Integer, _
    ByVal PropertyExtension As System.Object _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc
Dim ID As System.Integer
Dim PropertyExtension As System.Object
Dim value As System.Integer

value = instance.AddLightSourceExtProperty(ID, PropertyExtension)
```

C#



```
System.int AddLightSourceExtProperty(  
    System.int ID,  
    System.object PropertyExtension  
)
```

C++/CLI

```
System.int AddLightSourceExtProperty(  
& System.int ID,  
& System.Object^ PropertyExtension  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

PropertyExtension

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddLightSourceExtProperty](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddLightToScene Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddLightToScene Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddLightToScene](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddLightToScene( _  
    ByVal LpszNewValue As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim LpszNewValue As System.String  
Dim value As System.Integer  
  
value = instance.AddLightToScene(LpszNewValue)
```

C#

```
System.int AddLightToScene(  
    System.string LpszNewValue  
)
```

C++/CLI

```
System.int AddLightToScene(  
& System.String^ LpszNewValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpszNewValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddLightToScene](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddPropertyExtension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddPropertyExtension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddPropertyExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddPropertyExtension( _  
    ByVal PropertyExtension As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim PropertyExtension As System.Object  
Dim value As System.Integer
```

```
value = instance.AddPropertyExtension(PropertyExtension)
```

C#

```
System.int AddPropertyExtension(  
    System.object PropertyExtension  
)
```

C++/CLI

```
System.int AddPropertyExtension(  
& System.Object^ PropertyExtension  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyExtension

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddPropertyExtension](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddRadialDimension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddRadialDimension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddRadialDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddRadialDimension( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.AddRadialDimension(X, Y, Z)
```

C#

```
System.bool AddRadialDimension(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool AddRadialDimension(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddRadialDimension](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddRadialDimension2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddRadialDimension2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddRadialDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddRadialDimension2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _
```

```
ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.AddRadialDimension2(X, Y, Z)
```

C#

```
System.object AddRadialDimension2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ AddRadialDimension2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddRadialDimension2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddRelation Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddRelation Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddRelation](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AddRelation( _  
    ByVal RelStr As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim RelStr As System.String  
  
instance.AddRelation(RelStr)
```

C#

```
void AddRelation(  
    System.string RelStr  
)
```

C++/CLI

```
void AddRelation(  
& System.String^ RelStr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RelStr

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddRelation](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddSceneExtProperty Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddSceneExtProperty Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddSceneExtProperty](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddSceneExtProperty( _  
    ByVal PropertyExtension As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim PropertyExtension As System.Object  
Dim value As System.Integer  
  
value = instance.AddSceneExtProperty(PropertyExtension)
```

C#

```
System.int AddSceneExtProperty(  
    System.object PropertyExtension  
)
```

C++/CLI

```
System.int AddSceneExtProperty(  
& System.Object^ PropertyExtension  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyExtension

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddSceneExtProperty](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddVerticalDimension Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddVerticalDimension Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddVerticalDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddVerticalDimension( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.AddVerticalDimension(X, Y, Z)
```

C#

```
System.bool AddVerticalDimension(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool AddVerticalDimension(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::AddVerticalDimension](#).

See Also

AddVerticalDimension2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AddVerticalDimension2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AddVerticalDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddVerticalDimension2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.AddVerticalDimension2(X, Y, Z)
```

C#

```
System.Object AddVerticalDimension2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ AddVerticalDimension2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AddVerticalDimension2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

AlignDimensions Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AlignDimensions Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AlignDimensions](#).

 **.NET Syntax**

Visual Basic (Declaration)

Sub AlignDimensions()

Visual Basic (Usage)  Copy Code

Dim instance As [IModelDoc](#)

instance.AlignDimensions()

C#

void AlignDimensions()

C++/CLI

void AlignDimensions();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 **Visual Basic for Applications (VBA) Syntax**

See [ModelDoc::AlignDimensions](#).

 **See Also**

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help Send comments on this topic.

AlignOrdinate Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AlignOrdinate Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AlignOrdinate](#).

 **.NET Syntax**

Visual Basic (Declaration)

Sub Align0rdinate()

Visual Basic (Usage)  Copy Code

Dim instance As [IModelDoc](#)

instance.Align0rdinate()

C#

void Align0rdinate()

C++/CLI

void Align0rdinate();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 **Visual Basic for Applications (VBA) Syntax**

See [ModelDoc::AlignOrdinate](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AlignParallelDimensions Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AlignParallelDimensions Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AlignParallelDimensions](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AlignParallelDimensions()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.AlignParallelDimensions()
```

C#

```
void AlignParallelDimensions()
```

C++/CLI

```
void AlignParallelDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AlignParallelDimensions](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AndSelect Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AndSelect Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AndSelect](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AndSelect( _  
    ByVal SelID As System.String, _  
    ByVal SelParams As System.String, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim SelID As System.String
```

```
Dim SelParams As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double

instance.AndSelect(SelID, SelParams, X, Y, Z)
```

C#

```
void AndSelect(
    System.string SelID,
    System.string SelParams,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
void AndSelect(
    & System.String^ SelID,
    & System.String^ SelParams,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2.AndSelect](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AndSelectByID Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AndSelectByID Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2.AndSelectByID](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AndSelectByID( _
    ByVal SelID As System.String, _
    ByVal SelParams As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

Copy Code

```

Dim instance As IModelDoc
Dim SelID As System.String
Dim SelParams As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean

value = instance.AndSelectByID(SelID, SelParams, X, Y, Z)

```

C#

```

System.bool AndSelectByID(
    System.string SelID,
    System.string SelParams,
    System.double X,
    System.double Y,
    System.double Z
)

```

C++/CLI

```

System.bool AndSelectByID(
    & System.String^ SelID,
    & System.String^ SelParams,
    & System.double X,
    & System.double Y,
    & System.double Z
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AndSelectByID](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AndSelectByMark Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AndSelectByMark Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AndSelectByMark](#).

.NET Syntax

Visual Basic (Declaration)

```

Function AndSelectByMark(
    ByVal SelID As System.String, _
    ByVal SelParams As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
)

```

```
ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim SelID As System.String  
Dim SelParams As System.String  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.AndSelectByMark(SelID, SelParams, X, Y, Z, Mark)
```

C#

```
System.bool AndSelectByMark(  
    System.string SelID,  
    System.string SelParams,  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.int Mark  
)
```

C++/CLI

```
System.bool AndSelectByMark(  
& System.String^ SelID,  
& System.String^ SelParams,  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Mark

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AndSelectByMark](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AutoInferToggle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AutoInferToggle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AutoInferToggle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AutoInferToggle()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.AutoInferToggle()
```

C#

```
void AutoInferToggle()
```

C++/CLI

```
void AutoInferToggle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AutoInferToggle](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AutoSolveToggle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : AutoSolveToggle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::AutoSolveToggle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AutoSolveToggle()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.AutoSolveToggle()
```

C#

```
void AutoSolveToggle()
```

C++/CLI

```
void AutoSolveToggle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::AutoSolveToggle](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

BlankRefGeom Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : BlankRefGeom Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::BlankRefGeom](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BlankRefGeom()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.BlankRefGeom()
```

C#

```
void BlankRefGeom()
```

C++/CLI

```
void BlankRefGeom();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::BlankRefGeom](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

BlankSketch Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : BlankSketch Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::BlankSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BlankSketch()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.BlankSketch()
```

C#

```
void BlankSketch()
```

C++/CLI

```
void BlankSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::BlankSketch](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BreakAllExternalReferences Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : BreakAllExternalReferences Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::BreakAllExternalReferences](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakAllExternalReferences()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.BreakAllExternalReferences()
```

C#

```
void BreakAllExternalReferences()
```

C++/CLI

```
void BreakAllExternalReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::BreakAllExternalReferences](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BreakDimensionAlignment Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : BreakDimensionAlignment Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::BreakDimensionAlignment](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakDimensionAlignment()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.BreakDimensionAlignment()
```

C#

```
void BreakDimensionAlignment()
```

C++/CLI

```
void BreakDimensionAlignment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::BreakDimensionAlignment](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ChangeSketchPlane Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ChangeSketchPlane Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ChangeSketchPlane](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ChangeSketchPlane() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Boolean

value = instance.ChangeSketchPlane()
```

C#

```
System.bool ChangeSketchPlane()
```

C++/CLI

```
System.bool ChangeSketchPlane();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ChangeSketchPlane](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ClearSelection Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ClearSelection Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ClearSelection](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ClearSelection()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.ClearSelection()
```

C#

```
void ClearSelection()
```

C++/CLI

```
void ClearSelection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ClearSelection](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ClearUndoList Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ClearUndoList Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ClearUndoList](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ClearUndoList()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.ClearUndoList()
```

C#

```
void ClearUndoList()
```

C++/CLI

```
void ClearUndoList();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ClearUndoList](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

Close Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Close Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Close](#).

.NET Syntax

Visual Basic (Declaration)

Sub Close()

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.Close()
```

C#

```
void Close()
```

C++/CLI

```
void Close();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Close](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

CloseFamilyTable Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CloseFamilyTable Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CloseFamilyTable](#).

.NET Syntax

Visual Basic (Declaration)

Sub CloseFamilyTable()

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.CloseFamilyTable()
```

C#

```
void CloseFamilyTable()
```

C++/CLI

```
void CloseFamilyTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CloseFamilyTable](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ClosePrintPreview Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ClosePrintPreview Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ClosePrintPreview](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ClosePrintPreview()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.ClosePrintPreview()
```

C#

```
void ClosePrintPreview()
```

C++/CLI

```
void ClosePrintPreview();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ClosePrintPreview](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Create3PointArc Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Create3PointArc Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Create3PointArc](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Create3PointArc( _  
    ByVal P1x As System.Double, _  
    ByVal P1y As System.Double, _  
    ByVal P1z As System.Double, _  
    ByVal P2x As System.Double, _  
    ByVal P2y As System.Double, _  
    ByVal P2z As System.Double, _  
    ByVal P3x As System.Double, _
```

```

        ByVal P3y As System.Double, _
        ByVal P3z As System.Double _
    ) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim P1x As System.Double
Dim P1y As System.Double
Dim P1z As System.Double
Dim P2x As System.Double
Dim P2y As System.Double
Dim P2z As System.Double
Dim P3x As System.Double
Dim P3y As System.Double
Dim P3z As System.Double
Dim value As System.Boolean

```

```

value = instance.Create3PointArc(P1x, P1y, P1z, P2x, P2y, P2z, P3x, P3y, P3z)

```

C#

```

System.bool Create3PointArc(
    System.double P1x,
    System.double P1y,
    System.double P1z,
    System.double P2x,
    System.double P2y,
    System.double P2z,
    System.double P3x,
    System.double P3y,
    System.double P3z
)

```

C++/CLI

```

System.bool Create3PointArc(
    & System.double P1x,
    & System.double P1y,
    & System.double P1z,
    & System.double P2x,
    & System.double P2y,
    & System.double P2z,
    & System.double P3x,
    & System.double P3y,
    & System.double P3z
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1x

P1y

P1z

P2x

P2y

P2z

P3x

P3y

P3z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Create3PointArc](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateArc Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateArc Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateArc](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function CreateArc( _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal Dir As System.Short _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim Dir As System.Short  
Dim value As System.Boolean  
  
value = instance.CreateArc(P1, P2, P3, Dir)
```

C#

```
System.bool CreateArc(  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.short Dir  
)
```

C++/CLI

```
System.bool CreateArc(  
& System.Object^ P1,  
& System.Object^ P2,  
& System.Object^ P3,  
& System.short Dir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1

P2

P3

Dir

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateArc](#).

See Also

CreateArc2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateArc2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateArc2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateArc2( _  
    ByVal XC As System.Double, _  
    ByVal YC As System.Double, _  
    ByVal Zc As System.Double, _  
    ByVal Xp1 As System.Double, _  
    ByVal Yp1 As System.Double, _  
    ByVal Zp1 As System.Double, _  
    ByVal Xp2 As System.Double, _  
    ByVal Yp2 As System.Double, _  
    ByVal Zp2 As System.Double, _  
    ByVal Direction As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim XC As System.Double  
Dim YC As System.Double  
Dim Zc As System.Double  
Dim Xp1 As System.Double  
Dim Yp1 As System.Double  
Dim Zp1 As System.Double  
Dim Xp2 As System.Double  
Dim Yp2 As System.Double  
Dim Zp2 As System.Double  
Dim Direction As System.Short  
Dim value As System.Object
```

```
value = instance.CreateArc2(XC, YC, Zc, Xp1, Yp1, Zp1, Xp2, Yp2, Zp2, Direction)
```

C#

```
System.Object CreateArc2(  
    System.double XC,  
    System.double YC,  
    System.double Zc,  
    System.double Xp1,  
    System.double Yp1,  
    System.double Zp1,  
    System.double Xp2,  
    System.double Yp2,  
    System.double Zp2,  
    System.short Direction  
)
```

C++/CLI

```
System.Object^ CreateArc2(  
& System.double XC,  
& System.double YC,  
& System.double Zc,  
& System.double Xp1,  
& System.double Yp1,  
& System.double Zp1,  
& System.double Xp2,
```

```
& System.double Yp2,  
& System.double Zp2,  
& System.short Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XC

YC

Zc

Xp1

Yp1

Zp1

Xp2

Yp2

Zp2

Direction

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateArc2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateArcByCenter Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateArcByCenter Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateArcByCenter](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateArcByCenter( _  
    ByVal P1x As System.Double, _  
    ByVal P1y As System.Double, _  
    ByVal P1z As System.Double, _  
    ByVal P2x As System.Double, _  
    ByVal P2y As System.Double, _  
    ByVal P2z As System.Double, _  
    ByVal P3x As System.Double, _  
    ByVal P3y As System.Double, _  
    ByVal P3z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim P1x As System.Double  
Dim P1y As System.Double  
Dim P1z As System.Double  
Dim P2x As System.Double  
Dim P2y As System.Double  
Dim P2z As System.Double  
Dim P3x As System.Double  
Dim P3y As System.Double  
Dim P3z As System.Double  
Dim value As System.Boolean
```

```
value = instance.CreateArcByCenter(P1x, P1y, P1z, P2x, P2y, P2z, P3x, P3y, P3z)
```

C#

```
System.bool CreateArcByCenter(  
    System.double P1x,  
    System.double P1y,  
    System.double P1z,  
    System.double P2x,  
    System.double P2y,  
    System.double P2z,  
    System.double P3x,  
    System.double P3y,  
    System.double P3z  
)
```

C++/CLI

```
System.bool CreateArcByCenter(  
& System.double P1x,  
& System.double P1y,  
& System.double P1z,  
& System.double P2x,  
& System.double P2y,  
& System.double P2z,  
& System.double P3x,  
& System.double P3y,  
& System.double P3z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1x

P1y

P1z

P2x

P2y

P2z

P3x

P3y

P3z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateArcByCenter](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateArcDB Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateArcDB Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateArcDB](#).

.NET Syntax

Visual Basic (Declaration)

```

Function CreateArcDB( _
    ByVal X1 As System.Double, _
    ByVal Y1 As System.Double, _
    ByVal Z1 As System.Double, _
    ByVal X2 As System.Double, _
    ByVal Y2 As System.Double, _
    ByVal Z2 As System.Double, _
    ByVal X3 As System.Double, _
    ByVal Y3 As System.Double, _
    ByVal Z3 As System.Double, _
    ByVal Dir As System.Short _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim X1 As System.Double
Dim Y1 As System.Double
Dim Z1 As System.Double
Dim X2 As System.Double
Dim Y2 As System.Double
Dim Z2 As System.Double
Dim X3 As System.Double
Dim Y3 As System.Double
Dim Z3 As System.Double
Dim Dir As System.Short
Dim value As System.Boolean

```

```
value = instance.CreateArcDB(X1, Y1, Z1, X2, Y2, Z2, X3, Y3, Z3, Dir)
```

C#

```

System.bool CreateArcDB(
    System.double X1,
    System.double Y1,
    System.double Z1,
    System.double X2,
    System.double Y2,
    System.double Z2,
    System.double X3,
    System.double Y3,
    System.double Z3,
    System.short Dir
)

```

C++/CLI

```

System.bool CreateArcDB(
    & System.double X1,
    & System.double Y1,
    & System.double Z1,
    & System.double X2,
    & System.double Y2,
    & System.double Z2,
    & System.double X3,
    & System.double Y3,
    & System.double Z3,
    & System.short Dir
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X1

Y1

Z1

X2

Y2

Z2
X3
Y3
Z3
Dir

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateArcDB](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateArcVB Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateArcVB Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateArcVB](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub CreateArcVB( _  
    ByVal P1x As System.Double, _  
    ByVal P1y As System.Double, _  
    ByVal P1z As System.Double, _  
    ByVal P2x As System.Double, _  
    ByVal P2y As System.Double, _  
    ByVal P2z As System.Double, _  
    ByVal P3x As System.Double, _  
    ByVal P3y As System.Double, _  
    ByVal P3z As System.Double, _  
    ByVal Dir As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim P1x As System.Double  
Dim P1y As System.Double  
Dim P1z As System.Double  
Dim P2x As System.Double  
Dim P2y As System.Double  
Dim P2z As System.Double  
Dim P3x As System.Double  
Dim P3y As System.Double  
Dim P3z As System.Double  
Dim Dir As System.Short
```

```
instance.CreateArcVB(P1x, P1y, P1z, P2x, P2y, P2z, P3x, P3y, P3z, Dir)
```

C#

```
void CreateArcVB(  
    System.double P1x,  
    System.double P1y,  
    System.double P1z,  
    System.double P2x,  
    System.double P2y,  
    System.double P2z,  
    System.double P3x,
```

```
System.double P3y,  
System.double P3z,  
System.short Dir  
)
```

C++/CLI

```
void CreateArcVB(  
& System.double P1x,  
& System.double P1y,  
& System.double P1z,  
& System.double P2x,  
& System.double P2y,  
& System.double P2z,  
& System.double P3x,  
& System.double P3y,  
& System.double P3z,  
& System.short Dir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1x

P1y

P1z

P2x

P2y

P2z

P3x

P3y

P3z

Dir

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateArcVB](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateCenterLine Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateCenterLine Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateCenterLine](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateCenterLine( _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc  
Dim P1 As System.Object  
Dim P2 As System.Object
```



```
Dim value As System.Boolean

value = instance.CreateCenterLine(P1, P2)
```

C#

```
System.bool CreateCenterLine(
    System.object P1,
    System.object P2
)
```

C++/CLI

```
System.bool CreateCenterLine(
    & System.Object^ P1,
    & System.Object^ P2
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1

P2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateCenterLine](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateCenterLineVB Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateCenterLineVB Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateCenterLineVB](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub CreateCenterLineVB( _
    ByVal X1 As System.Double, _
    ByVal Y1 As System.Double, _
    ByVal Z1 As System.Double, _
    ByVal X2 As System.Double, _
    ByVal Y2 As System.Double, _
    ByVal Z2 As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim X1 As System.Double
Dim Y1 As System.Double
Dim Z1 As System.Double
Dim X2 As System.Double
Dim Y2 As System.Double
Dim Z2 As System.Double

instance.CreateCenterLineVB(X1, Y1, Z1, X2, Y2, Z2)
```

C#

```

void CreateCenterLineVB(
    System.double X1,
    System.double Y1,
    System.double Z1,
    System.double X2,
    System.double Y2,
    System.double Z2
)

```

C++/CLI

```

void CreateCenterLineVB(
&    System.double X1,
&    System.double Y1,
&    System.double Z1,
&    System.double X2,
&    System.double Y2,
&    System.double Z2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X1

Y1

Z1

X2

Y2

Z2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateCenterLineVB](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateCircle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateCircle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateCircle](#).

.NET Syntax

Visual Basic (Declaration)

```

Function CreateCircle( _
    ByVal P1x As System.Double, _
    ByVal P1y As System.Double, _
    ByVal P1z As System.Double, _
    ByVal P2x As System.Double, _
    ByVal P2y As System.Double, _
    ByVal P2z As System.Double _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As IModelDoc
Dim P1x As System.Double
Dim P1y As System.Double

```




```
Dim P1z As System.Double
Dim P2x As System.Double
Dim P2y As System.Double
Dim P2z As System.Double
Dim value As System.Boolean
```

```
value = instance.CreateCircle(P1x, P1y, P1z, P2x, P2y, P2z)
```

C#

```
System.bool CreateCircle(
    System.double P1x,
    System.double P1y,
    System.double P1z,
    System.double P2x,
    System.double P2y,
    System.double P2z
)
```

C++/CLI

```
System.bool CreateCircle(
    & System.double P1x,
    & System.double P1y,
    & System.double P1z,
    & System.double P2x,
    & System.double P2y,
    & System.double P2z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1x

P1y

P1z

P2x

P2y

P2z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateCircle](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateCircle2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : CreateCircle2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::CreateCircle2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateCircle2( _
    ByVal XC As System.Double, _
    ByVal YC As System.Double, _
    ByVal ZC As System.Double, _
    ByVal Xp As System.Double, _
    ByVal Yp As System.Double, _
```

```
ByVal Zp As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim XC As System.Double  
Dim YC As System.Double  
Dim Zc As System.Double  
Dim Xp As System.Double  
Dim Yp As System.Double  
Dim Zp As System.Double  
Dim value As System.Object  
  
value = instance.CreateCircle2(XC, YC, Zc, Xp, Yp, Zp)
```

C#

```
System.object CreateCircle2(  
    System.double XC,  
    System.double YC,  
    System.double Zc,  
    System.double Xp,  
    System.double Yp,  
    System.double Zp  
)
```

C++/CLI

```
System.Object^ CreateCircle2(  
& System.double XC,  
& System.double YC,  
& System.double Zc,  
& System.double Xp,  
& System.double Yp,  
& System.double Zp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XC

YC

Zc

Xp

Yp

Zp

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::CreateCircle2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)