

SOLIDWORKS API (.NET VBA C#) — Reference

(178/337): IModelDoc2 (part 1 of 17)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc2 (part 1 of 17) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IModelDoc2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelDoc2 Interface

Allows access to SOLIDWORKS documents: parts, assemblies, and drawings.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IModelDoc2
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

C#

```
public interface IModelDoc2
```

C++/CLI

```
public interface class IModelDoc2
```

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2](#).

Example

[Traverse Bodies \(C++\)](#)
[Get Names of Creators of Features \(C++\)](#)
[Get Spline Points \(C++\)](#)
[Create Equation-driven Curve \(C#\)](#)
[Create Equation-driven Curve \(VB.NET\)](#)
[Create Equation-driven Curve \(VBA\)](#)

Remarks

There are three main SOLIDWORKS document types:

- parts
- assemblies
- drawings

Each document type has its own object ([IPartDoc](#), [IAssemblyDoc](#), and [IDrawingDoc](#)) with its own set of related functions. For example, the [IAssemblyDoc::AddComponent4](#) method exists on the IAssemblyDoc object because adding components is specific to assembly documents.

The SOLIDWORKS API also has functions that are common to all document types. For example, printing, saving, or determining the file name associated with a document would be common operations. To expose common document-level functions, the SOLIDWORKS API uses the IModelDoc2 object.

Accessors

[IAssemblyDoc::GetEditTarget](#) and [IAssemblyDoc::IGetEditTarget2](#)

[IComponent2::GetModelDoc2](#)

[IConfigurationManager::Document](#)

[IEnumDocuments2::Next](#)

[IFeatureManager::Document](#)

[IMirrorPartFeatureData::GetModelDoc](#)

[IModelDoc2::GetNext](#) and [IModelDoc2::IGetNext](#)

[IModelDocExtension::Document](#)
[IModelViewManager::Document](#)
[IModelWindow::ModelDoc](#)
[IPartDoc::MirrorPart2](#)
[ISketchManager::Document](#)
[ISldWorks::ActivateDoc3](#) and [ISldWorks::!ActivateDoc3](#)
[ISldWorks::ActiveDoc](#) and [ISldWorks::!ActiveDoc2](#)
[ISldWorks::GetFirstDocument](#) and [ISldWorks::!GetFirstDocument2](#)
[ISldWorks::GetOpenDocument](#)
[ISldWorks::GetOpenDocumentByName](#) and [ISldWorks::!GetOpenDocumentByName2](#)
[ISldWorks::!NewDocument2](#)
[ISldWorks::LoadFile4](#)
[ISldWorks::NewDocument](#)
[ISldWorks::OpenDoc7](#)
[IView::ReferencedDocument](#)

 Access Diagram

[ModelDoc2](#)

 See Also

[IModelDoc2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IModelDoc2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelDoc2 Interface

The following tables list the members exposed by [IModelDoc2](#).

 Public Properties

Name	Description
 ActiveView	Gets the current active model view in read-only mode. NOTE: This property is a get-only property. Set is not implemented.
 ConfigurationManager	Gets the IConfigurationManager object, which allows access to a configuration in a model.
 CustomInfo	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
 CustomInfo2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
 Extension	Gets the IModelDocExtension object, which also allows access to the model document.
 FeatureManager	Gets the IFeatureManager object, which allows access to the FeatureManager design tree.
 FeatureManagerSplitterPosition	Splits the FeatureManager design tree and gets or sets the location of the split bar in the FeatureManager design tree panel.
 IActiveView	Gets the current active model view in read-only mode. NOTE: This property is a get-only property. Set is not implemented.
 ILightSourcePropertyValues	Gets and sets the light source property values.
 IMaterialPropertyValues	Gets or sets a material's properties in the active configuration.
 IPageSetup	Gets the page setup for this document.
 ISelectionManager	Gets the ISelectionMgr object for this document, which makes the currently selected object available.
 LargeAssemblyMode	Gets or sets Large Assembly Mode for this document.
 LengthUnit	Gets and sets the same LengthUnit value used by IModelDoc2::GetUnits , IModelDoc2::!GetUnits , and IModelDoc2::SetUnits .

	LightSourcePropertyValues	Gets and sets the light source property values.
	LightSourceUserName	Gets or sets the light source name that is displayed in the SOLIDWORKS Design user interface.
	MaterialIdName	Obsolete. Superseded by IPartDoc::GetMaterialPropertyName2 and IPartDoc::SetMaterialPropertyName2 .
	MaterialPropertyValues	Gets or sets a material's properties in the active configuration.
	MaterialUserName	Gets or sets the material name.
	ModelViewManager	Gets the IModelViewManager object, which allows access to the model view.
	PageSetup	Gets the page setup for this document.
	Printer	Gets or sets the default printer for this document.
	PrintSetup	Obsolete. See IModelDoc2::SetUserPreferenceDoubleValue , IModelDoc2::SetUserPreferenceIntegerValue , and IModelDoc2::SetUserPreferenceToggle .
	SceneBkgImageFileName	Controls the image filename used as the current background picture.
	SceneName	Gets and sets the name of the scene.
	SceneUserName	Gets and sets the user name of the scene.
	SelectionManager	Gets the ISelectionMgr object for this document, which makes the currently selected object available. NOTE: This property is a get-only property. Set is not implemented.
	ShowFeatureErrorDialog	Gets or sets whether to display the feature error dialog.
	SketchManager	Gets the sketch manager, which allows access to sketch-creation routines.
	SummaryInfo	Gets or sets file summary information for the SOLIDWORKS document.
	Visible	Gets or sets the visibility of the active document.

[Top](#)

Public Methods

Name	Description
	ActivateFeatureMgrView Obsolete. Superseded by IFeatureMgrView::ActivateView or IModelDocExtension::ActivateFeatureMgrViewx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
	ActivateSelectedFeature Activates the selected feature for editing.
	AddConfiguration Obsolete. Superseded by IModelDoc2::AddConfiguration3.
	AddConfiguration2 Obsolete. Superseded by IModelDoc2::AddConfiguration3.
	AddConfiguration3 Adds a new configuration to this model document.
	AddCustomInfo Obsolete. Superseded by IModelDocExtension::CustomPropertyManager.
	AddCustomInfo2 Obsolete. Superseded by IModelDocExtension::CustomPropertyManager.
	AddCustomInfo3 Obsolete. Superseded by IModelDocExtension::CustomPropertyManager.
	AddDiameterDimension Obsolete. Superseded by IModelDoc2::AddDiameterDimension2.
	AddDiameterDimension2 Adds a diameter dimension at the specified location for the selected item.
	AddDimension Obsolete. Superseded by IModelDoc2::AddDimension2.
	AddDimension2 Creates a display dimension at the specified location for selected entities.
	AddFeatureMgrView Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
	AddFeatureMgrView2 Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64.

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

	AddFeatureMgrView3	Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64.
		This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.
		The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
		Adds the specified tab to the FeatureManager design tree view.
	AddHorizontalDimension	Obsolete. Superseded by IModelDoc2::AddHorizontalDimension2.
	AddHorizontalDimension2	Creates a horizontal dimension for the currently selected entities at the specified location.
	AddIns	Displays the Add-In Manager dialog box.
	AddLightSource	Adds a type of light source to a scene with the specified names.
	AddLightSourceExtProperty	Stores a float, string, or integer value for the light source.
	AddLightToScene	Adds a light source to a scene.
	AddLoftSection	Adds a loft section to a blend feature.
	AddOrEditConfiguration	Obsolete. Superseded by IConfiguration::GetParameters, IConfiguration::IGetParameters, IConfiguration::ISetParameters, and IConfiguration::SetParameters.
	AddPropertyExtension	Adds a property extension to this model.
	AddRadialDimension	Obsolete. Superseded by IModelDoc2::AddRadialDimension2.
	AddRadialDimension2	Adds a radial dimension at the specified location for the selected item.
	AddRelation	Obsolete. Superseded by IEquationMgr::Add.
	AddSceneExtProperty	Stores a float, string, or integer value for a scene.
	AddVerticalDimension	Obsolete. Superseded by IModelDoc2::AddVerticalDimension2.
	AddVerticalDimension2	Creates a vertical dimension for the currently selected entities at the specified location.
	AlignDimensions	Obsolete. Superseded by IModelDocExtension::AlignDimensions.
	AlignOrdinate	Aligns the selected group of ordinate dimensions.
	AlignParallelDimensions	Aligns the selected linear dimensions in a parallel fashion.
	AndSelect	Obsolete. Superseded by IModelDocExtension::SelectByID2.
	AndSelectByID	Obsolete. Superseded by IModelDocExtension::SelectByID2.
	AndSelectByMark	Obsolete. Superseded by IModelDocExtension::SelectByID2.
	AutoInferToggle	Obsolete. Superseded by ISketchManager::AutoInference.
	AutoSolveToggle	Obsolete. Superseded by ISketchManager::AutoSolve.
	BlankRefGeom	Hides the selected reference geometry in the graphics window.
	BlankSketch	Hides the selected sketches.
	BreakAllExternalReferences	Obsolete. Superseded by IModelDocExtension::BreakAllExternalReferences2.
	BreakDimensionAlignment	Breaks the association of any selected dimensions belonging to an alignment group (parallel or collinear).
	ChangeSketchPlane	Obsolete. Superseded by IModelDocExtension::ChangeSketchPlane.
	ClearSelection	Obsolete. Superseded by IModelDoc2::ClearSelection2.
	ClearSelection2	Clears the selection list.
	ClearUndoList	Clears the undo list for this model document.
	Close	Not implemented. Use ISldWorks::CloseDoc .
	CloseFamilyTable	Closes the design table currently being edited.
	ClosePrintPreview	Closes the currently displayed Print Preview page for this document.
	ClosestDistance	Calculates the minimum distance between the specified geometric objects.

	Create3PointArc	Obsolete. Superseded by ISketchManager.Create3PointArc .
	CreateArc	Obsolete. Superseded by IModelDoc2.CreateArc2 .
	CreateArc2	Obsolete. Superseded by ISketchManager.CreateArc .
	CreateArcByCenter	Creates an arc by center in this model document.
	CreateArcDB	Obsolete. Superseded by IModelDoc2.CreateArc2 .
	CreateArcVB	Obsolete. Superseded by IModelDoc2.CreateArc2 .
	CreateCenterLine	Obsolete. Superseded by ISketchManager.CreateCenterLine .
	CreateCenterLineVB	Creates a center line from P1 to P2 and can be used in Visual Basic for Applications (VBA) and other forms of Basic that do not support SafeArrays.
	CreateCircle	Obsolete. Superseded by IModelDoc2.CreateCircle2 .
	CreateCircle2	Obsolete. Superseded by SketchManager.CreateCircle .
	CreateCircleByRadius	Obsolete. Superseded by IModelDoc2.CreateCircleByRadius2 .
	CreateCircleByRadius2	Obsolete. Superseded by SketchManager.CreateCircleByRadius .
	CreateCircleDB	Obsolete. Superseded by IModelDoc2.CreateCircle2 .
	CreateCircleVB	Obsolete. Superseded by IModelDoc2.CreateCircle2 .
	CreateCircularSketchStepAndRepeat	Obsolete. Superseded by ISketchManager.CreateCircularSketchStepAndRepeat .
	CreateClippedSplines	Creates one or more sketch spline segments that are clipped against a given (x1, y1), (x2, y2) rectangle. This rectangle lies in the space of the active 2D sketch.
	CreateEllipse	Obsolete. Superseded by IModelDoc2.CreateEllipse2 .
	CreateEllipse2	Obsolete. Superseded by ISketchManager.CreateEllipse .
	CreateEllipseVB	Obsolete. Superseded by IModelDoc2.CreateEllipse2 .
	CreateEllipticalArc	Obsolete. Superseded by SketchManager.CreateEllipticalArc .
	CreateEllipticalArcByCenter	Obsolete. Superseded by SketchManager.CreateEllipticalArc .
	CreateEllipticalArcByCenterVB	Obsolete. Superseded by SketchManager.CreateEllipticalArc .
	CreateFeatureMgrView	Obsolete. Superseded by IModelViewManager.CreateFeatureMgrView2 .
	CreateFeatureMgrView2	Obsolete. Superseded by IModelViewManager.CreateFeatureMgrView2 .
	CreateFeatureMgrView3	Obsolete. Superseded by IModelViewManager.CreateFeatureMgrView2 .
	CreateGroup	Creates an annotation group from the currently selected annotations.
	CreateLine	Obsolete. Superseded by IModelDoc2.CreateLine2 .
	CreateLine2	Obsolete. Superseded by SketchManager.CreateLine .
	CreateLinearSketchStepAndRepeat	Obsolete. Superseded by ISketchManager.CreateLinearSketchStepAndRepeat .
	CreateLineDB	Obsolete. Superseded by IModelDoc2.CreateLine2 .
	CreateLineVB	Obsolete. Superseded by IModelDoc2.CreateLine2 .
	CreatePlaneAtAngle	Obsolete. Superseded by IModelDoc2.CreatePlaneAtAngle3 .
	CreatePlaneAtAngle2	Obsolete. Superseded by IModelDoc2.CreatePlaneAtAngle3 .
	CreatePlaneAtAngle3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneAtOffset	Obsolete. Superseded by IModelDoc2.CreatePlaneAtOffset3 .
	CreatePlaneAtOffset2	Obsolete. Superseded by IModelDoc2.CreatePlaneAtOffset3 .
	CreatePlaneAtOffset3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneAtSurface	Obsolete. Superseded by IModelDoc2.CreatePlaneAtSurface3 .
	CreatePlaneAtSurface2	Obsolete. Superseded by IModelDoc2.CreatePlaneAtSurface3 .
	CreatePlaneAtSurface3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneFixed	Obsolete. Superseded by IModelDoc2.CreatePlaneFixed2 .
	CreatePlaneFixed2	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlanePerCurveAndPassPoint	Obsolete. Superseded by IModelDoc2.CreatePlanePerCurveAndPassPoint3 .

		
	CreatePlanePerCurveAndPassPoint2	Obsolete. Superseded by IModelDoc2::CreatePlanePerCurveAndPassPoint3 .
	CreatePlanePerCurveAndPassPoint3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	CreatePlaneThru3Points	Obsolete. Superseded by IModelDoc2::CreatePlaneThru3Points3 .
	CreatePlaneThru3Points2	Obsolete. Superseded by IModelDoc2::CreatePlaneThru3Points3 .
	CreatePlaneThru3Points3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	CreatePlaneThruLineAndPt	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	CreatePlaneThruPtParallelToPlane	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	CreatePoint	Obsolete. Superseded by IModelDoc2::CreatePoint2 .
	CreatePoint2	Obsolete. Superseded by ISketchManager::CreatePoint .
	CreatePointDB	Obsolete. Superseded by IModelDoc2::CreatePoint2 and IModelDoc2::CreatePoint2 .
	CreateSpline	Obsolete. Superseded by ISketchManager::CreateSpline .
	CreateSplineByEqnParams	Obsolete. Superseded by ISketchManager::CreateSplineByEqnParams .
	CreateSplinesByEqnParams	Obsolete. Superseded by ISketchManager::CreateSplinesByEqnParams .
	CreateTangentArc	Obsolete. Superseded by IModelDoc2::CreateTangentArc2 .
	CreateTangentArc2	Obsolete. Superseded by ISketchManager::CreateTangentArc .
	DeActivateFeatureMgrView	Deactivates a tab in the FeatureManager design tree view.
	DebugCheckIgesGeom	Dumps a IGES geometry check.
	DeleteAllRelations	Deletes all existing relations.
	DeleteBendTable	Deletes a bend table.
	DeleteBkgImage	Deletes any background image.
	DeleteConfiguration	Obsolete. Superseded by IModelDoc2::DeleteConfiguration2 .
	DeleteConfiguration2	Deletes a configuration.
	DeleteCustomInfo	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	DeleteCustomInfo2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	DeleteDesignTable	Deletes the design table for this document, if one exists.
	DeleteFeatureMgrView	Obsolete. Superseded by IModelDocExtension::DeleteFeatureMgrViewx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Removes the specified tab in the FeatureManager design tree.
	DeleteLightSource	Deletes a light source.
	DeleteNamedView	Deletes the specified model view.
	DeleteSelection	Obsolete. Superseded by IModelDocExtension::DeleteSelection2 .
	DeriveSketch	Creates a derived sketch.
	DeSelectByID	Removes the selected object from the selection list.
	DimPreferences	Sets dimension preferences.
	DissolveLibraryFeature	Dissolves the selected library features.
	DissolveSketchText	Dissolves sketch text.
	DragTo	Drags the specified end point.
	DrawLightIcons	Draws any visible light icons.
	EditBalloonProperties	Obsolete. Superseded by INote::SetBalloon and INote::SetBomBalloonText .
	EditClearAll	Obsolete. Superseded by IModelDoc2::ClearSelection2 .

	EditConfiguration	Obsolete. Superseded by IModelDoc2.EditConfiguration3
	EditConfiguration2	Obsolete. Superseded by IModelDoc2.EditConfiguration3
	EditConfiguration3	Edits the specified configuration.
	EditCopy	Copies the currently selected items and places them in the clipboard.
	EditCut	Cuts the currently selected items and places them on the Microsoft Windows Clipboard.
	EditDatumTargetSymbol	Edits a datum target symbol.
	EditDelete	Deletes the selected items.
	EditDimensionProperties	Obsolete. Superseded by IModelDoc2.EditDimensionProperties3
	EditDimensionProperties2	Obsolete. Superseded by IModelDoc2.EditDimensionProperties3
	EditDimensionProperties3	Obsolete. Superseded by IModelDocExtension.EditDimensionProperties
	EditOrdinate	Puts the currently selected ordinate dimension into edit mode so you could add more ordinate dimensions to this group.
	EditRebuild3	Rebuilds only those features that need to be rebuilt in the active configuration in the model.
	EditRedo	Obsolete. Superseded by IModelDoc2.EditRedo2
	EditRedo2	Repeats the specified number of actions in this SOLIDWORKS Design session.
	EditRollback	Obsolete. Superseded by IFeatureManager.EditRollback
	EditRollback2	Obsolete. Superseded by IFeatureManager.EditRollback
	EditRoute	Makes the last selected route the active route.
	EditSeedFeat	Gets the pattern seed feature, based on the selected face, and displays the Edit Definition dialog for that feature.
	EditSketch	Allows the currently selected sketch to be edited.
	EditSketchOrSingleSketchFeature	Edits a selected sketch or feature sketch.
	EditSuppress	Obsolete. Superseded IModelDoc2.EditSuppress2
	EditSuppress2	Suppresses the selected feature, the selected component, or the owning feature of the selected face.
	EditUndo	Obsolete. Superseded by IModelDoc2.EditUndo2
	EditUndo2	Undoes the specified number of actions in the active SOLIDWORKS Design session.
	EditUnsuppress	Obsolete. Superseded by IModelDoc2.EditUnsuppress2
	EditUnsuppress2	Unsuppresses the selected feature or component.
	EditUnsuppressDependent	Obsolete. Superseded by IModelDoc2.EditUnsuppressDependent2
	EditUnsuppressDependent2	Unsuppresses the selected feature or component and their dependents.
	EntityProperties	Displays the Properties dialog for the selected edge or face.
	EnumModelViews	Gets the model views enumeration in this document.
	FeatEdit	Puts the current feature into edit mode.
	FeatEditDef	Displays the Feature Definition dialog and lets the user edit the values.
	FeatureBoss	Obsolete. Superseded by IFeatureManager.FeatureExtrusion2
	FeatureBoss2	Obsolete. Superseded by IFeatureManager.FeatureExtrusion2
	FeatureBossThicken	Obsolete. Superseded by IFeatureManager.FeatureBossThicken
	FeatureBossThicken2	Obsolete. Superseded by IFeatureManager.FeatureBossThicken
	FeatureBossThin	Obsolete. Superseded by IFeatureManager.FeatureExtrusionThin2
	FeatureBossThin2	Obsolete. Superseded by IFeatureManager.FeatureExtrusionThin2
	FeatureByPositionReverse	Gets the <i>n</i> th from last feature in the document.
	FeatureChamfer	Creates a chamfer feature.
	FeatureChamferType	Obsolete. Superseded by IFeatureManager.InsertFeatureChamfer
	FeatureCirPattern	Obsolete. Superseded by IFeatureManager.FeatureCircularPattern2
	FeatureCurvePattern	Obsolete. See IFeatureManager.CreateFeature and the Remarks of ICurveDrivenPatternFeatureData

		
	FeatureCut	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut2	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut3	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut4	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut5	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCutThicken	Obsolete. Superseded by IFeatureManager:FeatureCutThicken .
	FeatureCutThicken2	Obsolete. Superseded by IFeatureManager:FeatureCutThicken .
	FeatureCutThin	Obsolete. Superseded by IFeatureManager:FeatureCutThin .
	FeatureCutThin2	Obsolete. Superseded by IFeatureManager:FeatureCutThin .
	FeatureExtrudeRefSurface	Obsolete. Superseded by IModelDoc2:FeatureExtrudeRefSurface2 .
	FeatureExtrudeRefSurface2	Obsolete. Superseded by IFeatureManager:FeatureExtrudeRefSurface .
	FeatureFillet	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet2	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet3	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet4	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet5	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureLinearPattern	Obsolete. Superseded by IFeatureManager:FeatureLinearPattern2 .
	FeatureReferenceCurve	Creates a reference curve feature from an array of curves.
	FeatureRevolve2	Obsolete. Superseded by IFeatureManager:FeatureRevolve .
	FeatureRevolveCut2	Obsolete. Superseded by IFeatureManager:FeatureRevolveCut .
	FeatureSketchDrivenPattern	Obsolete. Superseded by IFeatureManager:FeatureSketchDrivenPattern .
	FileReload	Obsolete. Superseded by IModelDoc2:ReloadOrReplace .
	FileSummaryInfo	Displays the File Summary Information dialog box for this file.
	FirstFeature	Gets the first feature in the document.
	FontBold	Enables or disables bold font style in the selected notes, dimensions, and GTols.
	FontFace	Changes the font face in the selected notes, dimensions, and GTols.
	FontItalic	Enables or disables italic font style in the selected notes, dimensions, and GTols.
	FontPoints	Changes the font height (specified in points) in the selected notes, dimensions, and GTols.
	FontUnderline	Enables or disables underlining the selected notes, dimensions, and GTols.
	FontUnits	Changes font height (specified in current system units) in the selected notes, dimensions, and GTols.
	ForceRebuild3	Forces a rebuild of all features in the active configuration in the model.
	ForceReleaseLocks	Releases the locks that a file system places on a file when it is opened and detaches that file from the file system.
	GetActiveConfiguration	Obsolete. Superseded by IConfigurationManager:ActiveConfiguration .
	GetActiveSketch	Obsolete. Superseded by IModelDoc2:GetActiveSketch2 .
	GetActiveSketch2	Obsolete. Superseded by ISketchManager:ActiveSketch .
	GetAddToDB	Gets whether entities are added directly to the SOLIDWORKS database.
	GetAmbientLightProperties	Gets the ambient light properties for this model document.
	GetAngularUnits	Gets the current angular unit settings.
	GetArcCentersDisplayed	Gets whether the arc centers are displayed.
	GetBendState	Gets the current bend state of a sheet metal part.
	GetBlockingState	Gets the current value of the SOLIDWORKS blocking state, within the range of values accessible by IModelDoc2:SetBlockingState .
	GetColorTable	Obsolete. Superseded by ISldWorks:GetColorTable .

		
	GetConfigurationByName	Gets the specified configuration.
	GetConfigurationCount	Gets the number of configurations.
	GetConfigurationNames	Gets the names of the configurations in this document.
	GetConsiderLeadersAsLines	Gets whether the display data of a leader is included as lines when the lines are retrieved from a view or annotation in this document.
	GetCoordinateSystemXformByName	Obsolete. Superseded by IModelDocExtension::GetCoordinateSystemTransformByName .
	GetCurrentCoordinateSystemName	Gets the name of the current coordinate system or an empty string for the default coordinate system.
	GetCustomInfoCount	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoCount2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoNames	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoNames2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoType	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoType2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoType3	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetCustomInfoValue	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	GetDefaultTextHeight	Gets the default text height in use for this document.
	GetDependencies	Obsolete. Superseded by IModelDoc2::GetDependencies2 .
	GetDependencies2	Obsolete. Superseded by IModelDocExtension::GetDependencies .
	GetDesignTable	Gets the design table associated with this part or assembly document.
	GetDetailingDefaults	Obsolete. Superseded by IModelDoc2::GetUserPreferenceTextFormat and IModelDoc2::SetUserPreferenceTextFormat .
	GetDirectionLightProperties	Gets the directional light properties.
	GetDisplayWhenAdded	Gets whether new sketch entities are displayed when created.
	GetEntityName	Gets the name of the specified face, edge, or vertex.
	GetEquationMgr	Gets the equation manager.
	GetExternalReferenceName	Gets the name of the externally referenced document (in the case of a join or mirrored part).
	GetFeatureCount	Gets the number of features in this document.
	GetFeatureManagerWidth	Gets the width of the FeatureManager design tree.
	GetFirstAnnotation	Obsolete. Superseded by IModelDoc2::GetFirstAnnotation2 .
	GetFirstAnnotation2	Gets the first annotation in the model.
	GetFirstModelView	Gets the first view in a model document.
	GetGridSettings	Gets the current grid settings.
	GetInferenceMode	Obsolete. Superseded by SketchManager::InferenceMode .
	GetLayerManager	Gets the layer manager for the current drawing document.
	GetLightSourceCount	Gets the number of light sources.
	GetLightSourceExtProperty	Gets a float, string, or integer value stored for the light source.
	GetLightSourceIdFromName	Gets the ID of the specified light source.
	GetLightSourceName	Gets the name of a light source used internally by the SOLIDWORKS Design application.
	GetLineCount	Gets the number of lines in the current sketch.
	GetLines	Gets all of the lines in the current sketch.
	GetMassProperties	Obsolete. Superseded by IModelDocExtension::GetMassProperties and IModelDocExtension::IGetMassProperties .
	GetMassProperties2	Obsolete. Superseded by IModelDocExtension::GetMassProperties and IModelDocExtension::IGetMassProperties .
	GetModelViewCount	Obsolete. Superseded by IModelDocExtension::GetModelViewCount .
	GetModelViewNames	Gets a list containing the names of each model view in this document.

		
	GetNext	Gets the next document opened in the current SOLIDWORKS Design session.
	GetNumDependencies	Gets the number of strings returned by IModelDoc2::GetDependencies2 .
	GetPathName	Gets the full path name for this document, including the file name.
	GetPointLightProperties	Gets point light properties.
	GetPopupMenuMode	Gets the current pop-up menu mode.
	GetPropertyExtension	Gets the specified property extension on this model.
	GetPropertyManagerPage	Obsolete. Superseded by ISldWorks::CreatePropertyManagerPage and ISldWorks::ICreatePropertyManagerPage .
	GetRayIntersectionsPoints	Gets the intersection point information generated by IModelDoc2::RayIntersections .
	GetRayIntersectionsTopology	Gets the topology intersections generated by IModelDoc2::RayIntersections .
	GetSaveFlag	Gets whether the document is currently dirty and needs to be saved.
	GetSceneBkgDIB	Obsolete. Superseded by IModelDocExtension::GetSceneBkgDIBx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Gets background image as a LPDIBSECTION.
	GetSceneExtProperty	Gets a float, string, or integer value stored for the scene.
	GetSpotlightProperties	Gets the spotlight properties.
	GetStandardViewRotation	Gets the specified view orientation matrix with respect to the Front view.
	GetTessellationQuality	Gets the shaded-display image quality number for the current document.
	GetTitle	Gets the title of the document that appears in the active window's title bar.
	GetToolBarVisibility	Gets the visibility of a toolbar.
	GetType	Gets the type of the document.
	GetUnits	Gets the current unit settings, fraction base, fraction value, and significant digits.
	GetUpdateStamp	Gets the current update stamp for this document.
	GetUserPreferenceDoubleValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceDouble .
	GetUserPreferenceIntegerValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceInteger .
	GetUserPreferenceStringValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceString .
	GetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceTextFormat .
	GetUserPreferenceToggle	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceToggle .
	GetUserUnit	Gets this document's units settings.
	GetVisibilityOfConstructPlanes	Gets whether construction (reference) planes are currently visible.
	GetZebraStripeData	Gets zebra line data.
	GraphicsRedraw	Obsolete. Superseded by IModelDoc2::GraphicsRedraw2 .
	GraphicsRedraw2	Obsolete. Superseded by IModelView::GraphicsRedraw and IModelView::IGraphicsRedraw .
	GridOptions	Obsolete. Superseded by ISketchManager::SetGridOptions .
	HideComponent2	Hides the selected component.
	HideCosmeticThread	Hides the selected cosmetic thread.
	HideDimension	Hides the selected dimension in this document.
	HideFeatureDimensions	Obsolete. Superseded by IModelDoc2::GetUserPreferenceToggle or IModelDoc2::SetUserPreferenceToggle and swDisplayFeatureDimensions .
	HideShowBodies	Sets whether to hide or show the bodies in the model.
	HideSolidBody	Hides the currently selected solid body.
	HoleWizard	Obsolete. Superseded by IFeatureManager::HoleWizard2 .

	IAddConfiguration3	Adds a new configuration to this model document.
	IAddDiameterDimension2	Adds a diameter dimension at the specified location for the selected item.
	IAddDimension2	Obsolete. Superseded by IModelDocExtension::IAddDimension .
	IAddHorizontalDimension2	Creates a horizontal dimension for the current selected entities at the specified location.
	IAddOrEditConfiguration	Obsolete. Superseded by IConfiguration::GetParameters , IConfiguration::IGetParameters , IConfiguration::ISetParameters , and IConfiguration::SetParameters .
	IAddRadialDimension2	Adds a radial dimension at the specified location for the selected item.
	IAddVerticalDimension2	Creates a vertical dimension for the currently selected entities at the specified location.
	IClosestDistance	Calculates the distance and closest points between two geometric objects.
	ICreateArc	Obsolete. Superseded by IModelDoc2::ICreateArc2 .
	ICreateArc2	Creates an arc based on a center point, a start, an end point, and a direction.
	ICreateCenterLine	Creates a center line from P1 to P2.
	ICreateCircle2	Creates a circle based on a center point and a point on the circle.
	ICreateCircleByRadius	Obsolete. Superseded by IModelDoc2::ICreateCircleByRadius2 .
	ICreateCircleByRadius2	Creates a circle based on a center point and a specified radius.
	ICreateClippedSplines	Creates one or more sketch spline segments that are clipped against a given (x1, y1), (x2, y2) rectangle. This rectangle lies in the space of the active 2D sketch.
	ICreateEllipse	Obsolete. Superseded by IModelDoc2::ICreateEllipse2 .
	ICreateEllipse2	Creates an ellipse using the specified center point and points.
	ICreateEllipticalArc2	Creates a partial ellipse given a center point, two points that specify the major and minor axis, and two points that define the elliptical start and end points.
	ICreateEllipticalArcByCenter	Creates an elliptical arc trimmed between two points.
	ICreateFeatureMgrView	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	ICreateFeatureMgrView2	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	ICreateFeatureMgrView3	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	ICreateLine	Obsolete. Superseded by IModelDoc2::ICreateLine2 .
	ICreateLine2	Creates a sketch line in the currently active 2D or 3D sketch.
	ICreatePlaneAtAngle2	Obsolete. Superseded by IModelDoc2::ICreatePlaneAtAngle3 .
	ICreatePlaneAtAngle3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneAtOffset2	Obsolete. Superseded by IModelDoc2::ICreatePlaneAtOffset3 .
	ICreatePlaneAtOffset3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneAtSurface2	Obsolete. Superseded by IModelDoc2::ICreatePlaneAtSurface3 .
	ICreatePlaneAtSurface3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneFixed	Obsolete. Superseded by IModelDoc2::ICreatePlaneFixed2 .
	ICreatePlaneFixed2	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlanePerCurveAndPassPoint2	Obsolete. Superseded by IModelDoc2::ICreatePlanePerCurveAndPassPoint3 .
	ICreatePlanePerCurveAndPassPoint3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneThru3Points2	Obsolete. Superseded by IModelDoc2::ICreatePlaneThru3Points3 .
	ICreatePlaneThru3Points3	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneThruLineAndPt	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePlaneThruPtParallelToPlane	Obsolete. Superseded by IFeatureManager::InsertRefPlane .
	ICreatePoint2	Obsolete. Superseded by ISketchManager::CreatePoint .
	ICreateSpline	Obsolete. Superseded by ISketchManager::ICreateSpline .
	ICreateSplineByEqnParams	Obsolete. Superseded by ISketchManager::ICreateSplineByEqnParams .
	ICreateSplinesByEqnParams	Obsolete. Superseded by ISketchManager::ICreateSplinesByEqnParams .
	IEditDimensionProperties3	Obsolete. Superseded by IModelDocExtension::IEditDimensionProperties .

		
	IFeatureByPositionReverse	Gets the <i>n</i> th from last feature in the document.
	IFeatureFillet2	Obsolete. Superseded by IFeatureManager:FeatureCut .
	IFeatureFillet3	Obsolete. Superseded by IFeatureManager:FeatureCut .
	IFeatureFillet4	Obsolete. Superseded by IFeatureManager:FeatureCut .
	IFeatureFillet5	Obsolete. Superseded by IFeatureManager:FeatureCut .
	IFeatureReferenceCurve	Creates a reference curve feature from an array of curves.
	IFirstFeature	Gets the first feature in the document.
	IGet3rdPartyStorage	Gets the IStream interface to the specified third-party stream inside this SOLIDWORKS Design document.
	IGetActiveConfiguration	Obsolete. Superseded by IConfigurationManager:ActiveConfiguration .
	IGetActiveSketch	Obsolete. Superseded by IModelDoc2:IGetActiveSketch2 .
	IGetActiveSketch2	Gets the active sketch.
	IGetAngularUnits	Gets the current angular unit settings.
	IGetColorTable	Obsolete. Superseded by ISldWorks:IGetColorTable .
	IGetConfigurationByName	Gets the specified configuration.
	IGetConfigurationNames	Gets the names of the configurations in this document.
	IGetCoordinateSystemXformByName	Obsolete. Superseded by IModelDocExtension:GetCoordinateSystemTransformByName .
	IGetCustomInfoNames	Obsolete. Superseded by IModelDocExtension:CustomPropertyManager .
	IGetCustomInfoNames2	Obsolete. Superseded by IModelDocExtension:CustomPropertyManager .
	IGetDependencies	Obsolete. Superseded by IModelDoc2:GetDependencies2 .
	IGetDependencies2	Gets all of the model's dependencies.
	IGetDesignTable	Gets the design table associated with this part or assembly document.
	IGetDetailingDefaults	Obsolete. Superseded by IModelDoc2:GetUserPreferenceTextFormat and IModelDoc2:SetUserPreferenceTextFormat .
	IGetEntityName	Gets the name of the specified face, edge, or vertex.
	IGetFirstAnnotation	Obsolete. Superseded by IModelDoc2:IGetFirstAnnotation2 .
	IGetFirstAnnotation2	Gets the first annotation in the model.
	IGetFirstModelView	Gets the first view in a model document.
	IGetLayerManager	Gets the layer manager ofr the current drawing document.
	IGetLines	Gets all of the lines in the current sketch.
	IGetMassProperties	Obsolete. Superseded by IModelDocExtension:IGetMassProperties .
	IGetMassProperties2	Obsolete. Superseded by IModelDocExtension:IGetMassProperties .
	IGetModelViewNames	Gets a list containing the names of each model view in this document.
	IGetNext	Gets the next document opened in the current SOLIDWORKS Design session.
	IGetNumDependencies	Obsolete. Superseded by IModelDoc2:IGetNumDependencies2 .
	IGetNumDependencies2	Gets the number of strings returned by IModelDoc2:IGetDependencies2 .
	IGetRayIntersectionsPoints	Gets the intersection point information generated by IModelDoc2:IRayIntersections .
	IGetRayIntersectionsTopology	Gets the topology intersections generated by IModelDoc2:IRayIntersections .
	IGetStandardViewRotation	Gets the specified view orientation matrix with respect to the Front view.
	IGetUnits	Gets the current unit settings, fraction base, fraction value, and significant digits.
	IGetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension:GetUserPreferenceTextFormat .
	IGetUserUnit	Gets this document's units settings.
	IGetVersionHistoryCount	Gets the size of the array required to hold data returned by IModelDoc2:VersionHistory .
	InsertBOMBalloon2	Obsolete. Superseded by IModelDocExtension:InsertBOMBalloon .

		
	InsertDatumTag2	Inserts a datum tag symbol at the selected location.
	InsertGtol	Creates a new geometric tolerance symbol (Gtol) in this document.
	InsertMacroFeature	Obsolete. Superseded by IFeatureManager::InsertMacroFeature3 .
	InsertMidSurfaceExt	Obsolete. Superseded by IFeatureManager::InsertMidSurface .
	InsertNote	Inserts a note in this document.
	InsertProjectedSketch2	Projects the selected sketch items from the current sketch onto a selected surface.
	InsertSheetMetalEdgeFlange	Obsolete. Superseded by IFeatureManager::InsertSheetMetalEdgeFlange2 .
	InsertSketchForEdgeFlange	Inserts a sketch for IFeatureManager::InsertSheetMetalEdgeFlange2 in this sheet metal part.
	InsertSketchText	Obsolete. Superseded by IModelDoc2::InsertSketchText .
	InsertWeldSymbol3	Inserts a weld symbol into the model.
	IListAuxiliaryExternalFileReferences	Gets the names of auxiliary external file references for this model.
	IListExternalFileReferences	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	IListExternalFileReferences2	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	IMultiSelectByRay	Selects multiple objects of the specified type that are intersected by a ray from point (x,y,z in meters) in direction vector (x,y,z) within a distance radius.
	Insert3DSketch	Obsolete. Superseded by IModelDoc2::Insert3DSketch2 .
	Insert3DSketch2	Obsolete. Superseded by ISketchManager::Insert3DSketch .
	Insert3DSplineCurve	Inserts a 3D-spline curve through the selected reference points.
	InsertAxis	Obsolete. Superseded by IModelDoc2::InsertAxis2 .
	InsertAxis2	Inserts a reference axis based on the currently selected items with an option to automatically size the axis.
	InsertBendTableEdit	Inserts a bend table and puts the bend table into its edit state.
	InsertBendTableNew	Inserts a new bend table into the model document.
	InsertBendTableOpen	Inserts an existing bend table from a file into this model document.
	InsertBkgImage	Inserts the scene background image.
	InsertBOMBalloon	Obsolete. Superseded by IModelDoc2::InsertBOMBalloon2 .
	InsertBOMBalloon2	Obsolete. Superseded by IModelDocExtension::InsertBOMBalloon .
	InsertCompositeCurve	Inserts a composite curve based on selections.
	InsertConnectionPoint	Adds a connection point based on the selected point and selected planar item.
	InsertCoordinateSystem	Obsolete. Superseded by IFeatureManager::InsertCoordinateSystem .
	InsertCosmeticThread	Obsolete. Superseded by IFeatureManager::InsertCosmeticThread2 .
	InsertCurveFile	Creates a curve.
	InsertCurveFileBegin	Creates a curve.
	InsertCurveFileEnd	Creates a curve.
	InsertCurveFilePoint	Creates a point for a curve.
	InsertCutBlend	Obsolete. Superseded by IFeatureManager::InsertCutBlend .
	InsertCutBlend2	Obsolete. Superseded by IFeatureManager::InsertCutBlend .
	InsertCutBlend3	Obsolete. Superseded by IFeatureManager::InsertCutBlend .
	InsertCutBlend4	Obsolete. Superseded by IFeatureManager::InsertCutBlend .
	InsertCutSurface	Obsolete. Superseded by IFeatureManager::InsertCutSurface .
	InsertCutSwept	Obsolete. Superseded by IFeatureManager::InsertCutSwept3 .
	InsertCutSwept2	Obsolete. Superseded by IFeatureManager::InsertCutSwept3 .
	InsertCutSwept3	Obsolete. Superseded by IFeatureManager::InsertCutSwept3 .
	InsertCutSwept4	Obsolete. Superseded by IFeatureManager::InsertCutSwept3 .

		
	InsertDatumTag2	Inserts a datum tag symbol at a selected location.
	InsertDatumTargetSymbol	Obsolete. Superseded by IModelDocExtension.InsertDatumTargetSymbol2 .
	InsertDeleteFace	Obsolete. Superseded by IModelDoc2.InsertDeleteFace2 .
	InsertDeleteFace2	Obsolete. Superseded by IModelDocExtension.InsertDeleteFace .
	InsertDeleteHole	Obsolete. Superseded by IFeatureManager.InsertDeleteHoleForSurface .
	InsertDome	Inserts a dome.
	InsertExtendSurface	Extends a surface along the selected faces or edges.
	InsertFamilyTableEdit	Edits an open design table from Microsoft Excel.
	InsertFamilyTableNew	Inserts an existing design table from the model into the selected drawing view.
	InsertFamilyTableOpen	Inserts the specified Microsoft Excel design table.
	InsertFeatureReplaceFace	Creates a Replace Face feature.
	InsertFeatureShell	Creates a shell feature.
	InsertFeatureShellAddThickness	Adds thickness to a face in a multi-thickness shell feature.
	InsertFramePoint	Obsolete. Not superseded.
	InsertGtol	Creates a new geometric tolerance symbol (GTol) in this document.
	InsertHatchedFace	Hatches the selected faces or closed sketch segments in a drawing.
	InsertHelix	Creates a constant-pitch helix or spiral.
	InsertLibraryFeature	Obsolete. See Remarks .
	InsertLoftRefSurface	Obsolete. Superseded by IModelDoc2.InsertLoftRefSurface2 .
	InsertLoftRefSurface2	Creates a loft surface from the selected profiles, centerline, and guide curves.
	InsertMacroFeature	Obsolete. Superseded by IFeatureManager.InsertMacroFeature3 .
	InsertMidDraft	Obsolete. Superseded by IFeatureManager.InsertMultifaceDraft .
	InsertMidDraft2	Obsolete. Superseded by IFeatureManager.InsertMultifaceDraft .
	InsertMidSurfaceExt	Obsolete. Superseded by IFeatureManager.InsertMidSurface .
	InsertNewNote3	Creates a new note.
	InsertNote	Inserts a note in this document.
	InsertObject	Activates the Microsoft Insert Object dialog.
	InsertObjectFromFile	Obsolete. Superseded by IModelDocExtension.InsertObjectFromFile .
	InsertOffsetSurface	Inserts an offset surface.
	InsertPlanarRefSurface	Inserts a planar reference surface.
	InsertPoint	Inserts a point in this model document.
	InsertProjectedSketch	Obsolete. Superseded by IModelDoc2.InsertProjectedSketch2 .
	InsertProjectedSketch2	Obsolete. See IProjectionCurveFeatureData and IFeatureManager.CreateDefinition .
	InsertProtrusionBlend	Obsolete. Superseded by IFeatureManager.InsertProtrusionBlend .
	InsertProtrusionBlend2	Obsolete. Superseded by IFeatureManager.InsertProtrusionBlend .
	InsertProtrusionBlend3	Obsolete. Superseded by IFeatureManager.InsertProtrusionBlend .
	InsertProtrusionBlend4	Obsolete. Superseded by IFeatureManager.InsertProtrusionBlend .
	InsertProtrusionSweep	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertProtrusionSweep2	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertProtrusionSweep3	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertProtrusionSweep4	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertRadiateSurface	Creates a radiate surface based on the selections.

		
	InsertRefPoint	Inserts a reference point based on the current selections.
	InsertRevolvedRefSurface	Obsolete. Superseded by IFeatureManager.InsertRevolvedRefSurface .
	InsertRib	Obsolete. Superseded by IModelDoc2.InsertRib2 .
	InsertRib2	Obsolete. Superseded by IFeatureManager.InsertRib .
	InsertRip	Creates a rip feature.
	InsertRoutePoint	Adds a route point based on the selected point.
	InsertScale	Obsolete. Superseded by IFeatureManager.InsertScale .
	InsertSewRefSurface	Obsolete. Superseded by IFeatureManager.InsertSewRefSurface .
	InsertSheetMetal3dBend	Obsolete. Superseded by IFeatureManager.InsertSheetMetal3dBend .
	InsertSheetMetalBaseFlange	Obsolete. Superseded by IFeatureManager.InsertSheetMetalBaseFlange .
	InsertSheetMetalBreakCorner	Inserts a break corner into a sheet metal part.
	InsertSheetMetalClosedCorner	Inserts a sheet metal closed corner into this model document.
	InsertSheetMetalEdgeFlange	Obsolete. Superseded by IFeatureManager.InsertSheetMetalEdgeFlange2 .
	InsertSheetMetalFold	Inserts a fold feature at the selected objects.
	InsertSheetMetalHem	Obsolete. Superseded by IFeatureManager.InsertSheetMetalHem .
	InsertSheetMetalJog	Inserts a sheet metal jog in the current model document.
	InsertSheetMetalMiterFlange	Obsolete. Superseded by IFeatureManager.InsertSheetMetalMiterFlange .
	InsertSheetMetalUnfold	Inserts an unfold feature at the selected objects.
	InsertSketch	Obsolete. Superseded by ISketchManager.InsertSketch .
	InsertSketch2	Obsolete. Superseded by ISketchManager.InsertSketch .
	InsertSketchForEdgeFlange	Inserts a profile sketch of an edge flange in this sheet metal part.
	InsertSketchPicture	Inserts a picture into the current sketch.
	InsertSketchPictureData	Obsolete. Superseded by IModelDoc2::InsertSketchPictureData64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Inserts a picture into the current sketch.
	InsertSketchPictureData64	Inserts a picture into the current sketch in 64-bit applications.
	InsertSketchText	Inserts sketch text.
	InsertSplinePoint	Inserts a spline point.
	InsertSplitLineProject	Splits a face by projecting sketch lines onto the face.
	InsertSplitLineSil	Splits a face by creating split lines along the silhouette of the selected faces.
	InsertStackedBalloon	Obsolete. Superseded by IModelDocExtension.InsertStackedBalloon .
	InsertSurfaceFinishSymbol2	Obsolete. Superseded by IModelDocExtension.InsertSurfaceFinishSymbol3 .
	InsertSweepRefSurface	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertSweepRefSurface2	Obsolete. Superseded by IFeatureManager.InsertProtrusionSweep3 .
	InsertWeldSymbol2	Obsolete. Superseded by IModelDoc2.InsertWeldSymbol3 .
	InsertWeldSymbol3	Inserts a weld symbol into the model.
	InspectCurvature	Adds curvature combs to the selected sketch segment.
	IParameter	Gets the specified parameter.
	IRayIntersections	Obsolete. Superseded by IModelDocExtension.RayIntersections .
	IRelease3rdPartyStorage	Releases the specified third-party stream.

	IsActive	Gets whether the specified assembly component is shown or hidden in this model document.
	IsEditingSelf	Gets whether this model is being edited in the context of another document.
	ISelectByRay	Obsolete. Superseded by IModelDocExtension::SelectByRay .
	ISetAngularUnits	Sets the current angular units.
	ISetNextSelectionGroupId	Sets the group ID for all remaining selections.
	ISetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceTextFormat .
	IsExploded	Obsolete. Superseded by IModelDocExtension::IsExploded .
	ISketchSplineByEqnParams	Creates a spline on the active 2D sketch using the specified b-curve parameters.
	IsLightLockedToModel	Gets whether the specified light is fixed.
	IsOpenedReadOnly	Gets whether a SOLIDWORKS document is open in read-only mode.
	IsOpenedViewOnly	Gets whether a SOLIDWORKS document is open in view-only mode.
	IsTessellationValid	Gets whether the current set of facets is valid.
	IVersionHistory	Gets an array of strings indicating the versions in which this model document was saved, including the SOLIDWORKS Design version in which the model document is currently opened and which is the last value returned in the array.
	LBDownAt	Generates a left mouse button press (down) event.
	LBUpAt	Generates a left-mouse button release (up) event.
	Lights	Obsolete. Not superseded.
	ListAuxiliaryExternalFileReferences	Gets the names of auxiliary external file references for this model.
	ListAuxiliaryExternalFileReferencesCount	Gets the number of auxiliary external file references for this model.
	ListExternalFileReferences	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	ListExternalFileReferences2	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	ListExternalFileReferencesCount	Obsolete. Superseded by IModelDocExtension::ListExternalFileReferenceCount .
	ListExternalFileReferencesCount2	Obsolete. Superseded by IModelDocExtension::ListExternalFileReferenceCount .
	Lock	Blocks the modifying commands in the user interface, effectively locking the application.
	LockAllExternalReferences	Locks all external references.
	LockFramePoint	Obsolete. Not superseded.
	LockLightToModel	Locks or unlocks the specified light.
	MoldDraftAnalysis	Performs a mold draft analysis.
	MultiSelectByRay	Selects multiple objects of the specified type that are intersected by a ray from point (x,y,z in meters) in direction vector (x,y,z) within a distance radius.
	NameView	Creates a named view using the current view.
	ObjectDisplayAsIcon	Shows the current OLE object as an icon.
	ObjectDisplayContent	Shows the current OLE object's content.
	ObjectResetSize	Sets the size of the current OLE object to the default.
	Parameter	Gets the specified parameter.
	ParentChildRelationship	Shows the Parent/Child Relationships dialog for the selected feature.
	Paste	Pastes the contents of the Microsoft Windows Clipboard at the current insertion point.
	PostTrimSurface	Obsolete. Superseded by IFeatureManager::PostTrimSurface .
	PreTrimSurface	Obsolete. Superseded by IFeatureManager::PreTrimSurface .
	PrintDirect	Prints the current document to the default printer.
	PrintOut	Obsolete. Superseded by IModelDocExtension::PrintOut2 and IModelDocExtension::IPrintOut2 .
	PrintOut2	Obsolete. Superseded by IModelDocExtension::PrintOut2 and IModelDocExtension::IPrintOut2 .
	PrintPreview	Displays the Print Preview page for the current document.
	PropertySheet	Displays the the selected object's property sheet.
	Quit	Closes the active document without saving changes (see Remarks).

		
	RayIntersections	Obsolete. Superseded by IModelDocExtension-RayIntersections .
	ReattachOrdinate	Reattaches an ordinate dimension to a different entity.
	Rebuild	Obsolete. Superseded by IModelDocExtension-Rebuild .
	ReloadOrReplace	Obsolete. Superseded by IModelDocExtension-ReloadOrReplace .
	RemoveGroups	Removes any annotation groups in the current selection.
	RemoveInspectCurvature	Removes curvature combs from the selected curved sketch segment.
	RemoveItemsFromGroup	Removes the selected annotations from their annotation groups.
	ResetBlockingState	Resets the blocking state for the SOLIDWORKS menus.
	ResetLightSourceExtProperty	Resets the properties for a light source.
	ResetPropertyExtension	Clears all values stored in the property extension.
	ResetSceneExtProperty	Resets the extension property for a scene.
	Save	Obsolete. Superseded by IModelDoc2-Save3 .
	Save2	Obsolete. Superseded by IModelDoc2-Save3 .
	Save3	Saves the current document.
	SaveAs	Obsolete. Superseded by IModelDocExtension-SaveAs .
	SaveAs2	Obsolete. Superseded by IModelDocExtension-SaveAs .
	SaveAs3	Obsolete. Superseded by IModelDocExtension-SaveAs .
	SaveAs4	Obsolete. Superseded by IModelDocExtension-SaveAs .
	SaveAsSilent	Obsolete. Superseded by IModelDocExtension-SaveAs .
	SaveBMP	Saves the current view as a bitmap (BMP) file.
	SaveSilent	Obsolete. Superseded by IModelDoc2-Save3 .
	Scale	Scales the part.
	ScreenRotate	Switches between model and screen center rotation.
	Select	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectAt	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectByID	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectByMark	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectByName	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectByRay	Obsolete. Superseded by IModelDocExtension-SelectByRay .
	SelectedEdgeProperties	Sets the property values of the selected edge.
	SelectedFaceProperties	Sets the material property values of the selected face.
	SelectedFeatureProperties	Sets the property values of the selected feature.
	SelectLoop	Selects the loop that corresponds to the selected edge.
	SelectMidpoint	Puts the midpoint (swSelMIDPOINTS) of that edge on the selection list and removes the edge from the selection list when an edge is selected.
	SelectSketchArc	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectSketchItem	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectSketchLine	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectSketchPoint	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectSketchSpline	Obsolete. Superseded by IModelDocExtension-SelectByID2 .
	SelectTangency	Selects all faces tangent to the selected face.
	SetAddToDB	Obsolete. Superseded by ISketchManager-AddToDB .
	SetAmbientLightProperties	Sets ambient light properties.

		
	SetAngularUnits	Sets the current angular units.
	SetArcCentersDisplayed	Sets the current arc centers displayed setting.
	SetBendState	Sets the bend state of a sheet metal part.
	SetBlockingState	Sets the blocking state for the SOLIDWORKS menus.
	SetConsiderLeadersAsLines	Sets a flag on the document that indicates whether the display data of a leader should be included as lines when the lines are retrieved from a view or annotation in this document.
	SetDirectionLightProperties	Sets direction light properties.
	SetDisplayWhenAdded	Obsolete. Superseded by ISketchManager::DisplayWhenAdded .
	SetFeatureManagerWidth	Sets the width of the FeatureManager design tree.
	SetInferenceMode	Obsolete. Superseded by SketchManager::InferenceMode .
	SetLightSourceName	Sets the light source name used internally by the SOLIDWORKS Design software.
	SetLightSourcePropertyValuesVB	Sets the light source property values.
	SetParamValue	Sets the value of selected dimension (or parameter).
	SetPickMode	Returns the user to the default selection mode.
	SetPointLightProperties	Sets point light properties.
	SetPopupMenuMode	Sets the pop-up menu mode.
	SetReadOnlyState	Sets whether this document is read-only or read-write.
	SetSaveAsFileName	Sets the Save As filename from within the FileSaveAsNotify2 event handlers, thereby, bypassing the Save As dialog.
	SetSaveFlag	Flags the document as dirty.
	SetSceneBkgDIB	Obsolete. Superseded by IModelDocExtension::SetSceneBkgDIBx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets background image described by DIBSECTION data.
	SetSpotlightProperties	Sets the spotlight properties.
	SetTessellationQuality	Sets the shaded-display image quality number for the current document.
	SetTitle2	Sets the title of a new document.
	SetToolbarVisibility	Sets the visibility of a toolbar.
	SetUnits	Sets the units used by the end-user for the model.
	SetUserPreferenceDoubleValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceDouble .
	SetUserPreferenceIntegerValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceInteger .
	SetUserPreferenceStringValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceString .
	SetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceTextFormat .
	SetUserPreferenceToggle	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceToggle .
	SetZebraStripeData	Sets the zebra-line data.
	ShowComponent2	Shows the selected component.
	ShowConfiguration	Obsolete. Superseded by IModelDoc2::ShowConfiguration2 .
	ShowConfiguration2	Shows the named configuration by switching to that configuration and making it the active configuration.
	ShowCosmeticThread	Shows the selected cosmetic thread.
	ShowFeatureDimensions	Obsolete. Superseded by IModelDoc2::GetUserPreferenceToggle and IModelDoc2::SetUserPreferenceToggle and swDisplayFeatureDimensions .
	ShowNamedView	Obsolete. Superseded by IModelDoc2::ShowNameView2 .
	ShowNamedView2	Shows the specified view.
	ShowSolidBody	Shows the selected solid body.

	SimpleHole	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimpleHole2	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimpleHole3	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimplifySpline	Obsolete. Superseded by ISketchSpline::Simplify .
	Sketch3DIntersections	Creates new sketch segments based on the selected surfaces.
	SketchAddConstraints	Adds the specified constraint to the selected entities.
	SketchAlign	Aligns the selected sketch entities.
	SketchArc	Creates an arc in the current model document.
	SketchCenterline	Adds a centerline to the current model document.
	SketchChamfer	Obsolete. Superseded by ISketchManager::CreateChamfer .
	SketchCircle	Obsolete. Superseded by IModelDoc2::CreateCircle2 .
	SketchConstrainCoincident	Makes the selected sketch entities coincident.
	SketchConstrainConcentric	Makes the selected sketch entities concentric.
	SketchConstrainParallel	Makes the selected sketch entities parallel.
	SketchConstrainPerp	Makes the selected sketch entities perpendicular.
	SketchConstrainTangent	Makes the selected entities tangent.
	SketchConstraintsDel	Deletes the specified relationship (constraint) on the currently selected sketch item.
	SketchConstraintsDelAll	Deletes all of the constraints on the currently selected sketch segment.
	SketchConvertIsoCurves	Converts ISO-parametric curves on a selected surface into a sketch entity.
	SketchFillet	Obsolete. Superseded by IModelDoc2::SketchFillet2 .
	SketchFillet1	Obsolete. Superseded by IModelDoc2::SketchFillet2 .
	SketchFillet2	Obsolete. Superseded by ISketchManager::CreateFillet .
	SketchMirror	Creates new entities that are mirror images of the selected entities.
	SketchModifyFlip	Flips the the active or selected sketch about the specified coordinate system axis.
	SketchModifyRotate	Rotates the coordinate system of the active or selected sketch.
	SketchModifyScale	Scales the active or selected sketch.
	SketchModifyTranslate	Translates the coordinate system of the active or selected sketch.
	SketchOffset	Obsolete. Superseded by IModelDoc2::SketchOffset2 .
	SketchOffset2	Obsolete. Superseded by ISketchManager::SketchOffset .
	SketchOffsetEdges	Offsets the edges of the selected entities.
	SketchOffsetEntities	Obsolete. Superseded by IModelDoc2::SketchOffsetEntities2 .
	SketchOffsetEntities2	Generates entities in the active sketch by offsetting the selected geometry by the specified amount.
	SketchParabola	Obsolete. Superseded by ISketchManager::CreateParabola .
	SketchPoint	Obsolete. Superseded by IModelDoc2::CreatePoint2 and IModelDoc2::ICreatePoint2 .
	SketchPolygon	Obsolete. Superseded by ISketchManager::CreatePolygon .
	SketchRectangle	Obsolete. Superseded by ISketchManager::CreateCornerRectangle .
	SketchRectangleAtAnyAngle	Obsolete. Superseded by ISketchManager::Create3PointCornerRectangle .
	SketchSpline	Starts a spline, or continues one, using the specified point.
	SketchSplineByEqnParams	Obsolete. Superseded by IModelDoc2::ISketchSplineByEqnParams2 .
	SketchSplineByEqnParams2	Obsolete. Superseded by ISketchManager::CreateSplineByEqnParams .
	SketchTangentArc	Creates a tangent arc in the current model document.
	SketchTrim	Obsolete. Superseded by ISketchManager::SketchExtend and ISketchManager::SketchTrim .
	SketchUndo	Undoes the last sketch command.

		
	SketchUseEdge	Obsolete. Superseded by ISketchManager::SketchUseEdge .
	SketchUseEdge2	Obsolete. Superseded by ISketchManager::SketchUseEdge .
	SketchUseEdgeCrtline	Uses this centerline in sketch.
	SkToolsAutoConstr	Automatically constrains the active sketch.
	SplitClosedSegment	Obsolete. Superseded by ISketchManager::SplitClosedSegment .
	SplitOpenSegment	Obsolete. Superseded by ISketchManager::SplitOpenSegment .
	Toolbars	Turns the specified SOLIDWORKS toolbars on and off.
	ToolsDistance	Computes distance.
	ToolsGrid	Shows and hides the grid in this model document.
	ToolsMacro	Not implemented.
	ToolsMassProps	Calculates the mass properties.
	ToolsSketchScale	Scales a sketch.
	ToolsSketchTranslate	Translates a sketch.
	UnBlankRefGeom	Shows the selected, hidden reference geometry in the graphics window.
	UnblankSketch	Shows a hidden sketch.
	UnderiveSketch	Changes a sketch to underived.
	UnLock	Reverses IModelDoc2::Lock and changes the status bar message to Process Complete .
	UnlockAllExternalReferences	Unlocks all external references.
	UnlockFramePoint	Obsolete. Not superseded.
	UserFavors	Specifies whether geometric relations are automatically created as you add sketch entities.
	UserPreferences	Obsolete. The See Also section of this topic contains links to the methods that supersede this method.
	VersionHistory	Gets an array of strings indicating the versions in which this document was saved, including the SOLIDWORKS Design version in which the model document is currently opened and which is the last value returned in the array.
	ViewConstraint	Shows the constraints for the current model document.
	ViewDispCoordinateSystems	Toggles the display of coordinate systems on and off.
	ViewDisplayCurvature	Toggles the display of surface curvature on and off.
	ViewDisplayFaceted	Sets the current display mode to show the facets that make up a shaded picture of STL output.
	ViewDisplayHiddengreyed	Sets the current display mode to Hidden Lines Visible .
	ViewDisplayHiddenremoved	Sets the current display mode to Hidden Lines Removed .
	ViewDisplayShaded	Sets the current display mode to Shaded .
	ViewDisplayWireframe	Sets the current display mode to Wireframe .
	ViewDispOrigins	Toggles the display of origins off and on.
	ViewDispRefaxes	Toggles the display of reference axis on and off.
	ViewDispRefplanes	Toggles the display of reference planes on and off.
	ViewDispRefPoints	Shows and hides the reference points for the current model document.
	ViewDispTempRefaxes	Toggles the display of temporary reference axes on and off.
	ViewOglShading	Sets the current display subsystem to use OpenGL.
	ViewOrientationUndo	Undoes previous view orientation changes that were made interactively by the user.
	ViewRotate	Rotates the view of the current model.
	ViewRotateminusx	Dynamically rotates the view around x in a negative direction with the current increment.
	ViewRotateminusy	Dynamically rotates the view around y in a negative direction with the current increment.
	ViewRotateminusz	Dynamically rotates the view around z in a negative direction with the current increment.
	ViewRotateplusx	Rotates the view around x in a positive direction with the current increment.

		
	ViewRotateplusy	Rotates the view around y in a positive direction with the current increment.
	ViewRotateplusz	Rotates the view around z in a positive direction with the current increment.
	ViewRotXMinusNinety	Dynamically rotates the view by negative 90 about x.
	ViewRotXPlusNinety	Dynamically rotates the view by 90 about x.
	ViewRotYMinusNinety	Dynamically rotates the view by negative 90 about y.
	ViewRotYPlusNinety	Dynamically rotates the view by 90 about y.
	ViewRwShading	Sets the current display subsystem to use renderware.
	ViewTranslate	Translates the view.
	ViewTranslateminusx	Dynamically shifts the view left.
	ViewTranslateminusy	Dynamically shifts the view down.
	ViewTranslateplusx	Dynamically shifts the view right.
	ViewTranslateplusy	Dynamically shifts the view up.
	ViewZoomin	Zooms the current view in by a factor of 20%.
	ViewZoomout	Zooms the current view out by a factor of 20%.
	ViewZoomto	Zooms the view to the selected box.
	ViewZoomTo2	Zooms to the specified region.
	ViewZoomtofit	Obsolete. Superseded by IModelDoc2::ViewZoomtofit2
	ViewZoomtofit2	Zooms the currently active view to fit the screen.
	ViewZoomToSelection	Zooms the display to the selection.
	WindowRedraw	Redraws the current window.

[Top](#)

See Also

[IModelDoc2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IModelDoc2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelDoc2 Interface

For a list of all members of this type, see [IModelDoc2 members](#).

Public Methods

Name	Description
 ActivateFeatureMgrView	Obsolete. Superseded by IFeatureMgrView::ActivateView or IModelDocExtension::ActivateFeatureMgrViewx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
 ActivateSelectedFeature	Activates the selected feature for editing.
 AddConfiguration	Obsolete. Superseded by IModelDoc2::AddConfiguration3
 AddConfiguration2	Obsolete. Superseded by IModelDoc2::AddConfiguration3
 AddConfiguration3	Adds a new configuration to this model document.
 AddCustomInfo	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager
 AddCustomInfo2	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager

	AddCustomInfo3	Obsolete. Superseded by IModelDocExtension::CustomPropertyManager .
	AddDiameterDimension	Obsolete. Superseded by IModelDoc2::AddDiameterDimension2 .
	AddDiameterDimension2	Adds a diameter dimension at the specified location for the selected item.
	AddDimension	Obsolete. Superseded by IModelDoc2::AddDimension2 .
	AddDimension2	Creates a display dimension at the specified location for selected entities.
	AddFeatureMgrView	Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
	AddFeatureMgrView2	Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.
	AddFeatureMgrView3	Obsolete. Superseded by IModelDocExtension::AddFeatureMgrView3x64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Adds the specified tab to the FeatureManager design tree view.
	AddHorizontalDimension	Obsolete. Superseded by IModelDoc2::AddHorizontalDimension2 .
	AddHorizontalDimension2	Creates a horizontal dimension for the currently selected entities at the specified location.
	AddIns	Displays the Add-In Manager dialog box.
	AddLightSource	Adds a type of light source to a scene with the specified names.
	AddLightSourceExtProperty	Stores a float, string, or integer value for the light source.
	AddLightToScene	Adds a light source to a scene.
	AddLoftSection	Adds a loft section to a blend feature.
	AddOrEditConfiguration	Obsolete. Superseded by IConfiguration::GetParameters , IConfiguration::IGetParameters , IConfiguration::ISetParameters , and IConfiguration::SetParameters .
	AddPropertyExtension	Adds a property extension to this model.
	AddRadialDimension	Obsolete. Superseded by IModelDoc2::AddRadialDimension2 .
	AddRadialDimension2	Adds a radial dimension at the specified location for the selected item.
	AddRelation	Obsolete. Superseded by IEquationMgr::Add .
	AddSceneExtProperty	Stores a float, string, or integer value for a scene.
	AddVerticalDimension	Obsolete. Superseded by IModelDoc2::AddVerticalDimension2 .
	AddVerticalDimension2	Creates a vertical dimension for the currently selected entities at the specified location.
	AlignDimensions	Obsolete. Superseded by IModelDocExtension::AlignDimensions .
	AlignOrdinate	Aligns the selected group of ordinate dimensions.
	AlignParallelDimensions	Aligns the selected linear dimensions in a parallel fashion.
	AndSelect	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	AndSelectByID	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	AndSelectByMark	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	AutoInferToggle	Obsolete. Superseded by ISketchManager::AutoInference .
	AutoSolveToggle	Obsolete. Superseded by ISketchManager::AutoSolve .
	BlankRefGeom	Hides the selected reference geometry in the graphics window.
	BlankSketch	Hides the selected sketches.
	BreakAllExternalReferences	Obsolete. Superseded by IModelDocExtension::BreakAllExternalReferences2 .

		
	BreakDimensionAlignment	Breaks the association of any selected dimensions belonging to an alignment group (parallel or collinear).
	ChangeSketchPlane	Obsolete. Superseded by IModelDocExtension::ChangeSketchPlane .
	ClearSelection	Obsolete. Superseded by IModelDoc2::ClearSelection2 .
	ClearSelection2	Clears the selection list.
	ClearUndoList	Clears the undo list for this model document.
	Close	Not implemented. Use ISldWorks::CloseDoc .
	CloseFamilyTable	Closes the design table currently being edited.
	ClosePrintPreview	Closes the currently displayed Print Preview page for this document.
	ClosestDistance	Calculates the minimum distance between the specified geometric objects.
	Create3PointArc	Obsolete. Superseded by ISketchManager::Create3PointArc .
	CreateArc	Obsolete. Superseded by IModelDoc2::CreateArc2 .
	CreateArc2	Obsolete. Superseded by ISketchManager::CreateArc .
	CreateArcByCenter	Creates an arc by center in this model document.
	CreateArcDB	Obsolete. Superseded by IModelDoc2::CreateArc2 .
	CreateArcVB	Obsolete. Superseded by IModelDoc2::CreateArc2 .
	CreateCenterLine	Obsolete. Superseded by ISketchManager::CreateCenterLine .
	CreateCenterLineVB	Creates a center line from P1 to P2 and can be used in Visual Basic for Applications (VBA) and other forms of Basic that do not support SafeArrays.
	CreateCircle	Obsolete. Superseded by IModelDoc2::CreateCircle2 .
	CreateCircle2	Obsolete. Superseded by SketchManager::CreateCircle .
	CreateCircleByRadius	Obsolete. Superseded by IModelDoc2::CreateCircleByRadius2 .
	CreateCircleByRadius2	Obsolete. Superseded by SketchManager::CreateCircleByRadius .
	CreateCircleDB	Obsolete. Superseded by IModelDoc2::CreateCircle2 .
	CreateCircleVB	Obsolete. Superseded by IModelDoc2::CreateCircle2 .
	CreateCircularSketchStepAndRepeat	Obsolete. Superseded by ISketchManager::CreateCircularSketchStepAndRepeat .
	CreateClippedSplines	Creates one or more sketch spline segments that are clipped against a given (x1, y1), (x2, y2) rectangle. This rectangle lies in the space of the active 2D sketch.
	CreateEllipse	Obsolete. Superseded by IModelDoc2::CreateEllipse2 .
	CreateEllipse2	Obsolete. Superseded by ISketchManager::CreateEllipse .
	CreateEllipseVB	Obsolete. Superseded by IModelDoc2::CreateEllipse2 .
	CreateEllipticalArc2	Obsolete. Superseded by SketchManager::CreateEllipticalArc .
	CreateEllipticalArcByCenter	Obsolete. Superseded by SketchManager::CreateEllipticalArc .
	CreateEllipticalArcByCenterVB	Obsolete. Superseded by SketchManager::CreateEllipticalArc .
	CreateFeatureMgrView	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	CreateFeatureMgrView2	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	CreateFeatureMgrView3	Obsolete. Superseded by IModelViewManager::CreateFeatureMgrView2 .
	CreateGroup	Creates an annotation group from the currently selected annotations.
	CreateLine	Obsolete. Superseded by IModelDoc2::CreateLine2 .
	CreateLine2	Obsolete. Superseded by SketchManager::CreateLine .
	CreateLinearSketchStepAndRepeat	Obsolete. Superseded by ISketchManager::CreateLinearSketchStepAndRepeat .
	CreateLineDB	Obsolete. Superseded by IModelDoc2::CreateLine2 .
	CreateLineVB	Obsolete. Superseded by IModelDoc2::CreateLine2 .
	CreatePlaneAtAngle	Obsolete. Superseded by IModelDoc2::CreatePlaneAtAngle3 .
	CreatePlaneAtAngle2	Obsolete. Superseded by IModelDoc2::CreatePlaneAtAngle3 .

		
	CreatePlaneAtAngle3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneAtOffset	Obsolete. Superseded by IModelDoc2.CreatePlaneAtOffset3 .
	CreatePlaneAtOffset2	Obsolete. Superseded by IModelDoc2.CreatePlaneAtOffset3 .
	CreatePlaneAtOffset3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneAtSurface	Obsolete. Superseded by IModelDoc2.CreatePlaneAtSurface3 .
	CreatePlaneAtSurface2	Obsolete. Superseded by IModelDoc2.CreatePlaneAtSurface3 .
	CreatePlaneAtSurface3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneFixed	Obsolete. Superseded by IModelDoc2.CreatePlaneFixed2 .
	CreatePlaneFixed2	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlanePerCurveAndPassPoint	Obsolete. Superseded by IModelDoc2.CreatePlanePerCurveAndPassPoint3 .
	CreatePlanePerCurveAndPassPoint2	Obsolete. Superseded by IModelDoc2.CreatePlanePerCurveAndPassPoint3 .
	CreatePlanePerCurveAndPassPoint3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneThru3Points	Obsolete. Superseded by IModelDoc2.CreatePlaneThru3Points3 .
	CreatePlaneThru3Points2	Obsolete. Superseded by IModelDoc2.CreatePlaneThru3Points3 .
	CreatePlaneThru3Points3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneThruLineAndPt	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePlaneThruPtParallelToPlane	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	CreatePoint	Obsolete. Superseded by IModelDoc2.CreatePoint2 .
	CreatePoint2	Obsolete. Superseded by ISketchManager.CreatePoint .
	CreatePointDB	Obsolete. Superseded by IModelDoc2.CreatePoint2 and IModelDoc2.ICreatePoint2 .
	CreateSpline	Obsolete. Superseded by ISketchManager.CreateSpline .
	CreateSplineByEqnParams	Obsolete. Superseded by ISketchManager.CreateSplineByEqnParams .
	CreateSplinesByEqnParams	Obsolete. Superseded by ISketchManager.CreateSplinesByEqnParams .
	CreateTangentArc	Obsolete. Superseded by IModelDoc2.CreateTangentArc2 .
	CreateTangentArc2	Obsolete. Superseded by ISketchManager.CreateTangentArc .
	DeActivateFeatureMgrView	Deactivates a tab in the FeatureManager design tree view.
	DebugCheckIgesGeom	Dumps a IGES geometry check.
	DeleteAllRelations	Deletes all existing relations.
	DeleteBendTable	Deletes a bend table.
	DeleteBkgImage	Deletes any background image.
	DeleteConfiguration	Obsolete. Superseded by IModelDoc2.DeleteConfiguration2 .
	DeleteConfiguration2	Deletes a configuration.
	DeleteCustomInfo	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	DeleteCustomInfo2	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	DeleteDesignTable	Deletes the design table for this document, if one exists.
	DeleteFeatureMgrView	Obsolete. Superseded by IModelDocExtension.DeleteFeatureMgrViewx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Removes the specified tab in the FeatureManager design tree.
	DeleteLightSource	Deletes a light source.
	DeleteNamedView	Deletes the specified model view.

	DeleteSelection	Obsolete. Superseded by IModelDocExtension.DeleteSelection2
	DeriveSketch	Creates a derived sketch.
	DeSelectByID	Removes the selected object from the selection list.
	DimPreferences	Sets dimension preferences.
	DissolveLibraryFeature	Dissolves the selected library features.
	DissolveSketchText	Dissolves sketch text.
	DragTo	Drags the specified end point.
	DrawLightIcons	Draws any visible light icons.
	EditBalloonProperties	Obsolete. Superseded by INote.SetBalloon and INote.SetBottomBalloonText .
	EditClearAll	Obsolete. Superseded by IModelDoc2.ClearSelection2 .
	EditConfiguration	Obsolete. Superseded by IModelDoc2.EditConfiguration3 .
	EditConfiguration2	Obsolete. Superseded by IModelDoc2.EditConfiguration3 .
	EditConfiguration3	Edits the specified configuration.
	EditCopy	Copies the currently selected items and places them in the clipboard.
	EditCut	Cuts the currently selected items and places them on the Microsoft Windows Clipboard.
	EditDatumTargetSymbol	Edits a datum target symbol.
	EditDelete	Deletes the selected items.
	EditDimensionProperties	Obsolete. Superseded by IModelDoc2.EditDimensionProperties3 .
	EditDimensionProperties2	Obsolete. Superseded by IModelDoc2.EditDimensionProperties3 .
	EditDimensionProperties3	Obsolete. Superseded by IModelDocExtension.EditDimensionProperties .
	EditOrdinate	Puts the currently selected ordinate dimension into edit mode so you could add more ordinate dimensions to this group.
	EditRebuild3	Rebuilds only those features that need to be rebuilt in the active configuration in the model.
	EditRedo	Obsolete. Superseded by IModelDoc2.EditRedo2 .
	EditRedo2	Repeats the specified number of actions in this SOLIDWORKS Design session.
	EditRollback	Obsolete. Superseded by IFeatureManager.EditRollback .
	EditRollback2	Obsolete. Superseded by IFeatureManager.EditRollback .
	EditRoute	Makes the last selected route the active route.
	EditSeedFeat	Gets the pattern seed feature, based on the selected face, and displays the Edit Definition dialog for that feature.
	EditSketch	Allows the currently selected sketch to be edited.
	EditSketchOrSingleSketchFeature	Edits a selected sketch or feature sketch.
	EditSuppress	Obsolete. Superseded by IModelDoc2.EditSuppress2 .
	EditSuppress2	Suppresses the selected feature, the selected component, or the owning feature of the selected face.
	EditUndo	Obsolete. Superseded by IModelDoc2.EditUndo2 .
	EditUndo2	Undoes the specified number of actions in the active SOLIDWORKS Design session.
	EditUnsuppress	Obsolete. Superseded by IModelDoc2.EditUnsuppress2 .
	EditUnsuppress2	Unsuppresses the selected feature or component.
	EditUnsuppressDependent	Obsolete. Superseded by IModelDoc2.EditUnsuppressDependent2 .
	EditUnsuppressDependent2	Unsuppresses the selected feature or component and their dependents.
	EntityProperties	Displays the Properties dialog for the selected edge or face.
	EnumModelViews	Gets the model views enumeration in this document.
	FeatEdit	Puts the current feature into edit mode.
	FeatEditDef	Displays the Feature Definition dialog and lets the user edit the values.
	FeatureBoss	Obsolete. Superseded by IFeatureManager.FeatureExtrusion2 .

		
	FeatureBoss2	Obsolete. Superseded by IFeatureManager:FeatureExtrusion2 .
	FeatureBossThicken	Obsolete. Superseded by IFeatureManager:FeatureBossThicken .
	FeatureBossThicken2	Obsolete. Superseded by IFeatureManager:FeatureBossThicken .
	FeatureBossThin	Obsolete. Superseded by IFeatureManager:FeatureExtrusionThin2 .
	FeatureBossThin2	Obsolete. Superseded by IFeatureManager:FeatureExtrusionThin2 .
	FeatureByPositionReverse	Gets the <i>n</i> th from last feature in the document.
	FeatureChamfer	Creates a chamfer feature.
	FeatureChamferType	Obsolete. Superseded by IFeatureManager:InsertFeatureChamfer .
	FeatureCirPattern	Obsolete. Superseded by IFeatureManager:FeatureCircularPattern2 .
	FeatureCurvePattern	Obsolete. See IFeatureManager::CreateFeature and the Remarks of ICurveDrivenPatternFeatureData .
	FeatureCut	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut2	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut3	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut4	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCut5	Obsolete. Superseded by IFeatureManager:FeatureCut .
	FeatureCutThicken	Obsolete. Superseded by IFeatureManager:FeatureCutThicken .
	FeatureCutThicken2	Obsolete. Superseded by IFeatureManager:FeatureCutThicken .
	FeatureCutThin	Obsolete. Superseded by IFeatureManager:FeatureCutThin .
	FeatureCutThin2	Obsolete. Superseded by IFeatureManager:FeatureCutThin .
	FeatureExtruRefSurface	Obsolete. Superseded by IModelDoc2:FeatureExtruRefSurface2 .
	FeatureExtruRefSurface2	Obsolete. Superseded by IFeatureManager:FeatureExtruRefSurface .
	FeatureFillet	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet2	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet3	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet4	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureFillet5	Obsolete. Superseded by IFeatureManager:FeatureFillet .
	FeatureLinearPattern	Obsolete. Superseded by IFeatureManager:FeatureLinearPattern2 .
	FeatureReferenceCurve	Creates a reference curve feature from an array of curves.
	FeatureRevolve2	Obsolete. Superseded by IFeatureManager:FeatureRevolve .
	FeatureRevolveCut2	Obsolete. Superseded by IFeatureManager:FeatureRevolveCut .
	FeatureSketchDrivenPattern	Obsolete. Superseded by IFeatureManager:FeatureSketchDrivenPattern .
	FileReload	Obsolete. Superseded by IModelDoc2:ReloadOrReplace .
	FileSummaryInfo	Displays the File Summary Information dialog box for this file.
	FirstFeature	Gets the first feature in the document.
	FontBold	Enables or disables bold font style in the selected notes, dimensions, and GTols.
	FontFace	Changes the font face in the selected notes, dimensions, and GTols.
	FontItalic	Enables or disables italic font style in the selected notes, dimensions, and GTols.
	FontPoints	Changes the font height (specified in points) in the selected notes, dimensions, and GTols.
	FontUnderline	Enables or disables underlining the selected notes, dimensions, and GTols.
	FontUnits	Changes font height (specified in current system units) in the selected notes, dimensions, and GTols.
	ForceRebuild3	Forces a rebuild of all features in the active configuration in the model.
	ForceReleaseLocks	Releases the locks that a file system places on a file when it is opened and detaches that file from the file system.

		
	GetActiveConfiguration	Obsolete. Superseded by IConfigurationManager.ActiveConfiguration .
	GetActiveSketch	Obsolete. Superseded by IModelDoc2.GetActiveSketch2 .
	GetActiveSketch2	Obsolete. Superseded by SketchManager.ActiveSketch .
	GetAddToDB	Gets whether entities are added directly to the SOLIDWORKS database.
	GetAmbientLightProperties	Gets the ambient light properties for this model document.
	GetAngularUnits	Gets the current angular unit settings.
	GetArcCentersDisplayed	Gets whether the arc centers are displayed.
	GetBendState	Gets the current bend state of a sheet metal part.
	GetBlockingState	Gets the current value of the SOLIDWORKS blocking state, within the range of values accessible by IModelDoc2.SetBlockingState .
	GetColorTable	Obsolete. Superseded by ISldWorks.GetColorTable .
	GetConfigurationByName	Gets the specified configuration.
	GetConfigurationCount	Gets the number of configurations.
	GetConfigurationNames	Gets the names of the configurations in this document.
	GetConsiderLeadersAsLines	Gets whether the display data of a leader is included as lines when the lines are retrieved from a view or annotation in this document.
	GetCoordinateSystemXformByName	Obsolete. Superseded by IModelDocExtension.GetCoordinateSystemTransformByName .
	GetCurrentCoordinateSystemName	Gets the name of the current coordinate system or an empty string for the default coordinate system.
	GetCustomInfoCount	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoCount2	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoNames	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoNames2	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoType	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoType2	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoType3	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetCustomInfoValue	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	GetDefaultTextHeight	Gets the default text height in use for this document.
	GetDependencies	Obsolete. Superseded by IModelDoc2.GetDependencies2 .
	GetDependencies2	Obsolete. Superseded by IModelDocExtension.GetDependencies .
	GetDesignTable	Gets the design table associated with this part or assembly document.
	GetDetailingDefaults	Obsolete. Superseded by IModelDoc2.GetUserPreferenceTextFormat and IModelDoc2.SetUserPreferenceTextFormat .
	GetDirectionLightProperties	Gets the directional light properties.
	GetDisplayWhenAdded	Gets whether new sketch entities are displayed when created.
	GetEntityName	Gets the name of the specified face, edge, or vertex.
	GetEquationMgr	Gets the equation manager.
	GetExternalReferenceName	Gets the name of the externally referenced document (in the case of a join or mirrored part).
	GetFeatureCount	Gets the number of features in this document.
	GetFeatureManagerWidth	Gets the width of the FeatureManager design tree.
	GetFirstAnnotation	Obsolete. Superseded by IModelDoc2.GetFirstAnnotation2 .
	GetFirstAnnotation2	Gets the first annotation in the model.
	GetFirstModelView	Gets the first view in a model document.
	GetGridSettings	Gets the current grid settings.
	GetInferenceMode	Obsolete. Superseded by SketchManager.InferenceMode .
	GetLayerManager	Gets the layer manager for the current drawing document.

		
	GetLightSourceCount	Gets the number of light sources.
	GetLightSourceExtProperty	Gets a float, string, or integer value stored for the light source.
	GetLightSourceIdFromName	Gets the ID of the specified light source.
	GetLightSourceName	Gets the name of a light source used internally by the SOLIDWORKS Design application.
	GetLineCount	Gets the number of lines in the current sketch.
	GetLines	Gets all of the lines in the current sketch.
	GetMassProperties	Obsolete. Superseded by IModelDocExtension::GetMassProperties and IModelDocExtension::IGetMassProperties .
	GetMassProperties2	Obsolete. Superseded by IModelDocExtension::GetMassProperties and IModelDocExtension::IGetMassProperties .
	GetModelViewCount	Obsolete. Superseded by IModelDocExtension::GetModelViewCount .
	GetModelViewNames	Gets a list containing the names of each model view in this document.
	GetNext	Gets the next document opened in the current SOLIDWORKS Design session.
	GetNumDependencies	Gets the number of strings returned by IModelDoc2::GetDependencies2 .
	GetPathName	Gets the full path name for this document, including the file name.
	GetPointLightProperties	Gets point light properties.
	GetPopupMenuMode	Gets the current pop-up menu mode.
	GetPropertyExtension	Gets the specified property extension on this model.
	GetPropertyManagerPage	Obsolete. Superseded by ISldWorks::CreatePropertyManagerPage and ISldWorks::ICreatePropertyManagerPage .
	GetRayIntersectionsPoints	Gets the intersection point information generated by IModelDoc2::RayIntersections .
	GetRayIntersectionsTopology	Gets the topology intersections generated by IModelDoc2::RayIntersections .
	GetSaveFlag	Gets whether the document is currently dirty and needs to be saved.
	GetSceneBkgDIB	Obsolete. Superseded by IModelDocExtension::GetSceneBkgDIBx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Gets background image as a LPDIBSECTION.
	GetSceneExtProperty	Gets a float, string, or integer value stored for the scene.
	GetSpotlightProperties	Gets the spotlight properties.
	GetStandardViewRotation	Gets the specified view orientation matrix with respect to the Front view.
	GetTessellationQuality	Gets the shaded-display image quality number for the current document.
	GetTitle	Gets the title of the document that appears in the active window's title bar.
	GetToolbarVisibility	Gets the visibility of a toolbar.
	GetType	Gets the type of the document.
	GetUnits	Gets the current unit settings, fraction base, fraction value, and significant digits.
	GetUpdateStamp	Gets the current update stamp for this document.
	GetUserPreferenceDoubleValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceDouble .
	GetUserPreferenceIntegerValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceInteger .
	GetUserPreferenceStringValue	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceString .
	GetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceTextFormat .
	GetUserPreferenceToggle	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceToggle .
	GetUserUnit	Gets this document's units settings.
	GetVisibilityOfConstructPlanes	Gets whether construction (reference) planes are currently visible.
	GetZebraStripeData	Gets zebra line data.

	GraphicsRedraw	Obsolete. Superseded by IModelDoc2:GraphicsRedraw2 .
	GraphicsRedraw2	Obsolete. Superseded by IModelView:GraphicsRedraw and IModelView:IGraphicsRedraw .
	GridOptions	Obsolete. Superseded by ISketchManager:SetGridOptions .
	HideComponent2	Hides the selected component.
	HideCosmeticThread	Hides the selected cosmetic thread.
	HideDimension	Hides the selected dimension in this document.
	HideFeatureDimensions	Obsolete. Superseded by IModelDoc2:GetUserPreferenceToggle or IModelDoc2:SetUserPreferenceToggle and swDisplayFeatureDimensions .
	HideShowBodies	Sets whether to hide or show the bodies in the model.
	HideSolidBody	Hides the currently selected solid body.
	HoleWizard	Obsolete. Superseded by IFeatureManager:HoleWizard2 .
	IAddConfiguration3	Adds a new configuration to this model document.
	IAddDiameterDimension2	Adds a diameter dimension at the specified location for the selected item.
	IAddDimension2	Obsolete. Superseded by IModelDocExtension:AddDimension .
	IAddHorizontalDimension2	Creates a horizontal dimension for the current selected entities at the specified location.
	IAddOrEditConfiguration	Obsolete. Superseded by IConfiguraiton:GetParameters , IConfiguration:IGetParameters , IConfiguration:ISetParameters , and IConfiguration:SetParameters .
	IAddRadialDimension2	Adds a radial dimension at the specified location for the selected item.
	IAddVerticalDimension2	Creates a vertical dimension for the currently selected entities at the specified location.
	IClosestDistance	Calculates the distance and closest points between two geometric objects.
	ICreateArc	Obsolete. Superseded by IModelDoc2:ICreateArc2 .
	ICreateArc2	Creates an arc based on a center point, a start, an end point, and a direction.
	ICreateCenterLine	Creates a center line from P1 to P2.
	ICreateCircle2	Creates a circle based on a center point and a point on the circle.
	ICreateCircleByRadius	Obsolete. Superseded by IModelDoc2:ICreateCircleByRadius2 .
	ICreateCircleByRadius2	Creates a circle based on a center point and a specified radius.
	ICreateClippedSplines	Creates one or more sketch spline segments that are clipped against a given (x1, y1), (x2, y2) rectangle. This rectangle lies in the space of the active 2D sketch.
	ICreateEllipse	Obsolete. Superseded by IModelDoc2:ICreateEllipse2 .
	ICreateEllipse2	Creates an ellipse using the specified center point and points.
	ICreateEllipticalArc2	Creates a partial ellipse given a center point, two points that specify the major and minor axis, and two points that define the elliptical start and end points.
	ICreateEllipticalArcByCenter	Creates an elliptical arc trimmed between two points.
	ICreateFeatureMgrView	Obsolete. Superseded by IModelViewManager:CreateFeatureMgrView2 .
	ICreateFeatureMgrView2	Obsolete. Superseded by IModelViewManager:CreateFeatureMgrView2 .
	ICreateFeatureMgrView3	Obsolete. Superseded by IModelViewManager:CreateFeatureMgrView2 .
	ICreateLine	Obsolete. Superseded by IModelDoc2:ICreateLine2 .
	ICreateLine2	Creates a sketch line in the currently active 2D or 3D sketch.
	ICreatePlaneAtAngle2	Obsolete. Superseded by IModelDoc2:ICreatePlaneAtAngle3 .
	ICreatePlaneAtAngle3	Obsolete. Superseded by IFeatureManager:InsertRefPlane .
	ICreatePlaneAtOffset2	Obsolete. Superseded by IModelDoc2:ICreatePlaneAtOffset3 .
	ICreatePlaneAtOffset3	Obsolete. Superseded by IFeatureManager:InsertRefPlane .
	ICreatePlaneAtSurface2	Obsolete. Superseded by IModelDoc2:ICreatePlaneAtSurface3 .
	ICreatePlaneAtSurface3	Obsolete. Superseded by IFeatureManager:InsertRefPlane .
	ICreatePlaneFixed	Obsolete. Superseded by IModelDoc2:ICreatePlaneFixed2 .
	ICreatePlaneFixed2	Obsolete. Superseded by IFeatureManager:InsertRefPlane .
	ICreatePlanePerCurveAndPassPoint2	Obsolete. Superseded by IModelDoc2:ICreatePlanePerCurveAndPassPoint3 .

		
	ICreatePlanePerCurveAndPassPoint3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	ICreatePlaneThru3Points2	Obsolete. Superseded by IModelDoc2.ICreatePlaneThru3Points3 .
	ICreatePlaneThru3Points3	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	ICreatePlaneThruLineAndPt	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	ICreatePlaneThruPtParallelToPlane	Obsolete. Superseded by IFeatureManager.InsertRefPlane .
	ICreatePoint2	Obsolete. Superseded by ISketchManager.CreatePoint .
	ICreateSpline	Obsolete. Superseded by ISketchManager.ICreateSpline .
	ICreateSplineByEqnParams	Obsolete. Superseded by ISketchManager.ICreateSplineByEqnParams .
	ICreateSplinesByEqnParams	Obsolete. Superseded by ISketchManager.ICreateSplinesByEqnParams .
	IEditDimensionProperties3	Obsolete. Superseded by IModelDocExtension.IEditDimensionProperties .
	IFeatureByPositionReverse	Gets the <i>n</i> th from last feature in the document.
	IFeatureFillet2	Obsolete. Superseded by IFeatureManager.FeatureCut .
	IFeatureFillet3	Obsolete. Superseded by IFeatureManager.FeatureCut .
	IFeatureFillet4	Obsolete. Superseded by IFeatureManager.FeatureCut .
	IFeatureFillet5	Obsolete. Superseded by IFeatureManager.FeatureCut .
	IFeatureReferenceCurve	Creates a reference curve feature from an array of curves.
	IFirstFeature	Gets the first feature in the document.
	IGet3rdPartyStorage	Gets the IStream interface to the specified third-party stream inside this SOLIDWORKS Design document.
	IGetActiveConfiguration	Obsolete. Superseded by IConfigurationManager.ActiveConfiguration .
	IGetActiveSketch	Obsolete. Superseded by IModelDoc2.IGetActiveSketch2 .
	IGetActiveSketch2	Gets the active sketch.
	IGetAngularUnits	Gets the current angular unit settings.
	IGetColorTable	Obsolete. Superseded by ISldWorks.IGetColorTable .
	IGetConfigurationByName	Gets the specified configuration.
	IGetConfigurationNames	Gets the names of the configurations in this document.
	IGetCoordinateSystemXformByName	Obsolete. Superseded by IModelDocExtension.GetCoordinateSystemTransformByName .
	IGetCustomInfoNames	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	IGetCustomInfoNames2	Obsolete. Superseded by IModelDocExtension.CustomPropertyManager .
	IGetDependencies	Obsolete. Superseded by IModelDoc2.GetDependencies2 .
	IGetDependencies2	Gets all of the model's dependencies.
	IGetDesignTable	Gets the design table associated with this part or assembly document.
	IGetDetailingDefaults	Obsolete. Superseded by IModelDoc2.GetUserPreferenceTextFormat and IModelDoc2.SetUserPreferenceTextFormat .
	IGetEntityName	Gets the name of the specified face, edge, or vertex.
	IGetFirstAnnotation	Obsolete. Superseded by IModelDoc2.IGetFirstAnnotation2 .
	IGetFirstAnnotation2	Gets the first annotation in the model.
	IGetFirstModelView	Gets the first view in a model document.
	IGetLayerManager	Gets the layer manager of the current drawing document.
	IGetLines	Gets all of the lines in the current sketch.
	IGetMassProperties	Obsolete. Superseded by IModelDocExtension.IGetMassProperties .
	IGetMassProperties2	Obsolete. Superseded by IModelDocExtension.IGetMassProperties .
	IGetModelViewNames	Gets a list containing the names of each model view in this document.
	IGetNext	Gets the next document opened in the current SOLIDWORKS Design session.

		
	IGetNumDependencies	Obsolete. Superseded by IModelDoc2::IGetNumDependencies2 .
	IGetNumDependencies2	Gets the number of strings returned by IModelDoc2::IGetDependencies2 .
	IGetRayIntersectionsPoints	Gets the intersection point information generated by IModelDoc2::IRayIntersections .
	IGetRayIntersectionsTopology	Gets the topology intersections generated by IModelDoc2::IRayIntersections .
	IGetStandardViewRotation	Gets the specified view orientation matrix with respect to the Front view.
	IGetUnits	Gets the current unit settings, fraction base, fraction value, and significant digits.
	IGetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceTextFormat .
	IGetUserUnit	Gets this document's units settings.
	IGetVersionHistoryCount	Gets the size of the array required to hold data returned by IModelDoc2::IVersionHistory .
	InsertBOMBalloon2	Obsolete. Superseded by IModelDocExtension::InsertBOMBalloon .
	InsertDatumTag2	Inserts a datum tag symbol at the selected location.
	InsertGtol	Creates a new geometric tolerance symbol (GTol) in this document.
	InsertMacroFeature	Obsolete. Superseded by IFeatureManager::InsertMacroFeature3 .
	InsertMidSurfaceExt	Obsolete. Superseded by IFeatureManager::InsertMidSurface .
	InsertNote	Inserts a note in this document.
	InsertProjectedSketch2	Projects the selected sketch items from the current sketch onto a selected surface.
	InsertSheetMetalEdgeFlange	Obsolete. Superseded by IFeatureManager::InsertSheetMetalEdgeFlange2 .
	InsertSketchForEdgeFlange	Inserts a sketch for IFeatureManager::InsertSheetMetalEdgeFlange2 in this sheet metal part.
	InsertSketchText	Obsolete. Superseded by IModelDoc2::InsertSketchText .
	InsertWeldSymbol3	Inserts a weld symbol into the model.
	IListAuxiliaryExternalFileReferences	Gets the names of auxiliary external file references for this model.
	IListExternalFileReferences	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	IListExternalFileReferences2	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	IMultiSelectByRay	Selects multiple objects of the specified type that are intersected by a ray from point (x,y,z in meters) in direction vector (x,y,z) within a distance radius.
	Insert3DSketch	Obsolete. Superseded by IModelDoc2::Insert3DSketch2 .
	Insert3DSketch2	Obsolete. Superseded by ISketchManager::Insert3DSketch .
	Insert3DSplineCurve	Inserts a 3D-spline curve through the selected reference points.
	InsertAxis	Obsolete. Superseded by IModelDoc2::InsertAxis2 .
	InsertAxis2	Inserts a reference axis based on the currently selected items with an option to automatically size the axis.
	InsertBendTableEdit	Inserts a bend table and puts the bend table into its edit state.
	InsertBendTableNew	Inserts a new bend table into the model document.
	InsertBendTableOpen	Inserts an existing bend table from a file into this model document.
	InsertBkgImage	Inserts the scene background image.
	InsertBOMBalloon	Obsolete. Superseded by IModelDoc2::InsertBOMBalloon2 .
	InsertBOMBalloon2	Obsolete. Superseded by IModelDocExtension::InsertBOMBalloon .
	InsertCompositeCurve	Inserts a composite curve based on selections.
	InsertConnectionPoint	Adds a connection point based on the selected point and selected planar item.
	InsertCoordinateSystem	Obsolete. Superseded by IFeatureManager::InsertCoordinateSystem .
	InsertCosmeticThread	Obsolete. Superseded by IFeatureManager::InsertCosmeticThread2 .
	InsertCurveFile	Creates a curve.
	InsertCurveFileBegin	Creates a curve.
	InsertCurveFileEnd	Creates a curve.

		
	InsertCurveFilePoint	Creates a point for a curve.
	InsertCutBlend	Obsolete. Superseded by IFeatureManager.InsertCutBlend .
	InsertCutBlend2	Obsolete. Superseded by IFeatureManager.InsertCutBlend .
	InsertCutBlend3	Obsolete. Superseded by IFeatureManager.InsertCutBlend .
	InsertCutBlend4	Obsolete. Superseded by IFeatureManager.InsertCutBlend .
	InsertCutSurface	Obsolete. Superseded by IFeatureManager.InsertCutSurface .
	InsertCutSwept	Obsolete. Superseded by IFeatureManager.InsertCutSwept3 .
	InsertCutSwept2	Obsolete. Superseded by IFeatureManager.InsertCutSwept3 .
	InsertCutSwept3	Obsolete. Superseded by IFeatureManager.InsertCutSwept3 .
	InsertCutSwept4	Obsolete. Superseded by IFeatureManager.InsertCutSwept3 .
	InsertDatumTag2	Inserts a datum tag symbol at a selected location.
	InsertDatumTargetSymbol	Obsolete. Superseded by IModelDocExtension.InsertDatumTargetSymbol2 .
	InsertDeleteFace	Obsolete. Superseded by IModelDoc2.InsertDeleteFace2 .
	InsertDeleteFace2	Obsolete. Superseded by IModelDocExtension.InsertDeleteFace .
	InsertDeleteHole	Obsolete. Superseded by IFeatureManager.InsertDeleteHoleForSurface .
	InsertDome	Inserts a dome.
	InsertExtendSurface	Extends a surface along the selected faces or edges.
	InsertFamilyTableEdit	Edits an open design table from Microsoft Excel.
	InsertFamilyTableNew	Inserts an existing design table from the model into the selected drawing view.
	InsertFamilyTableOpen	Inserts the specified Microsoft Excel design table.
	InsertFeatureReplaceFace	Creates a Replace Face feature.
	InsertFeatureShell	Creates a shell feature.
	InsertFeatureShellAddThickness	Adds thickness to a face in a multi-thickness shell feature.
	InsertFramePoint	Obsolete. Not superseded.
	InsertGtol	Creates a new geometric tolerance symbol (Gtol) in this document.
	InsertHatchedFace	Hatches the selected faces or closed sketch segments in a drawing.
	InsertHelix	Creates a constant-pitch helix or spiral.
	InsertLibraryFeature	Obsolete. See Remarks .
	InsertLoftRefSurface	Obsolete. Superseded by IModelDoc2.InsertLoftRefSurface2 .
	InsertLoftRefSurface2	Creates a loft surface from the selected profiles, centerline, and guide curves.
	InsertMacroFeature	Obsolete. Superseded by IFeatureManager.InsertMacroFeature3 .
	InsertMidDraft	Obsolete. Superseded by IFeatureManager.InsertMultifaceDraft .
	InsertMidDraft2	Obsolete. Superseded by IFeatureManager.InsertMultifaceDraft .
	InsertMidSurfaceExt	Obsolete. Superseded by IFeatureManager.InsertMidSurface .
	InsertNewNote3	Creates a new note.
	InsertNote	Inserts a note in this document.
	InsertObject	Activates the Microsoft Insert Object dialog.
	InsertObjectFromFile	Obsolete. Superseded by IModelDocExtension.InsertObjectFromFile .
	InsertOffsetSurface	Inserts an offset surface.
	InsertPlanarRefSurface	Inserts a planar reference surface.
	InsertPoint	Inserts a point in this model document.
	InsertProjectedSketch	Obsolete. Superseded by IModelDoc2.InsertProjectedSketch2 .

		
	InsertProjectedSketch2	Obsolete. See IProjectionCurveFeatureData and IFeatureManager::CreateDefinition .
	InsertProtrusionBlend	Obsolete. Superseded by IFeatureManager::InsertProtrusionBlend .
	InsertProtrusionBlend2	Obsolete. Superseded by IFeatureManager::InsertProtrusionBlend .
	InsertProtrusionBlend3	Obsolete. Superseded by IFeatureManager::InsertProtrusionBlend .
	InsertProtrusionBlend4	Obsolete. Superseded by IFeatureManager::InsertProtrusionBlend .
	InsertProtrusionSweep	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertProtrusionSweep2	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertProtrusionSweep3	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertProtrusionSweep4	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertRadiateSurface	Creates a radiate surface based on the selections.
	InsertRefPoint	Inserts a reference point based on the current selections.
	InsertRevolvedRefSurface	Obsolete. Superseded by IFeatureManager::InsertRevolvedRefSurface .
	InsertRib	Obsolete. Superseded by IModelDoc2::InsertRib2 .
	InsertRib2	Obsolete. Superseded by IFeatureManager::InsertRib .
	InsertRip	Creates a rip feature.
	InsertRoutePoint	Adds a route point based on the selected point.
	InsertScale	Obsolete. Superseded by IFeatureManager::InsertScale .
	InsertSewRefSurface	Obsolete. Superseded by IFeatureManager::InsertSewRefSurface .
	InsertSheetMetal3dBend	Obsolete. Superseded by IFeatureManager::InsertSheetMetal3dBend .
	InsertSheetMetalBaseFlange	Obsolete. Superseded by IFeatureManager::InsertSheetMetalBaseFlange .
	InsertSheetMetalBreakCorner	Inserts a break corner into a sheet metal part.
	InsertSheetMetalClosedCorner	Inserts a sheet metal closed corner into this model document.
	InsertSheetMetalEdgeFlange	Obsolete. Superseded by IFeatureManager::InsertSheetMetalEdgeFlange2 .
	InsertSheetMetalFold	Inserts a fold feature at the selected objects.
	InsertSheetMetalHem	Obsolete. Superseded by IFeatureManager::InsertSheetMetalHem .
	InsertSheetMetalJog	Inserts a sheet metal jog in the current model document.
	InsertSheetMetalMiterFlange	Obsolete. Superseded by IFeatureManager::InsertSheetMetalMiterFlange .
	InsertSheetMetalUnfold	Inserts an unfold feature at the selected objects.
	InsertSketch	Obsolete. Superseded by ISketchManager::InsertSketch .
	InsertSketch2	Obsolete. Superseded by ISketchManager::InsertSketch .
	InsertSketchForEdgeFlange	Inserts a profile sketch of an edge flange in this sheet metal part.
	InsertSketchPicture	Inserts a picture into the current sketch.
	InsertSketchPictureData	Obsolete. Superseded by IModelDoc2::InsertSketchPictureData64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Inserts a picture into the current sketch.
	InsertSketchPictureData64	Inserts a picture into the current sketch in 64-bit applications.
	InsertSketchText	Inserts sketch text.
	InsertSplinePoint	Inserts a spline point.
	InsertSplitLineProject	Splits a face by projecting sketch lines onto the face.
	InsertSplitLineSil	Splits a face by creating split lines along the silhouette of the selected faces.

	InsertStackedBalloon	Obsolete. Superseded by IModelDocExtension::InsertStackedBalloon .
	InsertSurfaceFinishSymbol2	Obsolete. Superseded by IModelDocExtension::InsertSurfaceFinishSymbol3 .
	InsertSweepRefSurface	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertSweepRefSurface2	Obsolete. Superseded by IFeatureManager::InsertProtrusionSweep3 .
	InsertWeldSymbol2	Obsolete. Superseded by IModelDoc2::InsertWeldSymbol3 .
	InsertWeldSymbol3	Inserts a weld symbol into the model.
	InspectCurvature	Adds curvature combs to the selected sketch segment.
	IParameter	Gets the specified parameter.
	IRayIntersections	Obsolete. Superseded by IModelDocExtension::RayIntersections .
	IRelease3rdPartyStorage	Releases the specified third-party stream.
	IsActive	Gets whether the specified assembly component is shown or hidden in this model document.
	IsEditingSelf	Gets whether this model is being edited in the context of another document.
	ISelectByRay	Obsolete. Superseded by IModelDocExtension::SelectByRay .
	ISetAngularUnits	Sets the current angular units.
	ISetNextSelectionGroupId	Sets the group ID for all remaining selections.
	ISetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceTextFormat .
	IsExploded	Obsolete. Superseded by IModelDocExtension::IsExploded .
	ISketchSplineByEqnParams	Creates a spline on the active 2D sketch using the specified b-curve parameters.
	IsLightLockedToModel	Gets whether the specified light is fixed.
	IsOpenedReadOnly	Gets whether a SOLIDWORKS document is open in read-only mode.
	IsOpenedViewOnly	Gets whether a SOLIDWORKS document is open in view-only mode.
	IsTessellationValid	Gets whether the current set of facets is valid.
	IVersionHistory	Gets an array of strings indicating the versions in which this model document was saved, including the SOLIDWORKS Design version in which the model document is currently opened and which is the last value returned in the array.
	LBDownAt	Generates a left mouse button press (down) event.
	LBUpAt	Generates a left-mouse button release (up) event.
	Lights	Obsolete. Not superseded.
	ListAuxiliaryExternalFileReferences	Gets the names of auxiliary external file references for this model.
	ListAuxiliaryExternalFileReferencesCount	Gets the number of auxiliary external file references for this model.
	ListExternalFileReferences	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	ListExternalFileReferences2	Obsolete. Superseded by IModelDocExtension::ListExternalReferences .
	ListExternalFileReferencesCount	Obsolete. Superseded by IModelDocExtension::ListExternalFileReferenceCount .
	ListExternalFileReferencesCount2	Obsolete. Superseded by IModelDocExtension::ListExternalFileReferenceCount .
	Lock	Blocks the modifying commands in the user interface, effectively locking the application.
	LockAllExternalReferences	Locks all external references.
	LockFramePoint	Obsolete. Not superseded.
	LockLightToModel	Locks or unlocks the specified light.
	MoldDraftAnalysis	Performs a mold draft analysis.
	MultiSelectByRay	Selects multiple objects of the specified type that are intersected by a ray from point (x,y,z in meters) in direction vector (x,y,z) within a distance radius.
	NameView	Creates a named view using the current view.
	ObjectDisplayAsIcon	Shows the current OLE object as an icon.
	ObjectDisplayContent	Shows the current OLE object's content.
	ObjectResetSize	Sets the size of the current OLE object to the default.
	Parameter	Gets the specified parameter.

	ParentChildRelationship	Shows the Parent/Child Relationships dialog for the selected feature.
	Paste	Pastes the contents of the Microsoft Windows Clipboard at the current insertion point.
	PostTrimSurface	Obsolete. Superseded by IFeatureManager.PostTrimSurface .
	PreTrimSurface	Obsolete. Superseded by IFeatureManager.PreTrimSurface .
	PrintDirect	Prints the current document to the default printer.
	PrintOut	Obsolete. Superseded by IModelDocExtension.PrintOut2 and IModelDocExtension.IPrintOut2 .
	PrintOut2	Obsolete. Superseded by IModelDocExtension.PrintOut2 and IModelDocExtension.IPrintOut2 .
	PrintPreview	Displays the Print Preview page for the current document.
	PropertySheet	Displays the the selected object's property sheet.
	Quit	Closes the active document without saving changes (see Remarks).
	RayIntersections	Obsolete. Superseded by IModelDocExtension.RayIntersections .
	ReattachOrdinate	Reattaches an ordinate dimension to a different entity.
	Rebuild	Obsolete. Superseded by IModelDocExtension.Rebuild .
	ReloadOrReplace	Obsolete. Superseded by IModelDocExtension.ReloadOrReplace .
	RemoveGroups	Removes any annotation groups in the current selection.
	RemoveInspectCurvature	Removes curvature combs from the selected curved sketch segment.
	RemoveItemsFromGroup	Removes the selected annotations from their annotation groups.
	ResetBlockingState	Resets the blocking state for the SOLIDWORKS menus.
	ResetLightSourceExtProperty	Resets the properties for a light source.
	ResetPropertyExtension	Clears all values stored in the property extension.
	ResetSceneExtProperty	Resets the extension property for a scene.
	Save	Obsolete. Superseded by IModelDoc2.Save3 .
	Save2	Obsolete. Superseded by IModelDoc2.Save3 .
	Save3	Saves the current document.
	SaveAs	Obsolete. Superseded by IModelDocExtension.SaveAs .
	SaveAs2	Obsolete. Superseded by IModelDocExtension.SaveAs .
	SaveAs3	Obsolete. Superseded by IModelDocExtension.SaveAs .
	SaveAs4	Obsolete. Superseded by IModelDocExtension.SaveAs .
	SaveAsSilent	Obsolete. Superseded by IModelDocExtension.SaveAs .
	SaveBMP	Saves the current view as a bitmap (BMP) file.
	SaveSilent	Obsolete. Superseded by IModelDoc2.Save3 .
	Scale	Scales the part.
	ScreenRotate	Switches between model and screen center rotation.
	Select	Obsolete. Superseded by IModelDocExtension.SelectById2 .
	SelectAt	Obsolete. Superseded by IModelDocExtension.SelectById2 .
	SelectById	Obsolete. Superseded by IModelDocExtension.SelectById2 .
	SelectByMark	Obsolete. Superseded by IModelDocExtension.SelectById2 .
	SelectByName	Obsolete. Superseded by IModelDocExtension.SelectById2 .
	SelectByRay	Obsolete. Superseded by IModelDocExtension.SelectByRay .
	SelectedEdgeProperties	Sets the property values of the selected edge.
	SelectedFaceProperties	Sets the material property values of the selected face.
	SelectedFeatureProperties	Sets the property values of the selected feature.

		
	SelectLoop	Selects the loop that corresponds to the selected edge.
	SelectMidpoint	Puts the midpoint (swSelMIDPOINTS) of that edge on the selection list and removes the edge from the selection list when an edge is selected.
	SelectSketchArc	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	SelectSketchItem	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	SelectSketchLine	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	SelectSketchPoint	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	SelectSketchSpline	Obsolete. Superseded by IModelDocExtension::SelectByID2 .
	SelectTangency	Selects all faces tangent to the selected face.
	SetAddToDB	Obsolete. Superseded by ISketchManager::AddToDB .
	SetAmbientLightProperties	Sets ambient light properties.
	SetAngularUnits	Sets the current angular units.
	SetArcCentersDisplayed	Sets the current arc centers displayed setting.
	SetBendState	Sets the bend state of a sheet metal part.
	SetBlockingState	Sets the blocking state for the SOLIDWORKS menus.
	SetConsiderLeadersAsLines	Sets a flag on the document that indicates whether the display data of a leader should be included as lines when the lines are retrieved from a view or annotation in this document.
	SetDirectionLightProperties	Sets direction light properties.
	SetDisplayWhenAdded	Obsolete. Superseded by ISketchManager::DisplayWhenAdded .
	SetFeatureManagerWidth	Sets the width of the FeatureManager design tree.
	SetInferenceMode	Obsolete. Superseded by SketchManager::InferenceMode .
	SetLightSourceName	Sets the light source name used internally by the SOLIDWORKS Design software.
	SetLightSourcePropertyValuesVB	Sets the light source property values.
	SetParamValue	Sets the value of selected dimension (or parameter).
	SetPickMode	Returns the user to the default selection mode.
	SetPointLightProperties	Sets point light properties.
	SetPopupMenuMode	Sets the pop-up menu mode.
	SetReadOnlyState	Sets whether this document is read-only or read-write.
	SetSaveAsFileName	Sets the Save As filename from within the FileSaveAsNotify2 event handlers, thereby, bypassing the Save As dialog.
	SetSaveFlag	Flags the document as dirty.
	SetSceneBkgDIB	Obsolete. Superseded by IModelDocExtension::SetSceneBkgDIBx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets background image described by DIBSECTION data.
	SetSpotlightProperties	Sets the spotlight properties.
	SetTessellationQuality	Sets the shaded-display image quality number for the current document.
	SetTitle2	Sets the title of a new document.
	SetToolbarVisibility	Sets the visibility of a toolbar.
	SetUnits	Sets the units used by the end-user for the model.
	SetUserPreferenceDoubleValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceDouble .
	SetUserPreferenceIntegerValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceInteger .
	SetUserPreferenceStringValue	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceString .
	SetUserPreferenceTextFormat	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceTextFormat .

	SetUserPreferenceToggle	Obsolete. Superseded by IModelDocExtension::SetUserPreferenceToggle .
	SetZebraStripeData	Sets the zebra-line data.
	ShowComponent2	Shows the selected component.
	ShowConfiguration	Obsolete. Superseded by IModelDoc2::ShowConfiguration2 .
	ShowConfiguration2	Shows the named configuration by switching to that configuration and making it the active configuration.
	ShowCosmeticThread	Shows the selected cosmetic thread.
	ShowFeatureDimensions	Obsolete. Superseded by IModelDoc2::GetUserPreferenceToggle and IModelDoc2::SetUserPreferenceToggle and swDisplayFeatureDimensions .
	ShowNamedView	Obsolete. Superseded by IModelDoc2::ShowNameView2 .
	ShowNamedView2	Shows the specified view.
	ShowSolidBody	Shows the selected solid body.
	SimpleHole	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimpleHole2	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimpleHole3	Obsolete. Superseded by IFeatureManager::SimpleHole .
	SimplifySpline	Obsolete. Superseded by ISketchSpline::Simplify .
	Sketch3DIntersections	Creates new sketch segments based on the selected surfaces.
	SketchAddConstraints	Adds the specified constraint to the selected entities.
	SketchAlign	Aligns the selected sketch entities.
	SketchArc	Creates an arc in the current model document.
	SketchCenterline	Adds a centerline to the current model document.
	SketchChamfer	Obsolete. Superseded by ISketchManager::CreateChamfer .
	SketchCircle	Obsolete. Superseded by IModelDoc2::CreateCircle2 .
	SketchConstrainCoincident	Makes the selected sketch entities coincident.
	SketchConstrainConcentric	Makes the selected sketch entities concentric.
	SketchConstrainParallel	Makes the selected sketch entities parallel.
	SketchConstrainPerp	Makes the selected sketch entities perpendicular.
	SketchConstrainTangent	Makes the selected entities tangent.
	SketchConstraintsDel	Deletes the specified relationship (constraint) on the currently selected sketch item.
	SketchConstraintsDelAll	Deletes all of the constraints on the currently selected sketch segment.
	SketchConvertIsoCurves	Converts ISO-parametric curves on a selected surface into a sketch entity.
	SketchFillet	Obsolete. Superseded by IModelDoc2::SketchFillet2 .
	SketchFillet1	Obsolete. Superseded by IModelDoc2::SketchFillet2 .
	SketchFillet2	Obsolete. Superseded by ISketchManager::CreateFillet .
	SketchMirror	Creates new entities that are mirror images of the selected entities.
	SketchModifyFlip	Flips the the active or selected sketch about the specified coordinate system axis.
	SketchModifyRotate	Rotates the coordinate system of the active or selected sketch.
	SketchModifyScale	Scales the active or selected sketch.
	SketchModifyTranslate	Translates the coordinate system of the active or selected sketch.
	SketchOffset	Obsolete. Superseded by IModelDoc2::SketchOffset2 .
	SketchOffset2	Obsolete. Superseded by ISketchManager::SketchOffset .
	SketchOffsetEdges	Offsets the edges of the selected entities.
	SketchOffsetEntities	Obsolete. Superseded by IModelDoc2::SketchOffsetEntities2 .
	SketchOffsetEntities2	Generates entities in the active sketch by offsetting the selected geometry by the specified amount.
	SketchParabola	Obsolete. Superseded by ISketchManager::CreateParabola .

		
	SketchPoint	Obsolete. Superseded by IModelDoc2::CreatePoint2 and IModelDoc2::ICreatePoint2 .
	SketchPolygon	Obsolete. Superseded by ISketchManager::CreatePolygon .
	SketchRectangle	Obsolete. Superseded by ISketchManager::CreateCornerRectangle .
	SketchRectangleAtAnyAngle	Obsolete. Superseded by ISketchManager::Create3PointCornerRectangle .
	SketchSpline	Starts a spline, or continues one, using the specified point.
	SketchSplineByEqnParams	Obsolete. Superseded by IModelDoc2::ISketchSplineByEqnParams2 .
	SketchSplineByEqnParams2	Obsolete. Superseded by ISketchManager::CreateSplineByEqnParams .
	SketchTangentArc	Creates a tangent arc in the current model document.
	SketchTrim	Obsolete. Superseded by ISketchManager::SketchExtend and ISketchManager::SketchTrim .
	SketchUndo	Undoes the last sketch command.
	SketchUseEdge	Obsolete. Superseded by ISketchManager::SketchUseEdge .
	SketchUseEdge2	Obsolete. Superseded by ISketchManager::SketchUseEdge .
	SketchUseEdgeCrtline	Uses this centerline in sketch.
	SkToolsAutoConstr	Automatically constrains the active sketch.
	SplitClosedSegment	Obsolete. Superseded by ISketchManager::SplitClosedSegment .
	SplitOpenSegment	Obsolete. Superseded by ISketchManager::SplitOpenSegment .
	Toolbars	Turns the specified SOLIDWORKS toolbars on and off.
	ToolsDistance	Computes distance.
	ToolsGrid	Shows and hides the grid in this model document.
	ToolsMacro	Not implemented.
	ToolsMassProps	Calculates the mass properties.
	ToolsSketchScale	Scales a sketch.
	ToolsSketchTranslate	Translates a sketch.
	UnBlankRefGeom	Shows the selected, hidden reference geometry in the graphics window.
	UnblankSketch	Shows a hidden sketch.
	UnderiveSketch	Changes a sketch to underived.
	UnLock	Reverses IModelDoc2::Lock and changes the status bar message to Process Complete .
	UnlockAllExternalReferences	Unlocks all external references.
	UnlockFramePoint	Obsolete. Not superseded.
	UserFavors	Specifies whether geometric relations are automatically created as you add sketch entities.
	UserPreferences	Obsolete. The See Also section of this topic contains links to the methods that supersede this method.
	VersionHistory	Gets an array of strings indicating the versions in which this document was saved, including the SOLIDWORKS Design version in which the model document is currently opened and which is the last value returned in the array.
	ViewConstraint	Shows the constraints for the current model document.
	ViewDispCoordinateSystems	Toggles the display of coordinate systems on and off.
	ViewDisplayCurvature	Toggles the display of surface curvature on and off.
	ViewDisplayFaceted	Sets the current display mode to show the facets that make up a shaded picture of STL output.
	ViewDisplayHiddengreyed	Sets the current display mode to Hidden Lines Visible .
	ViewDisplayHiddenremoved	Sets the current display mode to Hidden Lines Removed .
	ViewDisplayShaded	Sets the current display mode to Shaded .
	ViewDisplayWireframe	Sets the current display mode to Wireframe .
	ViewDispOrigins	Toggles the display of origins off and on.
	ViewDispRefaxes	Toggles the display of reference axis on and off.

		
	ViewDispRefPlanes	Toggles the display of reference planes on and off.
	ViewDispRefPoints	Shows and hides the reference points for the current model document.
	ViewDispTempRefAxes	Toggles the display of temporary reference axes on and off.
	ViewOglShading	Sets the current display subsystem to use OpenGL.
	ViewOrientationUndo	Undoes previous view orientation changes that were made interactively by the user.
	ViewRotate	Rotates the view of the current model.
	ViewRotateminusx	Dynamically rotates the view around x in a negative direction with the current increment.
	ViewRotateminusy	Dynamically rotates the view around y in a negative direction with the current increment.
	ViewRotateminusz	Dynamically rotates the view around z in a negative direction with the current increment.
	ViewRotateplusx	Rotates the view around x in a positive direction with the current increment.
	ViewRotateplusy	Rotates the view around y in a positive direction with the current increment.
	ViewRotateplusz	Rotates the view around z in a positive direction with the current increment.
	ViewRotXMinusNinety	Dynamically rotates the view by negative 90 about x.
	ViewRotXPlusNinety	Dynamically rotates the view by 90 about x.
	ViewRotYMinusNinety	Dynamically rotates the view by negative 90 about y.
	ViewRotYPlusNinety	Dynamically rotates the view by 90 about y.
	ViewRwShading	Sets the current display subsystem to use renderware.
	ViewTranslate	Translates the view.
	ViewTranslateminusx	Dynamically shifts the view left.
	ViewTranslateminusy	Dynamically shifts the view down.
	ViewTranslateplusx	Dynamically shifts the view right.
	ViewTranslateplusy	Dynamically shifts the view up.
	ViewZoomin	Zooms the current view in by a factor of 20%.
	ViewZoomout	Zooms the current view out by a factor of 20%.
	ViewZoomto	Zooms the view to the selected box.
	ViewZoomTo2	Zooms to the specified region.
	ViewZoomtofit	Obsolete. Superseded by IModelDoc2::ViewZoomtofit2
	ViewZoomtofit2	Zooms the currently active view to fit the screen.
	ViewZoomToSelection	Zooms the display to the selection.
	WindowRedraw	Redraws the current window.

[Top](#)

See Also

[IModelDoc2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)