

SOLIDWORKS API (.NET VBA C#) — Reference

(181/337): IModelDoc2 (part 4 of 17)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc2 (part 4 of 17) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreatePlanePerCurveAndPassPoint3 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlanePerCurveAndPassPoint3 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::InsertRefPlane](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePlanePerCurveAndPassPoint3( _  
    ByVal OrigAtCurve As System.Boolean, _  
    ByVal AutoSize As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim OrigAtCurve As System.Boolean  
Dim AutoSize As System.Boolean  
Dim value As System.Object  
  
value = instance.CreatePlanePerCurveAndPassPoint3(OrigAtCurve, AutoSize)
```

C#

```
System.Object CreatePlanePerCurveAndPassPoint3(  
    System.bool OrigAtCurve,  
    System.bool AutoSize  
)
```

C++/CLI

```
System.Object^ CreatePlanePerCurveAndPassPoint3(  
& System.bool OrigAtCurve,  
& System.bool AutoSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OrigAtCurve

True if you want the origin to be on the curve, false if not

AutoSize

True to automatically size the plane, false to not

Return Value

Newly created [reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlanePerCurveAndPassPoint3](#).

Example

[Create Plane Using Curve and Point \(VBA\)](#)

Remarks

This method uses the current document setting for displaying the reference plane. If display of reference planes is disabled, then you do not see the reference plane on the screen. If display of reference planes is enabled, then you see it. [IModelDocExtension::GetUserPreferenceToggle](#) swDisplayPlanes and [IModelDocExtension::SetUserPreferenceToggle](#) swDisplayPlanes get or set this display preference.

This method does not select the reference plane after it is created. Objects that are selected before running this method are still selected when the method completes, not the newly created reference plane.

This method returns an IRefPlane object. This object can then be used for subsequent operations on the reference plane feature. Having a IRefPlane object may not be useful, except that it is a feature, which is an entity, so methods available on those objects are available. For an OLE user, those functions are directly accessible; for a COM user, those functions are available via QueryInterface. For example, to select the reference plane, use [IEntity::Select4](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreatePlaneAtAngle3 Method](#)
[IModelDoc2::CreatePlaneAtOffset3 Method](#)
[IModelDoc2::CreatePlaneAtSurface3 Method](#)
[IModelDoc2::CreatePlaneFixed2 Method](#)
[IModelDoc2::CreatePlaneThru3Points3 Method](#)
[IModelDoc2::CreatePlaneThruLineAndPt Method](#)
[IModelDoc2::CreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::ICreatePlaneAtAngle3 Method](#)
[IModelDoc2::ICreatePlaneAtOffset3 Method](#)
[IModelDoc2::ICreatePlaneAtSurface3 Method](#)
[IModelDoc2::ICreatePlaneFixed2 Method](#)
[IModelDoc2::ICreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::ICreatePlaneThru3Points3 Method](#)
[IModelDoc2::ICreatePlaneThruLineAndPt Method](#)
[IModelDoc2::ICreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::GetVisibilityOfConstructPlanes Method](#)
[IModelDoc2::ViewDispRefplanes Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePlaneThru3Points Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlaneThru3Points Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::CreatePlaneThru3Points3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub CreatePlaneThru3Points()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.CreatePlaneThru3Points()
```

C#

```
void CreatePlaneThru3Points()
```

C++/CLI

```
void CreatePlaneThru3Points();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlaneThru3Points](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePlaneThru3Points2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlaneThru3Points2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::CreatePlaneThru3Points3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePlaneThru3Points2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.CreatePlaneThru3Points2()
```

C#

```
System.object CreatePlaneThru3Points2()
```

C++/CLI

```
System.Object^ CreatePlaneThru3Points2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlaneThru3Points2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePlaneThru3Points3 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlaneThru3Points3 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::InsertRefPlane](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePlaneThru3Points3( _  
    ByVal AutoSize As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim AutoSize As System.Boolean  
Dim value As System.Object  
  
value = instance.CreatePlaneThru3Points3(AutoSize)
```

C#

```
System.object CreatePlaneThru3Points3(  
    System.bool AutoSize  
)
```

C++/CLI

```
System.Object^ CreatePlaneThru3Points3(
& System.bool AutoSize
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoSize

True to automatically size the plane, false to not

Return Value

Newly created [reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlaneThru3Points3](#).

Example

[Create Plane Thru 3 Points In-context \(VBA\)](#)

Remarks

This method uses the current document setting for displaying the reference plane. If display of reference planes is disabled, then you do not see the reference plane on the screen. If display of reference planes is enabled, then you see it. [IModelDocExtension::GetUserPreferenceToggle](#) swDisplayPlanes and [IModelDocExtension::SetUserPreferenceToggle](#) swDisplayPlanes get or set this display preference.

This method does not select the reference plane after it is created. Objects that are selected before running this method are still selected when the method completes, not the newly created reference plane.

This method returns an IRefPlane object. This object can then be used for subsequent operations on the reference plane feature. Having a IRefPlane object may not be useful, except that it is a feature, which is an entity, so methods available on those objects are available. For an OLE user, those functions are directly accessible; for a COM user, those functions are available via QueryInterface. For example, to select the reference plane, use [IEntity::Select4](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreatePlaneAtAngle3 Method](#)
[IModelDoc2::CreatePlaneAtOffset3 Method](#)
[IModelDoc2::CreatePlaneAtSurface3 Method](#)
[IModelDoc2::CreatePlaneFixed2 Method](#)
[IModelDoc2::CreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::CreatePlaneThruLineAndPt Method](#)
[IModelDoc2::CreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::ICreatePlaneAtAngle3 Method](#)
[IModelDoc2::ICreatePlaneAtOffset3 Method](#)
[IModelDoc2::ICreatePlaneAtSurface3 Method](#)
[IModelDoc2::ICreatePlaneFixed2 Method](#)
[IModelDoc2::ICreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::ICreatePlaneThru3Points3 Method](#)
[IModelDoc2::ICreatePlaneThruLineAndPt Method](#)
[IModelDoc2::ICreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::GetVisibilityOfConstructPlanes Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePlaneThruLineAndPt Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlaneThruLineAndPt Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::InsertRefPlane](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePlaneThruLineAndPt( _
    ByVal AutoSize As System.Boolean _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim AutoSize As System.Boolean
Dim value As System.Object

value = instance.CreatePlaneThruLineAndPt(AutoSize)
```

C#

```
System.object CreatePlaneThruLineAndPt(
    System.bool AutoSize
)
```

C++/CLI

```
System.Object^ CreatePlaneThruLineAndPt(
    & System.bool AutoSize
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoSize

True to automatically size the plane, false to not

Return Value

Newly created [reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlaneThruLineAndPt](#).

Remarks

This method uses the current document setting for displaying the reference plane. If display of reference planes is disabled, then you do not see the reference plane on the screen. If display of reference planes is enabled, then you see it. [IModelDocExtension::GetUserPreferenceToggle](#) swDisplayPlanes and [IModelDocExtension::SetUserPreferenceToggle](#) swDisplayPlanes get or set this display preference.

This method does not select the reference plane after it is created. Objects that are selected before running this method are still selected when the method completes, not the newly created reference plane.

This method returns an IRefPlane object. This object can then be used for subsequent operations on the reference plane feature. Having a IRefPlane object may not be useful, except that it is a feature, which is an entity, so methods available on those objects are available. For an OLE user, those functions are directly accessible; for a COM user, those functions are available via QueryInterface. For example, to select the reference plane, use [IEntity::Select4](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreatePlaneAtAngle3 Method](#)
[IModelDoc2::CreatePlaneAtOffset3 Method](#)
[IModelDoc2::CreatePlaneAtSurface3 Method](#)
[IModelDoc2::CreatePlaneFixed2 Method](#)
[IModelDoc2::CreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::CreatePlaneThru3Points3 Method](#)
[IModelDoc2::CreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::ICreatePlaneAtAngle3 Method](#)
[IModelDoc2::ICreatePlaneAtOffset3 Method](#)
[IModelDoc2::ICreatePlaneAtSurface3 Method](#)
[IModelDoc2::ICreatePlaneFixed2 Method](#)
[IModelDoc2::ICreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::ICreatePlaneThru3Points3 Method](#)
[IModelDoc2::ICreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::GetVisibilityOfConstructPlanes Method](#)
[IModelDoc2::ViewDispRefplanes Method](#)

Availability

CreatePlaneThruPtParallelToPlane Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePlaneThruPtParallelToPlane Method (IModelDoc2)Obsolete. Superseded by [IFeatureManager::InsertRefPlane](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePlaneThruPtParallelToPlane( _
    ByVal AutoSize As System.Boolean _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim AutoSize As System.Boolean
Dim value As System.Object

value = instance.CreatePlaneThruPtParallelToPlane(AutoSize)
```

C#

```
System.object CreatePlaneThruPtParallelToPlane(
    System.bool AutoSize
)
```

C++/CLI

```
System.Object^ CreatePlaneThruPtParallelToPlane(
    & System.bool AutoSize
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoSize

True to automatically size the plane, false to not

Return Value

Newly created [reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePlaneThruPtParallelToPlane](#).

Remarks

This method uses the current document setting for displaying the reference plane. If display of reference planes is disabled, then you do not see the reference plane on the screen. If display of reference planes is enabled, then you see it. [IModelDocExtension::GetUserPreferenceToggle](#) and [IModelDocExtension::SetUserPreferenceToggle](#), with `swDisplayPlanes`, get or set this display preference.

This method does not select the reference plane after it is created. Objects that are selected before running this method are still selected when the method completes, not the newly created reference plane.

This method returns an `IRefPlane` object. This object can then be used for subsequent operations on the reference plane feature. Having a `IRefPlane` object may not be useful, except that it is a feature, which is an entity, so methods available on those objects are available. For an OLE user, those functions are directly accessible; for a COM user, those functions are available via `QueryInterface`. For example, to select the reference plane, use [IEntity::Select4](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreatePlaneAtAngle3 Method](#)
[IModelDoc2::CreatePlaneAtOffset3 Method](#)

[IModelDoc2::CreatePlaneAtSurface3 Method](#)
[IModelDoc2::CreatePlaneFixed2 Method](#)
[IModelDoc2::CreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::CreatePlaneThru3Points3 Method](#)
[IModelDoc2::CreatePlaneThruLineAndPt Method](#)
[IModelDoc2::ICreatePlaneAtAngle3 Method](#)
[IModelDoc2::ICreatePlaneAtOffset3 Method](#)
[IModelDoc2::ICreatePlaneAtSurface3 Method](#)
[IModelDoc2::ICreatePlaneFixed2 Method](#)
[IModelDoc2::ICreatePlanePerCurveAndPassPoint3 Method](#)
[IModelDoc2::ICreatePlaneThru3Points3 Method](#)
[IModelDoc2::ICreatePlaneThruLineAndPt Method](#)
[IModelDoc2::ICreatePlaneThruPtParallelToPlane Method](#)
[IModelDoc2::GetVisibilityOfConstructPlanes Method](#)
[IModelDoc2::ViewDispRefPlanes Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePoint Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePoint Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::CreatePoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePoint( _  
    ByVal PointX As System.Double, _  
    ByVal PointY As System.Double, _  
    ByVal PointZ As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim PointX As System.Double  
Dim PointY As System.Double  
Dim PointZ As System.Double  
Dim value As System.Boolean  
  
value = instance.CreatePoint(PointX, PointY, PointZ)
```

C#

```
System.bool CreatePoint(  
    System.double PointX,  
    System.double PointY,  
    System.double PointZ  
)
```

C++/CLI

```
System.bool CreatePoint(  
& System.double PointX,  
& System.double PointY,  
& System.double PointZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointX

PointY

PointZ

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePoint](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreatePoint2 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePoint2 Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::CreatePoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePoint2( _  
    ByVal PointX As System.Double, _  
    ByVal PointY As System.Double, _  
    ByVal PointZ As System.Double _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim PointX As System.Double  
Dim PointY As System.Double  
Dim PointZ As System.Double  
Dim value As System.Object  
  
value = instance.CreatePoint2(PointX, PointY, PointZ)
```

C#

```
System.object CreatePoint2(  
    System.double PointX,  
    System.double PointY,  
    System.double PointZ  
)
```

C++/CLI

```
System.Object^ CreatePoint2(  
& System.double PointX,  
& System.double PointY,  
& System.double PointZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointX
X location of the point
PointY
Y location of the point
PointZ
Z location of the point; ignored for 2D sketches

Return Value

Newly created [sketch point](#); this value is NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePoint2](#).

Example

[Calculate Closest Distance Between Model Components \(VBA\)](#)
[Create Plane Thru 3 Points In-context \(VBA\)](#)
[Get Intersecting Face and Edge \(VBA\)](#)
[Get Length of Spline or Elliptical Edge \(VBA\)](#)

Remarks

This method creates a point in the active 2D or 3D sketch. If a sketch is not active, the point is not created and NULL is returned. Use [IModelDoc2::GetActiveSketch2](#) or [IModelDoc2::!GetActiveSketch2](#) to check to see if the sketch is active.

[IModelDoc2::SetAddToDB](#) and [IModelDoc2::SetDisplayWhenAdded](#) increase performance during entity creation by adding entities directly to the SOLIDWORKS database. [IModelDoc2::SetAddToDB](#) also avoids inferencing.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::!CreatePoint2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreatePointDB Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreatePointDB Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::CreatePoint2](#) and [IModelDoc2::!CreatePoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreatePointDB( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.CreatePointDB(X, Y, Z)
```

C#

```
System.bool CreatePointDB(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool CreatePointDB(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
Y
Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreatePointDB](#).

Remarks

IMPORTANT: This method ignores the z value when adding a point to a 3D sketch. Thus, update your code to use the more current method, `IModelDoc2::CreatePoint2` or `IModelDoc2::ICreatePoint2`.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSpline Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreateSpline Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::CreateSpline](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSpline( _  
    ByVal PointData As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim PointData As System.Object  
Dim value As System.Object  
  
value = instance.CreateSpline(PointData)
```

C#

```
System.object CreateSpline(  
    System.object PointData  
)
```

C++/CLI

```
System.Object^ CreateSpline(  
& System.Object^ PointData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointData

Set of X,Y,Z point coordinates to use in creating the spline (see **Remarks**)

Return Value

Newly created spline

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateSpline](#).

Example

[Create 3D Spline \(VBA\)](#)

Remarks

This method creates a spline in the active 2D sketch. If a sketch is not active, then a new sketch is created. Use [IModelDoc2::GetActiveSketch2](#) or [IModelDoc2::IGetActiveSketch2](#) to check if the sketch active.

The PointData array is a set of, at least, two X, Y, Z values. The X value for the start point of the spline is PointData[0], the Y value for the start point is PointData[1], and the Z value for the start point is PointData[2]. The X value for the next point is PointData[3], and so on. For the COM interface, the total number of points in the array must be passed in. For the OLE interface, the total number of points are determined automatically, by taking the UBound of the PointData VARIANT and dividing by 3, so be careful to dimension that array correctly.

For COM applications, you can use the object pointer returned from this method to call any APIs on the [ISketchSegment](#) interface. You can obtain the underlying [ISketchSpline](#) object by using QueryInterface on the returned ISketchSegment object.

OLE applications can define a new ISketchSegment or ISketchSpline object using the returned Dispatch pointer. Visual Basic applications interpret the pointer for you automatically, so you can use the returned object to call SketchSegment or [ISketchEllipse](#) APIs.

This method does not work with [IModelDoc2::SetAddToDB](#) or [IModelDoc2::SetDisplayWhenAdded](#). It always adds the spline directly to the database (as if IModelDoc2::SetAddToDB(True) was in effect), and you must redraw your document window to see the entities that you added (as if IModelDoc2::SetDisplayWhenAdded(false) was in effect).

In 2D sketches, SOLIDWORKS ignores the Z value in PointData.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreateSplineByEqnParams Method](#)
[IModelDoc2::CreateSplinesByEqnParams Method](#)
[IModelDoc2::ICreateSpline Method](#)
[IModelDoc2::ICreateSplineByEqnParams Method](#)
[IModelDoc2::ICreateSplinesByEqnParams Method](#)
[IModelDoc2::InsertSplinePoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateSplineByEqnParams Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreateSplineByEqnParams Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::CreateSplineByEqnParams](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSplineByEqnParams( _  
    ByVal ParamsIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ParamsIn As System.Object  
Dim value As System.Object
```

```
value = instance.CreateSplineByEqnParams(ParamsIn)
```

C#

```
System.object CreateSplineByEqnParams(  
    System.object ParamsIn  
)
```

C++/CLI

```
System.Object^ CreateSplineByEqnParams(  
& System.Object^ ParamsIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParamsIn

Array containing an array of doubles to use in creating the spline

Return Value

Newly created spline

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateSplineByEqnParams](#).

Remarks

The parameters are provided as three arrays, which for OLE automation are packed into a single SafeArray, which is packed as follows:

[*Dimension*, *Order*, *Number of control Points*, *Periodicity*, *knot1*, *knot2*,...,*ControlPoint1[Dimension]*, *ControlPoint2[Dimension]*,...]

Pass the control point coordinates to this routine in sketch space. The Z value is interpreted as 0. In certain situations, you must transform your B-curve parameters to sketch space using [ISketch::ModelToSketchTransform](#).

NOTE: The curve can be either periodic or non-periodic. If the generated spline is a closed spline, then it must be flagged as periodic. Additionally, splines generated in sketches must be G1 continuous. If the data passed to this method does not generate a G1 continuous spline, then it is rejected and a spline is not created. If your data is not G1 continuous, then you must split the spline into multiple G1 segments and call this method for each segment.

For the OLE interface, you can use the returned object pointer directly to call any APIs on the [ISketchSpline](#) interface or its base class, [ISketchSegment](#).

This method does not work with [IModelDoc2::SetAddToDB](#) or [IModelDoc2::SetDisplayWhenAdded](#). It always adds the spline directly to the database (as if [IModelDoc2::SetAddToDB](#)(True) is in effect), and you must redraw your document window to see the entities that you added (as [IModelDoc2::SetDisplayWhenAdded](#)(false) is in effect).

To create 3D splines, see [IModelDoc2::InsertCurveFilePoint](#) and related functions.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreateSplinesByEqnParams Method](#)
[IModelDoc2::ICreateSpline Method](#)
[IModelDoc2::ICreateSplineByEqnParams Method](#)
[IModelDoc2::ICreateSplinesByEqnParams Method](#)
[IModelDoc2::CreateSpline Method](#)
[IModelDoc2::InsertCurveFile Method](#)
[IModelDoc2::InsertCurveFileBegin Method](#)
[IModelDoc2::InsertCurveFileEnd Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateSplinesByEqnParams Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : [CreateSplinesByEqnParams Method \(IModelDoc2\)](#)

Obsolete. Superseded by [ISketchManager::CreateSplinesByEqnParams](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSplinesByEqnParams( _  
    ByVal ParamsIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim ParamsIn As System.Object
Dim value As System.Object

value = instance.CreateSplinesByEqnParams(ParamsIn)
```

C#

```
System.Object CreateSplinesByEqnParams(
    System.Object ParamsIn
)
```

C++/CLI

```
System.Object^ CreateSplinesByEqnParams(
    & System.Object^ ParamsIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParamsIn
Array containing an array of doubles to use in creating the spline (see **Remarks**)

Return Value

Array containing an array of objects of the newly created splines

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateSplinesByEqnParams](#).

Remarks

The parameters are provided as three arrays, which for OLE automation are packed into a single SafeArray, which is packed as follows:

[*Dimension*, *Order*, *Number of control Points*, *Periodicity*, *knot1*, *knot2*,...,*ControlPoint1[Dimension]*, *ControlPoint2[Dimension]*,...]

Pass the control point coordinates to this routine in sketch space. The Z value is interpreted as 0. In certain situations, you must transform your B-curve parameters to sketch space using [ISketch::ModelToSketchTransform](#).

NOTE: If the generated spline is a closed spline, then it must be flagged as periodic. Additionally, splines generated in sketches must be G1 continuous. If the data passed to this method does not generate a G1 continuous spline, then it is rejected and a spline is not created. If your data is not G1 continuous, then you must split the spline into multiple G1 segments and call this method for each segment.

For the OLE interface, you can use the returned object pointer directly to call any APIs on the [ISketchSpline](#) interface or its base class, [ISketchSegment](#).

This method does not work with [IModelDoc2::SetAddToDB](#) or [IModelDoc2::SetDisplayWhenAdded](#). It always adds the spline directly to the database (as if [IModelDoc2::SetAddToDB\(True\)](#) is in effect), and you must redraw your document window to see the entities that you added (as [IModelDoc2::SetDisplayWhenAdded\(false\)](#) is in effect).

To create 3D splines, see [IModelDoc2::InsertCurveFilePoint](#) and related functions.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CreateSpline Method](#)
[IModelDoc2::CreateSplineByEqnParams Method](#)
[IModelDoc2::ICreateSpline Method](#)
[IModelDoc2::ICreateSplineByEqnParams Method](#)
[IModelDoc2::ICreateSplinesByEqnParams Method](#)
[IModelDoc2::InsertCurveFile Method](#)
[IModelDoc2::InsertCurveFileBegin Method](#)
[IModelDoc2::InsertCurveFileEnd Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreateTangentArc Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::CreateTangentArc2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateTangentArc(  
    ByVal P1x As System.Double, _  
    ByVal P1y As System.Double, _  
    ByVal P1z As System.Double, _  
    ByVal P2x As System.Double, _  
    ByVal P2y As System.Double, _  
    ByVal P2z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim P1x As System.Double  
Dim P1y As System.Double  
Dim P1z As System.Double  
Dim P2x As System.Double  
Dim P2y As System.Double  
Dim P2z As System.Double  
Dim value As System.Boolean  
  
value = instance.CreateTangentArc(P1x, P1y, P1z, P2x, P2y, P2z)
```

C#

```
System.bool CreateTangentArc(  
    System.double P1x,  
    System.double P1y,  
    System.double P1z,  
    System.double P2x,  
    System.double P2y,  
    System.double P2z  
)
```

C++/CLI

```
System.bool CreateTangentArc(  
& System.double P1x,  
& System.double P1y,  
& System.double P1z,  
& System.double P2x,  
& System.double P2y,  
& System.double P2z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P1x

P1y

P1z

P2x

P2y

P2z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateTangentArc](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateTangentArc2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CreateTangentArc2 Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::CreateTangentArc](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateTangentArc2( _  
    ByVal P1x As System.Double, _  
    ByVal P1y As System.Double, _  
    ByVal P1z As System.Double, _  
    ByVal P2x As System.Double, _  
    ByVal P2y As System.Double, _  
    ByVal P2z As System.Double, _  
    ByVal ArcTypeIn As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim P1x As System.Double  
Dim P1y As System.Double  
Dim P1z As System.Double  
Dim P2x As System.Double  
Dim P2y As System.Double  
Dim P2z As System.Double  
Dim ArcTypeIn As System.Integer  
Dim value As System.Boolean
```

```
value = instance.CreateTangentArc2(P1x, P1y, P1z, P2x, P2y, P2z, ArcTypeIn)
```

C#

```
System.bool CreateTangentArc2(  
    System.double P1x,  
    System.double P1y,  
    System.double P1z,  
    System.double P2x,  
    System.double P2y,  
    System.double P2z,  
    System.int ArcTypeIn  
)
```

C++/CLI

```
System.bool CreateTangentArc2(  
& System.double P1x,  
& System.double P1y,  
& System.double P1z,  
& System.double P2x,  
& System.double P2y,  
& System.double P2z,  
& System.int ArcTypeIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[P1x](#)

x coordinate of start point in meters

P1y
y coordinate of start point in meters

P1z
Always 0

P2x
x coordinate of end point in meters

P2y
y coordinate of end point in meters

P2z
Always 0

ArcTypeIn
Type of tangent arc as defined in [swTangentArcTypes_e](#)

Return Value

1 = success, 0 = failure

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CreateTangentArc2](#).

Remarks

This method can only create 2D tangent arcs. Use [ISketchManager::CreateTangentArc](#) to create 3D tangent arcs.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::Create3PointArc Method](#)
[IModelDoc2::CreateArc2 Method](#)
[IModelDoc2::CreateArcByCenter Method](#)
[IModelDoc2::ICreateArc2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomInfo Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CustomInfo Property (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CustomInfo( _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FieldName As System.String  
Dim value As System.String  
  
instance.CustomInfo(FieldName) = value  
  
value = instance.CustomInfo(FieldName)
```

C#

```
System.string CustomInfo(  
    System.string FieldName  
) {get; set;}
```

C++/CLI

```
property System.String^ CustomInfo {  
    System.String^ get(System.String^ FieldName);  
    void set (System.String^ FieldName, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CustomInfo](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomInfo2 Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : CustomInfo2 Property (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CustomInfo2( _  
    ByVal Configuration As System.String, _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim FieldName As System.String  
Dim value As System.String  
  
instance.CustomInfo2(Configuration, FieldName) = value  
value = instance.CustomInfo2(Configuration, FieldName)
```

C#

```
System.string CustomInfo2(  
    System.string Configuration,  
    System.string FieldName  
) {get; set;}
```

C++/CLI

```
property System.String^ CustomInfo2 {  
    System.String^ get(System.String^ Configuration, System.String^ FieldName);  
    void set (System.String^ Configuration, System.String^ FieldName, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::CustomInfo2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeActivateFeatureMgrView Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeActivateFeatureMgrView Method (IModelDoc2)

Deactivates a tab in the FeatureManager design tree view.

.NET Syntax

Visual Basic (Declaration)

```
Function DeActivateFeatureMgrView( _  
    ByRef AppView As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim AppView As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeActivateFeatureMgrView(AppView)
```

C#

```
System.bool DeActivateFeatureMgrView(  
    ref System.int AppView  
)
```

C++/CLI

```
System.bool DeActivateFeatureMgrView(  
& System.int% AppView  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppView

Pointer to the FeatureManager design tree view

Return Value

True if deactivated, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeActivateFeatureMgrView](#).

Remarks

This method is valid only for x86 applications.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddFeatureMgrView3 Method](#)
[IModelDocExtension::DeActivateFeatureMgrView64 Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DebugCheckIgesGeom Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DebugCheckIgesGeom Method (IModelDoc2)

Dumps a IGES geometry check.

.NET Syntax

Visual Basic (Declaration)

```
Sub DebugCheckIgesGeom()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.DebugCheckIgesGeom()
```

C#

```
void DebugCheckIgesGeom()
```

C++/CLI

```
void DebugCheckIgesGeom();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DebugCheckIgesGeom](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteAllRelations Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteAllRelations Method (IModelDoc2)

Deletes all existing relations.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteAllRelations()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.DeleteAllRelations()
```

C#

```
void DeleteAllRelations()
```

C++/CLI

```
void DeleteAllRelations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteAllRelations](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::ViewConstraint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteBendTable Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteBendTable Method (IModelDoc2)

Deletes a bend table.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteBendTable()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.DeleteBendTable()
```

C#

```
void DeleteBendTable()
```

C++/CLI

```
void DeleteBendTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteBendTable](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::InsertBendTableEdit Method](#)
[IModelDoc2::InsertBendTableNew Method](#)
[IModelDoc2::InsertBendTableOpen Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DeleteBkgImage Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteBkgImage Method (IModelDoc2)

Deletes any background image.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteBkgImage()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.DeleteBkgImage()
```

C#

```
void DeleteBkgImage()
```

C++/CLI

```
void DeleteBkgImage();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteBkgImage](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::InsertBkgImage Method](#)
[IModelDoc2::SetSceneBkgDIB Method](#)
[IModelDoc2::SceneBkgImageFileName Property](#)
[IModelDoc2::GetSceneBkgDIB Method](#)
[IModelDocExtension::GetSceneBkgDIBx64 Method](#)
[IModelDocExtension::SetSceneBkgDIBx64 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DeleteConfiguration Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteConfiguration Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::DeleteConfiguration2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteConfiguration( _  
    ByVal ConfigurationName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
Dim ConfigurationName As System.String
```

```
instance.DeleteConfiguration(ConfigurationName)
```

C#

```
void DeleteConfiguration(  
    System.string ConfigurationName  
)
```

C++/CLI

```
void DeleteConfiguration(  
& System.String^ ConfigurationName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigurationName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteConfiguration](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteConfiguration2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteConfiguration2 Method (IModelDoc2)

Deletes a configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteConfiguration2( _  
    ByVal ConfigurationName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ConfigurationName As System.String  
Dim value As System.Boolean
```

```
value = instance.DeleteConfiguration2(ConfigurationName)
```

C#

```
System.bool DeleteConfiguration2(  
    System.string ConfigurationName  
)
```

C++/CLI

```
System.bool DeleteConfiguration2(  
& System.String^ ConfigurationName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigurationName

Name of the configuration to delete

Return Value

True if the configuration is deleted, false if not

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteConfiguration2](#).

 Remarks

The configuration cannot be the active configuration.

 See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddConfiguration3 Method](#)
[IModelDoc2::EditConfiguration3 Method](#)
[IModelDoc2::GetConfigurationByName Method](#)
[IModelDoc2::GetConfigurationCount Method](#)
[IModelDoc2::GetConfigurationNames Method](#)
[IModelDoc2::ShowConfiguration2 Method](#)
[IModelDoc2::IAddConfiguration3 Method](#)
[IModelDoc2::IGetConfigurationByName Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IConfigurationManager Interface](#)
[IConfiguration Interface](#)
[IModelDoc2::ConfigurationManager Property](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteCustomInfo Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteCustomInfo Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function DeleteCustomInfo( _  
    ByVal FieldName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FieldName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteCustomInfo(FieldName)
```

C#

```
System.bool DeleteCustomInfo(  
    System.string FieldName  
)
```

C++/CLI

```
System.bool DeleteCustomInfo(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteCustomInfo](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteCustomInfo2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteCustomInfo2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteCustomInfo2( _  
    ByVal Configuration As System.String, _  
    ByVal FieldName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim FieldName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteCustomInfo2(Configuration, FieldName)
```

C#

```
System.bool DeleteCustomInfo2(  
    System.string Configuration,  
    System.string FieldName  
)
```

C++/CLI

```
System.bool DeleteCustomInfo2(  
    & System.String^ Configuration,  
    & System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteCustomInfo2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

DeleteDesignTable Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteDesignTable Method (IModelDoc2)

Deletes the design table for this document, if one exists.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteDesignTable()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.DeleteDesignTable()
```

C#

```
void DeleteDesignTable()
```

C++/CLI

```
void DeleteDesignTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteDesignTable](#).

Example

[Delete Design Table \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetDesignTable Method](#)
[IModelDoc2::IGetDesignTable Method](#)
[IDesignTable Interface](#)
[IModelDoc2::CloseFamilyTable Method](#)
[IModelDoc2::InsertFamilyTableEdit Method](#)
[IModelDoc2::InsertFamilyTableNew Method](#)
[IModelDoc2::InsertFamilyTableOpen Method](#)
[IModelDocExtension::HasDesignTable Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DeleteFeatureMgrView Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteFeatureMgrView Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::DeleteFeatureMgrViewx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Removes the specified tab in the FeatureManager design tree.

.NET Syntax

```
Sub DeleteFeatureMgrView( _
    ByRef AppView As System.Integer _
)
```



```
Dim instance As IModelDoc2
Dim AppView As System.Integer

instance.DeleteFeatureMgrView(AppView)
```

```
void DeleteFeatureMgrView(
    ref System.int AppView
)
```

```
void DeleteFeatureMgrView(
    & System.int% AppView
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppView

View handle of the FeatureManager design tree view to delete

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteFeatureMgrView](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

On the appropriate notification, you can call this method to clean up and delete your FeatureManager design tree view.

Use this method with [IModelViewManager::CreateFeatureMgrView2](#) or [IModelDoc2::AddFeatureMgrView3](#).

If you created the FeatureManager design tree view using...

Then...

IModelViewManager::CreateFeatureMgrView2

Calling IModelDoc2::DeleteFeatureMgrView destroys the CView object used for the FeatureManager design tree view.

IModelDoc2::AddFeatureMgrView3

Your application allocated the CView object and calling IModelDoc2::DeleteFeatureMgrView does not destroy the CView object. In this case, you must destroy the CView object using the appropriate destructor. Never use the delete operator directly on the CView object. Always use one of the appropriate MFC view destructors.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Deletes a light source.

-.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteLightSource( _  
    ByVal ID As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ID As System.Integer  
  
instance.DeleteLightSource(ID)
```

C#

```
void DeleteLightSource(  
    System.int ID  
)
```

C++/CLI

```
void DeleteLightSource(  
& System.int ID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
ID of the light source

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteLightSource](#).

Remarks

The light source ID ranges from 0 to n , where n = (the total number of light sources - 1). To get the total number of light sources, use [IModelDoc2::GetLightSourceCount](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetLightSourceExtProperty Method](#)
[IModelDoc2::GetLightSourceIdFromName Method](#)
[IModelDoc2::GetLightSourceName Method](#)
[IModelDoc2::AddLightSource Method](#)
[IModelDoc2::AddLightSourceExtProperty Method](#)
[IModelDoc2::AddLightToScene Method](#)
[IModelDoc2::LightSourcePropertyValues Property](#)
[IModelDoc2::LightSourceUserName Property](#)
[IModelDoc2::ResetLightSourceExtProperty Method](#)
[IModelDoc2::SetLightSourceName Method](#)
[IModelDoc2::SetLightSourcePropertyValuesVB Method](#)
[IModelDoc2::ILightSourcePropertyValues Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteNamedView Method (IModelDoc2)

Deletes the specified model view.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteNamedView( _  
    ByVal ViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ViewName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteNamedView(ViewName)
```

C#

```
System.bool DeleteNamedView(  
    System.string ViewName  
)
```

C++/CLI

```
System.bool DeleteNamedView(  
& System.String^ ViewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewName

Name of the model view to delete

Return Value

True if the named view is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteNamedView](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::ShowNamedView2 Method](#)
[IModelDoc2::NameView Method](#)
[IModelDocExtension::GetNamedViewRotation Method](#)
[IModelDocExtension::IGetNamedViewRotation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteSelection Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeleteSelection Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::DeleteSelection2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteSelection( _  
    ByVal ConfirmFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ConfirmFlag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.DeleteSelection(ConfirmFlag)
```

C#

```
System.bool DeleteSelection(  
    System.bool ConfirmFlag  
)
```

C++/CLI

```
System.bool DeleteSelection(  
&    System.bool ConfirmFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfirmFlag

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeleteSelection](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeriveSketch Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeriveSketch Method (IModelDoc2)

Creates a derived sketch.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeriveSketch()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.DeriveSketch()
```

C#

```
void DeriveSketch()
```

C++/CLI

```
void DeriveSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeriveSketch](#).

Example

[Create Derived or Underived Sketch \(VB.NET\)](#)
[Create Derived or Underived Sketch \(VBA\)](#)
[reate Derived or Underived Sketch \(C#\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::UnderiveSketch Method](#)
[ISketch::IsDerived Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeSelectByID Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DeSelectByID Method (IModelDoc2)

Removes the selected object from the selection list.

.NET Syntax

Visual Basic (Declaration)

```
Function DeSelectByID( _  
    ByVal SelID As System.String, _  
    ByVal SelParams As System.String, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim SelID As System.String  
Dim SelParams As System.String  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.DeSelectByID(SelID, SelParams, X, Y, Z)
```

C#

```
System.bool DeSelectByID(  
    System.string SelID,  
    System.string SelParams,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool DeSelectByID(  
& System.String^ SelID,  
& System.String^ SelParams,  
& System.double X,
```

```
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

ID of object

SelParams

Type name of object (uppercase)

X

X selection location

Y

Z selection location

Z

Z selection location

Return Value

True if object is deselected, false otherwise

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DeSelectByID](#).

Example

[Rotate, Scale, and Copy Sketch \(C#\)](#)

[Rotate, Scale, and Copy Sketch \(VB.NET\)](#)

[Rotate, Scale, and Copy Sketch \(VBA\)](#)

Remarks

See [IModelDocExtension::SelectByID2](#) for more information about selections.

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DimPreferences Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DimPreferences Method (IModelDoc2)

Sets dimension preferences.

.NET Syntax

Visual Basic (Declaration)

```
Sub DimPreferences()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.DimPreferences()
```

C#

```
void DimPreferences()
```

C++/CLI

```
void DimPreferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DimPreferences](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DissolveLibraryFeature Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DissolveLibraryFeature Method (IModelDoc2)

Dissolves the selected library features.

.NET Syntax

Visual Basic (Declaration)

```
Function DissolveLibraryFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Boolean
```

```
value = instance.DissolveLibraryFeature()
```

C#

```
System.bool DissolveLibraryFeature()
```

C++/CLI

```
System.bool DissolveLibraryFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selected library features are dissolved, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DissolveLibraryFeature](#).

Remarks

This method dissolves all library features that are selected when it executes. Only the selected library features are dissolved, anything else selected is ignored.

To create a library feature, use [IModelDoc2::InsertLibraryFeature](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[ILibraryFeatureData Interface](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DissolveSketchText Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DissolveSketchText Method (IModelDoc2)

Dissolves sketch text.

 .NET Syntax

Visual Basic (Declaration)

```
Sub DissolveSketchText()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.DissolveSketchText()
```

C#

```
void DissolveSketchText()
```

C++/CLI

```
void DissolveSketchText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DissolveSketchText](#).

 See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::InsertSketchText Method](#)
[ISketchText Interface](#)
[IModelDoc2::InsertSketchText Method](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DragTo Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DragTo Method (IModelDoc2)

Drags the specified end point.

 .NET Syntax

Visual Basic (Declaration)

```
Sub DragTo( _  
    ByVal Flags As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _
```

```
ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Flags As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
  
instance.DragTo(Flags, X, Y, Z)
```

C#

```
void DragTo(  
    System.int Flags,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void DragTo(  
& System.int Flags,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flags

Mouse-event flags as defined by the operating system. They can be combined to indicate the selection state. For example:

- Left-mouse button is pressed: 0x0001
- Right-mouse button is pressed: 0x0002
- Shift key is pressed: 0x0004
- Ctrl key is pressed: 0x0008
- Middle-mouse button is pressed: 0x0010

X
X coordinate of end point
Y
Y coordinate of end point
Z
Z coordinate of end point

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DragTo](#).

Remarks

This method is only valid for assemblies.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DrawLightIcons Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : DrawLightIcons Method (IModelDoc2)

Draws any visible light icons.

.NET Syntax

Visual Basic (Declaration)

```
Sub DrawLightIcons()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.DrawLightIcons()
```

C#

```
void DrawLightIcons()
```

C++/CLI

```
void DrawLightIcons();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::DrawLightIcons](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditBalloonProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditBalloonProperties Method (IModelDoc2)

Obsolete. Superseded by [INote::SetBalloon](#) and [INote::SetBomBalloonText](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EditBalloonProperties( _  
    ByVal Style As System.Integer, _  
    ByVal Size As System.Integer, _  
    ByVal UpperTextStyle As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextStyle As System.Integer, _  
    ByVal LowerText As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Style As System.Integer  
Dim Size As System.Integer
```

```
Dim UpperTextStyle As System.Integer
Dim UpperText As System.String
Dim LowerTextStyle As System.Integer
Dim LowerText As System.String
Dim value As System.Object
```

```
value = instance.EditBalloonProperties(Style, Size, UpperTextStyle, UpperText, LowerTextStyle, LowerText)
```

C#

```
System.Object EditBalloonProperties(
    System.Int Style,
    System.Int Size,
    System.Int UpperTextStyle,
    System.String UpperText,
    System.Int LowerTextStyle,
    System.String LowerText
)
```

C++/CLI

```
System.Object^ EditBalloonProperties(
    & System.Int Style,
    & System.Int Size,
    & System.Int UpperTextStyle,
    & System.String^ UpperText,
    & System.Int LowerTextStyle,
    & System.String^ LowerText
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Size

UpperTextStyle

UpperText

LowerTextStyle

LowerText

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditBalloonProperties](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditClearAll Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditClearAll Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::ClearSelection2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditClearAll()
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IModelDoc2
```

```
instance.EditClearAll()
```

C#

```
void EditClearAll()
```

C++/CLI

```
void EditClearAll();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditClearAll](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditConfiguration Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditConfiguration Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::EditConfiguration3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditConfiguration( _  
    ByVal Name As System.String, _  
    ByVal NewName As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal SuppressByDefault As System.Boolean, _  
    ByVal HideByDefault As System.Boolean, _  
    ByVal MinFeatureManager As System.Boolean, _  
    ByVal InheritProperties As System.Boolean, _  
    ByVal Flags As System.UInteger _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim NewName As System.String  
Dim Comment As System.String  
Dim AlternateName As System.String  
Dim SuppressByDefault As System.Boolean  
Dim HideByDefault As System.Boolean  
Dim MinFeatureManager As System.Boolean  
Dim InheritProperties As System.Boolean  
Dim Flags As System.UInteger
```

```
instance.EditConfiguration(Name, NewName, Comment, AlternateName, SuppressByDefault,  
HideByDefault, MinFeatureManager, InheritProperties, Flags)
```

C#

```
void EditConfiguration(  
    System.string Name,  
    System.string NewName,
```

```
System.string Comment,  
System.string AlternateName,  
System.bool SuppressByDefault,  
System.bool HideByDefault,  
System.bool MinFeatureManager,  
System.bool InheritProperties,  
System.uint Flags  
)
```

C++/CLI

```
void EditConfiguration(  
& System.String^ Name,  
& System.String^ NewName,  
& System.String^ Comment,  
& System.String^ AlternateName,  
& System.bool SuppressByDefault,  
& System.bool HideByDefault,  
& System.bool MinFeatureManager,  
& System.bool InheritProperties,  
& System.uint Flags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

NewName

Comment

AlternateName

SuppressByDefault

HideByDefault

MinFeatureManager

InheritProperties

Flags

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditConfiguration](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditConfiguration2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditConfiguration2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::EditConfiguration3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EditConfiguration2( _  
    ByVal Name As System.String, _  
    ByVal NewName As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal SuppressByDefault As System.Boolean, _  
    ByVal HideByDefault As System.Boolean, _  
    ByVal MinFeatureManager As System.Boolean, _  
    ByVal InheritProperties As System.Boolean, _
```

```
ByVal Flags As System.UInteger _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim NewName As System.String  
Dim Comment As System.String  
Dim AlternateName As System.String  
Dim SuppressByDefault As System.Boolean  
Dim HideByDefault As System.Boolean  
Dim MinFeatureManager As System.Boolean  
Dim InheritProperties As System.Boolean  
Dim Flags As System.UInteger  
Dim value As System.Boolean
```

```
value = instance.EditConfiguration2(Name, NewName, Comment, AlternateName, SuppressByDefault,  
HideByDefault, MinFeatureManager, InheritProperties, Flags)
```

C#

```
System.bool EditConfiguration2(  
    System.string Name,  
    System.string NewName,  
    System.string Comment,  
    System.string AlternateName,  
    System.bool SuppressByDefault,  
    System.bool HideByDefault,  
    System.bool MinFeatureManager,  
    System.bool InheritProperties,  
    System.uint Flags  
)
```

C++/CLI

```
System.bool EditConfiguration2(  
& System.String^ Name,  
& System.String^ NewName,  
& System.String^ Comment,  
& System.String^ AlternateName,  
& System.bool SuppressByDefault,  
& System.bool HideByDefault,  
& System.bool MinFeatureManager,  
& System.bool InheritProperties,  
& System.uint Flags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

NewName

Comment

AlternateName

SuppressByDefault

HideByDefault

MinFeatureManager

InheritProperties

Flags

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditConfiguration2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditConfiguration3 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditConfiguration3 Method (IModelDoc2)

Edits the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function EditConfiguration3( _  
    ByVal Name As System.String, _  
    ByVal NewName As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal Options As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim NewName As System.String  
Dim Comment As System.String  
Dim AlternateName As System.String  
Dim Options As System.Integer  
Dim value As System.Boolean  
  
value = instance.EditConfiguration3(Name, NewName, Comment, AlternateName, Options)
```

C#

```
System.bool EditConfiguration3(  
    System.string Name,  
    System.string NewName,  
    System.string Comment,  
    System.string AlternateName,  
    System.int Options  
)
```

C++/CLI

```
System.bool EditConfiguration3(  
& System.String^ Name,  
& System.String^ NewName,  
& System.String^ Comment,  
& System.String^ AlternateName,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Current configuration name

NewName

New configuration name

Comment

Comment used in configuration properties

AlternateName

Alternate configuration name; used if swConfigOption_UseAlternateName is set to True

Options

Combination of one or more BOOLEAN configuration options as defined in [swConfigurationOptions2_e](#) (see **Remarks**)

Return Value

True if configuration name was changed, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditConfiguration3](#).

Remarks

The Options argument can be a combination of any of the following values:

- swConfigOption_SuppressByDefault True if you want to suppress newly added features and mates in this configuration, false if not
- swConfigOption_HideByDefault - True if you want newly added components to be hidden, false if not
- swConfigOption_MinFeatureManager True if you want newly added components to only display their component name in the FeatureManager design tree, false if you want newly added components to display their name and each of their features in the FeatureManager design tree

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddConfiguration3 Method](#)
[IModelDoc2::DeleteConfiguration2 Method](#)
[IModelDoc2::GetConfigurationByName Method](#)
[IModelDoc2::GetConfigurationCount Method](#)
[IModelDoc2::GetConfigurationNames Method](#)
[IModelDoc2::IGetConfigurationByName Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::ShowConfiguration2 Method](#)
[IModelDoc2::ConfigurationManager Property](#)
[IConfiguration Interface](#)
[IModelDoc2::IConfigurationManager Interface](#)
[IModelDoc2::IAddConfiguration3 Method](#)

Availability

SOLIDWORKS 2001Pus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditCopy Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditCopy Method (IModelDoc2)

Copies the currently selected items and places them in the clipboard.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditCopy()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
```

```
instance.EditCopy()
```

C#

```
void EditCopy()
```

C++/CLI

```
void EditCopy();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditCopy](#).

Example

[Copy and Paste Feature \(C#\)](#)
[Copy and Paste Feature \(VB.NET\)](#)
[Copy and Paste Feature \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::Paste Method](#)
[IModelDoc2::EditCut Method](#)
[IModelDoc2::EditDelete Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditCut Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditCut Method (IModelDoc2)

Cuts the currently selected items and places them on the Microsoft Windows Clipboard.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditCut()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.EditCut()
```

C#

```
void EditCut()
```

C++/CLI

```
void EditCut();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditCut](#).

Example

[Cut and Paste Sketch \(C#\)](#)
[Cut and Paste Sketch \(VB.NET\)](#)
[Cut and Paste Sketch \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::EditCopy Method](#)
[IModelDoc2::EditDelete Method](#)
[IModelDoc2::Paste Method](#)

Availability

EditDatumTargetSymbol Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditDatumTargetSymbol Method (IModelDoc2)

Edits a datum target symbol.

 .NET Syntax

Visual Basic (Declaration)

```

Function EditDatumTargetSymbol( _
    ByVal Datum1 As System.String, _
    ByVal Datum2 As System.String, _
    ByVal Datum3 As System.String, _
    ByVal AreaStyle As System.Short, _
    ByVal AreaOutside As System.Boolean, _
    ByVal Value1 As System.Double, _
    ByVal Value2 As System.Double, _
    ByVal ValueStr1 As System.String, _
    ByVal ValueStr2 As System.String, _
    ByVal ArrowsSmart As System.Boolean, _
    ByVal ArrowStyle As System.Short, _
    ByVal LeaderLineStyle As System.Short, _
    ByVal LeaderBent As System.Boolean, _
    ByVal ShowArea As System.Boolean, _
    ByVal ShowSymbol As System.Boolean _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc2
Dim Datum1 As System.String
Dim Datum2 As System.String
Dim Datum3 As System.String
Dim AreaStyle As System.Short
Dim AreaOutside As System.Boolean
Dim Value1 As System.Double
Dim Value2 As System.Double
Dim ValueStr1 As System.String
Dim ValueStr2 As System.String
Dim ArrowsSmart As System.Boolean
Dim ArrowStyle As System.Short
Dim LeaderLineStyle As System.Short
Dim LeaderBent As System.Boolean
Dim ShowArea As System.Boolean
Dim ShowSymbol As System.Boolean
Dim value As System.Boolean

```

```

value = instance.EditDatumTargetSymbol(Datum1, Datum2, Datum3, AreaStyle, AreaOutside, Value1,
Value2, ValueStr1, ValueStr2, ArrowsSmart, ArrowStyle, LeaderLineStyle, LeaderBent, ShowArea,
ShowSymbol)

```

C#

```

System.bool EditDatumTargetSymbol(
    System.string Datum1,
    System.string Datum2,
    System.string Datum3,
    System.short AreaStyle,
    System.bool AreaOutside,
    System.double Value1,
    System.double Value2,
    System.string ValueStr1,
    System.string ValueStr2,
    System.bool ArrowsSmart,
    System.short ArrowStyle,

```

```

        System.short LeaderLineStyle,
        System.bool LeaderBent,
        System.bool ShowArea,
        System.bool ShowSymbol
    )

```

C++/CLI

```

System.bool EditDatumTargetSymbol(
& System.String^ Datum1,
& System.String^ Datum2,
& System.String^ Datum3,
& System.short AreaStyle,
& System.bool AreaOutside,
& System.double Value1,
& System.double Value2,
& System.String^ ValueStr1,
& System.String^ ValueStr2,
& System.bool ArrowsSmart,
& System.short ArrowStyle,
& System.short LeaderLineStyle,
& System.bool LeaderBent,
& System.bool ShowArea,
& System.bool ShowSymbol
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Datum1
Datum reference string 1

Datum2
Datum reference string 2

Datum3
Datum reference string 3

AreaStyle
0 = point, 1 = circle, 2 = rectangle

AreaOutside
True to display target area dimensions size outside, false otherwise

Value1
Numeric datum target area diameter or width

Value2
Numeric datum target area height

ValueStr1
Value for datum target area diameter or width

ValueStr2
Value for datum target area height

ArrowsSmart
True if you want smart arrows, false otherwise

ArrowStyle
Arrow head style (for example, open, closed, and so on) as defined in [swArrowStyle_e](#)

LeaderLineStyle
Leaderline type as defined in [swLeaderStyle_e](#)

LeaderBent
True if you want a bent leader line, false otherwise

ShowArea
True if you want to show the target area, false otherwise

ShowSymbol
True if you want to display the target symbol, false otherwise

Return Value

True if datum target symbol is modified, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditDatumTargetSymbol](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDocExtension::InsertDatumTargetSymbol2 Method](#)
[IDatumTargetSym Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

EditDelete Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditDelete Method (IModelDoc2)

Deletes the selected items.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditDelete()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.EditDelete()
```

C#

```
void EditDelete()
```

C++/CLI

```
void EditDelete();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditDelete](#).

Example

[Undo Deleted Note and Fire Undo Post-Notify Event \(VBA\)](#)
[Undo Deleted Note and Fire Undo Post-Notify Event \(VB.NET\)](#)
[Undo Deleted Note and Fire Undo Post-Notify Event \(C#\)](#)

Remarks

Use [IModelDocExtension::DeleteSelection2](#) to turn off prompting the user to confirm the deletion.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::EditCopy Method](#)
[IModelDoc2::EditCut Method](#)
[IModelDoc2::Paste Method](#)
[IAssemblyDoc::DeleteSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditDimensionProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditDimensionProperties Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::EditDimensionProperties3](#).

.NET Syntax

Visual Basic (Declaration)

```

Function EditDimensionProperties( _
    ByVal TolType As System.Integer, _
    ByVal TolMax As System.Double, _
    ByVal TolMin As System.Double, _
    ByVal TolMaxFit As System.String, _
    ByVal TolMinFit As System.String, _
    ByVal UseDocPrec As System.Boolean, _
    ByVal Precision As System.Integer, _
    ByVal ArrowsIn As System.Integer, _
    ByVal UseDocArrows As System.Boolean, _
    ByVal Arrow1 As System.Integer, _
    ByVal Arrow2 As System.Integer _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc2
Dim TolType As System.Integer
Dim TolMax As System.Double
Dim TolMin As System.Double
Dim TolMaxFit As System.String
Dim TolMinFit As System.String
Dim UseDocPrec As System.Boolean
Dim Precision As System.Integer
Dim ArrowsIn As System.Integer
Dim UseDocArrows As System.Boolean
Dim Arrow1 As System.Integer
Dim Arrow2 As System.Integer
Dim value As System.Boolean

value = instance.EditDimensionProperties(TolType, TolMax, TolMin, TolMaxFit, TolMinFit,
UseDocPrec, Precision, ArrowsIn, UseDocArrows, Arrow1, Arrow2)

```

C#

```

System.bool EditDimensionProperties(
    System.int TolType,
    System.double TolMax,
    System.double TolMin,
    System.string TolMaxFit,
    System.string TolMinFit,
    System.bool UseDocPrec,
    System.int Precision,
    System.int ArrowsIn,
    System.bool UseDocArrows,
    System.int Arrow1,
    System.int Arrow2
)

```

C++/CLI

```

System.bool EditDimensionProperties(
    & System.int TolType,
    & System.double TolMax,
    & System.double TolMin,
    & System.String^ TolMaxFit,
    & System.String^ TolMinFit,
    & System.bool UseDocPrec,
    & System.int Precision,
    & System.int ArrowsIn,
    & System.bool UseDocArrows,
    & System.int Arrow1,
    & System.int Arrow2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType

TolMax
TolMin
TolMaxFit
TolMinFit
UseDocPrec
Precision
ArrowsIn
UseDocArrows
Arrow1
Arrow2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditDimensionProperties](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditDimensionProperties2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditDimensionProperties2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::EditDimensionProperties3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EditDimensionProperties2( _  
    ByVal TolType As System.Integer, _  
    ByVal TolMax As System.Double, _  
    ByVal TolMin As System.Double, _  
    ByVal TolMaxFit As System.String, _  
    ByVal TolMinFit As System.String, _  
    ByVal UseDocPrec As System.Boolean, _  
    ByVal Precision As System.Integer, _  
    ByVal ArrowsIn As System.Integer, _  
    ByVal UseDocArrows As System.Boolean, _  
    ByVal Arrow1 As System.Integer, _  
    ByVal Arrow2 As System.Integer, _  
    ByVal PrefixText As System.String, _  
    ByVal SuffixText As System.String, _  
    ByVal ShowValue As System.Boolean, _  
    ByVal CalloutText1 As System.String, _  
    ByVal CalloutText2 As System.String, _  
    ByVal CenterText As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim TolType As System.Integer  
Dim TolMax As System.Double  
Dim TolMin As System.Double  
Dim TolMaxFit As System.String  
Dim TolMinFit As System.String  
Dim UseDocPrec As System.Boolean  
Dim Precision As System.Integer  
Dim ArrowsIn As System.Integer  
Dim UseDocArrows As System.Boolean
```

```

Dim Arrow1 As System.Integer
Dim Arrow2 As System.Integer
Dim PrefixText As System.String
Dim SuffixText As System.String
Dim ShowValue As System.Boolean
Dim CalloutText1 As System.String
Dim CalloutText2 As System.String
Dim CenterText As System.Boolean
Dim value As System.Boolean

```

```

value = instance.EditDimensionProperties2(TolType, TolMax, TolMin, TolMaxFit, TolMinFit,
UseDocPrec, Precision, ArrowsIn, UseDocArrows, Arrow1, Arrow2, PrefixText, SuffixText, ShowValue,
CalloutText1, CalloutText2, CenterText)

```

C#

```

System.bool EditDimensionProperties2(
    System.int TolType,
    System.double TolMax,
    System.double TolMin,
    System.string TolMaxFit,
    System.string TolMinFit,
    System.bool UseDocPrec,
    System.int Precision,
    System.int ArrowsIn,
    System.bool UseDocArrows,
    System.int Arrow1,
    System.int Arrow2,
    System.string PrefixText,
    System.string SuffixText,
    System.bool ShowValue,
    System.string CalloutText1,
    System.string CalloutText2,
    System.bool CenterText
)

```

C++/CLI

```

System.bool EditDimensionProperties2(
    & System.int TolType,
    & System.double TolMax,
    & System.double TolMin,
    & System.String^ TolMaxFit,
    & System.String^ TolMinFit,
    & System.bool UseDocPrec,
    & System.int Precision,
    & System.int ArrowsIn,
    & System.bool UseDocArrows,
    & System.int Arrow1,
    & System.int Arrow2,
    & System.String^ PrefixText,
    & System.String^ SuffixText,
    & System.bool ShowValue,
    & System.String^ CalloutText1,
    & System.String^ CalloutText2,
    & System.bool CenterText
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType

TolMax

TolMin

TolMaxFit

TolMinFit

UseDocPrec

Precision

ArrowsIn
UseDocArrows
Arrow1
Arrow2
PrefixText
SuffixText
ShowValue
CalloutText1
CalloutText2
CenterText

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditDimensionProperties2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditDimensionProperties3 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : EditDimensionProperties3 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::EditDimensionProperties](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EditDimensionProperties3( _  
    ByVal TolType As System.Integer, _  
    ByVal TolMax As System.Double, _  
    ByVal TolMin As System.Double, _  
    ByVal TolMaxFit As System.String, _  
    ByVal TolMinFit As System.String, _  
    ByVal UseDocPrec As System.Boolean, _  
    ByVal Precision As System.Integer, _  
    ByVal ArrowsIn As System.Integer, _  
    ByVal UseDocArrows As System.Boolean, _  
    ByVal Arrow1 As System.Integer, _  
    ByVal Arrow2 As System.Integer, _  
    ByVal PrefixText As System.String, _  
    ByVal SuffixText As System.String, _  
    ByVal ShowValue As System.Boolean, _  
    ByVal CalloutText1 As System.String, _  
    ByVal CalloutText2 As System.String, _  
    ByVal CenterText As System.Boolean, _  
    ByVal ConfigOption As System.Integer, _  
    ByVal ConfigNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim TolType As System.Integer  
Dim TolMax As System.Double  
Dim TolMin As System.Double  
Dim TolMaxFit As System.String  
Dim TolMinFit As System.String  
Dim UseDocPrec As System.Boolean  
Dim Precision As System.Integer  
Dim ArrowsIn As System.Integer
```

```

Dim UseDocArrows As System.Boolean
Dim Arrow1 As System.Integer
Dim Arrow2 As System.Integer
Dim PrefixText As System.String
Dim SuffixText As System.String
Dim ShowValue As System.Boolean
Dim CalloutText1 As System.String
Dim CalloutText2 As System.String
Dim CenterText As System.Boolean
Dim ConfigOption As System.Integer
Dim ConfigNames As System.Object
Dim value As System.Boolean

```

```

value = instance.EditDimensionProperties3(TolType, TolMax, TolMin, TolMaxFit, TolMinFit,
UseDocPrec, Precision, ArrowsIn, UseDocArrows, Arrow1, Arrow2, PrefixText, SuffixText, ShowValue,
CalloutText1, CalloutText2, CenterText, ConfigOption, ConfigNames)

```

C#

```

System.bool EditDimensionProperties3(
    System.int TolType,
    System.double TolMax,
    System.double TolMin,
    System.string TolMaxFit,
    System.string TolMinFit,
    System.bool UseDocPrec,
    System.int Precision,
    System.int ArrowsIn,
    System.bool UseDocArrows,
    System.int Arrow1,
    System.int Arrow2,
    System.string PrefixText,
    System.string SuffixText,
    System.bool ShowValue,
    System.string CalloutText1,
    System.string CalloutText2,
    System.bool CenterText,
    System.int ConfigOption,
    System.object ConfigNames
)

```

C++/CLI

```

System.bool EditDimensionProperties3(
    & System.int TolType,
    & System.double TolMax,
    & System.double TolMin,
    & System.String^ TolMaxFit,
    & System.String^ TolMinFit,
    & System.bool UseDocPrec,
    & System.int Precision,
    & System.int ArrowsIn,
    & System.bool UseDocArrows,
    & System.int Arrow1,
    & System.int Arrow2,
    & System.String^ PrefixText,
    & System.String^ SuffixText,
    & System.bool ShowValue,
    & System.String^ CalloutText1,
    & System.String^ CalloutText2,
    & System.bool CenterText,
    & System.int ConfigOption,
    & System.Object^ ConfigNames
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType

Type of tolerance as defined in [swTolType_e](#)

TolMax

Maximum value for the tolerance

TolMin

Minimum value for the tolerance

TolMaxFit

Text for the maximum FIT value when using a fit tolerance type

TolMinFit

Text for the minimum FIT value when using a fit tolerance type

UseDocPrec

True to use the document's precision value, false to use value specified for precision

Precision

Precision value to use for this dimension if UseDocPrec is false

ArrowsIn

Value for the arrow direction as defined in [swDimensionArrowsSide_e](#)

UseDocArrows

True to use the document's arrow types, false to use values specified for Arrow1 and Arrow2

Arrow1

Type of arrow to use on the first arrow of this dimension as defined in [swArrowStyle_e](#) if UseDocArrows is false

Arrow2

Type of arrow to use on the second arrow of this dimension as defined in [swArrowStyle_e](#) if UseDocArrows is false

PrefixText

Text for the prefix of the dimension

SuffixText

Text for the suffix of the dimension

ShowValue

True to display the value of the dimension in the user interface, false to not

CalloutText1

Callout text to display above the dimension

CalloutText2

Callout text to display below the dimension

CenterText

True if you want to center the text in the dimension, false if not

ConfigOption

Configuration options as defined [swInConfigurationOpts_e](#)

ConfigNames

Names of configurations to which to apply these edits (see **Remarks**)

Return Value

True if the dimension is modified, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::EditDimensionProperties3](#).

Remarks

This method always changes the dimension's parameters in the active configuration. For example, if you specify `swSpecifyConfiguration` for `ConfigOption` and do not specify the name of the active configuration in `ConfigNames`, then the dimension's parameters in the active configuration are still affected.

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IModelDoc2::IEditDimensionProperties3 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0