

SOLIDWORKS API (.NET VBA C#) — Reference

(183/337): IModelDoc2 (part 6 of 17)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc2 (part 6 of 17) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureFillet Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureFillet Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureFillet( _  
    ByVal R1 As System.Double, _  
    ByVal Propagate As System.Boolean, _  
    ByVal Ftyp As System.Boolean, _  
    ByVal VarRadTyp As System.Boolean, _  
    ByVal OverflowType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim R1 As System.Double  
Dim Propagate As System.Boolean  
Dim Ftyp As System.Boolean  
Dim VarRadTyp As System.Boolean  
Dim OverflowType As System.Integer  
  
instance.FeatureFillet(R1, Propagate, Ftyp, VarRadTyp, OverflowType)
```

C#

```
void FeatureFillet(  
    System.double R1,  
    System.bool Propagate,  
    System.bool Ftyp,  
    System.bool VarRadTyp,  
    System.int OverflowType  
)
```

C++/CLI

```
void FeatureFillet(  
& System.double R1,  
& System.bool Propagate,  
& System.bool Ftyp,  
& System.bool VarRadTyp,  
& System.int OverflowType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

R1

Propagate

Ftyp

VarRadTyp

OverflowType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureFillet](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureFillet2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureFillet2 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureFillet2( _  
    ByVal R1 As System.Double, _  
    ByVal Propagate As System.Boolean, _  
    ByVal Ftyp As System.Boolean, _  
    ByVal VarRadTyp As System.Boolean, _  
    ByVal OverflowType As System.Integer, _  
    ByVal NRadii As System.Integer, _  
    ByVal Radii As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim R1 As System.Double  
Dim Propagate As System.Boolean  
Dim Ftyp As System.Boolean  
Dim VarRadTyp As System.Boolean  
Dim OverflowType As System.Integer  
Dim NRadii As System.Integer  
Dim Radii As System.Object  
Dim value As System.Integer  
  
value = instance.FeatureFillet2(R1, Propagate, Ftyp, VarRadTyp, OverflowType, NRadii, Radii)
```

C#

```
System.int FeatureFillet2(  
    System.double R1,  
    System.bool Propagate,  
    System.bool Ftyp,  
    System.bool VarRadTyp,  
    System.int OverflowType,  
    System.int NRadii,  
    System.object Radii  
)
```

C++/CLI

```
System.int FeatureFillet2(  
& System.double R1,  
& System.bool Propagate,  
& System.bool Ftyp,  
& System.bool VarRadTyp,  
& System.int OverflowType,  
& System.int NRadii,  
& System.Object^ Radii  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

R1

Propagate

Ftyp

VarRadTyp

OverflowType

NRadii

Radii

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureFillet2](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureFillet3 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureFillet3 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureFillet3( _  
    ByVal R1 As System.Double, _  
    ByVal Propagate As System.Boolean, _  
    ByVal Ftyp As System.Integer, _  
    ByVal VarRadTyp As System.Boolean, _  
    ByVal OverflowType As System.Integer, _  
    ByVal NRadii As System.Integer, _  
    ByVal Radii As System.Object, _  
    ByVal UseHelpPoint As System.Boolean, _  
    ByVal UseTangentHoldLine As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim R1 As System.Double  
Dim Propagate As System.Boolean  
Dim Ftyp As System.Integer  
Dim VarRadTyp As System.Boolean  
Dim OverflowType As System.Integer  
Dim NRadii As System.Integer  
Dim Radii As System.Object  
Dim UseHelpPoint As System.Boolean  
Dim UseTangentHoldLine As System.Boolean  
Dim value As System.Integer
```

```
value = instance.FeatureFillet3(R1, Propagate, Ftyp, VarRadTyp, OverflowType, NRadii, Radii,  
    UseHelpPoint, UseTangentHoldLine)
```

C#

```
System.int FeatureFillet3(  
    System.double R1,  
    System.bool Propagate,  
    System.int Ftyp,  
    System.bool VarRadTyp,  
    System.int OverflowType,  
    System.int NRadii,  
    System.object Radii,
```

```
System.bool UseHelpPoint,  
System.bool UseTangentHoldLine  
)
```

C++/CLI

```
System.int FeatureFillet3(  
& System.double R1,  
& System.bool Propagate,  
& System.int Ftyp,  
& System.bool VarRadTyp,  
& System.int OverflowType,  
& System.int NRadii,  
& System.Object^ Radii,  
& System.bool UseHelpPoint,  
& System.bool UseTangentHoldLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

R1

Propagate

Ftyp

VarRadTyp

OverflowType

NRadii

Radii

UseHelpPoint

UseTangentHoldLine

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureFillet3](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureFillet4 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureFillet4 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureFillet4(  
    ByVal R1 As System.Double, _  
    ByVal Propagate As System.Boolean, _  
    ByVal UniformRadius As System.Boolean, _  
    ByVal Ftyp As System.Integer, _  
    ByVal VarRadTyp As System.Boolean, _  
    ByVal OverflowType As System.Integer, _  
    ByVal NRadii As System.Integer, _  
    ByVal Radii As System.Object, _  
    ByVal UseHelpPoint As System.Boolean, _  
    ByVal UseTangentHoldLine As System.Boolean, _  
    ByVal CornerType As System.Boolean, _  
    ByVal SetbackDistCount As System.Integer, _
```

```
ByVal SetBackDistances As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim R1 As System.Double  
Dim Propagate As System.Boolean  
Dim UniformRadius As System.Boolean  
Dim Ftyp As System.Integer  
Dim VarRadTyp As System.Boolean  
Dim OverflowType As System.Integer  
Dim NRadii As System.Integer  
Dim Radii As System.Object  
Dim UseHelpPoint As System.Boolean  
Dim UseTangentHoldLine As System.Boolean  
Dim CornerType As System.Boolean  
Dim SetbackDistCount As System.Integer  
Dim SetBackDistances As System.Object  
Dim value As System.Integer
```

```
value = instance.FeatureFillet4(R1, Propagate, UniformRadius, Ftyp, VarRadTyp, OverflowType,  
NRadii, Radii, UseHelpPoint, UseTangentHoldLine, CornerType, SetbackDistCount, SetBackDistances)
```

C#

```
System.int FeatureFillet4(  
    System.double R1,  
    System.bool Propagate,  
    System.bool UniformRadius,  
    System.int Ftyp,  
    System.bool VarRadTyp,  
    System.int OverflowType,  
    System.int NRadii,  
    System.object Radii,  
    System.bool UseHelpPoint,  
    System.bool UseTangentHoldLine,  
    System.bool CornerType,  
    System.int SetbackDistCount,  
    System.object SetBackDistances  
)
```

C++/CLI

```
System.int FeatureFillet4(  
& System.double R1,  
& System.bool Propagate,  
& System.bool UniformRadius,  
& System.int Ftyp,  
& System.bool VarRadTyp,  
& System.int OverflowType,  
& System.int NRadii,  
& System.Object^ Radii,  
& System.bool UseHelpPoint,  
& System.bool UseTangentHoldLine,  
& System.bool CornerType,  
& System.int SetbackDistCount,  
& System.Object^ SetBackDistances  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

R1

Propagate

UniformRadius

Ftyp

VarRadTyp

OverflowType

NRadii

Radii

UseHelpPoint

UseTangentHoldLine

CornerType

SetbackDistCount

SetBackDistances

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureFillet4](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureFillet5 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureFillet5 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureFillet5( _  
    ByVal Options As System.Integer, _  
    ByVal R1 As System.Double, _  
    ByVal Ftyp As System.Integer, _  
    ByVal OverflowType As System.Integer, _  
    ByVal Radii As System.Object, _  
    ByVal SetBackDistances As System.Object, _  
    ByVal PointRadiusArray As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Options As System.Integer  
Dim R1 As System.Double  
Dim Ftyp As System.Integer  
Dim OverflowType As System.Integer  
Dim Radii As System.Object  
Dim SetBackDistances As System.Object  
Dim PointRadiusArray As System.Object  
Dim value As System.Integer
```

```
value = instance.FeatureFillet5(Options, R1, Ftyp, OverflowType, Radii, SetBackDistances,  
PointRadiusArray)
```

C#

```
System.int FeatureFillet5(  
    System.int Options,  
    System.double R1,  
    System.int Ftyp,  
    System.int OverflowType,  
    System.object Radii,  
    System.object SetBackDistances,  
    System.object PointRadiusArray  
)
```

```

System.int FeatureFillet5(
& System.int Options,
& System.double R1,
& System.int Ftyp,
& System.int OverflowType,
& System.Object^ Radii,
& System.Object^ SetBackDistances,
& System.Object^ PointRadiusArray
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Options

R1

Ftyp

OverflowType

Radii

SetBackDistances

PointRadiusArray

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureFillet5](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureLinearPattern Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureLinearPattern Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureLinearPattern2](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub FeatureLinearPattern( _
    ByVal Num1 As System.Integer, _
    ByVal Spacing1 As System.Double, _
    ByVal Num2 As System.Integer, _
    ByVal Spacing2 As System.Double, _
    ByVal FlipDir1 As System.Boolean, _
    ByVal FlipDir2 As System.Boolean, _
    ByVal DName1 As System.String, _
    ByVal DName2 As System.String _
)

```

Visual Basic (Usage)

```

Dim instance As IModelDoc2
Dim Num1 As System.Integer
Dim Spacing1 As System.Double
Dim Num2 As System.Integer
Dim Spacing2 As System.Double
Dim FlipDir1 As System.Boolean
Dim FlipDir2 As System.Boolean
Dim DName1 As System.String
Dim DName2 As System.String

```



```
instance.FeatureLinearPattern(Num1, Spacing1, Num2, Spacing2, FlipDir1, FlipDir2, DName1, DName2)
```

C#

```
void FeatureLinearPattern(  
    System.int Num1,  
    System.double Spacing1,  
    System.int Num2,  
    System.double Spacing2,  
    System.bool FlipDir1,  
    System.bool FlipDir2,  
    System.string DName1,  
    System.string DName2  
)
```

C++/CLI

```
void FeatureLinearPattern(  
& System.int Num1,  
& System.double Spacing1,  
& System.int Num2,  
& System.double Spacing2,  
& System.bool FlipDir1,  
& System.bool FlipDir2,  
& System.String^ DName1,  
& System.String^ DName2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Num1

Spacing1

Num2

Spacing2

FlipDir1

FlipDir2

DName1

DName2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureLinearPattern](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureManager Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureManager Property (IModelDoc2)

Gets the [IFeatureManager](#) object, which allows access to the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FeatureManager As FeatureManager

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As FeatureManager

value = instance.FeatureManager
```

C#

```
FeatureManager FeatureManager {get;}
```

C++/CLI

```
property FeatureManager^ FeatureManager {
    FeatureManager^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFeatureManager](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureManager](#).

Example

[Insert Macro Feature \(C++\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Insert Folder in FeatureManager Design Tree \(VBA\)](#)
[Insert Reference PPoints \(VBA\)](#)
[Update FeatureManager Design Tree \(VBA\)](#)
[Insert MidSurface in Component \(C#\)](#)
[Insert MidSurface in Component \(VB.NET\)](#)
[Insert MidSurface in Component \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureManagerSplitterPosition Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureManagerSplitterPosition Property (IModelDoc2)

Splits the FeatureManager design tree and gets or sets the location of the split bar in the FeatureManager design tree panel.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureManagerSplitterPosition As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Double

instance.FeatureManagerSplitterPosition = value

value = instance.FeatureManagerSplitterPosition
```

C#

```
System.double FeatureManagerSplitterPosition {get; set;}
```

C++/CLI

```
property System.double FeatureManagerSplitterPosition {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Percentage value between 0 and 1, which sets the location of the split bar in the FeatureManager design tree panel and the size of each split FeatureManager design tree (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureManagerSplitterPosition](#).

Example

[Add ActiveX Tabs to FeatureManager Design Tree \(C#\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VB.NET\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VBA\)](#)
[Split FeatureManager Design Tree and Position Splitter \(C#\)](#)
[Split FeatureManager Design Tree and Position Splitter \(VB.NET\)](#)
[Split FeatureManager Design Tree and Position Splitter \(VBA\)](#)

Remarks

Setting this property to...	Results in the split panel bar...
0	Remaining above the FeatureManager design tree.
1	Moving below the FeatureManager design tree.
>0 and <1	Setting the size of the split FeatureManager design trees within the FeatureManager design tree panel. For example, if you specify: 0.5, then each FeatureManager design tree takes up 50 percent of the panel, and the split bar is located between them. 0.8, then the bottom FeatureManager design tree takes up 80 percent of the panel, the top FeatureManager design tree takes up 20 percent of the panel, and the split bar is located between them.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureReferenceCurve Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureReferenceCurve Method (IModelDoc2)

Creates a reference curve feature from an array of curves.

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureReferenceCurve( _  
    ByVal NumOfCurves As System.Integer, _  
    ByVal BaseCurves As System.Object, _  
    ByVal Merge As System.Boolean, _  
    ByVal FromFileName As System.String, _  
    ByRef ErrorCode As System.Integer _  
    ) As System.Object
```

Visual Basic (Usage)



```

Dim instance As IModelDoc2
Dim NumOfCurves As System.Integer
Dim BaseCurves As System.Object
Dim Merge As System.Boolean
Dim FromFileName As System.String
Dim ErrorCode As System.Integer
Dim value As System.Object

```

```

value = instance.FeatureReferenceCurve(NumOfCurves, BaseCurves, Merge, FromFileName, ErrorCode)

```

C#

```

System.object FeatureReferenceCurve(
    System.int NumOfCurves,
    System.object BaseCurves,
    System.bool Merge,
    System.string FromFileName,
    out System.int ErrorCode
)

```

C++/CLI

```

System.Object^ FeatureReferenceCurve(
    & System.int NumOfCurves,
    & System.Object^ BaseCurves,
    & System.bool Merge,
    & System.String^ FromFileName,
    & [Out] System.int ErrorCode
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfCurves

Number of curves from which to create the object

BaseCurves

Array of [curves](#)

Merge

True creates a single reference curve feature, false creates a reference curve feature for each curve in the array

FromFileName

Not used

ErrorCode

Error code as defined in [swFeatureError_e](#)

Return Value

[Reference curve](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureReferenceCurve](#).

Example

[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::IFeatureReferenceCurve Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureRevolve2 Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureRevolve](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureRevolve2( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer, _  
    ByVal Options As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer  
Dim Options As System.Integer  
Dim value As System.Integer  
  
value = instance.FeatureRevolve2(Angle, ReverseDir, Angle2, RevType, Options)
```

C#

```
System.int FeatureRevolve2(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType,  
    System.int Options  
)
```

C++/CLI

```
System.int FeatureRevolve2(  
& System.double Angle,  
& System.bool ReverseDir,  
& System.double Angle2,  
& System.int RevType,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

ReverseDir

Angle2

RevType

Options

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureRevolve2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

FeatureRevolveCut2 Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureRevolveCut2 Method (IModelDoc2)**Obsolete.** Superseded by [IFeatureManager.FeatureRevolveCut](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureRevolveCut2( _
    ByVal Angle As System.Double, _
    ByVal ReverseDir As System.Boolean, _
    ByVal Angle2 As System.Double, _
    ByVal RevType As System.Integer, _
    ByVal Options As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim Angle As System.Double
Dim ReverseDir As System.Boolean
Dim Angle2 As System.Double
Dim RevType As System.Integer
Dim Options As System.Integer
Dim value As System.Integer

value = instance.FeatureRevolveCut2(Angle, ReverseDir, Angle2, RevType, Options)
```

C#

```
System.int FeatureRevolveCut2(
    System.double Angle,
    System.bool ReverseDir,
    System.double Angle2,
    System.int RevType,
    System.int Options
)
```

C++/CLI

```
System.int FeatureRevolveCut2(
    & System.double Angle,
    & System.bool ReverseDir,
    & System.double Angle2,
    & System.int RevType,
    & System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*Angle**ReverseDir**Angle2**RevType**Options*

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2.FeatureRevolveCut2](#).

See Also

FeatureSketchDrivenPattern Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FeatureSketchDrivenPattern Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::FeatureSketchDrivenPattern](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureSketchDrivenPattern( _  
    ByVal UseCentroid As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UseCentroid As System.Boolean  
  
instance.FeatureSketchDrivenPattern(UseCentroid)
```

C#

```
void FeatureSketchDrivenPattern(  
    System.bool UseCentroid  
)
```

C++/CLI

```
void FeatureSketchDrivenPattern(  
&    System.bool UseCentroid  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseCentroid

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FeatureSketchDrivenPattern](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

FileReload Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FileReload Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::ReloadOrReplace](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FileReload()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.FileReload()
```

C#

```
void FileReload()
```

C++/CLI

```
void FileReload();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FileReload](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FileSummaryInfo Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FileSummaryInfo Method (IModelDoc2)

Displays the **File Summary Information** dialog box for this file.

.NET Syntax

Visual Basic (Declaration)

```
Sub FileSummaryInfo()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.FileSummaryInfo()
```

C#

```
void FileSummaryInfo()
```

C++/CLI

```
void FileSummaryInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FileSummaryInfo](#).

Remarks

When your application calls this method, SOLIDWORKS displays the dialog box but does not return control to your application until the user closes the dialog box.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstFeature Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FirstFeature Method (IModelDoc2)

Gets the first feature in the document.

.NET Syntax

Visual Basic (Declaration)

```
Function FirstFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.FirstFeature()
```

C#

```
System.Object FirstFeature()
```

C++/CLI

```
System.Object^ FirstFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [feature](#) in the document

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FirstFeature](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Iterate Through Dimensions in Model \(VBA\)](#)
[Select Plane \(VBA\)](#)
[Set Dimensions to Mid-Tolerance \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse Assembly and Hide All Sketches \(VBA\)](#)
[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)
[Roll Back Model \(C#\)](#)
[Roll Back Model \(VB.NET\)](#)
[Roll Back Model \(VBA\)](#)

Remarks

This method:

- is identical to [IPartDoc::FirstFeature](#), but is available on the IModelDoc2 interface to include access to assemblies and drawings.
- can access the first feature even if it is suppressed.
- returns features in the current order for the model, and this order changes when the model is edited.

Your application should not assume that:

- features retain the same relative or absolute position throughout the model's lifetime. For example, you should not assume that Sketch1 always appears before Sketch2.
- any feature has a specific name. Because features can be renamed, you cannot assume that the first reference plane feature is named Plane1.

When traversing the FeatureManager design tree, your application should use [IFeature::GetTypeName2](#) and [IFeature::GetSpecificFeature2](#) to identify specific features instead of relying solely on [IFeature::Name](#).

This method returns features in the model definition order, which is not the same as the order displayed in the user interface.

See [ITreeControlItem](#) for details.

To access the next feature in the FeatureManager design tree and subfeatures, use [IFeature::GetNextFeature](#) or [IFeature::!GetNextFeature](#) and [IFeature::GetFirstSubFeature](#) or [IFeature::!GetFirstSubFeature](#) methods, respectively.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetFeatureCount Method](#)
[IModelDoc2::!FirstFeature Method](#)
[IModelDoc2::!FeatureByPositionReverse Method](#)
[IModelDoc2::FeatureByPositionReverse Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::!FirstFeature Method](#)
[IComponent2::FirstFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontBold Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontBold Method (IModelDoc2)

Enables or disables bold font style in the selected notes, dimensions, and GTols.

.NET Syntax

Visual Basic (Declaration)

```
Sub FontBold( _  
    ByVal Bold As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Bold As System.Boolean  
  
instance.FontBold(Bold)
```

C#

```
void FontBold(  
    System.bool Bold  
)
```

C++/CLI

```
void FontBold(  
&    System.bool Bold  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bold

True to enable bold font style, false to disable it

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontBold](#).

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontFace Method](#)
[IModelDoc2::FontItalic Method](#)
[IModelDoc2::FontPoints Method](#)
[IModelDoc2::FontUnderline Method](#)
[IModelDoc2::FontUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontFace Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontFace Method (IModelDoc2)

Changes the font face in the selected notes, dimensions, and GTols.

.NET Syntax

Visual Basic (Declaration)

```
Sub FontFace(  
    ByVal Face As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Face As System.String  
  
instance.FontFace(Face)
```

C#

```
void FontFace(  
    System.string Face  
)
```

C++/CLI

```
void FontFace(  
& System.String^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Face

Points to a null-terminated string that specifies the name of the font face (for example, Times New Roman)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontFace](#).

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontBold Method](#)
[IModelDoc2::FontItalic Method](#)
[IModelDoc2::FontPoints Method](#)
[IModelDoc2::FontUnderline Method](#)
[IModelDoc2::FontUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontItalic Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontItalic Method (IModelDoc2)

Enables or disables italic font style in the selected notes, dimensions, and GTols.

.NET Syntax

Visual Basic (Declaration)

```
Sub FontItalic( _  
    ByVal Italic As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Italic As System.Boolean  
  
instance.FontItalic(Italic)
```

C#

```
void FontItalic(  
    System.bool Italic  
)
```

C++/CLI

```
void FontItalic(  
&    System.bool Italic  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Italic

True to enable italic font style, false to disable

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontItalic](#).

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontBold Method](#)
[IModelDoc2::FontFace Method](#)
[IModelDoc2::FontPoints Method](#)
[IModelDoc2::FontUnderline Method](#)
[IModelDoc2::FontUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontPoints Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontPoints Method (IModelDoc2)

Changes the font height (specified in points) in the selected notes, dimensions, and GTols.

.NET Syntax

Visual Basic (Declaration)

```
Sub FontPoints(  
    ByVal Points As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Points As System.Short  
  
instance.FontPoints(Points)
```

C#

```
void FontPoints(  
    System.short Points  
)
```

C++/CLI

```
void FontPoints(  
& System.short Points  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Points

Height, in points, of the font

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontPoints](#).

Example

[Add Watermark to Part \(C#\)](#)
[Add Watermark to Part \(VB.NET\)](#)
[Add Watermark to Part \(VBA\)](#)

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontBold Method](#)
[IModelDoc2::FontFace Method](#)
[IModelDoc2::FontItalic Method](#)
[IModelDoc2::FontUnderline Method](#)
[IModelDoc2::FontUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontUnderline Method (IModelDoc2)

Enables or disables underlining the selected notes, dimensions, and GTols.

.NET Syntax

Visual Basic (Declaration)

```
Sub FontUnderline( _  
    ByVal Underline As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Underline As System.Boolean  
  
instance.FontUnderline(Underline)
```

C#

```
void FontUnderline(  
    System.bool Underline  
)
```

C++/CLI

```
void FontUnderline(  
& System.bool Underline  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Underline

True to enable underlining, false to disable it

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontUnderline](#).

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontBold Method](#)
[IModelDoc2::FontFace Method](#)
[IModelDoc2::FontItalic Method](#)
[IModelDoc2::FontPoints Method](#)
[IModelDoc2::FontUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontUnits Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : FontUnits Method (IModelDoc2)

Changes font height (specified in current system units) in the selected notes, dimensions, and GTols.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub FontUnits( _  
    ByVal Units As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Units As System.Double  
  
instance.FontUnits(Units)
```

C#

```
void FontUnits(  
    System.double Units  
)
```

C++/CLI

```
void FontUnits(  
&    System.double Units  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Units

Specifies the font height in current system units (for example, inches, millimeters, and so on)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::FontUnits](#).

Example

[Add Watermark to Part \(C#\)](#)
[Add Watermark to Part \(VB.NET\)](#)
[Add Watermark to Part \(VBA\)](#)

Remarks

You can also use [ITextFormat](#) for full control of text formatting. Obtain ITextFormat using the appropriate GetTextFormat method (see index entry GetTextFormat for a list of available GetTextFormat methods).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::FontBold Method](#)
[IModelDoc2::FontFace Method](#)
[IModelDoc2::FontItalic Method](#)
[IModelDoc2::FontPoints Method](#)
[IModelDoc2::FontUnderline Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceRebuild3 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ForceRebuild3 Method (IModelDoc2)

Forces a rebuild of all features in the active configuration in the model.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ForceRebuild3( _  
    ByVal TopOnly As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim TopOnly As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ForceRebuild3(TopOnly)
```

C#

```
System.bool ForceRebuild3(  
    System.bool TopOnly  
)
```

C++/CLI

```
System.bool ForceRebuild3(  
& System.bool TopOnly  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopOnly

True rebuilds the top-level assembly only; false rebuilds the top-level assembly and all subassemblies

Return Value

True if all features in the active configuration at the specified assembly level in the model are rebuilt, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ForceRebuild3](#).

Example

[Force Rebuild \(VBA\)](#)
[Iterate Through All Configurations \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Rebuild Model \(VBA\)](#)
[Set Dimensions to Mid-Tolerance \(VBA\)](#)
[Use Safe Entity \(VBA\)](#)
[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::EditRebuild3 Method](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IModelDoc2::Rebuild Method](#)
[IModelDoc2::ShowFeatureErrorDialog Property](#)
[IConfiguration::AddRebuildSaveMark](#)
[IConfiguration::NeedsRebuild Property](#)
[IModelDocExtension::EditRebuildAll Method](#)
[IModelDocExtension::ForceRebuildAll Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ForceReleaseLocks Method (IModelDoc2)

Releases the locks that a file system places on a file when it is opened and detaches that file from the file system.

.NET Syntax

Visual Basic (Declaration)

```
Function ForceReleaseLocks() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Integer

value = instance.ForceReleaseLocks()
```

C#

```
System.int ForceReleaseLocks()
```

C++/CLI

```
System.int ForceReleaseLocks();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

1 if locks are released, 0 if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ForceReleaseLocks](#).

Remarks

This method only supports part and assembly documents; it does not support drawing documents. See [ISldWorks::CloseAndReopen](#) for details about closing and reopening a drawing document without unloading its references from memory.

You must call [IModelDoc2::ReloadOrReplace](#) after calling IModelDoc2::ForceReleaseLocks to re-attach the detached file to the file system. If you do not call IModelDoc2::ReloadOrReplace after calling IModelDoc2::ForceReleaseLocks, then you will experience problems with OLE objects (e.g., design tables).

IModelDoc2::ReloadOrReplace re-attaches the detached file to the file system; however, any changes made to the detached file are not preserved unless you save the file to disk before calling IModelDoc2::ReloadOrReplace.

CAUTION: This method is intended to be used by PDM systems. Using this method incorrectly could corrupt your data.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetActiveConfiguration Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetActiveConfiguration Method (IModelDoc2)

Obsolete. Superseded by [IConfigurationManager::ActiveConfiguration](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveConfiguration() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Object

value = instance.GetActiveConfiguration()
```

C#

```
System.Object GetActiveConfiguration()
```

C++/CLI

```
System.Object^ GetActiveConfiguration();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetActiveConfiguration](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetActiveSketch Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetActiveSketch Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::GetActiveSketch2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveSketch() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Object

value = instance.GetActiveSketch()
```

C#

```
System.Object GetActiveSketch()
```

C++/CLI

```
System.Object^ GetActiveSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetActiveSketch](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

GetActiveSketch2 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetActiveSketch2 Method (IModelDoc2)

Obsolete. Superseded by [SketchManager.ActiveSketch](#).

.NET Syntax

Visual Basic (Declaration)

Function GetActiveSketch2() As System.Object

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object
```

```
value = instance.GetActiveSketch2()
```

C#

```
System.object GetActiveSketch2()
```

C++/CLI

```
System.Object^ GetActiveSketch2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Active [sketch](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetActiveSketch2](#).

Example

[Dynamically Mirror Sketch Entities \(VBA\)](#)
[Find Outside Edges of Face \(VBA\)](#)
[Get Length of Spline or Elliptical Edge \(VBA\)](#)
[Get Sketch Points and Their Persistent IDs \(VBA\)](#)
[Rename Active Sketch \(VBA\)](#)
[Transform Coordinates from Sketch to Model Space \(VBA\)](#)

Remarks

Before you can use this method, you must select and activate a sketch. You can use [IModelDocExtension::SelectById2](#) to select a sketch and [ISketchManager::InsertSketch](#) to make the sketch active.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::IGetActiveSketch2 Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

GetAddToDB Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetAddToDB Method (IModelDoc2)

Gets whether entities are added directly to the SOLIDWORKS database.

Visual Basic (Declaration)

```
Function GetAddToDB() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim value As System.Boolean

value = instance.GetAddToDB()
```

C#

```
System.bool GetAddToDB()
```

C++/CLI

```
System.bool GetAddToDB();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if currently adding items directly to the database, false otherwise

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetAddToDB](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SetAddToDB Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAmbientLightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetAmbientLightProperties Method (IModelDoc2)

Gets the ambient light properties for this model document.

Visual Basic (Declaration)

```
Function GetAmbientLightProperties( _
    ByVal Name As System.String, _
    ByRef Ambient As System.Double, _
    ByRef Diffuse As System.Double, _
    ByRef Specular As System.Double, _
    ByRef Colour As System.Integer, _
    ByRef Enabled As System.Boolean, _
    ByRef Fixed As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim Name As System.String
Dim Ambient As System.Double
```

```
Dim Diffuse As System.Double
Dim Specular As System.Double
Dim Colour As System.Integer
Dim Enabled As System.Boolean
Dim Fixed As System.Boolean
Dim value As System.Boolean
```

```
value = instance.GetAmbientLightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled, Fixed)
```

C#

```
System.bool GetAmbientLightProperties(
    System.string Name,
    ref System.double Ambient,
    ref System.double Diffuse,
    ref System.double Specular,
    ref System.int Colour,
    ref System.bool Enabled,
    ref System.bool Fixed
)
```

C++/CLI

```
System.bool GetAmbientLightProperties(
    & System.String^ Name,
    & System.double% Ambient,
    & System.double% Diffuse,
    & System.double% Specular,
    & System.int% Colour,
    & System.bool% Enabled,
    & System.bool% Fixed
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name

Ambient

Light source ambient value

Diffuse

Light source diffuse value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True if a light is enabled, false if not

Fixed

True if a light is fixed, false if not

Return Value

True if light properties determined without a problem, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetAmbientLightProperties](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IModelDoc2::SetAmbientLightProperties Method](#)

[IModelDoc2::GetDirectionLightProperties Method](#)

[IModelDoc2::GetPointLightProperties Method](#)

[IModelDoc2::GetSpotlightProperties Method](#)

[IModelDoc2::SetDirectionLightProperties Method](#)

[IModelDoc2::SetPointLightProperties Method](#)

[IModelDoc2::SetSpotlightProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAngularUnits Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetAngularUnits Method (IModelDoc2)

Gets the current angular unit settings.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAngularUnits() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object
```

```
value = instance.GetAngularUnits()
```

C#

```
System.Object GetAngularUnits()
```

C++/CLI

```
System.Object^ GetAngularUnits();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 5 shorts (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetAngularUnits](#).

Remarks

The format of the returned data is an array of 5 shorts:

[*AngleUnit*, *FractionBase*, *FractionValue*, *SignificantDigits*, *RoundToFraction*]

where:

- *AngleUnit* = current angular units. You can find the unit types in [swAngleUnit e.](#)
- *FractionBase* = Not currently supported. Do not use the return value in this field.
- *FractionValue* = Not currently supported. Do not use the return value in this field.
- *SignificantDigits* = significant digits if using decimal units.
- *RoundToFraction* = Not currently supported. Do not use the return value in this field.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::IGetAngularUnits Method](#)
[IModelDoc2::ISetAngularUnits Method](#)
[IModelDoc2::SetAngularUnits Method](#)
[IModelDoc2::GetUnits Method](#)
[IModelDoc2::GetUserUnit Method](#)
[IModelDoc2::IGetUnits Method](#)
[IModelDoc2::IGetUserUnit Method](#)

[IModelDoc2::SetUnits Method](#)
[IModelDoc2::LengthUnit Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcCentersDisplayed Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetArcCentersDisplayed Method (IModelDoc2)

Gets whether the arc centers are displayed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCentersDisplayed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Boolean  
  
value = instance.GetArcCentersDisplayed()
```

C#

```
System.bool GetArcCentersDisplayed()
```

C++/CLI

```
System.bool GetArcCentersDisplayed();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if arc centers are currently displayed, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetArcCentersDisplayed](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SetArcCentersDisplayed Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBendState Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetBendState Method (IModelDoc2)

Gets the current bend state of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendState() As System.Integer
```

```
Dim instance As IModelDoc2  
Dim value As System.Integer  
  
value = instance.GetBendState()
```

C#

```
System.int GetBendState()
```

C++/CLI

```
System.int GetBendState();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current state of sheet metal bends as defined in [swSMBendState_e](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetBendState](#).

Example

[Flatten Sheet Metal Part \(VBA\)](#)

Remarks

If...	Then...
A part with bend information is being edited in context of the assembly (see IAssemblyDoc::EditPart2)	The bend state for that part is returned.
This method is run on a part without bend information or directly on an assembly	swSMBendStateNone is returned, and the return status is S_false (COM only).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SetBendState Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBlockingState Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetBlockingState Method (IModelDoc2)

Gets the current value of the SOLIDWORKS blocking state, within the range of values accessible by [IModelDoc2::SetBlockingState](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBlockingState() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim value As System.Integer
```

```
value = instance.GetBlockingState()
```

C#

```
System.int GetBlockingState()
```

C++/CLI

```
System.int GetBlockingState();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

State as defined by [swBlockingStates](#) [e](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetBlockingState](#).

Example

[Get Blocking State \(VBA\)](#)
[Set Blocking State \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::ResetBlockingState Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColorTable Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetColorTable Method (IModelDoc2)

Obsolete. Superseded by [ISldWorks::GetColorTable](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetColorTable() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.GetColorTable()
```

C#

```
System.object GetColorTable()
```

C++/CLI

```
System.Object^ GetColorTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetColorTable](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetConfigurationByName Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetConfigurationByName Method (IModelDoc2)

Gets the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationByName( _  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim value As System.Object  
  
value = instance.GetConfigurationByName(Name)
```

C#

```
System.object GetConfigurationByName(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ GetConfigurationByName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Configuration name

Return Value

[Configuration](#) or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetConfigurationByName](#).

Example

[Add Derived Configurations \(VBA\)](#)
[Change Configuration Properties \(VBA\)](#)
[Get Custom Properties \(VBA\)](#)
[Save Configuration Data \(C#\)](#)
[Save Configuration Data \(VB.NET\)](#)
[Save Configuration Data \(VBA\)](#)

Remarks

If the specified configuration has not been activated, then some data may be unavailable. For example, attempting to traverse assembly components for a configuration that has not been activated results in a NULL root component being returned from [IConfiguration::GetRootComponent](#). However, the IConfiguration object returned is useful for obtaining data that is stored with the IConfiguration

object, such as the [IConfiguration::AlternateName](#) value. The specified configuration does not have to be activated to obtain this type of stored information.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddConfiguration3 Method](#)
[IModelDoc2::GetConfigurationCount Method](#)
[IModelDoc2::GetConfigurationNames Method](#)
[IModelDoc2::IGetConfigurationByName Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::DeleteConfiguration2 Method](#)
[IModelDoc2::ShowConfiguration2 Method](#)
[IModelDoc2::ConfigurationManager Property](#)
[IConfigurationManager Interface](#)
[IConfiguration Interface](#)
[IModelDoc2::IAddConfiguration3 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationCount Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetConfigurationCount Method (IModelDoc2)

Gets the number of configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount()
```

C#

```
System.int GetConfigurationCount()
```

C++/CLI

```
System.int GetConfigurationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of configurations

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetConfigurationCount](#).

Example

[Get Names of Configurations Using Variant \(C++\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddConfiguration3 Method](#)
[IModelDoc2::DeleteConfiguration2 Method](#)
[IModelDoc2::GetConfigurationByName Method](#)
[IModelDoc2::GetConfigurationNames Method](#)

[IModelDoc2::IAddConfiguration3 Method](#)
[IModelDoc2::IGetConfigurationByName Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::ShowConfiguration2 Method](#)
[IConfigurationManager Interface](#)
[IConfiguration Interface](#)
[IModelDoc2::ConfigurationManager Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationNames Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetConfigurationNames Method (IModelDoc2)

Gets the names of the configurations in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.GetConfigurationNames()
```

C#

```
System.object GetConfigurationNames()
```

C++/CLI

```
System.Object^ GetConfigurationNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the names of the configurations in the order they are created in this document

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetConfigurationNames](#).

Example

[Extract Configuration-specific Parameters \(VBA\)](#)
[Get Custom Properties \(VBA\)](#)
[Get Dimension Values in All Configurations \(VBA\)](#)
[Iterate Through All Configurations \(VBA\)](#)
[List Custom Properties \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Remove Material Properties from Assembly Component \(VBA\)](#)
[Save Configuration Data \(C#\)](#)
[Save Configuration Data \(VB.NET\)](#)
[Save Configuration Data \(VBA\)](#)
[Get Names of Configurations Using Variant \(C++\)](#)
[Get List of Configurations \(C#\)](#)
[Get List of Configurations \(VB.NET\)](#)
[Get List of Configurations \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddConfiguration3 Method](#)
[IModelDoc2::DeleteConfiguration2 Method](#)
[IModelDoc2::GetConfigurationCount Method](#)
[IModelDoc2::GetConfigurationByName Method](#)
[IModelDoc2::IAddConfiguration3 Method](#)
[IModelDoc2::IGetConfigurationByName Method](#)

[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::ShowConfiguration2 Method](#)
[IModelDoc2::ConfigurationManager Property](#)
[IConfigurationManager Interface](#)
[IConfiguration Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConsiderLeadersAsLines Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetConsiderLeadersAsLines Method (IModelDoc2)

Gets whether the display data of a leader is included as lines when the lines are retrieved from a view or annotation in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConsiderLeadersAsLines() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Boolean
```

```
value = instance.GetConsiderLeadersAsLines()
```

C#

```
System.bool GetConsiderLeadersAsLines()
```

C++/CLI

```
System.bool GetConsiderLeadersAsLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if leaders are returned as line data, false if leaders are not returned as line data

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetConsiderLeadersAsLines](#).

Remarks

The various GetLeaderCount and GetLeaderAtIndex methods return information about where the vertices of the leader are located. These methods also return the leader information as part of its line information.

Depending on what your program is trying to accomplish and which APIs it is using, this duplication of information may not be desirable. [IModelDoc2::SetConsiderLeadersAsLines](#) controls this behavior by setting a flag on the document that indicates whether the leader information should be returned as part of the line information. IModelDoc2::GetConsiderLeadersAsLines gets the current behavior for this document.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoordinateSystemXformByName Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCoordinateSystemXformByName Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::GetCoordinateSystemTransformByName](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoordinateSystemXformByName( _  
    ByVal NameIn As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim NameIn As System.String  
Dim value As System.Object  
  
value = instance.GetCoordinateSystemXformByName(NameIn)
```

C#

```
System.object GetCoordinateSystemXformByName(  
    System.string NameIn  
)
```

C++/CLI

```
System.Object^ GetCoordinateSystemXformByName(  
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCoordinateSystemXformByName](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCurrentCoordinateSystemName Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCurrentCoordinateSystemName Method (IModelDoc2)

Gets the name of the current coordinate system or an empty string for the default coordinate system.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentCoordinateSystemName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.String  
  
value = instance.GetCurrentCoordinateSystemName()
```

C#

```
System.string GetCurrentCoordinateSystemName()
```

C++/CLI

```
System.String^ GetCurrentCoordinateSystemName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the current coordinate system

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCurrentCoordinateSystemName](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::InsertCoordinateSystem Method](#)
[IModelDocExtension::GetCoordinateSystemTransformByName Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomInfoCount Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoCount Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Integer  
  
value = instance.GetCustomInfoCount()
```

C#

```
System.int GetCustomInfoCount()
```

C++/CLI

```
System.int GetCustomInfoCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoCount](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomInfoCount2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoCount2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoCount2( _  
    ByVal Configuration As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim value As System.Integer  
  
value = instance.GetCustomInfoCount2(Configuration)
```

C#

```
System.int GetCustomInfoCount2(  
    System.string Configuration  
)
```

C++/CLI

```
System.int GetCustomInfoCount2(  
& System.String^ Configuration  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoCount2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomInfoNames Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoNames Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object
```

```
value = instance.GetCustomInfoNames()
```

C#

```
System.object GetCustomInfoNames()
```

C++/CLI

```
System.Object^ GetCustomInfoNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoNames](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomInfoNames2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoNames2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoNames2( _  
    ByVal Configuration As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim value As System.Object  
  
value = instance.GetCustomInfoNames2(Configuration)
```

C#

```
System.object GetCustomInfoNames2(  
    System.string Configuration  
)
```

C++/CLI

```
System.Object^ GetCustomInfoNames2(  
& System.String^ Configuration  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoNames2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomInfoType Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoType Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoType( _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FieldName As System.String  
Dim value As System.String  
  
value = instance.GetCustomInfoType(FieldName)
```

C#

```
System.string GetCustomInfoType(  
    System.string FieldName  
)
```

C++/CLI

```
System.String^ GetCustomInfoType(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoType](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomInfoType2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoType2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoType2( _  
    ByVal FieldName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FieldName As System.String  
Dim value As System.Integer  
  
value = instance.GetCustomInfoType2(FieldName)
```

C#

```
System.int GetCustomInfoType2(  
    System.string FieldName  
)
```

C++/CLI

```
System.int GetCustomInfoType2(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoType2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomInfoType3 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoType3 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoType3( _  
    ByVal Configuration As System.String, _  
    ByVal FieldName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim FieldName As System.String  
Dim value As System.Integer  
  
value = instance.GetCustomInfoType3(Configuration, FieldName)
```

C#

```
System.int GetCustomInfoType3(  
    System.string Configuration,  
    System.string FieldName  
)
```

C++/CLI

```
System.int GetCustomInfoType3(  
& System.String^ Configuration,  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

FieldName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoType3](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomInfoValue Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetCustomInfoValue Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomInfoValue( _  
    ByVal Configuration As System.String, _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Configuration As System.String  
Dim FieldName As System.String  
Dim value As System.String  
  
value = instance.GetCustomInfoValue(Configuration, FieldName)
```

C#

```
System.string GetCustomInfoValue(  
    System.string Configuration,  
    System.string FieldName  
)
```

C++/CLI

```
System.String^ GetCustomInfoValue(  
& System.String^ Configuration,  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

FieldName

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetCustomInfoValue](#).

 See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDefaultTextHeight Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetDefaultTextHeight Method (IModelDoc2)

Gets the default text height in use for this document.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetDefaultTextHeight() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Double  
  
value = instance.GetDefaultTextHeight()
```

C#

```
System.double GetDefaultTextHeight()
```

C++/CLI

```
System.double GetDefaultTextHeight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Default height (in meters) for text for this document

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDefaultTextHeight](#).

 See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDependencies Method (IModelDoc2)

[See Also](#)



Obsolete. Superseded by [IModelDoc2::GetDependencies2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDependencies( _  
    ByVal Traverseflag As System.Integer, _  
    ByVal Searchflag As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Traverseflag As System.Integer  
Dim Searchflag As System.Integer  
Dim value As System.Object  
  
value = instance.GetDependencies(Traverseflag, Searchflag)
```

C#

```
System.object GetDependencies(  
    System.int Traverseflag,  
    System.int Searchflag  
)
```

C++/CLI

```
System.Object^ GetDependencies(  
& System.int Traverseflag,  
& System.int Searchflag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Traverseflag

Searchflag

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDependencies](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

GetDependencies2 Method (IModelDoc2)

[See Also](#) [Example](#)



Obsolete. Superseded by [IModelDocExtension::GetDependencies](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDependencies2( _  
    ByVal Traverseflag As System.Boolean, _  
    ByVal Searchflag As System.Boolean, _  
    ByVal AddReadOnlyInfo As System.Boolean _  
) As System.Object
```

```

Dim instance As IModelDoc2
Dim Traverseflag As System.Boolean
Dim Searchflag As System.Boolean
Dim AddReadOnlyInfo As System.Boolean
Dim value As System.Object

value = instance.GetDependencies2(Traverseflag, Searchflag, AddReadOnlyInfo)

```

C#

```

System.Object GetDependencies2(
    System.bool Traverseflag,
    System.bool Searchflag,
    System.bool AddReadOnlyInfo
)

```

C++/CLI

```

System.Object^ GetDependencies2(
    & System.bool Traverseflag,
    & System.bool Searchflag,
    & System.bool AddReadOnlyInfo
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Traverseflag

True to traverse down into all dependent files, false for only the highest level within the dependencies

Searchflag

True to use the search rules to find dependencies, false to look where the documents were last saved

AddReadOnlyInfo

True to show read-only information in the returned strings, false to not

Return Value

Array of strings; there are two strings for each document returned in this list of dependent files:

- first string is the file name
- second string is the filename with the complete pathname

NOTE: This combination repeats itself for each dependent file found for this IModelDoc2.

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDependencies2](#).

Example

[Get Active Document Dependencies \(VBA\)](#)
[Get Unopened Document Dependents \(VBA\)](#)

Remarks

Calling this method on a drawing document returns a list of all the parts and assemblies used in the drawing. If you set Traverseflag to True, then each of the parts within the assembly file is also returned in this array of strings.

Because a derived mirror part is generated from another part, the list of model dependencies returned by this method would include the original part used to generate the derived mirror part.

Library features are completely unassociated. They do not require the library nor do they update when changes are made to the library feature. Therefore, this method does not return library features.

If you use this method with an assembly that contains two documents, Part1 and SubAssem1, an example of what might be returned is:

```
[ "Part1", "C:\temp\Part1.SLDPRT", "SubAssem1", "c:\temp\SubAssem1.SLDASM" ]
```

If Traverseflag is set to True, then all the documents contained in SubAssem1.ASM are returned. Also, suppressed components are recognized and returned by this method as a dependent file.

If AddReadOnlyInfo is set to True, then a string of True or false is added to the list of strings. If Part1 is read-only, then the resulting set of strings would be:

```
[ "Part1", "C:\temp\Part1.SLDPR1", "True", "SubAssem1", "c:\temp\SubAssem1.SLDASM", "" ]
```

NOTE: For assemblies containing suppressed or lightweight components, file references (return value from this method) point to the as-saved component reference because the actual component has not been loaded into memory. Because the suppressed and lightweight components have not actually been loaded, the current search criteria has not been applied to update the file references. Setting Searchflag to True vs. false causes this method to apply the current search criteria rules to locate the particular reference and may result in a different return value. Likewise unsuppressing or resolving these components causes the current search criteria to be applied and updates the assembly's component references in memory, if necessary.

When calling this method with Searchflag set to True, you can explicitly set the search folders first. This is important because this method uses the current SOLIDWORKS directory as its second search criteria. Because the user may have interactively opened files from some random directory, you cannot be certain the current SOLIDWORKS directory is pointing to the desired location. You may want to consider setting the search folders to that of the document being used in this method.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::IGetDependencies2 Method](#)
[IModelDoc2::GetNumDependencies Method](#)
[IModelDoc2::IGetNumDependencies2 Method](#)
[ISldWorks::GetDocumentDependencies2 Method](#)
[ISldWorks::IGetDocumentDependencies2 Method](#)
[ISldWorks::IGetDocumentDependenciesCount2 Method](#)
[ISldWorks::GetDocumentDependenciesCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDesignTable Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetDesignTable Method (IModelDoc2)

Gets the design table associated with this part or assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDesignTable() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.GetDesignTable()
```

C#

```
System.Object GetDesignTable()
```

C++/CLI

```
System.Object^ GetDesignTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Design table](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDesignTable](#).

Example

[Add Row to Design Table \(VBA\)](#)
[Get Excel Design Table Worksheet \(VBA\)](#)
[Get or Set Whether Edits Update Design Table \(VBA\)](#)

[Get Design Table \(C#\)](#)
[Get Design Table \(VB.NET\)](#)
[Get Design Table \(VBA\)](#)

Remarks

If you call this method from a drawing document, null or Nothing is returned.

To access design tables from a drawing document you must get the [IModelDoc2](#) object associated with a particular drawing view and then call this method from that IModelDoc2 object. To determine if a drawing view has a design table associated with it, use [IView::HasDesignTable](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::CloseFamilyTable Method](#)
[IModelDoc2::DeleteDesignTable Method](#)
[IModelDoc2::InsertFamilyTableEdit Method](#)
[IModelDoc2::InsertFamilyTableNew Method](#)
[IModelDoc2::InsertFamilyTableOpen Method](#)
[IModelDocExtension::HasDesignTable Method](#)
[IModelDoc2::IGetDesignTable Method](#)
[IModelDoc2::GetDesignTable Method](#)
[IDesignTable Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDetailingDefaults Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetDetailingDefaults Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::GetUserPreferenceTextFormat](#) and [IModelDoc2::SetUserPreferenceTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailingDefaults() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.GetDetailingDefaults()
```

C#

```
System.object GetDetailingDefaults()
```

C++/CLI

```
System.Object^ GetDetailingDefaults();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDetailingDefaults](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDirectionLightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : GetDirectionLightProperties Method (IModelDoc2)

Gets the directional light properties.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionLightProperties( _  
    ByVal Name As System.String, _  
    ByRef Ambient As System.Double, _  
    ByRef Diffuse As System.Double, _  
    ByRef Specular As System.Double, _  
    ByRef Colour As System.Integer, _  
    ByRef Enabled As System.Boolean, _  
    ByRef Fixed As System.Boolean, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim Ambient As System.Double  
Dim Diffuse As System.Double  
Dim Specular As System.Double  
Dim Colour As System.Integer  
Dim Enabled As System.Boolean  
Dim Fixed As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetDirectionLightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled,  
Fixed, X, Y, Z)
```

C#

```
System.bool GetDirectionLightProperties(  
    System.string Name,  
    ref System.double Ambient,  
    ref System.double Diffuse,  
    ref System.double Specular,  
    ref System.int Colour,  
    ref System.bool Enabled,  
    ref System.bool Fixed,  
    ref System.double X,  
    ref System.double Y,  
    ref System.double Z  
)
```

C++/CLI

```
System.bool GetDirectionLightProperties(  
& System.String^ Name,  
& System.double% Ambient,  
& System.double% Diffuse,  
& System.double% Specular,  
& System.int% Colour,  
& System.bool% Enabled,  
& System.bool% Fixed,  
& System.double% X,  
& System.double% Y,  
& System.double% Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name

Ambient

Light source ambient value

Diffuse

Light source diffuse value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True if a light is enabled, false if not

Fixed

True if a light is fixed, false if not

X

x component of the light direction vector

Y

y component of the light direction vector

Z

z component of the light direction vector

Return Value

True if light properties determined without a problem, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::GetDirectionLightProperties](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IModelDoc2::SetDirectionLightProperties Method](#)

[IModelDoc2::LightSourcePropertyValues Property](#)

[IModelDoc2::ILightSourcePropertyValues Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0