

# SOLIDWORKS API (.NET VBA C#) — Reference

## (190/337): IModelDoc2 (part 13 of 17)

SOLIDWORKS API Documentation (converted from CHM)

## IModelDoc2 (part 13 of 17) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

### ListExternalFileReferences2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ListExternalFileReferences2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::ListExternalReferences](#).

#### .NET Syntax

##### Visual Basic (Declaration)

```
Sub ListExternalFileReferences2( _  
    ByRef ModelPathName As System.Object, _  
    ByRef ComponentPathName As System.Object, _  
    ByRef Feature As System.Object, _  
    ByRef DataType As System.Object, _  
    ByRef Status As System.Object, _  
    ByRef RefEntity As System.Object, _  
    ByRef FeatCom As System.Object _  
)
```

##### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ModelPathName As System.Object  
Dim ComponentPathName As System.Object  
Dim Feature As System.Object  
Dim DataType As System.Object  
Dim Status As System.Object  
Dim RefEntity As System.Object  
Dim FeatCom As System.Object
```

```
instance.ListExternalFileReferences2(ModelPathName, ComponentPathName, Feature, DataType, Status,  
RefEntity, FeatCom)
```

##### C#

```
void ListExternalFileReferences2(  
    out System.object ModelPathName,  
    out System.object ComponentPathName,  
    out System.object Feature,  
    out System.object DataType,  
    out System.object Status,  
    out System.object RefEntity,  
    out System.object FeatCom  
)
```

##### C++/CLI

```
void ListExternalFileReferences2(  
& [Out] System.Object^ ModelPathName,  
& [Out] System.Object^ ComponentPathName,  
& [Out] System.Object^ Feature,  
& [Out] System.Object^ DataType,  
& [Out] System.Object^ Status,  
& [Out] System.Object^ RefEntity,  
& [Out] System.Object^ FeatCom  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ModelPathName*

*ComponentPathName*

*Feature*

[DataType](#)

[Status](#)

[RefEntity](#)

[FeatCom](#)

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ListExternalFileReferences2](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ListExternalFileReferencesCount Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ListExternalFileReferencesCount Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::ListExternalFileReferenceCount](#).

## .NET Syntax

Visual Basic (Declaration)

```
Function ListExternalFileReferencesCount( _  
    ByVal UseSearchRules As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UseSearchRules As System.Boolean  
Dim value As System.Integer  
  
value = instance.ListExternalFileReferencesCount(UseSearchRules)
```

C#

```
System.int ListExternalFileReferencesCount(  
    System.bool UseSearchRules  
)
```

C++/CLI

```
System.int ListExternalFileReferencesCount(  
&    System.bool UseSearchRules  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*UseSearchRules*

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ListExternalFileReferencesCount](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ListExternalFileReferencesCount2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ListExternalFileReferencesCount2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::ListExternalFileReferenceCount](#).

## .NET Syntax

Visual Basic (Declaration)

```
Function ListExternalFileReferencesCount2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Integer

value = instance.ListExternalFileReferencesCount2()
```

C#

```
System.int ListExternalFileReferencesCount2()
```

C++/CLI

```
System.int ListExternalFileReferencesCount2();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ListExternalFileReferencesCount2](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Lock Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Lock Method (IModelDoc2)

Blocks the modifying commands in the user interface, effectively locking the application.

## .NET Syntax

Visual Basic (Declaration)

```
Sub Lock()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2

instance.Lock()
```

C#

```
void Lock()
```

C++/CLI

```
void Lock();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Lock](#).

## Remarks

This method also changes the status bar to display **Processing**. Use this method with [IModelDoc2::UnLock](#) .

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## LockAllExternalReferences Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : LockAllExternalReferences Method (IModelDoc2)

Locks all external references.

## .NET Syntax

Visual Basic (Declaration)

```
Sub LockAllExternalReferences()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.LockAllExternalReferences()
```

C#

```
void LockAllExternalReferences()
```

C++/CLI

```
void LockAllExternalReferences();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::LockAllExternalReferences](#).

## Example

[Lock All External References \(VBA\)](#)

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::UnlockAllExternalReferences Method](#)  
[IModelDoc2::ListAuxiliaryExternalFileReferences Method](#)  
[IModelDoc2::ListAuxiliaryExternalFileReferences Method](#)  
[IModelDocExtension::ListExternalFileReferences Method](#)  
[IModelDocExtension::ListExternalFileReferences Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## LockFramePoint Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : LockFramePoint Method (IModelDoc2)

Obsolete. Not superseded.

### .NET Syntax

Visual Basic (Declaration)

```
Sub LockFramePoint()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.LockFramePoint()
```

C#

```
void LockFramePoint()
```

C++/CLI

```
void LockFramePoint();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::LockFramePoint](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## LockLightToModel Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : LockLightToModel Method (IModelDoc2)

Locks or unlocks the specified light.

### .NET Syntax

Visual Basic (Declaration)

```
Function LockLightToModel( _  
    ByVal LightId As System.Integer, _  
    ByVal Fix As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim LightId As System.Integer  
Dim Fix As System.Boolean  
Dim value As System.Boolean  
  
value = instance.LockLightToModel(LightId, Fix)
```

C#

```
System.bool LockLightToModel(  
    System.int LightId,
```

```
        System.bool Fix
    )
```

C++/CLI

```
System.bool LockLightToModel(
&    System.int LightId,
&    System.bool Fix
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*LightId*  
Light ID

*Fix*  
True if the light is locked, false if not

#### Return Value

True if change is successful, false if not

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::LockLightToModel](#).

### Example

[Add Spotlight and Get Light Feature \(C#\)](#)  
[Add Spotlight and Get Light Feature \(VB.NET\)](#)  
[Add Spotlight and Get Light Feature \(VBA\)](#)

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::IsLightLockedToModel Method](#)  
[IModelDoc2::GetLightSourceIdFromName Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## MaterialIdName Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : MaterialIdName Property (IModelDoc2)

**Obsolete.** Superseded by [IPartDoc::GetMaterialPropertyName2](#) and [IPartDoc::SetMaterialPropertyName2](#).

### .NET Syntax

Visual Basic (Declaration)

```
Property MaterialIdName As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.String

instance.MaterialIdName = value

value = instance.MaterialIdName
```

C#

```
System.string MaterialIdName {get; set;}
```

C++/CLI

```
property System.String^ MaterialIdName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Material name

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::MaterialIdName](#).

### Example

[Set Material Property Name \(VBA\)](#)  
[Add and Delete Appearances from Specific Display States \(C#\)](#)  
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)  
[Add and Delete Appearances from Specific Display States \(VBA\)](#)

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::MaterialPropertyValues Property](#)  
[IModelDoc2::MaterialPropertyValues Property](#)  
[IModelDoc2::MaterialUserName Property](#)  
[IModelDocExtension::GetMaterialPropertyValues Method](#)  
[IModelDocExtension::IGetMaterialPropertyValues Method](#)  
[IModelDocExtension::SetMaterialPropertyValues Method](#)  
[IModelDocExtension::SetMaterialPropertyValues Method](#)  
[IModelDocExtension::RemoveMaterialProperty Method](#)  
[IModelDocExtension::RemoveMaterialProperty Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## MaterialPropertyValues Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : MaterialPropertyValues Property (IModelDoc2)

Gets or sets a material's properties in the active configuration.

### .NET Syntax

Visual Basic (Declaration)

Property MaterialPropertyValues As System.Object

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Object

instance.MaterialPropertyValues = value

value = instance.MaterialPropertyValues
```

C#

```
System.object MaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.Object^ MaterialPropertyValues {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Array of 9 doubles describing the material's values (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::MaterialPropertyValues](#).

### Example

[Change Color of Face \(VBA\)](#)  
[Get Material Properties \(VBA\)](#)  
[Get Faces Associated with Feature \(C#\)](#)  
[Get Faces Associated with Feature \(VB.NET\)](#)  
[Get Faces Associated with Feature \(VBA\)](#)

### Remarks

The format of the return values is an array of doubles:

[ *R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission* ]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after setting this property.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDocExtension::SetMaterialPropertyValues Method](#)  
[IModelDocExtension::RemoveMaterialProperty Method](#)  
[IModelDocExtension::ISetMaterialPropertyValues Method](#)  
[IModelDocExtension::IRemoveMaterialProperty Method](#)  
[IModelDocExtension::IGetMaterialPropertyValues Method](#)  
[IModelDocExtension::GetMaterialPropertyValues Method](#)  
[IModelDoc2::MaterialUserName Property](#)  
[IModelDoc2::MaterialIdName Property](#)  
[IModelDoc2::IMaterialPropertyValues Property](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## MaterialUserName Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : MaterialUserName Property (IModelDoc2)

Gets or sets the material name.

### .NET Syntax

Visual Basic (Declaration)

Property MaterialUserName As System.String

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.String
```

```
instance.MaterialUserName = value
```

```
value = instance.MaterialUserName
```

C#

```
System.string MaterialUserName {get; set;}
```

C++/CLI

```
property System.String^ MaterialUserName {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Material's name property

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::MaterialUserName](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::MaterialPropertyValues Property](#)  
[IModelDoc2::MaterialIdName Property](#)  
[IModelDoc2::MaterialPropertyValues Property](#)  
[IModelDocExtension::GetMaterialPropertyValues Method](#)  
[IModelDocExtension::IGetMaterialPropertyValues Method](#)  
[IModelDocExtension::IRemoveMaterialProperty Method](#)  
[IModelDocExtension::ISetMaterialPropertyValues Method](#)  
[IModelDocExtension::RemoveMaterialProperty Method](#)  
[IModelDocExtension::SetMaterialPropertyValues Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ModelViewManager Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ModelViewManager Property (IModelDoc2)

Gets the [IModelViewManager](#) object, which allows access to the model view.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ModelViewManager As ModelViewManager
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As ModelViewManager  
  
value = instance.ModelViewManager
```

C#

```
ModelViewManager ModelViewManager {get;}
```

C++/CLI

```
property ModelViewManager^ ModelViewManager {  
    ModelViewManager^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ModelViewManager](#).

## Example

[Create Drag Arrow Manipulator \(VBA\)](#)  
[Set Viewports \(C#\)](#)  
[Set Viewports \(VB.NET\)](#)  
[Set Viewports \(VBA\)](#)  
[Add ActiveX Tabs to Model View \(C#\)](#)  
[Add ActiveX Tabs to Model View \(VB.NET\)](#)  
[Add ActiveX Tabs to Model View \(VBA\)](#)

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

## Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## MoldDraftAnalysis Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : MoldDraftAnalysis Method (IModelDoc2)

Performs a mold draft analysis.

## .NET Syntax

Visual Basic (Declaration)

```
Sub MoldDraftAnalysis( _  
    ByVal Angle As System.Double, _  
    ByVal Options As System.Integer, _  
    ByVal Colors As System.Object, _  
    ByVal Shows As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Angle As System.Double  
Dim Options As System.Integer  
Dim Colors As System.Object  
Dim Shows As System.Integer  
  
instance.MoldDraftAnalysis(Angle, Options, Colors, Shows)
```

C#

```
void MoldDraftAnalysis(  
    System.double Angle,  
    System.int Options,  
    System.object Colors,  
    System.int Shows  
)
```

C++/CLI

```
void MoldDraftAnalysis(  
&    System.double Angle,  
&    System.int Options,  
&    System.Object^ Colors,  
&    System.int Shows  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

### Angle

Reference draft angle

### Options

Analysis options as defined in [swDraftAnalysisOptions\\_e](#)

### Colors

Array of 4 colors (positive draft, negative draft, no draft, straddled faces)

### Shows

Show each draft type as defined in [swDraftAnalysisShow\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::MoldDraftAnalysis](#).

## See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## MultiSelectByRay Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : MultiSelectByRay Method (IModelDoc2)

Selects multiple objects of the specified type that are intersected by a ray from point (x,y,z in meters) in direction vector (x,y,z) within a distance radius.

## .NET Syntax

### Visual Basic (Declaration)

```
Function MultiSelectByRay( _  
    ByVal DoubleInfoIn As System.Object, _  
    ByVal TypeWanted As System.Integer, _  
    ByVal Append As System.Boolean _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim DoubleInfoIn As System.Object  
Dim TypeWanted As System.Integer  
Dim Append As System.Boolean  
Dim value As System.Boolean  
  
value = instance.MultiSelectByRay(DoubleInfoIn, TypeWanted, Append)
```

### C#

```
System.bool MultiSelectByRay(  
    System.object DoubleInfoIn,  
    System.int TypeWanted,  
    System.bool Append  
)
```

### C++/CLI

```
System.bool MultiSelectByRay(  
& System.Object^ DoubleInfoIn,  
& System.int TypeWanted,  
& System.bool Append  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*DoubleInfn*  
Array of 7 doubles:3 for the start point of the ray, 3 for the direction of the ray, and 1 for the radius  
*TypeWanted*  
Type of objects to select as defined in [swSelectType\\_e](#)

*Append*  
True to append the selections to the current selection list, false to not

#### Return Value

True if an object is selected, false if not

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::MultiSelectByRay](#).

### Remarks

This method:

- Defines a cylindrical region of infinite length that begins at pointIn, runs parallel to VectorIn, and has a radius of RadiusIn. If you specify edges or vertices, then any edge or vertex found within the selection cylinder is selected.
- Selects only entity objects, which include faces, edges, and vertices. You cannot use this function to select [ISketch](#) objects.

When selecting face entities, RadiusIn is ignored and a cylinder of infinitely small radius is used.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::GetRayIntersectionsPoints Method](#)  
[IModelDoc2::GetRayIntersectionsTopology Method](#)  
[IModelDoc2::IGetRayIntersectionsPoints Method](#)  
[IModelDoc2::IGetRayIntersectionsTopology Method](#)  
[IModelDoc2::IMultiSelectByRay Method](#)  
[IModelDoc2::IRayIntersections Method](#)  
[IModelDoc2::ISelectByRay Method](#)  
[IModelDoc2::RayIntersections Method](#)  
[IModelDoc2::SelectByRay Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## NameView Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : NameView Method (IModelDoc2)

Creates a named view using the current view.

### .NET Syntax

#### Visual Basic (Declaration)

```
Sub NameView( _  
    ByVal VName As System.String _  
)
```

#### Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim VName As System.String  
  
instance.NameView(VName)
```

#### C#

```
void NameView(  
    System.string VName  
)
```

C++/CLI

```
void NameView(  
& System.String^ VName  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

VName

Name for the new view

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::NameView](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::ShowNamedView2 Method](#)  
[IModelDoc2::DeleteNamedView Method](#)  
[IModelDocExtension::IGetNamedViewRotation Method](#)  
[IModelDocExtension::GetNamedViewRotation Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ObjectDisplayAsIcon Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ObjectDisplayAsIcon Method (IModelDoc2)

Shows the current OLE object as an icon.

### .NET Syntax

Visual Basic (Declaration)

```
Sub ObjectDisplayAsIcon()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.ObjectDisplayAsIcon()
```

C#

```
void ObjectDisplayAsIcon()
```

C++/CLI

```
void ObjectDisplayAsIcon();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ObjectDisplayAsIcon](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::ObjectDisplayContent Method](#)  
[IModelDoc2::ObjectResetsize Method](#)  
[IModelDocExtension::InsertObjectFromFile Method](#)  
[IModelDocExtension::ICreateOLEObject Method](#)

[IModelDocExtension::CreateOLEObject Method](#)  
[IModelDocExtension::GetOLEObjectCount Method](#)  
[IModelDocExtension::GetOLEObjects Method](#)  
[IModelDocExtension::IGetOLEObjects Method](#)  
[ISwOLEObject Interface](#)

 **Availability**

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

**ObjectDisplayContent Method (IModelDoc2)**

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ObjectDisplayContent Method (IModelDoc2)

Shows the current OLE object's content.

 **.NET Syntax**

Visual Basic (Declaration)

```
Sub ObjectDisplayContent()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.ObjectDisplayContent()
```

C#

```
void ObjectDisplayContent()
```

C++/CLI

```
void ObjectDisplayContent();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 **Visual Basic for Applications (VBA) Syntax**

See [ModelDoc2::ObjectDisplayContent](#).

 **See Also**

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::ObjectDisplayAsIcon Method](#)  
[IModelDoc2::ObjectResetSize Method](#)  
[IModelDocExtension::CreateOLEObject Method](#)  
[IModelDocExtension::GetOLEObjectCount Method](#)  
[IModelDocExtension::GetOLEObjects Method](#)  
[IModelDocExtension::ICreateOLEObject Method](#)  
[IModelDocExtension::IGetOLEObjects Method](#)  
[IModelDocExtension::InsertObjectFromFile Method](#)  
[ISwOLEObject Interface](#)

 **Availability**

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

**ObjectResetSize Method (IModelDoc2)**

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ObjectResetSize Method (IModelDoc2)

Sets the size of the current OLE object to the default.

 **.NET Syntax**

Visual Basic (Declaration)

```
Sub ObjectResetSize()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.ObjectResetSize()
```

C#

```
void ObjectResetSize()
```

C++/CLI

```
void ObjectResetSize();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ObjectResetSize](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::ObjectDisplayAsIcon Method](#)  
[IModelDoc2::ObjectDisplayContent Method](#)  
[IModelDocExtension::CreateOLEObject Method](#)  
[IModelDocExtension::GetOLEObjectCount Method](#)  
[IModelDocExtension::GetOLEObjects Method](#)  
[IModelDocExtension::IGetOLEObjects Method](#)  
[IModelDocExtension::InsertObjectFromFile Method](#)  
[ISwOLEObject Interface](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PageSetup Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PageSetup Property (IModelDoc2)

Gets the page setup for this document.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PageSetup As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object  
  
value = instance.PageSetup
```

C#

```
System.Object PageSetup {get;}
```

C++/CLI

```
property System.Object^ PageSetup {  
    System.Object^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

[Page setup](#)

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PageSetup](#).

## Example

[Print Drawing and Save As PDF \(VBA\)](#)  
[Print Drawing \(C#\)](#)  
[Print Drawing \(VB.NET\)](#)  
[Print Drawing \(VBA\)](#)

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::IPageSetup Property](#)  
[IModelDocExtension::AppPageSetup Property](#)  
[IModelDocExtension::UsePageSetup Property](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Parameter Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Parameter Method (IModelDoc2)

Gets the specified parameter.

## .NET Syntax

### Visual Basic (Declaration)

```
Function Parameter( _  
    ByVal StringIn As System.String _  
) As System.Object
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim StringIn As System.String  
Dim value As System.Object  
  
value = instance.Parameter(StringIn)
```

### C#

```
System.object Parameter(  
    System.string StringIn  
)
```

### C++/CLI

```
System.Object^ Parameter(  
& System.String^ StringIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*StringIn*

Name of parameter (for example, "D1@Base-Revolve")

## Return Value

Parameter (see **Remarks**)

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Parameter](#).

## Example

[Change Dimension \(VBA\)](#)  
[Get Depth of Extrusion \(VBA\)](#)  
[Modify Plane By Changing System Value \(VBA\)](#)  
[Recalculate Bounding Box \(C#\)](#)  
[Recalculate Bounding Box \(VB.NET\)](#)  
[Recalculate Bounding Box \(VBA\)](#)

## Remarks

Most parameters are [dimensions](#).

The StringIn argument must be the fully qualified dimension name (for example, "D1@Base-Extrude") for this method. However, the full dimension name is not needed if you use [IFeature::IParameter](#) or [IFeature::Parameter](#).

Some characters are recognized as special characters. The use of these characters in names or parts or features can cause this method to fail to return a dimension. These special characters are not recognized in names of parts or features:

- at sign ( @ )
- period ( . )
- backslash ( / )

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::IParameter Method](#)  
[IModelDoc2::SetParamValue Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ParentChildRelationship Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ParentChildRelationship Method (IModelDoc2)

Shows the **Parent/Child Relationships** dialog for the selected feature.

## .NET Syntax

Visual Basic (Declaration)

```
Sub ParentChildRelationship()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.ParentChildRelationship()
```

C#

```
void ParentChildRelationship()
```

C++/CLI

```
void ParentChildRelationship();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ParentChildRelationship](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IFeature::GetChildren Method](#)  
[IFeature::IGetChildren Method](#)  
[IFeature::IGetChildCount Method](#)  
[IFeature::IGetParents Method](#)  
[IFeature::GetParents Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Paste Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Paste Method (IModelDoc2)

Pastes the contents of the Microsoft Windows Clipboard at the current insertion point.

## .NET Syntax

Visual Basic (Declaration)

```
Sub Paste()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
instance.Paste()
```

C#

```
void Paste()
```

C++/CLI

```
void Paste();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Paste](#).

## Example

[Copy and Paste Feature \(C#\)](#)  
[Copy and Paste Feature \(VB.NET\)](#)  
[Copy and Paste Feature \(VBA\)](#)  
[Cut and Paste Sketch \(C#\)](#)  
[Cut and Paste Sketch \(VB.NET\)](#)  
[Cut and Paste Sketch \(VBA\)](#)

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::EditCopy Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PostTrimSurface Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PostTrimSurface Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::PostTrimSurface](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Sub PostTrimSurface( _  
    ByVal BSewSurfaceIn As System.Boolean _  
)
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim BSewSurfaceIn As System.Boolean  
  
instance.PostTrimSurface(BSewSurfaceIn)
```

### C#

```
void PostTrimSurface(  
    System.bool BSewSurfaceIn  
)
```

### C++/CLI

```
void PostTrimSurface(  
& System.bool BSewSurfaceIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*BSewSurfaceIn*

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PostTrimSurface](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## PreTrimSurface Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PreTrimSurface Method (IModelDoc2)

Obsolete. Superseded by [IFeatureManager::PreTrimSurface](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Sub PreTrimSurface( _  
    ByVal BMutualTrimIn As System.Boolean _  
)
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim BMutualTrimIn As System.Boolean
```

```
instance.PreTrimSurface(BMutualTrimIn)
```

C#

```
void PreTrimSurface(  
    System.bool BMutualTrimIn  
)
```

C++/CLI

```
void PreTrimSurface(  
&    System.bool BMutualTrimIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*BMutualTrimIn*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PreTrimSurface](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## PrintDirect Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PrintDirect Method (IModelDoc2)

Prints the current document to the default printer.

### .NET Syntax

Visual Basic (Declaration)

```
Sub PrintDirect()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.PrintDirect()
```

C#

```
void PrintDirect()
```

C++/CLI

```
void PrintDirect();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PrintDirect](#).

### Remarks

For this type of document...

Then this is printed...

|                  |             |
|------------------|-------------|
| Drawing          | All sheets  |
| Part or assembly | Active view |

#### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDocExtension::PrintOut Method](#)  
[IModelDocExtension::IPrintOut2 Method](#)  
[IModelDoc2::PrintPreview Method](#)  
[IModelDoc2::Printer Property](#)  
[IModelDoc2::PageSetup Property](#)  
[IModelDoc2::IPageSetup Property](#)

#### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Printer Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Printer Property (IModelDoc2)

Gets or sets the default printer for this document.

#### .NET Syntax

Visual Basic (Declaration)

Property Printer As System.String

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.String
```

```
instance.Printer = value
```

```
value = instance.Printer
```

C#

```
System.string Printer {get; set;}
```

C++/CLI

```
property System.String^ Printer {
    System.String^ get();
    void set ( & System.String^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Name of the printer, which is case-sensitive

#### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Printer](#).

#### Remarks

[IModelDoc2::PrintDirect](#), [IModelDocExtension::PrintOut2](#), and [IModelDocExtension::IPrintOut2](#) use this setting if you pass an empty string to printer.

#### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::ClosePrintPreview Method](#)  
[IModelDoc2::PrintPreview Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PrintOut Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PrintOut Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::PrintOut2](#) and [IModelDocExtension::IPrintOut2](#).

## .NET Syntax

Visual Basic (Declaration)

```
Sub PrintOut( _  
    ByVal FromPage As System.Integer, _  
    ByVal ToPage As System.Integer, _  
    ByVal NumCopies As System.Integer, _  
    ByVal Collate As System.Boolean, _  
    ByVal Printer As System.String, _  
    ByVal Scale As System.Double, _  
    ByVal PrintToFile As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FromPage As System.Integer  
Dim ToPage As System.Integer  
Dim NumCopies As System.Integer  
Dim Collate As System.Boolean  
Dim Printer As System.String  
Dim Scale As System.Double  
Dim PrintToFile As System.Boolean
```

```
instance.PrintOut(FromPage, ToPage, NumCopies, Collate, Printer, Scale, PrintToFile)
```

C#

```
void PrintOut(  
    System.int FromPage,  
    System.int ToPage,  
    System.int NumCopies,  
    System.bool Collate,  
    System.string Printer,  
    System.double Scale,  
    System.bool PrintToFile  
)
```

C++/CLI

```
void PrintOut(  
& System.int FromPage,  
& System.int ToPage,  
& System.int NumCopies,  
& System.bool Collate,  
& System.String^ Printer,  
& System.double Scale,  
& System.bool PrintToFile  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*FromPage*

*ToPage*

*NumCopies*

*Collate*

*Printer*

*Scale*

*PrintToFile*

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PrintOut](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## PrintOut2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PrintOut2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::PrintOut2](#) and [IModelDocExtension::IPrintOut2](#).

## .NET Syntax

Visual Basic (Declaration)

```
Sub PrintOut2( _  
    ByVal FromPage As System.Integer, _  
    ByVal ToPage As System.Integer, _  
    ByVal NumCopies As System.Integer, _  
    ByVal Collate As System.Boolean, _  
    ByVal Printer As System.String, _  
    ByVal Scale As System.Double, _  
    ByVal PrintToFile As System.Boolean, _  
    ByVal Pt fName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FromPage As System.Integer  
Dim ToPage As System.Integer  
Dim NumCopies As System.Integer  
Dim Collate As System.Boolean  
Dim Printer As System.String  
Dim Scale As System.Double  
Dim PrintToFile As System.Boolean  
Dim Pt fName As System.String
```

```
instance.PrintOut2(FromPage, ToPage, NumCopies, Collate, Printer, Scale, PrintToFile, Pt fName)
```

C#

```
void PrintOut2(  
    System.int FromPage,  
    System.int ToPage,  
    System.int NumCopies,  
    System.bool Collate,  
    System.string Printer,  
    System.double Scale,  
    System.bool PrintToFile,  
    System.string Pt fName  
)
```

```

void PrintOut2(
& System.int FromPage,
& System.int ToPage,
& System.int NumCopies,
& System.bool Collate,
& System.String^ Printer,
& System.double Scale,
& System.bool PrintToFile,
& System.String^ Pt fName
)

```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*FromPage*

*ToPage*

*NumCopies*

*Collate*

*Printer*

*Scale*

*PrintToFile*

*Pt fName*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PrintOut2](#).

### See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PrintPreview Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PrintPreview Method (IModelDoc2)

Displays the Print Preview page for the current document.

### .NET Syntax

Visual Basic (Declaration)

```
Sub PrintPreview()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
```

```
instance.PrintPreview()
```

C#

```
void PrintPreview()
```

C++/CLI

```
void PrintPreview();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax



See [ModelDoc2::PrintPreview](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDocExtension::PrintOut2 Method](#)  
[IModelDocExtension::IPrintOut2 Method](#)  
[IModelDoc2::Printer Property](#)  
[IModelDoc2::PageSetup Property](#)  
[IModelDoc2::IPageSetup Property](#)  
[IModelDoc2::PrintDirect Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## PrintSetup Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PrintSetup Property (IModelDoc2)

Obsolete. See [IModelDoc2::SetUserPreferenceDoubleValue](#), [IModelDoc2::SetUserPreferenceIntegerValue](#), and [IModelDoc2::SetUserPreferenceToggle](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Property PrintSetup(  
    ByVal SetupType As System.Integer _  
) As System.Short
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim SetupType As System.Integer  
Dim value As System.Short  
  
instance.PrintSetup(SetupType) = value  
  
value = instance.PrintSetup(SetupType)
```

### C#

```
System.short PrintSetup(  
    System.int SetupType  
) {get; set;}
```

### C++/CLI

```
property System.short PrintSetup {  
    System.short get(System.int SetupType);  
    void set (System.int SetupType, System.short value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*SetupType*

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PrintSetup](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

# PropertySheet Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : PropertySheet Method (IModelDoc2)

Displays the the selected object's property sheet.

## .NET Syntax

Visual Basic (Declaration)

```
Sub PropertySheet()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.PropertySheet()
```

C#

```
void PropertySheet()
```

C++/CLI

```
void PropertySheet();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::PropertySheet](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[ISWPropertySheet Interface](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

# Quit Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Quit Method (IModelDoc2)

Closes the active document without saving changes (see **Remarks**).

## .NET Syntax

Visual Basic (Declaration)

```
Sub Quit()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.Quit()
```

C#

```
void Quit()
```

C++/CLI

```
void Quit();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Quit](#).

## Remarks

This method is not available. Use [ISldWorks::QuitDoc](#) instead.

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RayIntersections Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : RayIntersections Method (IModelDoc2)

**Obsolete.** Superseded by [IModelDocExtension::RayIntersections](#).

## .NET Syntax

Visual Basic (Declaration)

```
Function RayIntersections( _  
    ByVal BodiesIn As System.Object, _  
    ByVal BasePointsIn As System.Object, _  
    ByVal VectorsIn As System.Object, _  
    ByVal Options As System.Integer, _  
    ByVal HitRadius As System.Double, _  
    ByVal Offset As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim BodiesIn As System.Object  
Dim BasePointsIn As System.Object  
Dim VectorsIn As System.Object  
Dim Options As System.Integer  
Dim HitRadius As System.Double  
Dim Offset As System.Double  
Dim value As System.Integer
```

```
value = instance.RayIntersections(BodiesIn, BasePointsIn, VectorsIn, Options, HitRadius, Offset)
```

C#

```
System.int RayIntersections(  
    System.object BodiesIn,  
    System.object BasePointsIn,  
    System.object VectorsIn,  
    System.int Options,  
    System.double HitRadius,  
    System.double Offset  
)
```

```
System.int RayIntersections(
& System.Object^ BodiesIn,
& System.Object^ BasePointsIn,
& System.Object^ VectorsIn,
& System.int Options,
& System.double HitRadius,
& System.double Offset
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*BodiesIn*

Array of [bodies](#) that are hit by the rays (see **Remarks**)

*BasePointsIn*

Array of doubles containing the x,y,z base points of each ray

*VectorsIn*

Array of doubles containing the direction vectors of each ray

*Options*

Number of options as defined in [swRayPtsOpts\\_e](#)

*HitRadius*

Radius of hit cylinder; this is used mainly in grazing cases to establish a hit

*Offset*

Length tolerance to use to establish whether a hit on a face represents the entry or exit of the ray from the body (see **Remarks**)

#### Return Value

Number of intersections found

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::RayIntersections](#).

### Remarks

The method performs the intersection operations between the specified bodies and the ray vectors. To get the results (a set of intersection point: intersection normals, and the bodies that were hit from your bodiesIn array) of the intersection operations, you must call [IModelDoc2::GetRayIntersectionsPoints](#) or [IModelDoc2::IGetRayIntersectionPoints](#) and [IModelDoc2::GetRayIntersectionTopology](#) or [IModelDoc2::IGetRayIntersectionsTopology](#).

Information returned by [IModelDoc2::GetRayIntersectionsPoints](#), [IModelDoc2::IGetRayIntersectionPoints](#), [IModelDoc2::GetRayIntersectionTopology](#), and [IModelDoc2::IGetRayIntersectionsTopology](#) depends partially on the value of the options argument. Valid values can be concatenated together using bitwise operations. See [IModelDoc2::GetRayIntersectionsPoints](#) or [IModelDoc2::IGetRayIntersectionPoints](#) to see which data is always output regardless of the values specified in the options argument.

For each ray that hits an edge or a vertex, the offset distance is added in both the positive and negative directions along the ray and the points computed are tested for spatial inclusion in the hit body. This determines if the ray was entering, leaving, or just grazing the body at the hit point. Entry and exit onto faces can be computed does not require such an offset.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::GetRayIntersectionsPoints Method](#)  
[IModelDoc2::GetRayIntersectionsTopology Method](#)  
[IModelDoc2::IGetRayIntersectionsPoints Method](#)  
[IModelDoc2::IGetRayIntersectionsTopology Method](#)  
[IModelDoc2::IMultiSelectByRay Method](#)  
[IModelDoc2::IRayIntersections Method](#)  
[IModelDoc2::ISelectByRay Method](#)  
[IModelDoc2::MultiSelectByRay Method](#)  
[IModelDoc2::SelectByRay Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Reattaches an ordinate dimension to a different entity.

## .NET Syntax

Visual Basic (Declaration)

```
Function ReattachOrdinate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.Boolean

value = instance.ReattachOrdinate()
```

C#

```
System.bool ReattachOrdinate()
```

C++/CLI

```
System.bool ReattachOrdinate();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

True if the re-attachment is successful, false if not

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ReattachOrdinate](#).

## Remarks

To use this method, you must first select the dimension to reattach and then call to [IModelDocExtension::SelectByID2](#) must be made that selects the new entity to which this dimension will be attached.

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDocExtension::AddOrdinateDimension Method](#)  
[IModelDoc2::EditOrdinate Method](#)  
[IModelDoc2::AlignOrdinate Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Rebuild Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Rebuild Method (IModelDoc2)

**Obsolete.** Superseded by [IModelDocExtension::Rebuild](#).

## .NET Syntax

Visual Basic (Declaration)

```
Sub Rebuild( _
    ByVal Options As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim Options As System.Integer

instance.Rebuild(Options)
```

C#

```
void Rebuild(
    System.int Options
)
```

C++/CLI

```
void Rebuild(
    & System.int Options
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Options*

Type of rebuild as defined in [swRebuildOptions\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Rebuild](#).

### Remarks

Use [IModelDoc2::GetType](#) to check the type of document.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::EditRebuild3 Method](#)  
[IModelDoc2::ForceRebuild3 Method](#)  
[IModelDocExtension::NeedsRebuild2 Property](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ReloadOrReplace Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ReloadOrReplace Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::ReloadOrReplace](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function ReloadOrReplace( _
    ByVal ReadOnly As System.Boolean, _
    ByVal ReplaceFileName As System.String, _
    ByVal DiscardChanges As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim ReadOnly As System.Boolean
Dim ReplaceFileName As System.String
Dim DiscardChanges As System.Boolean
Dim value As System.Integer
```



```
value = instance.ReloadOrReplace(ReadOnly, ReplaceFileName, DiscardChanges)
```

C#

```
System.int ReloadOrReplace(  
    System.bool ReadOnly,  
    System.string ReplaceFileName,  
    System.bool DiscardChanges  
)
```

C++/CLI

```
System.int ReloadOrReplace(  
& System.bool ReadOnly,  
& System.String^ ReplaceFileName,  
& System.bool DiscardChanges  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ReadOnly*

True to set the model document read-only after reload or replace, false to allow write access

*ReplaceFileName*

Replacement model document; null or Nothing to reload the current model document

*DiscardChanges*

True to discard changes made to the current model document, false to abort operation if the model document was changed (see **Remarks**)

#### Return Value

Error codes as defined by [swComponentReloadError\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ReloadOrReplace](#).

### Remarks

The model to reload or replace must be open in its own window frame.

This method does not reload or replace the model if the top assembly has been opened invisibly. In that case, make the model visible by calling [IModelDoc2::Visible](#) before calling this method.

You must call [IModelDoc2::ReloadOrReplace](#) after calling [IModelDoc2::ForceReleaseLocks](#), which detaches a file from the file system, to re-attach a detached file to the file system. If you do not call [IModelDoc2::ReloadOrReplace](#) after calling [IModelDoc2::ForceReleaseLocks](#), then you will experience problems with OLE objects (e.g., design tables). Any changes made to a file while it is detached are not preserved unless you save the file to disk before calling [IModelDoc2::ReloadOrReplace](#). Additionally if you set [IModelDoc2::ReloadOrReplace](#)'s [DiscardChanges](#) parameter to false and you made changes to a detached file that you are attempting to re-attach to the file system, then [IModelDoc2::ReloadOrReplace](#) will fail. [DiscardChanges](#) must be set to true to re-attach a detached file.

See [ISldWorks::CloseAndReopen](#) to perform a similar function with drawing documents.

### See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IAssemblyDoc::ReplaceComponents Method](#)

[IAssemblyDoc::ComponentReload2 Method \(\)](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RemoveGroups Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : RemoveGroups Method (IModelDoc2)

Removes any annotation groups in the current selection.

## .NET Syntax

Visual Basic (Declaration)

```
Sub RemoveGroups()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.RemoveGroups()
```

C#

```
void RemoveGroups()
```

C++/CLI

```
void RemoveGroups();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::RemoveGroups](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::CreateGroup Method](#)  
[IModelDoc2::RemoveItemsFromGroup Method](#)  
[IAnnotation Interface](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## RemoveInspectCurvature Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : RemoveInspectCurvature Method (IModelDoc2)

Removes curvature combs from the selected curved sketch segment.

## .NET Syntax

Visual Basic (Declaration)

```
Sub RemoveInspectCurvature()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.RemoveInspectCurvature()
```

C#

```
void RemoveInspectCurvature()
```

C++/CLI

```
void RemoveInspectCurvature();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::RemoveInspectCurvature](#).

## Example

[Add or Remove Curvature Combs \(VBA\)](#)

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::InspectCurvature Method](#)  
[ISketchSpline::ShowCurvatureCombs Property](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## RemoveItemsFromGroup Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : RemoveItemsFromGroup Method (IModelDoc2)

Removes the selected annotations from their annotation groups.

## .NET Syntax

Visual Basic (Declaration)

```
Sub RemoveItemsFromGroup()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.RemoveItemsFromGroup()
```

C#

```
void RemoveItemsFromGroup()
```

C++/CLI

```
void RemoveItemsFromGroup();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::RemoveItemsFromGroup](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::CreateGroup Method](#)  
[IModelDoc2::RemoveGroups Method](#)  
[IAnnotation Interface](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ResetBlockingState Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ResetBlockingState Method (IModelDoc2)

Resets the blocking state for the SOLIDWORKS menus.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub ResetBlockingState()
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.ResetBlockingState()
```

### C#

```
void ResetBlockingState()
```

### C++/CLI

```
void ResetBlockingState();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ResetBlockingState](#).

## Example

[Set Blocking State \(VBA\)](#)

## Remarks

Call this method after calling [IModelDoc2::SetBlockingState](#) to set the SOLIDWORKS menus back to their previous state.

**NOTE:** You must call this method every time you call [IModelDoc2::SetBlockingState](#). It is not enough to call this method once at the end of a sequence of operations that have called [IModelDoc2::SetBlockingState](#) several times.

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ResetLightSourceExtProperty Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ResetLightSourceExtProperty Method (IModelDoc2)

Resets the properties for a light source.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub ResetLightSourceExtProperty( _  
    ByVal ID As System.Integer _  
)
```

### Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim ID As System.Integer  
  
instance.ResetLightSourceExtProperty(ID)
```

C#

```
void ResetLightSourceExtProperty(  
    System.int ID  
)
```

C++/CLI

```
void ResetLightSourceExtProperty(  
    & System.int ID  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ID*  
ID of the light source

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ResetLightSourceExtProperty](#).

### Remarks

Values for *Id* can range from 0 to *n*, where *n* = (the total number of light sources - 1). To get the total number of light sources, see [IModelDoc2::GetLightSourceCount](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::GetLightSourceExtProperty Method](#)  
[IModelDoc2::GetLightSourceIdFromName Method](#)  
[IModelDoc2::GetLightSourceName Method](#)  
[IModelDoc2::AddLightSource Method](#)  
[IModelDoc2::AddLightSourceExtProperty Method](#)  
[IModelDoc2::DeleteLightSource Method](#)  
[IModelDoc2::SetLightSourceName Method](#)  
[IModelDoc2::SetLightSourcePropertyValuesVB Method](#)  
[IModelDoc2::LightSourcePropertyValues Property](#)  
[IModelDoc2::LightSourceUserName Property](#)  
[IModelDoc2::ILightSourcePropertyValues Property](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ResetPropertyExtension Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ResetPropertyExtension Method (IModelDoc2)

Clears all values stored in the property extension.

### .NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
  
instance.ResetPropertyExtension()
```

C#

```
void ResetPropertyExtension()
```

C++/CLI

```
void ResetPropertyExtension();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ResetPropertyExtension](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::AddPropertyExtension Method](#)  
[IModelDoc2::GetPropertyExtension Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ResetSceneExtProperty Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ResetSceneExtProperty Method (IModelDoc2)

Resets the extension property for a scene.

### .NET Syntax

Visual Basic (Declaration)

```
Sub ResetSceneExtProperty()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.ResetSceneExtProperty()
```

C#

```
void ResetSceneExtProperty()
```

C++/CLI

```
void ResetSceneExtProperty();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ResetSceneExtProperty](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

[IModelDoc2::AddSceneExtProperty Method](#)  
[IModelDoc2::GetSceneExtProperty Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Save Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Save Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::Save3](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Sub Save()
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2  
  
instance.Save()
```

### C#

```
void Save()
```

### C++/CLI

```
void Save();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Save](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Save2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Save2 Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::Save3](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Function Save2( _  
    ByVal Silent As System.Boolean _  
) As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim Silent As System.Boolean
Dim value As System.Integer

value = instance.Save2(Silent)
```

C#

```
System.int Save2(
    System.bool Silent
)
```

C++/CLI

```
System.int Save2(
    & System.bool Silent
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Silent*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Save2](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Save3 Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Save3 Method (IModelDoc2)

Saves the current document.

### .NET Syntax

Visual Basic (Declaration)

```
Function Save3( _
    ByVal Options As System.Integer, _
    ByRef Errors As System.Integer, _
    ByRef Warnings As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim Options As System.Integer
Dim Errors As System.Integer
Dim Warnings As System.Integer
Dim value As System.Boolean
```

```
value = instance.Save3(Options, Errors, Warnings)
```

C#

```
System.bool Save3(
    System.int Options,
    out System.int Errors,
    out System.int Warnings
)
```

```
System.bool Save3(
& System.int Options,
& [Out] System.int Errors,
& [Out] System.int Warnings
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

##### *Options*

Mode in which to save the document as defined in [swSaveAsOptions\\_e](#)

##### *Errors*

Errors that caused the save operation to fail as defined in [swFileSaveError\\_e](#)

##### *Warnings*

Warnings or extra information generated during the save operation as defined in [swFileSaveWarning\\_e](#)

#### Return Value

True if the save was successful, false if not

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Save3](#).

### Example

[Save File \(VBA\)](#)  
[Save File \(VB.NET\)](#)  
[Save File \(C#\)](#)  
[Rename Component and Update References \(C#\)](#)  
[Rename Component and Update References \(VB.NET\)](#)  
[Rename Component and Update References \(VBA\)](#)

### Remarks

| If saving the file... | Then...                                                                                                                                                                                |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Succeeds              | <ul style="list-style-type: none"> <li>Return value is true</li> <li>Errors argument is 0</li> </ul>                                                                                   |
| Fails                 | <ul style="list-style-type: none"> <li>Return value is false</li> <li>Errors argument contains a bitwise OR of the error codes that were generated when saving the document</li> </ul> |

You can find the masks to check against in the [swFileSaveError\\_e](#) enumeration.

Even if the file is saved successfully, there might be warnings or information that occur during the save that might interest you. The Warnings argument contains a bitwise OR of the warning codes that were generated when saving the document. You can find the masks to check against in the [swFileSaveWarning\\_e](#) enumeration.

| If you do not want SOLIDWORKS to return... | Then pass in null or Nothing for... |
|--------------------------------------------|-------------------------------------|
| Error information                          | Errors argument                     |
| Warning information                        | Warnings argument                   |

This method results in FileSaveNotify being sent to any application listening.

See [IModelDocExtension::SaveAs](#) if this is new document, this document is to be saved to a file with a new name, or this document is to be saved to a version of a particular format.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[ISldWorks::QuitDoc Method](#)

### Availability

## SaveAs Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveAs Method (IModelDoc2)**Obsolete.** Superseded by [IModelDocExtension::SaveAs](#).

### .NET Syntax

#### Visual Basic (Declaration)

```
Function SaveAs( _
    ByVal NewName As System.String _
) As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim NewName As System.String
Dim value As System.Boolean

value = instance.SaveAs(NewName)
```

#### C#

```
System.bool SaveAs(
    System.string NewName
)
```

#### C++/CLI

```
System.bool SaveAs(
    & System.String^ NewName
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NewName*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveAs](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

## SaveAs2 Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveAs2 Method (IModelDoc2)**Obsolete.** Superseded by [IModelDocExtension::SaveAs](#).

### .NET Syntax

#### Visual Basic (Declaration)

```
Function SaveAs2( _
    ByVal NewName As System.String, _
    ByVal SaveAsVersion As System.Integer, _
    ByVal SaveAsCopy As System.Boolean, _
```

```
ByVal Silent As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim NewName As System.String  
Dim SaveAsVersion As System.Integer  
Dim SaveAsCopy As System.Boolean  
Dim Silent As System.Boolean  
Dim value As System.Integer  
  
value = instance.SaveAs2(NewName, SaveAsVersion, SaveAsCopy, Silent)
```

C#

```
System.int SaveAs2(  
    System.string NewName,  
    System.int SaveAsVersion,  
    System.bool SaveAsCopy,  
    System.bool Silent  
)
```

C++/CLI

```
System.int SaveAs2(  
& System.String^ NewName,  
& System.int SaveAsVersion,  
& System.bool SaveAsCopy,  
& System.bool Silent  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NewName*

*SaveAsVersion*

*SaveAsCopy*

*Silent*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveAs2](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SaveAs3 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveAs3 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SaveAs](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function SaveAs3( _  
    ByVal NewName As System.String, _  
    ByVal SaveAsVersion As System.Integer, _  
    ByVal Options As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim NewName As System.String  
Dim SaveAsVersion As System.Integer  
Dim Options As System.Integer  
Dim value As System.Integer  
  
value = instance.SaveAs3(NewName, SaveAsVersion, Options)
```

C#

```
System.int SaveAs3(  
    System.string NewName,  
    System.int SaveAsVersion,  
    System.int Options  
)
```

C++/CLI

```
System.int SaveAs3(  
& System.String^ NewName,  
& System.int SaveAsVersion,  
& System.int Options  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NewName*

*SaveAsVersion*

*Options*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveAs3](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SaveAs4 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveAs4 Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SaveAs](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function SaveAs4(  
    ByVal Name As System.String, _  
    ByVal Version As System.Integer, _  
    ByVal Options As System.Integer, _  
    ByRef Errors As System.Integer, _  
    ByRef Warnings As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim Version As System.Integer
```

```
Dim Options As System.Integer
Dim Errors As System.Integer
Dim Warnings As System.Integer
Dim value As System.Boolean

value = instance.SaveAs4(Name, Version, Options, Errors, Warnings)
```

C#

```
System.bool SaveAs4(
    System.string Name,
    System.int Version,
    System.int Options,
    out System.int Errors,
    out System.int Warnings
)
```

C++/CLI

```
System.bool SaveAs4(
    & System.String^ Name,
    & System.int Version,
    & System.int Options,
    & [Out] System.int Errors,
    & [Out] System.int Warnings
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Name*

*Version*

*Options*

*Errors*

*Warnings*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveAs4](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SaveAsSilent Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveAsSilent Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SaveAs](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function SaveAsSilent( _
    ByVal NewName As System.String, _
    ByVal SaveAsCopy As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim NewName As System.String
Dim SaveAsCopy As System.Boolean
```



```
Dim value As System.Integer

value = instance.SaveAsSilent(NewName, SaveAsCopy)
```

C#

```
System.int SaveAsSilent(
    System.string NewName,
    System.bool SaveAsCopy
)
```

C++/CLI

```
System.int SaveAsSilent(
    & System.String^ NewName,
    & System.bool SaveAsCopy
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NewName*

*SaveAsCopy*

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveAsSilent](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SaveBMP Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveBMP Method (IModelDoc2)

Saves the current view as a bitmap (BMP) file.

### .NET Syntax

Visual Basic (Declaration)

```
Function SaveBMP( _
    ByVal FileNameIn As System.String, _
    ByVal WidthIn As System.Integer, _
    ByVal HeightIn As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim FileNameIn As System.String
Dim WidthIn As System.Integer
Dim HeightIn As System.Integer
Dim value As System.Boolean
```

```
value = instance.SaveBMP(FileNameIn, WidthIn, HeightIn)
```

C#

```
System.bool SaveBMP(
    System.string FileNameIn,
    System.int WidthIn,
    System.int HeightIn
)
```

```
System.bool SaveBMP(
& System.String^ FileNameIn,
& System.int WidthIn,
& System.int HeightIn
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*FileNameIn*

Path and file name of the new BMP file

*WidthIn*

Width of the BMP

*HeightIn*

Height of the BMP

#### Return Value

True if file is created successfully, false if not

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveBMP](#).

### Example

[Save Model as Bitmap \(C#\)](#)  
[Save Model as Bitmap \(VB.NET\)](#)  
[Save Model as Bitmap \(VBA\)](#)

### Remarks

Include the full path to the file in `FilenameIn` and use filename extension of `.bmp`.

If `WidthIn` or the `HeightIn` is less than or equal to 0, then the view size is based on the current window size.

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[ISldWorks::GetPreviewBitmapFile Method](#)  
[ISldWorks::GetPreviewBitmap Method](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SaveSilent Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SaveSilent Method (IModelDoc2)

Obsolete. Superseded by [IModelDoc2::Save3](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function SaveSilent() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim value As System.Integer

value = instance.SaveSilent()
```



Copy Code

C#

```
System.int SaveSilent()
```

C++/CLI

```
System.int SaveSilent();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SaveSilent](#).

#### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Scale Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Scale Method (IModelDoc2)

Scales the part.

#### .NET Syntax

Visual Basic (Declaration)

```
Sub Scale()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.Scale()
```

C#

```
void Scale()
```

C++/CLI

```
void Scale();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Scale](#).

#### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)

#### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SceneBkgImageFileName Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SceneBkgImageFileName Property (IModelDoc2)

Controls the image filename used as the current background picture.

## .NET Syntax

Visual Basic (Declaration)

```
Property SceneBkgImageFileName As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.String  
  
instance.SceneBkgImageFileName = value  
value = instance.SceneBkgImageFileName
```

C#

```
System.string SceneBkgImageFileName {get; set;}
```

C++/CLI

```
property System.String^ SceneBkgImageFileName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Name of the image file

## Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SceneBkgImageFileName](#).

## See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::DeleteBkgImage Method](#)  
[IModelDoc2::InsertBkgImage Method](#)  
[IModelDoc2::GetSceneBkgDIB Method](#)  
[IModelDocExtension::GetSceneBkgDIBx64 Method](#)  
[IModelDocExtension::SetSceneBkgDIBx64 Method](#)  
[IModelDoc2::SetSceneBkgDIB Method](#)

## Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SceneName Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SceneName Property (IModelDoc2)

Gets and sets the name of the scene.

## .NET Syntax

Visual Basic (Declaration)

```
Property SceneName As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.String  
  
instance.SceneName = value
```

```
value = instance.SceneName
```

C#

```
System.string SceneName {get; set;}
```

C++/CLI

```
property System.String^ SceneName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Name of the scene

### Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SceneName](#).

### See Also

[IModelDoc2 Interface](#)  
[IModelDoc2 Members](#)  
[IModelDoc2::SceneUserName Property](#)

### Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0