

SOLIDWORKS API (.NET VBA C#) — Reference

(191/337): IModelDoc2 (part 14 of 17)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc2 (part 14 of 17) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SceneUserName Property (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SceneUserName Property (IModelDoc2)

Gets and sets the user name of the scene.

.NET Syntax

Visual Basic (Declaration)

```
Property SceneUserName As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim value As System.String

instance.SceneUserName = value
value = instance.SceneUserName
```

C#

```
System.string SceneUserName {get; set;}
```

C++/CLI

```
property System.String^ SceneUserName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

User name of the scene

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SceneUserName](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SceneName Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ScreenRotate Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : ScreenRotate Method (IModelDoc2)

Switches between model and screen center rotation.

.NET Syntax

Visual Basic (Declaration)

```
Sub ScreenRotate()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.ScreenRotate()
```

C#

```
void ScreenRotate()
```

C++/CLI

```
void ScreenRotate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::ScreenRotate](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IModelView::RotateAboutCenter Method](#)

[IModelView::RotateAboutPoint Method](#)

[IModelView::RotateAboutAxis Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : Select Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Select( _  
    ByVal SelID As System.String, _  
    ByVal SelParams As System.String, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
Dim SelID As System.String
```

```
Dim SelParams As System.String
```

```
Dim X As System.Double
```

```
Dim Y As System.Double
```

```
Dim Z As System.Double
```

```
instance.Select(SelID, SelParams, X, Y, Z)
```

C#

```
void Select(
    System.string SelID,
    System.string SelParams,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
void Select(
    & System.String^ SelID,
    & System.String^ SelParams,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::Select](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectAt Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectAt Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectAt( _
    ByVal Flags As System.Integer, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2
Dim Flags As System.Integer
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double

instance.SelectAt(Flags, X, Y, Z)
```

C#



```
void SelectAt(  
    System.int Flags,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void SelectAt(  
& System.int Flags,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flags

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectAt](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectByID Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectByID Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByID(  
    ByVal SelID As System.String, _  
    ByVal SelParams As System.String, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim SelID As System.String  
Dim SelParams As System.String  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.SelectByID(SelID, SelParams, X, Y, Z)
```

C#

```
System.bool SelectByID(
    System.string SelID,
    System.string SelParams,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.bool SelectByID(
    & System.String^ SelID,
    & System.String^ SelParams,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectByID](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectByMark Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectByMark Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByMark( _
    ByVal SelID As System.String, _
    ByVal SelParams As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal Mark As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim SelID As System.String
Dim SelParams As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim Mark As System.Integer
```

```
Dim value As System.Boolean
```

```
value = instance.SelectByMark(SelID, SelParams, X, Y, Z, Mark)
```

C#

```
System.bool SelectByMark(  
    System.string SelID,  
    System.string SelParams,  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.int Mark  
)
```

C++/CLI

```
System.bool SelectByMark(  
& System.String^ SelID,  
& System.String^ SelParams,  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelID

SelParams

X

Y

Z

Mark

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectByMark](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectByName Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectByName Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectByName( _  
    ByVal Flags As System.Integer, _  
    ByVal IdStr As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Flags As System.Integer  
Dim IdStr As System.String
```

```
instance.SelectByName(Flags, IdStr)
```

C#

```
void SelectByName(  
    System.int Flags,  
    System.string IdStr  
)
```

C++/CLI

```
void SelectByName(  
& System.int Flags,  
& System.String^ IdStr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flags

IdStr

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectByName](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectByRay Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectByRay Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByRay](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByRay( _  
    ByVal DoubleInfoIn As System.Object, _  
    ByVal TypeWanted As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim DoubleInfoIn As System.Object  
Dim TypeWanted As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SelectByRay(DoubleInfoIn, TypeWanted)
```

C#

```
System.bool SelectByRay(  
    System.object DoubleInfoIn,  
    System.int TypeWanted  
)
```

C++/CLI

```
System.bool SelectByRay(  
& System.Object^ DoubleInfoIn,  
& System.int TypeWanted  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DoubleInfoIn

Array of 7 doubles: 3 for the start point of the ray, 3 for the direction of the ray, and 1 for the radius

TypeWanted

Type of objects to select as defined in [swSelectType_e](#)

Return Value

True if a selection is made, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectByRay](#).

Remarks

This method:

- Defines a cylindrical region of infinite length that begins at pointIn, runs parallel to VectorIn, and has a radius of RadiusIn. If you specify edge or vertex entities, then the first edge or vertex found within the selection cylinder is selected.
- Only selects entity objects, which include faces, edges, vertices, and so on. You cannot select sketch objects using this method.
- Does not support the selection of silhouette edges.

Only a single entity is selected within the distance radius regardless of multiple entities existing within that radius. For selecting face entities, RadiusIn is ignored and a cylinder of infinitely small radius is used.

Use model space view to determine the selection vector in a drawing.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetRayIntersectionsPoints Method](#)
[IModelDoc2::GetRayIntersectionsTopology Method](#)
[IModelDoc2::IGetRayIntersectionsPoints Method](#)
[IModelDoc2::IGetRayIntersectionsTopology Method](#)
[IModelDoc2::IMultiSelectByRay Method](#)
[IModelDoc2::IRayIntersections Method](#)
[IModelDoc2::ISelectByRay Method](#)
[IModelDoc2::MultiSelectByRay Method](#)
[IModelDoc2::RayIntersections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectedEdgeProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectedEdgeProperties Method (IModelDoc2)

Sets the property values of the selected edge.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectedEdgeProperties( _  
    ByVal EdgeName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim EdgeName As System.String
Dim value As System.Boolean

value = instance.SelectedEdgeProperties(EdgeName)
```

C#

```
System.bool SelectedEdgeProperties(
    System.string EdgeName
)
```

C++/CLI

```
System.bool SelectedEdgeProperties(
    & System.String^ EdgeName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeName

Name of the edge

Return Value

True if edge properties successfully changed, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectedEdgeProperties](#).

Remarks

If the edge...	Then this method...
Does not have a name	Sets the name.
Has a name	Does not change the name and returns false. This behavior is intended to prevent a program from renaming an edge that is referenced in some other location. For example, if an assembly contains a mate to an edge on a part, then a name is automatically assigned to that edge. If you change that name, then there is no guarantee that the mate remains valid. Therefore, when using entity names, you should first check to see if the entity is already named, and if so, use the existing name. If no name exists for the edge, then you can give the edge a name.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SelectedFaceProperties Method](#)
[IModelDoc2::SelectedFeatureProperties Method](#)
[IEdge Interface](#)
[IModelDoc2::EntityProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectedFaceProperties Method (IModelDoc2)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectedFaceProperties Method (IModelDoc2)

Sets the material property values of the selected face.

Visual Basic (Declaration)

```
Function SelectedFaceProperties( _
    ByVal RgbColor As System.Integer, _
    ByVal Ambient As System.Double, _
    ByVal Diffuse As System.Double, _
    ByVal Specular As System.Double, _
    ByVal Shininess As System.Double, _
    ByVal Transparency As System.Double, _
    ByVal Emission As System.Double, _
    ByVal UsePartProps As System.Boolean, _
    ByVal FaceName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim RgbColor As System.Integer
Dim Ambient As System.Double
Dim Diffuse As System.Double
Dim Specular As System.Double
Dim Shininess As System.Double
Dim Transparency As System.Double
Dim Emission As System.Double
Dim UsePartProps As System.Boolean
Dim FaceName As System.String
Dim value As System.Boolean

value = instance.SelectedFaceProperties(RgbColor, Ambient, Diffuse, Specular, Shininess,
Transparency, Emission, UsePartProps, FaceName)
```

C#

```
System.bool SelectedFaceProperties(
    System.int RgbColor,
    System.double Ambient,
    System.double Diffuse,
    System.double Specular,
    System.double Shininess,
    System.double Transparency,
    System.double Emission,
    System.bool UsePartProps,
    System.string FaceName
)
```

C++/CLI

```
System.bool SelectedFaceProperties(
    & System.int RgbColor,
    & System.double Ambient,
    & System.double Diffuse,
    & System.double Specular,
    & System.double Shininess,
    & System.double Transparency,
    & System.double Emission,
    & System.bool UsePartProps,
    & System.String^ FaceName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RgbColor

Face color (see **Remarks**)

Ambient

0.0 <= Face ambient light value <= 1.0

Diffuse

0.0 < Face diffuse value <= 1.0

Specular

0.0 < Face specular value <= 1.0

Shininess

0.0 < Face shininess value <= 1.0

Transparency

0.0 <= Face transparency value <= 1.0

Emission

0.0 <= Face emission value <= 1.0

UsePartProps

True if the face inherits the Part properties, false if not

FaceName

Name of the face

Return Value

True if face properties successfully changed, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectedFaceProperties](#).

Example

[Change Color of Face \(VBA\)](#)

Remarks

To see a color change, you must:

1. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
2. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
3. Refresh the graphics area after calling this method.

You can use the *FaceName* argument to set the name for this face.

If the face has a name, then this method does not change the name and returns false. This behavior is intended to prevent a program from renaming a face that is referenced in some other location.

For example, if an assembly contains a mate to a face on a part, then a name is automatically assigned to that face. If you change that name, then there is no guarantee that the mate will still be valid. Therefore, when using entity names, you should first check to see if the entity is already named, and, if so, use the existing name. If no name exists for the face, then you can assign the face a name.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::SelectedEdgeProperties Method](#)
[IModelDoc2::SelectedFeatureProperties Method](#)
[IFace2 Interface](#)
[IModelDoc2::EntityProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectedFeatureProperties Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectedFeatureProperties Method (IModelDoc2)

Sets the property values of the selected feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectedFeatureProperties( _  
    ByVal RgbColor As System.Integer, _  
    ByVal Ambient As System.Double, _  
    ByVal Diffuse As System.Double, _
```

```

    ByVal Specular As System.Double, _
    ByVal Shininess As System.Double, _
    ByVal Transparency As System.Double, _
    ByVal Emission As System.Double, _
    ByVal UsePartProps As System.Boolean, _
    ByVal Suppressed As System.Boolean, _
    ByVal FeatureName As System.String _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc2
Dim RgbColor As System.Integer
Dim Ambient As System.Double
Dim Diffuse As System.Double
Dim Specular As System.Double
Dim Shininess As System.Double
Dim Transparency As System.Double
Dim Emission As System.Double
Dim UsePartProps As System.Boolean
Dim Suppressed As System.Boolean
Dim FeatureName As System.String
Dim value As System.Boolean

```

```

value = instance.SelectedFeatureProperties(RgbColor, Ambient, Diffuse, Specular, Shininess,
Transparency, Emission, UsePartProps, Suppressed, FeatureName)

```

C#

```

System.bool SelectedFeatureProperties(
    System.int RgbColor,
    System.double Ambient,
    System.double Diffuse,
    System.double Specular,
    System.double Shininess,
    System.double Transparency,
    System.double Emission,
    System.bool UsePartProps,
    System.bool Suppressed,
    System.string FeatureName
)

```

C++/CLI

```

System.bool SelectedFeatureProperties(
    & System.int RgbColor,
    & System.double Ambient,
    & System.double Diffuse,
    & System.double Specular,
    & System.double Shininess,
    & System.double Transparency,
    & System.double Emission,
    & System.bool UsePartProps,
    & System.bool Suppressed,
    & System.String^ FeatureName
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RgbColor

Color of feature (see **Remarks**)

Ambient

0.0 <= Ambient value <= 1.0

Diffuse

0.0 < Diffuse value <= 1.0

Specular

0.0 < Specular value <= 1.0

Shininess

0.0 < Shininess value <= 1.0

Transparency

0.0 <= Transparency value <= 1.0

Emission

0.0 <= Emission value <= 1.0

UsePartProps

True if the feature inherits the properties from the part, false if not
Suppressed
True if the feature is suppressed, false if not
FeatureName
Name of the feature

Return Value

True if feature's properties are successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectedFeatureProperties](#).

Example

[Create Thicken Feature \(VBA\)](#)

Remarks

To see a color change, you must:

1. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
2. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
3. Refresh the graphics area after calling this method.

This method is different from [IModelDoc2::SelectedEdgeProperties](#) and [IModelDoc2::SelectedFaceProperties](#) in that it allows you to change the name of this feature. All features have names; however, a face or edge typically has a name only if it is being referenced. Because it is dangerous to change the name of a referenced object, you cannot programmatically change the names of faces or edges. See [IFeature::Name](#) and [IPartDoc::SetEntityName](#) for additional information.

This method requires that the feature to be selected. To select the feature programmatically, you can use [IModelDocExtension::SelectByID2](#) and pass in the feature name and the appropriate object type (for example, "BODYFEATURE", "ATTRIBUTE", "PLANE", "SKETCH", and so on) and the selection coordinates 0,0,0. To determine the feature name and object type, use the [IFeature::Name](#) and [IFeature::GetTypeName](#) methods, respectively.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IFeature Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionManager Property (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectionManager Property (IModelDoc2)

Gets the [ISelectionMgr](#) object for this document, which makes the currently selected object available.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property SelectionManager As System.Object

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim value As System.Object
```

```
instance.SelectionManager = value
```

```
value = instance.SelectionManager
```

C#

```
System.Object SelectionManager {get; set;}
```

C++/CLI

```
property System.Object^ SelectionManager {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectionManager](#).

Example

[Get Object's Persistent Reference ID \(C++\)](#)
[Create Plane Thru 3 Points In-context \(VBA\)](#)
[Determine If Sketch Suitable for Feature \(VBA\)](#)
[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Create Equation-driven Curve \(C#\)](#)
[Create Equation-driven Curve \(VB.NET\)](#)
[Create Equation-driven Curve \(VBA\)](#)

Remarks

[ISelectionMgr](#) objects are transient because they are invalid as soon as another selection is made. So, do not hold on to these pointers for any length of time.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::ISelectionManager Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectLoop Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectLoop Method (IModelDoc2)

Selects the loop that corresponds to the selected edge.

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectLoop()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.SelectLoop()
```

C#

```
void SelectLoop()
```

C++/CLI

```
void SelectLoop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectLoop](#).

Remarks

This method associates the loop with the selected edge in the [ISelectionMgr](#); it does not add an item to the ISelectionMgr. To find out if the selected edge has an associated loop, use [ISelectionMgr::GetSelectedObjectLoop2](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectMidpoint Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectMidpoint Method (IModelDoc2)

Puts the midpoint (swSelMIDPOINTS) of that edge on the selection list and removes the edge from the selection list when an edge is selected.

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectMidpoint()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.SelectMidpoint()
```

C#

```
void SelectMidpoint()
```

C++/CLI

```
void SelectMidpoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectMidpoint](#).

Example

[Select the Midpoint of an Edge \(VBA\)](#)
[Select the Midpoint of an Edge \(VB.NET\)](#)
[Select the Midpoint of an Edge \(C#\)](#)

Remarks

If the edge whose midpoint is desired is already on the selection list and you use [IModelDocExtension::SelectByID2](#) to select it again, then IModelDoc2::SelectMidpoint leaves both the edge and the point on the selection list.

This method does not support 3D sketches.

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectSketchArc Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectSketchArc Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectSketchArc( _  
    ByVal X0 As System.Double, _  
    ByVal Y0 As System.Double, _  
    ByVal Inc0 As System.Integer, _  
    ByVal X1 As System.Double, _  
    ByVal Y1 As System.Double, _  
    ByVal Inc1 As System.Integer, _  
    ByVal XC As System.Double, _  
    ByVal YC As System.Double, _  
    ByVal IncC As System.Integer, _  
    ByVal RotDir As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim X0 As System.Double  
Dim Y0 As System.Double  
Dim Inc0 As System.Integer  
Dim X1 As System.Double  
Dim Y1 As System.Double  
Dim Inc1 As System.Integer  
Dim XC As System.Double  
Dim YC As System.Double  
Dim IncC As System.Integer  
Dim RotDir As System.Integer  
  
instance.SelectSketchArc(X0, Y0, Inc0, X1, Y1, Inc1, XC, YC, IncC, RotDir)
```

C#

```
void SelectSketchArc(  
    System.double X0,  
    System.double Y0,  
    System.int Inc0,  
    System.double X1,  
    System.double Y1,  
    System.int Inc1,  
    System.double XC,  
    System.double YC,  
    System.int IncC,  
    System.int RotDir  
)
```

C++/CLI

```
void SelectSketchArc(  
& System.double X0,  
& System.double Y0,  
& System.int Inc0,  
& System.double X1,
```

```

& System.double Y1,
& System.int Inc1,
& System.double XC,
& System.double YC,
& System.int IncC,
& System.int RotDir
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X0

Y0

Inc0

X1

Y1

Inc1

XC

YC

IncC

RotDir

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectSketchArc](#).

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectSketchItem Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectSketchItem Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function SelectSketchItem( _
    ByVal SelOpt As System.Integer, _
    ByVal Name As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As IModelDoc2
Dim SelOpt As System.Integer
Dim Name As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean

```

```
value = instance.SelectSketchItem(SelOpt, Name, X, Y, Z)
```

C#



```
System.bool SelectSketchItem(
    System.int SelOpt,
    System.string Name,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.bool SelectSketchItem(
    & System.int SelOpt,
    & System.String^ Name,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelOpt

Name

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectSketchItem](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectSketchLine Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectSketchLine Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectSketchLine( _
    ByVal X0 As System.Double, _
    ByVal Y0 As System.Double, _
    ByVal Inc0 As System.Integer, _
    ByVal X1 As System.Double, _
    ByVal Y1 As System.Double, _
    ByVal Inc1 As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim X0 As System.Double
Dim Y0 As System.Double
Dim Inc0 As System.Integer
Dim X1 As System.Double
Dim Y1 As System.Double
Dim Inc1 As System.Integer
```

```
instance.SelectSketchLine(X0, Y0, Inc0, X1, Y1, Inc1)
```

C#

```
void SelectSketchLine(  
    System.double X0,  
    System.double Y0,  
    System.int Inc0,  
    System.double X1,  
    System.double Y1,  
    System.int Inc1  
)
```

C++/CLI

```
void SelectSketchLine(  
& System.double X0,  
& System.double Y0,  
& System.int Inc0,  
& System.double X1,  
& System.double Y1,  
& System.int Inc1  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X0

Y0

Inc0

X1

Y1

Inc1

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectSketchLine](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectSketchPoint Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectSketchPoint Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectSketchPoint( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Incidence As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim X As System.Double  
Dim Y As System.Double
```



```
Dim Incidence As System.Integer  
  
instance.SelectSketchPoint(X, Y, Incidence)
```

C#

```
void SelectSketchPoint(  
    System.double X,  
    System.double Y,  
    System.int Incidence  
)
```

C++/CLI

```
void SelectSketchPoint(  
& System.double X,  
& System.double Y,  
& System.int Incidence  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Incidence

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectSketchPoint](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectSketchSpline Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectSketchSpline Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectSketchSpline( _  
    ByVal Size As System.Integer, _  
    ByVal X0 As System.Double, _  
    ByVal Y0 As System.Double, _  
    ByVal Inc0 As System.Integer, _  
    ByVal X1 As System.Double, _  
    ByVal Y1 As System.Double, _  
    ByVal Inc1 As System.Integer, _  
    ByVal XC As System.Double, _  
    ByVal YC As System.Double, _  
    ByVal IncC As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As IModelDoc2  
Dim Size As System.Integer  
Dim X0 As System.Double  
Dim Y0 As System.Double  
Dim Inc0 As System.Integer
```



```
Dim X1 As System.Double
Dim Y1 As System.Double
Dim Inc1 As System.Integer
Dim XC As System.Double
Dim YC As System.Double
Dim IncC As System.Integer
```

```
instance.SelectSketchSpline(Size, X0, Y0, Inc0, X1, Y1, Inc1, XC, YC, IncC)
```

C#

```
void SelectSketchSpline(
    System.int Size,
    System.double X0,
    System.double Y0,
    System.int Inc0,
    System.double X1,
    System.double Y1,
    System.int Inc1,
    System.double XC,
    System.double YC,
    System.int IncC
)
```

C++/CLI

```
void SelectSketchSpline(
    & System.int Size,
    & System.double X0,
    & System.double Y0,
    & System.int Inc0,
    & System.double X1,
    & System.double Y1,
    & System.int Inc1,
    & System.double XC,
    & System.double YC,
    & System.int IncC
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size

X0

Y0

Inc0

X1

Y1

Inc1

XC

YC

IncC

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectSketchSpline](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SelectTangency Method (IModelDoc2)

Selects all faces tangent to the selected face.

.NET Syntax

Visual Basic (Declaration)

```
Sub SelectTangency()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
instance.SelectTangency()
```

C#

```
void SelectTangency()
```

C++/CLI

```
void SelectTangency();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SelectTangency](#).

Example

[Get Tangent Faces \(VBA\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IEdge::GetTangentEdges Method](#)
[IEdge::GetTangentEdgesCount Method](#)
[IEdge::IGetTangentEdges Method](#)
[IEdge Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetAddToDB Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetAddToDB Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::AddToDB](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetAddToDB( _  
    ByVal Setting As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Setting As System.Boolean
```

```
instance.SetAddToDB(Setting)
```

C#

```
void SetAddToDB(  
    System.bool Setting  
)
```

C++/CLI

```
void SetAddToDB(  
&    System.bool Setting  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Setting

True to add items directly to the SOLIDWORKS database, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetAddToDB](#).

Example

[Tessellate a Body \(C#\)](#)
[Calculate Closest Distance Between Faces \(VBA\)](#)
[Calculate Closest Distance Between Model Components \(VBA\)](#)
[Create Plane Thru 3 Points In-context \(VBA\)](#)
[Get Intersecting Face and Edge \(VBA\)](#)
[Get Intersecting Faces \(VBA\)](#)

Remarks

One of the benefits of adding sketch entities directly to the database is that you can avoid grid and entity snapping. For example, if you create a sketch line whose endpoint is near another entity or near a grid point, the new line endpoint snaps to the other item or grid point. Setting ModelDoc2::SetAddToDB to True avoids this behavior during sketch entity creation.

IModelDoc2::SetAddToDB and [IModelDoc2::SetDisplayWhenAdded](#) also increase performance during sketch entity creation. IModelDoc2::SetDisplayWhenAdded requires that IModelDoc2::SetAddToDB is True.

If you want to constrain all the sketch entities after creation, use [ISketch::ConstrainAll](#).

After setting IModelDoc2::SetAddToDB to True, you must set it back to false to restore SOLIDWORKS to its normal operating mode.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetAddToDB Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAmbientLightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetAmbientLightProperties Method (IModelDoc2)

Sets ambient light properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetAmbientLightProperties( _  
    ByVal Name As System.String, _  
    ByVal Ambient As System.Double, _
```

```

    ByVal Diffuse As System.Double, _
    ByVal Specular As System.Double, _
    ByVal Colour As System.Integer, _
    ByVal Enabled As System.Boolean, _
    ByVal Fixed As System.Boolean _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc2
Dim Name As System.String
Dim Ambient As System.Double
Dim Diffuse As System.Double
Dim Specular As System.Double
Dim Colour As System.Integer
Dim Enabled As System.Boolean
Dim Fixed As System.Boolean
Dim value As System.Boolean

```

```

value = instance.SetAmbientLightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled, Fixed)

```

C#

```

System.bool SetAmbientLightProperties(
    System.string Name,
    System.double Ambient,
    System.double Diffuse,
    System.double Specular,
    System.int Colour,
    System.bool Enabled,
    System.bool Fixed
)

```

C++/CLI

```

System.bool SetAmbientLightProperties(
    & System.String^ Name,
    & System.double Ambient,
    & System.double Diffuse,
    & System.double Specular,
    & System.int Colour,
    & System.bool Enabled,
    & System.bool Fixed
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name whose settings to modify

Ambient

Light source ambient value

Diffuse

Light source diffuse value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True to enable the light, false to not

Fixed

True to fix light, false to not

Return Value

True if light properties change successfully, false if not

See [ModelDoc2::SetAmbientLightProperties](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetAmbientLightProperties Method](#)
[IModelDoc2::GetDirectionLightProperties Method](#)
[IModelDoc2::GetSpotlightProperties Method](#)
[IModelDoc2::GetPointLightProperties Method](#)
[IModelDoc2::SetDirectionLightProperties Method](#)
[IModelDoc2::SetPointLightProperties Method](#)
[IModelDoc2::SetSpotlightProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAngularUnits Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetAngularUnits Method (IModelDoc2)

Sets the current angular units.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetAngularUnits( _  
    ByVal UType As System.Short, _  
    ByVal FractBase As System.Short, _  
    ByVal FractDenom As System.Short, _  
    ByVal SigDigits As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UType As System.Short  
Dim FractBase As System.Short  
Dim FractDenom As System.Short  
Dim SigDigits As System.Short  
  
instance.SetAngularUnits(UType, FractBase, FractDenom, SigDigits)
```

C#

```
void SetAngularUnits(  
    System.short UType,  
    System.short FractBase,  
    System.short FractDenom,  
    System.short SigDigits  
)
```

C++/CLI

```
void SetAngularUnits(  
& System.short UType,  
& System.short FractBase,  
& System.short FractDenom,  
& System.short SigDigits  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UType

Angular units as defined in [swAngleUnit e](#)

FractBase

Not supported; however, input to this field is required but is not used

FractDenom

Not supported; however, input to this field is required but is not used
SigDigits
Significant digits if using decimal units

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetAngularUnits](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::ISetAngularUnits Method](#)
[IModelDoc2::IGetAngularUnits Method](#)
[IModelDoc2::GetAngularUnits Method](#)
[IModelDoc2::GetUnits Method](#)
[IModelDoc2::GetUserUnit Method](#)
[IModelDoc2::IGetUnits Method](#)
[IModelDoc2::IGetUserUnit Method](#)
[IModelDoc2::SetUnits Method](#)
[IModelDoc2::LengthUnit Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetArcCentersDisplayed Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetArcCentersDisplayed Method (IModelDoc2)

Sets the current arc centers displayed setting.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetArcCentersDisplayed( _  
    ByVal Setting As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Setting As System.Boolean  
  
instance.SetArcCentersDisplayed(Setting)
```

C#

```
void SetArcCentersDisplayed(  
    System.bool Setting  
)
```

C++/CLI

```
void SetArcCentersDisplayed(  
& System.bool Setting  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Setting
True to display arc centers, false to not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetArcCentersDisplayed](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetArcCentersDisplayed Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBendState Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetBendState Method (IModelDoc2)

Sets the bend state of a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBendState( _  
    ByVal BendState As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim BendState As System.Integer  
Dim value As System.Integer  
  
value = instance.SetBendState(BendState)
```

C#

```
System.int SetBendState(  
    System.int BendState  
)
```

C++/CLI

```
System.int SetBendState(  
& System.int BendState  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BendState

Sheet metal state to set in this part as defined in [swSMBendState_e](#)

Return Value

Status of the set operation as defined in [swSMCommandStatus_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetBendState](#).

Example

[Flatten Sheet Metal Part \(VBA\)](#)

Remarks

This method only works for old-style sheet metal parts or non-sheet metal parts converted to sheet metal parts. To set the bend state on new-style sheet metal parts (i.e., those that have a base flange as their first feature), suppress and unsuppress the flat-pattern feature.

If editing a part with bend information in the context of the assembly (see [AssemblyDoc::EditPart2](#)), the bend state for that part will be set.

If this method is executed on...	Then...
Part without bend information	The part is not affected, and retval is set to swSMErrorNotASheetMetalPart
Assembly	The assembly is not affected, and retval is set to swSMErrorNotAPart

NOTE: In both of these cases, status is S_false for the COM version of this method.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetBendState Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBlockingState Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetBlockingState Method (IModelDoc2)

Sets the blocking state for the SOLIDWORKS menus.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetBlockingState( _
    ByVal StateIn As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim StateIn As System.Integer

instance.SetBlockingState(StateIn)
```

C#

```
void SetBlockingState(
    System.int StateIn
)
```

C++/CLI

```
void SetBlockingState(
    & System.int StateIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StateIn

State as defined in [swBlockingStates_e](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetBlockingState](#).

Example

[Set Blocking State \(VBA\)](#)

Remarks

Call [IModelDoc2::ResetBlockingState](#) to reset the state when the operations are completed.

IMPORTANT: There must be a corresponding call to IModelDoc2::ResetBlockingState for every call to IModelDoc2::SetBlockingState. It is not enough to call IModelDoc2::ResetBlockingState once at the end of a sequence of operations that have called IModelDoc2::SetBlockingState several times.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetBlockingState Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConsiderLeadersAsLines Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetConsiderLeadersAsLines Method (IModelDoc2)

Sets a flag on the document that indicates whether the display data of a leader should be included as lines when the lines are retrieved from a view or annotation in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function SetConsiderLeadersAsLines( _  
    ByVal LeadersAsLines As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim LeadersAsLines As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetConsiderLeadersAsLines(LeadersAsLines)
```

C#

```
System.bool SetConsiderLeadersAsLines(  
    System.bool LeadersAsLines  
)
```

C++/CLI

```
System.bool SetConsiderLeadersAsLines(  
& System.bool LeadersAsLines  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LeadersAsLines

True to return leaders as line data, false to not

Return Value

Original value of the flag before calling this method

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetConsiderLeadersAsLines](#).

Remarks

The various `GetLeaderCount` and `GetLeaderAtIndex` methods that are found on several different annotations return the information about where the vertices of the leader are located. `GetLineCount` and `GetLinesAtIndex` also return the leader information as part of its line information. Depending on what your program is trying to accomplish and which methods it is using, this duplication of information may not be desirable. This method controls this behavior by setting a flag on the document that indicates whether or not the leader information is returned as part of the line information or not.

Initially, when a document is opened, the flag is set to `True`, so that existing applications work as they have always worked. If you do not want to get back leader information as part of the line information, call this method and set the value to `false`. The flag is not saved with the document, so you must specifically set it to `false` whenever you do not want leaders as part of the line information.

The various `GetArrowHeadCount` and `GetArrowHeadAtIndex` methods are also affected. When this flag has been set to `false` so that leaders are not considered as lines, the arrowhead information for the arrowheads on those leaders is not returned. However, `GetArrowHeadInfo` still returns valid information.

Use [IModelDoc2::GetConsiderLeadersAsLines](#) to determine the current behavior.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDirectionLightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetDirectionLightProperties Method (IModelDoc2)

Sets direction light properties.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDirectionLightProperties( _  
    ByVal Name As System.String, _  
    ByVal Ambient As System.Double, _  
    ByVal Diffuse As System.Double, _  
    ByVal Specular As System.Double, _  
    ByVal Colour As System.Integer, _  
    ByVal Enabled As System.Boolean, _  
    ByVal Fixed As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim Ambient As System.Double  
Dim Diffuse As System.Double  
Dim Specular As System.Double  
Dim Colour As System.Integer  
Dim Enabled As System.Boolean  
Dim Fixed As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetDirectionLightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled,  
Fixed, X, Y, Z)
```

C#

```
System.bool SetDirectionLightProperties(  
    System.string Name,  
    System.double Ambient,  
    System.double Diffuse,  
    System.double Specular,  
    System.int Colour,  
    System.bool Enabled,  
    System.bool Fixed,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool SetDirectionLightProperties(  
& System.String^ Name,  
& System.double Ambient,  
& System.double Diffuse,  
& System.double Specular,  
& System.int Colour,  
& System.bool Enabled,  
& System.bool Fixed,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name to modify

Ambient

Light source ambient value

Diffuse

Light source diffuse value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True to enable the light, false to not

Fixed

True to fix the light, false to not

X

x component of the light direction vector

Y

y component of the light direction vector

Z

z component of the light direction vector

Return Value

True if light properties change successfully, false if not

See Also

[IModelDoc2 Interface](#)

[IModelDoc2 Members](#)

[IModelDoc2::ILightSourcePropertyValues Property](#)

[IModelDoc2::LightSourcePropertyValues Property](#)

[IModelDoc2::GetDirectionLightProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SetDisplayWhenAdded Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetDisplayWhenAdded Method (IModelDoc2)

Obsolete. Superseded by [ISketchManager::DisplayWhenAdded](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayWhenAdded( _  
    ByVal Setting As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Setting As System.Boolean  
  
instance.SetDisplayWhenAdded(Setting)
```

C#

```
void SetDisplayWhenAdded(  
    System.bool Setting  
)
```

C++/CLI

```
void SetDisplayWhenAdded(  
& System.bool Setting  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Setting

True to display new sketch entities when added, false to not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetDisplayWhenAdded](#).

Remarks

The sketch entities appear on the screen after performing [IModelDoc2::GraphicsRedraw2](#) or [IModelDoc2::EditRebuild3](#) is performed. Also, [IModelDoc2::SetAddToDB](#) must be True to use this method's settings.

This display setting remains even after your program run has ended. Therefore, it is recommended that you reset this parameter to True at the end of your program. For example, if you have ended your program and the display is set to false, then the user would have difficulty performing selections and newly created entities would not be seen until a redraw or a rebuild.

NOTES:

- IModelDoc2::GraphicsRedraw2 is much faster than ModelDoc2::EditRebuild3.
- IModelDoc2::SetAddToDB and [IModelDoc2::SetDisplayWhenAdded](#) also increase performance during sketch entity creation.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetDisplayWhenAdded Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SetFeatureManagerWidth Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetFeatureManagerWidth Method (IModelDoc2)

Sets the width of the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFeatureManagerWidth( _  
    ByVal Width As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Width As System.Integer  
Dim value As System.Integer  
  
value = instance.SetFeatureManagerWidth(Width)
```

C#

```
System.int SetFeatureManagerWidth(  
    System.int Width  
)
```

C++/CLI

```
System.int SetFeatureManagerWidth(  
& System.int Width  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Width
Width of the FeatureManager design tree, in pixels

Return Value

Status of the set width operation (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetFeatureManagerWidth](#).

Example

[Change Width of FeatureManager Design Tree \(VBA\)](#)

Remarks

The retval argument indicates the success or failure of the set width operation:

A value of...	Indicates setting of window width...
0	Succeeded
-1	Failed

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetInferenceMode Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetInferenceMode Method (IModelDoc2)

Obsolete. Superseded by [SketchManager::InferenceMode](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetInferenceMode( _  
    ByVal InferenceMode As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim InferenceMode As System.Boolean  
  
instance.SetInferenceMode(InferenceMode)
```

C#

```
void SetInferenceMode(  
    System.bool InferenceMode  
)
```

C++/CLI

```
void SetInferenceMode(  
    & System.bool InferenceMode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InferenceMode
True to enable sketch inference mode, false to disable it

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetInferenceMode](#).

Remarks

Setting inference mode to...	Allows...
True	Inferencing during sketch operations, subject to other settings that may disable inferencing such as IModelDoc2::AutoInferToggle , IModelDoc2::SetAddToDB , and IDrawingDoc::StartDrawing .
false	Faster sketching without inferencing, similar to IModelDoc2::SetAddToDB , except that using this method does not disable undo operations.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetInferenceMode Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLightSourceName Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetLightSourceName Method (IModelDoc2)

Sets the light source name used internally by the SOLIDWORKS Design software.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetLightSourceName( _  
    ByVal ID As System.Integer, _  
    ByVal NewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ID As System.Integer  
Dim NewName As System.String  
Dim value As System.Boolean  
  
value = instance.SetLightSourceName(ID, NewName)
```

C#

```
System.bool SetLightSourceName(  
    System.int ID,  
    System.string NewName  
)
```

C++/CLI

```
System.bool SetLightSourceName(  
& System.int ID,  
& System.String^ NewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

ID of the light source whose name you want to set

NewName

Name to be given to the specified light source

Return Value

True if the name is set successfully, false otherwise

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetLightSourceName](#).

Remarks

The light source ID ranges from 0 to n , where n = (the total number of light sources - 1). To get the total number of light sources, call [IModelDoc2::GetLightSourceCount](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddLightSource Method](#)
[IModelDoc2::AddLightSourceExtProperty Method](#)
[IModelDoc2::AddLightToScene Method](#)
[IModelDoc2::AddSceneExtProperty Method](#)
[IModelDoc2::DeleteLightSource Method](#)
[IModelDoc2::GetLightSourceExtProperty Method](#)
[IModelDoc2::GetLightSourceIdFromName Method](#)
[IModelDoc2::GetLightSourceName Method](#)
[IModelDoc2::ResetLightSourceExtProperty Method](#)
[IModelDoc2::ResetSceneExtProperty Method](#)
[IModelDoc2::SetLightSourcePropertyValuesVB Method](#)
[IModelDoc2::LightSourcePropertyValues Property](#)
[IModelDoc2::ILightSourcePropertyValues Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLightSourcePropertyValuesVB Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetLightSourcePropertyValuesVB Method (IModelDoc2)

Sets the light source property values.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLightSourcePropertyValuesVB( _  
    ByVal IdName As System.String, _  
    ByVal LType As System.Integer, _  
    ByVal Diff As System.Double, _  
    ByVal RgbColor As System.Integer, _  
    ByVal Dist As System.Double, _  
    ByVal DirX As System.Double, _  
    ByVal DirY As System.Double, _  
    ByVal DirZ As System.Double, _  
    ByVal SpotDirX As System.Double, _  
    ByVal SpotDirY As System.Double, _  
    ByVal SpotDirZ As System.Double, _  
    ByVal SpotAngle As System.Double, _  
    ByVal FallOff0 As System.Double, _  
    ByVal FallOff1 As System.Double, _  
    ByVal FallOff2 As System.Double, _  
    ByVal Ambient As System.Double, _  
    ByVal Specular As System.Double, _  
    ByVal SpotExponent As System.Double, _  
    ByVal BDisable As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim IdName As System.String  
Dim LType As System.Integer  
Dim Diff As System.Double  
Dim RgbColor As System.Integer  
Dim Dist As System.Double  
Dim DirX As System.Double  
Dim DirY As System.Double  
Dim DirZ As System.Double  
Dim SpotDirX As System.Double  
Dim SpotDirY As System.Double  
Dim SpotDirZ As System.Double  
Dim SpotAngle As System.Double  
Dim FallOff0 As System.Double  
Dim FallOff1 As System.Double  
Dim FallOff2 As System.Double  
Dim Ambient As System.Double  
Dim Specular As System.Double
```

```
Dim SpotExponent As System.Double
Dim BDisable As System.Boolean
Dim value As System.Boolean
```

```
value = instance.SetLightSourcePropertyValuesVB(IdName, LType, Diff, RgbColor, Dist, DirX, DirY,
DirZ, SpotDirX, SpotDirY, SpotDirZ, SpotAngle, Falloff0, Falloff1, Falloff2, Ambient, Specular,
SpotExponent, BDisable)
```

C#

```
System.bool SetLightSourcePropertyValuesVB(
    System.string IdName,
    System.int LType,
    System.double Diff,
    System.int RgbColor,
    System.double Dist,
    System.double DirX,
    System.double DirY,
    System.double DirZ,
    System.double SpotDirX,
    System.double SpotDirY,
    System.double SpotDirZ,
    System.double SpotAngle,
    System.double Falloff0,
    System.double Falloff1,
    System.double Falloff2,
    System.double Ambient,
    System.double Specular,
    System.double SpotExponent,
    System.bool BDisable
)
```

C++/CLI

```
System.bool SetLightSourcePropertyValuesVB(
    & System.String^ IdName,
    & System.int LType,
    & System.double Diff,
    & System.int RgbColor,
    & System.double Dist,
    & System.double DirX,
    & System.double DirY,
    & System.double DirZ,
    & System.double SpotDirX,
    & System.double SpotDirY,
    & System.double SpotDirZ,
    & System.double SpotAngle,
    & System.double Falloff0,
    & System.double Falloff1,
    & System.double Falloff2,
    & System.double Ambient,
    & System.double Specular,
    & System.double SpotExponent,
    & System.bool BDisable
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdName

Light source ID name

LType

Light source type; valid types are taken from OpenGL definitions (LIGHT_EYE, LIGHT_AMBIENT, LIGHT_SPOT, LIGHT_POINT, LIGHT_DISTANT)

Diff

Light source diffuseness where values range from 0 to 1

RgbColor

Color value

Dist

Distance between the light source position and the vertex

DirX

X unit vector value describing the lights position

DirY

Y unit vector value describing the lights po

DirZ

Z unit vector value describing the lights position

SpotDirX

Spot X direction

SpotDirY

Spot Y direction

SpotDirZ

Spot Z direction

SpotAngle

Spot angle

FallOff0

Light source falloff - constant attenuation

NOTE: This parameter is not supported in SOLIDWORKS 2011 and later.

FallOff1

Light source falloff - linear attenuation

NOTE: This parameter is not supported in SOLIDWORKS 2011 and later.

FallOff2

Light source falloff - quadratic attenuation

NOTE: This parameter is not supported in SOLIDWORKS 2011 and later.

Ambient

Light source ambient intensity

Specular

Light source specular intensity

SpotExponent

Spot exponent

NOTE: This parameter is not supported in SOLIDWORKS 2011 and later.

BDisable

Light source disabled

Return Value

True if setting the light source properties is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetLightSourcePropertyValuesVB](#).

Example

[Add Spotlight and Get Light Feature \(C#\)](#)
[Add Spotlight and Get Light Feature \(VB.NET\)](#)
[Add Spotlight and Get Light Feature \(VBA\)](#)

Remarks

This method is similar to [IModelDoc2::LightSourcePropertyValues](#) and [IModelDoc2::ILightSourcePropertyValues](#), except using this method you can pass each argument individually.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::AddLightSource Method](#)
[IModelDoc2::AddLightSourceExtProperty Method](#)
[IModelDoc2::AddLightToScene Method](#)
[IModelDoc2::AddSceneExtProperty Method](#)
[IModelDoc2::DeleteLightSource Method](#)
[IModelDoc2::GetLightSourceCount Method](#)
[IModelDoc2::GetLightSourceExtProperty Method](#)
[IModelDoc2::GetLightSourceIdFromName Method](#)
[IModelDoc2::GetLightSourceName Method](#)
[IModelDoc2::Lights Method](#)
[IModelDoc2::ResetLightSourceExtProperty Method](#)
[IModelDoc2::ResetSceneExtProperty Method](#)
[IModelDoc2::SetLightSourceName Method](#)

Availability

SetParamValue Method (IModelDoc2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetParamValue Method (IModelDoc2)

Sets the value of selected dimension (or parameter).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetParamValue( _  
    ByVal Val As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Val As System.Double  
  
instance.SetParamValue(Val)
```

C#

```
void SetParamValue(  
    System.double Val  
)
```

C++/CLI

```
void SetParamValue(  
&    System.double Val  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Val

Value of parameter (dimension) in meters or radians

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetParamValue](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::Parameter Method](#)
[IModelDoc2::IPParameter Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SetPickMode Method (IModelDoc2)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetPickMode Method (IModelDoc2)

Returns the user to the default selection mode.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPickMode()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.SetPickMode()
```

C#

```
void SetPickMode()
```

C++/CLI

```
void SetPickMode();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetPickMode](#).

Example

[Extend Sketch Entity \(VBA\)](#)
[Extend Sketch Entity \(VB.NET\)](#)
[Extend Sketch Entity \(C#\)](#)

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPointLightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetPointLightProperties Method (IModelDoc2)

Sets point light properties.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPointLightProperties( _  
    ByVal Name As System.String, _  
    ByVal Ambient As System.Double, _  
    ByVal Diffuse As System.Double, _  
    ByVal Specular As System.Double, _  
    ByVal Colour As System.Integer, _  
    ByVal Enabled As System.Boolean, _  
    ByVal Fixed As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim Ambient As System.Double
```

```

Dim Diffuse As System.Double
Dim Specular As System.Double
Dim Colour As System.Integer
Dim Enabled As System.Boolean
Dim Fixed As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean

```

```

value = instance.SetPointLightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled, Fixed,
X, Y, Z)

```

C#

```

System.bool SetPointLightProperties(
    System.string Name,
    System.double Ambient,
    System.double Diffuse,
    System.double Specular,
    System.int Colour,
    System.bool Enabled,
    System.bool Fixed,
    System.double X,
    System.double Y,
    System.double Z
)

```

C++/CLI

```

System.bool SetPointLightProperties(
    & System.String^ Name,
    & System.double Ambient,
    & System.double Diffuse,
    & System.double Specular,
    & System.int Colour,
    & System.bool Enabled,
    & System.bool Fixed,
    & System.double X,
    & System.double Y,
    & System.double Z
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name to modify

Ambient

Light source ambient value

Diffuse

Light source specular value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True to enable light, false to not

Fixed

True to fix light, false to not

X

x location of the point light

Y

y location of the point light

Z

z location of the point light

Return Value

True if the light properties change, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetPointLightProperties](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetAmbientLightProperties Method](#)
[IModelDoc2::GetDirectionLightProperties Method](#)
[IModelDoc2::GetPointLightProperties Method](#)
[IModelDoc2::GetSpotlightProperties Method](#)
[IModelDoc2::SetAmbientLightProperties Method](#)
[IModelDoc2::SetDirectionLightProperties Method](#)
[IModelDoc2::SetSpotlightProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPopupMenuMode Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetPopupMenuMode Method (IModelDoc2)

Sets the pop-up menu mode.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPopupMenuMode( _  
    ByVal ModeIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim ModeIn As System.Integer  
  
instance.SetPopupMenuMode(ModeIn)
```

C#

```
void SetPopupMenuMode(  
    System.int ModeIn  
)
```

C++/CLI

```
void SetPopupMenuMode(  
& System.int ModeIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModeIn

Pop-up menu mode (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetPopupMenuMode](#).

Remarks

When end users press the right-mouse button on an entity in the graphics window, they are be presented with one of two menu sets. These menu sets are defined as mode 0 and mode 1.

Mode

- 0 - Default shortcut mode. This mode presents the end user with options to **Select Other**, manipulate the view, access the properties dialog of the selected item, and so on.
- 1 - The end-user is presented with a limited set of choices including **Select Other** and **Clear Selection**. This mode is typically seen when a SOLIDWORKS dialog is active and the user is restricted to entity selection.

Using this method, you can simulate the same shortcut menu behavior as in the SOLIDWORKS Design user interface. If you have a dialog that requires user selection of entities, you can set the pop-up menu mode to 1 to simulate SOLIDWORKS behavior. Your application should always set the menu mode back to its previous value. To determine the previous behavior, call [IModelDoc2::GetPopupMenuMode](#) prior to calling to this method.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetReadOnlyState Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetReadOnlyState Method (IModelDoc2)

Sets whether this document is read-only or read-write.

.NET Syntax

Visual Basic (Declaration)

```
Function SetReadOnlyState( _
    ByVal SetReadOnly As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim SetReadOnly As System.Boolean
Dim value As System.Boolean

value = instance.SetReadOnlyState(SetReadOnly)
```

C#

```
System.bool SetReadOnlyState(
    System.bool SetReadOnly
)
```

C++/CLI

```
System.bool SetReadOnlyState(
    & System.bool SetReadOnly
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SetReadOnly

True to set this document to be read-only, false to set this document to read-write

Return Value

True if method executes successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetReadOnlyState](#).

Remarks

If the file is opened as read-write, specifying read-only should work except if it is a new file that has not yet been saved.

If the file is opened as read-only in SOLIDWORKS, then specifying read-write only changes the internal SOLIDWORKS state (not the access rights on disk) and only succeeds if it would be possible to open this file with write access. If the file is read-only on disk or if another user has it open with write access, then this method does not change the internal state to writeable; the document remains read-only.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::IsOpenedReadOnly Method](#)
[IModelDoc2::IsOpenedViewOnly Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSaveAsFileName Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetSaveAsFileName Method (IModelDoc2)

Sets the **Save As** filename from within the FileSaveAsNotify2 event handlers, thereby, bypassing the **Save As** dialog.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSaveAsFileName( _  
    ByVal FileName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim FileName As System.String  
  
instance.SetSaveAsFileName(FileName)
```

C#

```
void SetSaveAsFileName(  
    System.string FileName  
)
```

C++/CLI

```
void SetSaveAsFileName(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName
Save As filename

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetSaveAsFileName](#).

Remarks

Use this method from within the FileSaveAsNotify2 event handler. When setting the **Save As** filename using this method, S_false should be returned from the FileSaveAsNotify2 event handler. See [DAssemblyDocEvents FileSaveAsNotify2](#), [DDrawingDocEvents FileSaveAsNotify2](#), and

[DPartDocEvents FileSaveAsNotify2](#) notifications.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDocExtension::SaveAs Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSaveFlag Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetSaveFlag Method (IModelDoc2)

Flags the document as dirty.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSaveFlag()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
```

```
instance.SetSaveFlag()
```

C#

```
void SetSaveFlag()
```

C++/CLI

```
void SetSaveFlag();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetSaveFlag](#).

Example

[Remove Textures from Assembly Components \(VBA\)](#)

Remarks

If the user tries to close the part, the **Do you wish to save changes?** dialog is displayed.

If SOLIDWORKS data has changed, this method marks the SOLIDWORKS document as dirty so that the end-user is prompted when attempting to close the document. You might want to use this method with applications that use [IModelDoc2::IGet3rdPartyStorage](#) to save stream data in SOLIDWORKS files.

If you have programmatically changed the SOLIDWORKS model, using this method is not necessary because the SOLIDWORKS document is flagged as dirty automatically.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetSaveFlag Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSceneBkgDIB Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetSceneBkgDIB Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SetSceneBkgDIBx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Sets background image described by DIBSECTION data.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSceneBkgDIB( _  
    ByVal L\_dib As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim L_dib As System.Integer  
  
instance.SetSceneBkgDIB(L_dib)
```

C#

```
void SetSceneBkgDIB(  
    System.int L\_dib  
)
```

C++/CLI

```
void SetSceneBkgDIB(  
& System.int L\_dib  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

L_dib
DIBSECTION

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetSceneBkgDIB](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

Old background images are deleted automatically.

For more information about DIBSECTION, see Microsoft's documentation.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

[IModelDoc2::GetSceneBkgDIB Method](#)
[IModelDocExtension::GetSceneBkgDIBx64 Method](#)
[IModelDocExtension::InsertBkgImage Method](#)
[IModelDocExtension::DeleteBkgImage Method](#)
[IModelDocExtension::SceneBkgImageFileName Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSpotlightProperties Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetSpotlightProperties Method (IModelDoc2)

Sets the spotlight properties.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSpotlightProperties( _  
    ByVal Name As System.String, _  
    ByVal Ambient As System.Double, _  
    ByVal Diffuse As System.Double, _  
    ByVal Specular As System.Double, _  
    ByVal Colour As System.Integer, _  
    ByVal Enabled As System.Boolean, _  
    ByVal Fixed As System.Boolean, _  
    ByVal Posx As System.Double, _  
    ByVal Posy As System.Double, _  
    ByVal Posz As System.Double, _  
    ByVal Targetx As System.Double, _  
    ByVal Targety As System.Double, _  
    ByVal Targetz As System.Double, _  
    ByVal ConeAngle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Name As System.String  
Dim Ambient As System.Double  
Dim Diffuse As System.Double  
Dim Specular As System.Double  
Dim Colour As System.Integer  
Dim Enabled As System.Boolean  
Dim Fixed As System.Boolean  
Dim Posx As System.Double  
Dim Posy As System.Double  
Dim Posz As System.Double  
Dim Targetx As System.Double  
Dim Targety As System.Double  
Dim Targetz As System.Double  
Dim ConeAngle As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetSpotlightProperties(Name, Ambient, Diffuse, Specular, Colour, Enabled, Fixed,  
Posx, Posy, Posz, Targetx, Targety, Targetz, ConeAngle)
```

C#

```
System.bool SetSpotlightProperties(  
    System.string Name,  
    System.double Ambient,  
    System.double Diffuse,  
    System.double Specular,  
    System.int Colour,  
    System.bool Enabled,  
    System.bool Fixed,
```

```

        System.double Posx,
        System.double Posy,
        System.double Posz,
        System.double Targetx,
        System.double Targety,
        System.double Targetz,
        System.double ConeAngle
    )

```

C++/CLI

```

System.bool SetSpotlightProperties(
    & System.String^ Name,
    & System.double Ambient,
    & System.double Diffuse,
    & System.double Specular,
    & System.int Colour,
    & System.bool Enabled,
    & System.bool Fixed,
    & System.double Posx,
    & System.double Posy,
    & System.double Posz,
    & System.double Targetx,
    & System.double Targety,
    & System.double Targetz,
    & System.double ConeAngle
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Light name to modify

Ambient

Light source ambient value

Diffuse

Light source diffuse value

Specular

Light source specular value

Colour

COLORREF color value

Enabled

True to enable light, false to not

Fixed

True to fix light, false to not

Posx

x location of the spotlight

Posy

y location of the spotlight

Posz

z location of the spotlight

Targetx

x location of the spotlight target

Targety

y location of the spotlight target

Targetz

z location of the spotlight target

ConeAngle

Cone angle through which the beam spreads in degrees

Return Value

True if light properties are modified, false if not

 **Visual Basic for Applications (VBA) Syntax**

See [ModelDoc2::SetSpotlightProperties](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetAmbientLightProperties Method](#)
[IModelDoc2::GetDirectionLightProperties Method](#)
[IModelDoc2::GetPointLightProperties Method](#)
[IModelDoc2::GetSpotlightProperties Method](#)
[IModelDoc2::SetAmbientLightProperties Method](#)
[IModelDoc2::SetDirectionLightProperties Method](#)
[IModelDoc2::SetPointLightProperties Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTessellationQuality Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetTessellationQuality Method (IModelDoc2)

Sets the shaded-display image quality number for the current document.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTessellationQuality( _  
    ByVal QualityNum As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim QualityNum As System.Integer  
  
instance.SetTessellationQuality(QualityNum)
```

C#

```
void SetTessellationQuality(  
    System.int QualityNum  
)
```

C++/CLI

```
void SetTessellationQuality(  
& System.int QualityNum  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

QualityNum

0 < Shaded-display image quality number < 106 (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetTessellationQuality](#).

Remarks

QualityNum is the degree of tessellation of curved surfaces for shaded rendering output. **Tools > Options > Document Properties > Image Quality** includes a field that sets the maximum chordal deviation. QualityNum and the maximum chordal deviation (in meters) are coupled and inversely proportional as follows:

$$var = TessMin + QualityNum * ((TessMax - TessMin) / 100)$$

$$Deviation = 0.025 * (BodyDiameter * 2) / var;$$

where:

- *TessMin* = 6

- *TessMax* = 166
- *0 < QualityNum < 106*
- *BodyDiameter* is the diagonal distance across the bounds of the part box. See [IPartDoc::GetPartBox](#) or [IPartDoc::!GetPartBox](#) for more information.

There are two ways to set the image quality for assemblies using the API. You can either:

- Call this method
- OR -
- Set [swUserPreferenceIntegerValue e.swImageQualityShaded](#)
- Set [swUserPreferenceDoubleValue e.swImageQualityShadedDeviation](#)

Before doing either, you must set [swUserPreferenceToggle e.swImageQualityApplyToAllReferencedPartDoc](#) to true in order to affect the image quality of the assembly.

Call [IModelView::GraphicsRedraw](#) after calling this method to update the part.

NOTE: Setting the degree of tessellation to a higher value results in:

- finer tessellation,
- increased file size,
- slower graphics performance, and
- increased memory usage.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetTessellationQuality Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTitle2 Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetTitle2 Method (IModelDoc2)

Sets the title of a new document.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTitle2( _
    ByVal NewTitle As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2
Dim NewTitle As System.String
Dim value As System.Boolean

value = instance.SetTitle2(NewTitle)
```

C#

```
System.bool SetTitle2(
    System.string NewTitle
)
```

C++/CLI

```
System.bool SetTitle2(
    & System.String^ NewTitle
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NewTitle
 Name to give to the document window

Return Value

True if successfully renamed, false otherwise

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetTitle2](#).

Remarks

This title appears in the active window's title bar.

This method:

- Does not save this model document to disk; instead, it renames the document window.
- Is only valid when for a new document that has not yet been saved.
- Does not change the title of a document that has already been saved and exists on disk. If you want to rename an existing document, use `ModelDoc2::SaveAs`.

To retrieve the title of a document, use [IModelDoc2::GetTitle](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetToolbarVisibility Method (IModelDoc2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetToolbarVisibility Method (IModelDoc2)

Sets the visibility of a toolbar.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetToolbarVisibility( _  
    ByVal Toolbar As System.Integer, _  
    ByVal Visibility As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim Toolbar As System.Integer  
Dim Visibility As System.Boolean  
  
instance.SetToolbarVisibility(Toolbar, Visibility)
```

C#

```
void SetToolbarVisibility(  
    System.int Toolbar,  
    System.bool Visibility  
)
```

C++/CLI

```
void SetToolbarVisibility(  
& System.int Toolbar,  
& System.bool Visibility  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Toolbar

Identifier of toolbar as defined in [swToolbar_e](#)

Visibility

True if the toolbar is visible, false if hidden

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetToolbarVisibility](#).

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetToolbarVisibility Method](#)
[ISldWorks::AddToolbar4 Method](#)
[ISldWorks::GetToolbarState2 Method](#)
[ISldWorks::GetToolbarDock2 Method](#)
[ISldWorks::HideToolbar2 Method](#)
[ISldWorks::RemoveToolbar2 Method](#)
[ISldWorks::SetToolbarDock2 Method](#)
[ISldWorks::ShowToolbar2 Method](#)
[ICommandGroup Interface](#)
[ICommandManager Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUnits Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetUnits Method (IModelDoc2)

Sets the units used by the end-user for the model.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetUnits( _  
    ByVal UType As System.Short, _  
    ByVal FractBase As System.Short, _  
    ByVal FractDenom As System.Short, _  
    ByVal SigDigits As System.Short, _  
    ByVal RoundToFraction As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UType As System.Short  
Dim FractBase As System.Short  
Dim FractDenom As System.Short  
Dim SigDigits As System.Short  
Dim RoundToFraction As System.Boolean
```

```
instance.SetUnits(UType, FractBase, FractDenom, SigDigits, RoundToFraction)
```

C#

```
void SetUnits(  
    System.short UType,  
    System.short FractBase,  
    System.short FractDenom,  
    System.short SigDigits,  
    System.bool RoundToFraction  
)
```

C++/CLI

```

void SetUnits(
& System.short UType,
& System.short FractBase,
& System.short FractDenom,
& System.short SigDigits,
& System.bool RoundToFraction
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UType

Model units as defined in [swLengthUnit_e](#)

FractBase

Decimal or fraction as defined in [swFractionDisplay_e](#)

FractDenom

Denominator of the smallest inch fraction to be used, for example, 64 for 1/64; valid only if FractBase is set to swFRACTION (see **Remarks**)

SigDigits

Significant digits; valid only if FractBase is set to swDECIMAL

RoundToFraction

Flag denoting whether or not to round to the fraction; for example, if 4 is the denominator value given in FractDenom and the actual value is 0.27 it is rounded to 0.25

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetUnits](#).

Example

```

' VBA
' 1. Open a document in SOLIDWORKS.
' 2. Run the macro below to set inch units with
'    a fractional base of 16 and no rounding.

Dim swApp As SldWorks.SldWorks
Dim Part As SldWorks.ModelDoc2
Option Explicit
Sub main()
    Set swApp = Application.SldWorks
    Set Part = swApp.ActiveDoc
    Part.SetUnits swINCHES, swFRACTION, 16, 0, False
End Sub

```

Example

[Get and Set Units \(C++\)](#)

Remarks

Fractional units are only valid if UType is set to swINCHES or swFEETINCHES.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)
[IModelDoc2::GetUnits Method](#)
[IModelDoc2::IGetUnits Method](#)
[IModelDoc2::GetAngularUnits Method](#)
[IModelDoc2::GetUserUnit Method](#)
[IModelDoc2::IGetAngularUnits Method](#)
[IModelDoc2::IGetUnits Method](#)
[IModelDoc2::IGetUserUnit Method](#)
[IModelDoc2::ISetAngularUnits Method](#)
[IModelDoc2::SetAngularUnits Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUserPreferenceDoubleValue Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetUserPreferenceDoubleValue Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SetUserPreferenceDouble](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetUserPreferenceDoubleValue( _  
    ByVal UserPreferenceValue As System.Integer, _  
    ByVal Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UserPreferenceValue As System.Integer  
Dim Value As System.Double  
Dim value As System.Boolean  
  
value = instance.SetUserPreferenceDoubleValue(UserPreferenceValue, Value)
```

C#

```
System.bool SetUserPreferenceDoubleValue(  
    System.int UserPreferenceValue,  
    System.double Value  
)
```

C++/CLI

```
System.bool SetUserPreferenceDoubleValue(  
& System.int UserPreferenceValue,  
& System.double Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference value as defined in [swUserPreferenceDoubleValue_e](#)

Value

Numeric value to give to the user preference specified in UserPreferenceValue

Return Value

True if the user preference is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetUserPreferenceDoubleValue](#).

Example

[Get and Set Material Density \(VBA\)](#)
[Get Excel Cell Value for Density \(VBA\)](#)

Remarks

This method is equivalent to interactively setting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetUserPreferenceIntegerValue Method (IModelDoc2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc2 Interface](#) : SetUserPreferenceIntegerValue Method (IModelDoc2)

Obsolete. Superseded by [IModelDocExtension::SetUserPreferenceInteger](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetUserPreferenceIntegerValue( _  
    ByVal UserPreferenceValue As System.Integer, _  
    ByVal Value As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc2  
Dim UserPreferenceValue As System.Integer  
Dim Value As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetUserPreferenceIntegerValue(UserPreferenceValue, Value)
```

C#

```
System.bool SetUserPreferenceIntegerValue(  
    System.int UserPreferenceValue,  
    System.int Value  
)
```

C++/CLI

```
System.bool SetUserPreferenceIntegerValue(  
& System.int UserPreferenceValue,  
& System.int Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference value as defined in [swUserPreferenceIntegerValue_e](#)

Value

Numeric value you give to the user preference specified in UserPreferenceValue

Return Value

True if the setting is changed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::SetUserPreferenceIntegerValue](#).

Example

[Set Grid Lines \(VBA\)](#)

Remarks

This method is equivalent to interactively setting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

See Also

[IModelDoc2 Interface](#)
[IModelDoc2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0