

SOLIDWORKS API (.NET VBA C#) — Reference (196/337): IModelDocExtension (part 2 of 8)

SOLIDWORKS API Documentation (converted from CHM)

IModelDocExtension (part 2 of 8) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CheckVersionCompatibility Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CheckVersionCompatibility Method (IModelDocExtension)

Checks whether a document can be saved in the file format for an earlier version of SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Function CheckVersionCompatibility( _  
    ByVal Version As System.Integer, _  
    ByVal showDialog As System.Integer, _  
    ByRef Incompatibilities As System.Object, _  
    ByRef Warnings As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Version As System.Integer  
Dim showDialog As System.Integer  
Dim Incompatibilities As System.Object  
Dim Warnings As System.Object  
Dim value As System.Integer  
  
value = instance.CheckVersionCompatibility(Version, showDialog, Incompatibilities, Warnings)
```

C#

```
System.int CheckVersionCompatibility(  
    System.int Version,  
    System.int showDialog,  
    out System.object Incompatibilities,  
    out System.object Warnings  
)
```

C++/CLI

```
System.int CheckVersionCompatibility(  
& System.int Version,  
& System.int showDialog,  
& [Out] System.Object^ Incompatibilities,  
& [Out] System.Object^ Warnings  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Version

The previous file format to check for compatibility. (See [swSaveToVersion e](#))

showDialog

Display the compatibility results dialog. (See [swCompatibilityDialogOptions e](#))

Incompatibilities

Array of [IVersionCompatibilityItem](#) objects preventing the document from saving to the specified version.

Warnings

Array of [IVersionCompatibilityItem](#) objects warning about saving the document to the specified version.

Return Value

The outcome of the compatibility check (See [swVersionCompatibilityResult e](#)).

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CheckVersionCompatibility](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2026 SP03, Revision Number 34.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

CloseMessageBar Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CloseMessageBar Method (IModelDocExtension)

Closes the specified message bar in this document's window.

.NET Syntax

Visual Basic (Declaration)

```
Sub CloseMessageBar( _  
    ByVal Handler As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Handler As System.Object  
  
instance.CloseMessageBar(Handler)
```

C#

```
void CloseMessageBar(  
    System.object Handler  
)
```

C++/CLI

```
void CloseMessageBar(  
    & System.Object^ Handler  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Handler
[IMessageBarHandler](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CloseMessageBar](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

CloseUserNotification Method (IModelDocExtension)

[See Also](#)



Closes the specified user notification in this document's window.

.NET Syntax

Visual Basic (Declaration)

```
Sub CloseUserNotification( _  
    ByVal Handler As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Handler As System.Object  
  
instance.CloseUserNotification(Handler)
```

C#

```
void CloseUserNotification(  
    System.object Handler  
)
```

C++/CLI

```
void CloseUserNotification(  
    & System.Object^ Handler  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Handler
[IUserNotificationHandler](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CloseUserNotification](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CommandTabVisible Property (IModelDocExtension)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IModelDocExtension Interface : CommandTabVisible Property (IModelDocExtension)

Gets and sets the visibility of the specified SOLIDWORKS CommandManager tab.

.NET Syntax

Visual Basic (Declaration)

```
Property CommandTabVisible( _  
    ByVal TabIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IModelDocExtension
Dim TabIndex As System.Integer
Dim value As System.Boolean

instance.CommandTabVisible(TabIndex) = value

value = instance.CommandTabVisible(TabIndex)

```

C#

```

System.bool CommandTabVisible(
    System.int TabIndex
) {get; set;}

```

C++/CLI

```

property System.bool CommandTabVisible {
    System.bool get(System.int TabIndex);
    void set (System.int TabIndex, System.bool value);
}

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TabIndex
Index of the tab for which to get or set visibility

Property Value

True to make the tab visible, false to not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CommandTabVisible](#).

Example

[Activate SOLIDWORKS CommandManager Tab \(VBA\)](#)
[Activate SOLIDWORKS CommandManager Tab \(VB.NET\)](#)
[Activate SOLIDWORKS CommandManager Tab \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::ActiveCommandTab Property\(\)](#)
[IModelDocExtension::ActiveCommandTabIndex Property\(\)](#)
[IModelDocExtension::GetCommandTabs Method\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Compare3DPMI Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : Compare3DPMI Method (IModelDocExtension)

Compare DimXpert annotations, reference dimensions, and other annotations between different versions of the same part document.

.NET Syntax

Visual Basic (Declaration)

```

Function Compare3DPMI( _
    ByVal ReferenceDocument As System.String, _
    ByVal ModifiedDocument As System.String, _
    ByVal ReportName As System.String, _
    ByVal ReportFolderPath As System.String, _

```

```
ByVal ReportSaveOptions As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim ReferenceDocument As System.String  
Dim ModifiedDocument As System.String  
Dim ReportName As System.String  
Dim ReportFolderPath As System.String  
Dim ReportSaveOptions As System.Integer  
Dim value As System.Boolean
```

```
value = instance.Compare3DPMI(ReferenceDocument, ModifiedDocument, ReportName, ReportFolderPath,  
ReportSaveOptions)
```

C#

```
System.bool Compare3DPMI(  
    System.string ReferenceDocument,  
    System.string ModifiedDocument,  
    System.string ReportName,  
    System.string ReportFolderPath,  
    System.int ReportSaveOptions  
)
```

C++/CLI

```
System.bool Compare3DPMI(  
& System.String^ ReferenceDocument,  
& System.String^ ModifiedDocument,  
& System.String^ ReportName,  
& System.String^ ReportFolderPath,  
& System.int ReportSaveOptions  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ReferenceDocument

Path and file name of the open part document

ModifiedDocument

Path and file name of a different and open version of ReferenceDocument

ReportName

Name for the report and name of the folder to which to save the report and bitmap image files

ReportFolderPath

Path to the folder specified in ReportName in which to save the report and bitmap image files

ReportSaveOptions

Save options for the report as defined in [sw3DPMISaveOptions_e](#)

Return Value

True if the method executed, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::Compare3DPMI](#).

Example

[Compare DimXpert Annotations in Different Versions of Same Part \(C#\)](#)
[Compare DimXpert Annotations in Different Versions of Same Part \(VB.NET\)](#)
[Compare DimXpert Annotations in Different Versions of Same Part \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

CopyDraftingStandard Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CopyDraftingStandard Method (IModelDocExtension)

Copy the current custom drafting standard.

.NET Syntax

Visual Basic (Declaration)

```
Function CopyDraftingStandard( _
    ByVal Name As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim Name As System.String
Dim value As System.Boolean
```

```
value = instance.CopyDraftingStandard(Name)
```

C#

```
System.bool CopyDraftingStandard(
    System.string Name
)
```

C++/CLI

```
System.bool CopyDraftingStandard(
    & System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of current custom drafting standard

Return Value

True if the custom drafting standard is copied, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CopyDraftingStandard](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::DeleteDraftingStandard Method](#)
[IModelDocExtension::LoadDraftingStandard Method](#)
[IModelDocExtension::RenameDraftingStandard Method](#)
[IModelDocExtension::SaveDraftingStandard Method](#)
[IModelDocExtension::GetDraftingStandardNames Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

Create3DBoundingBox Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : Create3DBoundingBox Method (IModelDocExtension)

Creates a 3D bounding box for a cut list item in a weldment part.

.NET Syntax

Visual Basic (Declaration)

```
Sub Create3DBoundingBox()
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
instance.Create3DBoundingBox()
```

C#

```
void Create3DBoundingBox()
```

C++/CLI

```
void Create3DBoundingBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::Create3DBoundingBox](#).

Example

[Create 3D Bounding Box for Cut List Item \(VBA\)](#)
[Create 3D Bounding Box for Cut List Item \(VB.NET\)](#)
[Create 3D Bounding Box for Cut List Item \(C#\)](#)

Remarks

After selecting the bounding box, [ISelectionMgr::GetSelectedObjectType3](#) returns [swSelectType_e.swSelSKETCHES](#), while [ISelectionMgr::GetSelectedObject6](#) returns an [IFeature](#) instead of an [ISketch](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateAdvancedHoleElementData Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateAdvancedHoleElementData Method (IModelDocExtension)

Creates an Advanced Hole element data object of the specified type.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAdvancedHoleElementData( _  
    ByVal ElmType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim ElmType As System.Integer  
Dim value As System.Object
```

```
value = instance.CreateAdvancedHoleElementData(ElmType)
```

C#

```
System.object CreateAdvancedHoleElementData(  
    System.int ElmType  
)
```

C++/CLI

```
System.Object^ CreateAdvancedHoleElementData(  
& System.int ElmType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ElmType

Advanced Hole element type as defined in [swAdvWzdGeneralHoleTypes_e](#)

Return Value

[IAdvancedHoleElementData](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateAdvancedHoleElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

After calling this method, use the IAdvancedHoleElementData object to get and set the properties common to all Advanced Hole elements. Cast the returned object using one of the following hole type-specific interfaces to set hole-specific properties:

- [ICounterboreElementData](#)
- [ICountersinkElementData](#)
- [IStraightElementData](#)
- [IStraightTapElementData](#)
- [ITaperedTapElementData](#)

To create an Advanced Hole, see the [IFeatureManager::AdvancedHole](#) Remarks.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateBalloonOptions Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateBalloonOptions Method (IModelDocExtension)

Creates an object that stores BOM balloon options.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateBalloonOptions() As BalloonOptions
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As BalloonOptions  
  
value = instance.CreateBalloonOptions()
```

C#

```
BalloonOptions CreateBalloonOptions()
```

C++/CLI

```
BalloonOptions^ CreateBalloonOptions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBalloonOptions](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateBalloonOptions](#).

Example

[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)

Remarks

To create a single BOM balloon:

1. Select an item for which to create a BOM balloon.
2. Call this method to create an [IBalloonOptions](#) object.
3. Set the properties on the IBalloonOptions object.
4. Pass the IBalloonOptions object in a call to [IModelDocExtension::InsertBOMBalloon2](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateStackedBalloonOptions Method](#)
[IDrawingDoc::CreateAutoBalloonOptions Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateCallout Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateCallout Method (IModelDocExtension)

Creates a callout independent of a selection.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateCallout( _  
    ByVal NumberOfRows As System.Integer, _  
    ByVal Handler As System.Object _  
) As Callout
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim NumberOfRows As System.Integer
```

```
Dim Handler As System.Object
Dim value As Callout

value = instance.CreateCallout(NumberOfRows, Handler)
```

C#

```
Callout CreateCallout(
    System.int NumberOfRows,
    System.object Handler
)
```

C++/CLI

```
Callout^ CreateCallout(
    & System.int NumberOfRows,
    & System.Object^ Handler
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumberOfRows
Number of rows in the callout
Handler
Pointer to the event handler for the callout ([ISwCalloutHandler](#))

Return Value

[Callout](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateCallout](#).

Example

[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

Remarks

This method allows you to create a callout independently of a selection. You can define the position of the callout using the [ICallout::Position](#) and [ICallout::SetTargetPoint](#).

To create a callout dependent on a selection, use [ISelectionMgr::CreateCallout2](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDecal Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateDecal Method (IModelDocExtension)

Creates a decal for this model.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDecal() As Decal
```

```
Dim instance As IModelDocExtension
Dim value As Decal

value = instance.CreateDecal()
```

C#

```
Decal CreateDecal()
```

C++/CLI

```
Decal^ CreateDecal();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Decal](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateDecal](#).

Example

[Add Decal \(VBA\)](#)
[Add Decal \(VB.NET\)](#)
[Add Decal \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IDecal Interface](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::DeleteAllDecals Method](#)
[IModelDocExtension::DeleteDecal Method](#)
[IModelDocExtension::GetDecal Method](#)
[IModelDocExtension::GetDecals Method](#)
[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::IGetDecals Method](#)
[IModelDocExtension::MoveDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateMassProperty Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateMassProperty Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::CreateMassProperty2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateMassProperty() As MassProperty
```

Visual Basic (Usage)

```
Dim instance As IModelDocExtension
Dim value As MassProperty

value = instance.CreateMassProperty()
```

C#

MassProperty CreateMassProperty()

C++/CLI

```
MassProperty^ CreateMassProperty();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IMassProperty](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateMassProperty](#).

Example

[Insert Coordinate System at Center of Mass \(VBA\)](#)
[Set Dimensions to Mid-Tolerance \(VBA\)](#)
[Get Mass Properties of Multibody Assembly Component \(VBA\)](#)
[Get Mass Properties of Multibody Assembly Component \(C#\)](#)
[Get Mass Properties of Multibody Assembly Component \(VB.NET\)](#)

Remarks

The IMassProperty object obtains mass property information about one or more solid bodies in the document from which the IMassProperty object is obtained.

Only use solid bodies for the mass property calculations. You can specify the coordinate system about which the moments is calculated using [IMassProperty::SetCoordinateSystem](#). If you do not use IMassProperty::SetCoordinateSystem, then the documents origin is the coordinate system.

The results of the mass property calculations vary based on whether or not [IMassProperty::AddBodies](#) or [IMassProperty::!AddBodies](#) is used.

If IMassProperty::AddBodies or IMassProperty::!AddBodies is...	Then...
Called and bodies are specified	These bodies can either be from a subset of the documents body list or from temporary bodies. NOTE: Each specified body should either come from the owning document or be a temporary body. If the body does not satisfy either case, then it is not used when calculating the mass properties.
Not called	Mass properties' calculations include all available bodies in the document. • Part. All of the solid bodies are included in the calculations. • Assembly. All of the bodies in all of the components are used in the calculations.

If the document from which the IMassProperty object came is an assembly, then any body from any of the child components can be used. To obtain the body, call [IComponent2::GetBodies2](#). Your application does not need to make a copy of the body or apply a transform to the body.

IModelDocExtension::CreateMassProperty gets the recalculated up-to-date values regardless of the [IModelDocExtension::NeedsRebuild](#) status.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetMassProperties2 Method \(\)](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

Creates a mass properties object.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function CreateMassProperty2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim value As System.Object

value = instance.CreateMassProperty2()
```

C#

```
System.object CreateMassProperty2()
```

C++/CLI

```
System.Object^ CreateMassProperty2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IMassProperty2](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateMassProperty2](#).

Example

[Get and Override Mass Properties \(VBA\)](#)
[Get and Override Mass Properties \(VB.NET\)](#)
[Get and Override Mass Properties \(C#\)](#)

Remarks

If this document is a...	Then this method returns...
Part	A mass properties object with information about one or more bodies. Before calling this method, call IModelDocExtension::SelectByID2 to pre-select the bodies. You can also specify more bodies after calling this method by setting IMassProperty2::SelectedItems .
Assembly	A mass properties object with information about one or more components. Before calling this method, call IModelDocExtension::SelectByID2 to pre-select the components. You can also specify more components after calling this method by setting IMassProperty2::SelectedItems . Bodies from multibody part components cannot be selected for mass properties calculations.
Model that does not apply (e.g., a part with surface bodies only)	Null or Nothing.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateMeasure Method (IModelDocExtension)

Creates a measure tool.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateMeasure() As Measure
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As Measure
```

```
value = instance.CreateMeasure()
```

C#

```
Measure CreateMeasure()
```

C++/CLI

```
Measure^ CreateMeasure();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Measure](#) tool

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateMeasure](#).

Example

[Measure Selected Entities \(C#\)](#)
[Measure Selected Entities \(VB.NET\)](#)
[Measure Selected Entities \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateOLEObject Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateOLEObject Method (IModelDocExtension)

Creates an OLE object on the active document.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateOLEObject(  
    ByVal Aspect As System.Integer, _  
    ByVal Position As System.Object, _  
    ByVal Buffer As System.Object, _  
    ByRef ErrorCode As System.Integer _  
) As SwOLEObject
```

```
Dim instance As IModelDocExtension
Dim Aspect As System.Integer
Dim Position As System.Object
Dim Buffer As System.Object
Dim ErrorCode As System.Integer
Dim value As SwOLEObject

value = instance.CreateOLEObject(Aspect, Position, Buffer, ErrorCode)
```

C#

```
SwOLEObject CreateOLEObject(
    System.int Aspect,
    System.object Position,
    System.object Buffer,
    out System.int ErrorCode
)
```

C++/CLI

```
SwOLEObject^ CreateOLEObject(
    & System.int Aspect,
    & System.Object^ Position,
    & System.Object^ Buffer,
    & [Out] System.int ErrorCode
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters*Aspect*

Viewing aspect of the OLE object as defined in the DVASPECT enumeration (see **Remarks**)

Position

Top-left and bottom-right positions (see **Remarks**)

Buffer

Data for the OLE object (see **Remarks**)

ErrorCode

0 if True or 1 if false

Return Value

[OLE object](#)

 Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateOLEObject](#).

 Remarks

Argument	Information
Aspect	Uses the DVASPECT enumeration, which has the following values: - DVASPECT_CONTENT = 1 - DVASPECT_THUMBNAIL = 2 - DVASPECT_ICON = 4 - DVASPECT_DOCPRINT = 8 See the MSDN documentation for details about the DVASPECT enumeration.
Position	Specify: - Sheet coordinates for drawings. - Screen pixel coordinates for parts and assemblies.
Buffer	See ISwOLEObject::Buffer or specify ISwOLEObject::IGetBuffer - or - Get the data from your own OLE object.

The data is in the format obtained from the Microsoft MFC object COleClientItem using the GetHGlobalFromLockBytes.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetOLEObjectCount Method](#)
[IModelDocExtension::GetOLEObjects Method](#)
[IModelDocExtension::InsertObjectFromFile Method](#)
[IModelDocExtension::ICreateOLEObject Method](#)
[IModelDocExtension::IGetOLEObjects Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateRenderMaterial Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateRenderMaterial Method (IModelDocExtension)

Creates an appearance for this model.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateRenderMaterial( _  
    ByVal PathName As System.String _  
) As RenderMaterial
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PathName As System.String  
Dim value As RenderMaterial  
  
value = instance.CreateRenderMaterial(PathName)
```

C#

```
RenderMaterial CreateRenderMaterial(  
    System.string PathName  
)
```

C++/CLI

```
RenderMaterial^ CreateRenderMaterial(  
& System.String^ PathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathName

Fully qualified or relative path and filename of the appearance to add to the model

Return Value

[Appearance](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateRenderMaterial](#).

Example

[Add and Delete Appearances from Specific Display States \(C#\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)

[Add and Delete Appearances from Specific Display States \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IRenderMaterial Interface](#)
[IModelDocExtension::GetRenderMaterials Method](#)
[IModelDocExtension::GetRenderMaterialsCount Method](#)
[IModelDocExtension::!GetRenderMaterials Method](#)
[IModelDocExtension::UpdateRenderMaterialsInSceneGraph Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateStackedBalloonOptions Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateStackedBalloonOptions Method (IModelDocExtension)

Creates an object that stores options for stacked balloons.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateStackedBalloonOptions() As StackedBalloonOptions
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As StackedBalloonOptions  
  
value = instance.CreateStackedBalloonOptions()
```

C#

```
StackedBalloonOptions CreateStackedBalloonOptions()
```

C++/CLI

```
StackedBalloonOptions^ CreateStackedBalloonOptions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IStackedBalloonOptions](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateStackedBalloonOptions](#).

Example

[Insert BOM Table and Stacked Balloon \(VBA\)](#)
[Insert BOM Table and Stacked Balloon \(VB.NET\)](#)
[Insert BOM Table and Stacked Balloon \(C#\)](#)

Remarks

To create a stack of balloons:

1. Select an item to create the first balloon of the stack.
2. Call this method to create an [IStackedBalloonOptions](#) object.
3. Set the properties on the IStackedBalloonOptions object.
4. Pass the IStackedBalloonOptions object in a call to [IModelDocExtension::InsertStackedBalloon2](#).
5. Select one or more items to add one or more balloons to the stack.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateBalloonOptions Method](#)
[IDrawingDoc::CreateAutoBalloonOptions Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateStructureSystem Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateStructureSystem Method (IModelDocExtension)

Creates a structure system feature using the specified primary and secondary member arrays.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateStructureSystem( _  
    ByVal PrimaryMembersData As System.Object, _  
    ByVal SecondaryMembersData As System.Object _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PrimaryMembersData As System.Object  
Dim SecondaryMembersData As System.Object  
Dim value As Feature  
  
value = instance.CreateStructureSystem(PrimaryMembersData, SecondaryMembersData)
```

C#

```
Feature CreateStructureSystem(  
    System.object PrimaryMembersData,  
    System.object SecondaryMembersData  
)
```

C++/CLI

```
Feature^ CreateStructureSystem(  
& System.Object^ PrimaryMembersData,  
& System.Object^ SecondaryMembersData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PrimaryMembersData

Array of primary [IStructureSystemMemberFeatureData](#) objects; null or Nothing if none

SecondaryMembersData

Array of secondary [IStructureSystemMemberFeatureData](#) objects; null or Nothing if none

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateStructureSystem](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

The feature returned is an [IStructureSystemFolder](#). Use [IFeature::GetSpecificFeature2](#) to get the specific interface.

See the IStructureSystemFolder Remarks.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateStructureSystemMemberData Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateStructureSystemMemberData Method (IModelDocExtension)

Creates the specified structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateStructureSystemMemberData( _  
    ByVal MemberType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim MemberType As System.Integer  
Dim value As System.Object  
  
value = instance.CreateStructureSystemMemberData(MemberType)
```

C#

```
System.Object CreateStructureSystemMemberData(  
    System.int MemberType  
)
```

C++/CLI

```
System.Object^ CreateStructureSystemMemberData(  
    & System.int MemberType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MemberType

Type of member as defined by [swStructureSystemMemberCreationType_e](#)

Return Value

[IStructureSystemMemberFeatureData](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateStructureSystemMemberData](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

See the [IStructureSystemFolder](#) Remarks.

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateTexture Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CreateTexture Method (IModelDocExtension)

Creates a texture.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateTexture( _  
    ByVal MatName As System.String, _  
    ByVal Scale As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal Blend As System.Boolean _  
) As Texture
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim MatName As System.String  
Dim Scale As System.Double  
Dim Angle As System.Double  
Dim Blend As System.Boolean  
Dim value As Texture  
  
value = instance.CreateTexture(MatName, Scale, Angle, Blend)
```

C#

```
Texture CreateTexture(  
    System.string MatName,  
    System.double Scale,  
    System.double Angle,  
    System.bool Blend  
)
```

C++/CLI

```
Texture^ CreateTexture(  
& System.String^ MatName,  
& System.double Scale,  
& System.double Angle,  
& System.bool Blend  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MatName

Name of the texture file

Scale

Value by which to adjust the granularity of the texture; value between 0.001 and 1000000.00

Angle

Value by which to adjust the rotation of the texture; value between 0.0 and 360.0

Blend

True to blend the part color with the texture color, false to not

Return Value

[ITexture](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CreateTexture](#).

Example

[Apply and Remove Texture To and From Model By Display State \(VB.NET\)](#)
[Apply and Remove Texture To and From Model By Display State \(C#\)](#)
[Apply and Remove Texture To and From Model By Display State \(VBA\)](#)
[Change Texture on Face in Specified Configuration \(VBA\)](#)
[Change Texture on Face in Specified Configuration \(VB.NET\)](#)
[Change Texture on Face in Specified Configuration \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::RemoveTexture2 Method](#)
[IModelDocExtension::SetTexture Method](#)
[IModelDocExtension::GetTexture Method](#)
[IModelDocExtension::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::SetTextureByDisplayState Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomPropertyBuilderInterface Property (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CustomPropertyBuilderInterface Property (IModelDocExtension)

Gets or sets the custom property builder template for this part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property CustomPropertyBuilderInterface( _  
    ByVal WeldmentTemplate As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim WeldmentTemplate As System.Boolean  
Dim value As System.String  
  
instance.CustomPropertyBuilderInterface(WeldmentTemplate) = value
```

```
value = instance.CustomPropertyBuilderTemplate(WeldmentTemplate)
```

C#

```
System.string CustomPropertyBuilderTemplate(  
    System.bool WeldmentTemplate  
) {get; set;}
```

C++/CLI

```
property System.String^ CustomPropertyBuilderTemplate {  
    System.String^ get(System.bool WeldmentTemplate);  
    void set (System.bool WeldmentTemplate, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WeldmentTemplate
True if a weldment part, false if not (see **Remarks**)

Property Value

File name of the custom property builder template (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CustomPropertyBuilderTemplate](#).

Example

```
swModDocExt.CustomPropertyBuilderTemplate(False) = "template.prtprp"
```

```
swModDocExt.CustomPropertyBuilderTemplate(True) = "templateWeld2.wldprp"
```

Remarks

If WeldmentTemplate is:

- True, then this property gets or sets *.**wldprp**.
- False, then this property gets or sets *.**prtprp**.

All custom property builder templates are stored in the file location specified in **Tools > Options > File Locations > Custom Property Files**.

This property corresponds to the setting in the Template Options dialog that appears when you click on the button next to More Properties in the Custom Properties task pane. When you create a custom property layout, a template is created. The button is activated for parts and weldments only after a custom properties tab layout is created. The weldment custom property template (*.**wldprp**) can be created or modified only if a cut list item is selected in the Cut list folder.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomPropertyManager Property (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : CustomPropertyManager Property (IModelDocExtension)

Gets the custom properties for this document or configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CustomPropertyManager( _  
    ByVal ConfigName As System.String _
```

) As CustomPropertyManager

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim ConfigName As System.String  
Dim value As CustomPropertyManager  
  
value = instance.CustomPropertyManager(ConfigName)
```

C#

```
CustomPropertyManager CustomPropertyManager(  
    System.string ConfigName  
) {get;}
```

C++/CLI

```
property CustomPropertyManager^ CustomPropertyManager {  
    CustomPropertyManager^ get(System.String^ ConfigName);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName
Name of configuration

Property Value

[ICustomPropertyManager](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::CustomPropertyManager](#).

Example

[Get Custom Properties of Referenced Part \(C#\)](#)
[Get Custom Properties of Referenced Part \(VB.NET\)](#)
[Get Custom Properties of Referenced Part \(VBA\)](#)

Remarks

File custom information is stored in the document file. It can be:

- General to the file, in which case there is a single value whatever the model's configuration
 - or -
 - Configuration-specific, in which case a different value may be set for each configuration in the model
- To access a general custom information value, set the configuration argument to an empty string. To get a document-level property, pass an empty string ("") to the configuration argument.

As per Microsoft recommendations for OLE support, the file summary information for SOLIDWORKS documents is written as an OLE property set into a stream named "005Summary Information" off the root storage of the SOLIDWORKS document's compound file.

NOTE: MFC does not currently provide classes that manage summary information. However, the DRAWCLI application shipped with Visual C++ includes a sample implementation, in the form of the class CSummInfo, that you can use as an example when implementing your own. This class is used by the document class CDrawDoc. DRAWCLI also includes property pages for displaying and modifying Summary Information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IConfiguration::CustomPropertyManager Property](#)
[IFeature::CustomPropertyManager Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DeActivateFeatureMgrViewx64 Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeActivateFeatureMgrViewx64 Method (IModelDocExtension)

Deactivates a tab in the FeatureManager design tree view in x64 applications.

.NET Syntax

Visual Basic (Declaration)

```
Function DeActivateFeatureMgrViewx64( _  
    ByRef AppView As System.Long _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim AppView As System.Long  
Dim value As System.Boolean  
  
value = instance.DeActivateFeatureMgrViewx64(AppView)
```

C#

```
System.bool DeActivateFeatureMgrViewx64(  
    ref System.long AppView  
)
```

C++/CLI

```
System.bool DeActivateFeatureMgrViewx64(  
& System.int64% AppView  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppView
Pointer to the FeatureManager design tree view to deactivate

Return Value

True if view deactivated, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeActivateFeatureMgrViewx64](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::ActivateFeatureMgrViewx64 Method \(\)](#)
[IModelDocExtension::AddFeatureMgrView3x64 Method \(\)](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteAllDecals Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteAllDecals Method (IModelDocExtension)

Deletes all decals on this model.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteAllDecals() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Boolean  
  
value = instance.DeleteAllDecals()
```

C#

```
System.bool DeleteAllDecals()
```

C++/CLI

```
System.bool DeleteAllDecals();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if all decals on the model are deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeleteAllDecals](#).

Example

[Delete All Decals \(VBA\)](#)
[Delete All Decals \(VB.NET\)](#)
[Delete All Decals \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IDecal Interface](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::CreateDecal Method](#)
[IModelDocExtension::DeleteDecal Method](#)
[IModelDocExtension::GetDecal Method](#)
[IModelDocExtension::GetDecals Method](#)
[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::IGetDecals Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::MoveDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteAttachment Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteAttachment Method (IModelDocExtension)

Deletes the specified file in the Attachments folder in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteAttachment( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim FileName As System.String
Dim value As System.Boolean

value = instance.DeleteAttachment(FileName)
```

C#

```
System.bool DeleteAttachment(
    System.string FileName
)
```

C++/CLI

```
System.bool DeleteAttachment(
    & System.String^ FileName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Name of the file to delete from the Attachments folder in the FeatureManager design tree

Return Value

True if the file is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeleteAttachment](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetAttachmentCount Method](#)
[IModelDocExtension::GetAttachments Method](#)
[IModelDocExtension::IGetAttachments Method](#)
[IModelDocExtension::InsertAttachment Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteDecal Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteDecal Method (IModelDocExtension)

Removes the specified decal from this model.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteDecal( _
    ByVal DecalID As System.Integer, _
    ByVal BReassignIdsAndInvalidate As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



Copy Code

```

Dim instance As IModelDocExtension
Dim DecalID As System.Integer
Dim BReassignIdsAndInvalidate As System.Boolean
Dim value As System.Boolean

value = instance.DeleteDecal(DecalID, BReassignIdsAndInvalidate)

```

C#

```

System.bool DeleteDecal(
    System.int DecalID,
    System.bool BReassignIdsAndInvalidate
)

```

C++/CLI

```

System.bool DeleteDecal(
    & System.int DecalID,
    & System.bool BReassignIdsAndInvalidate
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DecalID

[Decal ID](#)

BReassignIdsAndInvalidate

True if the decal IDs are reassigned and this decal ID is invalidated, false if not

Return Value

True if the decal is removed from the model, false if not

Visual Basic for Applications (VBA) Syntax

See [IModelDocExtension::DeleteDecal](#).

Example

[Delete Decal \(VBA\)](#)

[Delete Decal \(VB.NET\)](#)

[Delete Decal \(C#\)](#)

Remarks

By default, decal IDs are persistent, which means if three decals (IDs 1, 2, and 3) were applied to the model, and you removed decal ID 2, then the remaining decal IDs are 1 and 3. However, if you set BReassignIdsAndInvalidate to true, then decal ID 2 is invalidated and decal ID 3 becomes decal ID 2.

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IDecal Interface](#)

[IModelDocExtension::AddDecal Method](#)

[IModelDocExtension::CreateDecal Method](#)

[IModelDocExtension::DeleteAllDecals Method](#)

[IModelDocExtension::GetDecal Method](#)

[IModelDocExtension::GetDecals Method](#)

[IModelDocExtension::GetDecalsCount Method](#)

[IModelDocExtension::HideDecal Method](#)

[IModelDocExtension::IGetDecals Method](#)

[IModelDocExtension::MoveDecal Method](#)

[IModelDocExtension::ReverseDecalsOrder Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteDisplayStateSpecificRenderMaterial Method (IModelDocExtension)

Deletes the specified appearances, using the IDs of the appearances, from the active configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteDisplayStateSpecificRenderMaterial( _  
    ByVal PWMaterialId1 As System.Object, _  
    ByVal PWMaterialId2 As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PWMaterialId1 As System.Object  
Dim PWMaterialId2 As System.Object  
Dim value As System.Boolean
```

```
value = instance.DeleteDisplayStateSpecificRenderMaterial(PWMaterialId1, PWMaterialId2)
```

C#

```
System.bool DeleteDisplayStateSpecificRenderMaterial(  
    System.object PWMaterialId1,  
    System.object PWMaterialId2  
)
```

C++/CLI

```
System.bool DeleteDisplayStateSpecificRenderMaterial(  
& System.Object^ PWMaterialId1,  
& System.Object^ PWMaterialId2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PWMaterialId1

Array of the first IDs of the appearances to delete

PWMaterialId2

Array of the second IDs of the appearance to delete

Return Value

True if the appearances are deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [IModelDocExtension.DeleteDisplayStateSpecificRenderMaterial](#).

Example

[Add and Delete Appearances from Specific Display States \(C#\)](#)

[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)

[Add and Delete Appearances from Specific Display States \(VBA\)](#)

Remarks

Call [IRenderMaterial.GetMaterialIds](#) to the get IDs of the appearances added to the model, then call [IModelDocExtension.DeleteDisplayStateSpecificRenderMaterial](#) to delete the appearances

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IModelDocExtension.AddDisplayStateSpecificRenderMaterial Method](#)

[IModelDocExtension.AddDisplayStateSpecificRenderMaterial Method](#)

[IModelDocExtension.DeleteDisplayStateSpecificRenderMaterial Method](#)

[IRenderMaterial Interface](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteDraftingStandard Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteDraftingStandard Method (IModelDocExtension)

Delete the current custom drafting standard.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteDraftingStandard() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Boolean
```

```
value = instance.DeleteDraftingStandard()
```

C#

```
System.bool DeleteDraftingStandard()
```

C++/CLI

```
System.bool DeleteDraftingStandard();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the current custom drafting standard is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeleteDraftingStandard](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CopyDraftingStandard Method](#)
[IModelDocExtension::GetDraftingStandardNames Method](#)
[IModelDocExtension::LoadDraftingStandard Method](#)
[IModelDocExtension::RenameDraftingStandard Method](#)
[IModelDocExtension::SaveDraftingStandard Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteFeatureMgrViewx64 Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteFeatureMgrViewx64 Method (IModelDocExtension)

Removes the specified tab in the FeatureManager design tree in 64-bit applications.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteFeatureMgrViewx64( _  
    ByRef AppView As System.Long _
```

)

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim AppView As System.Long  
  
instance.DeleteFeatureMgrViewx64(AppView)
```

C#

```
void DeleteFeatureMgrViewx64(  
    ref System.long AppView  
)
```

C++/CLI

```
void DeleteFeatureMgrViewx64(  
& System.int64% AppView  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppView
View handle of the FeatureManager design tree view to delete

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeleteFeatureMgrViewx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.
On the appropriate notification, you can call this method to clean up and delete your FeatureManager design tree view.
Use this method with [IModelViewManager::CreateFeatureMgrView2](#) or [IModelDoc2::AddFeatureMgrView3](#).

If you created the FeatureManager design tree view using...

Then...

IModelViewManager::CreateFeatureMgrView2

Calling IModelDocExtension::DeleteFeatureMgrViewx64 destroys the CView object used for the FeatureManager design tree view.

IModelDoc2::AddFeatureMgrView3

Your application allocated the CView object and calling IModelDocExtension::DeleteFeatureMgrViewx64 does not destroy the CView object. In this case, you must destroy the CView object using the appropriate destructor. Never use the delete operator directly on the CView object. Always use one of the appropriate MFC view destructors.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IFeatMgrView::GetFeatMgrViewWndx64 Method](#)
[IModelViewManager::GetFeatureMgrViewHWndx64 Method](#)
[IModelDoc2::DeleteFeatureMgrView Method](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteRenderMaterial Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteRenderMaterial Method (IModelDocExtension)

Not supported in SOLIDWORKS 2011 and later. Superseded by [IModelDocExtension::DeleteDisplayStateSpecificRenderMaterial](#) and [IModelDocExtension::!DeleteDisplayStateSpecificRenderMaterial](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function DeleteRenderMaterial( _  
    ByVal PwMaterialId As System.Integer, _  
    ByVal BReassignIdsAndInvalidate As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PwMaterialId As System.Integer  
Dim BReassignIdsAndInvalidate As System.Boolean  
Dim value As System.Boolean  
  
value = instance.DeleteRenderMaterial(PwMaterialId, BReassignIdsAndInvalidate)
```

C#

```
System.bool DeleteRenderMaterial(  
    System.int PwMaterialId,  
    System.bool BReassignIdsAndInvalidate  
)
```

C++/CLI

```
System.bool DeleteRenderMaterial(  
& System.int PwMaterialId,  
& System.bool BReassignIdsAndInvalidate  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PwMaterialId
Appearance ID
BReassignIdsAndInvalidate
True if the appearance IDs are reassigned and this appearance ID is invalidated, false if not

Return Value

True if the appearance is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DeleteRenderMaterial](#).

Remarks

By default, appearance IDs are persistent, which means if three appearances (IDs 1, 2, and 3) were applied to the model, and you removed appearance ID 2, then the remaining appearance IDs are 1 and 3. However, if you set [BReassignIdsAndInvalidate](#) to true, then appearance ID 2 is invalidated and appearance ID 3 becomes appearance ID 2.

To get the IDs of all of the appearances applied to this model document, call [IModelDocExtension::GetRenderMaterialsCount](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

Deletes the scene applied to this model.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteScene()
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
instance.DeleteScene()
```

C#

```
void DeleteScene()
```

C++/CLI

```
void DeleteScene();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension.DeleteScene](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension.InsertScene Method](#)
[IConfiguration.GetScene Method \(\)](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteSearchData Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteSearchData Method (IModelDocExtension)

Deletes the specified SOLIDWORKS Search third-party keywords from the model document.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteSearchData( _  
    ByVal AppName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim AppName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteSearchData(AppName)
```

C#

```
System.bool DeleteSearchData(  
    System.string AppName
```

```
)
```

C++/CLI

```
System.bool DeleteSearchData(  
& System.String^ AppName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppName

Application name whose keywords to delete

Return Value

True if the keywords for AppName are deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension.DeleteSearchData](#).

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IModelDocExtension::AddOrUpdateSearchData Method](#)

[IModelDocExtension::GetSearchData Method](#)

[IModelDocExtension::GetSearchDataCount Method](#)

[IModelDocExtension::IGetSearchData Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteSelection2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DeleteSelection2 Method (IModelDocExtension)

Deletes the selected items, with the option to delete absorbed features, child features, or both.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteSelection2( _  
    ByVal DeleteOptions As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDocExtension  
Dim DeleteOptions As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeleteSelection2(DeleteOptions)
```

C#

```
System.bool DeleteSelection2(  
    System.int DeleteOptions  
)
```

C++/CLI

```
System.bool DeleteSelection2(  
& System.int DeleteOptions  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DeleteOptions

Options as defined in [swDeleteSelectionOptions_e](#)

Return Value

True if the selected item is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension.DeleteSelection2](#).

Example

[Create Extruded Thin Feature \(VBA\)](#)

[Delete Selected Feature \(VBA\)](#)

[Undo Feature and Fire Undo Post-Notify Event \(VBA\)](#)

[Undo Feature and Fire Undo Post Notify Event \(VB.NET\)](#)

[Undo Feature and Fire Undo Post-Notify Event \(C#\)](#)

Remarks

This method does not ask the user to confirm the deletion.

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IAssemblyDoc.DeleteSelections Method \(\)](#)

[IModel2.EditDelete Method \(\)](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

DimXpertManager Property (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DimXpertManager Property (IModelDocExtension)

Gets the DimXpert schema for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DimXpertManager( _  
    ByVal Configuration As System.String, _  
    ByVal CreateSchema As System.Boolean _  
) As DimXpertManager
```

Visual Basic (Usage)

```
Dim instance As IModelDocExtension  
Dim Configuration As System.String  
Dim CreateSchema As System.Boolean  
Dim value As DimXpertManager
```

```
value = instance.DimXpertManager(Configuration, CreateSchema)
```

C#

```
DimXpertManager DimXpertManager(  
    System.string Configuration,  
    System.bool CreateSchema  
) {get;}
```

C++/CLI



```
property DimXpertManager^ DimXpertManager {
    DimXpertManager^ get(System.String^ Configuration, System.bool CreateSchema);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Configuration

Name of the configuration for which to retrieve the DimXpert schema

CreateSchema

True to create DimXpert schema if it does not already exist; false otherwise

Property Value

[IDimXpertManager](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DimXpertManager](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

Remarks

This interface retrieves the DimXpert schema information for opened parts which can be accessed in SOLIDWORKS via either the DimXpertManager tab of the Management Panel or the DimXpert tab of the CommandManager.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayMode Property (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DisplayMode Property (IModelDocExtension)

Gets and sets the display modes for the specified display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayMode( _
    ByVal Setting As DisplayStateSetting _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim Setting As DisplayStateSetting
Dim value As System.Object
```

```
instance.DisplayMode(Setting) = value
```

```
value = instance.DisplayMode(Setting)
```

C#

```
System.object DisplayMode(
    DisplayStateSetting Setting
```

```
) {get; set;}
```

C++/CLI

```
property System.Object^ DisplayMode {  
    System.Object^ get(DisplayStateSetting^ Setting);  
    void set (DisplayStateSetting^ Setting, System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Setting
[IDisplayStateSetting](#)

Property Value

One-dimensional array of display modes as defined in [swDisplayMode_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DisplayMode](#).

Example

[Get Display State Settings \(VBA\)](#)
[Get Display State Settings \(VB.NET\)](#)
[Get Display State Settings \(C#\)](#)

Remarks

Before calling this method:

1. Call [IModelDocExtension::GetDisplayStateSetting](#) to obtain an [IDisplayStateSetting](#) object.
2. Call [IDisplayStateSetting::Names](#) or [IDisplayStateSetting::ISetNames](#) to specify the display states.
3. Call [IDisplayStateSetting::Entities](#) or [IDisplayStateSetting::ISetEntities](#) to specify the components.
4. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
5. Specify the *Setting* parameter using the [IDisplayStateSetting](#) object.

Each display mode in the array returned by this method maps to a component in a display state. The size of the returned array is ([IDisplayStateSetting::GetEntityCount](#) X [IDisplayStateSetting::GetNameCount](#)).

The returned array stores display modes (DM) for N components in M display states as follows:

Component1 DisplayState1 DM, Component1 DisplayState2 DM, ..., Component1 DisplayStateM DM,
Component2 DisplayState1 DM, Component2 DisplayState2 DM, ..., Component2 DisplayStateM DM,
...,
ComponentN DisplayState1 DM, ComponentN DisplayState2 DM, ..., ComponentN DisplayStateM DM

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::DisplayStateSpecMaterialPropertyValues Property](#)
[IModelDocExtension::Transparency Property](#)
[IModelDocExtension::Visibility Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayStateSpecMaterialPropertyValues Property (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DisplayStateSpecMaterialPropertyValues Property (IModelDocExtension)

Gets and sets the appearance settings for the specified display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayStateSpecMaterialPropertyValues( _
    ByVal Setting As DisplayStateSetting _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim Setting As DisplayStateSetting
Dim value As System.Object

instance.DisplayStateSpecMaterialPropertyValues(Setting) = value

value = instance.DisplayStateSpecMaterialPropertyValues(Setting)
```

C#

```
System.Object DisplayStateSpecMaterialPropertyValues(
    DisplayStateSetting Setting
) {get; set;}
```

C++/CLI

```
property System.Object^ DisplayStateSpecMaterialPropertyValues {
    System.Object^ get(DisplayStateSetting^ Setting);
    void set (DisplayStateSetting^ Setting, System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Setting
[IDisplayStateSetting](#) (see **Remarks**)

Property Value

One-dimensional array of [IAppearanceSettings](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

Example

[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

Remarks

Before using this method to get or set appearance settings:

1. Call [IModelDocExtension::GetDisplayStateSetting](#) to obtain an [IDisplayStateSetting](#) object.
2. Call [IDisplayStateSetting::Names](#) or [IDisplayStateSetting::SetNames](#) to specify the display states.
3. Call [IDisplayStateSetting::Entities](#) or [IDisplayStateSetting::SetEntities](#) to specify the components.
4. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
5. Specify the Setting parameter using the [IDisplayStateSetting](#) object.

Each [IAppearanceSetting](#) in the array returned by this method maps to a component in a display state. The size of the returned array is ([IDisplayStateSetting::GetEntityCount](#) * [IDisplayStateSetting::GetNameCount](#)).

The returned array stores appearance settings (AS) for N components in M display states as follows:

```
Component1 DisplayState1 AS, Component1 DisplayState2 AS, ..., Component1 DisplayStateM AS,
Component2 DisplayState1 AS, Component2 DisplayState2 AS, ..., Component2 DisplayStateM AS,
...
ComponentN DisplayState1 AS, ComponentN DisplayState2 AS, ..., ComponentN DisplayStateM AS
```

Before using this method to set appearance settings:

1. Perform steps 1-5 as described above.
2. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
3. Set the properties in the [IAppearanceSetting](#) object for the component in the display state.
4. Repeat steps 2 and 3 for each component in each display state.
5. Create an array of the [IAppearanceSetting](#) objects in the order described above.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::DisplayMode Property](#)
[IModelDocExtension::Transparency Property](#)
[IModelDocExtension::Visibility Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayTitle Property (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : DisplayTitle Property (IModelDocExtension)

Gets and sets this model's title to display in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayTitle As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.String
```

```
instance.DisplayTitle = value
```

```
value = instance.DisplayTitle
```

C#

```
System.string DisplayTitle {get; set;}
```

C++/CLI

```
property System.String^ DisplayTitle {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Display title; empty string to display the model's file name

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::DisplayTitle](#).

Remarks

This property works like the **FeatureManager design tree > RMB > Rename tree item**.

To get the display title of lightweight assembly components, use [IComponent2::DisplayTitle](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[DAssemblyDocEvents_RenameDisplayTitleNotifyEventHandler Delegate \(IModelDocExtension\)](#)
[DDrawingDocEvents_RenameDisplayTitleNotifyEventHandler Delegate \(IModelDocExtension\)](#)
[DPartDocEvents_RenameDisplayTitleNotifyEventHandler Delegate \(IModelDocExtension\)](#)

Availability

Document Property (IModelDocExtension)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : Document Property (IModelDocExtension)

Gets the model document.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Document As ModelDoc2

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim value As ModelDoc2
```

```
value = instance.Document
```

C#

```
ModelDoc2 Document {get;}
```

C++/CLI

```
property ModelDoc2^ Document {
    ModelDoc2^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Document](#) to get

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::Document](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[ISldWorks::ActivateDoc2 Method](#)
[ISldWorks::ActiveDoc Property](#)
[ISldWorks::IActiveDoc2 Property](#)
[ISldWorks::GetFirstDocument Method](#)
[ISldWorks::GetFirstDocument2 Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

EditBalloonProperties Method (IModelDocExtension)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : EditBalloonProperties Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::EditBalloonProperties2](#).

.NET Syntax

Visual Basic (Declaration)

```

Function EditBalloonProperties( _
    ByVal Style As System.Integer, _
    ByVal Size As System.Integer, _
    ByVal UpperTextStyle As System.Integer, _
    ByVal UpperText As System.String, _
    ByVal LowerTextStyle As System.Integer, _
    ByVal LowerText As System.String, _
    ByVal CustomSize As System.Double, _
    ByVal ShowQuantity As System.Boolean, _
    ByVal QuantityPlacement As System.Short, _
    ByVal QuantityDenotationText As System.String _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IModelDocExtension
Dim Style As System.Integer
Dim Size As System.Integer
Dim UpperTextStyle As System.Integer
Dim UpperText As System.String
Dim LowerTextStyle As System.Integer
Dim LowerText As System.String
Dim CustomSize As System.Double
Dim ShowQuantity As System.Boolean
Dim QuantityPlacement As System.Short
Dim QuantityDenotationText As System.String
Dim value As System.Object

```

```

value = instance.EditBalloonProperties(Style, Size, UpperTextStyle, UpperText, LowerTextStyle,
LowerText, CustomSize, ShowQuantity, QuantityPlacement, QuantityDenotationText)

```

C#

```

System.object EditBalloonProperties(
    System.int Style,
    System.int Size,
    System.int UpperTextStyle,
    System.string UpperText,
    System.int LowerTextStyle,
    System.string LowerText,
    System.double CustomSize,
    System.bool ShowQuantity,
    System.short QuantityPlacement,
    System.string QuantityDenotationText
)

```

C++/CLI

```

System.Object^ EditBalloonProperties(
    & System.int Style,
    & System.int Size,
    & System.int UpperTextStyle,
    & System.String^ UpperText,
    & System.int LowerTextStyle,
    & System.String^ LowerText,
    & System.double CustomSize,
    & System.bool ShowQuantity,
    & System.short QuantityPlacement,
    & System.String^ QuantityDenotationText
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style of balloon as defined in [swBalloonStyle_e](#)

Size

Balloon size as defined in [swBalloonFit_e](#)

UpperTextStyle

Upper text style as defined in [swBalloonTextContent_e](#)

UpperText

Text for the upper text in the balloon

LowerTextStyle

Lower text style as defined in [swBalloonTextContent](#) e; valid for balloons only and Style must be set to swBS_SplitCirc

LowerText

Text for the lower text in the balloon; valid for balloons only and Style must be set to swBS_SplitCirc

CustomSize

User-defined size of the balloon; Size must be set to swBF_UserDef

ShowQuantity

True to show quantity, false to not

QuantityPlacement

Placement of quantity value:

- 0 = Left
- 1 = Right
- 2 = Top
- 3 = Bottom

QuantityDenotationText

Denotation text for quantity

Return Value

[Note](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::EditBalloonProperties](#).

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[INote::SetBalloon Method](#)

[INote::SetBomBalloonText Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditBalloonProperties2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : EditBalloonProperties2 Method (IModelDocExtension)

Edits the selected balloon's properties.

.NET Syntax

Visual Basic (Declaration)

```
Function EditBalloonProperties2( _  
    ByVal Style As System.Integer, _  
    ByVal Size As System.Integer, _  
    ByVal UpperTextStyle As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextStyle As System.Integer, _  
    ByVal LowerText As System.String, _  
    ByVal CustomSize As System.Double, _  
    ByVal ShowQuantity As System.Boolean, _  
    ByVal QuantityPlacement As System.Short, _  
    ByVal QuantityDenotationText As System.String, _  
    ByVal QuantityDistance As System.Double _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Style As System.Integer  
Dim Size As System.Integer  
Dim UpperTextStyle As System.Integer  
Dim UpperText As System.String  
Dim LowerTextStyle As System.Integer
```

```

Dim LowerText As System.String
Dim CustomSize As System.Double
Dim ShowQuantity As System.Boolean
Dim QuantityPlacement As System.Short
Dim QuantityDenotationText As System.String
Dim QuantityDistance As System.Double
Dim value As System.Object

```

```

value = instance.EditBalloonProperties2(Style, Size, UpperTextStyle, UpperText, LowerTextStyle,
LowerText, CustomSize, ShowQuantity, QuantityPlacement, QuantityDenotationText, QuantityDistance)

```

C#

```

System.Object EditBalloonProperties2(
    System.Int Style,
    System.Int Size,
    System.Int UpperTextStyle,
    System.String UpperText,
    System.Int LowerTextStyle,
    System.String LowerText,
    System.Double CustomSize,
    System.Bool ShowQuantity,
    System.Short QuantityPlacement,
    System.String QuantityDenotationText,
    System.Double QuantityDistance
)

```

C++/CLI

```

System.Object^ EditBalloonProperties2(
    & System.Int Style,
    & System.Int Size,
    & System.Int UpperTextStyle,
    & System.String^ UpperText,
    & System.Int LowerTextStyle,
    & System.String^ LowerText,
    & System.Double CustomSize,
    & System.Bool ShowQuantity,
    & System.Short QuantityPlacement,
    & System.String^ QuantityDenotationText,
    & System.Double QuantityDistance
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style of balloon as defined in [swBalloonStyle_e](#)

Size

Balloon size as defined in [swBalloonFit_e](#)

UpperTextStyle

Balloon text style as defined in [swBalloonTextContent_e](#)

UpperText

Text for the balloon; valid only if UpperTextStyle is one of the following:

- [swBalloonTextContent_e.swBalloonTextCustom](#)
- [swBalloonTextContent_e.swBalloonTextCustomProperties](#)
- [swBalloonTextContent_e.swBalloonTextCutListProperties](#)

LowerTextStyle

Lower text style as defined in [swBalloonTextContent_e](#); valid only if Style is [swBalloonStyle_e.swBS_SplitCirc](#)

LowerText

Text for the lower text in the balloon; valid only if Style is [swBalloonStyle_e.swBS_SplitCirc](#) and LowerTextStyle is one of the following:

- [swBalloonTextContent_e.swBalloonTextCustom](#)
- [swBalloonTextContent_e.swBalloonTextCustomProperties](#)
- [swBalloonTextContent_e.swBalloonTextCutListProperties](#)

CustomSize

User-defined size of the balloon; valid only if Size is [swBalloonFit_e.swBF_UserDef](#)

ShowQuantity

True to show quantity, false to not

QuantityPlacement

Placement of quantity value as defined in [swBalloonQuantityPlacement_e](#); valid only if ShowQuantity is true

QuantityDenotationText

Denotation text for quantity; valid only if ShowQuantity is true

QuantityDistance

Distance between the balloon and the quantity; valid only if ShowQuantity is true

Return Value

[Note](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::EditBalloonProperties2](#).

Example

[Edit Balloon \(VBA\)](#)
[Edit Balloon \(VB.NET\)](#)
[Edit Balloon \(C#\)](#)

Remarks

Before calling this method, select the balloon annotation whose properties you want to edit.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[INote::SetBalloon Method \(\)](#)
[INote::SetBomBalloonText Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditDimensionProperties Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : EditDimensionProperties Method (IModelDocExtension)

Edits the selected dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function EditDimensionProperties( _  
    ByVal TolType As System.Integer, _  
    ByVal TolMax As System.Double, _  
    ByVal TolMin As System.Double, _  
    ByVal TolMaxFit As System.String, _  
    ByVal TolMinFit As System.String, _  
    ByVal UseDocPrec As System.Boolean, _  
    ByVal Precision As System.Integer, _  
    ByVal ArrowsIn As System.Integer, _  
    ByVal UseDocArrows As System.Boolean, _  
    ByVal Arrow1 As System.Integer, _  
    ByVal Arrow2 As System.Integer, _  
    ByVal PrefixText As System.String, _  
    ByVal SuffixText As System.String, _  
    ByVal ShowValue As System.Boolean, _  
    ByVal CalloutText1 As System.String, _  
    ByVal CalloutText2 As System.String, _  
    ByVal DimensionLowerText As System.String, _  
    ByVal CenterText As System.Boolean, _  
    ByVal ConfigOption As System.Integer, _  
    ByVal ConfigNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IModelDocExtension  
Dim TolType As System.Integer  
Dim TolMax As System.Double  
Dim TolMin As System.Double  
Dim TolMaxFit As System.String  
Dim TolMinFit As System.String
```



```

Dim UseDocPrec As System.Boolean
Dim Precision As System.Integer
Dim ArrowsIn As System.Integer
Dim UseDocArrows As System.Boolean
Dim Arrow1 As System.Integer
Dim Arrow2 As System.Integer
Dim PrefixText As System.String
Dim SuffixText As System.String
Dim ShowValue As System.Boolean
Dim CalloutText1 As System.String
Dim CalloutText2 As System.String
Dim DimensionLowerText As System.String
Dim CenterText As System.Boolean
Dim ConfigOption As System.Integer
Dim ConfigNames As System.Object
Dim value As System.Boolean

```

```

value = instance.EditDimensionProperties(TolType, TolMax, TolMin, TolMaxFit, TolMinFit,
UseDocPrec, Precision, ArrowsIn, UseDocArrows, Arrow1, Arrow2, PrefixText, SuffixText, ShowValue,
CalloutText1, CalloutText2, DimensionLowerText, CenterText, ConfigOption, ConfigNames)

```

C#

```

System.bool EditDimensionProperties(
    System.int TolType,
    System.double TolMax,
    System.double TolMin,
    System.string TolMaxFit,
    System.string TolMinFit,
    System.bool UseDocPrec,
    System.int Precision,
    System.int ArrowsIn,
    System.bool UseDocArrows,
    System.int Arrow1,
    System.int Arrow2,
    System.string PrefixText,
    System.string SuffixText,
    System.bool ShowValue,
    System.string CalloutText1,
    System.string CalloutText2,
    System.string DimensionLowerText,
    System.bool CenterText,
    System.int ConfigOption,
    System.object ConfigNames
)

```

C++/CLI

```

System.bool EditDimensionProperties(
& System.int TolType,
& System.double TolMax,
& System.double TolMin,
& System.String^ TolMaxFit,
& System.String^ TolMinFit,
& System.bool UseDocPrec,
& System.int Precision,
& System.int ArrowsIn,
& System.bool UseDocArrows,
& System.int Arrow1,
& System.int Arrow2,
& System.String^ PrefixText,
& System.String^ SuffixText,
& System.bool ShowValue,
& System.String^ CalloutText1,
& System.String^ CalloutText2,
& System.String^ DimensionLowerText,
& System.bool CenterText,
& System.int ConfigOption,
& System.Object^ ConfigNames
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType

Type of tolerance as defined in [swTolType_e](#)

TolMax

Maximum value for the tolerance

TolMin

Minimum value for the tolerance

TolMaxFit

Text for the maximum FIT value when using a fit tolerance type

TolMinFit

Text for the minimum FIT value when using a fit tolerance type

UseDocPrec

True to use the document's precision value, false to use value specified for Precision

Precision

Precision to use for this dimension if UseDocPrec is false

ArrowsIn

Arrow direction as defined in [swDimensionArrowsSide_e](#)

UseDocArrows

True to use the document's arrow types, false to use values specified for Arrow1 and Arrow2

Arrow1

Type of arrow to use for the first arrow of this dimension as defined in [swArrowStyle_e](#) if UseDocArrows is false

Arrow2

Type of arrow to use for the second arrow of this dimension as defined in [swArrowStyle_e](#) if UseDocArrows is false

PrefixText

Text to display before the dimension, but on the same line (see **Remarks**)

SuffixText

Text to display after the dimension, but on the same line (see **Remarks**)

ShowValue

True to display the value of the dimension in the user interface, false to not

CalloutText1

Callout text to display above the dimension

CalloutText2

Callout text to display below the dimension

DimensionLowerText

Text to display below the dimension line; valid for [display dimensions](#) in drawings only

CenterText

True to center the text in the dimension, false to not

ConfigOption

Configuration option as defined in [swInConfigurationOpts_e](#)

ConfigNames

Names of the configurations to which to apply these edits (see **Remarks**)

Return Value

True if the dimension is modified, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::EditDimensionProperties](#).

Example

[Modify Dimension Properties \(C#\)](#)
[Modify Dimension Properties \(VB.NET\)](#)
[Modify Dimension Properties \(VBA\)](#)

Remarks

PrefixText and SuffixText must not include "/r/n".

This method:

- always changes the dimension's parameters in the active configuration. For example, if you specify swInConfigurationOpts_e.swSpecifyConfiguration for ConfigOption and do not specify the name of the active configuration in ConfigNames, then the dimension parameters in the active configuration are affected.
- does not support [hole callouts](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::!EditDimensionProperties Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditRebuildAll Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : EditRebuildAll Method (IModelDocExtension)

Rebuilds only those features that need to be rebuilt in all configurations without activating each configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function EditRebuildAll() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Boolean
```

```
value = instance.EditRebuildAll()
```

C#

```
System.bool EditRebuildAll()
```

C++/CLI

```
System.bool EditRebuildAll();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if only those features that need to be rebuilt are rebuilt in all configurations without activating each configuration, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::EditRebuildAll](#).

Example

[Rebuild All Configurations Without Activating Each Configuration \(C#\)](#)
[Rebuild All Configurations Without Activating Each Configuration \(VB.NET\)](#)
[Rebuild All Configurations Without Activating Each Configuration \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::ForceRebuildAll Method \(\)](#)
[IModelDocExtension::Rebuild Method \(\)](#)
[IModelDocExtension::NeedsRebuild2 Property \(\)](#)
[IModelDoc2::EditRebuild3 Method \(\)](#)
[IModelDoc2::ForceRebuild3 Method \(\)](#)
[IConfiguration::NeedsRebuild Property \(\)](#)

[IConfiguration::AddRebuildSaveMark Property \(\)](#)
[IConfigurationManager::AddRebuildSaveMark Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureManagerFilterString Property (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : FeatureManagerFilterString Property (IModelDocExtension)

Gets or sets the string in the FeatureManager design tree filter.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureManagerFilterString As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.String  
  
instance.FeatureManagerFilterString = value  
value = instance.FeatureManagerFilterString
```

C#

```
System.string FeatureManagerFilterString {get; set;}
```

C++/CLI

```
property System.String^ FeatureManagerFilterString {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

String in FeatureManager design tree filter

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::FeatureManagerFilterString](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FindTrackedObjects Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : FindTrackedObjects Method (IModelDocExtension)

Finds the tracking IDs assigned to entities in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function FindTrackedObjects( _
    ByVal TrackingCookie As System.Integer, _
    ByVal SearchObject As System.Object, _
    ByVal TypesFilter As System.Object, _
    ByVal TrackingIDs As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim TrackingCookie As System.Integer
Dim SearchObject As System.Object
Dim TypesFilter As System.Object
Dim TrackingIDs As System.Object
Dim value As System.Object

value = instance.FindTrackedObjects(TrackingCookie, SearchObject, TypesFilter, TrackingIDs)
```

C#

```
System.object FindTrackedObjects(
    System.int TrackingCookie,
    System.object SearchObject,
    System.object TypesFilter,
    System.object TrackingIDs
)
```

C++/CLI

```
System.Object^ FindTrackedObjects(
    & System.int TrackingCookie,
    & System.Object^ SearchObject,
    & System.Object^ TypesFilter,
    & System.Object^ TrackingIDs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie

Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

SearchObject

[Body](#) or [face](#) to search for tracking IDs; if empty, then all bodies in the document are searched

TypesFilter

Array of the type of entities for which to search as defined by [swTopoEntity_e](#); valid values are swTopoVertex, swTopoEdge, swTopoLoop, swTopoFace, and swTopoBody; if empty or set to 0, then all types are searched

TrackingIDs

Array of tracking IDs for which to search; if empty, then search for all tracking IDs

Return Value

Array of objects found that match the specified tracking cookie, types, and tracking IDs; this list can be empty if no matches are found

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::FindTrackedObjects](#)

Remarks

You can set tracking IDs on [bodies](#), [faces](#), [edges](#), [loops](#), and [vertices](#) in parts and assemblies only; you cannot set tracking IDs on these entities in drawings. See [Tracking IDs](#) for more information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::GetTrackingIDsCount Method](#)
[IBody2::RemoveTrackingID Method](#)
[IBody2::SetTrackingID Method](#)
[IEdge::GetTrackingIDs Method](#)
[IEdge::GetTrackingIDsCount Method](#)
[IEdge::RemoveTrackingID Method](#)

[IEdge::SetTrackingID Method](#)
[IFace2::GetTrackingIDs Method](#)
[IFace2::GetTrackingIDsCount Method](#)
[IFace2::RemoveTrackingID Method](#)
[IFace2::SetTrackingID Method](#)
[ILoop2::GetTrackingIDs Method](#)
[ILoop2::GetTrackingIDsCount Method](#)
[ILoop2::RemoveTrackingID Method](#)
[ILoop2::SetTrackingID Method](#)
[IVertex::GetTrackingIDs Method](#)
[IVertex::GetTrackingIDsCount Method](#)
[IVertex::IGetTrackingIDs Method](#)
[IVertex::RemoveTrackingID Method](#)
[IVertex::SetTrackingID Method](#)
[ILoop2::IGetTrackingIDs Method](#)
[IFace2::IGetTrackingIDs Method](#)
[IEdge::IGetTrackingIDs Method](#)
[IBody2::IGetTrackingIDs Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FinishRecordingUndoObject Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : FinishRecordingUndoObject Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::FinishRecordingUndoObject2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FinishRecordingUndoObject( _  
    ByVal UndoObjectName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim UndoObjectName As System.String  
Dim value As System.Boolean  
  
value = instance.FinishRecordingUndoObject(UndoObjectName)
```

C#

```
System.bool FinishRecordingUndoObject(  
    System.string UndoObjectName  
)
```

C++/CLI

```
System.bool FinishRecordingUndoObject(  
& System.String^ UndoObjectName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UndoObjectName
String to appear in SOLIDWORKS Undo list

Return Value

True if recording of the SOLIDWORKS Undo object ends, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::FinishRecordingUndoObject](#).

Remarks

Place [IModelDocExtension::StartRecordingUndoObject](#) at the beginning and this method at the end of any SOLIDWORKS API calls in your application that you want your user to undo as a group.

For example, if your application creates a complex gear that requires many SOLIDWORKS API calls, place [IModelDocExtension::StartRecordingUndoObject](#) and this method around the SOLIDWORKS API calls that create that gear. Then your user need only select the string specified for `UndoObjectName` in the SOLIDWORKS Undo list to undo all of the SOLIDWORKS API calls that created the gear.

NOTE: Only SOLIDWORKS operations that support Undo will be undone. Both SOLIDWORKS API and non-API operations are undone.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDoc2::ClearUndoList Method](#)
[IModelDoc2::EditUndo2 Method](#)
[IModelDoc2::EditRedo2 Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FinishRecordingUndoObject2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : FinishRecordingUndoObject2 Method (IModelDocExtension)

Ends recording of a SOLIDWORKS Undo object with the specified name and visibility.

.NET Syntax

Visual Basic (Declaration)

```
Function FinishRecordingUndoObject2( _  
    ByVal UndoObjectName As System.String, _  
    ByVal MakeHidden As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim UndoObjectName As System.String  
Dim MakeHidden As System.Boolean  
Dim value As System.Boolean  
  
value = instance.FinishRecordingUndoObject2(UndoObjectName, MakeHidden)
```

C#

```
System.bool FinishRecordingUndoObject2(  
    System.string UndoObjectName,  
    System.bool MakeHidden  
)
```

C++/CLI

```
System.bool FinishRecordingUndoObject2(  
& System.String^ UndoObjectName,  
& System.bool MakeHidden  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UndoObjectName

String that appears in the SOLIDWORKS Undo list

MakeHidden

True to hide this object in the Undo list and from the user; false to make this object visible in the Undo list and to the user

Return Value

True if recording of the SOLIDWORKS Undo object ends, false if not

Visual Basic for Applications (VBA) Syntax

See [IModelDocExtension::FinishRecordingUndoObject2](#).

Example

[Create Hidden Undo Object \(VBA\)](#)
[Create Hidden Undo Object \(VB.NET\)](#)
[Create Hidden Undo Object \(C#\)](#)

Remarks

To add an object with the name `UndoObjectName` to the SOLIDWORKS Undo list, place the SOLIDWORKS API calls between [IModelDocExtension::StartRecordingUndoObject](#) and `IModelDocExtension::FinishRecordingUndoObject2`:

For example, assume that your application creates a complex gear that requires many SOLIDWORKS API calls and you would like your SOLIDWORKS Design user to be able to undo that gear from the user interface at a later time. Your application can create an Undo object by calling:

1. `IModelDocExtension::StartRecordingUndoObject`
2. SOLIDWORKS API calls that create the gear
3. `IModelDocExtension::FinishRecordingUndoObject2` with `MakeHidden = False`

Now assume that your application performs many temporary operations that you do not want your users to see in the SOLIDWORKS Undo list, because they are not essential to the modeling and design process. For this case, your application can place the non-essential SOLIDWORKS API calls between `IModelDocExtension::StartRecordingUndoObject` and `IModelDocExtension::FinishRecordingUndoObject2` with `MakeHidden = True`. The Undo object is still added to the SOLIDWORKS Undo list, but the user does not see it in the list.

WARNING: If your application hides an Undo object in the Undo list by setting `MakeHidden = True` and the Undo object is the first item in the SOLIDWORKS Undo list, then SOLIDWORKS discards the Undo object from the Undo list. If this happens, then the SOLIDWORKS API calls in this Undo object cannot be undone.

Similarly if the last item to be redone is a hidden API Undo object, then SOLIDWORKS discards it and the SOLIDWORKS API calls cannot be redone.

Only SOLIDWORKS operations that support Undo are undone. Both SOLIDWORKS API and non-API operations are undone.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDoc2::ClearUndoList Method](#)
[IModelDoc2::EditUndo2 Method](#)
[IModelDoc2::EditRedo2 Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlyoutFeatureTreeVisibility Property (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : FlyoutFeatureTreeVisibility Property (IModelDocExtension)

Gets or sets the state of the flyout FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property FlyoutFeatureTreeVisibility As System.Integer

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Integer
```

```
instance.FlyoutFeatureTreeVisibility = value
```

```
value = instance.FlyoutFeatureTreeVisibility
```

C#

```
System.int FlyoutFeatureTreeVisibility {get; set;}
```

C++/CLI

```
property System.int FlyoutFeatureTreeVisibility {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

State of the flyout FeatureManager design tree as defined in [swFeatureTreeState_e](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::FlyoutFeatureTreeVisibility](#).

Example

[Get and Set the State of the Flyout FeatureManager Design Tree \(VBA\)](#)
[Get and Set the State of the Flyout FeatureManager Design Tree \(VB.NET\)](#)
[Get and Set the State of the Flyout FeatureManager Design Tree \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0