

SOLIDWORKS API (.NET VBA C#) — Reference (198/337): IModelDocExtension (part 4 of 8)

SOLIDWORKS API Documentation (converted from CHM)

IModelDocExtension (part 4 of 8) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetModelViews Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetModelViews Method (IModelDocExtension)

Gets the model views in this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelViews() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetModelViews()
```

C#

```
System.object GetModelViews()
```

C++/CLI

```
System.Object^ GetModelViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [model views](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetModelViews](#).

Example

[Get Scale Factor of Each Model View \(C++\)](#)
[Get Scale Factor of Each Model View \(C#\)](#)
[Get Scale Factor of Each Model View \(VB.NET\)](#)
[Get Scale Factor of Each Model View \(VBA\)](#)

Remarks

The model views are set using either **SOLIDWORKS** menu > **Window** > **Viewport** or [IModelViewManager::ViewportDisplay](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetModelViews Method](#)
[IModelDocExtension::GetModelViewCount Method](#)
[IModelDoc2::GetFirstModelView Method](#)
[IModelDoc2::IGetFirstModelView Method](#)
[IModelView::GetNext Method](#)
[IModelView::IGetNext Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetMotionStudyManager Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetMotionStudyManager Method (IModelDocExtension)

Gets the SOLIDWORKS motion study's MotionManager.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMotionStudyManager() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetMotionStudyManager()
```

C#

```
System.object GetMotionStudyManager()
```

C++/CLI

```
System.Object^ GetMotionStudyManager();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[MotionManager](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetMotionStudyManager](#).

Example

[Create Motion Studies \(VBA\)](#)
[Get COSMOSMotion Motion Study Properties and Results \(VBA\)](#)
[Get Motion Study \(VBA\)](#)
[Add Spring to Motion Study \(C#\)](#)
[Add Spring to Motion Study \(VB.NET\)](#)
[Add Spring to Motion Study \(VBA\)](#)
[Duplicate, Delete, and Create Motion Study \(C#\)](#)
[Duplicate, Delete, and Create Motion Study \(VB.NET\)](#)
[Duplicate, Delete, and Create Motion Study \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNamedViewRotation Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetNamedViewRotation Method (IModelDocExtension)

Gets the specified named view orientation matrix with respect to the Front view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNamedViewRotation( _  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Name As System.String  
Dim value As System.Object  
  
value = instance.GetNamedViewRotation(Name)
```

C#

```
System.object GetNamedViewRotation(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ GetNamedViewRotation(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of the named view

Return Value

Array of 9 doubles describing the view rotation with respect to the Front view

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetNamedViewRotation](#).

Remarks

The end-user may have redefined the Front view to be something other than the X-Y plane.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetNamedViewRotation Method](#)
[IModelDoc2::GetStandardViewRotation Method](#)
[IModelDoc2::IGetStandardViewRotation Method](#)
[IModelDoc2::DeleteNamedView Method](#)
[IModelDoc2::NameView Method](#)
[IModelDoc2::ShowNamedView2 Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetObjectByPersistReference Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetObjectByPersistReference Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetObjectByPersistReference3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetObjectByPersistReference( _  
    ByVal PersistId As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PersistId As System.Object  
Dim value As System.Object  
  
value = instance.GetObjectByPersistReference(PersistId)
```

C#

```
System.object GetObjectByPersistReference(  
    System.object PersistId  
)
```

C++/CLI

```
System.Object^ GetObjectByPersistReference(  
& System.Object^ PersistId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PersistId

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetObjectByPersistReference](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetObjectByPersistReference2 Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetObjectByPersistReference2 Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetObjectByPersistReference3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetObjectByPersistReference2( _  
    ByVal PersistId As System.Object, _  
    ByRef ErrorCode As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PersistId As System.Object  
Dim ErrorCode As System.Integer  
Dim value As System.Object  
  
value = instance.GetObjectByPersistReference2(PersistId, ErrorCode)
```

C#

```
System.Object GetObjectByPersistReference2(  
    System.Object PersistId,  
    out System.Int ErrorCode  
)
```

C++/CLI

```
System.Object^ GetObjectByPersistReference2(  
& System.Object^ PersistId,  
& [Out] System.Int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PersistId

ErrorCode
v

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetObjectByPersistReference2](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetObjectByPersistReference3 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetObjectByPersistReference3 Method (IModelDocExtension)

Gets the object assigned to the specified persistent reference ID.

.NET Syntax

Visual Basic (Declaration)

```
Function GetObjectByPersistReference3( _  
    ByVal PersistId As System.Object, _  
    ByRef ErrorCode As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IModelDocExtension  
Dim PersistId As System.Object  
Dim ErrorCode As System.Integer  
Dim value As System.Object  
  
value = instance.GetObjectByPersistReference3(PersistId, ErrorCode)
```

C#

```
System.Object GetObjectByPersistReference3(  
    System.Object PersistId,  
    out System.Int ErrorCode  
)
```

C++/CLI

```
System.Object^ GetObjectByPersistReference3(  
& System.Object^ PersistId,  
& [Out] System.Int ErrorCode  
)
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PersistId

Object's persistent reference ID (see **Remarks**)

ErrorCode

Success or error code as defined by [swPersistReferencedObjectStates_e](#) (see **Remarks**)

Return Value

Object (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetObjectByPersistReference3](#).

Example

```
Sub main ()
    Set swApp = Application.SldWorks
    Set Doc = swApp.ActiveDoc
    Set SelMgr = Doc.SelectionManager
    If SelMgr.GetSelectedObjectCount(-1) = 0 Then Debug.Print "No selections found.":
Exit Sub

    Dim persistRef As Variant
    Dim selObj As Object

    Set selObj = SelMgr.GetSelectedObject6(1, -1)
    persistRef = Doc.Extension.GetPersistReference3(selObj)
    Debug.Print UBound(persistRef)
    Set selObj = Nothing
    Set selObj = Doc.Extension.GetObjectByPersistReference3(persistRef, longstatus)
    Debug.Print (Not selObj Is Nothing)

    Dim selConfig As Configuration
    Set selConfig = selObj.GetSpecificFeature2

End Sub
```

Example

[Get Object's Persistent Reference ID \(VBA\)](#)
[Use Persistent Reference \(VBA\)](#)
[Use Persistent Reference \(VB.NET\)](#)
[Use Persistent Reference \(C#\)](#)

Remarks

A persistent reference ID is related to a model. It is portable and can be saved within the model or in other places. Some persistent reference ID are general to all models and can be instantiated from all models. Your application must handle persistent reference IDs and their relationships among models.

Before calling this method, call [IModelDocExtension::GetPersistReference3](#) to get the object's persistent reference ID. The swPersistReferencedObject_Suppressed and swPersistReferencedObject_Deleted enumerators only apply to references of topological entities.

IModelDocExtension::GetObjectByPersistReference3 was designed to return the base class of a feature to take advantage of the base feature class functionality. Objects returned by IModelDocExtension::GetObjectByPersistReference3 are often features, including [IConfiguration](#), [IRefPlane](#), and [IRefAxis](#) objects. You must first obtain a reference to a feature, and then use [IFeature::GetSpecificFeature2](#) to get the original object.

See [Persistent Reference IDs](#) for more information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

[IModelDocExtension::IModelDocExtension::IGetObjectByPersistReference3 Method](#)
[IModelDocExtension::GetPersistReference3 Method](#)
[IModelDocExtension::GetPersistReferenceCount3 Method](#)
[IModelDocExtension::IsSamePersistentID Method](#)
[IView::ReferencedConfigurationID Property](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetObjectID Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetObjectID Method (IModelDocExtension)

Gets the object ID for the specified annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetObjectID( _  
    ByVal Annotation As Annotation _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Annotation As Annotation  
Dim value As System.Integer  
  
value = instance.GetObjectID(Annotation)
```

C#

```
System.int GetObjectID(  
    Annotation Annotation  
)
```

C++/CLI

```
System.int GetObjectID(  
& Annotation^ Annotation  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Annotation
[Annotation](#)

Return Value

Object ID

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetObjectID](#).

Example

[Get Object ID of GTol Annotation \(C#\)](#)
[Get Object ID of GTol Annotation \(VB.NET\)](#)
[Get Object ID of GTol Annotation \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2014 SP5, Revision Number 22.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetOLEObjectCount Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetOLEObjectCount Method (IModelDocExtension)

Gets the number of OLE objects.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOLEObjectCount( _  
    ByVal Options As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Options As System.Integer  
Dim value As System.Integer  
  
value = instance.GetOLEObjectCount(Options)
```

C#

```
System.int GetOLEObjectCount(  
    System.int Options  
)
```

C++/CLI

```
System.int GetOLEObjectCount(  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Options

Options as defined in [swOleObjectOptions_e](#)

Return Value

Number of OLE objects

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetOLEObjectCount](#).

Example

[Determine if OLE Objects Are Linked or Embedded \(VBA\)](#)

Remarks

Call this method before calling [IModelDocExtension::!GetOLEObjects](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateOLEObject Method](#)

[IModelDocExtension::GetOLEObjects Method](#)
[IModelDocExtension::CreateOLEObject Method](#)
[IModelDocExtension::GetOLEObjects Method](#)
[IModelDocExtension::InsertObjectFromFile Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOLEObjects Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetOLEObjects Method (IModelDocExtension)

Get the OLE objects.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOLEObjects( _  
    ByVal Options As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Options As System.Integer  
Dim value As System.Object  
  
value = instance.GetOLEObjects(Options)
```

C#

```
System.object GetOLEObjects(  
    System.int Options  
)
```

C++/CLI

```
System.Object^ GetOLEObjects(  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Options

Options as defined in [swOleObjectOptions_e](#)

Return Value

Array of the [OLE objects](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetOLEObjects](#).

Example

[Determine if OLE Objects Are Linked or Embedded \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateOLEObject Method](#)
[IModelDocExtension::GetOLEObjectCount Method](#)
[IModelDocExtension::CreateOLEObject Method](#)
[IModelDocExtension::GetOLEObjects Method](#)
[IModelDocExtension::InsertObjectFromFile Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPackAndGo Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPackAndGo Method (IModelDocExtension)

Gets a Pack and Go object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPackAndGo() As PackAndGo
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim value As PackAndGo

value = instance.GetPackAndGo()
```

C#

```
PackAndGo GetPackAndGo()
```

C++/CLI

```
PackAndGo^ GetPackAndGo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPackAndGo](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPackAndGo](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)
[Add and Remove Files from Pack and Go \(C#\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::SavePackAndGo Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPersistReference Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPersistReference Method (IModelDocExtension)

Obsolete. Superseded [IModelDocExtension::GetPersistReference3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPersistReference( _  
    ByVal DispObj As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DispObj As System.Object  
Dim value As System.Object  
  
value = instance.GetPersistReference(DispObj)
```

C#

```
System.object GetPersistReference(  
    System.object DispObj  
)
```

C++/CLI

```
System.Object^ GetPersistReference(  
& System.Object^ DispObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispObj

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPersistReference](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPersistReference3 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPersistReference3 Method (IModelDocExtension)

Gets the persistent reference ID for the specified object in this model document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPersistReference3( _  
    ByVal DispObj As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DispObj As System.Object  
Dim value As System.Object  
  
value = instance.GetPersistReference3(DispObj)
```

C#

```
System.object GetPersistReference3(  
    System.object DispObj  
)
```

C++/CLI

```
System.Object^ GetPersistReference3(  
& System.Object^ DispObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispObj
Object

Return Value

Array containing the persistent reference ID assigned to that object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPersistReference3](#).

Example

[Check Faces for Faults \(VBA\)](#)
[Use Persistent Reference \(VBA\)](#)
[Get Object's Persistent Reference ID \(VBA\)](#)
[Get Object's Persistent Reference ID \(C++\)](#)
[Compare Selected Objects and Their Persistent Reference IDs \(C#\)](#)
[Compare Selected Objects and Their Persistent Reference IDs \(VB.NET\)](#)
[Compare Selected Objects and Their Persistent Reference IDs \(VBA\)](#)

Remarks

Persistent reference ID values obtained using the now obsolete `IModelDocExtension::GetPersistReference` and its related obsolete methods, `IModelDocExtension::GetPersistReferenceCount` and `IModelDocExtension::GetObjectByPersistReference2`, are not compatible with persistent reference IDs obtained using this method and its related methods, [IModelDocExtension::GetPersistReferenceCount3](#) and [IModelDocExtension::GetObjectByPersistReference3](#) or [IModelDocExtension::IGetObjectByPersistReference3](#).

A persistent reference ID is related to a model. It is portable and can be saved within the model or in other places. Some persistent reference IDs are general to all models and can be instantiated from all models. Your application must handle persistent reference IDs and their relationships among models.

The internal representations of the return value array may change, possibly from rebuild to rebuild, or more likely, from one release of SOLIDWORKS to the next, but their usage in finding the correct entity will be consistent across rebuilds and SOLIDWORKS releases.

To compare the referenced entities, you could use the Visual Basic **Is** operator to find out if the entities are the same.

See [Persistent Reference IDs](#) for more information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetPersistReference3 Method](#)
[IModelDocExtension::IsSamePersistentID Method](#)
[IView::ReferencedConfigurationID Property \(\)](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPersistReferenceCount Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPersistReferenceCount Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetPersistReferenceCount3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPersistReferenceCount( _  
    ByVal DispObj As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DispObj As System.Object  
Dim value As System.Integer  
  
value = instance.GetPersistReferenceCount(DispObj)
```

C#

```
System.int GetPersistReferenceCount(  
    System.object DispObj  
)
```

C++/CLI

```
System.int GetPersistReferenceCount(  
    & System.Object^ DispObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispObj

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPersistReferenceCount](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPersistReferenceCount3 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPersistReferenceCount3 Method (IModelDocExtension)

Gets the size of the persistent reference ID assigned to the selected object in this model document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPersistReferenceCount3( _  
    ByVal DispObj As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DispObj As System.Object  
Dim value As System.Integer  
  
value = instance.GetPersistReferenceCount3(DispObj)
```

C#

```
System.int GetPersistReferenceCount3(  
    System.object DispObj
```

)

C++/CLI

```
System.int GetPersistReferenceCount3(  
& System.Object^ DispObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispObj
Selected object

Return Value

Size of that object's persistent reference ID

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPersistReferenceCount3](#).

Example

[Get Object's Persistent Reference ID \(C++\)](#)

Remarks

Persistent reference ID values obtained using the now obsolete `IModelDocExtension::GetPersistReference` and its related obsolete methods, `IModelDocExtension::GetPersistReferenceCount` and `IModelDocExtension::GetObjectByPersistReference2`, are not compatible with persistent reference IDs obtained using [IModelDocExtension::GetPersistReference3](#) or [IModelDocExtension::IGetPersistReference3](#) and its related methods, [IModelDocExtension::GetObjectByPersistReference3](#) or [IModelDocExtension::IGetObjectByPersistReference3](#) and this method.

IMPORTANT: SOLIDWORKS recommends not using this method with `IModelDocExtension::IGetPersistReference3` because when these methods are used together, you will experience a significant decrease in performance.

See [Persistent Reference IDs](#) for more information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPLMID Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPLMID Method (IModelDocExtension)

Gets the ID of this [SOLIDWORKS Design](#) connected to the [3DEXPERIENCE platform](#) document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPLMID() As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.String
```

```
value = instance.GetPLMID()
```

C#

```
System.string GetPLMID()
```

C++/CLI

```
System.String^ GetPLMID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Document ID

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPLMID](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2020 SP3.1, Revision Number 28.3.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrint3DDialog Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPrint3DDialog Method (IModelDocExtension)

Gets the [IPrint3DDialog](#) object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrint3DDialog() As Print3DDialog
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As Print3DDialog
```

```
value = instance.GetPrint3DDialog()
```

C#

```
Print3DDialog GetPrint3DDialog()
```

C++/CLI

```
Print3DDialog^ GetPrint3DDialog();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPrint3DDialog](#) object

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPrint3DDialog](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrintSpecification Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetPrintSpecification Method (IModelDocExtension)

Gets the IPrintSpecification object for this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrintSpecification() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetPrintSpecification()
```

C#

```
System.object GetPrintSpecification()
```

C++/CLI

```
System.Object^ GetPrintSpecification();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPrintSpecification](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetPrintSpecification](#).

Example

[Print Drawing \(VBA\)](#)
[Print Drawing \(VB.NET\)](#)
[Print Drawing \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::PrintOut4 Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRenderCustomReferences Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderCustomReferences Method (IModelDocExtension)

Get the custom render references for this model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderCustomReferences() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetRenderCustomReferences()
```

C#

```
System.object GetRenderCustomReferences()
```

C++/CLI

```
System.Object^ GetRenderCustomReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Custom render references

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderCustomReferences](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetRenderStockReferences Method](#)
[IRenderMaterial Interface](#)
[IDecal Interface](#)
[IModelDocExtension::InsertScene Method](#)
[IPackAndGo Interface](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRenderMaterials Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderMaterials Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetRenderMaterials2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderMaterials() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetRenderMaterials()
```

C#

```
System.object GetRenderMaterials()
```

C++/CLI

```
System.Object^ GetRenderMaterials();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [appearances](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderMaterials](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetRenderMaterials Method](#)
[IModelDocExtension::CreateRenderMaterial Method](#)
[IModelDocExtension::GetRenderMaterialsCount Method](#)
[IModelDocExtension::UpdateRenderMaterialsInSceneGraph Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRenderMaterials2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderMaterials2 Method (IModelDocExtension)

Gets the appearances applied to this model document in the specified display states.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderMaterials2( _  
    ByVal DisplayStateOption As System.Integer, _  
    ByVal DisplayStateNames As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DisplayStateOption As System.Integer  
Dim DisplayStateNames As System.Object  
Dim value As System.Object  
  
value = instance.GetRenderMaterials2(DisplayStateOption, DisplayStateNames)
```

C#

```
System.object GetRenderMaterials2(  
    System.int DisplayStateOption,  
    System.object DisplayStateNames  
)
```

C++/CLI

```
System.Object^ GetRenderMaterials2(  
& System.int DisplayStateOption,  
& System.Object^ DisplayStateNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateOption
Display states as defined in [swDisplayStateOpts_e](#)
DisplayStateNames
Array of display state names

Return Value

Array of [appearances](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderMaterials2](#).

Example

[Add and Delete Appearances from Specific Display States \(VBA\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateRenderMaterial Method \(\)](#)
[IModelDocExtension::GetRenderMaterialsCount2 Method \(\)](#)
[IModelDocExtension::UpdateRenderMaterialsInSceneGraph Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRenderMaterialsCount Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderMaterialsCount Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetRenderMaterialsCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderMaterialsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Integer  
  
value = instance.GetRenderMaterialsCount()
```

C#

```
System.int GetRenderMaterialsCount()
```

C++/CLI

```
System.int GetRenderMaterialsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of appearances applied to this model document

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderMaterialsCount](#).

Remarks

Call this method before calling [IModelDocExtension::!GetRenderMaterials](#) to get the size of the array for that method.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateRenderMaterial Method](#)
[IModelDocExtension::GetRenderMaterials Method](#)
[IModelDocExtension::UpdateRenderMaterialsInSceneGraph Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRenderMaterialsCount2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderMaterialsCount2 Method (IModelDocExtension)

Gets the number of appearances applied to this model document in the specified display states.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderMaterialsCount2( _  
    ByVal DisplayStateOption As System.Integer, _  
    ByVal DisplayStateNames As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim DisplayStateOption As System.Integer  
Dim DisplayStateNames As System.Object  
Dim value As System.Integer
```

```
value = instance.GetRenderMaterialsCount2(DisplayStateOption, DisplayStateNames)
```

C#

```
System.int GetRenderMaterialsCount2(  
    System.int DisplayStateOption,  
    System.object DisplayStateNames  
)
```

C++/CLI

```
System.int GetRenderMaterialsCount2(  
& System.int DisplayStateOption,  
& System.Object^ DisplayStateNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateOption

Display states as defined in [swDisplayStateOptions](#)

DisplayStateNames

Array of display state names

Return Value

Number of [appearances](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderMaterialsCount2](#).

Example

[Add and Delete Appearances from Specific Display States \(VBA\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::UpdateRenderMaterialsInSceneGraph Method \(\)](#)
[IModelDocExtension::GetRenderMaterials2 Method \(\)](#)
[IModelDocExtension::CreateRenderMaterial Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRenderStockReferences Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRenderStockReferences Method (IModelDocExtension)

Gets the SOLIDWORKS-supplied (stock) render references for this model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRenderStockReferences() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetRenderStockReferences()
```

C#

```
System.Object GetRenderStockReferences()
```

C++/CLI

```
System.Object^ GetRenderStockReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Stock render references

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRenderStockReferences](#).

Example

[Get Render References \(C#\)](#)
[Get Render References \(VB.NET\)](#)
[Get Render References \(VBA\)](#)
[Add and Remove Files from Pack and Go \(C#\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetRenderCustomReferences Method](#)
[IRenderMaterial Interface](#)
[IDecal Interface](#)
[IModelDocExtension::InsertScene Method](#)
[IPackAndGo Interface](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

GetRoutingComponentManager Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetRoutingComponentManager Method (IModelDocExtension)

Gets the routing component manager.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRoutingComponentManager() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetRoutingComponentManager()
```

C#

```
System.object GetRoutingComponentManager()
```

C++/CLI

```
System.Object^ GetRoutingComponentManager();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRoutingComponentManager](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetRoutingComponentManager](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

GetScanto3D Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetScanto3D Method (IModelDocExtension)

Gets the IScanTo3D object for this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetScanto3D() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetScanto3D()
```

C#

```
System.Object GetScanto3D()
```

C++/CLI

```
System.Object^ GetScanto3D();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IScanTo3D](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetScanto3D](#).

Example

See the [IScanTo3D](#) examples.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSceneBkgDIBx64 Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSceneBkgDIBx64 Method (IModelDocExtension)

Gets the background image as DIBSECTION in 64-bit applications.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSceneBkgDIBx64() As System.Long
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Long  
  
value = instance.GetSceneBkgDIBx64()
```

C#

```
System.long GetSceneBkgDIBx64()
```

C++/CLI

```
System.int64 GetSceneBkgDIBx64();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Background image as DIBSECTION

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSceneBkgDIBx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

The memory for the image bits (DIBSECTION.dsBm.bmBits) and this structure are allocated by the SOLIDWORKS Design application and must be deleted by the caller.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::SetSceneBkgDIBx64 Method](#)
[IModelDoc2::GetSceneBkgDIB Method](#)
[IModelDoc2::SetSceneBkgDIB Method](#)
[IModelDoc2::InsertBkgImage Method](#)
[IModelDoc2::SceneBkgImageFileName Property](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

GetSearchData Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSearchData Method (IModelDocExtension)

Gets the SOLIDWORKS Search, third-party, application keywords from the model document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSearchData( _  
    ByVal AppName As System.String, _  
    ByRef AppNames As System.Object, _  
    ByRef NodeNames As System.Object, _  
    ByRef NodeValues As System.Object _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim AppName As System.String  
Dim AppNames As System.Object  
Dim NodeNames As System.Object  
Dim NodeValues As System.Object  
Dim value As System.Integer  
  
value = instance.GetSearchData(AppName, AppNames, NodeNames, NodeValues)
```

C#

```
System.int GetSearchData(  
    System.string AppName,  
    out System.object AppNames,  
    out System.object NodeNames,  
    out System.object NodeValues  
)
```

C++/CLI

```
System.int GetSearchData(  
& System.String^ AppName,  
& [Out] System.Object^ AppNames,  
& [Out] System.Object^ NodeNames,  
& [Out] System.Object^ NodeValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppName

Third-party application name whose keywords to get

AppNames

Array of strings of the third-party application name

NodeNames

Array of strings of the third-party application name's keywords

NodeValues

Array of strings of the third-party application name's keyword values

Return Value

Number of third-party application name's keywords

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSearchData](#).

Example

[Get SOLIDWORKS Search Third-party Keywords \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IModelDocExtension::IGetSearchData Method](#)

[IModelDocExtension::AddOrUpdateSearchData Method](#)

[IModelDocExtension::DeleteSearchData Method](#)

[IModelDocExtension::GetSearchDataCount Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSearchDataCount Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSearchDataCount Method (IModelDocExtension)

Gets the number of SOLIDWORKS Search keywords for the specified third-party application previously added to this model document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSearchDataCount( _  
    ByVal AppName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim AppName As System.String  
Dim value As System.Integer  
  
value = instance.GetSearchDataCount(AppName)
```

C#

```
System.int GetSearchDataCount(  
    System.string AppName  
)
```

C++/CLI

```
System.int GetSearchDataCount(  
& System.String^ AppName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppName

Third-party application name

Return Value

Number of keywords for AppName previously added to this model document

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSearchDataCount](#).

Remarks

Call this method before calling [IModelDocExtension::!GetSearchData](#) to determine the size of the arrays for that method.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::AddOrUpdateSearchData Method](#)
[IModelDocExtension::DeleteSearchData Method](#)
[IModelDocExtension::GetSearchData Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSectionProperties Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSectionProperties Method (IModelDocExtension)

Obsolete. Superseded by [IModelDocExtension::GetSectionProperties2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionProperties( _  
    ByVal Sections As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Sections As System.Object  
Dim value As System.Object  
  
value = instance.GetSectionProperties(Sections)
```

C#

```
System.object GetSectionProperties(  
    System.object Sections  
)
```

C++/CLI

```
System.Object^ GetSectionProperties(  
& System.Object^ Sections  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sections

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSectionProperties](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSectionProperties2 Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSectionProperties2 Method (IModelDocExtension)

Gets the section properties for the following types of selected items:

- Planar model face in any document
- Face on a section plane
- Crosshatch section face in a section view in a drawing a sketch
- Sketch

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionProperties2( _  
    ByVal Sections As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Sections As System.Object  
Dim value As System.Object  
  
value = instance.GetSectionProperties2(Sections)
```

C#

```
System.object GetSectionProperties2(  
    System.object Sections  
)
```

C++/CLI

```
System.Object^ GetSectionProperties2(  
& System.Object^ Sections  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sections
Array of sections

Return Value

Array of section properties for the selected items (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSectionProperties2](#).

Example

[Get Section Properties for Planar Faces \(VBA\)](#)

Remarks

This method clears the selection set.

If...	Then...
The user selected a set of either parallel planes or parallel faces	You can pass an empty sections array
The user selected any items and you pass a sections array	The properties of the user-selected items and the sections array are combined in the returned array
You pass a sections array and you do not want this array combined with the properties of any user-selected items	Clear any user-selected items

The objects in the Sections parameter are added to the current selection set. If the objects are already in the current selection set, an error is generated; that is, status code will be equal to 1, which means invalid input.

The format of the returned array (retval) of size 24:

. retval[0]	status of request: . 0 = success . 1 = invalid input . 2 = selected faces are not in the same or parallel planes . 3 = unable to compute section properties
. retval[1]	area
. retval[2]	centroid x
. retval[3]	centroid y
. retval[4]	centroid z
. retval[5]	moment of inertia XX
. reval[6]	moment of inertia YY
. retval[7]	moment of inertia ZZ
. retval[8]	moment of inertia -XY
. retval[9]	moment of inertia -ZX
. retval[10]	moment of inertia -YZ
. retval[11]	polar moment of inertia of an area at the centroid
. retval[12]	angle between principal axis and part axis
. retval[13]	principal moment of inertia of an area at the centroid, Ix
. retval[14]	principal moment of inertia of an area at the centroid, Iy
. retval[15]	direction vector X for principle axes (x component)
. retval[16]	direction vector X for principle axes (y component)
. retval[17]	direction vector X for principle axes (z component)
. retval[18]	direction vector Y for principle axes (x component)
. retval[19]	direction vector Y for principle axes (y component)
. retval[20]	direction vector Y for principle axes (z component)
. retval[21]	direction vector Z for principle axes (x component)
. retval[22]	direction vector Z for principle axes (y component)
. retval[23]	direction vector Z for principle axes (z component)

This method returns metric units unless explicitly specified otherwise.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetSectionProperties2 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetMetalObjectsByPersistReference Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSheetMetalObjectsByPersistReference Method (IModelDocExtension)

Gets the objects in a folded sheet metal part that correspond to the byte array of persistent reference IDs of an entity in a flattened sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetMetalObjectsByPersistReference( _  
    ByVal PersistId As System.Object, _  
    ByRef ErrorCode As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim PersistId As System.Object  
Dim ErrorCode As System.Integer  
Dim value As System.Object  
  
value = instance.GetSheetMetalObjectsByPersistReference(PersistId, ErrorCode)
```

C#

```
System.object GetSheetMetalObjectsByPersistReference(  
    System.object PersistId,  
    out System.int ErrorCode  
)
```

C++/CLI

```
System.Object^ GetSheetMetalObjectsByPersistReference(  
& System.Object^ PersistId,  
& [Out] System.int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PersistId

Persistent reference IDs returned by [IModelDocExtension::GetFlattenSheetMetalPersistReference](#) or [IModelDocExtension::IGetFlattenSheetMetalPersistReference](#)

ErrorCode

Error as defined by [swPersistReferencedObjectStates_e](#)

Return Value

Objects in a folded sheet metal part that correspond to the byte array of persistent reference IDs of an entity in a flattened sheet metal part

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSheetMetalObjectsByPersistReference](#).

Example

[Set and Get Sheet Metal Part's Persistent Reference IDs \(C#\)](#)
[Set and Get Sheet Metal Part's Persistent Reference IDS \(VB.NET\)](#)
[Set and Get Sheet Metal Part's Persistent Reference IDs \(VBA\)](#)

Remarks

See [Persistent Reference IDs](#) for more information.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::IGetSheetMetalObjectsByPersistReference Method](#)
[IModelDocExtension::GetObjectByPersistReference3 Method](#)
[IModelDocExtension::GetPersistReference3 Method](#)
[IModelDocExtension::GetPersistReferenceCount3 Method](#)
[IModelDocExtension::IGetObjectByPersistReference3 Method](#)
[IModelDocExtension::IGetPersistReference3 Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSphericalBoxDiameter Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSphericalBoxDiameter Method (IModelDocExtension)

Gets the diameter of the spherical bounding box of this model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSphericalBoxDiameter() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Double
```

```
value = instance.GetSphericalBoxDiameter()
```

C#

```
System.double GetSphericalBoxDiameter()
```

C++/CLI

```
System.double GetSphericalBoxDiameter();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Diameter of the sphere that encloses this model's bounding box

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSphericalBoxDiameter](#).

Example

See the [IBoundingBoxFeatureData](#) examples.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStream Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetStream Method (IModelDocExtension)

Gets the handle for the specified stream.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStream( _  
    ByVal StreamType As System.Integer, _  
    ByRef ReadOnly As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim StreamType As System.Integer  
Dim ReadOnly As System.Boolean  
Dim value As System.Object  
  
value = instance.GetStream(StreamType, ReadOnly)
```

C#

```
System.Object GetStream(  
    System.int StreamType,  
    out System.bool ReadOnly  
)
```

C++/CLI

```
System.Object^ GetStream(  
& System.int StreamType,  
& [Out] System.bool ReadOnly  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StreamType
1 = material stream
ReadOnly
True if the stream is read-only, false if not

Return Value

Pointer to the IUnknown interface for this stream

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetStream](#).

Remarks

To release the stream, call [IModelDocExtension::ReleaseStream](#).

VB Example

This example illustrates attaching an XML document to a stream, and then releasing the stream.

```
Dim swApp As Object  
Sub main()  
Set swApp = Application.SldWorks
```

```

Dim docext As SldWorks.ModelDocExtension

Set docext = swApp.ActiveDoc.Extension

Dim xmldoc As MSXML2.DOMDocument
Set xmldoc = CreateObject("MSXML2.DOMDocument")
Dim stat As Boolean
Dim stream
Set stream = docext.GetStream(1, stat)
xmldoc.Load (stream)
docext.ReleaseStream (1)

xmldoc.Save ("C:\temp\xmlmat.xml")

End Sub

```

C++ Example

```

//-----
CComPtr<IModelDocExtension> ext;
m_iModelDoc2->get_Extension(&ext);
LPSTREAM stream = NULL;
VARIANT_BOOL access = 0;
ext->IGetStream(1, &access, &stream);
// Your code
if (stream)
{
    VARIANT_BOOL status;
    ext->IReleaseStream(1, &status);
    stream->Release();
}
//-----

```

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSunLightAdvancedPropertyValues Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSunLightAdvancedPropertyValues Method (IModelDocExtension)

Gets the specified sunlight advanced properties.

.NET Syntax

```
Function GetSunLightAdvancedPropertyValues( _
    ByRef Haze As System.Double, _
    ByRef SunDiameter As System.Double, _
    ByRef GroundAlbedo As System.Integer, _
    ByRef SkyGamma As System.Double _
) As System.Boolean
```



```
Dim instance As IModelDocExtension
Dim Haze As System.Double
Dim SunDiameter As System.Double
Dim GroundAlbedo As System.Integer
Dim SkyGamma As System.Double
Dim value As System.Boolean
```

```
value = instance.GetSunLightAdvancedPropertyValues(Haze, SunDiameter, GroundAlbedo, SkyGamma)
```

```
System.bool GetSunLightAdvancedPropertyValues(
    out System.double Haze,
    out System.double SunDiameter,
    out System.int GroundAlbedo,
    out System.double SkyGamma
)
```

```
System.bool GetSunLightAdvancedPropertyValues(
    & [Out] System.double Haze,
    & [Out] System.double SunDiameter,
    & [Out] System.int GroundAlbedo,
    & [Out] System.double SkyGamma
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Haze

0.0 <= Haze setting <= 1.0

SunDiameter

0.01 <= sun diameter visible in the scene <= 21474836.47

GroundAlbedo

RGB color reflected from the ground upwards

SkyGamma

0.1 <= visible sky Output Gamma <= 100.0

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSunLightAdvancedPropertyValues](#).

Example

[Get and Set Sunlight Source Property Values \(VBA\)](#)
[Get and Set Sunlight Source Property Values \(VB.NET\)](#)
[Get and Set Sunlight Source Property Values \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::SetSunLightAdvancedPropertyValues Method \(\)](#)
[IModelDocExtension::UpdateSunLight Method \(\)](#)
[IModelDocExtension::GetSunLightSourcePropertyValues Method \(\)](#)
[IModelDocExtension::SunLightInformation Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSunLightSourcePropertyValues Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSunLightSourcePropertyValues Method (IModelDocExtension)

Gets the property values for a sunlight source.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSunLightSourcePropertyValues( _  
    ByRef NorthDirection As MathVector, _  
    ByRef NorthLatitude As System.Double, _  
    ByRef EastLongitude As System.Double, _  
    ByRef TimeZone As System.Double, _  
    ByRef DateTime As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim NorthDirection As MathVector  
Dim NorthLatitude As System.Double  
Dim EastLongitude As System.Double  
Dim TimeZone As System.Double  
Dim DateTime As System.String  
Dim value As System.Boolean
```

```
value = instance.GetSunLightSourcePropertyValues(NorthDirection, NorthLatitude, EastLongitude,  
TimeZone, DateTime)
```

C#

```
System.bool GetSunLightSourcePropertyValues(  
    out MathVector NorthDirection,  
    out System.double NorthLatitude,  
    out System.double EastLongitude,  
    out System.double TimeZone,  
    out System.string DateTime  
)
```

C++/CLI

```
System.bool GetSunLightSourcePropertyValues(  
& [Out] MathVector^ NorthDirection,  
& [Out] System.double NorthLatitude,  
& [Out] System.double EastLongitude,  
& [Out] System.double TimeZone,  
& [Out] System.String^ DateTime  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NorthDirection
[IMathVector](#); north direction of the sunlight source
NorthLatitude
North latitude of the sunlight source
EastLongitude
East longitude of the sunlight source
TimeZone
Standard time zone of the sunlight source
DateTime
Date and time stamp in the specified TimeZone

Return Value

True if getting the value is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSunLightSourcePropertyValues](#).

Example

[Get and Set Sunlight Source Property Values \(VBA\)](#)
[Get and Set Sunlight Source Property Values \(VB.NET\)](#)
[Get and Set Sunlight Source Property Values \(C#\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::SetSunLightSourcePropertyValues Method \(\)](#)
[IModelDoc2::LightSourcePropertyValues Property \(\)](#)
[IModelDocExtension::GetSunLightAdvancedPropertyValues Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSustainability Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetSustainability Method (IModelDocExtension)

Gets the entry-point interface to the SOLIDWORKS Sustainability API.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSustainability() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetSustainability()
```

C#

```
System.object GetSustainability()
```

C++/CLI

```
System.Object^ GetSustainability();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISustainabilityApp](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetSustainability](#).

Example

[Calculate Environmental Impact of Part \(VBA\)](#)
[Calculate Environmental Impact of Part \(VB.NET\)](#)
[Calculate Environmental Impact of Part \(C#\)](#)
[Calculate Environmental Impact of Assembly \(VBA\)](#)
[Calculate Environmental Impact of Assembly \(VB.NET\)](#)
[Calculate Environmental Impact of Assembly \(C#\)](#)

Remarks

SOLIDWORKS Sustainability and its API are only available in SOLIDWORKS Professional and SOLIDWORKS Premium.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTemplateSheetMetal Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetTemplateSheetMetal Method (IModelDocExtension)

Gets the sheet metal folder feature from this sheet metal model created in SOLIDWORKS 2013 or later.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTemplateSheetMetal() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Object  
  
value = instance.GetTemplateSheetMetal()
```

C#

```
System.object GetTemplateSheetMetal()
```

C++/CLI

```
System.Object^ GetTemplateSheetMetal();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#); Null if this model was created with SOLIDWORKS 2012 or earlier

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetTemplateSheetMetal](#).

Example

[Get Sheet Metal Feature Data \(VBA\)](#)
[Get Sheet Metal Feature Data \(VB.NET\)](#)
[Get Sheet Metal Feature Data \(C#\)](#)

Remarks

This method works only on sheet metal models created with SOLIDWORKS 2013 or later. To obtain sheet metal feature data for earlier models, follow the examples of [ISheetMetalFeatureData](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTexture Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetTexture Method (IModelDocExtension)

Gets the texture applied to the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTexture( _  
    ByVal Config\_name As System.String _  
) As Texture
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim Config_name As System.String  
Dim value As Texture  
  
value = instance.GetTexture(Config_name)
```

C#

```
Texture GetTexture(  
    System.string Config\_name  
)
```

C++/CLI

```
Texture^ GetTexture(  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of configuration or NULL if texture is not present

Return Value

[Texture](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetTexture](#).

Example

[Remove Textures from Assembly Components \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::CreateTexture Method](#)
[IModelDocExtension::RemoveTexture2 Method](#)
[IModelDocExtension::SetTexture Method](#)
[IModelDocExtension::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::SetTextureByDisplayState Method](#)

Availability

GetUserPreferenceDouble Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceDouble Method (IModelDocExtension)

Gets document default user preference values. This method is intended for user preferences of type double.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceDouble( _
    ByVal UserPref As System.Integer, _
    ByVal UserPrefOption As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim UserPref As System.Integer
Dim UserPrefOption As System.Integer
Dim value As System.Double

value = instance.GetUserPreferenceDouble(UserPref, UserPrefOption)
```

C#

```
System.double GetUserPreferenceDouble(
    System.int UserPref,
    System.int UserPrefOption
)
```

C++/CLI

```
System.double GetUserPreferenceDouble(
    & System.int UserPref,
    & System.int UserPrefOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceDoubleValue_e](#)

UserPrefOption

User-preference option for customizing annotation and dimension drafting standards and as defined in [swUserPreferenceOption_e](#); if not needed, then specify swDetailingNoOptionSpecified

Return Value

Value of UserPref

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetUserPreferenceDouble](#).

Example

[Get and Set User Preferences \(VBA\)](#)

[Get and Set User Preferences \(VB.NET\)](#)

[Get and Set User Preferences \(C#\)](#)

Remarks

This method is equivalent to interactively getting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

If you want to retrieve the current, minimum, and maximum values for a document user preference, use [IModelDocExtension::GetUserPreferenceDoubleValueRange](#). Be sure to read that method's **Remarks** section because its implementation is

limited.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetUserPreferenceDoubleValueRange Method](#)
[IModelDocExtension::GetUserPreferenceInteger Method](#)
[IModelDocExtension::GetUserPreferenceString Method](#)
[IModelDocExtension::GetUserPreferenceTextFormat Method](#)
[IModelDocExtension::GetUserPreferenceToggle Method](#)
[IModelDocExtension::SetUserPreferenceDouble Method](#)
[IModelDocExtension::SetUserPreferenceInteger Method](#)
[IModelDocExtension::SetUserPreferenceString Method](#)
[IModelDocExtension::SetUserPreferenceTextFormat Method](#)
[IModelDocExtension::SetUserPreferenceToggle Method](#)
[ISldWorks::GetUserPreferenceDoubleValue Method](#)
[ISldWorks::GetUserPreferenceIntegerValue Method](#)
[ISldWorks::GetUserPreferenceStringListValue Method](#)
[ISldWorks::GetUserPreferenceStringValue Method](#)
[ISldWorks::GetUserPreferenceToggle Method](#)
[ISldWorks::SetUserPreferenceDoubleValue Method](#)
[ISldWorks::SetUserPreferenceIntegerValue Method](#)
[ISldWorks::SetUserPreferenceStringListValue Method](#)
[ISldWorks::SetUserPreferenceStringValue Method](#)
[ISldWorks::SetUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUserPreferenceDoubleValueRange Method (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceDoubleValueRange Method (IModelDocExtension)

Gets the current document default user preference value, and the minimum and maximum valid document user preference values.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceDoubleValueRange( _  
    ByVal UserPref As System.Integer, _  
    ByRef Value As System.Double, _  
    ByRef MinValue As System.Double, _  
    ByRef MaxValue As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim UserPref As System.Integer  
Dim Value As System.Double  
Dim MinValue As System.Double  
Dim MaxValue As System.Double  
Dim value As System.Integer
```

```
value = instance.GetUserPreferenceDoubleValueRange(UserPref, Value, MinValue, MaxValue)
```

C#

```
System.int GetUserPreferenceDoubleValueRange(  
    System.int UserPref,  
    out System.double Value,  
    out System.double MinValue,  
    out System.double MaxValue  
)
```

C++/CLI

```
System.int GetUserPreferenceDoubleValueRange(  
& System.int UserPref,  
& [Out] System.double Value,  
& [Out] System.double MinValue,
```

```
& [Out] System.double MaxValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceDoubleValue_e](#)
Value

Current value of UserPref; if the return value >= 0, see **Remarks**
MinValue

Minimum value of UserPref; if the return value = 0, see **Remarks**
MaxValue

Maximum value of UserPref; if the return value= 0, see **Remarks**

Return Value

Status upon return from this method; see **Remarks**

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetUserPreferenceDoubleValueRange](#).

Remarks

This method is equivalent to interactively getting document properties in the SOLIDWORKS Design software.

The return value indicates the status upon return from this method:

- 0 indicates that the current, minimum, and maximum user preference values were retrieved.
- 1 indicates that the current user preference value was retrieved, but the minimum and maximum user preference values were not. This most likely occurred because the SOLIDWORKS API code was not implemented to retrieve the minimum and maximum allowed values so the return value is warning you that not all information was returned. It does not indicate a fatal error. The SOLIDWORKS API code is only implemented for returning the minimum and maximum value in cases where those values are not obvious to the user, such as with user preference swImageQualityShadedDeviation.
- -1 indicates that the current user preference value could not be retrieved. This most likely occurred because UserPref was not recognized as a valid user preference value.

If you want to retrieve the current user preference value only (i.e., you do not want to retrieve the valid minimum and maximum user preference values), use [IModelDocExtension::GetUserPreferenceDouble](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[ISldWorks::GetUserPreferenceDoubleValue Method](#)
[ISldWorks::GetUserPreferenceIntegerValue Method](#)
[ISldWorks::GetUserPreferenceStringListValue Method](#)
[ISldWorks::GetUserPreferenceStringValue Method](#)
[ISldWorks::GetUserPreferenceToggle Method](#)
[ISldWorks::SetUserPreferenceDoubleValue Method](#)
[ISldWorks::SetUserPreferenceIntegerValue Method](#)
[ISldWorks::SetUserPreferenceStringListValue Method](#)
[ISldWorks::SetUserPreferenceStringValue Method](#)
[ISldWorks::SetUserPreferenceToggle Method](#)
[IModelDocExtension::GetUserPreferenceDouble Method](#)
[IModelDocExtension::GetUserPreferenceInteger Method](#)
[IModelDocExtension::GetUserPreferenceString Method](#)
[IModelDocExtension::GetUserPreferenceTextFormat Method](#)
[IModelDocExtension::GetUserPreferenceToggle Method](#)
[IModelDocExtension::SetUserPreferenceDouble Method](#)
[IModelDocExtension::SetUserPreferenceInteger Method](#)
[IModelDocExtension::SetUserPreferenceString Method](#)
[IModelDocExtension::SetUserPreferenceTextFormat Method](#)
[IModelDocExtension::SetUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUserPreferenceInteger Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceInteger Method (IModelDocExtension)

Sets document default user preference values. This method is intended for user preferences of type integer.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceInteger( _
    ByVal UserPref As System.Integer, _
    ByVal UserPrefOption As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim UserPref As System.Integer
Dim UserPrefOption As System.Integer
Dim value As System.Integer

value = instance.GetUserPreferenceInteger(UserPref, UserPrefOption)
```

C#

```
System.int GetUserPreferenceInteger(
    System.int UserPref,
    System.int UserPrefOption
)
```

C++/CLI

```
System.int GetUserPreferenceInteger(
    & System.int UserPref,
    & System.int UserPrefOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceIntegerValue_e](#)

UserPrefOption

User-preference option for customizing annotation and dimension drafting standards and as defined in [swUserPreferenceOption_e](#); if not needed, then specify swDetailingNoOptionSpecified

Return Value

Value of UserPref

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetUserPreferenceInteger](#).

Example

[Change Drafting Standard to Custom \(VBA\)](#)
[Get and Set User Preferences \(VBA\)](#)
[Get and Set User Preferences \(VB.NET\)](#)
[Get and Set User Preferences \(C#\)](#)

Remarks

This method is equivalent to interactively setting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetUserPreferenceDouble Method](#)
[IModelDocExtension::GetUserPreferenceDoubleValueRange Method](#)
[IModelDocExtension::GetUserPreferenceString Method](#)
[IModelDocExtension::GetUserPreferenceTextFormat Method](#)
[IModelDocExtension::GetUserPreferenceToggle Method](#)
[IModelDocExtension::SetUserPreferenceDouble Method](#)
[IModelDocExtension::SetUserPreferenceInteger Method](#)
[IModelDocExtension::SetUserPreferenceString Method](#)
[IModelDocExtension::SetUserPreferenceTextFormat Method](#)
[IModelDocExtension::SetUserPreferenceToggle Method](#)
[ISldWorks::GetUserPreferenceDoubleValue Method](#)

[ISldWorks::GetUserPreferenceIntegerValue Method](#)
[ISldWorks::GetUserPreferenceStringListValue Method](#)
[ISldWorks::GetUserPreferenceStringValue Method](#)
[ISldWorks::GetUserPreferenceToggle Method](#)
[ISldWorks::SetUserPreferenceDoubleValue Method](#)
[ISldWorks::SetUserPreferenceIntegerValue Method](#)
[ISldWorks::SetUserPreferenceStringListValue Method](#)
[ISldWorks::SetUserPreferenceStringValue Method](#)
[ISldWorks::SetUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUserPreferenceString Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceString Method (IModelDocExtension)

Gets document default user preference values. This method is intended for user preferences of type string.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceString( _  
    ByVal UserPref As System.Integer, _  
    ByVal UserPrefOption As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim UserPref As System.Integer  
Dim UserPrefOption As System.Integer  
Dim value As System.String  
  
value = instance.GetUserPreferenceString(UserPref, UserPrefOption)
```

C#

```
System.string GetUserPreferenceString(  
    System.int UserPref,  
    System.int UserPrefOption  
)
```

C++/CLI

```
System.String^ GetUserPreferenceString(  
& System.int UserPref,  
& System.int UserPrefOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceStringValue_e](#)

UserPrefOption

User-preference option for customizing annotation and dimension drafting standards and as defined in [swUserPreferenceOption_e](#); if not needed, then specify swDetailingNoOptionSpecified

Return Value

Value of UserPref

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension.GetUserPreferenceString](#).

Example

[Change Drafting Standard to Custom \(VBA\)](#)
[Get and Set User Preferences \(VBA\)](#)
[Get and Set User Preferences \(VB.NET\)](#)
[Get and Set User Preferences \(C#\)](#)

Remarks

This method is equivalent to interactively getting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetUserPreferenceDouble Method](#)
[IModelDocExtension::GetUserPreferenceDoubleValueRange Method](#)
[IModelDocExtension::GetUserPreferenceInteger Method](#)
[IModelDocExtension::GetUserPreferenceTextFormat Method](#)
[IModelDocExtension::GetUserPreferenceToggle Method](#)
[IModelDocExtension::SetUserPreferenceDouble Method](#)
[IModelDocExtension::SetUserPreferenceInteger Method](#)
[IModelDocExtension::SetUserPreferenceString Method](#)
[IModelDocExtension::SetUserPreferenceTextFormat Method](#)
[IModelDocExtension::SetUserPreferenceToggle Method](#)
[ISldWorks::GetUserPreferenceDoubleValue Method](#)
[ISldWorks::GetUserPreferenceIntegerValue Method](#)
[ISldWorks::GetUserPreferenceStringListValue Method](#)
[ISldWorks::GetUserPreferenceStringValue Method](#)
[ISldWorks::GetUserPreferenceToggle Method](#)
[ISldWorks::SetUserPreferenceDoubleValue Method](#)
[ISldWorks::SetUserPreferenceIntegerValue Method](#)
[ISldWorks::SetUserPreferenceStringListValue Method](#)
[ISldWorks::SetUserPreferenceStringValue Method](#)
[ISldWorks::SetUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetUserPreferenceTextFormat Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceTextFormat Method (IModelDocExtension)

Gets document default user preference values. This method is intended for getting detailing text formats.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceTextFormat( _  
    ByVal UserPref As System.Integer, _  
    ByVal UserPrefOption As System.Integer _  
) As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim UserPref As System.Integer  
Dim UserPrefOption As System.Integer  
Dim value As TextFormat  
  
value = instance.GetUserPreferenceTextFormat(UserPref, UserPrefOption)
```

C#

```
TextFormat GetUserPreferenceTextFormat(  
    System.int UserPref,  
    System.int UserPrefOption  
)
```

C++/CLI

```
TextFormat^ GetUserPreferenceTextFormat(  
    & System.int UserPref,
```

```
& System.int UserPrefOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceTextFormat_e](#)

UserPrefOption

User-preference option for customizing annotation and dimension drafting standards and as defined in [swUserPreferenceOption_e](#); if not needed, then specify swDetailingNoOptionSpecified

Return Value

[Text format](#) associated with UserPref

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetUserPreferenceTextFormat](#).

Example

[Get and Set User Preferences \(VBA\)](#)

[Get and Set User Preferences \(VB.NET\)](#)

[Get and Set User Preferences \(C#\)](#)

Remarks

This method is equivalent to interactively getting document properties in the SOLIDWORKS Design software. See [System Options and Document Properties](#) for details.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetUserPreferenceDouble Method](#)
[IModelDocExtension::GetUserPreferenceDoubleValueRange Method](#)
[IModelDocExtension::GetUserPreferenceInteger Method](#)
[IModelDocExtension::GetUserPreferenceString Method](#)
[IModelDocExtension::GetUserPreferenceToggle Method](#)
[IModelDocExtension::SetUserPreferenceDouble Method](#)
[IModelDocExtension::SetUserPreferenceInteger Method](#)
[IModelDocExtension::SetUserPreferenceString Method](#)
[IModelDocExtension::SetUserPreferenceTextFormat Method](#)
[IModelDocExtension::SetUserPreferenceToggle Method](#)
[ISldWorks::GetUserPreferenceDoubleValue Method](#)
[ISldWorks::GetUserPreferenceIntegerValue Method](#)
[ISldWorks::GetUserPreferenceStringListValue Method](#)
[ISldWorks::GetUserPreferenceStringValue Method](#)
[ISldWorks::GetUserPreferenceToggle Method](#)
[ISldWorks::SetUserPreferenceDoubleValue Method](#)
[ISldWorks::SetUserPreferenceIntegerValue Method](#)
[ISldWorks::SetUserPreferenceStringListValue Method](#)
[ISldWorks::SetUserPreferenceStringValue Method](#)
[ISldWorks::SetUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUserPreferenceToggle Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetUserPreferenceToggle Method (IModelDocExtension)

Gets document default user preference values. This method is intended for user preferences that can be toggled.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUserPreferenceToggle( _  
    ByVal UserPref As System.Integer, _  
    ByVal UserPrefOption As System.Integer _  
) As System.Boolean
```

```
Dim instance As IModelDocExtension
Dim UserPref As System.Integer
Dim UserPrefOption As System.Integer
Dim value As System.Boolean

value = instance.GetUserPreferenceToggle(UserPref, UserPrefOption)
```

C#

```
System.bool GetUserPreferenceToggle(
    System.int UserPref,
    System.int UserPrefOption
)
```

C++/CLI

```
System.bool GetUserPreferenceToggle(
    & System.int UserPref,
    & System.int UserPrefOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPref

User preference as defined in [swUserPreferenceToggle_e](#)

UserPrefOption

User-preference option for customizing annotation and dimension drafting standards and as defined in [swUserPreferenceOption_e](#); if not needed, then specify swDetailingNoOptionSpecified

Return Value

True if UserPref is toggled on, false if toggled off

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetUserPreferenceToggle](#).

Example

[Get and Set User Preferences \(VBA\)](#)

[Get and Set User Preferences \(VB.NET\)](#)

[Get and Set User Preferences \(C#\)](#)

Remarks

See [System Options and Document Properties](#) for details.

See Also

[IModelDocExtension Interface](#)

[IModelDocExtension Members](#)

[IModelDocExtension::GetUserPreferenceDouble Method](#)

[IModelDocExtension::GetUserPreferenceDoubleValueRange Method](#)

[IModelDocExtension::GetUserPreferenceInteger Method](#)

[IModelDocExtension::GetUserPreferenceString Method](#)

[IModelDocExtension::GetUserPreferenceTextFormat Method](#)

[IModelDocExtension::SetUserPreferenceDouble Method](#)

[IModelDocExtension::SetUserPreferenceInteger Method](#)

[IModelDocExtension::SetUserPreferenceString Method](#)

[IModelDocExtension::SetUserPreferenceTextFormat Method](#)

[IModelDocExtension::SetUserPreferenceToggle Method](#)

[ISldWorks::GetUserPreferenceDoubleValue Method](#)

[ISldWorks::GetUserPreferenceIntegerValue Method](#)

[ISldWorks::GetUserPreferenceStringListValue Method](#)

[ISldWorks::GetUserPreferenceStringValue Method](#)

[ISldWorks::GetUserPreferenceToggle Method](#)

[ISldWorks::SetUserPreferenceDoubleValue Method](#)

[ISldWorks::SetUserPreferenceIntegerValue Method](#)

[ISldWorks::SetUserPreferenceStringListValue Method](#)

[ISldWorks::SetUserPreferenceStringValue Method](#)

[ISldWorks::SetUserPreferenceToggle Method](#)

Availability

GetVisibleBox Method (IModelDocExtension)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetVisibleBox Method (IModelDocExtension)Gets the visible bounding box set by [IModelDocExtension::SetVisibleBox](#) for a part or an assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleBox( _
    ByRef UpperLeft As MathPoint, _
    ByRef LowerRight As MathPoint _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim UpperLeft As MathPoint
Dim LowerRight As MathPoint
Dim value As System.Boolean
```

```
value = instance.GetVisibleBox(UpperLeft, LowerRight)
```

C#

```
System.bool GetVisibleBox(
    out MathPoint UpperLeft,
    out MathPoint LowerRight
)
```

C++/CLI

```
System.bool GetVisibleBox(
    & [Out] MathPoint^ UpperLeft,
    & [Out] MathPoint^ LowerRight
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*UpperLeft*Upper-left [point](#) of the bounding box*LowerRight*Lower-right [point](#) of the bounding box

Return Value

True if the bounding box was set, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetVisibleBox](#).

Remarks

SOLIDWORKS 2007 FCS, Revision Number 15.0

See Also

[IModelDocExtension Interface](#)[IModelDocExtension Members](#)[IModelDocExtension::RemoveVisibleBox Method](#)[IModelDocExtension::SetVisibleBox Method](#)

Availability

GetWhatsWrong Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetWhatsWrong Method (IModelDocExtension)

Gets the What's Wrong dialog information for this model document.

.NET Syntax

Visual Basic (Declaration)

```

Function GetWhatsWrong( _
    ByRef Features As System.Object, _
    ByRef ErrorCodes As System.Object, _
    ByRef Warnings As System.Object _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDocExtension
Dim Features As System.Object
Dim ErrorCodes As System.Object
Dim Warnings As System.Object
Dim value As System.Boolean

value = instance.GetWhatsWrong(Features, ErrorCodes, Warnings)

```

C#

```

System.bool GetWhatsWrong(
    out System.object Features,
    out System.object ErrorCodes,
    out System.object Warnings
)

```

C++/CLI

```

System.bool GetWhatsWrong(
    & [Out] System.Object^ Features,
    & [Out] System.Object^ ErrorCodes,
    & [Out] System.Object^ Warnings
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Features

Array of features in the What's Wrong dialog

ErrorCodes

Array of error codes corresponding to the features in the What's Wrong dialog as defined in [swFeatureError_e](#)

Warnings

Array of Booleans corresponding to the features in the What's Wrong dialog indicating whether SOLIDWORKS detected a What's Wrong item as a warning; true if SOLIDWORKS detected a What's Wrong item as a warning, false if not

Return Value

True if this method runs successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetWhatsWrong](#).

Example

[Get What's Wrong \(C#\)](#)
[Get What's Wrong \(VB.NET\)](#)
[Get What's Wrong \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IModelDocExtension::GetWhatsWrongCount Method](#)
[IFeature::GetErrorCode2 Method](#)
[IMacroFeatureData::Provider Property](#)

Availability

SOLIDWORKS 2009 SP3, Revision Number 17.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWhatsWrongCount Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : GetWhatsWrongCount Method (IModelDocExtension)

Gets the number of items in the What's Wrong dialog.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWhatsWrongCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension  
Dim value As System.Integer  
  
value = instance.GetWhatsWrongCount()
```

C#

```
System.int GetWhatsWrongCount()
```

C++/CLI

```
System.int GetWhatsWrongCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of items in the What's Wrong dialog

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::GetWhatsWrongCount](#).

Example

[Get What's Wrong \(C#\)](#)
[Get What's Wrong \(VB.NET\)](#)
[Get What's Wrong \(VBA\)](#)

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[IFeature::GetErrorCode2 Method](#)
[IModelDocExtension::GetWhatsWrong Method](#)

Availability

SOLIDWORKS 2009 SP3, Revision Number 17.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasDesignTable Method (IModelDocExtension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : HasDesignTable Method (IModelDocExtension)

Gets whether a document has a design table.

 **.NET Syntax**

Visual Basic (Declaration)

Function HasDesignTable() As System.Boolean

Visual Basic (Usage) Copy Code

Dim instance As [IModelDocExtension](#)
Dim value As System.Boolean

value = instance.HasDesignTable()

C#

System.bool HasDesignTable()

C++/CLI

System.bool HasDesignTable();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if document has a design table, false if not (see **Remarks**)

 **Visual Basic for Applications (VBA) Syntax**

See [ModelDocExtension::HasDesignTable](#).

 **Example**

[Delete Design Table \(VBA\)](#)

 **Remarks**

This method always returns false for drawing documents because in drawing documents the design table is attached to the drawing view and not the document. Use [IView::HasDesignTable](#) to determine if a drawing view in a drawing document has a design table.

 **See Also**

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

 **Availability**

SOLIDWORKS 2004 FCS, Revision Number 12.0

 

[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : HasLegacyCThreads Method (IModelDocExtension)

Gets whether this model has legacy cosmetic threads.

 **.NET Syntax**

Visual Basic (Declaration)

Function HasLegacyCThreads() As System.Boolean

Visual Basic (Usage) Copy Code

```
Dim instance As IModelDocExtension
Dim value As System.Boolean

value = instance.HasLegacyCThreads()
```

C#

```
System.bool HasLegacyCThreads()
```

C++/CLI

```
System.bool HasLegacyCThreads();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the model has legacy cosmetic threads, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::HasLegacyCThreads](#).

Remarks

If this method returns true, you can call [IModelDocExtension::UpgradeLegacyCThreads](#) to upgrade cosmetic thread features to the latest cosmetic thread architecture.

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)
[CThread Interface](#)
[IView::GetCThreads Method \(\)](#)
[IView::GetFirstCThread Method \(\)](#)

Availability

SOLIDWORKS 2022 SP02, Revision Number 30.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasLegacyCustomProperties Property (IModelDocExtension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDocExtension Interface](#) : HasLegacyCustomProperties Property (IModelDocExtension)

Gets whether this model has legacy custom properties.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property HasLegacyCustomProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDocExtension
Dim value As System.Boolean
```

```
value = instance.HasLegacyCustomProperties
```

C#

```
System.bool HasLegacyCustomProperties {get;}
```

C++/CLI

```
property System.bool HasLegacyCustomProperties {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the model has legacy custom properties, false if not

Visual Basic for Applications (VBA) Syntax

See [ModelDocExtension::HasLegacyCustomProperties](#).

See Also

[IModelDocExtension Interface](#)
[IModelDocExtension Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31