

# SOLIDWORKS API (.NET VBA C#) — Reference

## (210/337): IModelWindow- IMoveCopyBodyFeatureData

SOLIDWORKS API Documentation (converted from CHM)

# IModelWindow (Type)

## IModelWindow Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelWindow Interface

Allows access to SOLIDWORKS model windows.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

#### Visual Basic (Declaration)

Public Interface IModelWindow

#### Visual Basic (Usage)

Dim instance As [IModelWindow](#)

#### C#

public interface IModelWindow

#### C++/CLI

public interface class IModelWindow

### Visual Basic for Applications (VBA) Syntax

See [ModelWindow](#).

### Example

[Switch Documents \(C#\)](#)  
[Switch Documents \(VB.NET\)](#)  
[Switch Documents \(VBA\)](#)

### Accessors

[IFrame::IGetModelWindows](#)  
[IFrame::ModelWindows](#)

### Access Diagram

[ModelWindow](#)

### See Also

[IModelWindow Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFrame::ShowModelWindow Method](#)  
[IFrame::GetModelWindowCount Method](#)

## IModelWindow Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelWindow Interface

For a list of all members of this type, see [IModelWindow members](#).

### Public Methods

| Name                     | Description                  |
|--------------------------|------------------------------|
| <a href="#">Activate</a> | Activates this model window. |



[Top](#)

## See Also

[IModelWindow Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFrame::ShowModelWindow Method](#)  
[IFrame::GetModelWindowCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IModelWindow Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelWindow Interface

The following tables list the members exposed by [IModelWindow](#).

## Public Properties

| Name                                                                                                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">HWnd</a>     | <p><b>Obsolete. Superseded by <a href="#">IModelWindow::HWndx64</a>.</b></p> <p>This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.</p> <p>The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.</p> <p>Gets the handle to this model window.</p> |
|  <a href="#">HWndx64</a>  | Gets the handle to this model window in 64-bit applications.                                                                                                                                                                                                                                                                                                                                                                                               |
|  <a href="#">ModelDoc</a> | Gets the model document in this model window.                                                                                                                                                                                                                                                                                                                                                                                                              |
|  <a href="#">Title</a>    | Gets the title of this model window.                                                                                                                                                                                                                                                                                                                                                                                                                       |

[Top](#)

## Public Methods

| Name                                                                                                         | Description                  |
|--------------------------------------------------------------------------------------------------------------|------------------------------|
|  <a href="#">Activate</a> | Activates this model window. |

[Top](#)

## See Also

[IModelWindow Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFrame::ShowModelWindow Method](#)  
[IFrame::GetModelWindowCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IModelWindow Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IModelWindow Interface

For a list of all members of this type, see [IModelWindow members](#).

## Public Properties

| Name                                                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">HWnd</a>    | <p><b>Obsolete. Superseded by <a href="#">IModelWindow::HWndx64</a>.</b></p> <p>This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.</p> <p>The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.</p> <p>Gets the handle to this model window.</p> |
|  <a href="#">HWndx64</a> | Gets the handle to this model window in 64-bit applications.                                                                                                                                                                                                                                                                                                                                                                                               |

|                                                                                   |                          |                                               |
|-----------------------------------------------------------------------------------|--------------------------|-----------------------------------------------|
|   | <a href="#">ModelDoc</a> | Gets the model document in this model window. |
|  | <a href="#">Title</a>    | Gets the title of this model window.          |

[Top](#)

## See Also

[IModelWindow Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFrame::ShowModelWindow Method](#)  
[IFrame::GetModelWindowCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Activate Method (IModelWindow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelWindow Interface](#) : Activate Method (IModelWindow)

Activates this model window.

## .NET Syntax

Visual Basic (Declaration)

```
Sub Activate()
```

Visual Basic (Usage)



```
Dim instance As IModelWindow  
  
instance.Activate()
```

C#

```
void Activate()
```

C++/CLI

```
void Activate();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [ModelWindow::Activate](#).

## See Also

[IModelWindow Interface](#)  
[IModelWindow Members](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## HWnd Property (IModelWindow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelWindow Interface](#) : HWnd Property (IModelWindow)

**Obsolete. Superseded by [IModelWindow::HWndx64](#).**

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Gets the handle to this model window.

## Visual Basic Syntax

### Visual Basic (Declaration)

ReadOnly Property HWnd As System.Integer

### Visual Basic (Usage)



```
Dim instance As IModelWindow  
Dim value As System.Integer
```

```
value = instance.HWnd
```

### C#

```
System.int HWnd {get;}
```

### C++/CLI

```
property System.int HWnd {  
    System.int get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Handle for this model window

## Visual Basic for Applications (VBA) Syntax

See [ModelWindow::HWnd](#).

## Example

[Switch Documents \(C#\)](#)  
[Switch Documents \(VB.NET\)](#)  
[Switch Documents \(VBA\)](#)

## Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

## See Also

[IModelWindow Interface](#)  
[IModelWindow Members](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## HWndx64 Property (IModelWindow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelWindow Interface](#) : HWndx64 Property (IModelWindow)

Gets the handle to this model window in 64-bit applications.

## Visual Basic Syntax

### Visual Basic (Declaration)

ReadOnly Property HWndx64 As System.Long

### Visual Basic (Usage)

```
Dim instance As IModelWindow
Dim value As System.Long

value = instance.HWndx64
```

C#

```
System.long HWndx64 {get;}
```

C++/CLI

```
property System.int64 HWndx64 {
    System.int64 get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Handle for this model window

### Visual Basic for Applications (VBA) Syntax

See [ModelWindow::HWndx64](#).

### Remarks

This property is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

### See Also

[IModelWindow Interface](#)  
[IModelWindow Members](#)  
[IModelWindow::HWnd Property](#)

### Availability

SOLIDWORKS 2010 SP4, Revision 18.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ModelDoc Property (IModelWindow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelWindow Interface](#) : ModelDoc Property (IModelWindow)

Gets the model document in this model window.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ModelDoc As ModelDoc2
```

Visual Basic (Usage)

```
Dim instance As IModelWindow
Dim value As ModelDoc2

value = instance.ModelDoc
```

C#

```
ModelDoc2 ModelDoc {get;}
```

C++/CLI

```
property ModelDoc2^ ModelDoc {
    ModelDoc2^ get();
}
```

}

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

[Model document](#) in this model window

### Visual Basic for Applications (VBA) Syntax

See [ModelWindow::ModelDoc](#).

### Example

[Switch Documents \(C#\)](#)  
[Switch Documents \(VB.NET\)](#)  
[Switch Documents \(VBA\)](#)

### See Also

[IModelWindow Interface](#)  
[IModelWindow Members](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Title Property (IModelWindow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelWindow Interface](#) : Title Property (IModelWindow)

Gets the title of this model window.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Title As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelWindow  
Dim value As System.String  
  
value = instance.Title
```

C#

```
System.string Title {get;}
```

C++/CLI

```
property System.String^ Title {  
    System.String^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Title of this model window

### Visual Basic for Applications (VBA) Syntax

See [ModelWindow::Title](#).

### Example

[Switch Documents \(C#\)](#)  
[Switch Documents \(VB.NET\)](#)  
[Switch Documents \(VBA\)](#)

## See Also

[IModelWindow Interface](#)  
[IModelWindow Members](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

# IMotionPlotAxisFeatureData (Type)

## IMotionPlotAxisFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotAxisFeatureData Interface

Allows access to a plot's x- and y-axis feature data.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IMotionPlotAxisFeatureData
```

Visual Basic (Usage)



```
Dim instance As IMotionPlotAxisFeatureData
```

C#

```
public interface IMotionPlotAxisFeatureData
```

C++/CLI

```
public interface class IMotionPlotAxisFeatureData
```

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotAxisFeatureData](#).

### Example

[Create Plots and Get Values \(C#\)](#)  
[Create Plots and Get Values \(VB.NET\)](#)  
[Create Plots and Get Values \(VBA\)](#)

### Remarks

Typical steps for creating a motion study's plot data and plot:

1. Open an assembly model and create the motion study.
2. Select the model's entities whose motion you want to measure.
3. Perform the calculations and get the results.
4. Create a plot feature data.
5. Create the plot's x-axis and y-axis feature data objects.
6. Set the type of plot.
7. Select the result component.
8. Set the entities for the x-axis and y-axis feature data objects.
9. Get the plot's x-axis and y-axis values and insert and display the plot.

Examine the examples to see the calls for these steps.

### Accessors

[ICosmosMotionStudyResults::CreatePlotXAxisFeatureData](#)  
[ICosmosMotionStudyResults::CreatePlotYAxisFeatureData](#)

### Access Diagram

[MotionPlotAxisFeatureData](#)

### See Also

[IMotionPlotAxisFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IMotionPlotFeatureData Interface](#)

## IMotionPlotAxisFeatureData Interface Members

[See Also](#) [Properties](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotAxisFeatureData Interface

The following tables list the members exposed by [IMotionPlotAxisFeatureData](#).

### Public Properties

| Name                                                                                                            | Description                                                 |
|-----------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
|  <a href="#">Component</a>     | Gets or sets the component of the result vector quantity.   |
|  <a href="#">Entities</a>      | Gets or sets the entities whose motion you want to measure. |
|  <a href="#">ReferencePart</a> | Gets or sets the result component.                          |
|  <a href="#">Type</a>          | Gets or sets the type of plot.                              |

[Top](#)

### See Also

[IMotionPlotAxisFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IMotionPlotFeatureData Interface](#)

## IMotionPlotAxisFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotAxisFeatureData Interface

For a list of all members of this type, see [IMotionPlotAxisFeatureData members](#).

### Public Properties

| Name                                                                                                              | Description                                                 |
|-------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
|  <a href="#">Component</a>     | Gets or sets the component of the result vector quantity.   |
|  <a href="#">Entities</a>      | Gets or sets the entities whose motion you want to measure. |
|  <a href="#">ReferencePart</a> | Gets or sets the result component.                          |
|  <a href="#">Type</a>          | Gets or sets the type of plot.                              |

[Top](#)

### See Also

[IMotionPlotAxisFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IMotionPlotFeatureData Interface](#)

## Component Property (IMotionPlotAxisFeatureData)

[See Also](#) [Example](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotAxisFeatureData Interface](#) : Component Property (IMotionPlotAxisFeatureData)

Gets or sets the component of the result vector quantity.

### .NET Syntax

Visual Basic (Declaration)

Property Component As System.Integer

Visual Basic (Usage)

```
Dim instance As IMotionPlotAxisFeatureData  
Dim value As System.Integer
```



```
instance.Component = value  
value = instance.Component
```

C#

```
System.int Component {get; set;}
```

C++/CLI

```
property System.int Component {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Component of the result vector quantity as defined in [swMotionPlotAxisComponent\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotAxisFeatureData::Component](#).

### Example

[Create Plots and Get Values \(C#\)](#)  
[Create Plots and Get Values \(VB.NET\)](#)  
[Create Plots and Get Values \(VBA\)](#)

### Remarks

Some motion study results, such as linear displacement/velocity results, are a 3D vector where x, y, and z can be the component of the quantity. For example, if you want the x component of the result vector, then set this property to swMotionPlotAxisComponent\_X.

### See Also

[IMotionPlotAxisFeatureData Interface](#)  
[IMotionPlotAxisFeatureData Members](#)  
[IMotionPlotAxisFeatureData::ReferencePart Property](#)

### Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Entities Property (IMotionPlotAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotAxisFeatureData Interface](#) : Entities Property (IMotionPlotAxisFeatureData)

Gets or sets the entities whose motion you want to measure.

### .NET Syntax

Visual Basic (Declaration)

Property Entities As System.Object

Visual Basic (Usage)



```
Dim instance As IMotionPlotAxisFeatureData  
Dim value As System.Object  
  
instance.Entities = value  
  
value = instance.Entities
```

C#

```
System.Object Entities {get; set;}
```

C++/CLI

```
property System.Object^ Entities {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Array of [entities](#) to measure

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotAxisFeatureData::Entities](#).

### Example

[Create Plots and Get Values \(C#\)](#)  
[Create Plots and Get Values \(VB.NET\)](#)  
[Create Plots and Get Values \(VBA\)](#)

### Remarks

See the SOLIDWORKS Motion Studies Help for details about which entities can be measured.

### See Also

[IMotionPlotAxisFeatureData Interface](#)  
[IMotionPlotAxisFeatureData Members](#)

### Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ReferencePart Property (IMotionPlotAxisFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotAxisFeatureData Interface](#) : ReferencePart Property (IMotionPlotAxisFeatureData)

Gets or sets the result component.

### .NET Syntax

Visual Basic (Declaration)

```
Property ReferencePart As Component2
```

Visual Basic (Usage)



```
Dim instance As IMotionPlotAxisFeatureData  
Dim value As Component2
```

```
instance.ReferencePart = value
```

```
value = instance.ReferencePart
```

C#

```
Component2 ReferencePart {get; set;}
```

C++/CLI

```
property Component2^ ReferencePart {  
    Component2^ get();
```

```
void set ( & Component2^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Result [component](#)

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotAxisFeatureData::ReferencePart](#).

### Remarks

A component is one of the vector elements. To define a vector, you need to specify a coordinate frame. You can select a part or a subassembly to define the vector with regards to the origin coordinate system of the selected part or subassembly. If nothing is selected, then the top assembly's coordinate system is used to define the vector.

### See Also

[IMotionPlotAxisFeatureData Interface](#)  
[IMotionPlotAxisFeatureData Members](#)

### Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Type Property (IMotionPlotAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotAxisFeatureData Interface](#) : Type Property (IMotionPlotAxisFeatureData)

Gets or sets the type of plot.

### .NET Syntax

#### Visual Basic (Declaration)

Property Type As System.Integer

#### Visual Basic (Usage)



```
Dim instance As IMotionPlotAxisFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

#### C#

```
System.int Type {get; set;}
```

#### C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Type of plot as defined in [swMotionPlotAxisType\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotAxisFeatureData::Type](#).

## Example

[Create Plots and Get Values \(C#\)](#)  
[Create Plots and Get Values \(VB.NET\)](#)  
[Create Plots and Get Values \(VBA\)](#)

## See Also

[IMotionPlotAxisFeatureData Interface](#)  
[IMotionPlotAxisFeatureData Members](#)

## Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

# IMotionPlotFeatureData (Type)

## IMotionPlotFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotFeatureData Interface

Allows access to a plot's feature data.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

#### Visual Basic (Declaration)

```
Public Interface IMotionPlotFeatureData
```

#### Visual Basic (Usage)

```
Dim instance As IMotionPlotFeatureData
```

#### C#

```
public interface IMotionPlotFeatureData
```

#### C++/CLI

```
public interface class IMotionPlotFeatureData
```

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotFeatureData](#).

### Example

[Create Plots and Get Values \(C#\)](#)  
[Create Plots and Get Values \(VB.NET\)](#)  
[Create Plots and Get Values \(VBA\)](#)

### Remarks

Typical steps for creating a motion study's plot data and plot:

1. Open an assembly model and create the motion study.
2. Select the model's entities whose motion you want to measure.
3. Perform the calculations and get the results.
4. Create a plot feature data.
5. Create the plot's x-axis and y-axis feature data objects.
6. Set the type of plot.
7. Select the result component.
8. Set the entities for the x-axis and y-axis feature data objects.
9. Get the plot's x-axis and y-axis values and insert and display the plot.

Examine the examples to see the calls for these steps.

### Accessors

[ICosmosMotionStudyResults::CreatePlotFeatureData](#)

### Access Diagram

[MotionPlotFeatureData](#)

### See Also

[IMotionPlotFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotFeatureData Interface

For a list of all members of this type, see [IMotionPlotFeatureData members](#).

 **Public Methods**

| Name                                                                                                        | Description                     |
|-------------------------------------------------------------------------------------------------------------|---------------------------------|
|  <a href="#">AddYAxis</a>  | Adds y-axis feature to a plot.  |
|  <a href="#">GetXAxis</a>  | Gets x-axis feature of a plot.  |
|  <a href="#">GetYAxis</a>  | Gets y-axis features of a plot. |
|  <a href="#">IGetYAxis</a> | Gets y-axis features of a plot. |

[Top](#)

 **See Also**

[IMotionPlotFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

**IMotionPlotFeatureData Interface Members**

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotFeatureData Interface

The following tables list the members exposed by [IMotionPlotFeatureData](#).

 **Public Properties**

| Name                                                                                                          | Description                                            |
|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
|  <a href="#">Visibility</a> | Gets or sets whether a plot's feature data is visible. |

[Top](#)

 **Public Methods**

| Name                                                                                                          | Description                     |
|---------------------------------------------------------------------------------------------------------------|---------------------------------|
|  <a href="#">AddYAxis</a>  | Adds y-axis feature to a plot.  |
|  <a href="#">GetXAxis</a>  | Gets x-axis feature of a plot.  |
|  <a href="#">GetYAxis</a>  | Gets y-axis features of a plot. |
|  <a href="#">IGetYAxis</a> | Gets y-axis features of a plot. |

[Top](#)

 **See Also**

[IMotionPlotFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

**IMotionPlotFeatureData Interface Properties**

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMotionPlotFeatureData Interface

For a list of all members of this type, see [IMotionPlotFeatureData members](#).

 **Public Properties**

| Name                                                                                                           | Description                                            |
|----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
|  <a href="#">Visibility</a> | Gets or sets whether a plot's feature data is visible. |

[Top](#)

## See Also

[IMotionPlotFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## AddYAxis Method (IMotionPlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotFeatureData Interface](#) : AddYAxis Method (IMotionPlotFeatureData)

Adds y-axis feature to a plot.

## .NET Syntax

### Visual Basic (Declaration)

```
Function AddYAxis( _  
    ByVal YAxis As MotionPlotAxisFeatureData _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IMotionPlotFeatureData  
Dim YAxis As MotionPlotAxisFeatureData  
Dim value As System.Boolean
```

```
value = instance.AddYAxis(YAxis)
```

### C#

```
System.bool AddYAxis(  
    MotionPlotAxisFeatureData YAxis  
)
```

### C++/CLI

```
System.bool AddYAxis(  
    & MotionPlotAxisFeatureData^ YAxis  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

[YAxis](#)  
[Y-axis feature data](#)

### Return Value

True if y-axis feature is added to the plot, false if not

## Visual Basic for Applications (VBA) Syntax

See [MotionPlotFeatureData::AddYAxis](#).

## See Also

[IMotionPlotFeatureData Interface](#)  
[IMotionPlotFeatureData Members](#)  
[IMotionPlotFeatureData::GetYAxis Method](#)  
[IMotionPlotFeatureData::!GetYAxis Method](#)

## Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetXAxis Method (IMotionPlotFeatureData)

[See Also](#)



Gets x-axis feature of a plot.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetXAxis() As Feature
```

### Visual Basic (Usage)



```
Dim instance As IMotionPlotFeatureData  
Dim value As Feature
```

```
value = instance.GetXAxis()
```

### C#

```
Feature GetXAxis()
```

### C++/CLI

```
Feature^ GetXAxis();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

[x-axis feature](#)

## Visual Basic for Applications (VBA) Syntax

See [MotionPlotFeatureData::GetXAxis](#).

## See Also

[IMotionPlotFeatureData Interface](#)  
[IMotionPlotFeatureData Members](#)  
[IMotionPlotFeatureData::GetYAxis Method](#)  
[IMotionPlotFeatureData::IGetYAxis Method](#)

## Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetYAxis Method (IMotionPlotFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IMotionPlotFeatureData Interface : GetYAxis Method (IMotionPlotFeatureData)

Gets y-axis features of a plot.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetYAxis() As System.Object
```

### Visual Basic (Usage)



```
Dim instance As IMotionPlotFeatureData  
Dim value As System.Object
```

```
value = instance.GetYAxis()
```

### C#

```
System.object GetYAxis()
```

C++/CLI

```
System.Object^ GetYAxis();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

[Array of y-axis features](#)

### Visual Basic for Applications (VBA) Syntax

See [MotionPlotFeatureData::GetYAxis](#).

### See Also

[IMotionPlotFeatureData Interface](#)  
[IMotionPlotFeatureData Members](#)  
[IMotionPlotFeatureData::IGetYAxis Method](#)  
[IMotionPlotFeatureData::GetXAxis Method](#)

### Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetYAxis Method (IMotionPlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotFeatureData Interface](#) : IGetYAxis Method (IMotionPlotFeatureData)

Gets y-axis features of a plot.

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetYAxis( _  
    ByVal Count As System.Integer _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IMotionPlotFeatureData  
Dim Count As System.Integer  
Dim value As Feature  
  
value = instance.IGetYAxis(Count)
```

C#

```
Feature IGetYAxis(  
    System.int Count  
)
```

C++/CLI

```
Feature^ IGetYAxis(  
&    System.int Count  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Count*  
Number of y-axis features

#### Return Value

- in-process, unmanaged C++: Pointer to an [array of y-axis features](#)
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

## See Also

[IMotionPlotFeatureData Interface](#)  
[IMotionPlotFeatureData Members](#)  
[IMotionPlotFeatureData::GetYAxis Method](#)  
[IMotionPlotFeatureData::GetXAxis Method](#)

## Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Visibility Property (IMotionPlotFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMotionPlotFeatureData Interface](#) : Visibility Property (IMotionPlotFeatureData)

Gets or sets whether a plot's feature data is visible.

## .NET Syntax

### Visual Basic (Declaration)

Property Visibility As System.Boolean

### Visual Basic (Usage)



```
Dim instance As IMotionPlotFeatureData  
Dim value As System.Boolean
```

```
instance.Visibility = value
```

```
value = instance.Visibility
```

### C#

```
System.bool Visibility {get; set;}
```

### C++/CLI

```
property System.bool Visibility {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True if the plot's feature data is visible, false if not

## Visual Basic for Applications (VBA) Syntax

See [MotionPlotFeatureData::Visibility](#).

## See Also

[IMotionPlotFeatureData Interface](#)  
[IMotionPlotFeatureData Members](#)

## Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

# IMouse (Type)

## IMouse Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMouse Interface

Allows access to the mouse in a model view.  
**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IMouse
```

Visual Basic (Usage)



```
Dim instance As IMouse
```

C#

```
public interface IMouse
```

C++/CLI

```
public interface class IMouse
```

### Visual Basic for Applications (VBA) Syntax

See [Mouse](#).

### Example

[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VBA\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(C#\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VB.NET\)](#)

### Remarks

Events are implemented with delegates in the Microsoft .NET Framework. See the [Overview](#) topic for a list of delegates for this interface.

### Accessors

[IModelView::GetMouse](#)

### Access Diagram

[Mouse](#)

### See Also

[IMouse Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

## IMouse Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMouse Interface

The following tables list the members exposed by [IMouse](#).

### Public Methods

| Name                                                                                                            | Description                                  |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------|
|  <a href="#">MouseWheelXYZ</a> | Zoom in or zoom out using the mouse.         |
|  <a href="#">Move</a>          | Moves the mouse pointer in the window space. |
|  <a href="#">MoveXYZ</a>       | Moves the mouse pointer in the model space.  |

[Top](#)

 **See Also**

[IMouse Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

**IMouse Interface Methods**

[See Also](#)

|                                                                                   |
|-----------------------------------------------------------------------------------|
|  |
| <a href="#">SolidWorks.Interop.sldworks Namespace</a> : IMouse Interface          |

For a list of all members of this type, see [IMouse members](#).

 **Public Methods**

| Name                                                                                                            | Description                                  |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------|
|  <a href="#">MouseWheelXYZ</a> | Zoom in or zoom out using the mouse.         |
|  <a href="#">Move</a>          | Moves the mouse pointer in the window space. |
|  <a href="#">MoveXYZ</a>       | Moves the mouse pointer in the model space.  |

[Top](#)

 **See Also**

[IMouse Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

**MouseWheelXYZ Method (IMouse)**

[See Also](#)

|                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   |
| <a href="#">SolidWorks.Interop.sldworks Namespace</a> > <a href="#">IMouse Interface</a> : MouseWheelXYZ Method (IMouse)                                                |

Zoom in or zoom out using the mouse.

 **.NET Syntax**

Visual Basic (Declaration)

```
Function MouseWheelXYZ(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Clicks As System.Integer, _  
    ByVal Flags As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMouse  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Clicks As System.Integer  
Dim Flags As System.Integer  
Dim value As System.Boolean  
  
value = instance.MouseWheelXYZ(X, Y, Z, Clicks, Flags)
```

C#

```
System.bool MouseWheelXYZ(
    System.double X,
    System.double Y,
    System.double Z,
    System.int Clicks,
    System.int Flags
)
```

C++/CLI

```
System.bool MouseWheelXYZ(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.int Clicks,
    & System.int Flags
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

X  
x coordinate where to move the pointer  
Y  
y coordinate where to move the pointer  
Z  
z coordinate where to move the pointer  
Clicks  
Number of clicks to zoom in and out; specify -120 to zoom in one click and specify 120 to zoom out  
Flags  
Mouse command as defined in [swMouse](#) (see **Remarks**)

#### Return Value

True if the operation succeeded, false if not

### Visual Basic for Applications (VBA) Syntax

See [Mouse::MouseWheelXYZ](#).

### Example

#### Visual Basic for Applications (VBA)

```
' -----
' Preconditions: Model document is open.
'
' Postconditions: Model is zoomed in and out.
' -----
```

#### Option Explicit

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swModelView As SldWorks.ModelView
Dim swMouse As SldWorks.Mouse

Sub main()

    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set swModelView = swModel.ActiveView
    Set swMouse = swModelView.GetMouse

    swMouse.MouseWheelXYZ 0, 0, 0, 120, swMouse_RightUp
    swMouse.MouseWheelXYZ 0, 0, 0, 120, swMouse_RightUp
    swMouse.MouseWheelXYZ 0, 0, 0, 240, swMouse_RightUp
    swMouse.MouseWheelXYZ 0, 0, 0, -120, swMouse_RightUp
    swMouse.MouseWheelXYZ 0, 0, 0, -240, swMouse_RightUp

End Sub
```

## Remarks

To use this method and access SOLIDWORKS commands, you must add a reference to **SOLIDWORKS version Commands type library** (substitute the actual SOLIDWORKS version number for *version*) or **SolidWorks.Interop.swcommands.dll**, typically installed in *install\_dir\api\redist*.

The coordinate system is the model's coordinate system.

## See Also

[IMouse Interface](#)  
[IMouse Members](#)

## Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Move Method (IMouse)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMouse Interface](#) : Move Method (IMouse)

Moves the mouse pointer in the window space.

## .NET Syntax

### Visual Basic (Declaration)

```
Function Move( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal Flags As System.Integer _  
    ) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IMouse  
Dim X As System.Integer  
Dim Y As System.Integer  
Dim Flags As System.Integer  
Dim value As System.Boolean  
  
value = instance.Move(X, Y, Flags)
```

### C#

```
System.bool Move(  
    System.int X,  
    System.int Y,  
    System.int Flags  
)
```

### C++/CLI

```
System.bool Move(  
& System.int X,  
& System.int Y,  
& System.int Flags  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*X*  
x coordinate where to move the pointer  
*Y*  
y coordinate where to move the pointer  
*Flags*  
Mouse command as defined in [swMouse\\_e](#) (see **Remarks**)

## Return Value

True if the pointer moves to the specified position, false if not

## Visual Basic for Applications (VBA) Syntax

See [Mouse::Move](#).

## Example

[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VBA\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(C#\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VB.NET\)](#)

## Remarks

To use this method and access SOLIDWORKS commands, you must add a reference to **SOLIDWORKS version Commands type library** (substitute the actual SOLIDWORKS version number for *version*) or **SolidWorks.Interop.swcommands.dll**, typically installed in *install\_dir\api\redist*.

In window space, the origin of the coordinate system is the upper-left corner of the window. Positive x is to the right; positive y is down.

## See Also

[IMouse Interface](#)  
[IMouse Members](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## MoveXYZ Method (IMouse)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMouse Interface](#) : MoveXYZ Method (IMouse)

Moves the mouse pointer in the model space.

## .NET Syntax

Visual Basic (Declaration)

```
Function MoveXYZ( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Flags As System.Integer _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IMouse  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Flags As System.Integer  
Dim value As System.Boolean  
  
value = instance.MoveXYZ(X, Y, Z, Flags)
```

C#



```
System.bool MoveXYZ(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.int Flags  
)
```

C++/CLI

```
System.bool MoveXYZ(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.int Flags  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

X  
x coordinate where to move the pointer

Y  
y coordinate where to move the pointer

Z  
z coordinate where to move the pointer

Flags  
Mouse command as defined in [swMouse\\_e](#) (see **Remarks**)

#### Return Value

True if the pointer moved to the specified position, false if not

### Visual Basic for Applications (VBA) Syntax

See [Mouse::MoveXYZ](#).

### Example

[Run SOLIDWORKS Commands and Synthesize Mouse Events \(C#\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VB.NET\)](#)  
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VBA\)](#)

### Remarks

To use this method and access SOLIDWORKS commands, you must add a reference to **SOLIDWORKS version Commands type library** (substitute the actual SOLIDWORKS version number for *version*) or **SolidWorks.Interop.swcommands.dll**, typically installed in *install\_dir\api\redist*.

The coordinate system is the model's coordinate system.

### See Also

[IMouse Interface](#)  
[IMouse Members](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

# IMoveCopyBodyFeatureData (Type)

## IMoveCopyBodyFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveCopyBodyFeatureData Interface

Allows access to a move/copy body feature.  
**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IMoveCopyBodyFeatureData
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData
```

C#

```
public interface IMoveCopyBodyFeatureData
```

C++/CLI

```
public interface class IMoveCopyBodyFeatureData
```

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData](#).

### Example

[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

### Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

### Access Diagram

[MoveCopyBodyFeatureData](#)

### See Also

[IMoveCopyBodyFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::InsertMoveCopyBody2 Method](#)

## IMoveCopyBodyFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveCopyBodyFeatureData Interface

The following tables list the members exposed by [IMoveCopyBodyFeatureData](#).

### Public Properties

| Name                   | Description                                         |
|------------------------|-----------------------------------------------------|
| <a href="#">Bodies</a> | Gets or sets the bodies to move or rotate and copy. |
| <a href="#">Copy</a>   | Gets or sets whether to copy the selected bodies.   |

|                                                                                                                            |                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
|  <a href="#">NumberOfCopies</a>           | Gets or sets the number of copies.                                                                            |
|  <a href="#">RotationOriginX</a>          | Gets or sets the x coordinate for the origin about which to rotate the selected bodies.                       |
|  <a href="#">RotationOriginY</a>          | Gets or sets the y coordinate for the origin about which to rotate the selected bodies.                       |
|  <a href="#">RotationOriginZ</a>          | Gets or sets the z coordinate for the origin about which to rotate the selected bodies.                       |
|  <a href="#">TransformReferenceEntity</a> | Gets or sets the entity to reference when moving or rotating the selected bodies.                             |
|  <a href="#">TransformType</a>            | Gets or sets whether to move or rotate the selected bodies.                                                   |
|  <a href="#">TransformValue</a>           | Gets or sets the distance or angle by which to move or rotate the selected bodies based on the selected edge. |
|  <a href="#">TransformX</a>               | Gets or sets the x coordinate for either moving or rotating the selected bodies.                              |
|  <a href="#">TransformY</a>               | Gets or sets the y coordinate for either moving or rotating the selected bodies.                              |
|  <a href="#">TransformZ</a>               | Gets the z coordinate for either moving or rotating the selected bodies.                                      |
|  <a href="#">TranslateToVertex</a>        | Gets or sets the entity to which to move the selected bodies.                                                 |

[Top](#)

## Public Methods

| Name                                                                                                                       | Description                                                                |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  <a href="#">AccessSelections</a>         | Gains access to selections that define this feature.                       |
|  <a href="#">AddMate</a>                  | Adds a mate to the feature.                                                |
|  <a href="#">GetBodiesCount</a>           | Gets the number of bodies to move or rotate and copy.                      |
|  <a href="#">IAddMate</a>                 | Adds a mate to the feature.                                                |
|  <a href="#">IGetBodies</a>               | Gets the bodies to move or rotate and copy.                                |
|  <a href="#">ISetBodies</a>               | Sets the bodies to move or rotate and copy.                                |
|  <a href="#">ReleaseSelectionAccess</a> | Releases access to the selections that define this move/copy body feature. |

[Top](#)

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::InsertMoveCopyBody2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IMoveCopyBodyFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMoveCopyBodyFeatureData Interface

For a list of all members of this type, see [IMoveCopyBodyFeatureData members](#).

## Public Methods

| Name                                                                                                                       | Description                                                                |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  <a href="#">AccessSelections</a>       | Gains access to selections that define this feature.                       |
|  <a href="#">AddMate</a>                | Adds a mate to the feature.                                                |
|  <a href="#">GetBodiesCount</a>         | Gets the number of bodies to move or rotate and copy.                      |
|  <a href="#">IAddMate</a>               | Adds a mate to the feature.                                                |
|  <a href="#">IGetBodies</a>             | Gets the bodies to move or rotate and copy.                                |
|  <a href="#">ISetBodies</a>             | Sets the bodies to move or rotate and copy.                                |
|  <a href="#">ReleaseSelectionAccess</a> | Releases access to the selections that define this move/copy body feature. |

[Top](#)

## See Also

## IMoveCopyBodyFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveCopyBodyFeatureData Interface

For a list of all members of this type, see [IMoveCopyBodyFeatureData members](#).

### Public Properties

| Name                                     | Description                                                                                                   |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">Bodies</a>                   | Gets or sets the bodies to move or rotate and copy.                                                           |
| <a href="#">Copy</a>                     | Gets or sets whether to copy the selected bodies.                                                             |
| <a href="#">NumberOfCopies</a>           | Gets or sets the number of copies.                                                                            |
| <a href="#">RotationOriginX</a>          | Gets or sets the x coordinate for the origin about which to rotate the selected bodies.                       |
| <a href="#">RotationOriginY</a>          | Gets or sets the y coordinate for the origin about which to rotate the selected bodies.                       |
| <a href="#">RotationOriginZ</a>          | Gets or sets the z coordinate for the origin about which to rotate the selected bodies.                       |
| <a href="#">TransformReferenceEntity</a> | Gets or sets the entity to reference when moving or rotating the selected bodies.                             |
| <a href="#">TransformType</a>            | Gets or sets whether to move or rotate the selected bodies.                                                   |
| <a href="#">TransformValue</a>           | Gets or sets the distance or angle by which to move or rotate the selected bodies based on the selected edge. |
| <a href="#">TransformX</a>               | Gets or sets the x coordinate for either moving or rotating the selected bodies.                              |
| <a href="#">TransformY</a>               | Gets or sets the y coordinate for either moving or rotating the selected bodies.                              |
| <a href="#">TransformZ</a>               | Gets the z coordinate for either moving or rotating the selected bodies.                                      |
| <a href="#">TranslateToVertex</a>        | Gets or sets the entity to which to move the selected bodies.                                                 |

[Top](#)

### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::InsertMoveCopyBody2 Method](#)

## AccessSelections Method (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : AccessSelections Method (IMoveCopyBodyFeatureData)

Gains access to selections that define this feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IMoveCopyBodyFeatureData  
Dim PTopDoc As ModelDoc2  
Dim PComponent As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(PTopDoc, PComponent)
```

C#



```
System.bool AccessSelections(  
    ModelDoc2 PTopDoc,  
    Component2 PComponent  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ PTopDoc,  
& Component2^ PComponent  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*PTopDoc*

Top-level document (see **Remarks**)

*PComponent*

Component in which the feature is to be modified (see **Remarks**)

#### Return Value

True if the selections were successfully accessed, false if not

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::AccessSelections](#).

### Example

[Copy and Rotate Body Using Edge \(VBA\)](#)  
[Move and Copy Body By Setting Transforms \(VBA\)](#)  
[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)  
[Set Bodies for Move/Copy \(C#\)](#)  
[Set Bodies for Move/Copy \(VB.NET\)](#)  
[Set Bodies for Move/Copy \(VBA\)](#)

### Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                        |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>PTopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>PComponent argument is <i>Nothing</i> or null</li></ul>                                          |
| Assembly                    | <ul style="list-style-type: none"><li>PTopDoc is the IModelDoc2 object for the assembly</li><li>PComponent argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMoveCopyBodyFeatureData::ReleaseSelectionAccess](#) if you did not

### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## AddMate Method (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : AddMate Method (IMoveCopyBodyFeatureData)

Adds a mate to the feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function AddMate( _
    ByVal MateEntVar As System.Object, _
    ByVal MateTypeFromEnum As System.Integer, _
    ByVal AlignFromEnum As System.Integer, _
    ByVal Distance As System.Double, _
    ByVal Angle As System.Double, _
    ByRef ErrorStatus As System.Integer _
) As Mate2
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData
Dim MateEntVar As System.Object
Dim MateTypeFromEnum As System.Integer
Dim AlignFromEnum As System.Integer
Dim Distance As System.Double
Dim Angle As System.Double
Dim ErrorStatus As System.Integer
Dim value As Mate2
```

```
value = instance.AddMate(MateEntVar, MateTypeFromEnum, AlignFromEnum, Distance, Angle, ErrorStatus)
```

C#

```
Mate2 AddMate(
    System.object MateEntVar,
    System.int MateTypeFromEnum,
    System.int AlignFromEnum,
    System.double Distance,
    System.double Angle,
    out System.int ErrorStatus
)
```

C++/CLI

```
Mate2^ AddMate(
    & System.Object^ MateEntVar,
    & System.int MateTypeFromEnum,
    & System.int AlignFromEnum,
    & System.double Distance,
    & System.double Angle,
    & [Out] System.int ErrorStatus
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*MateEntVar*  
Array of the entities to use to create a mate (see **Remarks**)

*MateTypeFromEnum*  
Type of mate as defined in [swMateType\\_e](#)

*AlignFromEnum*  
Type of alignment as defined in [swMateAlign\\_e](#)

*Distance*  
Distance to use with distance or limit mates

*Angle*  
Angle to use with angle mates

*ErrorStatus*  
Success or error as defined by [swAddMateError\\_e](#)

#### Return Value

[Mate](#)

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::AddMate](#).

### Remarks

You can specify *MateEntVar* with either an array of mate entities or null. If you specify null, then before calling this method, you must call [IModelDocExtension::SelectById2](#) with a selection mark of 1 to select each mate entity.

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::IAddMate Method](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Bodies Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : Bodies Property (IMoveCopyBodyFeatureData)

Gets or sets the bodies to move or rotate and copy.

## .NET Syntax

Visual Basic (Declaration)

Property Bodies As System.Object

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Object
```

```
instance.Bodies = value
```

```
value = instance.Bodies
```

C#

```
System.object Bodies {get; set;}
```

C++/CLI

```
property System.Object^ Bodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Array of [bodies](#) to move or rotate and copy

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::Bodies](#).

## Example

[Set Bodies for Move/Copy \(C#\)](#)  
[Set Bodies for Move/Copy \(VB.NET\)](#)  
[Set Bodies for Move/Copy \(VBA\)](#)

## Remarks

Use:

- [IMoveCopyBodyFeatureData::Copy](#) to get whether to copy the bodies
- [IMoveCopyBodyFeatureData::TransformType](#) to get whether to move or rotate the bodies

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::GetBodiesCount Method](#)  
[IMoveCopyBodyFeatureData::IGetBodies Method](#)  
[IMoveCopyBodyFeatureData::ISetBodies Method](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Copy Property (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : Copy Property (IMoveCopyBodyFeatureData)

Gets or sets whether to copy the selected bodies.

## .NET Syntax

Visual Basic (Declaration)

Property Copy As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Boolean
```

```
instance.Copy = value
```

```
value = instance.Copy
```

C#

```
System.bool Copy {get; set;}
```

C++/CLI

```
property System.bool Copy {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to copy the selected bodies, false to not

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::Copy](#).

## Remarks

To get or set the number of copies of the selected bodies to create, call [IMoveCopyBodyFeatureData::NumberOfCopies](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

## GetBodiesCount Method (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : GetBodiesCount Method (IMoveCopyBodyFeatureData)

Gets the number of bodies to move or rotate and copy.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Integer
```

```
value = instance.GetBodiesCount()
```

C#

```
System.int GetBodiesCount()
```

C++/CLI

```
System.int GetBodiesCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of bodies to move or rotate and copy

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::GetBodiesCount](#).

### Example

[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

### Remarks

Call this method before calling [IMoveCopyBodyFeatureData::IGetBodies](#).

### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData.Bodies Property](#)  
[IMoveCopyBodyFeatureData.ISetBodies Method](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

## IAddMate Method (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : IAddMate Method (IMoveCopyBodyFeatureData)

Adds a mate to the feature.

### .NET Syntax

```

Function IAddMate( _
    ByVal Nsize As System.Integer, _
    ByRef MateEntArr As System.Object, _
    ByVal MateTypeFromEnum As System.Integer, _
    ByVal AlignFromEnum As System.Integer, _
    ByVal Distance As System.Double, _
    ByVal Angle As System.Double, _
    ByRef ErrorStatus As System.Integer _
) As Mate2

```



```

Dim instance As IMoveCopyBodyFeatureData
Dim Nsize As System.Integer
Dim MateEntArr As System.Object
Dim MateTypeFromEnum As System.Integer
Dim AlignFromEnum As System.Integer
Dim Distance As System.Double
Dim Angle As System.Double
Dim ErrorStatus As System.Integer
Dim value As Mate2

```

```

value = instance.IAddMate(Nsize, MateEntArr, MateTypeFromEnum, AlignFromEnum, Distance, Angle,
ErrorStatus)

```

```

Mate2 IAddMate(
    System.int Nsize,
    ref System.object MateEntArr,
    System.int MateTypeFromEnum,
    System.int AlignFromEnum,
    System.double Distance,
    System.double Angle,
    out System.int ErrorStatus
)

```

```

Mate2^ IAddMate(
    & System.int Nsize,
    & System.Object^% MateEntArr,
    & System.int MateTypeFromEnum,
    & System.int AlignFromEnum,
    & System.double Distance,
    & System.double Angle,
    & [Out] System.int ErrorStatus
)

```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

##### *Nsize*

Number of entities to use to create a mate

##### *MateEntArr*

Array of entities to sue to create a mate (see **Remarks**)

##### *MateTypeFromEnum*

Type of mate as defined in [swMateType\\_e](#)

##### *AlignFromEnum*

Type of alignment as defined in [swMateAlign\\_e](#)

##### *Distance*

Distance to use with distance or limit mates

##### *Angle*

Angle to use with angle mates

##### *ErrorStatus*

Success or error as defined by [swAddMateError\\_e](#)

#### Return Value

[Mate](#)

See [MoveCopyBodyFeatureData::IAddMate](#).

## Remarks

You can specify MateEntArr with either an array of mate entities or null. If you specify null, then before calling this method, you must call [IModelDocExtension::SelectById2](#) with a selection mark of 1 to select each mate entity.

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::AddMate Method](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetBodies Method (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : IGetBodies Method (IMoveCopyBodyFeatureData)

Gets the bodies to move or rotate and copy.

## .NET Syntax

### Visual Basic (Declaration)

```
Function IGetBodies( _  
    ByVal NCount As System.Integer _  
) As Body2
```

### Visual Basic (Usage)

```
Dim instance As IMoveCopyBodyFeatureData  
Dim NCount As System.Integer  
Dim value As Body2  
  
value = instance.IGetBodies(NCount)
```

### C#

```
Body2 IGetBodies(  
    System.int NCount  
)
```

### C++/CLI

```
Body2^ IGetBodies(  
& System.int NCount  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*NCount*

Number of bodies to move or rotate and copy

### Return Value

- in-process, unmanaged C++: Pointer to an array of [bodies](#) of size Count
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

## Remarks

Call [IMoveCopyBodyFeatureData::GetBodiesCount](#) before calling this method.

Use:

- [IMoveCopyBodyFeatureData::Copy](#) to get whether to copy the bodies
- [IMoveCopyBodyFeatureData::TransformType](#) to get whether to move or rotate the bodies

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::ISetBodies Method](#)  
[IMoveCopyBodyFeatureData::Bodies Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ISetBodies Method (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : ISetBodies Method (IMoveCopyBodyFeatureData)

Sets the bodies to move or rotate and copy.

## .NET Syntax

Visual Basic (Declaration)

```
Sub ISetBodies( _  
    ByVal NCount As System.Integer, _  
    ByRef PBodies As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim NCount As System.Integer  
Dim PBodies As Body2  
  
instance.ISetBodies(NCount, PBodies)
```

C#

```
void ISetBodies(  
    System.int NCount,  
    ref Body2 PBodies  
)
```

C++/CLI

```
void ISetBodies(  
& System.int NCount,  
& Body2^% PBodies  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*NCount*

Number of bodies to move or rotate and copy

*PBodies*

- in-process, unmanaged C++: Pointer to an array of [bodies](#) of size Count

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

## Remarks

Use:

- [IMoveCopyBodyFeatureData::Copy](#) to get whether to copy the bodies
- [IMoveCopyBodyFeatureData::TransformType](#) to get whether to move or rotate the bodies

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::GetBodiesCount Method](#)  
[IMoveCopyBodyFeatureData::IGetBodies Method](#)  
[IMoveCopyBodyFeatureData::Bodies Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## NumberOfCopies Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : NumberOfCopies Property (IMoveCopyBodyFeatureData)

Gets or sets the number of copies.

## .NET Syntax

### Visual Basic (Declaration)

Property NumberOfCopies As System.Integer

### Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Integer
```

```
instance.NumberOfCopies = value
```

```
value = instance.NumberOfCopies
```

### C#

```
System.int NumberOfCopies {get; set;}
```

### C++/CLI

```
property System.int NumberOfCopies {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Number of copies

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::NumberOfCopies](#).

## Example

[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

## Remarks

Call this property after calling [IMoveCopyBodyFeatureData::Copy](#).

## See Also

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ReleaseSelectionAccess Method (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : ReleaseSelectionAccess Method (IMoveCopyBodyFeatureData)

Releases access to the selections that define this move/copy body feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

### Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
instance.ReleaseSelectionAccess()
```

### C#

```
void ReleaseSelectionAccess()
```

### C++/CLI

```
void ReleaseSelectionAccess();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::ReleaseSelectionAccess](#).

## Example

[Copy and Rotate Body Using Edge \(VBA\)](#)  
[Move and Copy Body By Setting Transforms \(VBA\)](#)  
[Set Bodies for Move/Copy \(VBA\)](#)  
[Set Bodies for Move/Copy \(C#\)](#)  
[Set Bodies for Move/Copy \(VBA\)](#)

## Remarks

[IMoveCopyBodyFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#) if you did.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RotationOriginX Property (IMoveCopyBodyFeatureData)

[See Also](#)



Gets or sets the x coordinate for the origin about which to rotate the selected bodies.

## .NET Syntax

### Visual Basic (Declaration)

Property RotationOriginX As System.Double

### Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Double
```

```
instance.RotationOriginX = value
```

```
value = instance.RotationOriginX
```

### C#

```
System.double RotationOriginX {get; set;}
```

### C++/CLI

```
property System.double RotationOriginX {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

x coordinate

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::RotationOriginX](#).

## Remarks

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be NULL.

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)

[IMoveCopyBodyFeatureData Members](#)

[IMoveCopyBodyFeatureData::RotationOriginY Property](#)

[IMoveCopyBodyFeatureData::RotationOriginZ Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RotationOriginY Property (IMoveCopyBodyFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IMoveCopyBodyFeatureData Interface](#) : RotationOriginY Property (IMoveCopyBodyFeatureData)

Gets or sets the y coordinate for the origin about which to rotate the selected bodies.

## .NET Syntax

### Visual Basic (Declaration)

Property RotationOriginY As System.Double

```
Dim instance As IMoveCopyBodyFeatureData
Dim value As System.Double

instance.RotationOriginY = value

value = instance.RotationOriginY
```

C#

```
System.double RotationOriginY {get; set;}
```

C++/CLI

```
property System.double RotationOriginY {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

y coordinate

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::RotationOriginY](#).

### Remarks

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be NULL.

See [Accessing Selections that Define Features](#) for additional details on using this method.

### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::RotationOriginX Property](#)  
[IMoveCopyBodyFeatureData::RotationOriginZ Property](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RotationOriginZ Property (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : RotationOriginZ Property (IMoveCopyBodyFeatureData)

Gets or sets the z coordinate for the origin about which to rotate the selected bodies.

### .NET Syntax

Visual Basic (Declaration)

```
Property RotationOriginZ As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IMoveCopyBodyFeatureData
Dim value As System.Double

instance.RotationOriginZ = value

value = instance.RotationOriginZ
```

C#

```
System.double RotationOriginZ {get; set;}
```

C++/CLI

```
property System.double RotationOriginZ {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

z coordinate

### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::RotationOriginZ](#).

### Remarks

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be NULL.

See [Accessing Selections that Define Features](#) for additional details on using this method.

### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::RotationOriginX Property](#)  
[IMoveCopyBodyFeatureData::RotationOriginY Property](#)

### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransformReferenceEntity Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformReferenceEntity Property (IMoveCopyBodyFeatureData)

Gets or sets the entity to reference when moving or rotating the selected bodies.

### .NET Syntax

Visual Basic (Declaration)

```
Property TransformReferenceEntity As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Object
```

```
instance.TransformReferenceEntity = value
```

```
value = instance.TransformReferenceEntity
```

C#

```
System.object TransformReferenceEntity {get; set;}
```

C++/CLI

```
property System.Object^ TransformReferenceEntity {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Pointer to one of these entities:

- [Coordinate system](#)
- [Edge](#)
- [Sketch point](#)
- [Vertex](#)

#### Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformReferenceEntity](#).

#### Example

[Copy and Rotate Body Using Edge \(VBA\)](#)  
[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

#### Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

#### See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

#### Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

### TransformType Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformType Property (IMoveCopyBodyFeatureData)

Gets or sets whether to move or rotate the selected bodies.

#### .NET Syntax

Visual Basic (Declaration)

Property TransformType As System.Integer

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Integer
```

```
instance.TransformType = value
```

```
value = instance.TransformType
```

C#

```
System.int TransformType {get; set;}
```

C++/CLI

```
property System.int TransformType {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Move or rotate the selected bodies as defined in [swMoveCopyBodyFeatureTransformType\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformType](#).

## Example

[Copy and Rotate Body Using Edge \(VBA\)](#)  
[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

## Remarks

Use this property to get or set the transform type before setting any of these properties:

- [IMoveCopyBodyFeatureData::TransformX](#)
- [IMoveCopyBodyFeatureData::TransformY](#)
- [IMoveCopyBodyFeatureData::TransformZ](#)

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## TransformValue Property (IMoveCopyBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformValue Property (IMoveCopyBodyFeatureData)

Gets or sets the distance or angle by which to move or rotate the selected bodies based on the selected edge.

## .NET Syntax

Visual Basic (Declaration)

Property TransformValue As System.Double

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Double
```

```
instance.TransformValue = value
```

```
value = instance.TransformValue
```

C#

```
System.double TransformValue {get; set;}
```

C++/CLI

```
property System.double TransformValue {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Distance in meters or angle in radians

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformValue](#).

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransformX Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformX Property (IMoveCopyBodyFeatureData)

Gets or sets the x coordinate for either moving or rotating the selected bodies.

## .NET Syntax

Visual Basic (Declaration)

Property TransformX As System.Double

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Double
```

```
instance.TransformX = value
```

```
value = instance.TransformX
```

C#

```
System.double TransformX {get; set;}
```

C++/CLI

```
property System.double TransformX {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

x coordinate in meters for moving or radians for rotating

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformX](#).

## Example

[Copy and Rotate Body Using Edge \(VBA\)](#)  
[Move and Copy Body By Setting Transforms \(VBA\)](#)  
[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

## Remarks

Use [IMoveCopyBodyFeatureData::TransformType](#) to get or set the transform type before setting this property.

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be:

- Nothing or null if moving the selected bodies.
  - or -
- a vertex if rotating the selected bodies.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::TransformY Property](#)  
[IMoveCopyBodyFeatureData::TransformZ Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransformY Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformY Property (IMoveCopyBodyFeatureData)

Gets or sets the y coordinate for either moving or rotating the selected bodies.

## .NET Syntax

Visual Basic (Declaration)

```
Property TransformY As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData
Dim value As System.Double
```

```
instance.TransformY = value
```

```
value = instance.TransformY
```

C#

```
System.double TransformY {get; set;}
```

C++/CLI

```
property System.double TransformY {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Meters for moving or radians for rotating

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformY](#).

## Example

[Move and Copy Body By Setting Transforms \(VBA\)](#)

## Remarks

Use [IMoveCopyBodyFeatureData::TransformType](#) to get or set the transform type before setting this property.

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be:

- NULL if moving the selected bodies
  - or -
- a vertex if rotating the selected bodies

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::TransformX Property](#)  
[IMoveCopyBodyFeatureData::TransformZ Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TransformZ Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TransformZ Property (IMoveCopyBodyFeatureData)

Gets the z coordinate for either moving or rotating the selected bodies.

## .NET Syntax

Visual Basic (Declaration)

```
Property TransformZ As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Double
```

```
instance.TransformZ = value
```

```
value = instance.TransformZ
```

C#

```
System.double TransformZ {get; set;}
```

C++/CLI

```
property System.double TransformZ {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Meters for moving or radians for rotating

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TransformZ](#).

## Example

[Move and Copy Body By Setting Transforms \(VBA\)](#)

## Remarks

Use [IMoveCopyBodyFeatureData::TransformType](#) to get or set the transform type before setting this property.

[IMoveCopyBodyFeatureData::TransformReferenceEntity](#) must be:

- NULL if moving the selected bodies
- or -
- a vertex if rotating the selected bodies

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)  
[IMoveCopyBodyFeatureData::TransformX Property](#)  
[IMoveCopyBodyFeatureData::TransformY Property](#)

## Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TranslateToVertex Property (IMoveCopyBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveCopyBodyFeatureData Interface](#) : TranslateToVertex Property (IMoveCopyBodyFeatureData)

Gets or sets the entity to which to move the selected bodies.

## .NET Syntax

### Visual Basic (Declaration)

Property TranslateToVertex As System.Object

### Visual Basic (Usage)



```
Dim instance As IMoveCopyBodyFeatureData  
Dim value As System.Object
```

```
instance.TranslateToVertex = value
```

```
value = instance.TranslateToVertex
```

### C#

```
System.object TranslateToVertex {get; set;}
```

### C++/CLI

```
property System.Object^ TranslateToVertex {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

[Coordinate system](#), [sketch point](#), or [vertex](#) to which to move the selected bodies

## Visual Basic for Applications (VBA) Syntax

See [MoveCopyBodyFeatureData::TranslateToVertex](#).

## Example

[Modify Move/Copy Body Using Vertex \(C#\)](#)  
[Modify Move/Copy Body Using Vertex \(VB.NET\)](#)  
[Modify Move/Copy Body Using Vertex \(VBA\)](#)

## Remarks

A coordinate system, sketch point, or vertex must be selected from which to move the selected bodies.

See [Accessing Selections that Define Features](#) for additional details on using this method.

## See Also

[IMoveCopyBodyFeatureData Interface](#)  
[IMoveCopyBodyFeatureData Members](#)

