

SOLIDWORKS API (NET VBA C#) — Reference (211/337): IMoveFaceFeatureData-IMultiJogLeader

SOLIDWORKS API Documentation (converted from CHM)

IMoveFaceFeatureData (Type)

IMoveFaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveFaceFeatureData Interface

Allows access to Move Face features.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMoveFaceFeatureData

Visual Basic (Usage) [Copy Code](#)

Dim instance As [IMoveFaceFeatureData](#)

C#

public interface IMoveFaceFeatureData

C++/CLI

public interface class IMoveFaceFeatureData

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData](#).

Example

- [Translate Move Face Feature \(C#\)](#)
- [Translate Move Face Feature \(VB.NET\)](#)
- [Translate Move Face Feature \(VBA\)](#)
- [Create and Modify Move Face Feature \(C#\)](#)
- [Create and Modify Move Face Feature \(VB.NET\)](#)
- [Create and Modify Move Face Feature \(VBA\)](#)
- [Change Direction Reference of Move Face Feature \(VBA\)](#)
- [Change Faces of Move Face Feature \(VBA\)](#)
- [Rotate Move Face Feature \(VB.NET\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[MoveFaceFeatureData](#)

See Also

- [IMoveFaceFeatureData Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [ICavityFeatureData Interface](#)
- [ICoreFeatureData Interface](#)
- [IPartingLineFeatureData Interface](#)
- [IPartingSurfaceFeatureData Interface](#)
- [IRuledSurfaceFeatureData Interface](#)
- [IShutoffSurfaceFeatureData Interface](#)
- [IToolingSplitFeatureData Interface](#)
- [IFeatureManager::InsertMoveFace2 Method](#)
- [IFeatureManager::InsertMoveFace2 Method](#)

IMoveFaceFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveFaceFeatureData Interface

For a list of all members of this type, see [IMoveFaceFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this Move Face feature.
 GetDirectionReference	Gets the direction reference for this Move Face feature.
 GetEndConditionEntity	Gets the entity to which the Move Face feature is translated.
 GetFacesCount	Gets the number of faces for this Move Face feature.
 GetFromEntity	Gets the entity from which the face of the Move Face feature is translated.
 IGetFaces	Gets the faces for this Move Face feature.
 IGetTriadRotationParameters	Gets the rotation parameters for this Move Face feature.
 IGetTriadTranslationParameters	Gets the translation parameters for this Move Face feature.
 ISetFaces	Sets the faces for this Move Face feature.
 ISetTriadRotationParameters	Sets the rotation parameters for this Move Face feature.
 ISetTriadTranslationParameters	Sets the translation parameters for this Move Face feature.
 ReleaseSelectionAccess	Releases access to the selections that define this Move Face feature.
 SetDirectionReference	Sets the direction reference for the Move Face feature.
 SetEndConditionEntity	Sets the entity to which the face of the Move Face feature is translated.
 SetFromEntity	Sets the entity from which the face of the Move Face feature is translated.

[Top](#)

 See Also

- [IMoveFaceFeatureData Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [ICavityFeatureData Interface](#)
- [ICoreFeatureData Interface](#)
- [IPartingLineFeatureData Interface](#)
- [IPartingSurfaceFeatureData Interface](#)
- [IRuledSurfaceFeatureData Interface](#)
- [IShutOffSurfaceFeatureData Interface](#)
- [IToolingSplitFeatureData Interface](#)
- [IFeatureManager::InsertMoveFace2 Method](#)
- [IFeatureManager::InsertMoveFace2 Method](#)

IMoveFaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IMoveFaceFeatureData Interface](#)

The following tables list the members exposed by [IMoveFaceFeatureData](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle for the Move Face feature.
 Distance	Gets or sets the offset distance of this offset or translated Move Face feature.
 EndCondition	Gets the end condition for this translated Move Face feature.
 Faces	Gets or sets the faces for the Move Face feature.
 MoveType	Gets or sets the type of Move Face feature.
 OffsetDistance	Gets or sets the offset distance of this translated Move Face feature that has an end condition of Offset From Surface .
 ReverseDirection	Gets or sets whether to reverse the direction of the Move Face feature.
 TriadRotationParameters	Gets or sets the rotation parameters for this Move Face feature.
 TriadTranslationParameters	Gets or sets the translation parameters for this Move Face feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this Move Face feature.
 GetDirectionReference	Gets the direction reference for this Move Face feature.
 GetEndConditionEntity	Gets the entity to which the Move Face feature is translated.
 GetFacesCount	Gets the number of faces for this Move Face feature.
 GetFromEntity	Gets the entity from which the face of the Move Face feature is translated.
 IGetFaces	Gets the faces for this Move Face feature.
 IGetTriadRotationParameters	Gets the rotation parameters for this Move Face feature.
 IGetTriadTranslationParameters	Gets the translation parameters for this Move Face feature.
 ISetFaces	Sets the faces for this Move Face feature.
 ISetTriadRotationParameters	Sets the rotation parameters for this Move Face feature.
 ISetTriadTranslationParameters	Sets the translation parameters for this Move Face feature.
 ReleaseSelectionAccess	Releases access to the selections that define this Move Face feature.
 SetDirectionReference	Sets the direction reference for the Move Face feature.
 SetEndConditionEntity	Sets the entity to which the face of the Move Face feature is translated.
 SetFromEntity	Sets the entity from which the face of the Move Face feature is translated.

[Top](#)

See Also

[IMoveFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IFeatureManager::InsertMoveFace2 Method](#)
[IFeatureManager::InsertMoveFace2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMoveFaceFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMoveFaceFeatureData Interface

For a list of all members of this type, see [IMoveFaceFeatureData members](#).

Public Properties

Name	Description
 Angle	Gets or sets the angle for the Move Face feature.
 Distance	Gets or sets the offset distance of this offset or translated Move Face feature.
 EndCondition	Gets the end condition for this translated Move Face feature.
 Faces	Gets or sets the faces for the Move Face feature.
 MoveType	Gets or sets the type of Move Face feature.
 OffsetDistance	Gets or sets the offset distance of this translated Move Face feature that has an end condition of Offset From Surface .
 ReverseDirection	Gets or sets whether to reverse the direction of the Move Face feature.
 TriadRotationParameters	Gets or sets the rotation parameters for this Move Face feature.
 TriadTranslationParameters	Gets or sets the translation parameters for this Move Face feature.

[Top](#)

See Also

[IMoveFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IFeatureManager::InsertMoveFace2 Method](#)
[IFeatureManager::InsertMoveFace2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : AccessSelections Method (IMoveFaceFeatureData)

Gains access to selections that define this Move Face feature.

VB.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::AccessSelections](#).

Example

[Change Direction Reference of Move Face Feature \(VBA\)](#)
[Change Faces of Move Face Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMoveFaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : Angle Property (IMoveFaceFeatureData)

Gets or sets the angle for the Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians at which to draft the faces

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::Angle](#).

Example

[Rotate Move Face Feature \(VB.NET\)](#)
[Rotate Move Face Feature \(VBA\)](#)
[Rotate Move Face Feature \(C#\)](#)

Remarks

The property is valid only if [IMoveFaceFeatureData::MoveType](#) is [swMoveFaceType_e.swMoveFaceTypeRotate](#).

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Distance Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : Distance Property (IMoveFaceFeatureData)

Gets or sets the offset distance of this offset or translated Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance of this offset or translated Move Face feature (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::Distance](#).

Example

[Translate Move Face Feature \(C#\)](#)
[Translate Move Face Feature \(VB.NET\)](#)
[Translate Move Face Feature \(VBA\)](#)

Remarks

To find out whether the Move Face feature was offset or translated, use [IMoveFaceFeatureData::MoveType](#).

If setting the offset distance of a translated Move Face feature that has an [end condition](#) of **Offset From Surface**, then use [IMoveFaceFeatureData::OffsetDistance](#). For all other end conditions, use [IMoveFaceFeatureData::Distance](#) to set the offset distance.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndCondition Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : EndCondition Property (IMoveFaceFeatureData)

Gets the end condition for this translated Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property EndCondition As System.Integer

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Integer
```

```
instance.EndCondition = value
```

```
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition as defined in [swEndConditions](#) [e](#)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::EndCondition](#).

Example

[Translate Move Face Feature \(C#\)](#)
[Translate Move Face Feature \(VB.NET\)](#)
[Translate Move Face Feature \(VBA\)](#)

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetEndConditionEntity Method \(\)](#)
[IMoveFaceFeatureData::SetEndConditionEntity Method \(\)](#)
[IMoveFaceFeatureData::Distance Property \(\)](#)
[IMoveFaceFeatureData::OffsetDistance Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Faces Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : Faces Property (IMoveFaceFeatureData)

Gets or sets the faces for the Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) to move

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::Faces](#).

Example

[Change Faces of Move Face Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetFacesCount Method](#)
[IMoveFaceFeatureData::IGetFaces Method](#)
[IMoveFaceFeatureData::ISetFaces Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDirectionReference Method (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : GetDirectionReference Method (IMoveFaceFeatureData)

Gets the direction reference for this Move Face feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDirectionReference( _  
    ByRef DirRefType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim DirRefType As System.Integer  
Dim value As System.Object  
  
value = instance.GetDirectionReference(DirRefType)
```

C#

```
System.object GetDirectionReference(  
    out System.int DirRefType  
)
```

C++/CLI

```
System.Object^ GetDirectionReference(  
& [Out] System.int DirRefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DirRefType

Direction reference type as defined in [swSelectType_e](#)

Return Value

Direction reference:

- If a translated, then a [plane](#), [planar face](#), [linear edge](#), or [reference axis](#)
- If rotated, then a [linear edge](#) or [reference axis](#)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::GetDirectionReference](#).

Example

[Change Direction Reference of Move Face Feature \(VBA\)](#)

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::SetDirectionReference Method](#)
[IMoveFaceFeatureData::ReverseDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

GetEndConditionEntity Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : GetEndConditionEntity Method (IMoveFaceFeatureData)

Gets the entity to which the Move Face feature is translated.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndConditionEntity() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Object  
  
value = instance.GetEndConditionEntity()
```

C#

```
System.object GetEndConditionEntity()
```

C++/CLI

```
System.Object^ GetEndConditionEntity();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Body](#), [face](#), [plane](#), [surface](#), or [vertex](#) to which the face of the Move Face feature is translated (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::GetEndConditionEntity](#).

Remarks

The type of entity depends on the type of [end condition](#).

End condition	Type of entity
Up To Vertex	Vertex
Up To Surface or Offset From Surface	Face, plane, or surface
Up To Body	Body or surface

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::SetEndConditionEntity Method \(\)](#)
[IMoveFaceFeatureData::GetFromEntity Method \(\)](#)
[IMoveFaceFeatureData::SetFromEntity Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesCount Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : GetFacesCount Method (IMoveFaceFeatureData)

Gets the number of faces for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Integer
```

```
value = instance.GetFacesCount()
```

C#

```
System.int GetFacesCount()
```

C++/CLI

```
System.int GetFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::GetFacesCount](#).

Remarks

Call this method before calling [IMoveFaceFeatureData::IGetFaces](#) to dimension that method's array.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::ISetFaces Method](#)
[IMoveFaceFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFromEntity Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : GetFromEntity Method (IMoveFaceFeatureData)

Gets the entity from which the face of the Move Face feature is translated.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFromEntity( _  
    ByRef FromEntity As System.Object, _  
    ByRef Type As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim FromEntity As System.Object  
Dim Type As System.Integer
```

```
instance.GetFromEntity(FromEntity, Type)
```

C#

```
void GetFromEntity(  
    out System.object FromEntity,  
    out System.int Type  
)
```

C++/CLI

```
void GetFromEntity(  
& [Out] System.Object^ FromEntity,  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromEntity

[Face](#), [plane](#), or [surface](#) from which the face of the Move Face feature is translated

Type

Type of end condition as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::GetFromEntity](#).

See Also

[IMoveFaceFeatureData Interface](#)

[IMoveFaceFeatureData Members](#)

[IMoveFaceFeatureData::SetFromEntity Method \(\)](#)

[IMoveFaceFeatureData::GetEndConditionEntity Method \(\)](#)

[IMoveFaceFeatureData::SetEndConditionEntity Method \(\)](#)

[IMoveFaceFeatureData::EndCondition Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaces Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : IGetFaces Method (IMoveFaceFeatureData)

Gets the faces for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)

```
Dim instance As IMoveFaceFeatureData  
Dim Count As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces(Count)
```

C#

```
Face2 IGetFaces(  
    System.int Count  
)
```

C++/CLI



```
Face2^ IGetFaces(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of faces to move

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) to move
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IMoveFaceFeatureData::GetFacesCount](#) before calling this method to dimension the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::ISetFaces Method](#)
[IMoveFaceFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTriadRotationParameters Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : IGetTriadRotationParameters Method (IMoveFaceFeatureData)

Gets the rotation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriadRotationParameters() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Double  
  
value = instance.IGetTriadRotationParameters()
```

C#

```
System.double IGetTriadRotationParameters()
```

C++/CLI

```
System.double IGetTriadRotationParameters();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of six doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The first three doubles returned are the X, Y, and Z rotation origin parameters. The remaining three doubles returned are the X, Y, and Z rotation angle parameters.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::ISetTriadRotationParameters Method](#)
[IMoveFaceFeatureData::TriadRotationParameters Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTriadTranslationParameters Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : IGetTriadTranslationParameters Method (IMoveFaceFeatureData)

Gets the translation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriadTranslationParameters() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Double
```

```
value = instance.IGetTriadTranslationParameters()
```

C#

```
System.double IGetTriadTranslationParameters()
```

C++/CLI

```
System.double IGetTriadTranslationParameters();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of three doubles that are the X, Y, and Z translation parameters
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::ISetTriadTranslationParameters Method](#)
[IMoveFaceFeatureData::TriadTranslationParameters Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFaces Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : ISetFaces Method (IMoveFaceFeatureData)

Sets the faces for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim Count As System.Integer  
Dim EntIn As Face2  
  
instance.ISetFaces(Count, EntIn)
```

C#

```
void ISetFaces(  
    System.int Count,  
    ref Face2 EntIn  
)
```

C++/CLI

```
void ISetFaces(  
& System.int Count,  
& Face2^% EntIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces to move

EntIn

- in-process, unmanaged C++: Pointer to an array of [faces](#) to move
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetFacesCount Method](#)
[IMoveFaceFeatureData::IGetFaces Method](#)
[IMoveFaceFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTriadRotationParameters Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : ISetTriadRotationParameters Method (IMoveFaceFeatureData)

Sets the rotation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetTriadRotationParameters( _  
    ByRef RotationParameters As System.Double _  
)
```

```
Dim instance As IMoveFaceFeatureData
Dim RotationParameters As System.Double

instance.ISetTriadRotationParameters(RotationParameters)
```

C#

```
void ISetTriadRotationParameters(
    ref System.double RotationParameters
)
```

C++/CLI

```
void ISetTriadRotationParameters(
    & System.double% RotationParameters
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RotationParameters

- in-process, unmanaged C++: pointer to an array of six doubles for the rotation parameters (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The first three doubles are the X, Y, and Z rotation origin parameters. The remaining three doubles are the X, Y, and Z rotation angle parameters.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::IGetTriadRotationParameters Method](#)
[IMoveFaceFeatureData::TriadRotationParameters Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTriadTranslationParameters Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : ISetTriadTranslationParameters Method (IMoveFaceFeatureData)

Sets the translation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetTriadTranslationParameters( _
    ByRef TranslationParameters As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As IMoveFaceFeatureData
Dim TranslationParameters As System.Double

instance.ISetTriadTranslationParameters(TranslationParameters)
```

C#

```
void ISetTriadTranslationParameters(  
    ref System.double TranslationParameters  
)
```

C++/CLI

```
void ISetTriadTranslationParameters(  
&    System.double% TranslationParameters  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TranslationParameters

- in-process, unmanaged C++: pointer to an array of three doubles for the X, Y, and Z translation parameters
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IMoveFaceFeatureData Interface](#)

[IMoveFaceFeatureData Members](#)

[IMoveFaceFeatureData::IGetTriadTranslationParameters Method](#)

[IMoveFaceFeatureData::TriadTranslationParameters Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MoveType Property (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : MoveType Property (IMoveFaceFeatureData)

Gets or sets the type of Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MoveType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Integer
```

```
instance.MoveType = value
```

```
value = instance.MoveType
```

C#

```
System.int MoveType {get; set;}
```

C++/CLI

```
property System.int MoveType {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of move as defined in [swMoveFaceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::MoveType](#).

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : OffsetDistance Property (IMoveFaceFeatureData)

Gets or sets the offset distance of this translated Move Face feature that has an end condition of **Offset From Surface**.

.NET Syntax

Visual Basic (Declaration)

Property OffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance of this translated Move Face feature that has an end condition of **Offset From Surface** (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::OffsetDistance](#).

Example

[Translate Move Face Feature \(C#\)](#)
[Translate Move Face Feature \(VB.NET\)](#)
[Translate Move Face Feature \(VBA\)](#)

Remarks

For all other end conditions, use [IMoveFaceFeatureData::Distance](#) to get or set the offset distance of a translated Move Face feature.

To find out the type of:

- Move Face feature, use [IMoveFaceFeatureData::MoveType](#).
- end condition, use [IMoveFaceFeatureData::EndCondition](#).

See Also

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : ReleaseSelectionAccess Method (IMoveFaceFeatureData)

Releases access to the selections that define this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::ReleaseSelectionAccess](#).

Remarks

[IMoveFaceFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the Move Face feature. Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : ReverseDirection Property (IMoveFaceFeatureData)

Gets or sets whether to reverse the direction of the Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction, false to not

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::ReverseDirection](#).

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetDirectionReference Method](#)
[IMoveFaceFeatureData::SetDirectionReference Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDirectionReference Method (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : SetDirectionReference Method (IMoveFaceFeatureData)

Sets the direction reference for the Move Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDirectionReference( _  
    ByVal LpDispatch As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim LpDispatch As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetDirectionReference(LpDispatch)
```

C#

```
System.bool SetDirectionReference(  
    System.object LpDispatch  
)
```

C++/CLI

```
System.bool SetDirectionReference(  
& System.Object^ LpDispatch  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpDispatch

Direction reference:

- If a translated, then a [plane](#), [planar face](#), [linear edge](#), or [reference axis](#)
- If rotated, then a [linear edge](#) or [reference axis](#)

Return Value

True if the direction reference is set, false if not

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::SetDirectionReference](#).

Example

[Change Direction Reference of Move Face Feature \(VBA\)](#)

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetDirectionReference Method](#)
[IMoveFaceFeatureData::ReverseDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEndConditionEntity Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : SetEndConditionEntity Method (IMoveFaceFeatureData)

Sets the entity to which the face of the Move Face feature is translated.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndConditionEntity( _  
    ByVal EndEntity As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim EndEntity As System.Object  
  
instance.SetEndConditionEntity(EndEntity)
```

C#

```
void SetEndConditionEntity(  
    System.object EndEntity  
)
```

C++/CLI

```
void SetEndConditionEntity(  
&    System.Object^ EndEntity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EndEntity
[Body](#), [face](#), [plane](#), [surface](#), or [vertex](#) to which the face of the Move Face feature is translated (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::SetEndConditionEntity](#).

 Remarks

The type of entity depends on the type of [end condition](#).

End condition	Type of entity
Up To Vertex	Vertex
Up To Surface or Offset From Surface	Face, plane, or surface
Up To Body	Body or surface

 See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::GetEndConditionEntity Method \(\)](#)
[IMoveFaceFeatureData::GetFromEntity Method \(\)](#)
[IMoveFaceFeatureData::SetFromEntity Method \(\)](#)

 Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFromEntity Method (IMoveFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : SetFromEntity Method (IMoveFaceFeatureData)

Sets the entity from which the face of the Move Face feature is translated.

 .NET Syntax

Visual Basic (Declaration)

```
Sub SetFromEntity( _  
    ByVal FromEntity As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData  
Dim FromEntity As System.Object  
  
instance.SetFromEntity(FromEntity)
```

C#

```
void SetFromEntity(  
    System.object FromEntity
```

```
)
```

C++/CLI

```
void SetFromEntity(  
& System.Object^ FromEntity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromEntity

[Face](#), [plane](#), or [surface](#) from which the face of the Move Face feature is translated

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::SetFromEntity](#).

See Also

[IMoveFaceFeatureData Interface](#)

[IMoveFaceFeatureData Members](#)

[IMoveFaceFeatureData::SetFromEntity Method \(\)](#)

[IMoveFaceFeatureData::GetEndConditionEntity Method \(\)](#)

[IMoveFaceFeatureData::SetEndConditionEntity Method \(\)](#)

[IMoveFaceFeatureData::EndCondition Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TriadRotationParameters Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : TriadRotationParameters Property (IMoveFaceFeatureData)

Gets or sets the rotation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property TriadRotationParameters As System.Object

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData
```

```
Dim value As System.Object
```

```
instance.TriadRotationParameters = value
```

```
value = instance.TriadRotationParameters
```

C#

```
System.object TriadRotationParameters {get; set;}
```

C++/CLI

```
property System.Object^ TriadRotationParameters {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of six doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::TriadRotationParameters](#).

Example

[Rotate Move Face Feature \(VB.NET\)](#)
[Rotate Move Face Feature \(VBA\)](#)
[Rotate Move Face Feature \(C#\)](#)

Remarks

The first three doubles are the X, Y, and Z rotation origin parameters. The remaining three doubles are the X, Y, and Z rotation angle parameters.

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::IGetTriadRotationParameters Method](#)
[IMoveFaceFeatureData::ISetTriadRotationParameters Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TriadTranslationParameters Property (IMoveFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMoveFaceFeatureData Interface](#) : TriadTranslationParameters Property (IMoveFaceFeatureData)

Gets or sets the translation parameters for this Move Face feature.

.NET Syntax

Visual Basic (Declaration)

Property TriadTranslationParameters As System.Object

Visual Basic (Usage)



```
Dim instance As IMoveFaceFeatureData
Dim value As System.Object

instance.TriadTranslationParameters = value
value = instance.TriadTranslationParameters
```

C#

```
System.object TriadTranslationParameters {get; set;}
```

C++/CLI

```
property System.Object^ TriadTranslationParameters {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of three doubles, which are the X, Y, and Z translation parameters

Visual Basic for Applications (VBA) Syntax

See [MoveFaceFeatureData::TriadTranslationParameters](#).

Example

[Translate Move Face Feature \(VB.NET\)](#)
[Translate Move Face Feature \(VBA\)](#)
[Translate Move Face Feature \(C#\)](#)
[Create and Modify Move Face Feature \(C#\)](#)

See Also

[IMoveFaceFeatureData Interface](#)
[IMoveFaceFeatureData Members](#)
[IMoveFaceFeatureData::IGetTriadTranslationParameters Method](#)
[IMoveFaceFeatureData::ISetTriadTranslationParameters Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IMultiJogLeader (Type)

IMultiJogLeader Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMultiJogLeader Interface

Allows access to display information for multi-jog leaders.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMultiJogLeader
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
```

C#

```
public interface IMultiJogLeader
```

C++/CLI

```
public interface class IMultiJogLeader
```

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader](#).

Example

[Get Multi-jog Leader Data \(C#\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(VBA\)](#)

Accessors

[IDrawingDoc::InsertMultiJogLeader3](#) and [IDrawingDoc::InsertMultiJogLeader3](#)
[IMultiJogLeader::GetNext](#) and [IMultiJogLeader::IGetNext](#)
[IView::GetFirstMultiJogLeader](#) and [IView::IGetFirstMultiJogLeader](#)
[IView::GetMultiJogLeaders](#) and [IView::IGetMultiJogLeaders](#)

Access Diagram

[MultiJogLeader](#)

See Also

[IMultiJogLeader Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

IMultiJogLeader Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMultiJogLeader Interface

For a list of all members of this type, see [IMultiJogLeader members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this multi-jog leader.
 GetArrowHeadAtIndex	Gets information for the specified arrow head.
 GetArrowHeadCount	Gets the number of arrowheads in the multi-jog leader.
 GetDisplayData	Gets the display data for this multi-jog leader.
 GetLineAtIndex	Gets the symbol information for the specified line.
 GetLineCount	Gets the number of line items in this multi-jog leader.
 GetNext	Gets the next leader in the view.
 IGetAnnotation	Gets the annotation for this multi-jog leader.
 IGetArrowHeadAtIndex	Gets the information for the specified arrow head.
 IGetDisplayData	Gets the display data for this multi-jog leader.
 IGetLineAtIndex	Gets the symbol information for the specified line.
 IGetNext	Gets the next leader in the view.

[Top](#)

See Also

[IMultiJogLeader Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMultiJogLeader Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMultiJogLeader Interface

The following tables list the members exposed by [IMultiJogLeader](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this multi-jog leader.
 GetArrowHeadAtIndex	Gets information for the specified arrow head.
 GetArrowHeadCount	Gets the number of arrowheads in the multi-jog leader.
 GetDisplayData	Gets the display data for this multi-jog leader.
 GetLineAtIndex	Gets the symbol information for the specified line.
 GetLineCount	Gets the number of line items in this multi-jog leader.
 GetNext	Gets the next leader in the view.
 IGetAnnotation	Gets the annotation for this multi-jog leader.
 IGetArrowHeadAtIndex	Gets the information for the specified arrow head.
 IGetDisplayData	Gets the display data for this multi-jog leader.
 IGetLineAtIndex	Gets the symbol information for the specified line.
 IGetNext	Gets the next leader in the view.

[Top](#)

See Also

[IMultiJogLeader Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (IMultiJogLeader)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetAnnotation Method (IMultiJogLeader)

Gets the annotation for this multi-jog leader.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
Dim value As System.Object

value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)
[Get Multi-jog Leader Data \(C#\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(VBA\)](#)

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::IGetAnnotation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadAtIndex Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetArrowHeadAtIndex Method (IMultiJogLeader)

Gets information for the specified arrow head.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IMultiJogLeader
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.Object GetArrowHeadAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetArrowHeadAtIndex](#).

Remarks

The return value is the following array of doubles :

[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

- *arrowHeadPt*[3] = XYZ arrow head tip location.
- *arrowHeadDir*[3] = XYZ arrow head direction.
- *arrowHeadWidth* = arrow head width where the width is measured along the arrow head direction.
- *arrowHeadHeight* = arrow head height.
- *arrowHeadStyle* = arrow head style; for example, open, closed, and so on. See [swArrowStyle_e](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetArrowHeadCount Method](#)
[IMultiJogLeader::IGetArrowHeadAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadCount Method (IMultiJogLeader)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetArrowHeadCount Method (IMultiJogLeader)

Gets the number of arrowheads in the multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
Dim value As System.Integer

value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrowheads

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetArrowHeadCount](#).

Example

[Get Multi-jog Leader Data \(C#\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(VBA\)](#)

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetArrowHeadAtIndex Method](#)
[IMultiJogLeader::!GetArrowHeadAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayData Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetDisplayData Method (IMultiJogLeader)

Gets the display data for this multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
Dim value As System.Object

value = instance.GetDisplayData()
```

C#

```
System.object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#) for this multi-jog leader

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetDisplayData](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetDisplayData Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineAtIndex Method (IMultiJogLeader)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetLineAtIndex Method (IMultiJogLeader)

Gets the symbol information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLineAtIndex(Index)
```

C#

```
System.object GetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the line

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetLineAtIndex](#).

Example

[Get Multi-jog Leader Data \(C#\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(VBA\)](#)

Remarks

The return value is the following array of doubles:

[*lineType*, *startPt*[3], *endPt*[3]]

where:

- *lineType* = line type. See [swLineTypes_e](#).
- *startPt*[3] = XYZ line start point.
- *endPt*[3] = XYZ line end point.

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetLineCount Method](#)
[IMultiJogLeader::IGetLineAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineCount Method (IMultiJogLeader)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetLineCount Method (IMultiJogLeader)

Gets the number of line items in this multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
Dim value As System.Integer

value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of line items

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetLineCount](#).

Example

[Get Multi-jog Leader Data \(C#\)](#)
[Get Multi-jog Leader Data \(VB.NET\)](#)
[Get Multi-jog Leader Data \(VBA\)](#)

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetLineAtIndex Method](#)
[IMultiJogLeader::!GetLineAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : GetNext Method (IMultiJogLeader)

Gets the next leader in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [leader](#)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::GetNext](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::!GetNext Method](#)
[IView::!GetFirstMultiJogLeader Method](#)
[IView::GetFirstMultiJogLeader Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IGetAnnotation Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : IGetAnnotation Method (IMultiJogLeader)

Gets the annotation for this multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::IGetAnnotation](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetAnnotation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IGetArrowHeadAtIndex Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : IGetArrowHeadAtIndex Method (IMultiJogLeader)

Gets the information for the specified arrow head.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim Index As System.Integer
```

```
Dim value As System.Double  
  
value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arrow head where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles :

[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

- *arrowHeadPt*[3] = XYZ arrow head tip location.
- *arrowHeadDir*[3] = XYZ arrow head direction.
- *arrowHeadWidth* = arrow head width where the width is measured along the arrow head direction.
- *arrowHeadHeight* = arrow head height.
- *arrowHeadStyle* = arrow head style; for example, open, closed, and so on. See [swArrowStyle_e](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetArrowHeadAtIndex Method](#)
[IMultiJogLeader::GetArrowHeadCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDisplayData Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : IGetDisplayData Method (IMultiJogLeader)

Gets the display data for this multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDisplayData() As DisplayData
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader
Dim value As DisplayData

value = instance.IGetDisplayData()
```

C#

```
DisplayData IGetDisplayData()
```

C++/CLI

```
DisplayData^ IGetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#) for this multi-jog leader

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::IGetDisplayData](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetDisplayData Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineAtIndex Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : IGetLineAtIndex Method (IMultiJogLeader)

Gets the symbol information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles:

[*lineType*, *startPt*[3], *endPt*[3]]

where:

- *lineType* = line type. See [swLineTypes_e](#).
- *startPt*[3] = XYZ line start point.
- *endPt*[3] = XYZ line end point.

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetLineAtIndex Method](#)
[IMultiJogLeader::GetLineCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (IMultiJogLeader)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMultiJogLeader Interface](#) : IGetNext Method (IMultiJogLeader)

Gets the next leader in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As MultiJogLeader
```

Visual Basic (Usage)



```
Dim instance As IMultiJogLeader  
Dim value As MultiJogLeader
```

```
value = instance.IGetNext()
```

C#

```
MultiJogLeader IGetNext()
```

C++/CLI

```
MultiJogLeader^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [leader](#)

Visual Basic for Applications (VBA) Syntax

See [MultiJogLeader::!GetNext](#).

See Also

[IMultiJogLeader Interface](#)
[IMultiJogLeader Members](#)
[IMultiJogLeader::GetNext Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0