

SOLIDWORKS API (.NET VBA C#) — Reference

(213/337): INote (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

I^{Note} (part 2 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAngleAtIndex Method (I^{Note})

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [I^{Note} Interface](#) : GetTextAngleAtIndex Method (I^{Note})

Gets the text angle for the specified piece of text in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 1

Return Value

Text angle for the specified piece of text in radians; angle is measured CCW from the X axis

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextAngleAtIndex](#).

Remarks

Before using this method, use [I^{Note}::GetTextCount](#). To set the specified text's angle, use [I^{Annotation}::SetTextFormat](#) or [I^{Annotation}::!SetTextFormat](#).

See Also

[I^{Note} Interface](#)
[I^{Note} Members](#)
[I^{Note}::AddText Method](#)
[I^{Note}::GetText Method](#)
[I^{Note}::GetTextAtIndex Method](#)
[I^{Note}::GetTextFontAtIndex Method](#)
[I^{Note}::GetTextHeightAtIndex Method](#)
[I^{Note}::GetTextInvertAtIndex Method](#)
[I^{Note}::GetTextJustification Method](#)
[I^{Note}::GetTextJustificationAtIndex Method](#)
[I^{Note}::GetTextLineSpacingAtIndex Method](#)
[I^{Note}::GetTextOffsetAtIndex Method](#)

[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAtIndex Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextAtIndex Method (INote)

Gets the specified text in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex(  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the text; index begins at 1

Return Value

Text string

Visual Basic for Applications (VBA) Syntax

See [INote::GetTextAtIndex](#).

Example

[Change Note Text \(VBA\)](#)

Remarks

Before calling this method, call with [INote::GetTextCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextCount Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextCount Method (INote)

Gets the number of text items in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextCount](#).

Example

[Change Note Text \(VBA\)](#)

Remarks

After calling this method, call any of the following methods:

- [INote::GetTextAtIndex](#)

- [INote::GetTextHeightAtIndex](#)
- [INote::GetTextPositionAtIndex](#) or [INote::IGetTextPositionAtIndex](#)
- [INote::GetTextAngleAtIndex](#)
- [INote::GetTextRefPositionAtIndex](#)
- [INote::GetTextInvertAtIndex](#)
- [INote::GetTextFontAtIndex](#)
- [INote::GetTextLineSpacingAtIndex](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::INote::AddText Method](#)
[INote::INote::GetText Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFontAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextFontAtIndex Method (INote)

Gets the font used by the specified text item in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFontAtIndex( _
    ByVal Index As System.Integer _
) As System.String
```

Visual Basic (Usage)



```
Dim instance As INote
Dim Index As System.Integer
Dim value As System.String

value = instance.GetTextFontAtIndex(Index)
```

C#

```
System.string GetTextFontAtIndex(
    System.int Index
)
```

C++/CLI

```
System.String^ GetTextFontAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 0

Return Value

Font name used by this note

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextFontAtIndex](#).

Remarks

Before using this method, use [INote::GetTextCount](#). To set the specified text's font, use [IAnnotation::SetTextFormat](#) or [IAnnotation::!SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::!GetTextFormat Method](#)
[INote::!GetTextOffsetAtIndex Method](#)
[INote::!GetTextPoint2 Method](#)
[INote::!GetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextFormat Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextFormat Method (INote)

Obsolete. Superseded by [IAnnotation::GetTextFormat](#) and [IAnnotation::!GetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetTextFormat()
```

C#

```
System.object GetTextFormat()
```

C++/CLI

```
System.Object^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFormatAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextFormatAtIndex Method (INote)

Obsolete. Superseded by [IAnnotation::GetTextFormat](#) and [IAnnotation::IGetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormatAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextFormatAtIndex(Index)
```

C#

```
System.object GetTextFormatAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextFormatAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextFormatAtIndex](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextHeightAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextHeightAtIndex Method (INote)

Gets the text height for the specified piece of text in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 0

Return Value

Text height for the specified piece of text in meters

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextHeightAtIndex](#).

Remarks

Before using this method, use [INote::GetTextCount](#). To set the specified text's font, use [IAnnotation::SetTextFormat](#) or [IAnnotation::!SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::!GetTextOffsetAtIndex Method](#)
[INote::!GetTextPoint2 Method](#)
[INote::!GetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextInvertAtIndex Method (INote)

Gets the specified text item's invert flag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 0

Return Value

Text item's invert flag

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextInvertAtIndex](#).

Remarks

The invert flag specifies whether the text has been mirrored (reflected) about the X axis. Any reflection is applied after text rotation.

Before using this method, use [INote::GetTextCount](#). To set the specified text's font, use [IAnnotation::SetTextFormat](#) or [IAnnotation::!SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::!GetTextOffsetAtIndex Method](#)
[INote::!GetTextPoint2 Method](#)
[INote::!GetTextPositionAtIndex Method](#)

[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextJustification Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextJustification Method (INote)

Gets the text justification of a standard note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextJustification() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Integer

value = instance.GetTextJustification()
```

C#

```
System.int GetTextJustification()
```

C++/CLI

```
System.int GetTextJustification();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text justification as defined in [swTextJustification](#) e

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextJustification](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextJustificationAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextJustificationAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text justification for the specified text item in a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextJustificationAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextJustificationAtIndex(Index)
```

C#

```
System.int GetTextJustificationAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextJustificationAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index position of the text

Return Value

Text justification as defined in [swTextJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextJustificationAtIndex](#).

Remarks

Before using this method, use [INote::GetCompoundTextCount](#) to get the number of text items.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)

[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::!GetExtent Method](#)
[INote::!GetExtentAtIndex Method](#)
[INote::!GetSketch Method](#)
[INote::!GetTextOffsetAtIndex Method](#)
[INote::!GetTextPoint2 Method](#)
[INote::!GetTextPositionAtIndex Method](#)
[INote::!IsCompoundNote Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextFormat Method](#)
[INote::SetTextFormatAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextLineSpacingAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextLineSpacingAtIndex Method (INote)

Gets the line spacing for this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextLineSpacingAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextLineSpacingAtIndex(Index)
```

C#

```
System.double GetTextLineSpacingAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextLineSpacingAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

1-based index position of the text

Return Value

Line spacing

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextLineSpacingAtIndex](#).

Remarks

Before using this method, use [INote::GetTextCount](#).

To set this the specified text's line spacing, use [IAnnotation::SetTextFormat](#) and [IAnnotation::!SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextOffsetAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextOffsetAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item's offset relative to note's text point in a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextOffsetAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextOffsetAtIndex(Index)
```

C#

```
System.object GetTextOffsetAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextOffsetAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the text

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextOffsetAtIndex](#).

Remarks

Before using this method, use [INote::GetCompoundTextCount](#) to get the number of text items.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextPoint Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextPoint Method (INote)

Obsolete. Superseded by [INote::GetTextPoint2](#) or [INote::IGetTextPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetTextPoint()
```

C#

```
System.object GetTextPoint()
```

C++/CLI

```
System.Object^ GetTextPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextPoint](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextPoint2 Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextPoint2 Method (INote)

Gets the note's text reference point (i.e., note origin).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetTextPoint2()
```

C#

```
System.object GetTextPoint2()
```

C++/CLI

```
System.Object^ GetTextPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 3 doubles

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextPoint2](#).

Remarks

This is the upper-left corner of the bounding rectangle. It also works when zooming the view in and out.

Format of retval is the following array of 3 doubles:

- *return value*[0] = x coordinate of text reference point
- *return value*[1] = y coordinate of text reference point
- *return value*[2] = z coordinate of text reference point

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)

[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextPositionAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextPositionAtIndex Method (INote)

Gets the text item's offset relative to the document origin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.Object GetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 1

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextPositionAtIndex](#).

Remarks

Before using this method, use [INote::GetTextCount](#).

The return value is the following array of doubles :

$$\left[\text{textPtX}, \text{textPtY}, \text{textPtZ} \right]$$

where these text position values are in relation to the document.

The data returned from this method is in terms of document space.

If the document containing this note is...

Then the coordinates returned are based on the...

Drawing

Sheet origin

Part or assembly

Model origin

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextRefPositionAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextRefPositionAtIndex Method (INote)

Gets the specified text item's reference position in this note; for example, the upper left, lower left, or center.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired piece of text where the index begins at 1

Return Value

Reference position of the specified text item as defined in [swTextPosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextRefPositionAtIndex](#).

Remarks

Before using this method, use [INote::GetTextCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextVerticalJustification Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTextVerticalJustification Method (INote)

Gets the vertical justification of a standard note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextVerticalJustification() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetTextVerticalJustification()
```

C#

```
System.int GetTextVerticalJustification()
```

C++/CLI

```
System.int GetTextVerticalJustification();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Vertical justification as defined in [swTextAlignmentVertical_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTextVerticalJustification](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::SetTextVerticalJustification Method \(\)](#)
[INote::GetText Method \(\)](#)
[INote::GetTextAngleAtIndex Method \(\)](#)
[INote::GetTextCount Method \(\)](#)
[INote::GetTextFontAtIndex Method \(\)](#)
[INote::GetTextHeightAtIndex Method \(\)](#)
[INote::GetTextInvertAtIndex Method \(\)](#)
[INote::GetTextJustification Method \(\)](#)
[INote::GetTextLineSpacingAtIndex Method \(\)](#)
[INote::GetTextPoint2 Method \(\)](#)
[INote::GetTextPositionAtIndex Method \(\)](#)
[INote::GetTextRefPositionAtIndex Method \(\)](#)
[INote::SetText Method \(\)](#)
[INote::SetTextJustification Method \(\)](#)
[INote::SetTextPoint Method \(\)](#)
[INote::PropertyLinkedText Property \(\)](#)
[INote::TextRightToLeft Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTriangleAtIndex Method (INote)

Gets the triangle at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTriangleAtIndex(Index)
```

C#

```
System.object GetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles :

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	= first XYZ vertex point
<i>vertexPt2</i> [3]	= second XYZ vertex point
<i>vertexPt3</i> [3]	= third XYZ vertex point
<i>isFilled</i>	= BOOLEAN returned as a double and is True if the triangle is filled, false otherwise
<i>lineType</i>	= line type; see swLineTypes_e

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetTriangleCount Method](#)
[INote::!GetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTriangleCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetTriangleCount Method (INote)

Gets the number of triangles in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Integer

value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of triangles in this note

Visual Basic for Applications (VBA) Syntax

See [Note::GetTriangleCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetTriangleAtIndex Method](#)
[INote::GetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUpperRight Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetUpperRight Method (INote)

Gets the note's upper-right text point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUpperRight() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Object

value = instance.GetUpperRight()
```

C#

```
System.object GetUpperRight()
```

C++/CLI

```
System.Object^ GetUpperRight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [Note::GetUpperRight](#).

Example

[Get Upper-right Text Coordinates of Selected Note \(VBA\)](#)

Remarks

Format of retval is the following array of 3 doubles:

- return value[0] = x coordinate of upper-right text point
- return value[1] = y coordinate of upper-right text point
- return value[2] = z coordinate of upper-right text point

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetUpperRight Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocTextFormat Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetUseDocTextFormat Method (INote)

Obsolete. Superseded by [IAnnotation::GetUseDocTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::GetUseDocTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasBalloon Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : HasBalloon Method (INote)

Gets whether this note has a balloon.

.NET Syntax

Visual Basic (Declaration)

```
Function HasBalloon() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.HasBalloon()
```

C#

```
System.bool HasBalloon()
```

C++/CLI

```
System.bool HasBalloon();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the note has a balloon, false otherwise

Visual Basic for Applications (VBA) Syntax

See [Note::HasBalloon](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasExtraLeader Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : HasExtraLeader Method (INote)

Gets whether this note has a bent or straight leaderline.

.NET Syntax

Visual Basic (Declaration)

```
Function HasExtraLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.HasExtraLeader()
```

C#

```
System.bool HasExtraLeader()
```

C++/CLI

```
System.bool HasExtraLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if leaderline bent, false if straight

Visual Basic for Applications (VBA) Syntax

See [Note::HasExtraLeader](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderAtIndex Method](#)
[INote::GetLeaderCount Method](#)
[INote::GetLeaderInfo Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasMultipleFonts Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : HasMultipleFonts Property (INote)

Gets whether a note contains multiple fonts.

 **.NET Syntax**

Visual Basic (Declaration)

ReadOnly Property HasMultipleFonts As System.Boolean

Visual Basic (Usage) Copy Code

Dim instance As [INote](#)
Dim value As System.Boolean

value = instance.HasMultipleFonts

C#

System.bool HasMultipleFonts {get;}

C++/CLI

property System.bool HasMultipleFonts {
 System.bool get();
}

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the note contains multiple fonts, false if not

 **Visual Basic for Applications (VBA) Syntax**

See [Note::HasMultipleFonts](#).

 **Example**

[Get Whether Note Contains Rich Embedded Text \(VBA\)](#)

 **See Also**

[INote Interface](#)
[INote Members](#)
[INote::GetFontInfo Method](#)
[INote::IGetFontInfo Method](#)
[INote::GetTextFontAtIndex Method](#)

 **Availability**

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help [Send comments on this topic.](#)

IGetAnnotation Method (INote)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetAnnotation Method (INote)

Gets the annotation for this specific note.

 **.NET Syntax**

Visual Basic (Declaration)

Function IGetAnnotation() As Annotation

Visual Basic (Usage) Copy Code

Dim instance As [INote](#)
Dim value As Annotation

```
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [Note::IGetAnnotation](#).

Remarks

This method obtains the owning [IAnnotation](#) object for this [INote](#) object. The IAnnotation object is a higher-level object that contains methods that are general to all types of annotations.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetArcAtIndex Method (INote)

Gets information for the specified arc in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired arc where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [INote::GetArcCount](#) before calling this method to determine the size of the return array.

Return value is an array of doubles:

[*LineType*, *StartPt*[3], *EndPt*[3], *CenterPt*[3], *RotDir*]

where :

<i>LineType</i>	Line type. Valid returns are defined in swLineTypes_e . A LineType is a combination of a line style and line weight.
<i>StartPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the start point.
<i>EndPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the end point. If the arc is closed, then this is the same point as the <i>StartPt</i> .
<i>CenterPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the center point.
<i>RotDir</i>	Rotational direction (CW = -1, CCW = 1)

The data returned from this method is in terms of document apace.

If the document containing this note is...	Then the coordinates returned are based on the...
Drawing	Sheet origin
Part or assembly	Model origin

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowHeadAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetArrowHeadAtIndex Method (INote)

Gets information on the specified arrowhead in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



Copy Code

```
Dim instance As INote
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired arrowhead where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method returns an array of doubles that describe the geometry of the arrowhead on the far end of the leader line. This information is independent of whether this note actually has an arrowhead.

Format of return information is the following array of doubles:

- return value[0] = arrow length (i.e. leader into arrowhead)
- return value[1] = arrowhead length
- return value[2] = arrowhead width

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetArrowHeadAtIndex Method](#)
[INote::GetArrowHeadInfo Method](#)
[INote::GetArrowHeadCount Method](#)
[INote::IGetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArrowHeadInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetArrowHeadInfo Method (INote)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Double

value = instance.IGetArrowHeadInfo()
```

C#

```
System.double IGetArrowHeadInfo()
```

C++/CLI

```
System.double IGetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This information is independent of whether this note actually has an arrowhead.

This method returns an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

Format of return information is the following array of doubles:

- return value[0] = arrow length (i.e. leader into arrowhead)
- return value[1] = arrowhead length
- return value[2] = arrowhead width
- return value[3] = arrowhead style as defined in [swArrowStyle_e](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetArrowHeadAtIndex Method](#)
[INote::GetArrowHeadAtIndex Method](#)
[INote::GetArrowHeadCount Method](#)
[INote::GetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAttachPos Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetAttachPos Method (INote)

Gets the attachment point of this note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAttachPos() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetAttachPos()
```

C#

```
System.double IGetAttachPos()
```

C++/CLI

```
System.double IGetAttachPos();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This is only meaningful if the note is attached.

Format of return information is the following array of doubles:

- *return value*[0] = x-coord of attachment point
- *return value*[1] = y-coord of attachment point
- *return value*[2] = z-coord of attachment point

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetAttachPos Method](#)
[INote::IsAttached Method](#)
[INote::LockPosition Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBalloonInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetBalloonInfo Method (INote)

Gets information describing the geometry of the balloon, if any, that encloses the note text.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBalloonInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetBalloonInfo()
```

C#

```
System.double IGetBalloonInfo()
```

C++/CLI

```
System.double IGetBalloonInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This consists of two points: center point and a point on the balloon circle.

Format of return information is the following array of doubles:

- *return value*[0] = x coordinate of balloon center point
- *return value*[1] = y coordinate of balloon center point
- *return value*[2] = z coordinate of balloon center point
- *return value*[3] = x coordinate of balloon arc point
- *return value*[4] = y coordinate of balloon arc point
- *return value*[5] = z coordinate of balloon arc point
- *return value*[6] = radius

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetExtent Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetExtent Method (INote)

Gets the extents of a note in sheet space.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExtent() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetExtent()
```

C#

```
System.double IGetExtent()
```

C++/CLI

```
System.double IGetExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The data returned is an array of 6 doubles that describe the lower-left and upper-right box extents of the note. The values (X,Y,Z) are in sheet space. In other words, the X,Y,Z values are in relation to the origin of the drawing document, which is in the lower-left hand corner of the drawing

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)

IGetExtentAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetExtentAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExtentAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetExtentAtIndex(Index)
```

C#

```
System.double IGetExtentAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetExtentAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index number of text

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The data returned is an array of 6 doubles that describe the lower-left and upper-right box extents of the text string. The values (X,Y,Z) are in sheet space. In other words, they are in relation to the origin of the drawing document which is in the lower-left corner of the drawing.

In a compound note, this method determines the text item's offset relative to note's text point.

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number 2, and so on.

If you use this method on a standard note (not a compound note), then the index value should be set to 1.

See Also

[INote Interface](#)
[INote Members](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)

[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFontInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetFontInfo Method (INote)

Gets with the note's font information.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFontInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetFontInfo()
```

C#

```
System.double IGetFontInfo()
```

C++/CLI

```
System.double IGetFontInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Currently this method returns only a line type index. See [swLineTypes_e](#) for line type index information.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetFontInfo Method](#)
[INote::HasMultipleFonts Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetLeaderAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetLeaderAtIndex Method (INote)

Gets information about the specified leader on this note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderAtIndex(  
    ByVal Index As System.Integer, _  
    ByRef PointCount As System.Integer _  
) As System.Double
```

```

Dim instance As INote
Dim Index As System.Integer
Dim PointCount As System.Integer
Dim value As System.Double

value = instance.IGetLeaderAtIndex(Index, PointCount)

```

C#

```

System.double IGetLeaderAtIndex(
    System.int Index,
    out System.int PointCount
)

```

C++/CLI

```

System.double IGetLeaderAtIndex(
    & System.int Index,
    & [Out] System.int PointCount
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of leader

PointCount

Number of (x,y,z) points returned in the array

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

There can be 0, 1, or 2 lines used with the leader line. In other words, if the note is not attached, then there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on `IsAttached()` and `HasExtraLeader()`

- `IsAttached() == false` implies no leaderline and no leaderline points (`PointCount=0`).
- `HasExtraLeader() == false` implies that this is a straight leaderline and 1 line (`PointCount=2`)
- `HasExtraLeader() == True` means that this is a bent leaderline and 2 lines (`PointCount=3`)

Format of return information is the following array of doubles:

- *return value*[0] = x coordinate of first leader point
- *return value*[1] = y coordinate of first leader point
- *return value*[2] = z coordinate of first leader point
- *return value*[3] = x coordinate of second leader point
- *return value*[4] = y coordinate of second leader point
- *return value*[5] = z coordinate of second leader point
- *return value*[6] = x coordinate of third leader point
- *return value*[7] = y coordinate of third leader point
- *return value*[8] = z coordinate of third leader point

Use [INote::GetLeaderCount](#) to see how many leaders there are on the note.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderInfo Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::HasExtraLeader Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetLeaderAtIndex Method](#)
[INote::IsAttached Method](#)

IGetLeaderInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetLeaderInfo Method (INote)

Gets information describing the layout of the note leader lines.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderInfo( _
    ByRef PointCount As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote
Dim PointCount As System.Integer
Dim value As System.Double

value = instance.IGetLeaderInfo(PointCount)
```

C#

```
System.double IGetLeaderInfo(
    out System.int PointCount
)
```

C++/CLI

```
System.double IGetLeaderInfo(
    & [Out] System.int PointCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointCount
Number of points

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

There can be 0, 1, or 2 lines used with the leader line. If the note is not attached, then there are 0 lines; otherwise, you have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on `IsAttached()` and `HasExtraLeader()`.

- `IsAttached() == false` implies no leaderline and no leaderline points (`PointCount=0`).
- `HasExtraLeader() == false` implies a straight leaderline and 1 line (`PointCount=2`)
- `HasExtraLeader() == True` implies a bent leaderline and 2 lines (`PointCount=3`)

Format of return information is the following array of doubles:

- *return value*[0] = x coordinate of first leader point
- *return value*[1] = y coordinate of first leader point
- *return value*[2] = z coordinate of first leader point
- *return value*[3] = x coordinate of second leader point
- *return value*[4] = y coordinate of second leader point
- *return value*[5] = z coordinate of second leader point
- *return value*[6] = x coordinate of third leader point
- *return value*[7] = y coordinate of third leader point

- *return value[8]* = z coordinate of third leader point

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderCount Method](#)
[INote::GetLeaderInfo Method](#)
[INote::GetLeaderAtIndex Method](#)
[INote::HasExtraLeader Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::IsAttached Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetLineAtIndex Method (INote)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired line where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3]]$

where:

lineType = the line type. Refer to the [swLineTypes_e](#) enumeration.

startPt[3] = the XYZ line start point

`endPt[3]` = the XYZ line end point

The data returned from this method is in terms of document space. If the document containing this note is a drawing, then the coordinates returned are based on the sheet origin. If the document is a part or assembly, then the coordinates are based on the model origin.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLineAtIndex Method](#)
[INote::GetLineCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetNext Method (INote)

Gets the next note in [drawing view](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetNext() As Note
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As Note
```

```
value = instance.IGetNext()
```

C#

```
Note IGetNext()
```

C++/CLI

```
Note^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [note](#)

Visual Basic for Applications (VBA) Syntax

See [Note::IGetNext](#).

Remarks

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetNext Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketch Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetSketch Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As Sketch
```

```
value = instance.IGetSketch()
```

C#

```
Sketch IGetSketch()
```

C++/CLI

```
Sketch^ IGetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#) for this compound note

Visual Basic for Applications (VBA) Syntax

See [Note::IGetSketch](#).

Remarks

If the current note is not a compound note, then a NULL value is returned.

For adding or modifying actual sketch geometry in a compound note, use [INote::BeginSketchEdit](#), which activates the sketch of the compound note for modification.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextFormat Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextFormat Method (INote)

Obsolete. Superseded by [IAnnotation::GetTextFormat](#) and [IAnnotation::IGetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormat() As TextFormat
```

```
Dim instance As INote
Dim value As TextFormat

value = instance.IGetTextFormat()
```

C#

```
TextFormat IGetTextFormat()
```

C++/CLI

```
TextFormat^ IGetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::IGetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextFormatAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextFormatAtIndex Method (INote)

Obsolete. Superseded by [IAnnotation::GetTextFormat](#) and [IAnnotation::GetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormatAtIndex( _
    ByVal Index As System.Integer _
) As TextFormat
```

Visual Basic (Usage)

```
Dim instance As INote
Dim Index As System.Integer
Dim value As TextFormat

value = instance.IGetTextFormatAtIndex(Index)
```

C#

```
TextFormat IGetTextFormatAtIndex(
    System.int Index
)
```

C++/CLI

```
TextFormat^ IGetTextFormatAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [Note::IGetTextFormatAtIndex](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextOffsetAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextOffsetAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the text item's offset relative to note's text point in a compound note.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetTextOffsetAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTextOffsetAtIndex(Index)
```

C#

```
System.double IGetTextOffsetAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTextOffsetAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the text

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before using this method, use [INote::GetCompoundTextCount](#) to get the number of text items.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)

[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextPoint Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextPoint Method (INote)

Obsolete. Superseded by [INote::IGetTextPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetTextPoint()
```

C#

```
System.double IGetTextPoint()
```

C++/CLI

```
System.double IGetTextPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [INote::IGetTextPoint](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextPoint2 Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextPoint2 Method (INote)

Gets the note's text reference point (i.e., note origin).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPoint2() As MathPoint
```

```
Dim instance As INote
Dim value As MathPoint

value = instance.IGetTextPoint2()
```

C#

```
MathPoint IGetTextPoint2()
```

C++/CLI

```
MathPoint^ IGetTextPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Math point](#)

Visual Basic for Applications (VBA) Syntax

See [Note::IGetTextPoint2](#).

Remarks

This is the upper-left corner of the bounding rectangle. It also works when zooming the view in and out.

Format of retval is the following array of 3 doubles:

- *return value*[0] = x coordinate of text reference point
- *return value*[1] = y coordinate of text reference point
- *return value*[2] = z coordinate of text reference point

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextPositionAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTextPositionAtIndex Method (INote)

Gets the text item's offset relative to the document origin.

.NET Syntax

```
Function IGetTextPositionAtIndex( _
    ByVal Index As System.Integer _
) As System.Double
```



```
Dim instance As INote
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetTextPositionAtIndex(Index)
```

```
System.double IGetTextPositionAtIndex(
    System.int Index
)
```

```
System.double IGetTextPositionAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the piece of text where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before using this method, use [INote::GetTextCount](#).

The return value is the following array of doubles :

$\left[\text{textPtX}, \text{textPtY}, \text{textPtZ} \right]$

where these text position values are in relation to the document.

The data returned from this method is in terms of document space.

If the document containing this note is...

Then the coordinates returned are based on the...

Drawing

Sheet origin

Part or assembly

Model origin

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)

[INote::IGetTextPoint2 Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

IGetTriangleAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetTriangleAtIndex Method (INote)

Gets the triangle at the specified index.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of doubles :

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	= first XYZ vertex point
<i>vertexPt2</i> [3]	= second XYZ vertex point
<i>vertexPt3</i> [3]	= third XYZ vertex point
<i>isFilled</i>	= BOOLEAN returned as a double and is True if the triangle is filled, false otherwise

lineType = line type; see [swLineTypes_e](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetTriangleAtIndex Method](#)
[INote::GetTriangleCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetUpperRight Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IGetUpperRight Method (INote)

Gets the note's upper-right text point.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUpperRight() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.IGetUpperRight()
```

C#

```
System.double IGetUpperRight()
```

C++/CLI

```
System.double IGetUpperRight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Format of retval is the following array of 3 doubles:

- return value[0] = x coordinate of upper-right text point
- return value[1] = y coordinate of upper-right text point
- return value[2] = z coordinate of upper-right text point

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetUpperRight Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IncludeDimPrefixSuffixTolerance Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IncludeDimPrefixSuffixTolerance Property (INote)

Gets or sets whether to include the dimension prefix, suffix, and tolerance in this dimension note.

.NET Syntax

Visual Basic (Declaration)

Property IncludeDimPrefixSuffixTolerance As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.IncludeDimPrefixSuffixTolerance = value  
value = instance.IncludeDimPrefixSuffixTolerance
```

C#

```
System.bool IncludeDimPrefixSuffixTolerance {get; set;}
```

C++/CLI

```
property System.bool IncludeDimPrefixSuffixTolerance {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include the dimension prefix, suffix, and tolerance; false to not

Visual Basic for Applications (VBA) Syntax

See [Note::IncludeDimPrefixSuffixTolerance](#).

See Also

[INote Interface](#)
[INote Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsAttached Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsAttached Method (INote)

Gets whether the note is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function IsAttached() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsAttached()
```

C#

```
System.bool IsAttached()
```

C++/CLI

```
System.bool IsAttached();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if note is attached with a leaderline, false otherwise

Visual Basic for Applications (VBA) Syntax

See [Note::IsAttached](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetAttachPos Method](#)
[INote::GetLeaderCount Method](#)
[INote::GetLeaderInfo Method](#)
[INote::GetLeaderAtIndex Method](#)
[INote::HasExtraLeader Method](#)
[INote::IGetAttachPos Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsAttribute Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsAttribute Method (INote)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function IsAttribute() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsAttribute()
```

C#

```
System.bool IsAttribute()
```

C++/CLI

```
System.bool IsAttribute();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::IsAttribute](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBendLineNote Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsBendLineNote Property (INote)

Gets whether this note is a bendline note.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IsBendLineNote As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsBendLineNote
```

C#

```
System.bool IsBendLineNote {get;}
```

C++/CLI

```
property System.bool IsBendLineNote {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if note is a bendline note, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::IsBendLineNote](#).

Example

[Merge and Unmerge Bend Tags \(C#\)](#)
[Merge and Unmerge Bend Tags \(VB.NET\)](#)
[Merge and Unmerge Bend Tags \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBendLineValues Method](#)
[IView::MergeBendTags Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBomBalloon Method (INote)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsBomBalloon Method (INote)

Gets whether this note has a BOM balloon.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBomBalloon() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean
```

```
value = instance.IsBomBalloon()
```

C#

```
System.bool IsBomBalloon()
```

C++/CLI

```
System.bool IsBomBalloon();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the note has a BOM balloon, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::IsBomBalloon](#).

Example

[Get BOM Balloon Properties \(VBA\)](#)
[Set BOM Balloon Text \(VBA\)](#)
[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[IModelDocExtension::InsertBOMBalloon Method](#)
[INote::vGetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCompoundNote Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsCompoundNote Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the current note is a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCompoundNote() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsCompoundNote()
```

C#

```
System.bool IsCompoundNote()
```

C++/CLI

```
System.bool IsCompoundNote();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if note is compound, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::IsCompoundNote](#).

Example

[Change Note Text \(VBA\)](#)
[Create Compound Note \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)