

SOLIDWORKS API (.NET VBA C#) — Reference

(214/337): INote (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

INote (part 3 of 3) (Type)

ISetTextFormat Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : ISetTextFormat Method (INote)

Obsolete. Superseded by [IAnnotation::SetTextFormat](#) and [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetTextFormat( _  
    ByVal TextFormatType As System.Integer, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim TextFormatType As System.Integer  
Dim TextFormat As TextFormat  
Dim value As System.Boolean  
  
value = instance.ISetTextFormat(TextFormatType, TextFormat)
```

C#

```
System.bool ISetTextFormat(  
    System.int TextFormatType,  
    TextFormat TextFormat  
)
```

C++/CLI

```
System.bool ISetTextFormat(  
    & System.int TextFormatType,  
    & TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextFormatType

TextFormat

Visual Basic for Applications (VBA) Syntax

See [Note::ISetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)

ISetTextFormatAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : ISetTextFormatAtIndex Method (INote)

Obsolete. Superseded by [IAnnotation::SetTextFormat](#) and [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetTextFormatAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal TextFormat As TextFormat _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim TextFormat As TextFormat  
  
instance.ISetTextFormatAtIndex(Index, TextFormat)
```

C#

```
void ISetTextFormatAtIndex(  
    System.int Index,  
    TextFormat TextFormat  
)
```

C++/CLI

```
void ISetTextFormatAtIndex(  
& System.int Index,  
& TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

TextFormat

Visual Basic for Applications (VBA) Syntax

See [Note::ISetTextFormatAtIndex](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsStackedBalloon Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsStackedBalloon Method (INote)

Gets whether this note is part of a stacked balloon.

.NET Syntax

Visual Basic (Declaration)

```
Function IsStackedBalloon() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsStackedBalloon()
```

C#

```
System.bool IsStackedBalloon()
```

C++/CLI

```
System.bool IsStackedBalloon();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this note is part of a stacked balloon, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::IsStackedBalloon](#).

Example

[Insert BOM Table and Stacked Balloon \(C#\)](#)
[Insert BOM Table and Stacked Balloon \(VB.NET\)](#)
[Insert BOM Table and Stacked Balloon \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsStackedBalloonMaster Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : IsStackedBalloonMaster Method (INote)

Gets whether this note is the master note of a balloon stack.

.NET Syntax

Visual Basic (Declaration)

```
Function IsStackedBalloonMaster() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
value = instance.IsStackedBalloonMaster()
```

C#

```
System.bool IsStackedBalloonMaster()
```

C++/CLI

```
System.bool IsStackedBalloonMaster();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this note is the master note of a balloon stack, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::IsStackedBalloonMaster](#).

Example

[Get BOM Balloon Properties \(C#\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LockPosition Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : LockPosition Property (INote)

Gets and sets whether to anchor this note.

.NET Syntax

Visual Basic (Declaration)

Property LockPosition As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.LockPosition = value  
value = instance.LockPosition
```

C#

```
System.bool LockPosition {get; set;}
```

C++/CLI

```
property System.bool LockPosition {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to anchor the note, false to not

Visual Basic for Applications (VBA) Syntax

See [Note::LockPosition](#).

Example

[Anchor a Note \(VBA\)](#)
[Anchor a Note \(VB.NET\)](#)
[Anchor a Note \(C#\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[IAnnotation::SetPosition Method](#)
[IAnnotation::GetPosition Method](#)
[INote::GetAttachPos Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MakeStackedBalloon Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : MakeStackedBalloon Method (INote)

Converts this balloon to a stacked balloon.

.NET Syntax

Visual Basic (Declaration)

```
Sub MakeStackedBalloon( _  
    ByVal StackedBalloonOptions As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim StackedBalloonOptions As System.Object  
  
instance.MakeStackedBalloon(StackedBalloonOptions)
```

C#

```
void MakeStackedBalloon(  
    System.object StackedBalloonOptions  
)
```

C++/CLI

```
void MakeStackedBalloon(  
& System.Object^ StackedBalloonOptions  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StackedBalloonOptions
[IStackedBalloonOptions](#)

Visual Basic for Applications (VBA) Syntax

See [Note::MakeStackedBalloon](#).

Remarks

Before calling this method, use [IModelDocExtension::SelectByID2](#) to select the entity to add to the balloon stack.

After calling this method to convert the balloon to a stacked balloon, add more balloons by calling:

1. [INote::GetBalloonStack](#)
2. [IBalloonStack::AddTo](#)

See Also

[INote Interface](#)
[INote Members](#)
[IModelDocExtension::InsertStackedBalloon2 Method \(\)](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PromptText Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : PromptText Property (INote)

Gets and sets the message prompt text.

.NET Syntax

Visual Basic (Declaration)

Property PromptText As System.String

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String  
  
instance.PromptText = value  
  
value = instance.PromptText
```

C#

```
System.string PromptText {get; set;}
```

C++/CLI

```
property System.String^ PromptText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text to use in prompt message

Visual Basic for Applications (VBA) Syntax

See [Note::PromptText](#).

See Also

[INote Interface](#)
[INote Members](#)

Availability

PropertyLinkedText Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : PropertyLinkedText Property (INote)

Gets or sets the text for the note using the values of the properties linked to the note.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property PropertyLinkedText As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String  
  
instance.PropertyLinkedText = value  
  
value = instance.PropertyLinkedText
```

C#

```
System.string PropertyLinkedText {get; set;}
```

C++/CLI

```
property System.String^ PropertyLinkedText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text of note

Visual Basic for Applications (VBA) Syntax

See [Note::PropertyLinkedText](#).

Remarks

The string returned by this property is the unresolved string of the note. If the note has linked text, then the source of the link is returned rather than the value of the link.

For example:

For links to...	This property....	Returns...
Custom properties	INote::PropertyLinkedText	Date: (\$PRPVIEW:"SW-Long Date")
	INote::GetText	Date: (Monday, December 16, 2016)
Dimensions	INote::PropertyLinkedText	Value: ("RD1@Drawing View1")
	INote::GetText	Value: (70)

NOTE: For notes without links, INote::PropertyLinkedText and INote::GetText behave the same.

See Also

[INote Interface](#)
[INote Members](#)

[INote::AddText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReadOnly Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : ReadOnly Property (INote)

Gets or sets the read-only state of a note.

.NET Syntax

Visual Basic (Declaration)

Property ReadOnly As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.ReadOnly = value  
  
value = instance.ReadOnly
```

C#

```
System.bool ReadOnly {get; set;}
```

C++/CLI

```
property System.bool ReadOnly {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the note is read-only, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::ReadOnly](#).

See Also

[INote Interface](#)
[INote Members](#)

Availability

SetBalloon Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetBalloon Method (INote)

Sets the balloon style, size, and fit for this note.

.NET Syntax

Visual Basic (Declaration)

```

Function SetBalloon( _
    ByVal Style As System.Integer, _
    ByVal Size As System.Integer _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As INote
Dim Style As System.Integer
Dim Size As System.Integer
Dim value As System.Boolean

value = instance.SetBalloon(Style, Size)

```

C#

```

System.bool SetBalloon(
    System.int Style,
    System.int Size
)

```

C++/CLI

```

System.bool SetBalloon(
    & System.int Style,
    & System.int Size
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Balloon style as defined in [swBalloonStyle_e](#)

Size

Balloon size or fit as defined in [swBalloonFit_e](#)

Return Value

True if the style and size are successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetBalloon](#).

Example

[Insert Note \(VBA\)](#)
[Create Block Definition and Insert Block Instance \(VBA\)](#)
[Create Block Definition and Insert Block Instance \(C#\)](#)
[Create Block Definition and Insert Block Instance \(VB.NET\)](#)

Remarks

If the style is specified as swBS_None, the size value is ignored.

The swBS_SplitCirc style is not valid for use with this method. If it is used, then the style is set to swBS_None instead.

If an invalid style or size is specified (one that is not in the enumeration), this method returns false and no action is taken.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBalloonPadding Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetBalloonPadding Method (INote)

Sets the padding for this balloon note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBalloonPadding( _  
    ByVal Padding As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Padding As System.Double  
Dim value As System.Boolean  
  
value = instance.SetBalloonPadding(Padding)
```

C#

```
System.bool SetBalloonPadding(  
    System.double Padding  
)
```

C++/CLI

```
System.bool SetBalloonPadding(  
    & System.double Padding  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Padding
Balloon padding

Return Value

True if padding is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetBalloonPadding](#).

Remarks

This method is valid only if [INote::GetBalloonSize](#) is set to [swBalloonFit_e.swBF_Tightest](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonPadding Method \(\)](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetBomBalloonText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetBomBalloonText Method (INote)

Sets the text for this BOM balloon note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBomBalloonText( _  
    ByVal UpperTextStyle As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextStyle As System.Integer, _  
    ByVal LowerText As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim UpperTextStyle As System.Integer  
Dim UpperText As System.String  
Dim LowerTextStyle As System.Integer  
Dim LowerText As System.String  
Dim value As System.Boolean  
  
value = instance.SetBomBalloonText(UpperTextStyle, UpperText, LowerTextStyle, LowerText)
```

C#

```
System.bool SetBomBalloonText(  
    System.int UpperTextStyle,  
    System.string UpperText,  
    System.int LowerTextStyle,  
    System.string LowerText  
)
```

C++/CLI

```
System.bool SetBomBalloonText(  
& System.int UpperTextStyle,  
& System.String^ UpperText,  
& System.int LowerTextStyle,  
& System.String^ LowerText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpperTextStyle
Style for the upper text as defined in [swDetailingNoteTextContent_e](#)

UpperText
Upper text

LowerTextStyle
Style for the lower text as defined in [swDetailingNoteTextContent_e](#)

LowerText
Lower text

Return Value

True if successfully returned, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetBomBalloonText](#).

Example

[Set BOM Balloon Text \(VBA\)](#)
[Get Balloon Properties \(C#\)](#)
[Get Balloon Properties \(VB.NET\)](#)
[Get Balloon Properties \(VBA\)](#)

Remarks

If the upper- or lower-text style is swBalloonTextQuantity or swBalloonTextItemNumber, then SOLIDWORKS ignores the specified upper or lower text.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[IModelDocExtension::InsertBOMBalloon Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetHeight Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetHeight Method (INote)

Sets the height of this note in meters.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetHeight( _  
    ByVal HeightIn As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim HeightIn As System.Double  
  
instance.SetHeight(HeightIn)
```

C#

```
void SetHeight(  
    System.double HeightIn  
)
```

C++/CLI

```
void SetHeight(  
& System.double HeightIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HeightIn

Height for this note in meters

Visual Basic for Applications (VBA) Syntax

See [Note::SetHeight](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetHeight Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetHeightInPoints Method](#)
[INote::SetHeightInPoints Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetHeightInPoints Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetHeightInPoints Method (INote)

Sets the height of this note in points (for example, 8, 10, 12, and so on).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetHeightInPoints( _  
    ByVal HeightIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim HeightIn As System.Integer  
  
instance.SetHeightInPoints(HeightIn)
```

C#

```
void SetHeightInPoints(  
    System.int HeightIn  
)
```

C++/CLI

```
void SetHeightInPoints(  
& System.int HeightIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HeightIn

Height for this note in points

Visual Basic for Applications (VBA) Syntax

See [Note::SetHeightInPoints](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetHeight Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetHeightInPoints Method](#)
[INote::SetHeight Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetHyperlinkText Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetHyperlinkText Method (INote)

Sets the hyperlink in a note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetHyperlinkText(  
    ByVal Text As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Text As System.String  
Dim value As System.Boolean  
  
value = instance.SetHyperlinkText(Text)
```

C#

```
System.bool SetHyperlinkText(  
    System.string Text  
)
```

C++/CLI

```
System.bool SetHyperlinkText(  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text
Text for hyperlink

Return Value

True if the hyperlink is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetHyperlinkText](#).

Remarks

You can retrieve the hyperlink text using [INote::GetHyperlinkText](#).

The input text can be a URL address or the name of a document on the local network or on your local system. You must specify the full address for a URL address, starting with the **http://**. You can specify a file name on your local network or system either as a full pathname or pathname relative to the current document, for example, **D:\parts\drawing1.slddrw**, or **drawing1.slddrw**.

To remove the hyperlink from a note, use this method and specify non-hyperlinked text.

See Also

SetName Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetName Method (INote)

Sets the name for this note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetName( _  
    ByVal NameIn As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim NameIn As System.String  
Dim value As System.Boolean  
  
value = instance.SetName(NameIn)
```

C#

```
System.bool SetName(  
    System.string NameIn  
)
```

C++/CLI

```
System.bool SetName(  
    & System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Note name

Return Value

True if the note name is changed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetName](#).

Example

[Set Note Name \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetName Method](#)

SetText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetText Method (INote)

Sets the text of the note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetText( _  
    ByVal Txt As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Txt As System.String  
Dim value As System.Boolean  
  
value = instance.SetText(Txt)
```

C#

```
System.bool SetText(  
    System.string Txt  
)
```

C++/CLI

```
System.bool SetText(  
&    System.String^ Txt  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Txt

Text to replace the current note text

Return Value

True if the text is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetText](#).

Example

[Change Note Text \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SetTextAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text value at the specified index within the compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Txt As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim Txt As System.String  
Dim value As System.Boolean  
  
value = instance.SetTextAtIndex(Index, Txt)
```

C#

```
System.bool SetTextAtIndex(  
    System.int Index,  
    System.string Txt  
)
```

C++/CLI

```
System.bool SetTextAtIndex(  
& System.int Index,  
& System.String^ Txt  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the text within the compound note; an invalid index value causes false to be returned

Txt

Text to replace the current note text

Return Value

True if the text change is made successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextAtIndex](#).

Remarks

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number of 2, and so on.

After completing any note changes, you must perform an [IModelDoc2::EditRebuild3](#).

If you use this method on a standard note (not a compound note), then the index value should be set to 1. Use [INote::SetText](#) for modifying text in a standard note.

See Also

[INote Interface](#)
[INote Members](#)

[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextFormat Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextFormat Method (INote)

Obsolete. Superseded by [IAnnotation::SetTextFormat](#) and [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal TextFormatType As System.Integer, _  
    ByVal TextFormat As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim TextFormatType As System.Integer  
Dim TextFormat As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetTextFormat(TextFormatType, TextFormat)
```

C#

```
System.bool SetTextFormat(  
    System.int TextFormatType,  
    System.object TextFormat  
)
```

C++/CLI

```
System.bool SetTextFormat(  
& System.int TextFormatType,  
& System.Object^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextFormatType

TextFormat
v

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextFormatAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextFormatAtIndex Method (INote)

Obsolete. Superseded by [IAnnotation::SetTextFormat](#) and [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextFormatAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal TextFormat As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim TextFormat As System.Object  
  
instance.SetTextFormatAtIndex(Index, TextFormat)
```

C#

```
void SetTextFormatAtIndex(  
    System.int Index,  
    System.object TextFormat  
)
```

C++/CLI

```
void SetTextFormatAtIndex(  
& System.int Index,  
& System.Object^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextFormatAtIndex](#).

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextJustification Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextJustification Method (INote)

Sets the text justification of a standard note.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextJustification( _
    ByVal Justification As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As INote
Dim Justification As System.Integer

instance.SetTextJustification(Justification)
```

C#

```
void SetTextJustification(
    System.int Justification
)
```

C++/CLI

```
void SetTextJustification(
    & System.int Justification
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Justification

Text justification as defined in [swTextJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextJustification](#).

Remarks

To see the changes made to the text, the graphics window must be redrawn. See [IModelDoc2::GraphicsRedraw2](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)

[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextJustificationAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextJustificationAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text justification for the specified text item in a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextJustificationAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Justification As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim Justification As System.Integer  
  
instance.SetTextJustificationAtIndex(Index, Justification)
```

C#

```
void SetTextJustificationAtIndex(  
    System.int Index,  
    System.int Justification  
)
```

C++/CLI

```
void SetTextJustificationAtIndex(  
& System.int Index,  
& System.int Justification  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

1-based index value for the text within the note

Justification

Text justification as defined in [swTextJustification_e](#)

Return Value

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number of 2, and so on.

If you use this method on a standard note (not a compound note), then the index value must be set to 1.

To see the changes made to the text, the graphics window must be redrawn. See [IModelDoc2::GraphicsRedraw2](#).

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextJustificationAtIndex](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextOffsetAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextOffsetAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Relocates the offset (origin) of the specified piece of text in a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextOffsetAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)

```
Dim instance As INote  
Dim Index As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double
```

```
instance.SetTextOffsetAtIndex(Index, X, Y, Z)
```

C#

```
void SetTextOffsetAtIndex(  
    System.int Index,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```



```
void SetTextOffsetAtIndex(
& System.int Index,
& System.double X,
& System.double Y,
& System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index number of the text to relocate.

X

X location for the piece of text

Y

Y location for the piece of text

Z

Z location for the piece of text

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextOffsetAtIndex](#).

Remarks

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has index number of 1, the second text added has an index number of 2, and so on.

This method does not support standard notes.

See Also

[INote Interface](#)
[INote Members](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)

SetTextPoint Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextPoint Method (INote)

Relocates the note origin to the specified location.

.NET Syntax

```
Sub SetTextPoint( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
)
```



```
Dim instance As INote
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double

instance.SetTextPoint(X, Y, Z)
```

```
void SetTextPoint(
    System.double X,
    System.double Y,
    System.double Z
)
```

```
void SetTextPoint(
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate of text reference point

Y
y coordinate of text reference point

Z
z coordinate of text reference point

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextPoint](#).

Remarks

The note origin is located in the upper-left corner of the bounding rectangle of the note.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)

[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::GetTextVerticalJustification Method](#)
[INote::SetTextVerticalJustification Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextVerticalJustification Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetTextVerticalJustification Method (INote)

Sets the vertical justification of a standard note.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextVerticalJustification( _  
    ByVal Justification As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Justification As System.Integer  
  
instance.SetTextVerticalJustification(Justification)
```

C#

```
void SetTextVerticalJustification(  
    System.int Justification  
)
```

C++/CLI

```
void SetTextVerticalJustification(  
&    System.int Justification  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Justification

Vertical justification as defined in [swTextAlignmentVertical_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::SetTextVerticalJustification](#).

Example

[Anchor a Note \(C#\)](#)
[Anchor a Note \(VB.NET\)](#)
[Anchor a Note \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetTextVerticalJustification Method \(\)](#)
[INote::GetText Method \(\)](#)
[INote::GetTextAngleAtIndex Method \(\)](#)
[INote::GetTextCount Method \(\)](#)
[INote::GetTextFontAtIndex Method \(\)](#)

[INote::GetTextHeightAtIndex Method \(\)](#)
[INote::GetTextInvertAtIndex Method \(\)](#)
[INote::GetTextJustification Method \(\)](#)
[INote::GetTextLineSpacingAtIndex Method \(\)](#)
[INote::GetTextPoint2 Method \(\)](#)
[INote::GetTextPositionAtIndex Method \(\)](#)
[INote::GetTextRefPositionAtIndex Method \(\)](#)
[INote::SetText Method \(\)](#)
[INote::SetTextJustification Method \(\)](#)
[INote::SetTextPoint Method \(\)](#)
[INote::PropertyLinkedText Property \(\)](#)
[INote::TextRightToLeft Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetZeroLengthLeader Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : SetZeroLengthLeader Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Sets a 0-length leader for a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetZeroLengthLeader( _  
    ByVal Flag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Flag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetZeroLengthLeader(Flag)
```

C#

```
System.bool SetZeroLengthLeader(  
    System.bool Flag  
)
```

C++/CLI

```
System.bool SetZeroLengthLeader(  
& System.bool Flag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flag

True for compound note object to have no leaderline and be attached to an object, false to display leaderline

Return Value

Previous state for this compound note; True if the previous state was a 0-length leaderline, false if the previous state was to display the leaderline

Visual Basic for Applications (VBA) Syntax

See [Note::SetZeroLengthLeader](#).

Remarks

The note is still attached to an object, such as an edge. It also returns the previous state for this compound note.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetLeaderAtIndex Method](#)
[INote::GetLeaderCount Method](#)
[INote::GetLeaderInfo Method](#)
[INote::GetSketch Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::HasExtraLeader Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

TagName Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : TagName Property (INote)

Gets or sets the tag name for this note.

.NET Syntax

Visual Basic (Declaration)

```
Property TagName As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String
```

```
instance.TagName = value
```

```
value = instance.TagName
```

C#

```
System.string TagName {get; set;}
```

C++/CLI

```
property System.String^ TagName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tag name

Visual Basic for Applications (VBA) Syntax

See [Note::TagName](#).

Example

[Get Block Information \(VBA\)](#)
[Remove Hyperlink From Note in Drawing \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextRightToLeft Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : TextRightToLeft Property (INote)

Gets or sets whether notes are displayed right to left.

.NET Syntax

Visual Basic (Declaration)

Property TextRightToLeft As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Boolean

instance.TextRightToLeft = value

value = instance.TextRightToLeft
```

C#

```
System.bool TextRightToLeft {get; set;}
```

C++/CLI

```
property System.bool TextRightToLeft {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display notes right to left, false to display notes left to right

Visual Basic for Applications (VBA) Syntax

See [Note::TextRightToLeft](#).

Remarks

This property only supports systems that have Hebrew as the system language.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::GetText Method](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)

[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ToBoundingBox Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : ToBoundingBox Property (INote)

Gets and sets whether to select the **To bounding box** option for leaders in this note's PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property ToBoundingBox As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.ToBoundingBox = value  
  
value = instance.ToBoundingBox
```

C#

```
System.bool ToBoundingBox {get; set;}
```

C++/CLI

```
property System.bool ToBoundingBox {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to select the **To bounding box** option, false to not

Visual Basic for Applications (VBA) Syntax

See [Note::ToBoundingBox](#).

Remarks

See the SOLIDWORKS Help for information about the **To bounding box** option.

See Also

[INote Interface](#)
[INote Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : Visible Property (INote)

Gets and sets the visibility state of a note during the creation of a block.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Boolean

instance.Visible = value

value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True makes the note visible in the block, false does not

Visual Basic for Applications (VBA) Syntax

See [Note::Visible](#).

See Also

[INote Interface](#)
[INote Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

WatermarkBehindGeometry Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : WatermarkBehindGeometry Property (INote)

Gets or sets whether to place this note, specified to be a watermark, behind the geometry in a part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property WatermarkBehindGeometry As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Boolean
```

```
instance.WatermarkBehindGeometry = value  
value = instance.WatermarkBehindGeometry
```

C#

```
System.bool WatermarkBehindGeometry {get; set;}
```

C++/CLI

```
property System.bool WatermarkBehindGeometry {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to place this note behind the geometry in a part or assembly, false to place this note in front of the geometry in a part or assembly

Visual Basic for Applications (VBA) Syntax

See [Note::WatermarkBehindGeometry](#).

Example

[Add Watermark to Part \(C#\)](#)
[Add Watermark to Part \(VB.NET\)](#)
[Add Watermark to Part \(VBA\)](#)

Remarks

This property is only available when [INote::WatermarkNote](#) is true.

See Also

[INote Interface](#)
[INote Members](#)
[INote::WatermarkTransparencyLevel Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

WatermarkNote Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : WatermarkNote Property (INote)

Gets or sets whether the note is a watermark in a part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property WatermarkNote As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.WatermarkNote = value  
value = instance.WatermarkNote
```

C#

```
System.bool WatermarkNote {get; set;}
```

C++/CLI

```
property System.bool WatermarkNote {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the note is a watermark in a part or assembly, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::WatermarkNote](#).

Example

[Add Watermark to Part \(C#\)](#)
[Add Watermark to Part \(VB.NET\)](#)
[Add Watermark to Part \(VBA\)](#)

Remarks

To add a watermark to a part or assembly document:

1. Open a part or assembly document.
2. Expand the **Annotations** folder in the FeatureManager design tree.
3. Right click **Notes Area** and click **Activate**.
4. Click **Insert > Annotations > Note**
5. Place the note in the graphics area, type the note text, and click **OK** in the Notes PropertyManager page.
6. Right-click the note and click **Watermark**.

Use [ISheet::BehindSheet](#) to place a note on the sheet format behind a drawing sheet, which allows you to display the note as watermark in a drawing.

See Also

[INote Interface](#)
[INote Members](#)
[INote::WatermarkBehindGeometry Property \(\)](#)
[INote::WatermarkTransparencyLevel Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WatermarkTransparencyLevel Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : WatermarkTransparencyLevel Property (INote)

Gets or sets the transparency level of a note specified to be a watermark.

.NET Syntax

Visual Basic (Declaration)

```
Property WatermarkTransparencyLevel As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
instance.WatermarkTransparencyLevel = value  
  
value = instance.WatermarkTransparencyLevel
```

C#

```
System.double WatermarkTransparencyLevel {get; set;}
```

C++/CLI

```
property System.double WatermarkTransparencyLevel {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Level of transparency <= 1.0 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::WatermarkTransparencyLevel](#).

Example

[Add Watermark to Part \(C#\)](#)
[Add Watermark to Part \(VB.NET\)](#)
[Add Watermark to Part \(VBA\)](#)

Remarks

This property is only available when [INote::WatermarkNote](#) is true.

A transparency level of 0.0 indicates that the transparency level is not set for the watermark; a transparency level of 1.0 indicates that the watermark is fully transparent.

See Also

[INote Interface](#)
[INote Members](#)
[INote::WatermarkBehindGeometry Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0