

SOLIDWORKS API (.NET VBA C#) — Reference (215/337): IOneBendFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IOneBendFeatureData (Type)

IOneBendFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IOneBendFeatureData Interface

Allows access to a bend feature (sharp bend, round bend, or flat bend).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IOneBendFeatureData
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
```

C#

```
public interface IOneBendFeatureData
```

C++/CLI

```
public interface class IOneBendFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData](#).

Example

[Get Names of Sketch Segments \(VBA\)](#)
[Get Names of Sketch Segments \(VB.NET\)](#)
[Get Names of Sketch Segments \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[OneBendFeatureData](#)

See Also

[IOneBendFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

IOneBendFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IOneBendFeatureData Interface

The following tables list the members exposed by [IOneBendFeatureData](#).

Public Properties

Name	Description
 AutoReliefType	Gets or sets the auto-relief type from this bend.
 BendAllowance	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .

 BendAllowanceType	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 BendAngle	Gets or sets the bend angle of this bend.
 BendDirection	Gets the direction of this bend.
 BendDown	Gets or sets the bend-down state of this bend.
 BendOrder	Gets or sets the bend order of this bend.
 BendRadius	Gets or sets the bend radius of this bend.
 BendTableFile	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 FlatPatternSketchSegment	Obsolete. Superseded by IOneBendFeatureData::FlatPatternSketchSegments .
 FlatPatternSketchSegments	Obsolete. Superseded by IOneBendFeatureData::FlatPatternSketchSegments2 .
 FlatPatternSketchSegments2	Gets the sketch segments and bend lines for this bend.
 KFactor	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 ReliefDepth	Gets or sets the relief depth for this bend.
 ReliefRatio	Gets and sets the relief ratio for the one bend feature.
 ReliefWidth	Gets or sets the relief width of this bend.
 SimplifyGeometry	Gets or sets whether to simplify the geometry for this bend feature.
 UseAutoRelief	Gets or sets whether to use auto relief for this bend.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this bend.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius of this bend.
 UseDefaultBendRelief	Gets or sets whether to use the default bend relief of this bend.
 UseReliefRatio	Gets or sets whether to use the relief ratio for this bend feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this bend feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this bend feature.
 GetFlatPatternSketchSegmentCount	Obsolete. Superseded by IOneBendFeatureData::GetFlatPatternSketchSegmentCount2 .
 GetFlatPatternSketchSegmentCount2	Gets the number of sketch segments, including bend lines, in this bend.
 GetType	Gets the type of bend for this one bend feature.
 IAccessSelections	Obsolete. Superseded by IOneBendFeatureData::IAccessSelections2 .
 IAccessSelections2	Gains access to selections that define this bend feature.
 IFlatPatternSketchSegments	Obsolete. Superseded by IOneBendFeatureData::IFlatPatternSketchSegments2 .
 IFlatPatternSketchSegments2	Gets the sketch segments and bend lines for this bend.
 ReleaseSelectionAccess	Accesses the selections that describe this bend feature.
 SetCustomBendAllowance	Sets the custom bend allowance for the bend feature.

[Top](#)

See Also

[IOneBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IOneBendFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IOneBendFeatureData Interface

For a list of all members of this type, see [IOneBendFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this bend feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this bend feature.
 GetFlatPatternSketchSegmentCount	Obsolete. Superseded by IOneBendFeatureData::GetFlatPatternSketchSegmentCount2 .
 GetFlatPatternSketchSegmentCount2	Gets the number of sketch segments, including bend lines, in this bend.
 GetType	Gets the type of bend for this one bend feature.
 IAccessSelections	Obsolete. Superseded by IOneBendFeatureData::IAccessSelections2 .
 IAccessSelections2	Gains access to selections that define this bend feature.
 IFlatPatternSketchSegments	Obsolete. Superseded by IOneBendFeatureData::IFlatPatternSketchSegments2 .
 IFlatPatternSketchSegments2	Gets the sketch segments and bend lines for this bend.
 ReleaseSelectionAccess	Accesses the selections that describe this bend feature.
 SetCustomBendAllowance	Sets the custom bend allowance for the bend feature.

[Top](#)

 See Also

[IOneBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

IOneBendFeatureData Interface Properties

[See Also](#)

	SolidWorks.Interop.sldworks Namespace : IOneBendFeatureData Interface
---	---

For a list of all members of this type, see [IOneBendFeatureData members](#).

 Public Properties

Name	Description
 AutoReliefType	Gets or sets the auto-relief type from this bend.
 BendAllowance	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 BendAllowanceType	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 BendAngle	Gets or sets the bend angle of this bend.
 BendDirection	Gets the direction of this bend.
 BendDown	Gets or sets the bend-down state of this bend.
 BendOrder	Gets or sets the bend order of this bend.
 BendRadius	Gets or sets the bend radius of this bend.
 BendTableFile	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 FlatPatternSketchSegment	Obsolete. Superseded by IOneBendFeatureData::FlatPatternSketchSegments .
 FlatPatternSketchSegments	Obsolete. Superseded by IOneBendFeatureData::FlatPatternSketchSegments2 .
 FlatPatternSketchSegments2	Gets the sketch segments and bend lines for this bend.
 KFactor	Obsolete. Superseded by IOneBendFeatureData::GetCustomBendAllowance and IOneBendFeatureData::SetCustomBendAllowance .
 ReliefDepth	Gets or sets the relief depth for this bend.
 ReliefRatio	Gets and sets the relief ratio for the one bend feature.
 ReliefWidth	Gets or sets the relief width of this bend.

	SimplifyGeometry	Gets or sets whether to simplify the geometry for this bend feature.
	UseAutoRelief	Gets or sets whether to use auto relief for this bend.
	UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this bend.
	UseDefaultBendRadius	Gets or sets whether to use the default bend radius of this bend.
	UseDefaultBendRelief	Gets or sets whether to use the default bend relief of this bend.
	UseReliefRatio	Gets or sets whether to use the relief ratio for this bend feature.

[Top](#)

See Also

[IOneBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : AccessSelections Method (IOneBendFeatureData)

Gains access to selections that define this bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean
```

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [OneBendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[OneBendFeatureData Interface](#)
[OneBendFeatureData Members](#)
[OneBendFeatureData::IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoReliefType Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : AutoReliefType Property (IOneBendFeatureData)

Gets or sets the auto-relief type from this bend.

.NET Syntax

Visual Basic (Declaration)

Property AutoReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Integer
```

```
instance.AutoReliefType = value
```

```
value = instance.AutoReliefType
```

C#

```
System.int AutoReliefType {get; set;}
```

C++/CLI

```
property System.int AutoReliefType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Auto-relief type as defined in [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::AutoReliefType](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefDepth Property](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseAutoRelief Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAllowance Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendAllowance Property (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::GetCustomBendAllowance](#) and [IOneBendFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property BendAllowance As System.Double

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.BendAllowance = value
```

```
value = instance.BendAllowance
```

C#

```
System.double BendAllowance {get; set;}
```

C++/CLI

```
property System.double BendAllowance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendAllowance](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAllowanceType Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendAllowanceType Property (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::GetCustomBendAllowance](#) and [IOneBendFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property BendAllowanceType As System.Integer

```
Dim instance As IOneBendFeatureData
Dim value As System.Integer

instance.BendAllowanceType = value

value = instance.BendAllowanceType
```

C#

```
System.int BendAllowanceType {get; set;}
```

C++/CLI

```
property System.int BendAllowanceType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendAllowanceType](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendAngle Property (IOneBendFeatureData)

[See Also](#)


[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendAngle Property (IOneBendFeatureData)

Gets or sets the bend angle of this bend.

.NET Syntax

Visual Basic (Declaration)

```
Property BendAngle As System.Double
```

Visual Basic (Usage)

```
Dim instance As IOneBendFeatureData
Dim value As System.Double

instance.BendAngle = value

value = instance.BendAngle
```

C#

```
System.double BendAngle {get; set;}
```

C++/CLI

```
property System.double BendAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend angle

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendAngle](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendDirection Property (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendDirection Property (IOneBendFeatureData)

Gets the direction of this bend.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BendDirection As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Integer
```

```
value = instance.BendDirection
```

C#

```
System.int BendDirection {get;}
```

C++/CLI

```
property System.int BendDirection {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend direction as defined in [swBendDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendDirection](#).

Example

[Get Direction of a Bend \(VBA\)](#)
[Get Direction of a Bend \(VB.NET\)](#)
[Get Direction of a Bend \(C#\)](#)

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::BendDown Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendDown Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendDown Property (IOneBendFeatureData)

Gets or sets the bend-down state of this bend.

.NET Syntax

Visual Basic (Declaration)

Property BendDown As System.Boolean

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Boolean
```

```
instance.BendDown = value
```

```
value = instance.BendDown
```

C#

```
System.bool BendDown {get; set;}
```

C++/CLI

```
property System.bool BendDown {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to set bend down, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendDown](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)
[IOneBendFeatureData::BendDirection Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendOrder Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendOrder Property (IOneBendFeatureData)

Gets or sets the bend order of this bend.

.NET Syntax

Visual Basic (Declaration)

Property BendOrder As System.Integer

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Integer  
  
instance.BendOrder = value  
value = instance.BendOrder
```

C#

```
System.int BendOrder {get; set;}
```

C++/CLI

```
property System.int BendOrder {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend order

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendOrder](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendRadius Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendRadius Property (IOneBendFeatureData)

Gets or sets the bend radius of this bend.

.NET Syntax

Visual Basic (Declaration)

Property BendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.BendRadius = value  
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendRadius](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendTableFile Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : BendTableFile Property (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::GetCustomBendAllowance](#) and [IOneBendFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BendTableFile As System.String
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.String
```

```
instance.BendTableFile = value  
value = instance.BendTableFile
```

C#

```
System.string BendTableFile {get; set;}
```

C++/CLI

```
property System.String^ BendTableFile {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::BendTableFile](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlatPatternSketchSegment Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : FlatPatternSketchSegment Property (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::FlatPatternSketchSegments](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FlatPatternSketchSegment As SketchSegment

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As SketchSegment
```

```
value = instance.FlatPatternSketchSegment
```

C#

```
SketchSegment FlatPatternSketchSegment {get;}
```

C++/CLI

```
property SketchSegment^ FlatPatternSketchSegment {  
    SketchSegment^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sketch segment](#) for this bend

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::FlatPatternSketchSegment](#).

Remarks

The sketch segment is not calculated until the part is unfolded through the user interface or by [IModelDoc2::SetBendState](#) with BendState of swSMBendStateFlattened.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

Availability

FlatPatternSketchSegments Property (IOneBendFeatureData)

[See Also](#) [Example](#)SolidWorks.Interop.sldworks Namespace > [IOneBendFeatureData Interface](#) : FlatPatternSketchSegments Property (IOneBendFeatureData)**Obsolete.** Superseded by [IOneBendFeatureData::FlatPatternSketchSegments2](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FlatPatternSketchSegments As System.Object

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Object
```

```
value = instance.FlatPatternSketchSegments
```

C#

```
System.Object FlatPatternSketchSegments {get;}
```

C++/CLI

```
property System.Object^ FlatPatternSketchSegments {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**Array of [ISketchSegments](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::FlatPatternSketchSegments](#).

Example

[Get Names of Sketch Segments \(VBA\)](#)
[Get Names of Sketch Segments \(VB.NET\)](#)
[Get Names of Sketch Segments \(C#\)](#)

Remarks

The sketch segments are calculated in the flattened model. Before calling this method, flatten the model either by un-suppressing the flat pattern in the FeatureManager design tree or by calling [IModelDoc2::SetBendState](#) to set BendState to [swSMBendState_e.swSMBendStateFlattened](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::IFlatPatternSketchSegments Method](#)
[IOneBendFeatureData::GetFlatPatternSketchSegmentCount Method](#)

Availability

SOLIDWORKS 2011 SP02, Revision Number 19.2

FlatPatternSketchSegments2 Property (IOneBendFeatureData)

[See Also](#) [Example](#)SolidWorks.Interop.sldworks Namespace > [IOneBendFeatureData Interface](#) : FlatPatternSketchSegments2 Property (IOneBendFeatureData)

Gets the sketch segments and bend lines for this bend.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property FlatPatternSketchSegments2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Object

value = instance.FlatPatternSketchSegments2
```

C#

```
System.Object FlatPatternSketchSegments2 {get;}
```

C++/CLI

```
property System.Object^ FlatPatternSketchSegments2 {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [ISketchSegment](#)s

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::FlatPatternSketchSegments2](#).

Example

[Get Names of Sketch Segments \(VBA\)](#)

Remarks

The sketch segments are calculated in the flattened model. Before calling this method, flatten the model either by unsuppressing the flat pattern in the FeatureManager design tree or by calling [IModelDoc2::SetBendState](#) to set BendState to [swSMBendState_e.swSMBendStateFlattened](#).

This property returns the bend lines for older parts that do not have flat patterns.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::IFlatPatternSketchSegments2 Method \(\)](#)
[IOneBendFeatureData::GetFlatPatternSketchSegmentCount2 Method \(\)](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#): GetCustomBendAllowance Method (IOneBendFeatureData)

Gets the custom bend allowance for this bend feature.

Visual Basic Syntax

Visual Basic (Declaration)

Function GetCustomBendAllowance() As CustomBendAllowance

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As CustomBendAllowance

value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::GetCustomBendAllowance](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFlatPatternSketchSegmentCount Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : GetFlatPatternSketchSegmentCount Method (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::GetFlatPatternSketchSegmentCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFlatPatternSketchSegmentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Integer

value = instance.GetFlatPatternSketchSegmentCount()
```

C#

```
System.int GetFlatPatternSketchSegmentCount()
```

C++/CLI

```
System.int GetFlatPatternSketchSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch segments

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::GetFlatPatternSketchSegmentCount](#).

Remarks

Call this method to populate SegmentsCount in [IOneBendFeatureData::IFlatPatternSketchSegments](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::FlatPatternSketchSegments Property](#)

Availability

SOLIDWORKS 2011 SP02, Revision Number 19.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFlatPatternSketchSegmentCount2 Method (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : GetFlatPatternSketchSegmentCount2 Method (IOneBendFeatureData)

Gets the number of sketch segments, including bend lines, in this bend.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFlatPatternSketchSegmentCount2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Integer

value = instance.GetFlatPatternSketchSegmentCount2()
```

C#

```
System.int GetFlatPatternSketchSegmentCount2()
```

C++/CLI

```
System.int GetFlatPatternSketchSegmentCount2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch segments in this bend

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::GetFlatPatternSketchSegmentCount2](#).

Example

[Get Names of Sketch Segments \(VBA\)](#)

Remarks

Call this method to populate SegmentsCount in [OneBendFeatureData::IFlatPatternSketchSegments2](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::FlatPatternSketchSegments2 Property \(\)](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : GetType Method (IOneBendFeatureData)

Gets the type of bend for this one bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Integer

value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Bend type as defined in [swBendType_e](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::GetType](#).

Example

[Get Names of Sketch Segments \(VBA\)](#)
[Get Names of Sketch Segments \(VB.NET\)](#)
[Get Names of Sketch Segments \(C#\)](#)

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : IAccessSelections Method (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::IAccessSelections](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : IAccessSelections2 Method (IOneBendFeatureData)

Gains access to selections that define this bend feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IOneBendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IOneBendFeatureData Interface](#)

[IOneBendFeatureData Members](#)

[IOneBendFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFlatPatternSketchSegments Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : IFlatPatternSketchSegments Method (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::IFlatPatternSketchSegments2](#)

.NET Syntax

Visual Basic (Declaration)

```
Function IFlatPatternSketchSegments( _  
    ByVal SegmentsCount As System.Integer _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim SegmentsCount As System.Integer  
Dim value As SketchSegment  
  
value = instance.IFlatPatternSketchSegments(SegmentsCount)
```

C#

```
SketchSegment IFlatPatternSketchSegments(  
    System.int SegmentsCount  
)
```

C++/CLI

```
SketchSegment^ IFlatPatternSketchSegments(  
& System.int SegmentsCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SegmentsCount
Number of sketch segments (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISketchSegments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IOneBendFeatureData::GetFlatPatternSketchSegmentCount](#) to populate SegmentsCount.

The sketch segments are calculated in the flattened model. Before calling this method, flatten the model either by un-suppressing the flat pattern in the FeatureManager design tree or by calling [IModelDoc2::SetBendState](#) to set BendState to [swSMBendState_e.swSMBendStateFlattened](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::FlatPatternSketchSegments Property](#)

Availability

SOLIDWORKS 2011 SP02, Revision Number 19.2

IFlatPatternSketchSegments2 Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : IFlatPatternSketchSegments2 Method (IOneBendFeatureData)

Gets the sketch segments and bend lines for this bend.

.NET Syntax

Visual Basic (Declaration)

```
Function IFlatPatternSketchSegments2( _
    ByVal SegmentsCount As System.Integer _
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim SegmentsCount As System.Integer
Dim value As SketchSegment
```

```
value = instance.IFlatPatternSketchSegments2(SegmentsCount)
```

C#

```
SketchSegment IFlatPatternSketchSegments2(
    System.int SegmentsCount
)
```

C++/CLI

```
SketchSegment^ IFlatPatternSketchSegments2(
    & System.int SegmentsCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SegmentsCount
Number of sketch segments (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISketchSegments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IOneBendFeatureData::GetFlatPatternSketchSegmentCount2](#) to populate SegmentsCount.

The sketch segments are calculated in the flattened model. Before calling this method, flatten the model either by unsuppressing the flat pattern in the FeatureManager design tree or by calling [IModelDoc2::SetBendState](#) to set BendState to [swSMBendState_e.swSMBendStateFlattened](#).

This property returns the bend lines for older parts that do not have flat patterns.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::FlatPatternSketchSegments2 Property\(\)](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

KFactor Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : KFactor Property (IOneBendFeatureData)

Obsolete. Superseded by [IOneBendFeatureData::GetCustomBendAllowance](#) and [IOneBendFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property KFactor As System.Double

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.KFactor = value
```

```
value = instance.KFactor
```

C#

```
System.double KFactor {get; set;}
```

C++/CLI

```
property System.double KFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::KFactor](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : ReleaseSelectionAccess Method (IOneBendFeatureData)

Accesses the selections that describe this bend feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::ReleaseSelectionAccess](#).

Remarks

[IOneBendFeatureData::AccessSelections](#) and [IOneBendFeatureData::IAccessSelections2](#) put the model in a rollback state to allow access to the selections that define the bend feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefDepth Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : ReliefDepth Property (IOneBendFeatureData)

Gets or sets the relief depth for this bend.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.ReliefDepth = value
```

```
value = instance.ReliefDepth
```

C#

```
System.double ReliefDepth {get; set;}
```

C++/CLI

```
property System.double ReliefDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief depth

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::ReliefDepth](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::AutoReliefType Property](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : ReliefRatio Property (IOneBendFeatureData)

Gets and sets the relief ratio for the one bend feature.

.NET Syntax

Visual Basic (Declaration)

Property ReliefRatio As System.Double

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.ReliefRatio = value
```

```
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief ratio

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::ReliefRatio](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefDepth Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseAutoRelief Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefWidth Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : ReliefWidth Property (IOneBendFeatureData)

Gets or sets the relief width of this bend.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Double
```

```
instance.ReliefWidth = value
```

```
value = instance.ReliefWidth
```

C#

```
System.double ReliefWidth {get; set;}
```

C++/CLI

```
property System.double ReliefWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::ReliefWidth](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefDepth Property](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)
[IOneBendFeatureData::AutoReliefType Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetCustomBendAllowance Method (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : SetCustomBendAllowance Method (IOneBendFeatureData)

Sets the custom bend allowance for the bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData
[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimplifyGeometry Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : SimplifyGeometry Property (IOneBendFeatureData)

Gets or sets whether to simplify the geometry for this bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SimplifyGeometry As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Boolean

instance.SimplifyGeometry = value
value = instance.SimplifyGeometry
```

C#

```
System.bool SimplifyGeometry {get; set;}
```

C++/CLI

```
property System.bool SimplifyGeometry {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to simplify the geometry, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::SimplifyGeometry](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseAutoRelief Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : UseAutoRelief Property (IOneBendFeatureData)

Gets or sets whether to use auto relief for this bend.

.NET Syntax

Visual Basic (Declaration)

```
Property UseAutoRelief As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData
Dim value As System.Boolean

instance.UseAutoRelief = value
value = instance.UseAutoRelief
```

C#

```
System.bool UseAutoRelief {get; set;}
```

C++/CLI

```
property System.bool UseAutoRelief {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use auto relief, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::UseAutoRelief](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)
[IOneBendFeatureData::AutoReliefType Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : UseDefaultBendAllowance Property (IOneBendFeatureData)

Gets or sets whether to use the default bend allowance for this bend.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendAllowance As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Boolean  
  
instance.UseDefaultBendAllowance = value  
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend allowance, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::UseDefaultBendAllowance](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::UseDefaultBendRadius Property](#)
[IOneBendFeatureData::BendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRadius Property (IOneBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : UseDefaultBendRadius Property (IOneBendFeatureData)

Gets or sets whether to use the default bend radius of this bend.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Boolean  
  
instance.UseDefaultBendRadius = value  
  
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend radius, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::UseDefaultBendRadius](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)

[IOneBendFeatureData::BendRadius Property](#)
[IOneBendFeatureData::GetCustomBendAllowance Method](#)
[IOneBendFeatureData::SetCustomBendAllowance Method](#)
[IOneBendFeatureData::BendAngle Property](#)
[IOneBendFeatureData::BendDown Property](#)
[IOneBendFeatureData::BendOrder Property](#)
[IOneBendFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRelief Property (IOneBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IOneBendFeatureData Interface](#) : UseDefaultBendRelief Property (IOneBendFeatureData)

Gets or sets whether to use the default bend relief of this bend.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendRelief As System.Boolean

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRelief = value
```

```
value = instance.UseDefaultBendRelief
```

C#

```
System.bool UseDefaultBendRelief {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRelief {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend relief, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::UseDefaultBendRelief](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefDepth Property](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseReliefRatio Property](#)
[IOneBendFeatureData::AutoReliefType Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseReliefRatio Property (IOneBendFeatureData)

[See Also](#)



Gets or sets whether to use the relief ratio for this bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseReliefRatio As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IOneBendFeatureData  
Dim value As System.Boolean
```

```
instance.UseReliefRatio = value
```

```
value = instance.UseReliefRatio
```

C#

```
System.bool UseReliefRatio {get; set;}
```

C++/CLI

```
property System.bool UseReliefRatio {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the relief ratio, false to not

Visual Basic for Applications (VBA) Syntax

See [OneBendFeatureData::UseReliefRatio](#).

See Also

[IOneBendFeatureData Interface](#)
[IOneBendFeatureData Members](#)
[IOneBendFeatureData::ReliefDepth Property](#)
[IOneBendFeatureData::ReliefRatio Property](#)
[IOneBendFeatureData::ReliefWidth Property](#)
[IOneBendFeatureData::UseDefaultBendRelief Property](#)
[IOneBendFeatureData::AutoReliefType Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0