

SOLIDWORKS API (.NET VBA C#) — Reference

(216/337): IPackAndGo-IPageSetup

SOLIDWORKS API Documentation (converted from CHM)

IPackAndGo (Type)

IPackAndGo Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPackAndGo Interface

Allows access to Pack and Go.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPackAndGo
```

Visual Basic (Usage)

```
Dim instance As IPackAndGo
```

C#

```
public interface IPackAndGo
```

C++/CLI

```
public interface class IPackAndGo
```

Visual Basic for Applications (VBA) Syntax

See [PackAndGo](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)
[Add and Remove Files from Pack and Go \(C#\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(VBA\)](#)
[Pack and Go Part and Linked Equation \(C#\)](#)
[Pack and Go Part and Linked Equation \(VB.NET\)](#)
[Pack and Go Part and Linked Equation \(VBA\)](#)

Remarks

Call [IModelDocExtension::SavePackAndGo](#) after setting up Pack and Go.

Accessors

[IModelDocExtension::GetPackAndGo](#)

Access Diagram

[PackAndGo](#)

See Also

[IPackAndGo Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPackAndGo Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPackAndGo Interface

For a list of all members of this type, see [IPackAndGo members](#).

Public Methods

Name	Description
 AddExternalDocuments	Adds non-SOLIDWORKS files to Pack and Go.
 GetDocumentNames	Gets the original paths and filenames of all of the model's documents for Pack and Go.
 GetDocumentNamesCount	Gets the number of documents comprising the model for Pack and Go.
 GetDocumentSaveToNames	Gets the paths and filenames to which to save the model's documents for Pack and Go set by IPackAndGo::SetDocumentSaveToNames .
 GetExternalDocuments	Gets the paths and filenames of the non-SOLIDWORKS files added to Pack And Go.
 GetSaveToName	Gets the path or the path and filename of the Zip file for Pack and Go set by IPackAndGo::SetSaveToName .
 IGetDocumentNames	Gets the original paths and filenames of all of the model's documents for Pack and Go.
 IGetDocumentSaveToNames	Gets the paths and filenames to which to save the model's documents for Pack and Go set by IPackAndGo::IGetDocumentSaveToNames .
 ISetDocumentSaveToNames	Sets the paths and filenames of the documents to save in Pack and Go.
 RemoveExternalDocuments	Removes the specified non-SOLIDWORKS files from Pack and Go.
 SetDocumentSaveToNames	Sets the paths and filenames of the documents for Pack and Go.
 SetSaveToName	Obsolete. Superseded by IPackAndGo::SetSaveToName2
 SetSaveToName2	Overrides the paths and filenames of the documents set by IPackAndGo::SetDocumentSaveToNames or IPackAndGo::ISetDocumentSaveToNames with the specified path or the path and name of the Zip file.

[Top](#)

See Also

[IPackAndGo Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPackAndGo Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPackAndGo Interface

The following tables list the members exposed by [IPackAndGo](#).

Public Properties

Name	Description
 AddPrefix	Gets or sets a prefix for all filenames for Pack and Go.
 AddSuffix	Gets or sets a suffix for all filenames for Pack and Go.
 FlattenToSingleFolder	Gets or sets whether to save all files to the root directory of the Pack and Go destination folder.
 FolderStructureOption	Gets or sets the folder structure to save to with Pack and Go.
 IncludeDrawings	Gets or sets whether to add the model's drawing documents to Pack and Go.
 IncludeSimulationResults	Gets or sets whether to add the model's SOLIDWORKS Simulation results to Pack and Go.
 IncludeSuppressed	Gets or sets whether to include suppressed components in Pack and Go.
 IncludeToolboxComponents	Gets or sets whether to include SOLIDWORKS Toolbox components in Pack and Go.

[Top](#)

Public Methods

Name	Description
 AddExternalDocuments	Adds non-SOLIDWORKS files to Pack and Go.
 GetDocumentNames	Gets the original paths and filenames of all of the model's documents for Pack and Go.
 GetDocumentNamesCount	Gets the number of documents comprising the model for Pack and Go.
 GetDocumentSaveToNames	Gets the paths and filenames to which to save the model's documents for Pack and Go set by IPackAndGo::SetDocumentSaveToNames .

	GetExternalDocuments	Gets the paths and filenames of the non-SOLIDWORKS files added to Pack And Go.
	GetSaveToName	Gets the path or the path and filename of the Zip file for Pack and Go set by IPackAndGo::SetSaveToName .
	IGetDocumentNames	Gets the original paths and filenames of all of the model's documents for Pack and Go.
	IGetDocumentSaveToNames	Gets the paths and filenames to which to save the model's documents for Pack and Go set by IPackAndGo::IGetDocumentSaveToNames .
	ISetDocumentSaveToNames	Sets the paths and filenames of the documents to save in Pack and Go.
	RemoveExternalDocuments	Removes the specified non-SOLIDWORKS files from Pack and Go.
	SetDocumentSaveToNames	Sets the paths and filenames of the documents for Pack and Go.
	SetSaveToName	Obsolete. Superseded by IPackAndGo::SetSaveToName2 .
	SetSaveToName2	Overrides the paths and filenames of the documents set by IPackAndGo::SetDocumentSaveToNames or IPackAndGo::ISetDocumentSaveToNames with the specified path or the path and name of the Zip file.

[Top](#)

 See Also

[IPackAndGo Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IPackAndGo Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPackAndGo Interface

For a list of all members of this type, see [IPackAndGo members](#).

 Public Properties

Name	Description
 AddPrefix	Gets or sets a prefix for all filenames for Pack and Go.
 AddSuffix	Gets or sets a suffix for all filenames for Pack and Go.
 FlattenToSingleFolder	Gets or sets whether to save all files to the root directory of the Pack and Go destination folder.
 FolderStructureOption	Gets or sets the folder structure to save to with Pack and Go.
 IncludeDrawings	Gets or sets whether to add the model's drawing documents to Pack and Go.
 IncludeSimulationResults	Gets or sets whether to add the model's SOLIDWORKS Simulation results to Pack and Go.
 IncludeSuppressed	Gets or sets whether to include suppressed components in Pack and Go.
 IncludeToolboxComponents	Gets or sets whether to include SOLIDWORKS Toolbox components in Pack and Go.

[Top](#)

 See Also

[IPackAndGo Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

AddExternalDocuments Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : AddExternalDocuments Method (IPackAndGo)

Adds non-SOLIDWORKS files to Pack and Go.

 .NET Syntax

Visual Basic (Declaration)

```
Function AddExternalDocuments( _  
    ByVal DocumentNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo
Dim DocumentNames As System.Object
Dim value As System.Boolean

value = instance.AddExternalDocuments(DocumentNames)
```

C#

```
System.bool AddExternalDocuments(
    System.object DocumentNames
)
```

C++/CLI

```
System.bool AddExternalDocuments(
    & System.Object^ DocumentNames
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DocumentNames
Array of paths and filenames of non-SOLIDWORKS files to add to Pack and Go

Return Value

True if the files are added to Pack and Go, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::AddExternalDocuments](#).

Example

[Add and Remove Files from Pack And Go \(C#\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(VBA\)](#)

Remarks

Duplicate files are not allowed. You can add any type of non-SOLIDWORKS file.

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetExternalDocuments Method](#)
[IModelDocExtension::GetRenderCustomReferences Method](#)
[IModelDocExtension::GetRenderStockReferences Method](#)
[IPackAndGo::RemoveExternalDocuments Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddPrefix Property (IPackAndGo)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : AddPrefix Property (IPackAndGo)

Gets or sets a prefix for all filenames for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Property AddPrefix As System.String
```

```
Dim instance As IPackAndGo
Dim value As System.String

instance.AddPrefix = value

value = instance.AddPrefix
```

C#

```
System.string AddPrefix {get; set;}
```

C++/CLI

```
property System.String^ AddPrefix {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Prefix for all filenames

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::AddPrefix](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::AddSuffix Property](#)
[IPackAndGo::ISetDocumentSaveToNames Method](#)
[IPackAndGo::SetDocumentSaveToNames Method](#)
[IPackAndGo::SetSaveToName Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddSuffix Property (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : AddSuffix Property (IPackAndGo)

Gets or sets a suffix for all filenames for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Property AddSuffix As System.String
```

Visual Basic (Usage)

```
Dim instance As IPackAndGo
Dim value As System.String

instance.AddSuffix = value

value = instance.AddSuffix
```

C#

```
System.string AddSuffix {get; set;}
```

C++/CLI

```
property System.String^ AddSuffix {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Suffix for all filenames

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::AddSuffix](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::AddPrefix Property](#)
[IPackAndGo::ISetDocumentSaveToNames Method](#)
[IPackAndGo::SetDocumentSaveToNames Method](#)
[IPackAndGo::SetSaveToName Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlattenToSingleFolder Property (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : FlattenToSingleFolder Property (IPackAndGo)

Gets or sets whether to save all files to the root directory of the Pack and Go destination folder.

.NET Syntax

Visual Basic (Declaration)

```
Property FlattenToSingleFolder As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.Boolean  
  
instance.FlattenToSingleFolder = value  
  
value = instance.FlattenToSingleFolder
```

C#

```
System.bool FlattenToSingleFolder {get; set;}
```

C++/CLI

```
property System.bool FlattenToSingleFolder {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to save all files to the root directory of the Pack and Go destination folder, false to save the files to subfolders in the destination folder that mirror the current model's folder structure

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::FlattenToSingleFolder](#).

Example

[Pack and Go an Assembly \(VBA\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(C#\)](#)

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::SetSaveToName Method \(\)](#)
[IPackAndGo::SetDocumentSaveToNames Method \(\)](#)
[IPackAndGo::!SetDocumentSaveToNames Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FolderStructureOption Property (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : FolderStructureOption Property (IPackAndGo)

Gets or sets the folder structure to save to with Pack and Go.

.NET Syntax

Visual Basic (Declaration)

Property FolderStructureOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.Integer  
  
instance.FolderStructureOption = value  
value = instance.FolderStructureOption
```

C#

```
System.int FolderStructureOption {get; set;}
```

C++/CLI

```
property System.int FolderStructureOption {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Folder structure as defined by [swPackAndGoFolderOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::FolderStructureOption](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::SetSaveToName2 Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentNames Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : GetDocumentNames Method (IPackAndGo)

Gets the original paths and filenames of all of the model's documents for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentNames( _  
    ByRef DocumentNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim DocumentNames As System.Object  
Dim value As System.Boolean  
  
value = instance.GetDocumentNames(DocumentNames)
```

C#

```
System.bool GetDocumentNames(  
    out System.object DocumentNames  
)
```

C++/CLI

```
System.bool GetDocumentNames(  
& [Out] System.Object^ DocumentNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DocumentNames

Array of strings of the original paths and filenames of all of the model's documents

Return Value

True if the original paths and filenames of all of the model's documents are returned, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::GetDocumentNames](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

Remarks

To get the drawing documents of the model, set [IPackAndGo::IncludeDrawings](#) to true; otherwise, the paths and filenames of the model's drawing documents are not returned.

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetDocumentNamesCount Method](#)
[IPackAndGo::!GetDocumentNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentNamesCount Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : GetDocumentNamesCount Method (IPackAndGo)

Gets the number of documents comprising the model for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentNamesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.Integer  
  
value = instance.GetDocumentNamesCount()
```

C#

```
System.int GetDocumentNamesCount()
```

C++/CLI

```
System.int GetDocumentNamesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of documents comprising the model

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::GetDocumentNamesCount](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

Remarks

Call this method before calling [IPackAndGo::!GetDocumentNames](#) and [IPackAndGo::!GetDocumentSaveToNames](#) to determine the size of the array for each method.

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentSaveToNames Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : GetDocumentSaveToNames Method (IPackAndGo)

Gets the paths and filenames to which to save the model's documents for Pack and Go set by [IPackAndGo::SetDocumentSaveToNames](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDocumentSaveToNames( _  
    ByRef PathNameList As System.Object, _  
    ByRef DocumentStatusList As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim PathNameList As System.Object  
Dim DocumentStatusList As System.Object  
Dim value As System.Boolean  
  
value = instance.GetDocumentSaveToNames(PathNameList, DocumentStatusList)
```

C#

```
System.bool GetDocumentSaveToNames(  
    out System.object PathNameList,  
    out System.object DocumentStatusList  
)
```

C++/CLI

```
System.bool GetDocumentSaveToNames(  
& [Out] System.Object^ PathNameList,  
& [Out] System.Object^ DocumentStatusList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathNameList

Array of strings containing the path and filenames to which to save the model's documents (see **Remarks**)

DocumentStatusList

Array containing the types of documents as defined in [swPackAndGoDocumentStatus_e](#)

Return Value

True if the paths and filenames of the model's documents are returned, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::GetDocumentSaveToNames](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

Remarks

The order and number of documents must match the order of the array returned by [IPackAndGo::GetDocumentNames](#). If a [prefix](#) or [suffix](#) is set then the filenames include it. You can set both a prefix and suffix for the filenames.

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::IGetDocumentSaveToNames Method](#)
[IPackAndGo::ISetDocumentSaveToNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetExternalDocuments Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : GetExternalDocuments Method (IPackAndGo)

Gets the paths and filenames of the non-SOLIDWORKS files added to Pack And Go.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExternalDocuments( _  
    ByRef DocumentNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim DocumentNames As System.Object  
Dim value As System.Boolean  
  
value = instance.GetExternalDocuments(DocumentNames)
```

C#

```
System.bool GetExternalDocuments(  
    out System.object DocumentNames  
)
```

C++/CLI

```
System.bool GetExternalDocuments(  
    & [Out] System.Object^ DocumentNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DocumentNames
Array of strings of the paths and filenames of the non-SOLIDWORKS files added to Pack and Go

Return Value

True if the paths and filenames of the non-SOLIDWORKS files are returned, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::GetExternalDocuments](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::AddExternalDocuments Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

GetSaveToName Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : GetSaveToName Method (IPackAndGo)

Gets the path or the path and filename of the Zip file for Pack and Go set by [IPackAndGo::SetSaveToName](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSaveToName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.String  
  
value = instance.GetSaveToName()
```

C#

```
System.string GetSaveToName()
```

C++/CLI

```
System.String^ GetSaveToName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Path or the path and filename of the Zip file set by [IPackAndGo::SetSaveToName](#)

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::GetSaveToName](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetDocumentSaveToNames Method](#)
[IPackAndGo::IGetDocumentSaveToNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

IGetDocumentNames Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IGetDocumentNames Method (IPackAndGo)

Gets the original paths and filenames of all of the model's documents for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDocumentNames( _  
    ByVal Count As System.Integer, _  
    ByRef DocumentNames As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo
Dim Count As System.Integer
Dim DocumentNames As System.String
Dim value As System.Boolean

value = instance.IGetDocumentNames(Count, DocumentNames)
```

C#

```
System.bool IGetDocumentNames(
    System.int Count,
    out System.string DocumentNames
)
```

C++/CLI

```
System.bool IGetDocumentNames(
    & System.int Count,
    & [Out] System.String^ DocumentNames
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of model's documents

DocumentNames

- in-process, unmanaged C++: Pointer to an array of strings containing the original paths and filenames of the model's documents
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the original paths and filenames of the model's documents are returned, false if not

Remarks

Before calling this method, call [IPackAndGo::GetDocumentNamesCount](#) to get the value of Count.

To get the drawing documents of the model, set [IPackAndGo::IncludeDrawings](#) to true; otherwise, the paths and filenames of the model's drawing documents are not returned.

See Also

[IPackAndGo Interface](#)

[IPackAndGo Members](#)

[IPackAndGo::GetDocumentNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDocumentSaveToNames Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IGetDocumentSaveToNames Method (IPackAndGo)

Gets the paths and filenames to which to save the model's documents for Pack and Go set by [IPackAndGo::ISetDocumentSaveToNames](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDocumentSaveToNames( _
    ByVal NameCount As System.Integer, _
    ByRef NameList As System.String, _
    ByRef StatusList As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```

Dim instance As IPackAndGo
Dim NameCount As System.Integer
Dim NameList As System.String
Dim StatusList As System.Integer
Dim value As System.Boolean

value = instance.IGetDocumentSaveToNames(NameCount, NameList, StatusList)

```

C#

```

System.bool IGetDocumentSaveToNames(
    System.int NameCount,
    out System.string NameList,
    out System.int StatusList
)

```

C++/CLI

```

System.bool IGetDocumentSaveToNames(
    & System.int NameCount,
    & [Out] System.String^ NameList,
    & [Out] System.int StatusList
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameCount

Number of documents comprising the model

NameList

- in-process, unmanaged C++: Pointer to an array of strings containing the paths and filenames of the model's documents
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

StatusList

Array containing the types of documents as defined in [swPackAndGoDocumentStatus_e](#)

Return Value

True if the paths and filenames of the model's documents are returned, false if not

Remarks

Before calling this method, call [IPackAndGo::GetDocumentNamesCount](#) to get the value of NameCount.

See Also

[IPackAndGo Interface](#)

[IPackAndGo Members](#)

[IPackAndGo::ISetDocumentSaveToNames Method](#)

[IPackAndGo::GetDocumentSaveToNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeDrawings Property (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IncludeDrawings Property (IPackAndGo)

Gets or sets whether to add the model's drawing documents to Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Property IncludeDrawings As System.Boolean
```

```
Dim instance As IPackAndGo
Dim value As System.Boolean

instance.IncludeDrawings = value

value = instance.IncludeDrawings
```

C#

```
System.bool IncludeDrawings {get; set;}
```

C++/CLI

```
property System.bool IncludeDrawings {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the model's drawings documents are added to Pack and Go, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::IncludeDrawings](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeSimulationResults Property (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IncludeSimulationResults Property (IPackAndGo)

Gets or sets whether to add the model's SOLIDWORKS Simulation results to Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Property IncludeSimulationResults As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPackAndGo
Dim value As System.Boolean

instance.IncludeSimulationResults = value

value = instance.IncludeSimulationResults
```

C#

```
System.bool IncludeSimulationResults {get; set;}
```

C++/CLI

```
property System.bool IncludeSimulationResults {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the model's SOLIDWORKS Simulation results are added to Pack and Go, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::IncludeSimulationResults](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeSuppressed Property (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IncludeSuppressed Property (IPackAndGo)

Gets or sets whether to included suppressed components in Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Property IncludeSuppressed As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.Boolean  
  
instance.IncludeSuppressed = value  
  
value = instance.IncludeSuppressed
```

C#

```
System.bool IncludeSuppressed {get; set;}
```

C++/CLI

```
property System.bool IncludeSuppressed {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if suppressed components are added to Pack and Go, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::IncludeSuppressed](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IncludeToolboxComponents Property (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : IncludeToolboxComponents Property (IPackAndGo)

Gets or sets whether to include SOLIDWORKS Toolbox components in Pack and Go.

.NET Syntax

Visual Basic (Declaration)

Property IncludeToolboxComponents As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim value As System.Boolean
```

```
instance.IncludeToolboxComponents = value
```

```
value = instance.IncludeToolboxComponents
```

C#

```
System.bool IncludeToolboxComponents {get; set;}
```

C++/CLI

```
property System.bool IncludeToolboxComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include SOLIDWORKS Toolbox components in Pack and Go, false to not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::IncludeToolboxComponents](#).

Example

[Pack and Go an Assembly \(C#\)](#)
[Pack and Go an Assembly \(VB.NET\)](#)
[Pack and Go an Assembly \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetDocumentSaveToNames Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : ISetDocumentSaveToNames Method (IPackAndGo)

Sets the paths and filenames of the documents to save in Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetDocumentSaveToNames( _  
    ByVal NameCount As System.Integer, _  
    ByRef NameList As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim NameCount As System.Integer  
Dim NameList As System.String  
Dim value As System.Boolean  
  
value = instance.ISetDocumentSaveToNames(NameCount, NameList)
```

C#

```
System.bool ISetDocumentSaveToNames(  
    System.int NameCount,  
    ref System.string NameList  
)
```

C++/CLI

```
System.bool ISetDocumentSaveToNames(  
& System.int NameCount,  
& System.String^% NameList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameCount

Number of documents comprising the model

NameList

- in-process, unmanaged C++: Pointer to an array of strings containing the paths and filenames to which to save the model's documents
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the paths and filenames are set, false if not

Remarks

The number, order, and type of documents must match the array returned by [IPackAndGo::IGetDocumentNames](#). You cannot change the filename of a document if the document is a virtual component. Duplicate files are not allowed.

To remove a file from Pack and Go, specify an empty string for that file's element in the NameList array. To override the paths and filenames set by this method, use [IPackAndGo::SetSaveToName](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::IGetDocumentSaveToNames Method](#)
[IPackAndGo::SetDocumentSaveToNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveExternalDocuments Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : RemoveExternalDocuments Method (IPackAndGo)

Removes the specified non-SOLIDWORKS files from Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveExternalDocuments( _  
    ByVal DocumentNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim DocumentNames As System.Object  
Dim value As System.Boolean  
  
value = instance.RemoveExternalDocuments(DocumentNames)
```

C#

```
System.bool RemoveExternalDocuments(  
    System.object DocumentNames  
)
```

C++/CLI

```
System.bool RemoveExternalDocuments(  
& System.Object^ DocumentNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DocumentNames

Array of the paths and filenames of the non-SOLIDWORKS files to remove from Pack and Go

Return Value

True if all of the specified non-SOLIDWORKS files are removed from Pack and Go, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::RemoveExternalDocuments](#).

Example

[Add and Remove Files from Pack and Go \(C#\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(VBA\)](#)

Remarks

In C# applications, you must wrap the array of objects for the DocumentNames parameter using the .NET Framework BStrWrapper class.

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::AddExternalDocuments Method](#)
[IPackAndGo::GetDocumentNames Method](#)
[IPackAndGo::GetDocumentNamesCount Method](#)
[IPackAndGo::GetDocumentNames Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDocumentSaveToNames Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : SetDocumentSaveToNames Method (IPackAndGo)

Sets the paths and filenames of the documents for Pack and Go.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDocumentSaveToNames(  
    ByVal PathNameList As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim PathNameList As System.Object  
Dim value As System.Boolean  
  
value = instance.SetDocumentSaveToNames(PathNameList)
```

C#

```
System.bool SetDocumentSaveToNames(  
    System.object PathNameList  
)
```

C++/CLI

```
System.bool SetDocumentSaveToNames(  
& System.Object^ PathNameList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathNameList

Array of paths and filenames to which to save the model's documents

Return Value

True if the paths and filenames are set, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::SetDocumentSaveToNames](#).

Remarks

The number, order, and type of documents to save must match the array returned by [IPackAndGo::GetDocumentNames](#). You cannot change the filename of a document if the document is a virtual component. Duplicate files are not allowed.

To remove a file from Pack and Go, specify an empty string for that file's element in the PathNameList array. To override the paths and filenames set by this method, use [IPackAndGo::SetSaveToName](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetDocumentSaveToNames Method](#)
[IPackAndGo::!SetDocumentSaveToNames Method](#)
[IPackAndGo::FlattenToSingleFolder Property \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSaveToName Method (IPackAndGo)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : SetSaveToName Method (IPackAndGo)

Obsolete. Superseded by [IPackAndGo::SetSaveToName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetSaveToName( _  
    ByVal Override As System.Boolean, _  
    ByVal SaveToName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim Override As System.Boolean  
Dim SaveToName As System.String  
Dim value As System.Boolean  
  
value = instance.SetSaveToName(Override, SaveToName)
```

C#

```
System.bool SetSaveToName(  
    System.bool Override,  
    System.string SaveToName  
)
```

C++/CLI

```
System.bool SetSaveToName(  
& System.bool Override,  
& System.String^ SaveToName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Override

True to override the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::!SetDocumentSaveToNames](#), false to not

SaveToName

Path or the path and filename of the Zip file to use to override the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::!SetDocumentSaveToNames](#)

Return Value

True if the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::!SetDocumentSaveToNames](#) are overridden, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::SetSaveToName](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetSaveToName Method](#)
[IPackAndGo::FlattenToSingleFolder Property \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSaveToName2 Method (IPackAndGo)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPackAndGo Interface](#) : SetSaveToName2 Method (IPackAndGo)

Overrides the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::ISetDocumentSaveToNames](#) with the specified path or the path and name of the Zip file.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSaveToName2( _  
    ByVal Override As System.Boolean, _  
    ByVal SaveToName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPackAndGo  
Dim Override As System.Boolean  
Dim SaveToName As System.String  
Dim value As System.Boolean  
  
value = instance.SetSaveToName2(Override, SaveToName)
```

C#

```
System.bool SetSaveToName2(  
    System.bool Override,  
    System.string SaveToName  
)
```

C++/CLI

```
System.bool SetSaveToName2(  
& System.bool Override,  
& System.String^ SaveToName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Override

True to override the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::ISetDocumentSaveToNames](#), false to not

SaveToName

Path or the path and filename of the Zip file to use to override the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::ISetDocumentSaveToNames](#)

Return Value

True if the paths and filenames of the documents set by [IPackAndGo::SetDocumentSaveToNames](#) or [IPackAndGo::ISetDocumentSaveToNames](#) are overridden, false if not

Visual Basic for Applications (VBA) Syntax

See [PackAndGo::SetSaveToName2](#).

Example

[Add and Remove Files from Pack and Go \(VBA\)](#)
[Add and Remove Files from Pack and Go \(VB.NET\)](#)
[Add and Remove Files from Pack and Go \(C#\)](#)

Remarks

The difference between this method and the now obsolete `IPackAndGo::SetSaveToName` is that this method supports saving to minimal folders. It saves to any folder structure as defined by [IPackAndGo::FolderStructureOption](#).

See Also

[IPackAndGo Interface](#)
[IPackAndGo Members](#)
[IPackAndGo::GetSaveToName Method \(\)](#)
[IPackAndGo::FlattenToSingleFolder Property \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

IPageSetup (Type)

IPageSetup Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPageSetup Interface

Allows access to a number of properties related to printer and page setup, including page header and footer information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPageSetup
```

Visual Basic (Usage)

```
Dim instance As IPageSetup
```

C#

```
public interface IPageSetup
```

C++/CLI

```
public interface class IPageSetup
```

Visual Basic for Applications (VBA) Syntax

See [PageSetup](#).

Example

[Get Whether Draft Edges Scaled in Printed Drawing \(C#\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VB.NET\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VBA\)](#)
[Print Drawing \(C#\)](#)
[Print Drawing \(VB.NET\)](#)
[Print Drawing \(VBA\)](#)

Accessors

[IModelDoc2::PageSetup](#)

[IModelDocExtension::AppPageSetup](#)

[ISheet::PageSetup](#) and [ISheet::IPageSetup](#)

Access Diagram

[PageSetup](#)

See Also

[IPageSetup Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPageSetup Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPageSetup Interface

The following tables list the members exposed by [IPageSetup](#).

Public Properties

Name	Description
 CenterFooter	Gets or sets the page footer in the center of the page.
 CenterHeader	Gets or sets the page header in the center of the page.
 DrawingColor	Sets the color of the drawing for printing.
 FooterTextFormat	Gets or sets the text format for the page footer.
 HeaderTextFormat	Gets or sets the text format for the page header.
 HighQuality	Gets or sets whether to print a drawing in high quality.
 LeftFooter	Gets or sets the page footer on the left side of the page.
 LeftHeader	Gets or sets the page header on the left side of the page.
 Orientation	Gets or sets the page orientation.
 PrinterPaperLength	Gets or sets the user-defined printer paper length for this document or sheet.
 PrinterPaperSize	Gets or sets the printer paper size for this document or sheet.
 PrinterPaperSource	Gets or sets the printer paper source for this document or sheet.
 PrinterPaperWidth	Gets or sets the user-defined printer paper width for this document or sheet.
 RightFooter	Gets or sets the page footer on the right side of the page.
 RightHeader	Gets or sets the page header on the right side of the page.
 Scale2	Gets or sets the scale for printing the page.
 ScaleDraftEdges	Gets or sets whether to scale draft edges when printing a drawing in high quality.
 ScaleToFit	Enables or disables scaling the page to fit the printer.
 UsePageSetupOnSheets	Obsolete. Superseded by IModelDocExtension.UsePageSetup .

[Top](#)

Public Methods

Name	Description
 GetHeaderFooterString	Gets the specified standard string that can be used in headers and footers.
 GetResolution	Gets the current printer resolution on documents and drawing sheets.
 GetUseDefaultResolution	Gets whether the printer default resolution is in use on documents and drawing sheets.
 SetFooter	Sets the entire page footer.
 SetHeader	Sets the entire page header.
 SetResolution	Sets the current printer resolution on documents and drawing sheets.

[Top](#)

See Also

[IPageSetup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPageSetup Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPageSetup Interface

For a list of all members of this type, see [IPageSetup members](#).

Public Methods

Name	Description
 GetHeaderFooterString	Gets the specified standard string that can be used in headers and footers.
 GetResolution	Gets the current printer resolution on documents and drawing sheets.
 GetUseDefaultResolution	Gets whether the printer default resolution is in use on documents and drawing sheets.

		
	SetFooter	Sets the entire page footer.
	SetHeader	Sets the entire page header.
	SetResolution	Sets the current printer resolution on documents and drawing sheets.

[Top](#)

See Also

[IPageSetup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPageSetup Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPageSetup Interface

For a list of all members of this type, see [IPageSetup members](#).

Public Properties

Name	Description
 CenterFooter	Gets or sets the page footer in the center of the page.
 CenterHeader	Gets or sets the page header in the center of the page.
 DrawingColor	Sets the color of the drawing for printing.
 FooterTextFormat	Gets or sets the text format for the page footer.
 HeaderTextFormat	Gets or sets the text format for the page header.
 HighQuality	Gets or sets whether to print a drawing in high quality.
 LeftFooter	Gets or sets the page footer on the left side of the page.
 LeftHeader	Gets or sets the page header on the left side of the page.
 Orientation	Gets or sets the page orientation.
 PrinterPaperLength	Gets or sets the user-defined printer paper length for this document or sheet.
 PrinterPaperSize	Gets or sets the printer paper size for this document or sheet.
 PrinterPaperSource	Gets or sets the printer paper source for this document or sheet.
 PrinterPaperWidth	Gets or sets the user-defined printer paper width for this document or sheet.
 RightFooter	Gets or sets the page footer on the right side of the page.
 RightHeader	Gets or sets the page header on the right side of the page.
 Scale2	Gets or sets the scale for printing the page.
 ScaleDraftEdges	Gets or sets whether to scale draft edges when printing a drawing in high quality.
 ScaleToFit	Enables or disables scaling the page to fit the printer.
 UsePageSetupOnSheets	Obsolete. Superseded by IModelDocExtension::UsePageSetup .

[Top](#)

See Also

[IPageSetup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenterFooter Property (IPageSetup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : CenterFooter Property (IPageSetup)

Gets or sets the page footer in the center of the page.

.NET Syntax

Visual Basic (Declaration)

Property CenterFooter As System.String

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.String

instance.CenterFooter = value

value = instance.CenterFooter
```

C#

```
System.string CenterFooter {get; set;}
```

C++/CLI

```
property System.String^ CenterFooter {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for the footer

Visual Basic for Applications (VBA) Syntax

See [PageSetup::CenterFooter](#).

Example

[Print Drawing \(C#\)](#)
[Print Drawing \(VB.NET\)](#)
[Print Drawing \(VBA\)](#)

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenterHeader Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : CenterHeader Property (IPageSetup)

Gets or sets the page header in the center of the page.

.NET Syntax

Visual Basic (Declaration)

Property CenterHeader As System.String

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.String  
  
instance.CenterHeader = value  
  
value = instance.CenterHeader
```

C#

```
System.string CenterHeader {get; set;}
```

C++/CLI

```
property System.String^ CenterHeader {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for header

Visual Basic for Applications (VBA) Syntax

See [PageSetup.CenterHeader](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DrawingColor Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : DrawingColor Property (IPageSetup)

Sets the color of the drawing for printing.

.NET Syntax

Visual Basic (Declaration)

```
Property DrawingColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.Integer  
  
instance.DrawingColor = value
```

```
value = instance.DrawingColor
```

C#

```
System.int DrawingColor {get; set;}
```

C++/CLI

```
property System.int DrawingColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Color of drawing for printing as defined in [swPageSetupDrawingColor_e](#)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::DrawingColor](#).

Remarks

This method can only be set with an application-level ([IModelDocExtension::AppPageSetup](#)) or document-level ([IModelDoc2::PageSetup](#) or [IModelDoc2::IPageSetup](#)) object. This method is not available at the sheet level.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2008 SP4, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FooterTextFormat Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : FooterTextFormat Property (IPageSetup)

Gets or sets the text format for the page footer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FooterTextFormat As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As TextFormat
```

```
value = instance.FooterTextFormat
```

C#

```
TextFormat FooterTextFormat {get;}
```

C++/CLI

```
property TextFormat^ FooterTextFormat {  
    TextFormat^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Text format](#) for footer

Visual Basic for Applications (VBA) Syntax

See [PageSetup::FooterTextFormat](#).

Remarks

The following line of code changes the font of the footer text to Arial:

```
PageSetup.FooterTextFormat.TypeFaceName = "Arial"
```

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHeaderFooterString Method (IPageSetup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : GetHeaderFooterString Method (IPageSetup)

Gets the specified standard string that can be used in headers and footers.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeaderFooterString( _  
    ByVal WhichOne As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim WhichOne As System.Integer  
Dim value As System.String  
  
value = instance.GetHeaderFooterString(WhichOne)
```

C#

```
System.string GetHeaderFooterString(  
    System.int WhichOne  
)
```

C++/CLI

```
System.String^ GetHeaderFooterString(  
&    System.int WhichOne  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

Type of string as defined in [swStandardHeaderFooterPageSetupTexts_e](#)

Return Value

Standard header or footer text

 Visual Basic for Applications (VBA) Syntax

See [PageSetup::GetHeaderFooterString](#).

 Example

[Print Drawing \(C#\)](#)
[Print Drawing \(VB.NET\)](#)
[Print Drawing \(VBA\)](#)

 See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetResolution Method (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : GetResolution Method (IPageSetup)

Gets the current printer resolution on documents and drawing sheets.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetResolution() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.Integer  
  
value = instance.GetResolution()
```

C#

```
System.int GetResolution()
```

C++/CLI

```
System.int GetResolution();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current printer resolution

 Visual Basic for Applications (VBA) Syntax

See [PageSetup::GetResolution](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetUseDefaultResolution Method](#)
[IPageSetup::SetResolution Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDefaultResolution Method (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : GetUseDefaultResolution Method (IPageSetup)

Gets whether the printer default resolution is in use on documents and drawing sheets.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDefaultResolution() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.Boolean  
  
value = instance.GetUseDefaultResolution()
```

C#

```
System.bool GetUseDefaultResolution()
```

C++/CLI

```
System.bool GetUseDefaultResolution();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if printer default resolution is in use, false if not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::GetUseDefaultResolution](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetResolution Method](#)
[IPageSetup::SetResolution Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HeaderTextFormat Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : HeaderTextFormat Property (IPageSetup)

Gets or sets the text format for the page header.

.NET Syntax

ReadOnly Property HeaderTextFormat As TextFormat



```
Dim instance As IPageSetup
Dim value As TextFormat

value = instance.HeaderTextFormat
```

```
TextFormat HeaderTextFormat {get;}
```

```
property TextFormat^ HeaderTextFormat {
    TextFormat^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Text format](#) for header

Visual Basic for Applications (VBA) Syntax

See [PageSetup.HeaderTextFormat](#).

Remarks

The following line of code to change the font of the header text to Arial:

```
PageSetup.HeaderTextFormat.TypeFaceName = "Arial"
```

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

HighQuality Property (IPageSetup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : HighQuality Property (IPageSetup)

Gets or sets whether to print a drawing in high quality.

.NET Syntax

Property HighQuality As System.Boolean



```
Dim instance As IPageSetup
Dim value As System.Boolean

instance.HighQuality = value

value = instance.HighQuality
```

C#

```
System.bool HighQuality {get; set;}
```

C++/CLI

```
property System.bool HighQuality {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to print a drawing in high quality, false to not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::HighQuality](#).

Example

[Get Whether Draft Edges Scaled in Printed Drawing \(C#\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VB.NET\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VBA\)](#)

Remarks

You can [scale draft edges](#) in a printed drawing when this property is set to true.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeftFooter Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : LeftFooter Property (IPageSetup)

Gets or sets the page footer on the left side of the page.

.NET Syntax

Visual Basic (Declaration)

```
Property LeftFooter As System.String
```

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.String

instance.LeftFooter = value
```

```
value = instance.LeftFooter
```

C#

```
System.string LeftFooter {get; set;}
```

C++/CLI

```
property System.String^ LeftFooter {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for footer

Visual Basic for Applications (VBA) Syntax

See [PageSetup::LeftFooter](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LeftHeader Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : LeftHeader Property (IPageSetup)

Gets or sets the page header on the left side of the page.

.NET Syntax

Visual Basic (Declaration)

```
Property LeftHeader As System.String
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.String  
  
instance.LeftHeader = value  
  
value = instance.LeftHeader
```

C#

```
System.string LeftHeader {get; set;}
```

C++/CLI

```
property System.String^ LeftHeader {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for header

Visual Basic for Applications (VBA) Syntax

See [PageSetup::LeftHeader](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Orientation Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : Orientation Property (IPageSetup)

Gets or sets the page orientation.

.NET Syntax

Visual Basic (Declaration)

Property Orientation As System.Integer

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.Integer  
  
instance.Orientation = value  
  
value = instance.Orientation
```

C#

```
System.int Orientation {get; set;}
```

C++/CLI

```
property System.int Orientation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Page orientation as defined in [swPageSetupOrientation_e](#)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::Orientation](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PrinterPaperLength Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : PrinterPaperLength Property (IPageSetup)

Gets or sets the user-defined printer paper length for this document or sheet.

.NET Syntax

Visual Basic (Declaration)

Property PrinterPaperLength As System.Integer

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Integer

instance.PrinterPaperLength = value

value = instance.PrinterPaperLength
```

C#

```
System.int PrinterPaperLength {get; set;}
```

C++/CLI

```
property System.int PrinterPaperLength {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Paper length (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::PrinterPaperLength](#).

Remarks

Use [IPageSetup::PrinterPaperSize](#) to set the printer's paper size. A possible value for IPageSetup::PrinterPaperSize is to have a user-defined paper size. In that case, this property indicates the length of that user-defined paper.

Length is in 0.1mm units. To define a paper that is 250mm long, set Length to 2500.

To get or set the printer paper width, use [IPageSetup::PrinterPaperWidth](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::PrinterPaperSource Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrinterPaperSize Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : PrinterPaperSize Property (IPageSetup)

Gets or sets the printer paper size for this document or sheet.

Visual Basic Syntax

Visual Basic (Declaration)

Property PrinterPaperSize As System.Integer

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Integer

instance.PrinterPaperSize = value
value = instance.PrinterPaperSize
```

C#

```
System.int PrinterPaperSize {get; set;}
```

C++/CLI

```
property System.int PrinterPaperSize {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Paper size (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::PrinterPaperSize](#).

Remarks

This property is one of a set of standard constants defined by the operating system or by a specific printer device; there is no SOLIDWORKS enumeration for these values. See your operating system's and programming language's Help for the details on printers and paper sizes.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::PrinterPaperLength Property](#)
[IPageSetup::PrinterPaperSource Property](#)
[IPageSetup::PrinterPaperWidth Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrinterPaperSource Property (IPageSetup)

[See Also](#)



Gets or sets the printer paper source for this document or sheet.

.NET Syntax

Visual Basic (Declaration)

Property PrinterPaperSource As System.Integer

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Integer

instance.PrinterPaperSource = value

value = instance.PrinterPaperSource
```

C#

```
System.int PrinterPaperSource {get; set;}
```

C++/CLI

```
property System.int PrinterPaperSource {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Printer paper source (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::PrinterPaperSource](#).

Remarks

The property value is one of a set of standard constants defined by the operating system or by a specific printer device; there is no SOLIDWORKS enumeration for these values. See your operating system's and programming language's Help for the details on printers and paper sizes.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::PrinterPaperLength Property](#)
[IPageSetup::PrinterPaperSize Property](#)
[IPageSetup::PrinterPaperWidth Property](#)

Availability

SolidWorks 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrinterPaperWidth Property (IPageSetup)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IPageSetup Interface : PrinterPaperWidth Property (IPageSetup)

Gets or sets the user-defined printer paper width for this document or sheet.

.NET Syntax

Visual Basic (Declaration)

Property PrinterPaperWidth As System.Integer

```
Dim instance As IPageSetup
Dim value As System.Integer

instance.PrinterPaperWidth = value

value = instance.PrinterPaperWidth
```

C#

```
System.int PrinterPaperWidth {get; set;}
```

C++/CLI

```
property System.int PrinterPaperWidth {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Paper width (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PageSetup::PrinterPaperWidth](#).

Remarks

Use [IPageSetup::PrinterPaperSize](#) to set the printer paper size. A value for [IPageSetup::PrinterPaperSize](#) is a user-defined paper size. In that case, this property indicates the width of that user-defined paper.

Width is in 0.1mm units. To define a paper that is 200mm wide, Width is 2000.

To get or set the printer paper length, use [IPageSetup::PrinterPaperLength](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::PrinterPaperSource Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

RightFooter Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : RightFooter Property (IPageSetup)

Gets or sets the page footer on the right side of the page.

.NET Syntax

Visual Basic (Declaration)

```
Property RightFooter As System.String
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPageSetup
Dim value As System.String

instance.RightFooter = value
```

```
value = instance.RightFooter
```

C#

```
System.string RightFooter {get; set;}
```

C++/CLI

```
property System.String^ RightFooter {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for footer

Visual Basic for Applications (VBA) Syntax

See [PageSetup::RightFooter](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RightHeader Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : RightHeader Property (IPageSetup)

Gets or sets the page header on the right side of the page.

.NET Syntax

Visual Basic (Declaration)

```
Property RightHeader As System.String
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.String  
  
instance.RightHeader = value  
  
value = instance.RightHeader
```

C#

```
System.string RightHeader {get; set;}
```

C++/CLI

```
property System.String^ RightHeader {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for header

Visual Basic for Applications (VBA) Syntax

See [PageSetup::RightHeader](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightFooter Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale2 Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : Scale2 Property (IPageSetup)

Gets or sets the scale for printing the page.

.NET Syntax

Visual Basic (Declaration)

```
Property Scale2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Double
```

```
instance.Scale2 = value
```

```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Print scale factor from 1% to 1000%

Visual Basic for Applications (VBA) Syntax

See [PageSetup::Scale2](#).

Remarks

This value is only used when [IPageSetup::ScaleToFit](#) is set to false.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ScaleDraftEdges Property (IPageSetup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : ScaleDraftEdges Property (IPageSetup)

Gets or sets whether to scale draft edges when printing a drawing in high quality.

.NET Syntax

Visual Basic (Declaration)

Property ScaleDraftEdges As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Boolean

instance.ScaleDraftEdges = value

value = instance.ScaleDraftEdges
```

C#

```
System.bool ScaleDraftEdges {get; set;}
```

C++/CLI

```
property System.bool ScaleDraftEdges {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to scale draft edges when printing a drawing in high quality, false to not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::ScaleDraftEdges](#).

Example

[Get Whether Draft Edges Scaled in Printed Drawing \(C#\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VB.NET\)](#)
[Get Whether Draft Edges Scaled in Printed Drawing \(VBA\)](#)

Remarks

This property is only valid when [IPageSetup::HighQuality](#) is set to true.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleToFit Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : ScaleToFit Property (IPageSetup)

Enables or disables scaling the page to fit the printer.

.NET Syntax

Visual Basic (Declaration)

Property ScaleToFit As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim value As System.Boolean  
  
instance.ScaleToFit = value  
  
value = instance.ScaleToFit
```

C#

```
System.bool ScaleToFit {get; set;}
```

C++/CLI

```
property System.bool ScaleToFit {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to scale page to fit the printer, false to not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::ScaleToFit](#).

Remarks

If this property is false, then you can use [IPageSetup::Scale2](#) to set the scaling factor.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFooter Method (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : SetFooter Method (IPageSetup)

Sets the entire page footer.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFooter( _  
    ByVal Left As System.String, _  
    ByVal Center As System.String, _  
    ByVal Right As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim Left As System.String  
Dim Center As System.String  
Dim Right As System.String  
Dim value As System.Boolean  
  
value = instance.SetFooter(Left, Center, Right)
```

C#

```
System.bool SetFooter(  
    System.string Left,  
    System.string Center,  
    System.string Right  
)
```

C++/CLI

```
System.bool SetFooter(  
& System.String^ Left,  
& System.String^ Center,  
& System.String^ Right  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Left

Left-footer text

Center

Center-footer text

Right

Right-footer text

Return Value

True if the footer is successfully changed, false if not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::SetFooter](#).

Remarks

This method is equivalent to setting [IPageSetup::LeftFooter](#), [IPageSetup::CenterFooter](#), and [IPageSetup::RightFooter](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)

[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetHeader Method](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::CenterHeader Property](#)
[IPageSetup::LeftHeader Property](#)
[IPageSetup::RightHeader Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetHeader Method (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : SetHeader Method (IPageSetup)

Sets the entire page header.

.NET Syntax

Visual Basic (Declaration)

```
Function SetHeader( _  
    ByVal Left As System.String, _  
    ByVal Center As System.String, _  
    ByVal Right As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim Left As System.String  
Dim Center As System.String  
Dim Right As System.String  
Dim value As System.Boolean  
  
value = instance.SetHeader(Left, Center, Right)
```

C#

```
System.bool SetHeader(  
    System.string Left,  
    System.string Center,  
    System.string Right  
)
```

C++/CLI

```
System.bool SetHeader(  
& System.String^ Left,  
& System.String^ Center,  
& System.String^ Right  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Left

Left-header text

Center

Center-header text

Right

Right-header text

Return Value

True if the header is successfully changed, false if not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::SetHeader](#).

Remarks

This method is equivalent to setting [IPageSetup::LeftHeader](#), [IPageSetup::CenterHeader](#), and [IPageSetup::RightHeader](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetHeaderFooterString Method](#)
[IPageSetup::SetFooter Method](#)
[IPageSetup::CenterFooter Property](#)
[IPageSetup::FooterTextFormat Property](#)
[IPageSetup::HeaderTextFormat Property](#)
[IPageSetup::LeftFooter Property](#)
[IPageSetup::RightFooter Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetResolution Method (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : SetResolution Method (IPageSetup)

Sets the current printer resolution on documents and drawing sheets.

.NET Syntax

Visual Basic (Declaration)

```
Function SetResolution( _  
    ByVal UseDefault As System.Boolean, _  
    ByVal DPI As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPageSetup  
Dim UseDefault As System.Boolean  
Dim DPI As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetResolution(UseDefault, DPI)
```

C#

```
System.bool SetResolution(  
    System.bool UseDefault,  
    System.int DPI  
)
```

C++/CLI

```
System.bool SetResolution(  
& System.bool UseDefault,  
& System.int DPI  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDefault

True to use the default printer resolution, false to set the printer resolution

DPI

Dots per inch

Return Value

True if printer resolution is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PageSetup::SetResolution](#).

Remarks

Specifying IPageSetup::SetResolution (false, 0) turns on the default resolution, which results in [IPageSetup::GetUseDefaultResolution](#) returning True.

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)
[IPageSetup::GetResolution Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UsePageSetupOnSheets Property (IPageSetup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPageSetup Interface](#) : UsePageSetupOnSheets Property (IPageSetup)

Obsolete. Superseded by [IModelDocExtension::UsePageSetup](#).

.NET Syntax

Visual Basic (Declaration)

Property UsePageSetupOnSheets As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPageSetup
Dim value As System.Boolean

instance.UsePageSetupOnSheets = value

value = instance.UsePageSetupOnSheets
```

C#

```
System.bool UsePageSetupOnSheets {get; set;}
```

C++/CLI

```
property System.bool UsePageSetupOnSheets {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PageSetup::UsePageSetupOnSheets](#).

See Also

[IPageSetup Interface](#)
[IPageSetup Members](#)