

SOLIDWORKS API (.NET VBA C#) — Reference

(217/337): IParagraphs-IParameter

SOLIDWORKS API Documentation (converted from CHM)

IParagraphs (Type)

IParagraphs Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParagraphs Interface

Allows access to paragraphs in note annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IParagraphs
```

Visual Basic (Usage)



```
Dim instance As IParagraphs
```

C#

```
public interface IParagraphs
```

C++/CLI

```
public interface class IParagraphs
```

Visual Basic for Applications (VBA) Syntax

See [Paragraphs](#).

Example

[Get and Set Paragraph Properties \(VBA\)](#)
[Get and Set Paragraph Properties \(VB.NET\)](#)
[Get and Set Paragraph Properties \(C#\)](#)

Accessors

[IAnnotation::GetParagraphs](#)

Access Diagram

[Paragraphs](#)

See Also

[IParagraphs Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IParagraphs Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParagraphs Interface

For a list of all members of this type, see [IParagraphs members](#).

Public Methods

Name	Description
 GetBulletsAndNumbering	Gets the list properties of the current paragraph.
 GetFormatting	Gets the formatting of the current paragraph.
GetIndentation	Gets the indentation of the current paragraph.

		
	GetText	Gets the text of the current paragraph.
	GetTextSegmentCount	Gets the number of text segments in the current paragraph.
	GetTextSegmentFormat	Gets the text format for the specified text segment in the current paragraph.
	GetTextSegmentText	Gets the text of the specified text segment in the current paragraph.
	SetBulletsAndNumbering	Sets the list properties of the current paragraph.
	SetFormatting	Sets the formatting of the current paragraph.
	SetIndentation	Sets the indentation of the current paragraph.
	SetTextSegmentFormat	Sets the text format for the specified text segment in the current paragraph.
	UpdateParagraph	Updates the model with the changes made to the current paragraph.

[Top](#)

See Also

[IParagraphs Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IParagraphs Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParagraphs Interface

The following tables list the members exposed by [IParagraphs](#).

Public Properties

Name	Description
 Count	Gets the number of paragraphs in the annotation.
 CurrentParagraph	Gets or sets the current paragraph.

[Top](#)

Public Methods

Name	Description
 GetBulletsAndNumbering	Gets the list properties of the current paragraph.
 GetFormatting	Gets the formatting of the current paragraph.
 GetIndentation	Gets the indentation of the current paragraph.
 GetText	Gets the text of the current paragraph.
 GetTextSegmentCount	Gets the number of text segments in the current paragraph.
 GetTextSegmentFormat	Gets the text format for the specified text segment in the current paragraph.
 GetTextSegmentText	Gets the text of the specified text segment in the current paragraph.
 SetBulletsAndNumbering	Sets the list properties of the current paragraph.
 SetFormatting	Sets the formatting of the current paragraph.
 SetIndentation	Sets the indentation of the current paragraph.
 SetTextSegmentFormat	Sets the text format for the specified text segment in the current paragraph.
 UpdateParagraph	Updates the model with the changes made to the current paragraph.

[Top](#)

See Also

[IParagraphs Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IParagraphs Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IParagraphs Interface

For a list of all members of this type, see [IParagraphs members](#).

Public Properties

Name	Description
 Count	Gets the number of paragraphs in the annotation.
 CurrentParagraph	Gets or sets the current paragraph.

[Top](#)

See Also

[IParagraphs Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Count Property (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : Count Property (IParagraphs)

Gets the number of paragraphs in the annotation.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Count As System.Integer

Visual Basic (Usage)



```
Dim instance As IParagraphs
Dim value As System.Integer

value = instance.Count
```

C#

```
System.int Count {get;}
```

C++/CLI

```
property System.int Count {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of paragraphs in the annotation

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::Count](#).

Example

See the [IParagraphs](#) examples.

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurrentParagraph Property (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : CurrentParagraph Property (IParagraphs)

Gets or sets the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Property CurrentParagraph As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim value As System.Integer  
  
instance.CurrentParagraph = value  
  
value = instance.CurrentParagraph
```

C#

```
System.int CurrentParagraph {get; set;}
```

C++/CLI

```
property System.int CurrentParagraph {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0-based index of current paragraph

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::CurrentParagraph](#).

Example

See the [IParagraphs](#) examples.

Remarks

Before calling any of the methods of [IParagraphs](#), you must call this method to set the current paragraph.

Use [IParagraphs::Count](#) to determine the index with which to set this property.

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

GetBulletsAndNumbering Method (IParagraphs)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetBulletsAndNumbering Method (IParagraphs)

Gets the list properties of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBulletsAndNumbering( _
    ByRef ParagraphType As System.Integer, _
    ByRef NumberingType As System.Integer, _
    ByRef StartAt As System.Integer, _
    ByRef Type As System.Integer, _
    ByRef Format As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs
Dim ParagraphType As System.Integer
Dim NumberingType As System.Integer
Dim StartAt As System.Integer
Dim Type As System.Integer
Dim Format As System.Integer
Dim value As System.Boolean

value = instance.GetBulletsAndNumbering(ParagraphType, NumberingType, StartAt, Type, Format)
```

C#

```
System.bool GetBulletsAndNumbering(
    out System.int ParagraphType,
    out System.int NumberingType,
    out System.int StartAt,
    out System.int Type,
    out System.int Format
)
```

C++/CLI

```
System.bool GetBulletsAndNumbering(
    & [Out] System.int ParagraphType,
    & [Out] System.int NumberingType,
    & [Out] System.int StartAt,
    & [Out] System.int Type,
    & [Out] System.int Format
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*ParagraphType*List type as defined in [swParagraphType_e](#)*NumberingType*Numbering direction as defined in [swNumberedListStartType_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered*StartAt*

Letter or number starting this numbered list, depending on Type; valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

*Type*Numbered list type as defined in [swNumberedListType_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered*Format*Numbered list format as defined in [swNumberingFormat_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetBulletsAndNumbering](#).

Example

See the [IParagraphs](#) examples.

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::SetBulletsAndNumbering Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFormatting Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetFormatting Method (IParagraphs)

Gets the formatting of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFormatting( _  
    ByRef Paragraphspacing As System.Double, _  
    ByRef LineSpacing As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim Paragraphspacing As System.Double  
Dim LineSpacing As System.Double  
Dim value As System.Boolean  
  
value = instance.GetFormatting(Paragraphspacing, LineSpacing)
```

C#

```
System.bool GetFormatting(  
    out System.double Paragraphspacing,  
    out System.double LineSpacing  
)
```

C++/CLI

```
System.bool GetFormatting(  
& [Out] System.double Paragraphspacing,  
& [Out] System.double LineSpacing  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Paragraphspacing
Paragraph spacing
LineSpacing
Line spacing

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetFormatting](#).

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::SetFormatting Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetIndentation Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetIndentation Method (IParagraphs)

Gets the indentation of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIndentation(  
    ByRef FirstlineIndent As System.Double, _  
    ByRef Indent As System.Double, _  
    ByRef IndentIncrement As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim FirstlineIndent As System.Double  
Dim Indent As System.Double  
Dim IndentIncrement As System.Double  
Dim value As System.Boolean  
  
value = instance.GetIndentation(FirstlineIndent, Indent, IndentIncrement)
```

C#

```
System.bool GetIndentation(  
    out System.double FirstlineIndent,  
    out System.double Indent,  
    out System.double IndentIncrement  
)
```

C++/CLI

```
System.bool GetIndentation(  
& [Out] System.double FirstlineIndent,  
& [Out] System.double Indent,  
& [Out] System.double IndentIncrement  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstlineIndent
Indentation of first line
Indent
Indentation of lines other than the first line
IndentIncrement

Amount by which to increment the current indents

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetIndentation](#).

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::SetIndentation Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetText Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetText Method (IParagraphs)

Gets the text of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText( _  
    ByVal ShowWordWrap As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim ShowWordWrap As System.Boolean  
Dim value As System.String  
  
value = instance.GetText(ShowWordWrap)
```

C#

```
System.string GetText(  
    System.bool ShowWordWrap  
)
```

C++/CLI

```
System.String^ GetText(  
&    System.bool ShowWordWrap  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowWordWrap
True to show word wrap, false to not

Return Value

Text of the current paragraph

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetText](#).

Example

See the [IParagraphs](#) examples.

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextSegmentCount Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetTextSegmentCount Method (IParagraphs)

Gets the number of text segments in the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextSegmentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim value As System.Integer  
  
value = instance.GetTextSegmentCount()
```

C#

```
System.int GetTextSegmentCount()
```

C++/CLI

```
System.int GetTextSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text segments

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetTextSegmentCount](#).

Example

See the [IParagraphs](#) examples.

Remarks

Paragraphs contain one or more text segments. Each text segment has a different format.
Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::GetTextSegmentFormat Method \(\)](#)
[IParagraphs::GetTextSegmentText Method \(\)](#)
[IParagraphs::SetTextSegmentFormat Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextSegmentFormat Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetTextSegmentFormat Method (IParagraphs)

Gets the text format for the specified text segment in the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextSegmentFormat( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IParagraphs  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextSegmentFormat(Index)
```

C#

```
System.object GetTextSegmentFormat(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextSegmentFormat(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based index of text segment whose text format to get

Return Value

[ITextFormat](#)

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetTextSegmentFormat](#).

Example

See the [IParagraphs](#) examples.

Remarks

Paragraphs contain one or more text segments. Each text segment has a different format.

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

To populate Index, call [IParagraphs::GetTextSegmentCount](#).

See Also

[IParagraphs Interface](#)

[IParagraphs Members](#)

[IParagraphs::GetTextSegmentText Method \(\)](#)

[IParagraphs::SetTextSegmentFormat Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextSegmentText Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : GetTextSegmentText Method (IParagraphs)

Gets the text of the specified text segment in the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextSegmentText( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextSegmentText(Index)
```

C#

```
System.string GetTextSegmentText(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextSegmentText(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of text segment whose text to get

Return Value

Text of text segment

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::GetTextSegmentText](#).

Example

See the [IParagraphs](#) examples.

Remarks

Paragraphs contain one or more text segments. Each text segment has a different format.

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

To populate Index, call [IParagraphs::GetTextSegmentCount](#).

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::GetTextSegmentFormat Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetBulletsAndNumbering Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : SetBulletsAndNumbering Method (IParagraphs)

Sets the list properties of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBulletsAndNumbering( _  
    ByVal ParagraphType As System.Integer, _  
    ByVal NumberingType As System.Integer, _  
    ByVal StartAt As System.Integer, _  
    ByVal Type As System.Integer, _  
    ByVal Format As System.Integer _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim ParagraphType As System.Integer  
Dim NumberingType As System.Integer  
Dim StartAt As System.Integer  
Dim Type As System.Integer  
Dim Format As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetBulletsAndNumbering(ParagraphType, NumberingType, StartAt, Type, Format)
```

C#

```
System.bool SetBulletsAndNumbering(  
    System.int ParagraphType,  
    System.int NumberingType,  
    System.int StartAt,  
    System.int Type,  
    System.int Format  
)
```

C++/CLI

```
System.bool SetBulletsAndNumbering(  
& System.int ParagraphType,
```

```

& System.int NumberingType,
& System.int StartAt,
& System.int Type,
& System.int Format
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParagraphType

List type as defined in [swParagraphType_e](#)

NumberingType

Numbering direction as defined in [swNumberedListStartType_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

StartAt

Letter or number starting this numbered list, depending on Type; valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

Type

Numbered list type as defined in [swNumberedListType_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

Format

Numbered list format as defined in [swNumberingFormat_e](#); valid only if ParagraphType is swParagraphType_e.swParagraphNumbered

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::SetBulletsAndNumbering](#).

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

After calling this method, call [IParagraphs::UpdateParagraph](#) to update the model.

See Also

[IParagraphs Interface](#)

[IParagraphs Members](#)

[IParagraphs::GetBulletsAndNumbering Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFormatting Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : SetFormatting Method (IParagraphs)

Sets the formatting of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```

Function SetFormatting( _
    ByVal Paragraphspacing As System.Double, _
    ByVal LineSpacing As System.Double _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As IParagraphs
Dim Paragraphspacing As System.Double
Dim LineSpacing As System.Double
Dim value As System.Boolean

```

```
value = instance.SetFormatting(Paragraphspacing, LineSpacing)
```

C#



```
System.bool SetFormatting(
    System.double Paragraphspacing,
    System.double LineSpacing
)
```

C++/CLI

```
System.bool SetFormatting(
    & System.double Paragraphspacing,
    & System.double LineSpacing
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Paragraphspacing
Paragraph spacing
LineSpacing
Line spacing

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::SetFormatting](#).

Example

See the [IParagraphs](#) examples.

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).

After calling this method, call [IParagraphs::UpdateParagraph](#) to update the model.

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::GetFormatting Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetIndentation Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : SetIndentation Method (IParagraphs)

Sets the indentation of the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function SetIndentation( _
    ByVal FirstlineIndent As System.Double, _
    ByVal Indent As System.Double, _
    ByVal IndentIncrement As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IParagraphs
Dim FirstlineIndent As System.Double
Dim Indent As System.Double
Dim IndentIncrement As System.Double
Dim value As System.Boolean

value = instance.SetIndentation(FirstlineIndent, Indent, IndentIncrement)

```

C#

```

System.bool SetIndentation(
    System.double FirstlineIndent,
    System.double Indent,
    System.double IndentIncrement
)

```

C++/CLI

```

System.bool SetIndentation(
    & System.double FirstlineIndent,
    & System.double Indent,
    & System.double IndentIncrement
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstlineIndent
Indentation of first line
Indent
Indentation of lines other than the first line
IndentIncrement
Amount by which to increment the current indents

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::SetIndentation](#).

Remarks

Before calling this method, set the current paragraph using [IParagraphs::CurrentParagraph](#).
After calling this method, call [IParagraphs::UpdateParagraph](#) to update the model.

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::GetIndentation Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextSegmentFormat Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : SetTextSegmentFormat Method (IParagraphs)

Sets the text format for the specified text segment in the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextSegmentFormat( _  
    ByVal Segment As System.Integer, _  
    ByVal Format As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim Segment As System.Integer  
Dim Format As System.Object  
Dim value As System.Boolean  
  
value = instance.SetTextSegmentFormat(Segment, Format)
```

C#

```
System.bool SetTextSegmentFormat(  
    System.int Segment,  
    System.object Format  
)
```

C++/CLI

```
System.bool SetTextSegmentFormat(  
& System.int Segment,  
& System.Object^ Format  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Segment
0-based index of the text segment whose format to set
Format
[ITextFormat](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::SetTextSegmentFormat](#).

Example

See the [IParagraphs](#) examples.

Remarks

Paragraphs contain one or more text segments. Each text segment has a different format.

Before calling this method:

- set the current paragraph using [IParagraphs::CurrentParagraph](#).
- call [IParagraphs::GetTextSegmentCount](#) to get the total number of text segments and a valid value for Segment.

After calling this method, call [IParagraphs::UpdateParagraph](#) to update the model.

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)
[IParagraphs::GetTextSegmentFormat Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

UpdateParagraph Method (IParagraphs)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParagraphs Interface](#) : UpdateParagraph Method (IParagraphs)

Updates the model with the changes made to the current paragraph.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateParagraph() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParagraphs  
Dim value As System.Boolean  
  
value = instance.UpdateParagraph()
```

C#

```
System.bool UpdateParagraph()
```

C++/CLI

```
System.bool UpdateParagraph();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the model is updated with the paragraph changes, false if not

Visual Basic for Applications (VBA) Syntax

See [Paragraphs::UpdateParagraph](#).

Example

See the [IParagraphs](#) examples.

Remarks

You must call this method to update the model after calling:

- [IParagraphs::SetBulletsAndNumbering](#)
- [IParagraphs::SetFormatting](#)
- [IParagraphs::SetIndentation](#)
- [IParagraphs::SetTextSegmentFormat](#)

See Also

[IParagraphs Interface](#)
[IParagraphs Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

IParallelMateFeatureData (Type)

IParallelMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParallelMateFeatureData Interface

Allows access to a parallel mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IParallelMateFeatureData

Visual Basic (Usage)

Dim instance As [IParallelMateFeatureData](#)

C#

public interface IParallelMateFeatureData

C++/CLI

public interface class IParallelMateFeatureData

Visual Basic for Applications (VBA) Syntax

See [ParallelMateFeatureData](#).

Example

[Create Standard Mates \(VBA\)](#)
[Create Standard Mates \(C#\)](#)

Remarks

A parallel mate places selected items a constant distance apart.

[IMateFeatureData](#) is the parent of this mate interface.

To create a parallel mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IParallelMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1.
3. Specify other properties of the ParallelMateFeatureData object.

To edit a parallel mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a ParallelMateFeatureData object.
3. Modify the ParallelMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this parallel mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[ParallelMateFeatureData](#)

See Also

[IParallelMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IParallelMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParallelMateFeatureData Interface

The following tables list the members exposed by [IParallelMateFeatureData](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this parallel mate.
 MateAlignment	Gets or sets the alignment of this angle mate.
 PickPoints	Gets or sets the pick points for the entities to mate in this parallel mate.

[Top](#)

See Also

[IParallelMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IParallelMateFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IParallelMateFeatureData Interface

For a list of all members of this type, see [IParallelMateFeatureData members](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this parallel mate.
 MateAlignment	Gets or sets the alignment of this angle mate.
 PickPoints	Gets or sets the pick points for the entities to mate in this parallel mate.

[Top](#)

See Also

[IParallelMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

EntitiesToMate Property (IParallelMateFeatureData)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IParallelMateFeatureData Interface](#) : EntitiesToMate Property (IParallelMateFeatureData)

Gets or sets the entities to mate in this parallel mate.

.NET Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)

 Copy Code

```
Dim instance As IParallelMateFeatureData
Dim value As System.Object

instance.EntitiesToMate = value

value = instance.EntitiesToMate
```

C#

System.object EntitiesToMate {get; set;}

C++/CLI

```
property System.Object^ EntitiesToMate {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entities to mate (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [ParallelMateFeatureData::EntitiesToMate](#).

 Example

See the [IParallelMateFeatureData](#) example.

 Remarks

You can create parallel mates with the following mate entity combinations:

Mate entity/Mate entity	IRefAxis (cone, cylinder)	IFace2 (extrusion face, draft is not allowed)	IEdge , IRefAxis , ICenterLine , ISketchLine (line)	IRefPlane	ISurface , IFace2 (non-analytic surface)
IRefAxis (cone, cylinder)	•	•	•		•
IFace2 (extrusion face, draft is not allowed)	•	•	•		
IEdge , IRefAxis , ICenterLine , ISketchLine (line)	•	•	•	•	•
IRefPlane			•	•	
ISurface, IFace2 (non-analytic surface)	•		•		

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1. You can pre-select mate entities during mate creation, but not during mate editing.

 See Also

[IParallelMateFeatureData Interface](#)
[IParallelMateFeatureData Members](#)

 Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

MateAlignment Property (IParallelMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParallelMateFeatureData Interface](#) : MateAlignment Property (IParallelMateFeatureData)

Gets or sets the alignment of this angle mate.

 .NET Syntax

Visual Basic (Declaration)

Property MateAlignment As System.Integer

Visual Basic (Usage)



```
Dim instance As IParallelMateFeatureData
Dim value As System.Integer

instance.MateAlignment = value

value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [ParallelMateFeatureData::MateAlignment](#).

Example

See the [IParallelMateFeatureData](#) example.

See Also

[IParallelMateFeatureData Interface](#)
[IParallelMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PickPoints Property (IParallelMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParallelMateFeatureData Interface](#) : PickPoints Property (IParallelMateFeatureData)

Gets or sets the pick points for the entities to mate in this parallel mate.

.NET Syntax

Visual Basic (Declaration)

```
Property PickPoints As System.Object
```

Visual Basic (Usage)



```
Dim instance As IParallelMateFeatureData
Dim value As System.Object

instance.PickPoints = value

value = instance.PickPoints
```

C#

```
System.object PickPoints {get; set;}
```

C++/CLI

```
property System.Object^ PickPoints {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of x, y, z-coordinates, one set for each mate entity

Visual Basic for Applications (VBA) Syntax

See [ParallelMateFeatureData::PickPoints](#).

Remarks

After you set the pick points for a given selection of [IParallelMateFeatureData::EntitiesToMate](#), you cannot modify the pick points. If you want to use new pick points, then you must create an entirely new parallel mate.

See Also

[IParallelMateFeatureData Interface](#)
[IParallelMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IParameter (Type)

IParameter Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParameter Interface

Allows you to get and set values in an attribute.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IParameter
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As IParameter
```

C#

```
public interface IParameter
```

C++/CLI

```
public interface class IParameter
```

Visual Basic for Applications (VBA) Syntax

See [Parameter](#).

Example

[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)

Accessors

[IAttribute::GetParameter](#) and [IAttribute::IGetParameter](#)

Access Diagram

[Parameter](#)

See Also

[IParameter Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IParameter Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IParameter Interface

The following tables list the members exposed by [IParameter](#).

Public Methods

Name	Description
GetDoubleValue	Gets an attribute value of type double.
GetName	Gets the name of this parameter.

 GetStringValue	Gets an attribute value of type string.
 GetType	Gets the type of data stored on the parameter.
 GetVector	Extracts information of type vector from a parameter.
 GetVectorVB	Extracts information of type vector from a parameter.
 SetDoubleValue	Obsolete. Superseded by IPParameter.SetDoubleValue2 .
 SetDoubleValue2	Sets the double or integer value of a named configuration option parameter.
 SetStringValue	Obsolete. Superseded by IPParameter.SetStringValue2 .
 SetStringValue2	Sets the double or integer value of a named configuration option parameter.
 SetVector	Obsolete. Superseded by IPParameter.SetVector2 .
 SetVector2	Sets the vector values of a named configuration option parameter.

[Top](#)

 See Also

[IPParameter Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPParameter Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPParameter Interface

For a list of all members of this type, see [IPParameter members](#).

 Public Methods

Name	Description
 GetDoubleValue	Gets an attribute value of type double.
 GetName	Gets the name of this parameter.
 GetStringValue	Gets an attribute value of type string.
 GetType	Gets the type of data stored on the parameter.
 GetVector	Extracts information of type vector from a parameter.
 GetVectorVB	Extracts information of type vector from a parameter.
 SetDoubleValue	Obsolete. Superseded by IPParameter.SetDoubleValue2 .
 SetDoubleValue2	Sets the double or integer value of a named configuration option parameter.
 SetStringValue	Obsolete. Superseded by IPParameter.SetStringValue2 .
 SetStringValue2	Sets the double or integer value of a named configuration option parameter.
 SetVector	Obsolete. Superseded by IPParameter.SetVector2 .
 SetVector2	Sets the vector values of a named configuration option parameter.

[Top](#)

 See Also

[IPParameter Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDoubleValue Method (IPParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPParameter Interface](#) : GetDoubleValue Method (IPParameter)

Gets an attribute value of type double.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDoubleValue() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IParameter  
Dim value As System.Double  
  
value = instance.GetDoubleValue()
```

C#

```
System.double GetDoubleValue()
```

C++/CLI

```
System.double GetDoubleValue();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Attribute value of type double

Visual Basic for Applications (VBA) Syntax

See [Parameter::GetDoubleValue](#).

Example

[Find Attribute \(C#\)](#)
[Find Attribute \(VB.NET\)](#)
[Find Attribute \(VBA\)](#)

Remarks

Value of the parameter in system units

See Also

[IParameter Interface](#)
[IParameter Members](#)
[IParameter::SetDoubleValue2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetName Method (IParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : GetName Method (IParameter)

Gets the name of this parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IParameter  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Parameter::GetName](#).

Example

[Get Info on Plane-Axis \(C++\)](#)
[Get Sketches \(C++\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)

Remarks

Name of the parameter

See Also

[IParameter Interface](#)
[IParameter Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStringValue Method (IParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : GetStringValue Method (IParameter)

Gets an attribute value of type string.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStringValue() As System.String
```

Visual Basic (Usage)



```
Dim instance As IParameter  
Dim value As System.String  
  
value = instance.GetStringValue()
```

C#

```
System.string GetStringValue()
```

C++/CLI

```
System.String^ GetStringValue();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Parameter::GetStringValue](#).

Example

[Find Attribute \(C#\)](#)
[Find Attribute \(VB.NET\)](#)
[Find Attribute \(VBA\)](#)

Remarks

Value of the parameter

See Also

[IParameter Interface](#)
[IParameter Members](#)
[IParameter::SetStringValue2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (IParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : GetType Method (IParameter)

Gets the type of data stored on the parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IParameter  
Dim value As System.Integer  
  
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of data stored on the parameter as defined in [swParam_Type_e](#)

Visual Basic for Applications (VBA) Syntax

See [Parameter::GetType](#).

Example

[Enumerate Bodies \(C++\)](#)
[Get Document Information \(VBA\)](#)
[Create Note \(VBA\)](#)

See Also

[IParameter Interface](#)
[IParameter Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVector Method (IParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : GetVector Method (IParameter)

Extracts information of type vector from a parameter.

 .NET Syntax

Visual Basic (Declaration)

Sub GetVector(_
 ByRef X As System.Double, _
 ByRef Y As System.Double, _
 ByRef Z As System.Double _
)

Visual Basic (Usage)

Dim instance As [IParameter](#)
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double

instance.GetVector(X, Y, Z)

C#

void GetVector(
 out System.double X,
 out System.double Y,
 out System.double Z
)

C++/CLI

void GetVector(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- X
x vector value stored on the parameter
- Y
y vector value stored on the parameter
- Z
z vector value stored on the parameter

 Visual Basic for Applications (VBA) Syntax

See [Parameter::GetVector](#).

 See Also

- [IParameter Interface](#)
- [IParameter Members](#)
- [IParameter::GetVectorVB Method](#)
- [IParameter::SetVector2 Method](#)

GetVectorVB Method (IParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : GetVectorVB Method (IParameter)

Extracts information of type vector from a parameter.

 .NET Syntax

Visual Basic (Declaration)

Function GetVectorVB() As System.Object

Visual Basic (Usage)



```
Dim instance As IParameter
Dim value As System.Object

value = instance.GetVectorVB()
```

C#

```
System.Object GetVectorVB()
```

C++/CLI

```
System.Object^ GetVectorVB();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 3 values in the vector (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Parameter::GetVectorVB](#).

Remarks

This method packs the data into a SafeArray in Visual Basic for Applications (VBA):

[X,Y,Z]

where:

(double) X	x vector value stored on the parameter
(double) Y	y vector value stored on the parameter
(double) Z	z vector value stored on the parameter

See Also

[IParameter Interface](#)
[IParameter Members](#)
[IParameter::GetVector Method](#)
[IParameter::SetVector2 Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDoubleValue Method (IParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : SetDoubleValue Method (IParameter)

Obsolete. Superseded by [IParameter::SetDoubleValue2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetDoubleValue( _  
    ByVal Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPParameter
Dim Value As System.Double
Dim value As System.Boolean

value = instance.SetDoubleValue(Value)
```

C#

```
System.bool SetDoubleValue(
    System.double Value
)
```

C++/CLI

```
System.bool SetDoubleValue(
    & System.double Value
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Value

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetDoubleValue](#).

See Also

[IPParameter Interface](#)
[IPParameter Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDoubleValue2 Method (IPParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPParameter Interface](#) : SetDoubleValue2 Method (IPParameter)

Sets the double or integer value of a named configuration option parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDoubleValue2( _
    ByVal Value As System.Double, _
    ByVal ConfigurationOption As System.Integer, _
    ByVal ConfigurationName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPParameter
Dim Value As System.Double
Dim ConfigurationOption As System.Integer
Dim ConfigurationName As System.String
Dim value As System.Boolean

value = instance.SetDoubleValue2(Value, ConfigurationOption, ConfigurationName)
```

C#

```
System.bool SetDoubleValue2(
    System.double Value,
    System.int ConfigurationOption,
    System.string ConfigurationName
)
```

```
System.bool SetDoubleValue2(
& System.double Value,
& System.int ConfigurationOption,
& System.String^ ConfigurationName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Value

Value to store for the named configuration option

ConfigurationOption

Configuration option as defined in [swSetValueInConfiguration_e](#)

ConfigurationName

Name of the configuration

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetDoubleValue2](#).

Example

[Create Attribute \(VBA\)](#)
[Delete Attribute \(C#\)](#)
[Delete Attribute \(VB.NET\)](#)
[Delete Attribute \(VBA\)](#)

Remarks

The ConfigurationName argument is:

- Not required if ConfigurationOption is set to swSetValue_InThisConfiguration = 1 or swSetValue_InAllConfigurations = 2.
- Required if ConfigurationOption is set to swSetValue_InSpecificConfigurations = 3.

Set ConfigurationOption to swSetValue_InAllConfigurations = 2 for drawing documents because they do not have configurations.

See Also

[IParameter Interface](#)
[IParameter Members](#)
[IParameter::GetDoubleValue Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetStringValue Method (IParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : SetStringValue Method (IParameter)

Obsolete. Superseded by [IParameter::SetStringValue2](#)

.NET Syntax

Visual Basic (Declaration)

```
Function SetStringValue( _
    ByVal StringValue As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParameter
Dim StringValue As System.String
Dim value As System.Boolean

value = instance.SetStringValue(StringValue)
```

C#

```
System.bool SetStringValue(
    System.string StringValue
)
```

C++/CLI

```
System.bool SetStringValue(
    & System.String^ StringValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringValue

Return Value

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetStringValue](#).

See Also

[IParameter Interface](#)
[IParameter Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetStringValue2 Method (IParameter)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : SetStringValue2 Method (IParameter)

Sets the double or integer value of a named configuration option parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function SetStringValue2( _
    ByVal StringValue As System.String, _
    ByVal ConfigurationOption As System.Integer, _
    ByVal ConfigurationName As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IParameter
Dim StringValue As System.String
Dim ConfigurationOption As System.Integer
Dim ConfigurationName As System.String
Dim value As System.Boolean

value = instance.SetStringValue2(StringValue, ConfigurationOption, ConfigurationName)
```

C#

```
System.bool SetStringValue2(
    System.string StringValue,
```



```
System.int ConfigurationOption,  
System.string ConfigurationName  
)
```

C++/CLI

```
System.bool SetStringValue2(  
& System.String^ StringValue,  
& System.int ConfigurationOption,  
& System.String^ ConfigurationName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringValue

Value to store for the named configuration option

ConfigurationOption

Configuration option as defined in [swInConfigurationOpts_e](#)

ConfigurationName

Name of the configuration

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetStringValue2](#).

Example

[Create Attribute \(VBA\)](#)
[Delete Attribute \(C#\)](#)
[Delete Attribute \(VB.NET\)](#)
[Delete Attribute \(VBA\)](#)

Remarks

The ConfigurationName argument is:

- Not required if ConfigurationOption is set to swThisConfiguration = 1 or swAllConfiguration = 2.
- Required if ConfigurationOption is set to swSpecifyConfiguration = 3 .

Set ConfigurationOption to swAllConfiguration = 2 for drawing documents because they do not have configurations.

See Also

[IPParameter Interface](#)
[IPParameter Members](#)
[IPParameter::GetStringValue Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVector Method (IPParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPParameter Interface](#) : SetVector Method (IPParameter)

Obsolete. Superseded by [IPParameter::SetVector2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetVector( _  
ByVal x As System.Double, _
```

```
ByVal Y As System.Double, _  
ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IParameter  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.SetVector(X, Y, Z)
```

C#

```
System.bool SetVector(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool SetVector(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetVector](#).

See Also

[IParameter Interface](#)
[IParameter Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVector2 Method (IParameter)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IParameter Interface](#) : SetVector2 Method (IParameter)

Sets the vector values of a named configuration option parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function SetVector2(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal ConfigurationOption As System.Integer, _  
    ByVal ConfigurationName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IPParameter
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim ConfigurationOption As System.Integer
Dim ConfigurationName As System.String
Dim value As System.Boolean

value = instance.SetVector2(X, Y, Z, ConfigurationOption, ConfigurationName)

```

C#

```

System.bool SetVector2(
    System.double X,
    System.double Y,
    System.double Z,
    System.int ConfigurationOption,
    System.string ConfigurationName
)

```

C++/CLI

```

System.bool SetVector2(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.int ConfigurationOption,
    & System.String^ ConfigurationName
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x value to store for the named configuration option

Y
y value to store for the named configuration option

Z
z value to store for the named configuration option

ConfigurationOption
Configuration option as defined in [swInConfigurationOpts_e](#)

ConfigurationName
Name of the configuration

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Parameter::SetVector2](#).

Remarks

The ConfigurationName argument is:

- Not required if ConfigurationOption is set to swThisConfiguration = 1 or swAllConfiguration = 2.
- Required if ConfigurationOption is set to swSpecifyConfiguration = 3.

Set the ConfigurationOption argument to swAllConfiguration = 2 for Drawing Docs as they do not have configurations.

See Also

[IPParameter Interface](#)
[IPParameter Members](#)
[IPParameter::GetVector Method](#)
[IPParameter::GetVectorVB Method](#)