

SOLIDWORKS API (.NET VBA C#) — Reference

(221/337): IPartDoc (part 4 of 4)

SOLIDWORKS API Documentation (converted from CHM)

IPartDoc (part 4 of 4) (Type)

SetMaterialPropertyName Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : SetMaterialPropertyName Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::SetMaterialPropertyName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetMaterialPropertyName( _  
    ByVal Database As System.String, _  
    ByVal Name As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Database As System.String  
Dim Name As System.String  
  
instance.SetMaterialPropertyName(Database, Name)
```

C#

```
void SetMaterialPropertyName(  
    System.string Database,  
    System.string Name  
)
```

C++/CLI

```
void SetMaterialPropertyName(  
& System.String^ Database,  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Database

Name

Visual Basic for Applications (VBA) Syntax

See [PartDoc::SetMaterialPropertyName](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SetMaterialPropertyName2 Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : SetMaterialPropertyName2 Method (IPartDoc)

Sets the name of the material property for the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetMaterialPropertyName2( _
    ByVal ConfigName As System.String, _
    ByVal Database As System.String, _
    ByVal Name As System.String _
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim ConfigName As System.String
Dim Database As System.String
Dim Name As System.String

instance.SetMaterialPropertyName2(ConfigName, Database, Name)
```

C#

```
void SetMaterialPropertyName2(
    System.string ConfigName,
    System.string Database,
    System.string Name
)
```

C++/CLI

```
void SetMaterialPropertyName2(
    & System.String^ ConfigName,
    & System.String^ Database,
    & System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName

Name of configuration

Database

Name of the material database (see **Remarks**)

Name

Name of material (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::SetMaterialPropertyName2](#).

Example

[Get and Set Material Visual Properties \(VBA\)](#)
[Get and Set Material Visual Properties \(VB.NET\)](#)
[Get and Set Material Visual Properties \(C#\)](#)

Remarks

This method only supports parts.

Click **Tools > Options > System Options > File Locations > Material Databases** to verify that a folder for Database is specified.

If Database is an empty string, then the default **sldmaterials** is used. Otherwise, specify the material database file name with the **.sldmat** filename extension. For example:

```
PartDoc.SetMaterialPropertyName2 "AddHoles", "solidworks materials.sldmat", "Alloy Steel"
```

- or -

```
PartDoc.SetMaterialPropertyName2 "AddHoles", "c:\Program Files\SOLIDWORKS\lang\english\sldmaterials\solidworks materials.sldmat", "Alloy Steel"
```

To remove a material, pass an empty string to Name.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::GetMaterialPropertyName2 Method](#)
[IPartDoc::GetMaterialVisualProperties Method](#)
[IPartDoc::SetMaterialVisualProperties Method](#)
[IPartDoc::IMaterialPropertyValues Property](#)
[IPartDoc::MaterialIdName Property](#)
[IPartDoc::MaterialPropertyValues Property](#)
[IPartDoc::MaterialUserName Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMaterialVisualProperties Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : SetMaterialVisualProperties Method (IPartDoc)

Sets the material visual properties for the active configuration and any specified configurations of this part.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialVisualProperties( _  
    ByVal Properties As MaterialVisualPropertiesData, _  
    ByVal ConfigOption As System.Integer, _  
    ByVal ConfigNames As System.Object _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Properties As MaterialVisualPropertiesData  
Dim ConfigOption As System.Integer  
Dim ConfigNames As System.Object  
Dim value As System.Integer  
  
value = instance.SetMaterialVisualProperties(Properties, ConfigOption, ConfigNames)
```

C#

```
System.int SetMaterialVisualProperties(  
    MaterialVisualPropertiesData Properties,  
    System.int ConfigOption,  
    System.object ConfigNames  
)
```

C++/CLI

```
System.int SetMaterialVisualProperties(  
& MaterialVisualPropertiesData^ Properties,  
& System.int ConfigOption,  
& System.Object^ ConfigNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Properties

[Material visual properties](#)

ConfigOption

Configurations as defined in [swInConfigurationOpts_e](#)

ConfigNames

Array of strings of the names of the configurations whose material visual properties to set

Return Value

0 on success, non-0 on failure

Visual Basic for Applications (VBA) Syntax

See [PartDoc::SetMaterialVisualProperties](#).

Example

[Get and Set Material Visual Properties \(VBA\)](#)
[Get and Set Material Visual Properties \(VB.NET\)](#)
[Get and Set Material Visual Properties \(C#\)](#)

Remarks

ConfigNames is used only when ConfigOption is set to swSpecifyConfiguration. If a different value is specified for ConfigOption, then ConfigNames is ignored.

This method always affects the active configuration, regardless of the value specified for ConfigNames.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::GetMaterialPropertyName2 Method](#)
[IPartDoc::GetMaterialVisualProperties Method](#)
[IPartDoc::SetMaterialPropertyName2 Method](#)
[IPartDoc::IMaterialPropertyValues Property](#)
[IPartDoc::MaterialIdName Property](#)
[IPartDoc::MaterialPropertyValues Property](#)
[IPartDoc::MaterialUserName Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowExploded Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : ShowExploded Method (IPartDoc)

Displays the specified explode view for this multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowExploded( _  
    ByVal ShowIt As System.Boolean, _  
    ByVal ExplodeViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim ShowIt As System.Boolean  
Dim ExplodeViewName As System.String  
Dim value As System.Boolean  
  
value = instance.ShowExploded(ShowIt, ExplodeViewName)
```

C#

```
System.bool ShowExploded(  
    System.bool ShowIt,  
    System.string ExplodeViewName  
)
```

C++/CLI



```
System.bool ShowExploded(  
& System.bool ShowIt,  
& System.String^ ExplodeViewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowIt

True to show ExplodeViewName in its exploded state, false to show it in its collapsed state

ExplodeViewName

Name of the explode view to show

Return Value

True if the explode view displays correctly, false if not

Visual Basic for Applications (VBA) Syntax

See [PartDoc::ShowExploded](#).

Example

See the [IPartExplodeStep](#) example.

Remarks

This method only works with explode views in the current, active configuration.

See Also

[IPartDoc Interface](#)

[IPartDoc Members](#)

[IPartDoc::GetExplodedViewConfigurationName Method \(\)](#)

[IPartDoc::GetExplodedViewNames Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0