

SOLIDWORKS API (.NET VBA C#) — Reference

(222/337): IPartExplodeStep- IPartingLineFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IPartExplodeStep (Type)

IPartExplodeStep Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartExplodeStep Interface

Allows access to the explode step of an explode view of a multibody part.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPartExplodeStep
```

Visual Basic (Usage)

```
Dim instance As IPartExplodeStep
```

C#

```
public interface IPartExplodeStep
```

C++/CLI

```
public interface class IPartExplodeStep
```

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep](#).

Example

[Add Multibody Part Explode Step \(VBA\)](#)
[Add Multibody Part Explode Step \(VB.NET\)](#)
[Add Multibody Part Explode Step \(C#\)](#)

Remarks

This interface is valid only for an active current explode view of a multibody part. To create an explode view of a multibody part, call [IPartDoc::CreateExplodedView](#).

The setter properties and methods of this interface:

- Always clear selection lists.
- Do not work if the Explode PropertyManager is open.
- Do not work if any body is being edited in the context of the multibody part.

To edit an explode step:

1. Use [IPartDoc::ShowExploded](#) to activate the explode view of interest.
2. Use [IPartDoc::GetExplodedViewConfigurationName](#) to get the configuration for the explode view.
3. Call [IConfiguration::GetPartExplodeStep](#) to access the explode step of interest.
4. Call [IModelDocExtension::SelectByIID2](#) to select:
 - a. Bodies to move with Mark = 1.
 - b. An explode direction entity (cylindrical [face](#), conical face, linear [edge](#), or [axis](#)) with Mark = 2.
5. Call [ISelectionMgr::GetSelectedObject6](#) to get the bodies selected in step 4a.
6. Call [IPartExplodeStep::SetBodies](#), passing in the bodies gotten in step 4a.
7. Call [IPartExplodeStep::SetExplodeDirection](#), passing in the explode direction entity that was selected in step 4b. See **Notes**.
8. Modify other explode step properties.

Notes:

When editing the object entity for the explode direction, please bear in mind:

If...	Then...
Both object and manipulator index are valid	Both object and manipulator index are set.
Manipulator index is valid, but object is invalid	Manipulator index is set, and object is unchanged.
Object is valid, but manipulator index is invalid	Object is set, and the manipulator index is reset to the Z direction index.
Both object and manipulator index are invalid	No values change.

For more information, see **Exploded Views in Multibody Parts** topic in the SOLIDWORKS Design user-interface help.

To access explode steps of explode views of assemblies, see [IExplodeStep](#).

Accessors

[IConfiguration::AddPartExplodeStep](#)

[IConfiguration::GetPartExplodeStep](#)

Access Diagram

[PartExplodeStep](#)

See Also

[IPartExplodeStep Members](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartExplodeStep Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartExplodeStep Interface

The following tables list the members exposed by [IPartExplodeStep](#).

Public Properties

Name	Description
 AutoSpaceBodiesOnDrag	Gets or sets whether to automatically space a group of bodies equally along an axis as you drag them in this explode step.
 ExplodeDistance	Gets or sets the distance to move bodies in this explode step.
 Name	Gets or sets the name of this explode step.
 ReverseTranslationDirection	Gets or sets whether to reverse the direction of explode in this explode step.

[Top](#)

Public Methods

Name	Description
 GetBodies	Gets the bodies of this explode step.
 GetExplodeDirection	Gets the explode direction (manipulator index and entity) for this explode step.
 SetBodies	Sets the bodies of this explode step.
 SetExplodeDirection	Sets the explode direction (manipulator index and entity) for this explode step.

[Top](#)

See Also

[IPartExplodeStep Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartExplodeStep Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartExplodeStep Interface

For a list of all members of this type, see [IPartExplodeStep members](#).

Public Methods

Name	Description
 GetBodies	Gets the bodies of this explode step.
 GetExplodeDirection	Gets the explode direction (manipulator index and entity) for this explode step.
 SetBodies	Sets the bodies of this explode step.



[SetExplodeDirection](#)

Sets the explode direction (manipulator index and entity) for this explode step.

[Top](#)

See Also

[IPartExplodeStep Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartExplodeStep Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartExplodeStep Interface

For a list of all members of this type, see [IPartExplodeStep members](#).

Public Properties

Name	Description
 AutoSpaceBodiesOnDrag	Gets or sets whether to automatically space a group of bodies equally along an axis as you drag them in this explode step.
 ExplodeDistance	Gets or sets the distance to move bodies in this explode step.
 Name	Gets or sets the name of this explode step.
 ReverseTranslationDirection	Gets or sets whether to reverse the direction of explode in this explode step.

[Top](#)

See Also

[IPartExplodeStep Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSpaceBodiesOnDrag Property (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : AutoSpaceBodiesOnDrag Property (IPartExplodeStep)

Gets or sets whether to automatically space a group of bodies equally along an axis as you drag them in this explode step.

.NET Syntax

Visual Basic (Declaration)

Property AutoSpaceBodiesOnDrag As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep
Dim value As System.Boolean

instance.AutoSpaceBodiesOnDrag = value

value = instance.AutoSpaceBodiesOnDrag
```

C#

```
System.bool AutoSpaceBodiesOnDrag {get; set;}
```

C++/CLI

```
property System.bool AutoSpaceBodiesOnDrag {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically space components equally along an axis as you drag them, false to not

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::AutoSpaceBodiesOnDrag](#).

Example

See the [IPartExplodeStep](#) example.

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExplodeDistance Property (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : ExplodeDistance Property (IPartExplodeStep)

Gets or sets the distance to move bodies in this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property ExplodeDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim value As System.Double
```

```
instance.ExplodeDistance = value
```

```
value = instance.ExplodeDistance
```

C#

```
System.double ExplodeDistance {get; set;}
```

C++/CLI

```
property System.double ExplodeDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in meters to move bodies

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::ExplodeDistance](#).

Example

See the [IPartExplodeStep](#) example.

See Also

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodies Method (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : GetBodies Method (IPartExplodeStep)

Gets the bodies of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodies() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim value As System.Object
```

```
value = instance.GetBodies()
```

C#

```
System.Object GetBodies()
```

C++/CLI

```
System.Object^ GetBodies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of solid [bodies](#)

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::GetBodies](#).

Example

See the [IPartExplodeStep](#) example.

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)
[IPartExplodeStep.SetBodies Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExplodeDirection Method (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : GetExplodeDirection Method (IPartExplodeStep)

Gets the explode direction (manipulator index and entity) for this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExplodeDirection( _  
    ByRef ExplDirIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim ExplDirIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetExplodeDirection(ExplDirIndex)
```

C#

```
System.object GetExplodeDirection(  
    out System.int ExplDirIndex  
)
```

C++/CLI

```
System.Object^ GetExplodeDirection(  
    & [Out] System.int ExplDirIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDirIndex
Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#)

Return Value

Explode direction entity (e.g., [IEdge](#), [IFace2](#), [IRefAxis](#)); Nothing or null if an explode direction entity was not selected during creation of this explode step

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::GetExplodeDirection](#).

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)
[IPartExplodeStep::SetExplodeDirection Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : Name Property (IPartExplodeStep)

Gets or sets the name of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim value As System.String  
  
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this explode step

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::Name](#).

Example

See the [IPartExplodeStep](#) example.

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseTranslationDirection Property (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : ReverseTranslationDirection Property (IPartExplodeStep)

Gets or sets whether to reverse the direction of explode in this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseTranslationDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim value As System.Boolean
```

```
instance.ReverseTranslationDirection = value
```

```
value = instance.ReverseTranslationDirection
```

C#

```
System.bool ReverseTranslationDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseTranslationDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of explode, false to not

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep.ReverseTranslationDirection](#).

Example

See the [IPartExplodeStep](#) example.

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBodies Method (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : SetBodies Method (IPartExplodeStep)

Sets the bodies of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetBodies( _
    ByVal Bodies As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep
Dim Bodies As System.Object

instance.SetBodies(Bodies)
```

C#

```
void SetBodies(
    System.object Bodies
)
```

C++/CLI

```
void SetBodies(
    & System.Object^ Bodies
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bodies
Array of solid [bodies](#)

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::SetBodies](#).

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)
[IPartExplodeStep::GetBodies Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetExplodeDirection Method (IPartExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartExplodeStep Interface](#) : SetExplodeDirection Method (IPartExplodeStep)

Sets the explode direction (manipulator index and entity) for this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetExplodeDirection( _  
    ByVal ExplodeDirection As System.Object, _  
    ByVal ExplDirIndex As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartExplodeStep  
Dim ExplodeDirection As System.Object  
Dim ExplDirIndex As System.Integer  
  
instance.SetExplodeDirection(ExplodeDirection, ExplDirIndex)
```

C#

```
void SetExplodeDirection(  
    System.object ExplodeDirection,  
    System.int ExplDirIndex  
)
```

C++/CLI

```
void SetExplodeDirection(  
& System.Object^ ExplodeDirection,  
& System.int ExplDirIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeDirection
Explode direction entity (e.g., [IEdge](#), [IFace2](#), [IRefAxis](#))
ExplDirIndex
Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartExplodeStep::SetExplodeDirection](#).

See Also

[IPartExplodeStep Interface](#)
[IPartExplodeStep Members](#)
[IPartExplodeStep::GetExplodeDirection Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

IPartialEdgeFilletData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartialEdgeFilletData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartialEdgeFilletData Interface

Allows access to partial fillet/chamfer properties.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPartialEdgeFilletData
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
```

C#

```
public interface IPartialEdgeFilletData
```

C++/CLI

```
public interface class IPartialEdgeFilletData
```

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData](#).

Example

```
'=====
'Preconditions:
'1. Open Public_documents\samples\tutorial\api\Block20.sldprt.
'2. Open an Immediate window.
'
'Postconditions:
'1. Creates Chamfer1.
'2. Chamfer1 contains two partial chamfers.
'3. Inspect the Immediate window.
'
'NOTE: Because the model is used elsewhere, do not save changes to it.
'=====

Option Explicit
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swModelDocExt As SldWorks.ModelDocExtension
Dim swFeatMgr As SldWorks.FeatureManager
Dim swSelMgr As SldWorks.SelectionMgr
Dim swFeat As SldWorks.Feature
Dim swFilletData As SldWorks.SimpleFilletFeatureData2
Dim PartialEdgeAFilletData As SldWorks.PartialEdgeFilletData
Dim PartialEdgeBFilletData As SldWorks.PartialEdgeFilletData
Dim filletItemA As SldWorks.Edge
Dim filletItemB As SldWorks.Edge
Dim swFeatDataObj As Object
Dim boolstatus As Boolean
Dim errorCode As Long
Dim warning As Boolean
Sub main()

    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set swFeatMgr = swModel.FeatureManager
    Set swSelMgr = swModel.SelectionManager

    ' Create the fillet feature data object to be a simple fillet type
    Set swFeatDataObj = swFeatMgr.CreateDefinition(swFmFillet)
```

```

Set swFilletData = swFeatDataObj

' Initialize the feature type to be a constant radius fillet
swFilletData.Initialize swConstRadiusFillet

' Specialize the feature type to be a chamfer
swFilletData.ConicTypeForCrossSectionProfile = swFeatureFilletConicRhoZeroChamfer

swFilletData.OverflowType = swFilletOverFlowType_Default
swFilletData.DefaultRadius = 0.01

' Select two edges to partially chamfer
boolstatus = swModel.Extension.SelectByRay(-6.27751435901871E-02, 3.95396450382464E-02, 6.03865270420556E-04,
0.156569748366562, -0.551708952719479, -0.81920885333693, 1.1220164860728E-03, 1, False, 1, 0)
boolstatus = swModel.Extension.SelectByRay(6.44200432014657E-02, 0.039572847309671, 1.30368065144353E-02, 0.156569748366562,
-0.551708952719479, -0.81920885333693, 1.1220164860728E-03, 1, True, 1, 0)

Set filletItemA = swSelMgr.GetSelectedObject6(1, -1)
Set filletItemB = swSelMgr.GetSelectedObject6(2, -1)

swFilletData.EnablePartialEdgeParameters = True
Set PartialEdgeAFilletData = swFilletData.GetPartialEdgeFilletData(filletItemA)
PartialEdgeAFilletData.SetPartialFilletParameters(True, swPartialEdgeDistanceOffset, 0.01, Nothing, swPartialEdgeDistanceOffset, 0.03,
Nothing)
Set PartialEdgeBFilletData = swFilletData.GetPartialEdgeFilletData(filletItemB)
PartialEdgeBFilletData.SetPartialFilletParameters(False, swPartialEdgeDistanceOffset, 0.01, Nothing, swPartialEdgeDistanceOffset, 0.03,
Nothing)

Set swFeat = swFeatMgr.CreateFeature(swFilletData)
errorCode = swFeat.GetErrorCode2(warning)

End Sub

```

Example

[Create Partial Chamfer \(C#\)](#)

Remarks

Use [IFeature.GetErrorCode2](#) after creating the partial edge fillet feature to see if anything is wrong with the new feature.

For more information, see the **Partial Edge Parameters** section of the **Constant Size Fillets** topic in the SOLIDWORKS Design user-interface help.

Accessors

[ISimpleFilletFeatureData2::GetPartialEdgeFilletData](#)

Access Diagram

[PartialEdgeFilletData](#)

See Also

[IPartialEdgeFilletData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartialEdgeFilletData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartialEdgeFilletData Interface

The following tables list the members exposed by [IPartialEdgeFilletData](#).

Public Properties

Name	Description
 AlongEdgeDirection	Gets which end of the edge to start the fillet.
 DistanceOffsetEnd	Gets the offset distance from the end point for this partial edge fillet.

	DistanceOffsetStart	Gets the offset distance from the start point for this partial edge fillet.
	EndCondition	Gets the type of end condition for this partial edge fillet.
	PercentOffsetEnd	Gets the percentage offset from the end point for this partial edge fillet.
	PercentOffsetStart	Gets the percentage offset from the start point for this partial edge fillet.
	ReferenceOffsetEnd	Gets the offset reference for the end condition for this partial edge fillet.
	ReferenceOffsetEndType	Gets the type of offset reference for the end condition for this partial edge fillet.
	ReferenceOffsetStart	Gets the offset reference for the start condition for this partial edge fillet.
	ReferenceOffsetStartType	Gets the type of offset reference for the start condition for this partial edge fillet.
	StartCondition	Gets the type of start condition for this partial edge fillet.

[Top](#)

Public Methods

Name	Description
 SetPartialFilletParameters	Sets the properties of this partial edge fillet.

[Top](#)

See Also

[IPartialEdgeFilletData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IPartialEdgeFilletData Interface Methods

[See Also](#)


SolidWorks.Interop.sldworks Namespace : IPartialEdgeFilletData Interface

For a list of all members of this type, see [IPartialEdgeFilletData members](#).

Public Methods

Name	Description
 SetPartialFilletParameters	Sets the properties of this partial edge fillet.

[Top](#)

See Also

[IPartialEdgeFilletData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IPartialEdgeFilletData Interface Properties

[See Also](#)


SolidWorks.Interop.sldworks Namespace : IPartialEdgeFilletData Interface

For a list of all members of this type, see [IPartialEdgeFilletData members](#).

Public Properties

Name	Description
	AlongEdgeDirection
	DistanceOffsetEnd
	DistanceOffsetStart
	EndCondition
	PercentOffsetEnd
	PercentOffsetStart

 ReferenceOffsetEnd	Gets the offset reference for the end condition for this partial edge fillet.
 ReferenceOffsetEndType	Gets the type of offset reference for the end condition for this partial edge fillet.
 ReferenceOffsetStart	Gets the offset reference for the start condition for this partial edge fillet.
 ReferenceOffsetStartType	Gets the type of offset reference for the start condition for this partial edge fillet.
 StartCondition	Gets the type of start condition for this partial edge fillet.

[Top](#)

See Also

[IPartialEdgeFilletData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlongEdgeDirection Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : AlongEdgeDirection Property (IPartialEdgeFilletData)

Gets which end of the edge to start the fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property AlongEdgeDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
Dim value As System.Boolean
```

```
value = instance.AlongEdgeDirection
```

C#

```
System.bool AlongEdgeDirection {get;}
```

C++/CLI

```
property System.bool AlongEdgeDirection {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to start the fillet at the start point of the edge, false to start the fillet at the end point of the edge

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::AlongEdgeDirection](#).

Remarks

To modify the starting point of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

DistanceOffsetEnd Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : DistanceOffsetEnd Property (IPartialEdgeFilletData)

Gets the offset distance from the end point for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property DistanceOffsetEnd As System.Double

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData  
Dim value As System.Double
```

```
value = instance.DistanceOffsetEnd
```

C#

```
System.double DistanceOffsetEnd {get;}
```

C++/CLI

```
property System.double DistanceOffsetEnd {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance offset from the end point

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::DistanceOffsetEnd](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::EndCondition](#) is set to swSimpleFilletPartialEdgeCondition_e.PartialEdgeDistanceOffset. To modify the end distance offset of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::DistanceOffsetStart Property\(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

DistanceOffsetStart Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : DistanceOffsetStart Property (IPartialEdgeFilletData)

Gets the offset distance from the start point for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property DistanceOffsetStart As System.Double

```
Dim instance As IPartialEdgeFilletData
Dim value As System.Double

value = instance.DistanceOffsetStart
```

C#

```
System.double DistanceOffsetStart {get;}
```

C++/CLI

```
property System.double DistanceOffsetStart {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance offset from the start point

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::DistanceOffsetStart](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::StartCondition](#) is set to swSimpleFilletPartialEdgeCondition_e.PartialEdgeDistanceOffset. To modify the start distance offset of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::DistanceOffsetEnd Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndCondition Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : EndCondition Property (IPartialEdgeFilletData)

Gets the type of end condition for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property EndCondition As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPartialEdgeFilletData
Dim value As System.Integer

value = instance.EndCondition
```

C#

```
System.int EndCondition {get;}
```

C++/CLI

```
property System.int EndCondition {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition as defined in [swSimpleFilletPartialEdgeCondition_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::EndCondition](#).

Remarks

To modify the end condition of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::StartCondition Property \(\)](#)
[IPartialEdgeFilletData::DistanceOffsetEnd Property \(\)](#)
[IPartialEdgeFilletData::PercentOffsetEnd Property \(\)](#)
[IPartialEdgeFilletData::ReferenceOffsetEnd Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PercentOffsetEnd Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : PercentOffsetEnd Property (IPartialEdgeFilletData)

Gets the percentage offset from the end point for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PercentOffsetEnd As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
Dim value As System.Double
```

```
value = instance.PercentOffsetEnd
```

C#

```
System.double PercentOffsetEnd {get;}
```

C++/CLI

```
property System.double PercentOffsetEnd {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= percentage offset from the end point < 100.0

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::PercentOffsetEnd](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::EndCondition](#) is `swSimpleFilletPartialEdgeCondition_e.PartialEdgePercentOffset`.
To modify the end percent offset of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::PercentOffsetStart Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PercentOffsetStart Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : PercentOffsetStart Property (IPartialEdgeFilletData)

Gets the percentage offset from the start point for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PercentOffsetStart As System.Double

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData  
Dim value As System.Double
```

```
value = instance.PercentOffsetStart
```

C#

```
System.double PercentOffsetStart {get;}
```

C++/CLI

```
property System.double PercentOffsetStart {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= percentage offset from the start point < 100.0

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::PercentOffsetStart](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::StartCondition](#) is `swSimpleFilletPartialEdgeCondition_e.PartialEdgePercentOffset`.
To modify the start percent offset of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::PercentOffsetEnd Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceOffsetEnd Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : ReferenceOffsetEnd Property (IPartialEdgeFilletData)

Gets the offset reference for the end condition for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferenceOffsetEnd As System.Object

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
Dim value As System.Object
```

```
value = instance.ReferenceOffsetEnd
```

C#

```
System.Object ReferenceOffsetEnd {get;}
```

C++/CLI

```
property System.Object^ ReferenceOffsetEnd {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset reference (2D/3D sketch [point](#), reference [point](#), planar [face](#))

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::ReferenceOffsetEnd](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::EndCondition](#) is swSimpleFilletPartialEdgeCondition_e.PartialEdgeReferenceOffset.

Use [IPartialEdgeFilletData::ReferenceOffsetEndType](#) to get the type of object returned by this property.

To modify the reference offset for the end condition of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceOffsetEndType Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : ReferenceOffsetEndType Property (IPartialEdgeFilletData)

Gets the type of [offset reference for the end condition](#) for this partial edge fillet.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceOffsetEndType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
Dim value As System.Integer

value = instance.ReferenceOffsetEndType
```

C#

```
System.int ReferenceOffsetEndType {get;}
```

C++/CLI

```
property System.int ReferenceOffsetEndType {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition offset reference type as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::ReferenceOffsetEndType](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReferenceOffsetStart Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : ReferenceOffsetStart Property (IPartialEdgeFilletData)

Gets the offset reference for the start condition for this partial edge fillet.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceOffsetStart As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
Dim value As System.Object

value = instance.ReferenceOffsetStart
```

C#

```
System.object ReferenceOffsetStart {get;}
```

C++/CLI

```
property System.Object^ ReferenceOffsetStart {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset reference (2D/3D sketch [point](#), reference [point](#), planar [face](#))

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::ReferenceOffsetStart](#).

Remarks

This property is valid only if [IPartialEdgeFilletData::StartCondition](#) is `swSimpleFilletPartialEdgeCondition_e.PartialEdgeReferenceOffset`.

Use [IPartialEdgeFilletData::ReferenceOffsetStartType](#) to get the type of object returned by this property.

To modify reference offset for the start condition of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReferenceOffsetStartType Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : ReferenceOffsetStartType Property (IPartialEdgeFilletData)

Gets the type of [offset reference for the start condition](#) for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceOffsetStartType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData  
Dim value As System.Integer
```

```
value = instance.ReferenceOffsetStartType
```

C#

```
System.int ReferenceOffsetStartType {get;}
```

C++/CLI

```
property System.int ReferenceOffsetStartType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start condition offset reference type as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::ReferenceOffsetStartType](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPartialFilletParameters Method (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : SetPartialFilletParameters Method (IPartialEdgeFilletData)

Sets the properties of this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPartialFilletParameters( _  
    ByVal AlongEdgeDirection As System.Boolean, _  
    ByVal StartCondition As System.Integer, _  
    ByVal StartValue As System.Double, _  
    ByVal StartReference As System.Object, _  
    ByVal EndCondition As System.Integer, _  
    ByVal EndValue As System.Double, _  
    ByVal EndReference As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData  
Dim AlongEdgeDirection As System.Boolean  
Dim StartCondition As System.Integer  
Dim StartValue As System.Double  
Dim StartReference As System.Object  
Dim EndCondition As System.Integer  
Dim EndValue As System.Double  
Dim EndReference As System.Object  
Dim value As System.Integer
```

```
value = instance.SetPartialFilletParameters(AlongEdgeDirection, StartCondition, StartValue,  
StartReference, EndCondition, EndValue, EndReference)
```

C#

```
System.int SetPartialFilletParameters(  
    System.bool AlongEdgeDirection,  
    System.int StartCondition,  
    System.double StartValue,  
    System.object StartReference,  
    System.int EndCondition,  
    System.double EndValue,  
    System.object EndReference  
)
```

C++/CLI

```
System.int SetPartialFilletParameters(  
& System.bool AlongEdgeDirection,  
& System.int StartCondition,  
& System.double StartValue,  
& System.Object^ StartReference,  
& System.int EndCondition,  
& System.double EndValue,
```

& System.Object^ [EndReference](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AlongEdgeDirection

True to start the fillet at the start point of the edge, false to start the fillet at the end point of the edge

StartCondition

Start condition as defined in [swSimpleFilletPartialEdgeCondition_e](#) (see **Remarks**)

StartValue

Distance or percent offset from the start point (see **Remarks**)

StartReference

Offset reference (2D/3D sketch [point](#), reference [point](#), planar [face](#)); valid only if StartCondition is swPartialEdgeReferenceOffset

EndCondition

End condition as defined in [swSimpleFilletPartialEdgeCondition_e](#) (see **Remarks**)

EndValue

Distance or percent offset from the end point (see **Remarks**)

EndReference

Offset reference (2D/3D sketch [point](#), reference [point](#), planar [face](#)); valid only if EndCondition is swPartialEdgeReferenceOffset

Return Value

Result code as defined in [swFeatureError_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::SetPartialFilletParameters](#).

Example

See the [IPartialEdgeFilletData](#) examples.

Remarks

StartValue (or EndValue) is a:

- Distance if StartCondition (or EndCondition) is swSimpleFilletPartialEdgeCondition_e.swPartialEdgeDistanceOffset.
- Percent value if StartCondition (or EndCondition) is swSimpleFilletPartialEdgeCondition_e.swPartialEdgePercentOffset.

See Also

[IPartialEdgeFilletData Interface](#)

[IPartialEdgeFilletData Members](#)

[IPartialEdgeFilletData::AlongEdgeDirection Property \(\)](#)

[IPartialEdgeFilletData::DistanceOffsetEnd Property \(\)](#)

[IPartialEdgeFilletData::DistanceOffsetStart Property \(\)](#)

[IPartialEdgeFilletData::PercentOffsetEnd Property \(\)](#)

[IPartialEdgeFilletData::PercentOffsetStart Property \(\)](#)

[IPartialEdgeFilletData::ReferenceOffsetEnd Property \(\)](#)

[IPartialEdgeFilletData::ReferenceOffsetStart Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartCondition Property (IPartialEdgeFilletData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartialEdgeFilletData Interface](#) : StartCondition Property (IPartialEdgeFilletData)

Gets the type of start condition for this partial edge fillet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property StartCondition As System.Integer

Visual Basic (Usage)



```
Dim instance As IPartialEdgeFilletData
```

```
Dim value As System.Integer
```

```
value = instance.StartCondition
```

C#

```
System.int StartCondition {get;}
```

C++/CLI

```
property System.int StartCondition {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start condition as defined in [swSimpleFilletPartialEdgeCondition_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartialEdgeFilletData::StartCondition](#).

Remarks

To modify the start condition of the fillet after creation, you must call [IPartialEdgeFilletData::SetPartialFilletParameters](#).

See Also

[IPartialEdgeFilletData Interface](#)
[IPartialEdgeFilletData Members](#)
[IPartialEdgeFilletData::EndCondition Property \(\)](#)
[IPartialEdgeFilletData::DistanceOffsetStart Property \(\)](#)
[IPartialEdgeFilletData::PercentOffsetStart Property \(\)](#)
[IPartialEdgeFilletData::ReferenceOffsetStart Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

IPartingLineFeatureData (Type)

IPartingLineFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingLineFeatureData Interface

Allows access to a parting line feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPartingLineFeatureData
```

Visual Basic (Usage)

```
Dim instance As IPartingLineFeatureData
```

C#

```
public interface IPartingLineFeatureData
```

C++/CLI

```
public interface class IPartingLineFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[PartingLineFeatureData](#)

See Also

[IPartingLineFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMoldPartingLine Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutOffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)

IPartingLineFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingLineFeatureData Interface

The following tables list the members exposed by [IPartingLineFeatureData](#).

Public Properties

Name	Description
 Angle	Gets or sets the draft angle for the parting line.
 CoreCavitySplit	Gets or sets the core/cavity split option for a parting line.
 PartingLines	Gets and sets the edges for the parting lines.
 PullDirection	Gets whether the direction of pull is reversed.
 PullDirectionBase	Gets or sets the direction of pull for the parting line feature.
 PullDirectionType	Gets the type of entity indicating the direction of pull.
 SplitFaces	Gets or sets whether to split faces.
 SplitFacesOption	Gets or sets the split faces option for this parting line.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe the parting line feature.
 DraftAnalysis	Performs draft analysis for the input angle and the direction of pull.
 GetEntitiesToSplit	Gets the entities that are used to split a face.
 GetEntitiesToSplitCount	Gets the number of entities to use to split a face and add edges to the parting line feature.
 GetFacesByType	Gets the specified faces after performing a draft analysis of the parting line feature.
 GetFacesByTypeCount	Gets the number of faces of the specified type for this parting line.
 GetPartingLinesCount	Gets the number of edges used as parting lines.
 IGetEntitiesToSplit	Gets the entities that are used to split a face.
 IGetFacesByType	Gets the specified faces after performing a draft analysis of the parting line feature.
 IGetPartingLines	Gets the edges used as parting lines.
 ISetEntitiesToSplit	Sets the entities to use to split a face and add edges to the parting line feature.
 ISetPartingLines	Sets the edges to use as parting lines.
 ReleaseSelectionAccess	Releases access to the selections that define this parting line feature.
 SetEntitiesToSplit	Sets the entities to use to split a face and add edges to the parting line feature.
 Status	Gets the status of this parting line feature.

[Top](#)

See Also

[IPartingLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMoldPartingLine Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutOffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartingLineFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingLineFeatureData Interface

For a list of all members of this type, see [IPartingLineFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe the parting line feature.

 DraftAnalysis	Performs draft analysis for the input angle and the direction of pull.
 GetEntitiesToSplit	Gets the entities that are used to split a face.
 GetEntitiesToSplitCount	Gets the number of entities to use to split a face and add edges to the parting line feature.
 GetFacesByType	Gets the specified faces after performing a draft analysis of the parting line feature.
 GetFacesByTypeCount	Gets the number of faces of the specified type for this parting line.
 GetPartingLinesCount	Gets the number of edges used as parting lines.
 IGetEntitiesToSplit	Gets the entities that are used to split a face.
 IGetFacesByType	Gets the specified faces after performing a draft analysis of the parting line feature.
 IGetPartingLines	Gets the edges used as parting lines.
 ISetEntitiesToSplit	Sets the entities to use to split a face and add edges to the parting line feature.
 ISetPartingLines	Sets the edges to use as parting lines.
 ReleaseSelectionAccess	Releases access to the selections that define this parting line feature.
 SetEntitiesToSplit	Sets the entities to use to split a face and add edges to the parting line feature.
 Status	Gets the status of this parting line feature.

[Top](#)

 See Also

[IPartingLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMoldPartingLine Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutOffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartingLineFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingLineFeatureData Interface

For a list of all members of this type, see [IPartingLineFeatureData members](#).

 Public Properties

Name	Description
 Angle	Gets or sets the draft angle for the parting line.
 CoreCavitySplit	Gets or sets the core/cavity split option for a parting line.
 PartingLines	Gets and sets the edges for the parting lines.
 PullDirection	Gets whether the direction of pull is reversed.
 PullDirectionBase	Gets or sets the direction of pull for the parting line feature.
 PullDirectionType	Gets the type of entity indicating the direction of pull.
 SplitFaces	Gets or sets whether to split faces.
 SplitFacesOption	Gets or sets the split faces option for this parting line.

[Top](#)

 See Also

[IPartingLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMoldPartingLine Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutOffSurfaceFeatureData Interface](#)

AccessSelections Method (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : AccessSelections Method (IPartingLineFeatureData)

Gains access to the selections that describe the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::AccessSelections](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...

Then...

Part	• TopDoc argument is the IModelDoc2 for the part • Component argument is Nothing or null
Assembly	• TopDoc is the IModelDoc2 object for the assembly • Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IPartingLineFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : Angle Property (IPartingLineFeatureData)

Gets or sets the draft angle for the parting line.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
Dim value As System.Double

instance.Angle = value

value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle in radians

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::Angle](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::DraftAnalysis Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CoreCavitySplit Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : CoreCavitySplit Property (IPartingLineFeatureData)

Gets or sets the core/cavity split option for a parting line.

.NET Syntax

Visual Basic (Declaration)

```
Property CoreCavitySplit As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Boolean
```

```
instance.CoreCavitySplit = value
```

```
value = instance.CoreCavitySplit
```

C#

```
System.bool CoreCavitySplit {get; set;}
```

C++/CLI

```
property System.bool CoreCavitySplit {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable a core/cavity split, false to not

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::CoreCavitySplit](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftAnalysis Method (IPartingLineFeatureData)

[See Also](#)



Performs draft analysis for the input angle and the direction of pull.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function DraftAnalysis( _  
    ByVal Angle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim Angle As System.Double  
Dim value As System.Boolean  
  
value = instance.DraftAnalysis(Angle)
```

C#

```
System.bool DraftAnalysis(  
    System.double Angle  
)
```

C++/CLI

```
System.bool DraftAnalysis(  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle
Draft angle

Return Value

True if draft analysis is performed, false if not

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::DraftAnalysis](#).

Remarks

If you want a different pull direction, then use [IPartingLineFeatureData::PullDirectionBase](#) to change the direction. Once this method is called, only the information for different faces (negative, positive, and so on) is generated.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData:Angle Property](#)
[IPartingLineFeatureData:GetFacesByType Method](#)
[IPartingLineFeatureData:IGetFacesByType Method](#)
[IPartingLineFeatureData:GetFacesByTypeCount Method](#)
[IPartingLineFeatureData:PullDirectionType Property](#)
[IPartingLineFeatureData:PullDirection Property](#)
[IPartingLineFeatureData:PullDirectionType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0



Gets the entities that are used to split a face.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetEntitiesToSplit( _  
    ByRef TypeArr As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim TypeArr As System.Object  
Dim value As System.Object  
  
value = instance.GetEntitiesToSplit(TypeArr)
```

C#

```
System.object GetEntitiesToSplit(  
    out System.object TypeArr  
)
```

C++/CLI

```
System.Object^ GetEntitiesToSplit(  
    & [Out] System.Object^ TypeArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TypeArr

Array of these entities as defined in [swSelectType_e](#):

- swSelVERTICES
- swSelSKETCHSEGS

Return Value

Array of [vertices](#) or [sketch segments](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::GetEntitiesToSplit](#).

Remarks

The resulting edges are added to the parting line feature.

When two vertices are specified, then an edge is created between them for the parting line feature.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::GetEntitiesToSplitCount Method](#)
[IPartingLineFeatureData::ISetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SplitFaces Property](#)
[IPartingLineFeatureData::SplitFacesOption Property](#)

Availability

GetEntitiesToSplitCount Method (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : GetEntitiesToSplitCount Method (IPartingLineFeatureData)

Gets the number of entities to use to split a face and add edges to the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntitiesToSplitCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
Dim value As System.Integer

value = instance.GetEntitiesToSplitCount()
```

C#

```
System.int GetEntitiesToSplitCount()
```

C++/CLI

```
System.int GetEntitiesToSplitCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::GetEntitiesToSplitCount](#).

Example

[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

Remarks

Call this method before calling [IPartingLineFeatureData::!GetEntitiesToSplit](#).

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::GetEntitiesToSplit Method](#)
[IPartingLineFeatureData::!SetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SplitFaces Property](#)
[IPartingLineFeatureData::SplitFacesOption Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GetFacesByType Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : GetFacesByType Method (IPartingLineFeatureData)

Gets the specified faces after performing a draft analysis of the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesByType( _  
    ByVal Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.GetFacesByType(Type)
```

C#

```
System.object GetFacesByType(  
    System.int Type  
)
```

C++/CLI

```
System.Object^ GetFacesByType(  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of face as defined by [swDraftAnalysisFaceType_e](#)

Return Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::GetFacesByType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::IGetFacesByType Method](#)
[IPartingLineFeatureData::GetFacesByTypeCount Method](#)
[IPartingLineFeatureData::DraftAnalysis Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesByTypeCount Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : GetFacesByTypeCount Method (IPartingLineFeatureData)

Gets the number of faces of the specified type for this parting line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesByTypeCount( _  
    ByVal Type As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim Type As System.Integer  
Dim value As System.Integer  
  
value = instance.GetFacesByTypeCount(Type)
```

C#

```
System.int GetFacesByTypeCount(  
    System.int Type  
)
```

C++/CLI

```
System.int GetFacesByTypeCount(  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of faces as defined by [swDraftAnalysisFaceType_e](#)

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::GetFacesByTypeCount](#).

Remarks

Call this method before calling [IPartingLineFeatureData::!GetFacesbyType](#).

See Also

[IPartingLineFeatureData Interface](#)

[IPartingLineFeatureData Members](#)

[IPartingLineFeatureData::GetFacesByType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPartingLinesCount Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : GetPartingLinesCount Method (IPartingLineFeatureData)

Gets the number of edges used as parting lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartingLinesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Integer  
  
value = instance.GetPartingLinesCount()
```

C#

```
System.int GetPartingLinesCount()
```

C++/CLI

```
System.int GetPartingLinesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::GetPartingLinesCount](#).

Remarks

Call this method before calling [IPartingLineFeatureData::IGetPartingLines](#).

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::ISetPartingLines Method](#)
[IPartingLineFeatureData::PartingLines Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEntitiesToSplit Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : IGetEntitiesToSplit Method (IPartingLineFeatureData)

Gets the entities that are used to split a face.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntitiesToSplit( _  
    ByVal Count As System.Integer, _  
    ByRef TypeArr As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim Count As System.Integer  
Dim TypeArr As System.Integer  
Dim value As System.Object  
  
value = instance.IGetEntitiesToSplit(Count, TypeArr)
```

C#

```
System.object IGetEntitiesToSplit(  
    System.int Count,
```

```
    out System.int TypeArr  
)
```

C++/CLI

```
System.Object^ IGetEntitiesToSplit(  
& System.int Count,  
& [Out] System.int TypeArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities

TypeArr

- in-process, unmanaged C++: Pointer to an array of these entities as defined in [swSelectType_e](#):
 - swSelVERTICES
 - swSelSKETCHSEGS
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of [vertices](#) or [sketch segments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

The resulting edges are added to the parting line feature.

Call [IPartingLineFeatureData::GetEntitiesToSplitCount](#) before this method.

When two vertices are specified, then an edge is created between them for the parting line feature.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::GetEntitiesToSplit Method](#)
[IPartingLineFeatureData::ISetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SplitFaces Property](#)
[IPartingLineFeatureData::SplitFacesOption Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFacesByType Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : IGetFacesByType Method (IPartingLineFeatureData)

Gets the specified faces after performing a draft analysis of the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacesByType(  
    ByVal Type As System.Integer, _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim Type As System.Integer  
Dim Count As System.Integer
```

```
Dim value As Face2

value = instance.IGetFacesByType(Type, Count)
```

C#

```
Face2 IGetFacesByType(
    System.int Type,
    System.int Count
)
```

C++/CLI

```
Face2^ IGetFacesByType(
    & System.int Type,
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of face as defined by [swDraftAnalysisFaceType_e](#)

Count

Number of faces

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IPartingLineFeatureData::GetFacesByTypeCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)

[IPartingLineFeatureData Members](#)

[IPartingLineFeatureData::GetFacesByType Method](#)

[IPartingLineFeatureData::DraftAnalysis Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPartingLines Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : IGetPartingLines Method (IPartingLineFeatureData)

Gets the edges used as parting lines.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPartingLines( _
    ByVal Count As System.Integer _
) As Edge
```

Visual Basic (Usage)

```
Dim instance As IPartingLineFeatureData
Dim Count As System.Integer
Dim value As Edge
```



```
value = instance.IGetPartingLines(Count)
```

C#

```
Edge IGetPartingLines(  
    System.int Count  
)
```

C++/CLI

```
Edge^ IGetPartingLines(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of edges used as parting lines

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) used as parting lines of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IPartingLineFeatureData::GetPartingLinesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::ISetPartingLines Method](#)
[IPartingLineFeatureData::PartingLines Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEntitiesToSplit Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : ISetEntitiesToSplit Method (IPartingLineFeatureData)

Sets the entities to use to split a face and add edges to the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEntitiesToSplit( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IPartingLineFeatureData  
Dim Count As System.Integer  
Dim EntIn As System.Object  
  
instance.ISetEntitiesToSplit(Count, EntIn)
```

C#



```
void ISetEntitiesToSplit(  
    System.int Count,  
    ref System.object EntIn  
)
```

C++/CLI

```
void ISetEntitiesToSplit(  
& System.int Count,  
& System.Object^% EntIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities

EntIn

- in-process, unmanaged C++: Pointer to an array of [vertices](#) or [sketch segments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

Remarks

If sketch segments and vertices are specified, then a pair of vertices appear together; for example, segment1, vtx11, vtx12, segment2, vtx21, vtx22, vtx31, vtx32, and so on.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)

[IPartingLineFeatureData Members](#)

[IPartingLineFeatureData::SetEntitiesToSplit Method](#)

[IPartingLineFeatureData::GetEntitiesToSplit Method](#)

[IPartingLineFeatureData::GetEntitiesToSplitCount Method](#)

[IPartingLineFeatureData::IGetEntitiesToSplit Method](#)

[IPartingLineFeatureData::SplitFaces Property](#)

[IPartingLineFeatureData::SplitFacesOption Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPartingLines Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : ISetPartingLines Method (IPartingLineFeatureData)

Sets the edges to use as parting lines.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPartingLines( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As Edge _  
)
```

Visual Basic (Usage)

```
Dim instance As IPartingLineFeatureData  
Dim Count As System.Integer  
Dim EntIn As Edge
```



```
instance.ISetPartingLines(Count, EntIn)
```

C#

```
void ISetPartingLines(  
    System.int Count,  
    ref Edge EntIn  
)
```

C++/CLI

```
void ISetPartingLines(  
& System.int Count,  
& Edge^% EntIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges to use as parting lines

EntIn

- in-process, unmanaged C++: Pointer to an array of [edges](#) to use as parting lines of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)

[IPartingLineFeatureData Members](#)

[IPartingLineFeatureData::PartingLines Property](#)

[IPartingLineFeatureData::IGetPartingLines Method](#)

[IPartingLineFeatureData::GetPartingLinesCount Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartingLines Property (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : PartingLines Property (IPartingLineFeatureData)

Gets and sets the edges for the parting lines.

.NET Syntax

Visual Basic (Declaration)

```
Property PartingLines As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
```

```
Dim value As System.Object
```

```
instance.PartingLines = value
```

```
value = instance.PartingLines
```

C#

```
System.object PartingLines {get; set;}
```

C++/CLI

```
property System.Object^ PartingLines {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::PartingLines](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::IGetPartingLines Method](#)
[IPartingLineFeatureData::ISetPartingLines Method](#)
[IPartingLineFeatureData::GetPartingLinesCount Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PullDirection Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : PullDirection Property (IPartingLineFeatureData)

Gets whether the direction of pull is reversed.

.NET Syntax

Visual Basic (Declaration)

Property PullDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
Dim value As System.Boolean

instance.PullDirection = value

value = instance.PullDirection
```

C#

```
System.bool PullDirection {get; set;}
```

C++/CLI

```
property System.bool PullDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the direction of pull is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::PullDirection](#).

Example

[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::DraftAnalysis Method](#)
[IPartingLineFeatureData::PullDirectionBase Property](#)
[IPartingLineFeatureData::PullDirectionType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PullDirectionBase Property (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : PullDirectionBase Property (IPartingLineFeatureData)

Gets or sets the direction of pull for the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PullDirectionBase As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Object
```

```
instance.PullDirectionBase = value
```

```
value = instance.PullDirectionBase
```

C#

```
System.object PullDirectionBase {get; set;}
```

C++/CLI

```
property System.Object^ PullDirectionBase {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entity that indicates the direction of pull: [edge](#), [face](#), [plane](#), or [axis](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::PullDirectionBase](#).

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::DraftAnalysis Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirectionType Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : PullDirectionType Property (IPartingLineFeatureData)

Gets the type of entity indicating the direction of pull.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PullDirectionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Integer
```

```
value = instance.PullDirectionType
```

C#

```
System.int PullDirectionType {get;}
```

C++/CLI

```
property System.int PullDirectionType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of entity indicating the direction of pull as defined in [swSelectType_e](#):

- swSelEDGES
- swSelFACES
- swSelDATUMAXES
- swSelDATUMPLANES

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::PullDirectionType](#).

Example

[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::DraftAnalysis Method](#)
[IPartingLineFeatureData::PullDirection Property](#)
[IPartingLineFeatureData::PullDirectionBase Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

ReleaseSelectionAccess Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : ReleaseSelectionAccess Method (IPartingLineFeatureData)

Releases access to the selections that define this parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::ReleaseSelectionAccess](#).

Remarks

[IPartingLineFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the parting line feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SetEntitiesToSplit Method (IPartingLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : SetEntitiesToSplit Method (IPartingLineFeatureData)

Sets the entities to use to split a face and add edges to the parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEntitiesToSplit( _  
    ByVal PVar As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
Dim PVar As System.Object

instance.SetEntitiesToSplit(PVar)
```

C#

```
void SetEntitiesToSplit(
    System.Object PVar
)
```

C++/CLI

```
void SetEntitiesToSplit(
    & System.Object^ PVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PVar
Array of [vertices](#) or [sketch segments](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::SetEntitiesToSplit](#).

Remarks

If sketch segments and vertices are specified, then a pair of vertices appear together; for example, segment1, vtx11, vtx12, segment2, vtx21, vtx22, vtx31, vtx32, and so on.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::ISetEntitiesToSplit Method](#)
[IPartingLineFeatureData::GetEntitiesToSplit Method](#)
[IPartingLineFeatureData::GetEntitiesToSplitCount Method](#)
[IPartingLineFeatureData::ISetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SplitFaces Property](#)
[IPartingLineFeatureData::SplitFacesOption Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SplitFaces Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : SplitFaces Property (IPartingLineFeatureData)

Gets or sets whether to split faces.

.NET Syntax

Visual Basic (Declaration)

```
Property SplitFaces As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData
Dim value As System.Boolean

instance.SplitFaces = value
```

```
value = instance.SplitFaces
```

C#

```
System.bool SplitFaces {get; set;}
```

C++/CLI

```
property System.bool SplitFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to split faces, false to not

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::SplitFaces](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[IPartingLineFeatureData::SplitFacesOption Property](#)
[IPartingLineFeatureData::GetEntitiesToSplit Method](#)
[IPartingLineFeatureData::GetEntitiesToSplitCount Method](#)
[IPartingLineFeatureData::!GetEntitiesToSplit Method](#)
[IPartingLineFeatureData::!SetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SetEntitiesToSplit Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitFacesOption Property (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : SplitFacesOption Property (IPartingLineFeatureData)

Gets or sets the split faces option for this parting line.

.NET Syntax

Visual Basic (Declaration)

```
Property SplitFacesOption As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Integer
```

```
instance.SplitFacesOption = value
```

```
value = instance.SplitFacesOption
```

C#

```
System.int SplitFacesOption {get; set;}
```

C++/CLI

```
property System.int SplitFacesOption {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Split faces option as defined in [swSplitFacesOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::SplitFacesOption](#).

Example

[Set Options for Parting Line \(VBA\)](#)
[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)
[SplitFaces Property](#)
[GetEntitiesToSplit Method](#)
[GetEntitiesToSplitCount Method](#)
[IGetEntitiesToSplit Method](#)
[ISetEntitiesToSplit Method](#)
[IPartingLineFeatureData::SetEntitiesToSplit Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Status Method (IPartingLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingLineFeatureData Interface](#) : Status Method (IPartingLineFeatureData)

Gets the status of this parting line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function Status() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingLineFeatureData  
Dim value As System.Integer  
  
value = instance.Status()
```

C#

```
System.int Status()
```

C++/CLI

```
System.int Status();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Status of parting line feature as defined in [swPartingLineFeatureStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartingLineFeatureData::Status](#).

Example

[Get and Set Parting Line Feature Data \(C#\)](#)
[Get and Set Parting Line Feature Data \(VB.NET\)](#)
[Get and Set Parting Line Feature Data \(VBA\)](#)

Remarks

Call this method after specifying the settings and options for this feature to find out the status of the feature.

See Also

[IPartingLineFeatureData Interface](#)
[IPartingLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0