

SOLIDWORKS API (.NET VBA C#) — Reference (223/337): IPartingSurfaceFeatureData- IPMIDatumFeature

SOLIDWORKS API Documentation (converted from CHM)

IPartingSurfaceFeatureData (Type)

IPartingSurfaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingSurfaceFeatureData Interface

Allows access to a parting surface feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPartingSurfaceFeatureData
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
```

C#

```
public interface IPartingSurfaceFeatureData
```

C++/CLI

```
public interface class IPartingSurfaceFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[PartingSurfaceFeatureData](#)

See Also

[IPartingSurfaceFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMoldPartingSurface Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)

IPartingSurfaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingSurfaceFeatureData Interface

The following tables list the members exposed by [IPartingSurfaceFeatureData](#).

Public Properties

Name	Description
 Knit	Gets or sets whether to knit all surfaces.
 OffsetAngle	Gets or sets the angle for this parting surface feature.
 OffsetDistance	Gets or sets the distance that this parting surface feature extends.
 PartingLines	Gets or sets the entities for the parting lines for this parting surface feature.
 PartingType	Gets or sets the type of parting surface.
 PullDirectionBase	Gets or sets the entity that defines the direction of pull for this parting surface feature.
 PullDirectionType	Gets the type of entity that specifies the direction of pull for this parting surface feature.
 ReverseAlignment	Gets or sets whether to reverse alignment of this parting surface feature.
 ReverseOffsetDirection	Gets or sets whether to reverse the direction of this parting surface feature.
 TransitionDistance	Gets or sets the distance to set between adjacent edges for this parting surface feature.
 TransitionType	Gets or sets the type of transition between adjacent edges for this parting surface feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this parting surface feature.
 GetPartingLinesCount	Gets the number of parting lines for this parting surface feature.
 GetPartingLinesType	Gets the type of entity to use for parting lines for this parting surface feature.
 IGetPartingLines	Gets the parting lines for this parting surface feature.
 ISetPartingLines	Sets the parting lines for this parting surface feature.
 ReleaseSelectionAccess	Releases access to the selections that define this parting surface feature.

[Top](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMoldPartingSurface Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartingSurfaceFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartingSurfaceFeatureData Interface

For a list of all members of this type, see [IPartingSurfaceFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this parting surface feature.
 GetPartingLinesCount	Gets the number of parting lines for this parting surface feature.
 GetPartingLinesType	Gets the type of entity to use for parting lines for this parting surface feature.
 IGetPartingLines	Gets the parting lines for this parting surface feature.
 ISetPartingLines	Sets the parting lines for this parting surface feature.
 ReleaseSelectionAccess	Releases access to the selections that define this parting surface feature.

[Top](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMoldPartingSurface Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartingSurfaceFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPartingSurfaceFeatureData Interface

For a list of all members of this type, see [IPartingSurfaceFeatureData members](#).

Public Properties

Name	Description
 Knit	Gets or sets whether to knit all surfaces.
 OffsetAngle	Gets or sets the angle for this parting surface feature.
 OffsetDistance	Gets or sets the distance that this parting surface feature extends.
 PartingLines	Gets or sets the entities for the parting lines for this parting surface feature.
 PartingType	Gets or sets the type of parting surface.
 PullDirectionBase	Gets or sets the entity that defines the direction of pull for this parting surface feature.
 PullDirectionType	Gets the type of entity that specifies the direction of pull for this parting surface feature.
 ReverseAlignment	Gets or sets whether to reverse alignment of this parting surface feature.
 ReverseOffsetDirection	Gets or sets whether to reverse the direction of this parting surface feature.
 TransitionDistance	Gets or sets the distance to set between adjacent edges for this parting surface feature.
 TransitionType	Gets or sets the type of transition between adjacent edges for this parting surface feature.

[Top](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMoldPartingSurface Method](#)
[ICavityFeatureData Interface](#)
[ICoreFeatureData Interface](#)
[IMoveFaceFeatureData Interface](#)
[IPartingLineFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : AccessSelections Method (IPartingSurfaceFeatureData)

Gains access to the selections that define this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::AccessSelections](#).

 Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IPartingSurfaceFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

 Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Gets the number of parting lines for this parting surface feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetPartingLinesCount() As System.Integer
```

Visual Basic (Usage) 

```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Integer

value = instance.GetPartingLinesCount()
```

C#

```
System.int GetPartingLinesCount()
```

C++/CLI

```
System.int GetPartingLinesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value
Number of parting lines

 Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::GetPartingLinesCount](#).

 Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

 Remarks

Call this method before calling [IPartingSurfaceFeatureData::!GetPartingLines](#).

 See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::!SetPartingLines Method](#)
[IPartingSurfaceFeatureData::PartingLines Property](#)
[IPartingSurfaceFeatureData::GetPartingLinesType Method](#)

 Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help [Send comments on this topic.](#)

GetPartingLinesType Method (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : GetPartingLinesType Method (IPartingSurfaceFeatureData)

Gets the type of entity to use for parting lines for this parting surface feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetPartingLinesType() As System.Integer
```

```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Integer

value = instance.GetPartingLinesType()
```

C#

```
System.int GetPartingLinesType()
```

C++/CLI

```
System.int GetPartingLinesType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- 0 = [Parting-line feature](#)
- 1 = [Edge](#)

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::GetPartingLinesType](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::GetPartingLinesCount Method](#)
[IPartingSurfaceFeatureData::IGetPartingLines Method](#)
[IPartingSurfaceFeatureData::ISetPartingLines Method](#)
[IPartingSurfaceFeatureData::PartingLines Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPartingLines Method (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : IGetPartingLines Method (IPartingSurfaceFeatureData)

Gets the parting lines for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPartingLines( _
    ByVal Count As System.Integer _
) As System.Object
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPartingSurfaceFeatureData
Dim Count As System.Integer
Dim value As System.Object

value = instance.IGetPartingLines(Count)
```

C#

```
System.object IGetPartingLines(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetPartingLines(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of parting lines

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) or [parting line features](#) used as parting lines
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IPartingSurfaceFeatureData::GetPartingLinesCount](#) before calling this method to get the number of parting lines for this parting surface feature.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::GetPartingLinesType Method](#)
[IPartingSurfaceFeatureData::ISetPartingLines Method](#)
[IPartingSurfaceFeatureData::PartingLines Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPartingLines Method (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : ISetPartingLines Method (IPartingSurfaceFeatureData)

Sets the parting lines for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPartingLines( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim Count As System.Integer  
Dim EntIn As System.Object
```

```
instance.ISetPartingLines(Count, EntIn)
```

C#

```
void ISetPartingLines(  
    System.int Count,
```

```
    ref System.object EntIn
)
```

C++/CLI

```
void ISetPartingLines(
&    System.int Count,
&    System.Object^% EntIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of parting lines

EntIn

- in-process, unmanaged C++: Pointer to an array of [edges](#) or [parting-line features](#) used as parting lines
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::GetPartingLinesCount Method](#)
[IPartingSurfaceFeatureData::GetPartingLinesType Method](#)
[IPartingSurfaceFeatureData::IPartingLines Method](#)
[IPartingSurfaceFeatureData::PartingLines Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Knit Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : Knit Property (IPartingSurfaceFeatureData)

Gets or sets whether to knit all surfaces.

.NET Syntax

Visual Basic (Declaration)

```
Property Knit As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Boolean
```

```
instance.Knit = value
```

```
value = instance.Knit
```

C#

```
System.bool Knit {get; set;}
```

C++/CLI

```
property System.bool Knit {
    System.bool get();
    void set ( &    System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to knit all surfaces, false to not

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::Knit](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetAngle Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : OffsetAngle Property (IPartingSurfaceFeatureData)

Gets or sets the angle for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property OffsetAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Double

instance.OffsetAngle = value
value = instance.OffsetAngle
```

C#

```
System.double OffsetAngle {get; set;}
```

C++/CLI

```
property System.double OffsetAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::OffsetAngle](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

Remarks

This property only applies if you set [IPartingSurfaceFeatureData::PartingType](#) to swPartingSurfaceMoldParmTangent or swPartingSurfaceMoldParmNormal.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OffsetDistance Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : OffsetDistance Property (IPartingSurfaceFeatureData)

Gets or sets the distance that this parting surface feature extends.

.NET Syntax

Visual Basic (Declaration)

Property OffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Double  
  
instance.OffsetDistance = value  
  
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::OffsetDistance](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartingLines Property (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : PartingLines Property (IPartingSurfaceFeatureData)

Gets or sets the entities for the parting lines for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property PartingLines As System.Object

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Object
```

```
instance.PartingLines = value
```

```
value = instance.PartingLines
```

C#

```
System.object PartingLines {get; set;}
```

C++/CLI

```
property System.Object^ PartingLines {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#) or [parting-line features](#) to use as parting lines

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::PartingLines](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::GetPartingLinesCount Method](#)
[IPartingSurfaceFeatureData::GetPartingLinesType Method](#)
[IPartingSurfaceFeatureData::IGetPartingLines Method](#)
[IPartingSurfaceFeatureData::ISetPartingLines Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartingType Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : PartingType Property (IPartingSurfaceFeatureData)

Gets or sets the type of parting surface.

.NET Syntax

Visual Basic (Declaration)

```
Property PartingType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Integer

instance.PartingType = value

value = instance.PartingType
```

C#

```
System.int PartingType {get; set;}
```

C++/CLI

```
property System.int PartingType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of parting surface as defined in [swPartingSurfaceMoldParmType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::PartingType](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

Remarks

swPartingSurfaceMoldParmType_e.swPartingSurfaceMoldParmTangent is not available for some geometry.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::ReverseAlignment Property](#)
[IPartingSurfaceFeatureData::OffsetAngle Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirectionBase Property (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : PullDirectionBase Property (IPartingSurfaceFeatureData)

Gets or sets the entity that defines the direction of pull for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property PullDirectionBase As System.Object

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Object
```

```
instance.PullDirectionBase = value
```

```
value = instance.PullDirectionBase
```

C#

```
System.object PullDirectionBase {get; set;}
```

C++/CLI

```
property System.Object^ PullDirectionBase {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Edge](#), [face](#), [plane](#), or [axis](#)

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::PullDirectionBase](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::PullDirectionType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirectionType Property (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : PullDirectionType Property (IPartingSurfaceFeatureData)

Gets the type of entity that specifies the direction of pull for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PullDirectionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Integer
```

```
value = instance.PullDirectionType
```

C#

```
System.int PullDirectionType {get;}
```

C++/CLI

```
property System.int PullDirectionType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of entity that represents the direction of pull as defined by [swSelectType_e](#):

- swSelEDGES
- swSelDATUMAXES
- swSelDATUMPLANES
- swSelFaCES

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::PullDirectionType](#).

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::PullDirectionBase Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : ReleaseSelectionAccess Method (IPartingSurfaceFeatureData)

Releases access to the selections that define this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::ReleaseSelectionAccess](#).

Remarks

[IPartingSurfaceFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the parting surface feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseAlignment Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : ReverseAlignment Property (IPartingSurfaceFeatureData)

Gets or sets whether to reverse alignment of this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseAlignment As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseAlignment = value
```

```
value = instance.ReverseAlignment
```

C#

```
System.bool ReverseAlignment {get; set;}
```

C++/CLI

```
property System.bool ReverseAlignment {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse alignment, false to not

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::ReverseAlignment](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseOffsetDirection Property (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : ReverseOffsetDirection Property (IPartingSurfaceFeatureData)

Gets or sets whether to reverse the direction of this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseOffsetDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseOffsetDirection = value
```

```
value = instance.ReverseOffsetDirection
```

C#

```
System.bool ReverseOffsetDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseOffsetDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction, false to not

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::ReverseOffsetDirection](#).

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransitionDistance Property (IPartingSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : TransitionDistance Property (IPartingSurfaceFeatureData)

Gets or sets the distance to set between adjacent edges for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property TransitionDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Double

instance.TransitionDistance = value
value = instance.TransitionDistance
```

C#

```
System.double TransitionDistance {get; set;}
```

C++/CLI

```
property System.double TransitionDistance {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::TransitionDistance](#).

Remarks

This property is only available when [IPartingSurfaceFeatureData::TransitionType](#) is set to swPartingSurfaceSmoothingType_e.swPartingSurfaceSmooth.

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransitionType Property (IPartingSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartingSurfaceFeatureData Interface](#) : TransitionType Property (IPartingSurfaceFeatureData)

Gets or sets the type of transition between adjacent edges for this parting surface feature.

.NET Syntax

Visual Basic (Declaration)

Property TransitionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IPartingSurfaceFeatureData
Dim value As System.Integer

instance.TransitionType = value
value = instance.TransitionType
```

C#

```
System.int TransitionType {get; set;}
```

C++/CLI

```
property System.int TransitionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of transition as defined in [swPartingSurfaceSmoothingType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PartingSurfaceFeatureData::TransitionType](#).

Example

[Get and Set Parting Surface Feature Data \(C#\)](#)
[Get and Set Parting Surface Feature Data \(VB.NET\)](#)
[Get and Set Parting Surface Feature Data \(VBA\)](#)

See Also

[IPartingSurfaceFeatureData Interface](#)
[IPartingSurfaceFeatureData Members](#)
[IPartingSurfaceFeatureData::TransitionDistance Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

IPerpendicularMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPerpendicularMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPerpendicularMateFeatureData Interface

Allows access to a perpendicular mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPerpendicularMateFeatureData
```

Visual Basic (Usage)

```
Dim instance As IPerpendicularMateFeatureData
```

C#

```
public interface IPerpendicularMateFeatureData
```

C++/CLI

```
public interface class IPerpendicularMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [PerpendicularMateFeatureData](#).

Example

[Create Standard Mates \(VBA\)](#)
[Create Standard Mates \(C#\)](#)

Remarks

A perpendicular mate places selected items at a 90° angle.

[IMateFeatureData](#) is the parent of this mate interface.

To create a perpendicular mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IPerpendicularMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByD2](#) to pre-select the entities to mate using Mark = 1.
3. Modify other properties of the PerpendicularMateFeatureData object.

To edit a perpendicular mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a PerpendicularMateFeatureData object.
3. Modify the PerpendicularMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this perpendicular mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[PerpendicularMateFeatureData](#)

See Also

[IPerpendicularMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPerpendicularMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPerpendicularMateFeatureData Interface

The following tables list the members exposed by [IPerpendicularMateFeatureData](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this perpendicular mate.
 PickPoints	Gets or sets the pick points for the entities to mate in this perpendicular mate.

[Top](#)

See Also

[IPerpendicularMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPerpendicularMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPerpendicularMateFeatureData Interface

For a list of all members of this type, see [IPerpendicularMateFeatureData members](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this perpendicular mate.
 PickPoints	Gets or sets the pick points for the entities to mate in this perpendicular mate.

[Top](#)

See Also

[IPerpendicularMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

EntitiesToMate Property (IPerpendicularMateFeatureData)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IPerpendicularMateFeatureData Interface](#) : EntitiesToMate Property (IPerpendicularMateFeatureData)

Gets or sets the entities to mate in this perpendicular mate.

Visual Basic Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)

```
Dim instance As IPerpendicularMateFeatureData
Dim value As System.Object

instance.EntitiesToMate = value
value = instance.EntitiesToMate
```

C#

```
System.object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entities to mate (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [PerpendicularMateFeatureData.EntitiesToMate](#).

 Example

See the [IPerpendicularMateFeatureData](#) example.

 Remarks

You can create perpendicular mates with the following mate entity combinations:

Mate entity/Mate entity	IRefAxis (cone, cylinder)	IFace2 (extrusion face, draft is not allowed)	IEdge , IRefAxis , ICenterLine , ISketchLine (line)	IRefPlane	ISurface , IFace2 (non-analytic surface)
IRefAxis (cone, cylinder)	•	•	•		•
IFace2 (extrusion face, draft is not allowed)	•	•	•		
IEdge , IRefAxis , ICenterLine , ISketchLine (line)	•	•	•	•	•
IRefPlane			•	•	
ISurface , IFace2 (non-analytic surface)	•		•		•

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1. You can pre select mate entities during mate creation, but not during mate editing.

 See Also

[IPerpendicularMateFeatureData Interface](#)
[IPerpendicularMateFeatureData Members](#)

 Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PickPoints Property (IPerpendicularMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPerpendicularMateFeatureData Interface](#) : PickPoints Property (IPerpendicularMateFeatureData)

Gets or sets the pick points for the entities to mate in this perpendicular mate.

 .NET Syntax

Visual Basic (Declaration)

Property PickPoints As System.Object

Visual Basic (Usage)



```
Dim instance As IPerpendicularMateFeatureData
Dim value As System.Object

instance.PickPoints = value

value = instance.PickPoints
```

C#

```
System.Object PickPoints {get; set;}
```

C++/CLI

```
property System.Object^ PickPoints {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of x, y, z-coordinates, one set for each mate entity

Visual Basic for Applications (VBA) Syntax

See [PerpendicularMateFeatureData.PickPoints](#).

Remarks

After you set the pick points for a given selection of [IPerpendicularMateFeatureData.EntitiesToMate](#), you cannot modify the pick points. If you want to use new pick points, then you must create an entirely new perpendicular mate.

See Also

[IPerpendicularMateFeatureData Interface](#)
[IPerpendicularMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPlaneManipulator (Type)

IPlaneManipulator Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPlaneManipulator Interface

Allows access to a plane that has a manipulator.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPlaneManipulator
```

Visual Basic (Usage)

```
Dim instance As IPlaneManipulator
```

C#

```
public interface IPlaneManipulator
```

C++/CLI

```
public interface class IPlaneManipulator
```

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

Remarks

An add-in application must create the handler for the manipulator. See [ISwManipulatorHandler2](#) and [Manipulators](#) for details.

Accessors

[IManipulator::GetSpecificManipulator](#)

Access Diagram

[PlaneManipulator](#)

See Also

[IPlaneManipulator Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPlaneManipulator Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPlaneManipulator Interface

The following tables list the members exposed by [IPlaneManipulator](#).

Public Properties

Name	Description
 Color	Gets or sets the color of a plane.
 Distance	Gets or sets the distance to move a plane that has a manipulator.
 Height	Gets or sets the height of a plane that has a manipulator.
 Normal	Gets or sets the normal-to vector for a plane that has a manipulator.
 Origin	Gets or sets the origin of the plane.
 Width	Gets or sets the width of a plane that has a manipulator.
 XAngle	Gets or sets the x coordinate of the angle to use to rotate a plane that has a manipulator.
 YAngle	Gets or sets the y coordinate of the angle to use to rotate a plane that has a manipulator.

[Top](#)

Public Methods

Name	Description
 Update	Updates a plane that has a manipulator after modifying it.

[Top](#)

See Also

[IPlaneManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPlaneManipulator Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPlaneManipulator Interface

For a list of all members of this type, see [IPlaneManipulator members](#).

Public Methods

Name	Description
 Update	Updates a plane that has a manipulator after modifying it.

[Top](#)

See Also

[IPlaneManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPlaneManipulator Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPlaneManipulator Interface

For a list of all members of this type, see [IPlaneManipulator members](#).

Public Properties

Name	Description
 Color	Gets or sets the color of a plane.
 Distance	Gets or sets the distance to move a plane that has a manipulator.
 Height	Gets or sets the height of a plane that has a manipulator.
 Normal	Gets or sets the normal-to vector for a plane that has a manipulator.
 Origin	Gets or sets the origin of the plane.
 Width	Gets or sets the width of a plane that has a manipulator.



[XAngle](#)

Gets or sets the x coordinate of the angle to use to rotate a plane that has a manipulator.



[YAngle](#)

Gets or sets the y coordinate of the angle to use to rotate a plane that has a manipulator.

[Top](#)

See Also

[IPlaneManipulator Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Color Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Color Property (IPlaneManipulator)

Gets or sets the color of a plane.

.NET Syntax

Visual Basic (Declaration)

Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB color for plane

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Color](#).

Example

[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)
[Insert and Use Plane with Manipulator \(VBA\)](#)

See Also

[IPlaneManipulator Interface](#)

[IPlaneManipulator Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Distance Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Distance Property (IPlaneManipulator)

Gets or sets the distance to move a plane that has a manipulator.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance to move a plane that has a manipulator

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Distance](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Height Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Height Property (IPlaneManipulator)

Gets or sets the height of a plane that has a manipulator.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Double

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of a plane that has a manipulator

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Height](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)
[IPlaneManipulator::Width Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Normal Property (IPlaneManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Normal Property (IPlaneManipulator)

Gets or sets the normal-to vector for a plane that has a manipulator.

.NET Syntax

Visual Basic (Declaration)

```
Property Normal As MathVector
```

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As MathVector
```

```
instance.Normal = value
```

```
value = instance.Normal
```

C#

```
MathVector Normal {get; set;}
```

C++/CLI

```
property MathVector^ Normal {  
    MathVector^ get();  
    void set ( & MathVector^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Normal-to vector](#)

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Normal](#).

Remarks

If a plane with a manipulator is already displayed, then do not set a new normal-to vector or [origin](#) for that plane.

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Origin Property (IPlaneManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Origin Property (IPlaneManipulator)

Gets or sets the origin of the plane.

.NET Syntax

Visual Basic (Declaration)

```
Property Origin As MathPoint
```

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As MathPoint
```

```
instance.Origin = value
```

```
value = instance.Origin
```

C#

```
MathPoint Origin {get; set;}
```

C++/CLI

```
property MathPoint^ Origin {
    MathPoint^ get();
    void set ( & MathPoint^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Origin](#)

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Origin](#).

Remarks

If a plane with a manipulator is already displayed, then do not set a new [normal-to vector](#) or origin for that plane.

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Update Method (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Update Method (IPlaneManipulator)

Updates a plane that has a manipulator after modifying it.

.NET Syntax

Visual Basic (Declaration)

```
Function Update() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IPlaneManipulator
Dim value As System.Boolean
```

```
value = instance.Update()
```

C#

```
System.bool Update()
```

C++/CLI

```
System.bool Update();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a plane that has a manipulator is updated after being modified, false if not

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::Update](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Width Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : Width Property (IPlaneManipulator)

Gets or sets the width of a plane that has a manipulator.

.NET Syntax

Visual Basic (Declaration)

Property Width As System.Double

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As System.Double
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.double Width {get; set;}
```

C++/CLI

```
property System.double Width {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width of a plane that has a manipulator

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator.Width](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)

Availability

XAngle Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : XAngle Property (IPlaneManipulator)

Gets or sets the x coordinate of the angle to use to rotate a plane that has a manipulator.

.NET Syntax

Visual Basic (Declaration)

Property XAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IPlaneManipulator  
Dim value As System.Double
```

```
instance.XAngle = value
```

```
value = instance.XAngle
```

C#

```
System.double XAngle {get; set;}
```

C++/CLI

```
property System.double XAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

x coordinate of the angle to use to rotate a plane that has a manipulator

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::XAngle](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)
[IPlaneManipulator::YAngle Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

YAngle Property (IPlaneManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPlaneManipulator Interface](#) : YAngle Property (IPlaneManipulator)

Gets or sets the y coordinate of the angle to use to rotate a plane that has a manipulator.

.NET Syntax

Property YAngle As System.Double

```
Dim instance As IPlaneManipulator  
Dim value As System.Double
```

```
instance.YAngle = value
```

```
value = instance.YAngle
```

```
System.double YAngle {get; set;}
```

```
property System.double YAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

y coordinate of the angle to use to rotate a plane that has a manipulator

Visual Basic for Applications (VBA) Syntax

See [PlaneManipulator::YAngle](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)

See Also

[IPlaneManipulator Interface](#)
[IPlaneManipulator Members](#)
[IPlaneManipulator::XAngle Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

IPLMObjectSpecification (Type)

IPLMObjectSpecification Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPLMObjectSpecification Interface

Allows access to a [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#) document specification.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPLMObjectSpecification
```

Visual Basic (Usage)



```
Dim instance As IPLMObjectSpecification
```

C#

```
public interface IPLMObjectSpecification
```

C++/CLI

```
public interface class IPLMObjectSpecification
```

Visual Basic for Applications (VBA) Syntax

See [PLMObjectSpecification](#).

Example

[Open and Save 3DEXPERIENCE Document \(VBA\)](#)
[Open and Save 3DEXPERIENCE Document \(VB.NET\)](#)
[Open and Save 3DEXPERIENCE Document \(C#\)](#)

Accessors

[IDocumentSpecification::PLMObjectSpecification](#)

Access Diagram

[PLMObjectSpecification](#)

See Also

[IPLMObjectSpecification Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPLMObjectSpecification Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPLMObjectSpecification Interface

The following tables list the members exposed by [IPLMObjectSpecification](#).

Public Properties

Name	Description
 PLMID	Gets or sets the ID of a SOLIDWORKS Design connected to the 3DEXPERIENCE platform document.

[Top](#)

See Also

[IPLMObjectSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPLMObjectSpecification Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPLMObjectSpecification Interface

For a list of all members of this type, see [IPLMObjectSpecification members](#).

Public Properties

Name	Description
 PLMID	Gets or sets the ID of a SOLIDWORKS Design connected to the 3DEXPERIENCE platform document.

[Top](#)

See Also

[IPLMObjectSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

PLMID Property (IPLMObjectSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPLMObjectSpecification Interface](#) : PLMID Property (IPLMObjectSpecification)

Gets or sets the ID of a [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#) document.

.NET Syntax

Visual Basic (Declaration)

Property PLMID As System.String

Visual Basic (Usage)



```
Dim instance As IPLMObjectSpecification
Dim value As System.String

instance.PLMID = value

value = instance.PLMID
```

C#

```
System.string PLMID {get; set;}
```

C++/CLI

```
property System.String^ PLMID {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Document ID

Visual Basic for Applications (VBA) Syntax

See [PLMObjectSpecification::PLMID](#).

Example

See the [IPLMObjectSpecification](#) examples.

See Also

[IPLMObjectSpecification Interface](#)
[IPLMObjectSpecification Members](#)

Availability

SOLIDWORKS 2020 SP3.1, Revision Number 28.3.1

IPMIDatumData (Type)

IPMIDatumData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumData Interface

Allows access to the Product and Manufacturing Information (PMI) for a datum annotation in a STEP 242 model.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IPMIDatumData

Visual Basic (Usage)

Dim instance As [IPMIDatumData](#)

C#

public interface IPMIDatumData

C++/CLI

public interface class IPMIDatumData

Visual Basic for Applications (VBA) Syntax

See [PMIDatumData](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This interface is valid only if [IAnnotation::GetPMIType](#) returns [swPMIType_e.swPMIType_Datum](#).

Accessors

[IAnnotation::GetPMIData](#)

Access Diagram

[PMIDatumData](#)

See Also

[IPMIDatumData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDimensionData Interface](#)
[IPMIGtolData Interface](#)

IPMIDatumData Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumData Interface

The following tables list the members exposed by [IPMIDatumData](#).

Public Methods

Name	Description
 GetDatumFeature	Gets the PMI datum feature.
 GetDatumTarget	Gets the PMI datum target.
 GetDatumType	Gets the PMI datum type.

[Top](#)

 See Also

[IPMIDatumData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDimensionData Interface](#)
[IPMIGtolData Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IPMIDatumData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumData Interface

For a list of all members of this type, see [IPMIDatumData members](#).

 Public Methods

Name	Description
 GetDatumFeature	Gets the PMI datum feature.
 GetDatumTarget	Gets the PMI datum target.
 GetDatumType	Gets the PMI datum type.

[Top](#)

 See Also

[IPMIDatumData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDimensionData Interface](#)
[IPMIGtolData Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

GetDatumFeature Method (IPMIDatumData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumData Interface](#) : GetDatumFeature Method (IPMIDatumData)

Gets the PMI datum feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetDatumFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumData  
Dim value As System.Object  
  
value = instance.GetDatumFeature()
```

C#

```
System.object GetDatumFeature()
```

C++/CLI

```
System.Object^ GetDatumFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Visual Basic for Applications (VBA) Syntax

See [PMIDatumData::GetDatumFeature](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This method is valid only if [IPMIDatumData::GetDatumType](#) returns [swPMIDatumType_e.swPMIDatumType_DatumFeature](#).

See Also

[IPMIDatumData Interface](#)
[IPMIDatumData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDatumTarget Method (IPMIDatumData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumData Interface](#) : GetDatumTarget Method (IPMIDatumData)

Gets the PMI datum target.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTarget() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumData  
Dim value As System.Object  
  
value = instance.GetDatumTarget()
```

C#

```
System.Object GetDatumTarget()
```

C++/CLI

```
System.Object^ GetDatumTarget();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPMIDatumTarget](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumData::GetDatumTarget](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This method is valid only if [IPMIDatumData::GetDatumType](#) returns [swPMIDatumType_e.swPMIDatumType_DatumTarget](#).

See Also

[IPMIDatumData Interface](#)
[IPMIDatumData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumType Method (IPMIDatumData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumData Interface](#) : GetDatumType Method (IPMIDatumData)

Gets the PMI datum type.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumData  
Dim value As System.Integer  
  
value = instance.GetDatumType()
```

C#

```
System.int GetDatumType()
```

C++/CLI

```
System.int GetDatumType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

PMI datum type as defined in [swPMIDatumType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumData::GetDatumType](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumData Interface](#)
[IPMIDatumData Members](#)
[IPMIDatumData::GetDatumFeature Method \(\)](#)
[IPMIDatumData::GetDatumTarget Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIDatumFeature (Type)

IPMIDatumFeature Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumFeature Interface

Allows access to a Product and Manufacturing Information (PMI) datum feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPMIDatumFeature
```

Visual Basic (Usage)

```
Dim instance As IPMIDatumFeature
```

C#

```
public interface IPMIDatumFeature
```

C++/CLI

```
public interface class IPMIDatumFeature
```

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

A PMI datum consists of a label in a square or round symbol. Leader and text are optional.

Accessors

[IPMIDatumData::GetDatumFeature](#)

Access Diagram

[PMIDatumFeature](#)

See Also

[IPMIDatumFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDatumFeature Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumFeature Interface

The following tables list the members exposed by [IPMIDatumFeature](#).

Public Properties

Name	Description
------	-------------

 Label	Gets the non-numeric label of this PMI datum. NOTE: This property is a get-only property. Set is not implemented.
 LeaderAnchorStyle	Gets the PMI datum leader anchor style. NOTE: This property is a get-only property. Set is not implemented.
 LeaderBendLength	Gets the length of the unbent portion of the leader to this PMI datum. NOTE: This property is a get-only property. Set is not implemented.
 Shape	Gets the PMI datum shape. NOTE: This property is a get-only property. Set is not implemented.
 Text	Gets the PMI datum text. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[IPMIDatumFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDatumFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumFeature Interface

For a list of all members of this type, see [IPMIDatumFeature members](#).

 Public Properties

Name	Description
 Label	Gets the non-numeric label of this PMI datum. NOTE: This property is a get-only property. Set is not implemented.
 LeaderAnchorStyle	Gets the PMI datum leader anchor style. NOTE: This property is a get-only property. Set is not implemented.
 LeaderBendLength	Gets the length of the unbent portion of the leader to this PMI datum. NOTE: This property is a get-only property. Set is not implemented.
 Shape	Gets the PMI datum shape. NOTE: This property is a get-only property. Set is not implemented.
 Text	Gets the PMI datum text. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[IPMIDatumFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Label Property (IPMIDatumFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumFeature Interface](#) : Label Property (IPMIDatumFeature)

Gets the non-numeric label of this PMI datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Label As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumFeature  
Dim value As System.String
```

```
instance.Label = value
```

```
value = instance.Label
```

C#

```
System.string Label {get; set;}
```

C++/CLI

```
property System.String^ Label {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Datum label

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature.Label](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumFeature Interface](#)
[IPMIDatumFeature Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderAnchorStyle Property (IPMIDatumFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumFeature Interface](#) : LeaderAnchorStyle Property (IPMIDatumFeature)

Gets the PMI datum leader anchor style.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderAnchorStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumFeature
Dim value As System.Integer

instance.LeaderAnchorStyle = value
value = instance.LeaderAnchorStyle
```

C#

```
System.int LeaderAnchorStyle {get; set;}
```

C++/CLI

```
property System.int LeaderAnchorStyle {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

PMI datum leader anchor style as defined in [swPMIDatumAnchorStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature::LeaderAnchorStyle](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumFeature Interface](#)
[IPMIDatumFeature Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderBendLength Property (IPMIDatumFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumFeature Interface](#) : LeaderBendLength Property (IPMIDatumFeature)

Gets the length of the unbent portion of the leader to this PMI datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderBendLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumFeature
Dim value As System.Double

instance.LeaderBendLength = value
value = instance.LeaderBendLength
```

C#

```
System.double LeaderBendLength {get; set;}
```

C++/CLI

```
property System.double LeaderBendLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of the unbent portion of the PMI datum leader

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature::LeaderBendLength](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumFeature Interface](#)
[IPMIDatumFeature Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Shape Property (IPMIDatumFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumFeature Interface](#) : Shape Property (IPMIDatumFeature)

Gets the PMI datum shape.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Shape As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPMIDatumFeature  
Dim value As System.Integer
```

```
instance.Shape = value
```

```
value = instance.Shape
```

C#

```
System.int Shape {get; set;}
```

C++/CLI

```
property System.int Shape {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).



Property Value

PMI datum shape as defined in [swPMIDatumShape_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature::Shape](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumFeature Interface](#)
[IPMIDatumFeature Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

Text Property (IPMIDatumFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumFeature Interface](#) : Text Property (IPMIDatumFeature)

Gets the PMI datum text.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Text As System.String

Visual Basic (Usage)



```
Dim instance As IPMIDatumFeature  
Dim value As System.String
```

```
instance.Text = value
```

```
value = instance.Text
```

C#

```
System.string Text {get; set;}
```

C++/CLI

```
property System.String^ Text {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

PMI datum text

Visual Basic for Applications (VBA) Syntax

See [PMIDatumFeature::Text](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumFeature Interface](#)
[IPMIDatumFeature Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0