

SOLIDWORKS API (.NET VBA C#) — Reference (224/337): IPMIDatumTarget-IPMIFrameData

SOLIDWORKS API Documentation (converted from CHM)

IPMIDatumTarget (Type)

IPMIDatumTarget Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumTarget Interface

Allows access to a Product and Manufacturing Information (PMI) datum target.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IPMIDatumTarget

Visual Basic (Usage)



Dim instance As [IPMIDatumTarget](#)

C#

public interface IPMIDatumTarget

C++/CLI

public interface class IPMIDatumTarget

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

A PMI datum target consists of a target symbol and a target area.

Accessors

[IPMIDatumData::GetDatumTarget](#)

Access Diagram

[PMIDatumTarget](#)

See Also

[IPMIDatumTarget Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDatumTarget Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumTarget Interface

For a list of all members of this type, see [IPMIDatumTarget members](#).

Public Methods

Name	Description
GetDatumTargetReferences	Gets the datum references for this PMI datum target.



[Top](#)

See Also

[IPMIDatumTarget Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIDatumTarget Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumTarget Interface

The following tables list the members exposed by [IPMIDatumTarget](#).

Public Properties

Name	Description
 AreaStyle	Gets the area style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Diameter	Gets the PMI datum target diameter. NOTE: This property is a get-only property. Set is not implemented.
 Height	Gets the PMI datum target height. NOTE: This property is a get-only property. Set is not implemented.
 MovableStyle	Gets the movable style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 SymbolStyle	Gets the symbol style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Unit	Gets the units for the values of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Width	Gets the PMI datum target width. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 GetDatumTargetReferences	Gets the datum references for this PMI datum target.

[Top](#)

See Also

[IPMIDatumTarget Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIDatumTarget Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDatumTarget Interface

For a list of all members of this type, see [IPMIDatumTarget members](#).

Public Properties

Name	Description
 AreaStyle	Gets the area style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Diameter	Gets the PMI datum target diameter. NOTE: This property is a get-only property. Set is not implemented.
 Height	Gets the PMI datum target height. NOTE: This property is a get-only property. Set is not implemented.
 MovableStyle	Gets the movable style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 SymbolStyle	Gets the symbol style of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Unit	Gets the units for the values of this PMI datum target. NOTE: This property is a get-only property. Set is not implemented.
 Width	Gets the PMI datum target width. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIDatumTarget Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AreaStyle Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : AreaStyle Property (IPMIDatumTarget)

Gets the area style of this PMI datum target.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property AreaStyle As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPMIDatumTarget
Dim value As System.Integer

instance.AreaStyle = value
value = instance.AreaStyle
```

C#

```
System.int AreaStyle {get; set;}
```

C++/CLI

```
property System.int AreaStyle {
    System.int get();
    void set ( & System.int value);
}
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Target area as defined in [swPMIDatumTargetAreaStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::AreaStyle](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)
[IPMIDatumTarget::Diameter Property \(\)](#)
[IPMIDatumTarget::Height Property \(\)](#)
[IPMIDatumTarget::Width Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Diameter Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : Diameter Property (IPMIDatumTarget)

Gets the PMI datum target diameter.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Diameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Double
```

```
instance.Diameter = value
```

```
value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Datum target diameter

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::Diameter](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDatumTarget::AreaStyle](#) is set to [swPMIDatumTargetAreaStyle_e.swPMIDatumTargetAreaStyle_X](#) or [swPMIDatumTargetAreaStyle_Circular](#).

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)
[IPMIDatumTarget::Unit Property\(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDatumTargetReferences Method (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : GetDatumTargetReferences Method (IPMIDatumTarget)

Gets the datum references for this PMI datum target.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumTargetReferences() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Object  
  
value = instance.GetDatumTargetReferences()
```

C#

```
System.object GetDatumTargetReferences()
```

C++/CLI

```
System.Object^ GetDatumTargetReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of datum string references (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::GetDatumTargetReferences](#).

Remarks

The datum references appear in the lower half of the datum target symbols.

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : Height Property (IPMIDatumTarget)

Gets the PMI datum target height.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Double

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Datum target height

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget.Height](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDatumTarget::AreaStyle](#) is set to [swPMIDatumTargetAreaStyle_e.swPMIDatumTargetAreaStyle_Rectangular](#).

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)
[IPMIDatumTarget::Unit Property\(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MovableStyle Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : MovableStyle Property (IPMIDatumTarget)

Gets the movable style of this PMI datum target.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property MovableStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Integer
```

```
instance.MovableStyle = value
```

```
value = instance.MovableStyle
```

C#

```
System.int MovableStyle {get; set;}
```

C++/CLI

```
property System.int MovableStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Movable style as defined in [swPMIDatumTargetMovableStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::MovableStyle](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SymbolStyle Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : SymbolStyle Property (IPMIDatumTarget)

Gets the symbol style of this PMI datum target.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property SymbolStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Integer
```

```
instance.SymbolStyle = value
```

```
value = instance.SymbolStyle
```

C#

```
System.int SymbolStyle {get; set;}
```

C++/CLI

```
property System.int SymbolStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Symbol style as defined in [swPMIDatumTargetSymbolStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::SymbolStyle](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Unit Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : Unit Property (IPMIDatumTarget)

Gets the units for the values of this PMI datum target.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Unit As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Integer
```

```
instance.Unit = value
```

```
value = instance.Unit
```

C#

```
System.int Unit {get; set;}
```

C++/CLI

```
property System.int Unit {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Units as defined in [swPMIUnit_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget::Unit](#).

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)
[IPMIDatumTarget::Diameter Property \(\)](#)
[IPMIDatumTarget::Height Property \(\)](#)
[IPMIDatumTarget::Width Property \(\)](#)
[IPMIDatumTarget::DiameterPrecision Property \(\)](#)
[IPMIDatumTarget::HeightPrecision Property \(\)](#)
[IPMIDatumTarget::WidthPrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (IPMIDatumTarget)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDatumTarget Interface](#) : Width Property (IPMIDatumTarget)

Gets the PMI datum target width.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Width As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIDatumTarget  
Dim value As System.Double
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.double Width {get; set;}
```

C++/CLI

```
property System.double Width {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Datum target width

Visual Basic for Applications (VBA) Syntax

See [PMIDatumTarget.Width](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDatumTarget::AreaStyle](#) is set to [swPMIDatumTargetAreaStyle_e.swPMIDatumTargetAreaStyle_Rectangular](#).

See Also

[IPMIDatumTarget Interface](#)
[IPMIDatumTarget Members](#)
[IPMIDatumTarget::Unit Property\(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIDimensionData (Type)

IPMIDimensionData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionData Interface

Allows access to the Product and Manufacturing Information (PMI) for a dimension annotation in a STEP 242 model.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPMIDimensionData
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionData
```

C#

```
public interface IPMIDimensionData
```

C++/CLI

```
public interface class IPMIDimensionData
```

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionData](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This interface is valid only if [IAnnotation::GetPMIType](#) returns [swPMIType_e.swPMIType_Dimension](#).

Accessors

[IAnnotation::GetPMIData](#)

Access Diagram

[PMIDimensionData](#)

See Also

[IPMIDimensionData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIGtolData Interface](#)

IPMIDimensionData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionData Interface

For a list of all members of this type, see [IPMIDimensionData members](#).

Public Methods

Name	Description
 GetDimensionItemAtIndex	Gets the PMI dimension item at the specified index.
 GetDimensionItemCount	Gets the number of dimension items in this PMI dimension annotation.

[Top](#)

See Also

[IPMIDimensionData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIGtolData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIDimensionData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionData Interface

The following tables list the members exposed by [IPMIDimensionData](#).

Public Properties

Name	Description
 DimensionText	Gets the text of this PMI dimension. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 GetDimensionItemAtIndex	Gets the PMI dimension item at the specified index.
 GetDimensionItemCount	Gets the number of dimension items in this PMI dimension annotation.

[Top](#)

See Also

[IPMIDimensionData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIGtolData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIDimensionData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionData Interface

For a list of all members of this type, see [IPMIDimensionData members](#).

Public Properties

Name	Description
 DimensionText	Gets the text of this PMI dimension. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIDimensionData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIGtolData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DimensionText Property (IPMIDimensionData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionData Interface](#) : DimensionText Property (IPMIDimensionData)

Gets the text of this PMI dimension.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DimensionText As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionData  
Dim value As System.String
```

```
instance.DimensionText = value
```

```
value = instance.DimensionText
```

C#

```
System.string DimensionText {get; set;}
```

C++/CLI

```
property System.String^ DimensionText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Dimension text

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionData::DimensionText](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionData Interface](#)
[IPMIDimensionData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionItemAtIndex Method (IPMIDimensionData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionData Interface](#) : GetDimensionItemAtIndex Method (IPMIDimensionData)

Gets the PMI dimension item at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionItemAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionData  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetDimensionItemAtIndex(Index)
```

C#

```
System.object GetDimensionItemAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetDimensionItemAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Zero-based index of the dimension item to get

Return Value

[IPMIDimensionItem](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionData::GetDimensionItemAtIndex](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIDimensionData::GetDimensionItemCount](#) to set Index.

See Also

[IPMIDimensionData Interface](#)
[IPMIDimensionData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionItemCount Method (IPMIDimensionData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionData Interface](#) : GetDimensionItemCount Method (IPMIDimensionData)

Gets the number of dimension items in this PMI dimension annotation.

.NET Syntax

Visual Basic (Declaration)

Function GetDimensionItemCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIDimensionData  
Dim value As System.Integer  
  
value = instance.GetDimensionItemCount()
```

C#

```
System.int GetDimensionItemCount()
```

C++/CLI

```
System.int GetDimensionItemCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of dimension items

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionData::GetDimensionItemCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionData Interface](#)
[IPMIDimensionData Members](#)
[IPMIDimensionData::GetDimensionItemAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIDimensionItem (Type)

IPMIDimensionItem Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionItem Interface

Allows access to a Product and Manufacturing Information (PMI) dimension item.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPMIDimensionItem
```

Visual Basic (Usage)

```
Dim instance As IPMIDimensionItem
```

C#

```
public interface IPMIDimensionItem
```

C++/CLI

```
public interface class IPMIDimensionItem
```

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This API does not yet support the fit tolerance information typically associated with shafts in holes, such as classification, hole fit, and shaft fit.

If [IPMIDimensionItem::TolType](#) returns [swTolType_e](#):

- [swTolFIT](#)
- [swTolFITONLY](#)
- [swTolFITWITHTOL](#)

then no classification, hole fit, or shaft fit data is available through this API.

Accessors

[IPMIDimensionData::GetDimensionItemAtIndex](#)

Access Diagram

[PMIDimensionItem](#)

See Also

[IPMIDimensionItem Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDimensionItem Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionItem Interface

The following tables list the members exposed by [IPMIDimensionItem](#).

Public Properties

Name	Description
 AdditionalSymbol	Gets the tolerance zone modifier for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 CalloutText	Gets the callout value for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 InstanceCount	Gets the instance count of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 MaxVariation	Gets the maximum variation of tolerance for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 MinVariation	Gets the minimum variation of tolerance for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Prefix	Gets the prefix of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Suffix	Gets the suffix of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Symbol	Gets the dimension symbols for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 TolerancePrecision	Gets the tolerance precision of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 TolType	Gets the tolerance type of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Unit	Gets the units of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Value	Gets the primary value of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 ValuePrecision	Gets the value precision of this dimension item. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 IsReferenceOnly	Gets whether this PMI dimension is reference only. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIDimensionItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDimensionItem Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionItem Interface

For a list of all members of this type, see [IPMIDimensionItem members](#).

Public Methods

Name	Description
 IsReferenceOnly	Gets whether this PMI dimension is reference only. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIDimensionItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIDimensionItem Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IPMIDimensionItem Interface

For a list of all members of this type, see [IPMIDimensionItem members](#).

Public Properties

Name	Description
 AdditionalSymbol	Gets the tolerance zone modifier for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 CalloutText	Gets the callout value for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 InstanceCount	Gets the instance count of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 MaxVariation	Gets the maximum variation of tolerance for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 MinVariation	Gets the minimum variation of tolerance for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Prefix	Gets the prefix of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Suffix	Gets the suffix of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 Symbol	Gets the dimension symbols for this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 TolerancePrecision	Gets the tolerance precision of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.
 TolType	Gets the tolerance type of this PMI dimension item. NOTE: This property is a get-only property. Set is not implemented.



[Unit](#)

Gets the units of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.



[Value](#)

Gets the primary value of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.



[ValuePrecision](#)

Gets the value precision of this dimension item.

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIDimensionItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AdditionalSymbol Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : AdditionalSymbol Property (IPMIDimensionItem)

Gets the tolerance zone modifier for this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property AdditionalSymbol As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem
Dim value As System.Integer
```

```
instance.AdditionalSymbol = value
```

```
value = instance.AdditionalSymbol
```

C#

```
System.int AdditionalSymbol {get; set;}
```

C++/CLI

```
property System.int AdditionalSymbol {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance zone modifier as defined in [swToleranceZoneModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::AdditionalSymbol](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CalloutText Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : CalloutText Property (IPMIDimensionItem)

Gets the callout value for this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property CalloutText As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.String
```

```
instance.CalloutText = value
```

```
value = instance.CalloutText
```

C#

```
System.string CalloutText {get; set;}
```

C++/CLI

```
property System.String^ CalloutText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Callout value

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::CalloutText](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InstanceCount Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : InstanceCount Property (IPMIDimensionItem)

Gets the instance count of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property InstanceCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer
```

```
instance.InstanceCount = value
```

```
value = instance.InstanceCount
```

C#

```
System.int InstanceCount {get; set;}
```

C++/CLI

```
property System.int InstanceCount {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances of this dimension item

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::InstanceCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsReferenceOnly Method (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : IsReferenceOnly Method (IPMIDimensionItem)

Gets whether this PMI dimension is reference only.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Function IsReferenceOnly() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem
Dim value As System.Boolean

value = instance.IsReferenceOnly()
```

C#

```
System.bool IsReferenceOnly()
```

C++/CLI

```
System.bool IsReferenceOnly();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this PMI dimension is reference-only, false if not

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::IsReferenceOnly](#).

Remarks

If this method returns true, then this dimension item is used for information purposes only. It does not govern production or inspection operations.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaxVariation Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : MaxVariation Property (IPMIDimensionItem)

Gets the maximum variation of tolerance for this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property MaxVariation As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem
Dim value As System.Double

instance.MaxVariation = value

value = instance.MaxVariation
```

C#

```
System.double MaxVariation {get; set;}
```

C++/CLI

```
property System.double MaxVariation {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum variation of tolerance

Visual Basic for Applications (VBA) Syntax

See [IPMIDimensionItem::MaxVariation](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDimensionItem::TolType](#) returns [swTolType_e](#):

- swTolBILAT
- swTolLIMIT
- swTolSYMMETRIC
- swTolFITWITHTOL
- swTolFITTOONLY

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::Unit Property \(\)](#)
[IPMIDimensionItem::TolerancePrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MinVariation Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : MinVariation Property (IPMIDimensionItem)

Gets the minimum variation of tolerance for this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property MinVariation As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Double  
  
instance.MinVariation = value  
  
value = instance.MinVariation
```

C#

```
System.double MinVariation {get; set;}
```

C++/CLI

```
property System.double MinVariation {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum variation of tolerance

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::MinVariation](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDimensionItem::TolType](#) returns [swTolType_e](#):

- swTolBILAT
- swTolLIMIT
- swTolFITWITHTOL
- swTolFITTOLONLY

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::Unit Property \(\)](#)
[IPMIDimensionItem::TolerancePrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Prefix Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : Prefix Property (IPMIDimensionItem)

Gets the prefix of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Prefix As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.String
```

```
instance.Prefix = value
```

```
value = instance.Prefix
```

C#

```
System.string Prefix {get; set;}
```

C++/CLI

```
property System.String^ Prefix {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Prefix

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::Prefix](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Suffix Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : Suffix Property (IPMIDimensionItem)

Gets the suffix of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Suffix As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.String
```

```
instance.Suffix = value
```

```
value = instance.Suffix
```

C#

```
System.string Suffix {get; set;}
```

C++/CLI

```
property System.String^ Suffix {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Suffix

Visual Basic for Applications (VBA) Syntax

See [IPMIDimensionItem::Suffix](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Symbol Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : Symbol Property (IPMIDimensionItem)

Gets the dimension symbols for this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Symbol As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer
```

```
instance.Symbol = value
```

```
value = instance.Symbol
```

C#

```
System.int Symbol {get; set;}
```

C++/CLI

```
property System.int Symbol {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of dimension symbols as defined in [swDimensionSymbol_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::Symbol](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolerancePrecision Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : TolerancePrecision Property (IPMIDimensionItem)

Gets the tolerance precision of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property TolerancePrecision As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer  
  
instance.TolerancePrecision = value  
  
value = instance.TolerancePrecision
```

C#

```
System.int TolerancePrecision {get; set;}
```

C++/CLI

```
property System.int TolerancePrecision {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance precision

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::TolerancePrecision](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIDimensionItem::TolType](#) does not return [swTolType_e.swTolNONE](#).

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::TolType Property \(\)](#)
[IPMIDimensionItem::Unit Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolType Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : TolType Property (IPMIDimensionItem)

Gets the tolerance type of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property TolType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer
```

```
instance.TolType = value
```

```
value = instance.TolType
```

C#

```
System.int TolType {get; set;}
```

C++/CLI

```
property System.int TolType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance type as defined in [swTolType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::TolType](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::MaxVariation Property \(\)](#)
[IPMIDimensionItem::MinVariation Property \(\)](#)
[IPMIDimensionItem::TolerancePrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Unit Property (IPMIDimensionItem)

[See Also](#)



Gets the units of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Unit As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer
```

```
instance.Unit = value
```

```
value = instance.Unit
```

C#

```
System.int Unit {get; set;}
```

C++/CLI

```
property System.int Unit {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Units of dimension as defined in [swPMIUnit_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::Unit](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::Value Property \(\)](#)
[IPMIDimensionItem::MaxVariation Property \(\)](#)
[IPMIDimensionItem::MinVariation Property \(\)](#)
[IPMIDimensionItem::TolerancePrecision Property \(\)](#)
[IPMIDimensionItem::ValuePrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

Value Property (IPMIDimensionItem)

[See Also](#)



Gets the primary value of this PMI dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Value As System.Double

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Double
```

```
instance.Value = value
```

```
value = instance.Value
```

C#

```
System.double Value {get; set;}
```

C++/CLI

```
property System.double Value {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Primary value of this PMI dimension item

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::Value](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::ValuePrecision Property \(\)](#)
[IPMIDimensionItem::Unit Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ValuePrecision Property (IPMIDimensionItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIDimensionItem Interface](#) : ValuePrecision Property (IPMIDimensionItem)

Gets the value precision of this dimension item.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property ValuePrecision As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIDimensionItem  
Dim value As System.Integer
```

```
instance.ValuePrecision = value
```

```
value = instance.ValuePrecision
```

C#

```
System.int ValuePrecision {get; set;}
```

C++/CLI

```
property System.int ValuePrecision {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Value](#) precision

Visual Basic for Applications (VBA) Syntax

See [PMIDimensionItem::ValuePrecision](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIDimensionItem Interface](#)
[IPMIDimensionItem Members](#)
[IPMIDimensionItem::Unit Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIFrameData (Type)

IPMIFrameData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIFrameData Interface

Allows access to a Product and Manufacturing Information (PMI) Gtol frame.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPMIFrameData
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData
```

C#

```
public interface IPMIFrameData
```

C++/CLI

```
public interface class IPMIFrameData
```

Visual Basic for Applications (VBA) Syntax

See [PMIFrameData](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Accessors

[IPMIGtolData::GetFrameAtIndex](#)

Access Diagram

[PMIFrameData](#)

See Also

[IPMIFrameData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIFrameData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIFrameData Interface

The following tables list the members exposed by [IPMIFrameData](#).

Public Properties

Name	Description
 FrameNumber	Gets the index of this Gtol frame. NOTE: This property is a get-only property. Set is not implemented.
 GeometricCharacteristic	Gets the geometric characteristic of this Gtol frame.

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 GetGtolBoxAtIndex	Gets the specified tolerance box in this Gtol frame.
 GetGtolBoxCount	Gets the number of tolerance boxes in this Gtol frame.
 GetGtolDatumAtIndex	Gets the specified datum box in this Gtol frame.
 GetGtolDatumCount	Gets the number of datum boxes in this Gtol frame.

[Top](#)

See Also

[IPMIFrameData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIFrameData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIFrameData Interface

For a list of all members of this type, see [IPMIFrameData members](#).

Public Methods

Name	Description
 GetGtolBoxAtIndex	Gets the specified tolerance box in this Gtol frame.
 GetGtolBoxCount	Gets the number of tolerance boxes in this Gtol frame.
 GetGtolDatumAtIndex	Gets the specified datum box in this Gtol frame.
 GetGtolDatumCount	Gets the number of datum boxes in this Gtol frame.

[Top](#)

See Also

[IPMIFrameData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIFrameData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIFrameData Interface

For a list of all members of this type, see [IPMIFrameData members](#).

Public Properties

Name	Description
 FrameNumber	Gets the index of this Gtol frame. NOTE: This property is a get-only property. Set is not implemented.
 GeometricCharacteristic	Gets the geometric characteristic of this Gtol frame. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

FrameNumber Property (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : FrameNumber Property (IPMIFrameData)

Gets the index of this Gtol frame.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameNumber As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData  
Dim value As System.Integer
```

```
instance.FrameNumber = value
```

```
value = instance.FrameNumber
```

C#

```
System.int FrameNumber {get; set;}
```

C++/CLI

```
property System.int FrameNumber {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Zero-based index of this Gtol frame

Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::FrameNumber](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

GeometricCharacteristic Property (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : GeometricCharacteristic Property (IPMIFrameData)

Gets the geometric characteristic of this Gtol frame.

NOTE: This property is a get-only property. Set is not implemented.

Visual Basic Syntax

Visual Basic (Declaration)

Property GeometricCharacteristic As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIFrameData
Dim value As System.Integer

instance.GeometricCharacteristic = value
value = instance.GeometricCharacteristic
```

C#

```
System.int GeometricCharacteristic {get; set;}
```

C++/CLI

```
property System.int GeometricCharacteristic {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Geometric characteristic as defined in [swGeometricCharacteristic](#) e

Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::GeometricCharacteristic](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGtolBoxAtIndex Method (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : GetGtolBoxAtIndex Method (IPMIFrameData)

Gets the specified tolerance box in this Gtol frame.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetGtolBoxAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetGtolBoxAtIndex(Index)
```

C#

```
System.Object GetGtolBoxAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetGtolBoxAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0 <= Gtol frame box index <= 2

Return Value

[IPMIGtolBoxData](#)

Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::GetGtolBoxAtIndex](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIFrameData::GetGtolBoxCount](#) to determine Index.

See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGtolBoxCount Method (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : GetGtolBoxCount Method (IPMIFrameData)

Gets the number of tolerance boxes in this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGtolBoxCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData
Dim value As System.Integer
```

```
value = instance.GetGtolBoxCount()
```

C#

```
System.int GetGtolBoxCount()
```

C++/CLI

```
System.int GetGtolBoxCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of Gtol tolerance boxes

Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::GetGtolBoxCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGtolDatumAtIndex Method (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : GetGtolDatumAtIndex Method (IPMIFrameData)

Gets the specified datum box in this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGtolDatumAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData  
Dim Index As System.Integer  
Dim value As System.Object
```

```
value = instance.GetGtolDatumAtIndex(Index)
```

C#

```
System.object GetGtolDatumAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetGtolDatumAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0 <= Gtol frame datum index <= 2

Return Value

[IPMIGtolFrameDatum](#)

 Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::GetGtolDatumAtIndex](#).

 Example

See the [IAnnotation::GetPMIData](#) example.

 Remarks

Use [IPMIFrameData::GetGtolDatumCount](#) to determine Index.

 See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

 Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

GetGtolDatumCount Method (IPMIFrameData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIFrameData Interface](#) : GetGtolDatumCount Method (IPMIFrameData)

Gets the number of datum boxes in this Gtol frame.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetGtolDatumCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIFrameData  
Dim value As System.Integer  
  
value = instance.GetGtolDatumCount()
```

C#

```
System.int GetGtolDatumCount()
```

C++/CLI

```
System.int GetGtolDatumCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of Gtol datum boxes

 Visual Basic for Applications (VBA) Syntax

See [PMIFrameData::GetGtolDatumCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIFrameData Interface](#)
[IPMIFrameData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0