

SOLIDWORKS API (.NET VBA C#) — Reference

(225/337): IPMIGtoIBoxData- IPrimaryMemberFacePlaneIntersectionFeatu

SOLIDWORKS API Documentation (converted from CHM)

IPMIGtolBoxData (Type)

IPMIGtolBoxData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolBoxData Interface

Allows access to a Product and Manufacturing Information (PMI) Gtol tolerance box.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

```
Public Interface IPMIGtolBoxData
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData
```

C#

```
public interface IPMIGtolBoxData
```

C++/CLI

```
public interface class IPMIGtolBoxData
```

 Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData](#).

 Example

See the [IAnnotation::GetPMIData](#) example.

 Accessors

[IPMIFrameData::GetGtolBoxAtIndex](#)

 Access Diagram

[PMIGtolBoxData](#)

 See Also

[IPMIGtolBoxData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIGtolBoxData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolBoxData Interface

For a list of all members of this type, see [IPMIGtolBoxData members](#).

 Public Methods

Name	Description
 GetAdditionalSymbols	Gets additional material conditions in this PMI Gtol frame box.
 GetTolTypes	Gets the tolerance zone types in this PMI Gtol frame box.
 GetTolTypeValues	Gets the tolerance zone values in this PMI Gtol frame box.

[Top](#)

 See Also

[IPMIGtolBoxData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIGtolBoxData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolBoxData Interface

The following tables list the members exposed by [IPMIGtolBoxData](#).

Public Properties

Name	Description
MaterialModifier	Gets the material condition for this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolerancePerUnitType	Gets the tolerance per unit area type in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolerancePerUnitValue1	Gets the tolerance 1 per unit area value in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolerancePerUnitValue2	Gets the tolerance 2 per unit area in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
ToleranceZoneModifier	Gets the tolerance zone modifier in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolValue	Gets the tolerance value in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
Unit	Gets the units of tolerance for this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
GetAdditionalSymbols	Gets additional material conditions in this PMI Gtol frame box.
GetTolTypes	Gets the tolerance zone types in this PMI Gtol frame box.
GetTolTypeValues	Gets the tolerance zone values in this PMI Gtol frame box.

[Top](#)

See Also

[IPMIGtolBoxData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIGtolBoxData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolBoxData Interface

For a list of all members of this type, see [IPMIGtolBoxData members](#).

Public Properties

Name	Description
MaterialModifier	Gets the material condition for this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolerancePerUnitType	Gets the tolerance per unit area type in this PMI Gtol frame box. NOTE: This property is a get-only property. Set is not implemented.
TolerancePerUnitValue1	Gets the tolerance 1 per unit area value in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.



[TolerancePerUnitValue2](#)

Gets the tolerance 2 per unit area in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.



[ToleranceZoneModifier](#)

Gets the tolerance zone modifier in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.



[TolValue](#)

Gets the tolerance value in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.



[Unit](#)

Gets the units of tolerance for this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIGtolBoxData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAdditionalSymbols Method (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : GetAdditionalSymbols Method (IPMIGtolBoxData)

Gets additional material conditions in this PMI Gtol frame box.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAdditionalSymbols() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Object  
  
value = instance.GetAdditionalSymbols()
```

C#

```
System.object GetAdditionalSymbols()
```

C++/CLI

```
System.Object^ GetAdditionalSymbols();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of material conditions as defined in [swAdditionalSymbol_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::GetAdditionalSymbols](#).

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::MaterialModifier Property_0](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTolTypes Method (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : GetTolTypes Method (IPMIGtolBoxData)

Gets the tolerance zone types in this PMI Gtol frame box.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTolTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Object  
  
value = instance.GetTolTypes()
```

C#

```
System.object GetTolTypes()
```

C++/CLI

```
System.Object^ GetTolTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of tolerance zone types as defined in [swGtolType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::GetTolTypes](#).

Remarks

The tolerance zone types returned by this method map on-to-one and onto with tolerance zone values returned by [IPMIGtolBoxData::GetTolTypeValues](#).

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTolTypeValues Method (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : GetTolTypeValues Method (IPMIGtolBoxData)

Gets the tolerance zone values in this PMI Gtol frame box.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTolTypeValues() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Object  
  
value = instance.GetTolTypeValues()
```

C#

```
System.object GetTolTypeValues()
```

C++/CLI

```
System.Object^ GetTolTypeValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of tolerance zone values

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolBoxData::GetTolTypeValues](#).

Remarks

The array returned by this method maps one-to-one and onto with the array returned by [IPMIGtolBoxData::GetTolTypes](#).

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::Unit Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaterialModifier Property (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : MaterialModifier Property (IPMIGtolBoxData)

Gets the material condition for this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialModifier As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Integer  
  
instance.MaterialModifier = value  
  
value = instance.MaterialModifier
```

C#

```
System.int MaterialModifier {get; set;}
```

C++/CLI

```
property System.int MaterialModifier {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Material condition as defined in [swMaterialModifier_e](#) (see Remarks)

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolBoxData::MaterialModifier](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

All material conditions in `swMaterialModifier_e` are valid except `swMaterialModifier_e.swMaterialModifier_Translation`.

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::GetAdditionalSymbols Method\(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolerancePerUnitType Property (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : TolerancePerUnitType Property (IPMIGtolBoxData)

Gets the tolerance per unit area type in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property TolerancePerUnitType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Integer  
  
instance.TolerancePerUnitType = value  
  
value = instance.TolerancePerUnitType
```

C#

```
System.int TolerancePerUnitType {get; set;}
```

C++/CLI

```
property System.int TolerancePerUnitType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance per unit area type as defined in [swPMITolPerUnitAreaType_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::TolerancePerUnitType](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIFrameData::GeometricCharacteristic](#) returns [swGeometricCharacteristic_e](#):

- `swGeometricCharacteristic_Flatness`
- `swGeometricCharacteristic_Straightness`

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::TolerancePerUnitValue1 Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue1Precision Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue2 Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue2Precision Property \(\)](#)
[IPMIGtolBoxData::TolValue Property \(\)](#)
[IPMIGtolBoxData::TolValuePrecision Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolerancePerUnitValue1 Property (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : TolerancePerUnitValue1 Property (IPMIGtolBoxData)

Gets the tolerance 1 per unit area value in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property TolerancePerUnitValue1 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData  
Dim value As System.Double  
  
instance.TolerancePerUnitValue1 = value  
  
value = instance.TolerancePerUnitValue1
```

C#

```
System.double TolerancePerUnitValue1 {get; set;}
```

C++/CLI

```
property System.double TolerancePerUnitValue1 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance 1 per unit area

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::TolerancePerUnitValue1](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if [IPMIFrameData::GeometricCharacteristic](#) returns [swGeometricCharacteristic_e](#):

- [swGeometricCharacteristic_Flatness](#)
- [swGeometricCharacteristic_Straightness](#)

Use this property to calculate the unit square or circular area. If [IPMIGtolBoxData::TolerancePerUnitType](#) returns [swPMITolPerUnitAreaType_e](#).swPMITolPerUnitType_Rectangular, use this property and [IPMIGtolBoxData::TolerancePerUnitValue2](#) to calculate the unit area value. Then divide [IPMIGtolBoxData::TolValue](#) by the unit area value to get the tolerance per unit area value.

See Also

[IPMITolBoxData Interface](#)
[IPMITolBoxData Members](#)
[IPMITolBoxData::Unit Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolerancePerUnitValue2 Property (IPMITolBoxData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IPMITolBoxData Interface](#) : TolerancePerUnitValue2 Property (IPMITolBoxData)

Gets the tolerance 2 per unit area in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property TolerancePerUnitValue2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMITolBoxData  
Dim value As System.Double  
  
instance.TolerancePerUnitValue2 = value  
value = instance.TolerancePerUnitValue2
```

C#

```
System.double TolerancePerUnitValue2 {get; set;}
```

C++/CLI

```
property System.double TolerancePerUnitValue2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance 2 per unit area

Visual Basic for Applications (VBA) Syntax

See [PMITolBoxData::TolerancePerUnitValue2](#).

Example

See the [JAnnotation::GetPMIData](#) example.

Remarks

This property is valid only if:

- [IPMIFrameData::GeometricCharacteristic](#) returns [swGeometricCharacteristic_e](#)
 - swGeometricCharacteristic_Flatness
 - swGeometricCharacteristic_Straightness
- [IPMITolBoxData::TolerancePerUnitType](#) returns [swPMITolPerUnitAreaType_e](#) swPMITolPerUnitType_Rectangular.

If IPMITolBoxData::TolerancePerUnitType returns swPMITolPerUnitAreaType_e.swPMITolPerUnitType_Rectangular, use this property and [IPMITolBoxData::TolerancePerUnitValue1](#) to calculate the unit area value. Then divide [IPMITolBoxData::TolValue](#) by the unit area value to get the tolerance per unit area value.

See Also

[IPMITolBoxData Interface](#)
[IPMITolBoxData Members](#)
[IPMITolBoxData::Unit Property \(\)](#)

Availability

ToleranceZoneModifier Property (IPMIGtolBoxData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : ToleranceZoneModifier Property (IPMIGtolBoxData)

Gets the tolerance zone modifier in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property ToleranceZoneModifier As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData
Dim value As System.Integer

instance.ToleranceZoneModifier = value
value = instance.ToleranceZoneModifier
```

C#

```
System.int ToleranceZoneModifier {get; set;}
```

C++/CLI

```
property System.int ToleranceZoneModifier {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance zone modifier as defined in [swToleranceZoneModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::ToleranceZoneModifier](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

TolValue Property (IPMIGtolBoxData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : TolValue Property (IPMIGtolBoxData)

Gets the tolerance value in this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property TolValue As System.Double

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData
Dim value As System.Double

instance.TolValue = value

value = instance.TolValue
```

C#

```
System.double TolValue {get; set;}
```

C++/CLI

```
property System.double TolValue {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance value

Visual Basic for Applications (VBA) Syntax

See [PMIGtolBoxData::TolValue](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::Unit Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitType Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue1 Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue2 Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Unit Property (IPMIGtolBoxData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolBoxData Interface](#) : Unit Property (IPMIGtolBoxData)

Gets the units of tolerance for this PMI Gtol frame box.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Unit As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolBoxData
Dim value As System.Integer

instance.Unit = value

value = instance.Unit
```

C#

```
System.int Unit {get; set;}
```

C++/CLI

```
property System.int Unit {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Units of tolerance as defined in [swPMIUnit_e](#)

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolBoxData::Unit](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolBoxData Interface](#)
[IPMIGtolBoxData Members](#)
[IPMIGtolBoxData::TolerancePerUnitValue1 Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue1Precision Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue2 Property \(\)](#)
[IPMIGtolBoxData::TolerancePerUnitValue2Precision Property \(\)](#)
[IPMIGtolBoxData::TolValue Property \(\)](#)
[IPMIGtolBoxData::TolValuePrecision Property \(\)](#)
[IPMIGtolBoxData::GetTolTypeValues Method \(\)](#)
[IPMIGtolBoxData::GetTolTypeValuesPrecision Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIGtolData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIGtolData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolData Interface

Allows access to the Product and Manufacturing Information (PMI) for a Gtol annotation in a STEP 242 model.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IPMIGtolData

Visual Basic (Usage)



Dim instance As [IPMIGtolData](#)

C#

public interface IPMIGtolData

C++/CLI

public interface class IPMIGtolData

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This interface is valid only if [IAnnotation::GetPMIType](#) returns [swPMIType_e.swPMIType_GTol](#).

Accessors

IAnnotation::GetPMIData

Access Diagram

[PMIGtolData](#)

See Also

[IPMIGtolData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIDimensionData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIGtolData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolData Interface

The following tables list the members exposed by [IPMIGtolData](#).

Public Properties

Name	Description
 InstanceCount	Gets the number of times this PMI Gtol is repeated. NOTE: This property is a get-only property. Set is not implemented.

 LeaderLocation	Gets the leader location of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderModifier	Gets the leader modifier of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderStyle	Gets the leader style of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderType	Gets the leader type of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 GetFirstPoint	Gets the label of the first point for tolerances applied between two points or entities in this PMI Gtol.
 GetFrameAtIndex	Gets the data of the frame at the specified index of this PMI Gtol.
 GetFrameCount	Gets the number of frames in this PMI Gtol.
 GetSecondPoint	Gets the label of the second point for tolerances applied between two points or entities in this PMI Gtol.
 GetText	Gets the text of this PMI Gtol.
 GetTextBelowFrames	Gets the text below the feature control frame of this PMI Gtol.
 IsComposite	Gets whether this PMI Gtol combines the symbols of two frames.

[Top](#)

See Also

[IPMIGtolData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIDimensionData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIGtolData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolData Interface

For a list of all members of this type, see [IPMIGtolData members](#).

Public Methods

Name	Description
 GetFirstPoint	Gets the label of the first point for tolerances applied between two points or entities in this PMI Gtol.
 GetFrameAtIndex	Gets the data of the frame at the specified index of this PMI Gtol.
 GetFrameCount	Gets the number of frames in this PMI Gtol.
 GetSecondPoint	Gets the label of the second point for tolerances applied between two points or entities in this PMI Gtol.
 GetText	Gets the text of this PMI Gtol.
 GetTextBelowFrames	Gets the text below the feature control frame of this PMI Gtol.
 IsComposite	Gets whether this PMI Gtol combines the symbols of two frames.

[Top](#)

See Also

[IPMIGtolData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIDimensionData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIGtolData Interface Properties

[See Also](#)



For a list of all members of this type, see [IPMIGtolData members](#).

 Public Properties

Name	Description
 InstanceCount	Gets the number of times this PMI Gtol is repeated. NOTE: This property is a get-only property. Set is not implemented.
 LeaderLocation	Gets the leader location of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderModifier	Gets the leader modifier of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderStyle	Gets the leader style of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.
 LeaderType	Gets the leader type of this PMI Gtol. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[IPMIGtolData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPMIDatumData Interface](#)
[IPMIDimensionData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstPoint Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetFirstPoint Method (IPMIGtolData)

Gets the label of the first point for tolerances applied between two points or entities in this PMI Gtol.

 .NET Syntax

Visual Basic (Declaration)
Function GetFirstPoint() As System.String
Visual Basic (Usage)
Dim instance As IPMIGtolData Dim value As System.String value = instance.GetFirstPoint()
C#
System.string GetFirstPoint()
C++/CLI
System.String^ GetFirstPoint();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Label of the first point

 Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::GetFirstPoint](#).

 See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)
[IPMIGtolData::GetSecondPoint Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFrameAtIndex Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetFrameAtIndex Method (IPMIGtolData)

Gets the data of the frame at the specified index of this PMI Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFrameAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetFrameAtIndex(Index)
```

C#

```
System.object GetFrameAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetFrameAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Zero-based index of the frame to get

Return Value

[IPMIFrameData](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::GetFrameAtIndex](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIGtolData::GetFrameCount](#) to determine Index.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

GetFrameCount Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetFrameCount Method (IPMIGtolData)

Gets the number of frames in this PMI Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFrameCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData  
Dim value As System.Integer  
  
value = instance.GetFrameCount()
```

C#

```
System.int GetFrameCount()
```

C++/CLI

```
System.int GetFrameCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of frames

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::GetFrameCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

GetSecondPoint Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetSecondPoint Method (IPMIGtolData)

Gets the label of the second point for tolerances applied between two points or entities in this PMI Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSecondPoint() As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData  
Dim value As System.String  
  
value = instance.GetSecondPoint()
```

C#

```
System.string GetSecondPoint()
```

C++/CLI

```
System.String^ GetSecondPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Label of the second point

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolData::GetSecondPoint](#).

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)
[IPMIGtolData::GetFirstPoint Method\(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetText Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetText Method (IPMIGtolData)

Gets the text of this PMI Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText() As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData  
Dim value As System.String  
  
value = instance.GetText()
```

C#

```
System.string GetText()
```

C++/CLI

```
System.String^ GetText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text of this PMI Gtol

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::GetText](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextBelowFrames Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : GetTextBelowFrames Method (IPMIGtolData)

Gets the text below the feature control frame of this PMI Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextBelowFrames() As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData
Dim value As System.String

value = instance.GetTextBelowFrames()
```

C#

```
System.string GetTextBelowFrames()
```

C++/CLI

```
System.String^ GetTextBelowFrames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Below-frame text

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::GetTextBelowFrames](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InstanceCount Property (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : InstanceCount Property (IPMIGtolData)

Gets the number of times this PMI Gtol is repeated.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property InstanceCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData
Dim value As System.Integer

instance.InstanceCount = value

value = instance.InstanceCount
```

C#

```
System.int InstanceCount {get; set;}
```

C++/CLI

```
property System.int InstanceCount {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of repeated instances of this Gtol

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::InstanceCount](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsComposite Method (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : IsComposite Method (IPMIGtolData)

Gets whether this PMI Gtol combines the symbols of two frames.

.NET Syntax

Visual Basic (Declaration)

```
Function IsComposite() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData
Dim value As System.Boolean

value = instance.IsComposite()
```

C#

```
System.bool IsComposite()
```

C++/CLI

```
System.bool IsComposite();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a composite frame, false if not

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolData::IsComposite](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderLocation Property (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : LeaderLocation Property (IPMIGtolData)

Gets the leader location of this PMI Gtol.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderLocation As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolData  
Dim value As System.Integer  
  
instance.LeaderLocation = value  
  
value = instance.LeaderLocation
```

C#

```
System.int LeaderLocation {get; set;}
```

C++/CLI

```
property System.int LeaderLocation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader location as defined in [swPMILeaderLocation_e](#)

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolData::LeaderLocation](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

LeaderModifier Property (IPMIGtolData)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [IPMIGtolData Interface](#) : LeaderModifier Property (IPMIGtolData)

Gets the leader modifier of this PMI Gtol.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property LeaderModifier As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIGtolData
Dim value As System.Integer

instance.LeaderModifier = value
value = instance.LeaderModifier
```

C#

```
System.int LeaderModifier {get; set;}
```

C++/CLI

```
property System.int LeaderModifier {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader modifier as defined in [swPMILeaderModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolData::LeaderModifier](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

LeaderStyle Property (IPMIGtolData)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [IPMIGtolData Interface](#) : LeaderStyle Property (IPMIGtolData)

Gets the leader style of this PMI Gtol.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property LeaderStyle As System.Integer

```
Dim instance As IPMIGtolData
Dim value As System.Integer

instance.LeaderStyle = value

value = instance.LeaderStyle
```

C#

```
System.int LeaderStyle {get; set;}
```

C++/CLI

```
property System.int LeaderStyle {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader style as defined in [swPMILeaderStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolData::LeaderStyle](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderType Property (IPMIGtolData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolData Interface](#) : LeaderType Property (IPMIGtolData)

Gets the leader type of this PMI Gtol.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderType As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPMIGtolData
Dim value As System.Integer

instance.LeaderType = value

value = instance.LeaderType
```

C#

```
System.int LeaderType {get; set;}
```

C++/CLI

```
property System.int LeaderType {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader type as defined in [swPMILeaderType_e](#)

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolData::LeaderType](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolData Interface](#)
[IPMIGtolData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPMIGtolFrameDatum (Type)

IPMIGtolFrameDatum Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolFrameDatum Interface

Allows access to a Product and Manufacturing Information (PMI) Gtol datum box.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface IPMIGtolFrameDatum
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
```

C#

```
public interface IPMIGtolFrameDatum
```

C++/CLI

```
public interface class IPMIGtolFrameDatum
```

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This interface allows you to access the primary, secondary, and tertiary frame datum.

Accessors

[IPMIFrameData::GetGtolDatumAtIndex](#)

Access Diagram

[PMIGtolFrameDatum](#)

See Also

[IPMIGtolFrameDatum Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPMIGtolFrameDatum Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolFrameDatum Interface

The following tables list the members exposed by [IPMIGtolFrameDatum](#).

Public Properties

Name	Description
 Datum	Gets the Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinked1	Gets the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.

 DatumLinked2	Gets the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifier1	Gets the modifier of the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifier2	Gets the modifier of the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifierValue1	Gets the value of the modifier of the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifierValue2	Gets the value of the modifier of the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumModifier	Gets the material modifier of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumModifierValue	Gets the value of the material modifier of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIGtolFrameDatum Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPMIGtolFrameDatum Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPMIGtolFrameDatum Interface

For a list of all members of this type, see [IPMIGtolFrameDatum members](#).

Public Properties

Name	Description
 Datum	Gets the Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinked1	Gets the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinked2	Gets the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifier1	Gets the modifier of the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifier2	Gets the modifier of the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifierValue1	Gets the value of the modifier of the first linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumLinkedModifierValue2	Gets the value of the modifier of the second linked datum of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.
 DatumModifier	Gets the material modifier of this Gtol frame datum. NOTE: This property is a get-only property. Set is not implemented.



[DatumModifierValue](#)

Gets the value of the material modifier of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IPMIGtolFrameDatum Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Datum Property (IPMIGtolFrameDatum)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : Datum Property (IPMIGtolFrameDatum)

Gets the Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Datum As System.String

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum  
Dim value As System.String
```

```
instance.Datum = value
```

```
value = instance.Datum
```

C#

```
System.string Datum {get; set;}
```

C++/CLI

```
property System.String^ Datum {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gtol frame datum

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::Datum](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

In the Geometric Tolerance Properties dialog, you can specify up to two datums linked to the Primary, Secondary, and Tertiary datums. Click the drop-down selector next to each datum field to pop up a linked datum dialog where you can specify the linked datums and their material modifiers.

This property gets the primary, secondary, or tertiary datum. Use [IPMIGtolFrameDatum::DatumLinked1](#) and [IPMIGtolFrameDatum::DatumLinked2](#) to get the datums linked to this datum.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

DatumLinked1 Property (IPMIGtolFrameDatum)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumLinked1 Property (IPMIGtolFrameDatum)

Gets the first linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLinked1 As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum  
Dim value As System.String
```

```
instance.DatumLinked1 = value
```

```
value = instance.DatumLinked1
```

C#

```
System.string DatumLinked1 {get; set;}
```

C++/CLI

```
property System.String^ DatumLinked1 {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

First linked datum

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinked1](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

DatumLinked2 Property (IPMIGtolFrameDatum)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumLinked2 Property (IPMIGtolFrameDatum)

Gets the second linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLinked2 As System.String
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
Dim value As System.String

instance.DatumLinked2 = value

value = instance.DatumLinked2
```

C#

```
System.string DatumLinked2 {get; set;}
```

C++/CLI

```
property System.String^ DatumLinked2 {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Second linked datum

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinked2](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DatumLinkedModifier1 Property (IPMIGtolFrameDatum)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumLinkedModifier1 Property (IPMIGtolFrameDatum)

Gets the modifier of the first linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLinkedModifier1 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
Dim value As System.Integer

instance.DatumLinkedModifier1 = value

value = instance.DatumLinkedModifier1
```

C#

```
System.int DatumLinkedModifier1 {get; set;}
```

C++/CLI

```
property System.int DatumLinkedModifier1 {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[First linked datum](#) material modifier as defined in [swMaterialModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinkedModifier1](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIGtolFrameDatum::DatumLinkedModifierValue1](#) to get this linked datum's modifier value, if one exists.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DatumLinkedModifier2 Property (IPMIGtolFrameDatum)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumLinkedModifier2 Property (IPMIGtolFrameDatum)

Gets the modifier of the second linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLinkedModifier2 As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPMIGtolFrameDatum  
Dim value As System.Integer  
  
instance.DatumLinkedModifier2 = value  
  
value = instance.DatumLinkedModifier2
```

C#

```
System.int DatumLinkedModifier2 {get; set;}
```

C++/CLI

```
property System.int DatumLinkedModifier2 {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Second linked datum](#) material modifier as defined in [swMaterialModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinkedModifier2](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIGtolFrameDatum::DatumLinkedModifierValue2](#) to get this linked datum's modifier value, if one exists.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DatumLinkedModifierValue1 Property (IPMIGtolFrameDatum)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumLinkedModifierValue1 Property (IPMIGtolFrameDatum)

Gets the value of the modifier of the first linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumLinkedModifierValue1 As System.Double
```

Visual Basic (Usage)

```
Dim instance As IPMIGtolFrameDatum  
Dim value As System.Double  
  
instance.DatumLinkedModifierValue1 = value  
value = instance.DatumLinkedModifierValue1
```

C#

```
System.double DatumLinkedModifierValue1 {get; set;}
```

C++/CLI

```
property System.double DatumLinkedModifierValue1 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the [first linked datum modifier](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinkedModifierValue1](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

DatumLinkedModifierValue2 Property (IPMIGtolFrameDatum)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [IPMIGtolFrameDatum Interface](#) : DatumLinkedModifierValue2 Property (IPMIGtolFrameDatum)

Gets the value of the modifier of the second linked datum of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property DatumLinkedModifierValue2 As System.Double

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
Dim value As System.Double

instance.DatumLinkedModifierValue2 = value

value = instance.DatumLinkedModifierValue2
```

C#

```
System.double DatumLinkedModifierValue2 {get; set;}
```

C++/CLI

```
property System.double DatumLinkedModifierValue2 {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the [second linked datum modifier](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumLinkedModifierValue2](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

DatumModifier Property (IPMIGtolFrameDatum)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [IPMIGtolFrameDatum Interface](#) : DatumModifier Property (IPMIGtolFrameDatum)

Gets the material modifier of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property DatumModifier As System.Integer

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
Dim value As System.Integer

instance.DatumModifier = value

value = instance.DatumModifier
```

C#

```
System.int DatumModifier {get; set;}
```

C++/CLI

```
property System.int DatumModifier {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Datum](#) material modifier as defined in [swMaterialModifier](#) e

Visual Basic for Applications (VBA) Syntax

See [IPMIGtolFrameDatum::DatumModifier](#).

Example

See the [JAnnotation::GetPMIData](#) example.

Remarks

Use [IPMIGtolFrameDatum::DatumModifierValue](#) to get this datum modifier's value, if one exists.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DatumModifierValue Property (IPMIGtolFrameDatum)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPMIGtolFrameDatum Interface](#) : DatumModifierValue Property (IPMIGtolFrameDatum)

Gets the value of the material modifier of this Gtol frame datum.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property DatumModifierValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPMIGtolFrameDatum
Dim value As System.Double

instance.DatumModifierValue = value

value = instance.DatumModifierValue
```

C#

```
System.double DatumModifierValue {get; set;}
```

C++/CLI

```
property System.double DatumModifierValue {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the [datum modifier](#)

Visual Basic for Applications (VBA) Syntax

See [PMIGtolFrameDatum::DatumModifierValue](#).

Example

See the [IAnnotation::GetPMIData](#) example.

See Also

[IPMIGtolFrameDatum Interface](#)
[IPMIGtolFrameDatum Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IPrimaryMemberFacePlaneIntersectionFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrimaryMemberFacePlaneIntersectionFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPrimaryMemberFacePlaneIntersectionFeatureData Interface

Allows access to a structure system member created along the intersection of a face or surface with a plane.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPrimaryMemberFacePlaneIntersectionFeatureData
```

Visual Basic (Usage)



```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData
```

C#

```
public interface IPrimaryMemberFacePlaneIntersectionFeatureData
```

C++/CLI

```
public interface class IPrimaryMemberFacePlaneIntersectionFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData](#).

Example

```
'VBA
'=====
'Preconditions:
'1. Ensure the specified part template exists.
'2. Open an Immediate window.
'3. Press F5.
'
'Postconditions:
' 1. Creates Boss-Extrude1 and Plane1 in a new part.
' 2. Selects a parameter face on the extrusion.
' 3. Selects Plane1.
' 4. Creates a face plane intersection member along the intersection of the selected face
and plane.
' 5. Creates a Structure System1.
' 6. Inspect the member on Plane1 in the graphics area.
' 7. Press F5 to edit the structure system.
' 8. Gets all of the structure system members in all of the profile group folders.
' 9. Changes the member extension lengths in directions 1 and 2.
'10. Selects the Right Plane to intersect the parameter face.
'11. Modifies the structure system.
'12. Inspect the member move to the Right Plane in the graphics area.
'=====

Dim swApp As SldWorks.SldWorks
Dim modDoc As SldWorks.ModelDoc2
```

```

Dim swFeatMgr As SldWorks.FeatureManager
Dim swSelMgr As SldWorks.SelectionMgr
Dim modDocExt As SldWorks.ModelDocExtension
Dim structMemDef As SldWorks.StructureSystemMemberFeatureData
Dim profDef As SldWorks.StructureSystemMemberProfile
Dim PrimDef As SldWorks.PrimaryStructuralMemberFeatureData
Dim facePlaneIntrSecDef As SldWorks.PrimaryMemberFacePlaneIntersectionFeatureData
Dim faces(0) As Object
Dim stat As Boolean
Dim IntSecPlane(0) As Object
Dim memData(0) As SldWorks.StructureSystemMemberFeatureData
Dim memDataArray As Variant
Dim structSys As SldWorks.Feature
Dim structSysModDef As SldWorks.StructureSystemFolder
Dim outProfiles As Variant
Dim MemberData As SldWorks.StructureSystemMemberFeatureData
Dim memberArray As Variant
Dim profileGrpFeat As SldWorks.Feature
Dim profileGrp As SldWorks.ProfileGroupFolder
Dim memToChange As SldWorks.StructureSystemMemberFeatureData
Dim faceIntrMemberToChange As SldWorks.PrimaryMemberFacePlaneIntersectionFeatureData
Dim newIntSecPlane(0) As Object
Dim feat As Feature
Dim I As Long
Dim j As Long
Option Explicit
Sub main()
    Set swApp = Application.SldWorks

    Dim swSheetWidth As Double
    swSheetWidth = 0
    Dim swSheetHeight As Double
    swSheetHeight = 0
    Set modDoc = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS
2022\templates\Part.PRTDOT", 0, swSheetWidth, swSheetHeight)
    Dim swPart As SldWorks.PartDoc
    Set swPart = modDoc
    Set modDoc = swApp.ActiveDoc

    Set modDocExt = modDoc.Extension
    Set swSelMgr = modDoc.SelectionManager

    stat = modDocExt.SelectByID2("Right Plane", "PLANE", 0, 0, 0, False, 0, Nothing, 0)
    modDoc.SketchManager.InsertSketch True
    modDoc.ClearSelection2 True
    stat =
modDocExt.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstToRectEntity,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, False)

```

```

stat =
modDocExt.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstLineDiagonalType,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, True)

Dim vSkLines As Variant
vSkLines = modDoc.SketchManager.CreateCornerRectangle(-1.68788132580097E-02,
1.16544186781496E-02, 0, 1.39317188796271E-02, -7.36773594595662E-03, 0)

modDoc.ShowNamedView2 "*Trimetric", 8
modDoc.ViewZoomtofit2
Dim myFeature As SldWorks.Feature
Set myFeature = modDoc.FeatureManager.FeatureExtrusion2(False, False, False, 0, 0, 0.2,
0.2, False, False, False, False, 1.74532925199433E-02, 1.74532925199433E-02, False, False,
False, False, True, True, True, 0, 0, False)
swSelMgr.EnableContourSelection = False
stat = modDocExt.SelectByRay(0.199999999999932, 2.80649656951937E-03, 8.80259028576802E-
04, -0.400036026779314, -0.515038074910018, -0.758094294050287, 1.11139990390966E-03, 2,
False, 0, 0)
Dim myRefPlane As SldWorks.RefPlane
Set myRefPlane = modDoc.FeatureManager.InsertRefPlane(4, 0, 0, 0, 0, 0)
modDoc.ClearSelection2 True

'Configure a structure system face plane intersection member
Set structMemDef = modDocExt.CreateStructureSystemMemberData(3)
Debug.Print "Type of structure system member as defined by
swStructureSystemMemberType_e: " & structMemDef.StructureSystemMemberType

structMemDef.StartEndExtendD1 = 0.4
Debug.Print "Extend length in direction 1: " & structMemDef.StartEndExtendD1
structMemDef.StartEndExtendD2 = 0.15
Debug.Print "Extend length in direction 2: " & structMemDef.StartEndExtendD2

Set profDef = structMemDef.MemberProfile

profDef.ProfileStandard = "ansi inch"
profDef.ProfileType = "c channel"
profDef.ProfileSize = "3 x 5"

Set PrimDef = structMemDef
Debug.Print "Structure system primary member creation type as defined by
swStructureSystemMemberCreationType_e: " & PrimDef.PrimaryMemberType

Set facePlaneIntrSecDef = PrimDef

facePlaneIntrSecDef.MergeTangentMembers = False

'Select parameter face and intersecting plane
stat = modDocExt.SelectByRay(-1.7443058891331E-04, 1.16544186780629E-02,
-4.26704146832435E-04, -0.400036026779314, -0.515038074910018, -0.758094294050287,
1.89520697225961E-04, 2, False, 0, 0)
stat = modDocExt.SelectByID2("Plane1", "PLANE", 0, 0, 0, True, 0, Nothing, 0)

```

```

Set faces(0) = swSelMgr.GetSelectedObject6(1, -1)

stat = facePlaneIntrSecDef.SetParameterFaces(faces)
Debug.Print "Member's parameter face set successfully: " & stat

Set IntSecPlane(0) = swSelMgr.GetSelectedObject6(2, -1)

stat = facePlaneIntrSecDef.SetIntersectingPlanesAndFaces(IntSecPlane)
Debug.Print "Member's intersecting plane set successfully: " & stat

Set memData(0) = structMemDef

memDataArray = memData

'Create Structure System1 in the FeatureManager design tree
Set structSys = modDocExt.CreateStructureSystem(memDataArray, Nothing)

modDoc.ViewZoomtofit2

Stop

Debug.Print ""
Debug.Print "Edit Structure System1..."

Set structSysModDef = structSys.GetSpecificFeature2()
Debug.Print "Number of structure system profile groups: " &
structSysModDef.GetProfileGroupFoldersCount

outProfiles = structSysModDef.GetProfileGroupFolders()

If (Not IsEmpty(outProfiles)) Then
    For I = 0 To UBound(outProfiles)
        Set profileGrpFeat = outProfiles(I)
        Set profileGrp = profileGrpFeat.GetSpecificFeature2
        If Not profileGrp Is Nothing Then
            Debug.Print "Number of members inside group: " &
profileGrp.GetStructureSystemMemberCount
            memberArray = profileGrp.GetStructureSystemMembers()
            If (Not IsEmpty(memberArray)) Then
                For j = 0 To UBound(memberArray)
                    Set MemberData = memberArray(j)
                    Exit For
                Next
            End If
        End If
    Next
End If

```

```

Set memToChange = MemberData
Set feat = memToChange.GetFeature()

Debug.Print "Change member extensions in directions 1 and 2..."
memToChange.StartEndExtendD1 = 0.1
memToChange.StartEndExtendD2 = 0.2

Set faceIntrMemberToChange = memToChange

modDoc.ClearSelection2 True

stat = modDocExt.SelectByID2("Right Plane", "PLANE", 0, 0, 0, True, 0, Nothing, 0)
Set newIntSecPlane(0) = swSelMgr.GetSelectedObject6(1, -1)
stat = faceIntrMemberToChange.SetIntersectingPlanesAndFaces(newIntSecPlane)
Debug.Print "Intersecting plane successfully changed: " & stat

stat = feat.ModifyDefinition(MemberData, modDoc, Nothing)

```

End Sub

Example

[Create Face Plane Intersection Structure System Member \(VB.NET\)](#)
[Create Face Plane Intersection Structure System Member \(C#\)](#)

Remarks

See the [IStructureSystemFolder](#) Remarks.

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > PrimaryMemberPropertyManager** topic.

Accessors

Cast [IPrimaryStructuralMemberFeatureData](#) or [IStructureSystemMemberFeatureData](#) to this interface.

Access Diagram

[PrimaryMemberFacePlaneIntersectionFeatureData](#)

See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrimaryMemberFacePlaneIntersectionFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPrimaryMemberFacePlaneIntersectionFeatureData Interface

The following tables list the members exposed by [IPrimaryMemberFacePlaneIntersectionFeatureData](#).

Public Properties

Name	Description
MergeTangentMembers	Gets and sets whether to merge tangent structure system members.

[Top](#)

Public Methods

Name	Description
------	-------------

 GetIntersectingObjectTypes	Gets the types of entities that intersect with parameter faces of this structure system member.
 GetIntersectingPlanesAndFaces	Gets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.
 GetParameterFaces	Gets the parameter faces of this structure system member.
 SetIntersectingPlanesAndFaces	Sets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.
 SetParameterFaces	Sets the parameter faces of this structure system member.

[Top](#)

 See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrimaryMemberFacePlaneIntersectionFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IPrimaryMemberFacePlaneIntersectionFeatureData Interface

For a list of all members of this type, see [IPrimaryMemberFacePlaneIntersectionFeatureData members](#).

 Public Methods

Name	Description
 GetIntersectingObjectTypes	Gets the types of entities that intersect with parameter faces of this structure system member.
 GetIntersectingPlanesAndFaces	Gets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.
 GetParameterFaces	Gets the parameter faces of this structure system member.
 SetIntersectingPlanesAndFaces	Sets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.
 SetParameterFaces	Sets the parameter faces of this structure system member.

[Top](#)

 See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrimaryMemberFacePlaneIntersectionFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IPrimaryMemberFacePlaneIntersectionFeatureData Interface

For a list of all members of this type, see [IPrimaryMemberFacePlaneIntersectionFeatureData members](#).

 Public Properties

Name	Description
 MergeTangentMembers	Gets and sets whether to merge tangent structure system members.

[Top](#)

 See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetIntersectingObjectTypes Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : GetIntersectingObjectTypes Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

Gets the types of entities that intersect with parameter faces of this structure system member.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectingObjectTypes() As System.Object
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData
Dim value As System.Object

value = instance.GetIntersectingObjectTypes()
```

C#

```
System.object GetIntersectingObjectTypes()
```

C++/CLI

```
System.Object^ GetIntersectingObjectTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of intersecting object types as defined by [swSelectType_e](#):

- swSelFACES
- swSelREFFACES
- swSelDATUMPLANES

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::GetIntersectingObjectTypes](#).

See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[IPrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetIntersectingPlanesAndFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : GetIntersectingPlanesAndFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

Gets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectingPlanesAndFaces() As System.Object
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData
Dim value As System.Object

value = instance.GetIntersectingPlanesAndFaces()
```

C#

```
System.object GetIntersectingPlanesAndFaces()
```

C++/CLI

```
System.Object^ GetIntersectingPlanesAndFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IRefPlanes](#), [ISurfaces](#), and/or [IFace2s](#)

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::GetIntersectingPlanesAndFaces](#).

See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[IPrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParameterFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : GetParameterFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

Gets the parameter faces of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParameterFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData  
Dim value As System.Object  
  
value = instance.GetParameterFaces()
```

C#

```
System.object GetParameterFaces()
```

C++/CLI

```
System.Object^ GetParameterFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFace2s](#)

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::GetParameterFaces](#).

See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[IPrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeTangentMembers Property (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : MergeTangentMembers Property (IPrimaryMemberFacePlaneIntersectionFeatureData)

Gets and sets whether to merge tangent structure system members.

.NET Syntax

Visual Basic (Declaration)

```
Property MergeTangentMembers As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData
Dim value As System.Boolean

instance.MergeTangentMembers = value

value = instance.MergeTangentMembers
```

C#

```
System.bool MergeTangentMembers {get; set;}
```

C++/CLI

```
property System.bool MergeTangentMembers {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge tangent members, false to not

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::MergeTangentMembers](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See Also

[IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[IPrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetIntersectingPlanesAndFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : SetIntersectingPlanesAndFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

Sets the planes, surfaces, and faces that intersect with parameter faces of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function SetIntersectingPlanesAndFaces( _
    ByVal RefList As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPrimaryMemberFacePlaneIntersectionFeatureData
Dim RefList As System.Object
Dim value As System.Boolean

value = instance.SetIntersectingPlanesAndFaces(RefList)
```

C#

```
System.bool SetIntersectingPlanesAndFaces(
    System.object RefList
)
```

C++/CLI

```
System.bool SetIntersectingPlanesAndFaces(  
& System.Object^ RefList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RefList
Array of [IRefPlanes](#), [ISurface](#)s, and/or [IFace2](#)s that intersect with parameter faces

Return Value

True if intersecting objects successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::SetIntersectingPlanesAndFaces](#).

Example

See the [PrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

Remarks

Entities passed should intersect with at least one entity returned by [PrimaryMemberFacePlaneIntersectionFeatureData::GetParameterFaces](#).
At edit time, you can set only one intersecting entity.

See Also

[PrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[PrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetParameterFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [PrimaryMemberFacePlaneIntersectionFeatureData Interface](#) : SetParameterFaces Method (IPrimaryMemberFacePlaneIntersectionFeatureData)

Sets the parameter faces of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function SetParameterFaces(  
    ByVal Faces As System.Object  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As PrimaryMemberFacePlaneIntersectionFeatureData  
Dim Faces As System.Object  
Dim value As System.Boolean  
  
value = instance.SetParameterFaces(Faces)
```

C#

```
System.bool SetParameterFaces(  
    System.Object Faces  
)
```

C++/CLI

```
System.bool SetParameterFaces(  
& System.Object^ Faces  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Faces
Array of [IFace2s](#)

Return Value

True if parameter faces successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [PrimaryMemberFacePlaneIntersectionFeatureData::SetParameterFaces](#).

Example

See the [PrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

Remarks

Only [swSelectType_e](#).swSelfFACES type entities can be set using this method.

At edit time you can set only one parameter face.

See Also

[PrimaryMemberFacePlaneIntersectionFeatureData Interface](#)
[PrimaryMemberFacePlaneIntersectionFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30