

SOLIDWORKS API (.NET VBA C#) — Reference (227/337): IPrintSpecification-IProjectionArrow

SOLIDWORKS API Documentation (converted from CHM)

IPrintSpecification (Type)

IPrintSpecification Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPrintSpecification Interface

Allows access to a document's printing specification.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPrintSpecification
```

Visual Basic (Usage)

```
Dim instance As IPrintSpecification
```

C#

```
public interface IPrintSpecification
```

C++/CLI

```
public interface class IPrintSpecification
```

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification](#).

Example

[Print Drawing \(VBA\)](#)
[Print Drawing \(VB.NET\)](#)
[Print Drawing \(C#\)](#)

Accessors

[IModelDocExtension::GetPrintSpecification](#)

Access Diagram

[PrintSpecification](#)

See Also

[IPrintSpecification Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PrintOut4 Method \(\)](#)

IPrintSpecification Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPrintSpecification Interface

The following tables list the members exposed by [IPrintSpecification](#).

Public Properties

Name	Description
Collate	Gets or sets whether to collate the pages in multiple copies of this document.
ConvertToHighQuality	Gets or sets whether to convert draft quality drawing views to high quality.

 CurrentSheet	Gets the index of the current sheet.
 FromScale	Gets or sets the custom "from" scale factor for the current drawing sheet.
 NumberOfCopies	Gets or sets the number of copies to print.
 PrintBackground	Gets or sets whether to print the background.
 PrintCrossHatchOnOutOfDateViews	Gets or sets whether to print a cross hatch on out-of-date views.
 PrinterQueue	Gets or sets the printer to use.
 PrintFile	Gets or sets the path and file name to which to print the document.
 PrintRange	Gets or sets the range of pages to print.
 PrintToFile	Gets or sets whether to print to a file.
 PrintWhiteItemsBlack	Gets or sets whether to print white lines and white text in black.
 ScaleMethod	Gets or sets the page selection option for printing.
 SheetCount	Gets the number of sheets in this drawing.
 ToScale	Gets or sets the custom "to" scale factor for the current drawing sheet.
 XOrigin	Gets or sets the X-coordinate of the print window origin.
 YOrigin	Gets or sets the Y-coordinate of the print window origin.

[Top](#)

Public Methods

Name	Description
 AddPrintRange	Adds a range of pages to print.
 ResetPrintRange	Resets the print range to the default.
 RestoreDefaults	Restores the default printing options.

[Top](#)

See Also

[IPrintSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PrintOut4 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrintSpecification Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPrintSpecification Interface

For a list of all members of this type, see [IPrintSpecification members](#).

Public Methods

Name	Description
 AddPrintRange	Adds a range of pages to print.
 ResetPrintRange	Resets the print range to the default.
 RestoreDefaults	Restores the default printing options.

[Top](#)

See Also

[IPrintSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PrintOut4 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPrintSpecification Interface Properties

[See Also](#)



For a list of all members of this type, see [IPrintSpecification members](#).

Public Properties

Name	Description
 Collate	Gets or sets whether to collate the pages in multiple copies of this document.
 ConvertToHighQuality	Gets or sets whether to convert draft quality drawing views to high quality.
 CurrentSheet	Gets the index of the current sheet.
 FromScale	Gets or sets the custom "from" scale factor for the current drawing sheet.
 NumberOfCopies	Gets or sets the number of copies to print.
 PrintBackground	Gets or sets whether to print the background.
 PrintCrossHatchOnOutOfDateViews	Gets or sets whether to print a cross hatch on out-of-date views.
 PrinterQueue	Gets or sets the printer to use.
 PrintFile	Gets or sets the path and file name to which to print the document.
 PrintRange	Gets or sets the range of pages to print.
 PrintToFile	Gets or sets whether to print to a file.
 PrintWhiteItemsBlack	Gets or sets whether to print white lines and white text in black.
 ScaleMethod	Gets or sets the page selection option for printing.
 SheetCount	Gets the number of sheets in this drawing.
 ToScale	Gets or sets the custom "to" scale factor for the current drawing sheet.
 XOrigin	Gets or sets the X-coordinate of the print window origin.
 YOrigin	Gets or sets the Y-coordinate of the print window origin.

[Top](#)

See Also

[IPrintSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PrintOut4 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddPrintRange Method (IPrintSpecification)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IPrintSpecification Interface](#) : AddPrintRange Method (IPrintSpecification)

Adds a range of pages to print.

.NET Syntax

Visual Basic (Declaration)

```
Sub AddPrintRange( _  
    ByVal FirstPage As System.Integer, _  
    ByVal LastPage As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim FirstPage As System.Integer  
Dim LastPage As System.Integer  
  
instance.AddPrintRange(FirstPage, LastPage)
```

C#

```
void AddPrintRange(  
    System.int FirstPage,  
    System.int LastPage  
)
```

C++/CLI

```
void AddPrintRange(  
& System.int FirstPage,  
& System.int LastPage  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstPage
First page of print range
LastPage
Last page of print range

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::AddPrintRange](#).

Example

See the [IPrintSpecification](#) examples.

Remarks

Call this method multiple times to specify multiple ranges of pages to print.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::ResetPrintRange Method \(\)](#)
[IPrintSpecification::PrintRange Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Collate Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : Collate Property (IPrintSpecification)

Gets or sets whether to collate the pages in multiple copies of this document.

.NET Syntax

Visual Basic (Declaration)

Property Collate As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Boolean
```

```
instance.Collate = value
```

```
value = instance.Collate
```

C#

```
System.bool Collate {get; set;}
```

C++/CLI

```
property System.bool Collate {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to collate pages in multiple copies, false to not

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::Collate](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConvertToHighQuality Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : ConvertToHighQuality Property (IPrintSpecification)

Gets or sets whether to convert draft quality drawing views to high quality.

.NET Syntax

Visual Basic (Declaration)

```
Property ConvertToHighQuality As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Boolean  
  
instance.ConvertToHighQuality = value  
value = instance.ConvertToHighQuality
```

C#

```
System.bool ConvertToHighQuality {get; set;}
```

C++/CLI

```
property System.bool ConvertToHighQuality {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to convert to high quality, false to not

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::ConvertToHighQuality](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CurrentSheet Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : CurrentSheet Property (IPrintSpecification)

Gets the index of the current sheet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CurrentSheet As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Integer  
  
value = instance.CurrentSheet
```

C#

```
System.int CurrentSheet {get;}
```

C++/CLI

```
property System.int CurrentSheet {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index of current sheet

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::CurrentSheet](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FromScale Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : FromScale Property (IPrintSpecification)

Gets or sets the custom "from" scale factor for the current drawing sheet.

.NET Syntax

Visual Basic (Declaration)

Property FromScale As System.Double

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Double
```

```
instance.FromScale = value
```

```
value = instance.FromScale
```

C#

```
System.double FromScale {get; set;}
```

C++/CLI

```
property System.double FromScale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

"From" scale factor in the From:To scale

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::FromScale](#).

Example

See the [IPrintSpecification](#) examples.

Remarks

This property is valid only if [IPrintSpecification::ScaleMethod](#) is set to [swPrintSelectionScaleFactor_e.swPrintSelection](#).

For details about applying a scale factor to the current drawing sheet, see the **Print Specification** Help topic in the SOLIDWORKS Help.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::ToScale Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfCopies Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : NumberOfCopies Property (IPrintSpecification)

Gets or sets the number of copies to print.

.NET Syntax

Visual Basic (Declaration)

Property NumberOfCopies As System.Integer

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Integer
```

```
instance.NumberOfCopies = value
```

```
value = instance.NumberOfCopies
```

C#

```
System.int NumberOfCopies {get; set;}
```

C++/CLI

```
property System.int NumberOfCopies {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of copies to print

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::NumberOfCopies](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrintBackground Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintBackground Property (IPrintSpecification)

Gets or sets whether to print the background.

.NET Syntax

Visual Basic (Declaration)

Property PrintBackground As System.Boolean

```
Dim instance As IPrintSpecification
Dim value As System.Boolean

instance.PrintBackground = value

value = instance.PrintBackground
```

C#

```
System.bool PrintBackground {get; set;}
```

C++/CLI

```
property System.bool PrintBackground {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to print the background, false to not

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintBackground](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrintCrossHatchOnOutOfDateViews Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintCrossHatchOnOutOfDateViews Property (IPrintSpecification)

Gets or sets whether to print a cross hatch on out-of-date views.

.NET Syntax

Visual Basic (Declaration)

```
Property PrintCrossHatchOnOutOfDateViews As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPrintSpecification
Dim value As System.Boolean

instance.PrintCrossHatchOnOutOfDateViews = value

value = instance.PrintCrossHatchOnOutOfDateViews
```

C#

```
System.bool PrintCrossHatchOnOutOfDateViews {get; set;}
```

C++/CLI

```
property System.bool PrintCrossHatchOnOutOfDateViews {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to print a cross hatch on out-of-date views, false to not

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintCrossHatchOnOutOfDateViews](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrinterQueue Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrinterQueue Property (IPrintSpecification)

Gets or sets the printer to use.

.NET Syntax

Visual Basic (Declaration)

Property PrinterQueue As System.String

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.String
```

```
instance.PrinterQueue = value
```

```
value = instance.PrinterQueue
```

C#

```
System.string PrinterQueue {get; set;}
```

C++/CLI

```
property System.String^ PrinterQueue {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Printer name; default is [IModelDoc2::Printer](#)

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrinterQueue](#).

Example

See the [IPrintSpecification](#) examples.

Remarks

This property is valid only if [IPrintSpecification::PrintToFile](#) is set to false.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrintFile Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintFile Property (IPrintSpecification)

Gets or sets the path and file name to which to print the document.

.NET Syntax

Visual Basic (Declaration)

Property PrintFile As System.String

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.String
```

```
instance.PrintFile = value
```

```
value = instance.PrintFile
```

C#

```
System.string PrintFile {get; set;}
```

C++/CLI

```
property System.String^ PrintFile {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

File name; default file name is **output.prn**

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintFile](#).

Remarks

This property is valid only if [IPrintSpecification::PrintToFile](#) is set to true.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PrintRange Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintRange Property (IPrintSpecification)

Gets or sets the range of pages to print.

.NET Syntax

Visual Basic (Declaration)

Property PrintRange As System.Object

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Object
```

```
instance.PrintRange = value
```

```
value = instance.PrintRange
```

C#

```
System.object PrintRange {get; set;}
```

C++/CLI

```
property System.Object^ PrintRange {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of first and last page numbers of a range to print (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintRange](#).

Remarks

The array can contain multiple pairs of integers, each pair indicating the start and end pages of a range of pages to print. For example, to print sheets 1, 2, 3, 6, and 7 of a drawing, this array contains 2 pairs of page numbers { 1, 3, 6, 7 } indicating to print pages 1-3 and 6-7. To print only page 6, this array is { 6, 6 }.

Instead of calling this method to set the print ranges, call [IPrintSpecification::AddPrintRange](#) for each range of pages you want to print.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::ResetPrintRange Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

PrintToFile Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintToFile Property (IPrintSpecification)

Gets or sets whether to print to a file.

.NET Syntax

Visual Basic (Declaration)

Property PrintToFile As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Boolean
```

```
instance.PrintToFile = value
```

```
value = instance.PrintToFile
```

C#

```
System.bool PrintToFile {get; set;}
```

C++/CLI

```
property System.bool PrintToFile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to print to a file, false to print to a [printer queue](#)

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintToFile](#).

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

PrintWhiteItemsBlack Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : PrintWhiteItemsBlack Property (IPrintSpecification)

Gets or sets whether to print white lines and white text in black.

.NET Syntax

Visual Basic (Declaration)

Property PrintWhiteItemsBlack As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPrintSpecification
Dim value As System.Boolean

instance.PrintWhiteItemsBlack = value

value = instance.PrintWhiteItemsBlack
```

C#

```
System.bool PrintWhiteItemsBlack {get; set;}
```

C++/CLI

```
property System.bool PrintWhiteItemsBlack {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to print white lines and white text in black

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::PrintWhiteItemsBlack](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetPrintRange Method (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : ResetPrintRange Method (IPrintSpecification)

Resets the print range to the default.

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPrintRange()
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification

instance.ResetPrintRange()
```

C#

```
void ResetPrintRange()
```

C++/CLI

```
void ResetPrintRange();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::ResetPrintRange](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::AddPrintRange Method \(\)](#)
[IPrintSpecification::PrintRange Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RestoreDefaults Method (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : RestoreDefaults Method (IPrintSpecification)

Restores the default printing options.

.NET Syntax

Visual Basic (Declaration)

```
Sub RestoreDefaults()
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
instance.RestoreDefaults()
```

C#

```
void RestoreDefaults()
```

C++/CLI

```
void RestoreDefaults();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::RestoreDefaults](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

ScaleMethod Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : ScaleMethod Property (IPrintSpecification)

Gets or sets the page selection option for printing.

.NET Syntax

Visual Basic (Declaration)

Property ScaleMethod As System.Integer

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Integer
```

```
instance.ScaleMethod = value
```

```
value = instance.ScaleMethod
```

C#

```
System.int ScaleMethod {get; set;}
```

C++/CLI

```
property System.int ScaleMethod {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Page selection option as defined in [swPrintSelectionScaleFactor_e](#)

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::ScaleMethod](#).

Example

See the [IPrintSpecification](#) examples.

Remarks

For details about applying a scale factor to the current drawing sheet, see the **Print Specification** Help topic in the SOLIDWORKS Help.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SheetCount Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : SheetCount Property (IPrintSpecification)

Gets the number of sheets in this drawing.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property SheetCount As System.Integer

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Integer  
  
value = instance.SheetCount
```

C#

```
System.int SheetCount {get;}
```

C++/CLI

```
property System.int SheetCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of sheets

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::SheetCount](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ToScale Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : ToScale Property (IPrintSpecification)

Gets or sets the custom "to" scale factor for the current drawing sheet.

.NET Syntax

Visual Basic (Declaration)

Property ToScale As System.Double

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Double  
  
instance.ToScale = value  
  
value = instance.ToScale
```

C#

```
System.double ToScale {get; set;}
```

C++/CLI

```
property System.double ToScale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

"To" scale factor in the From:To scale

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::ToScale](#).

Example

See the [IPrintSpecification](#) examples.

Remarks

This property is valid only if [IPrintSpecification::ScaleMethod](#) is set to [swPrintSelectionScaleFactor_e.swPrintSelection](#).

For details about applying a scale factor to the current drawing sheet, see the **Print Specification** Help topic in the SOLIDWORKS Help.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::FromScale Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

XOrigin Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : XOrigin Property (IPrintSpecification)

Gets or sets the X-coordinate of the print window origin.

.NET Syntax

Visual Basic (Declaration)

```
Property XOrigin As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPrintSpecification  
Dim value As System.Double  
  
instance.XOrigin = value  
value = instance.XOrigin
```

C#

```
System.double XOrigin {get; set;}
```

C++/CLI

```
property System.double X0origin {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

X-coordinate of the print window origin

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::XOrigin](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)
[IPrintSpecification::YOrigin Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

YOrigin Property (IPrintSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPrintSpecification Interface](#) : YOrigin Property (IPrintSpecification)

Gets or sets the Y-coordinate of the print window origin.

.NET Syntax

Visual Basic (Declaration)

Property Y0origin As System.Double

Visual Basic (Usage)



```
Dim instance As IPrintSpecification
Dim value As System.Double
```

```
instance.Y0origin = value
```

```
value = instance.Y0origin
```

C#

```
System.double Y0origin {get; set;}
```

C++/CLI

```
property System.double Y0origin {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Y-coordinate of the print window origin

Visual Basic for Applications (VBA) Syntax

See [PrintSpecification::YOrigin](#).

Example

See the [IPrintSpecification](#) examples.

See Also

[IPrintSpecification Interface](#)
[IPrintSpecification Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

IProfileCenterMateFeatureData (Type)

IProfileCenterMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProfileCenterMateFeatureData Interface

Allows access to profile center mate feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IProfileCenterMateFeatureData

Visual Basic (Usage)

Dim instance As [IProfileCenterMateFeatureData](#)

C#

public interface IProfileCenterMateFeatureData

C++/CLI

public interface class IProfileCenterMateFeatureData

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData](#).

Example

[Create and Edit Profile Center Mate \(VBA\)](#)
[Create and Edit Profile Center Mate \(C#\)](#)

Remarks

A profile center mate centrally aligns rectangular and circular profiles to each other and fully defines the components.

[IMateFeatureData](#) is the parent of this advanced mate interface.

To create a profile center mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IProfileCenterMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByIID2](#) to pre-select the entities using Mark = 1.
3. Specify other properties of the ProfileCenterMateFeatureData object.

To edit a profile center mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a ProfileCenterMateFeatureData object.
3. Modify the ProfileCenterMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete a profile center mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[ProfileCenterMateFeatureData](#)

See Also

[IProfileCenterMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IProfileCenterMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProfileCenterMateFeatureData Interface

The following tables list the members exposed by [IProfileCenterMateFeatureData](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this profile center mate.
 FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this profile center mate.
 LockRotation	Gets or sets whether to lock the rotation of this profile center mate.
 MateAlignment	Gets or sets the alignment of this profile center mate.
 OffsetDistance	Gets or sets the offset distance for this profile center mate.

[Top](#)

See Also

[IProfileCenterMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IProfileCenterMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProfileCenterMateFeatureData Interface

For a list of all members of this type, see [IProfileCenterMateFeatureData members](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this profile center mate.
 FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this profile center mate.
 LockRotation	Gets or sets whether to lock the rotation of this profile center mate.
 MateAlignment	Gets or sets the alignment of this profile center mate.
 OffsetDistance	Gets or sets the offset distance for this profile center mate.

[Top](#)

See Also

[IProfileCenterMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

EntitiesToMate Property (IProfileCenterMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileCenterMateFeatureData Interface](#) : EntitiesToMate Property (IProfileCenterMateFeatureData)

Gets or sets the entities to mate in this profile center mate.

Visual Basic Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)

```
Dim instance As IProfileCenterMateFeatureData  
Dim value As System.Object  
  
instance.EntitiesToMate = value  
  
value = instance.EntitiesToMate
```

Copy Code

C#

```
System.Object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) or [edges](#) to center align

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData::EntitiesToMate](#).

Example

See the [IProfileCenterMateFeatureData](#) examples.

Remarks

See Also

[IProfileCenterMateFeatureData Interface](#)
[IProfileCenterMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipDimension Property (IProfileCenterMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileCenterMateFeatureData Interface](#) : FlipDimension Property (IProfileCenterMateFeatureData)

Gets or sets whether to move entities to opposite sides of the dimension of this profile center mate.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipDimension As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProfileCenterMateFeatureData  
Dim value As System.Boolean
```

```
instance.FlipDimension = value
```

```
value = instance.FlipDimension
```

C#

```
System.bool FlipDimension {get; set;}
```

C++/CLI

```
property System.bool FlipDimension {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the dimension, false to not

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData::FlipDimension](#).

Example

See the [IProfileCenterMateFeatureData](#) examples.

See Also

[IProfileCenterMateFeatureData Interface](#)
[IProfileCenterMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LockRotation Property (IProfileCenterMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileCenterMateFeatureData Interface](#) : LockRotation Property (IProfileCenterMateFeatureData)

Gets or sets whether to lock the rotation of this profile center mate.

.NET Syntax

Visual Basic (Declaration)

Property LockRotation As System.Boolean

Visual Basic (Usage)



```
Dim instance As IProfileCenterMateFeatureData  
Dim value As System.Boolean
```

```
instance.LockRotation = value
```

```
value = instance.LockRotation
```

C#

```
System.bool LockRotation {get; set;}
```

C++/CLI

```
property System.bool LockRotation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to lock the rotation, false to not

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData::LockRotation](#).

Example

See the [IProfileCenterMateFeatureData](#) examples.

See Also

[IProfileCenterMateFeatureData Interface](#)
[IProfileCenterMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (IProfileCenterMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileCenterMateFeatureData Interface](#) : MateAlignment Property (IProfileCenterMateFeatureData)

Gets or sets the alignment of this profile center mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IProfileCenterMateFeatureData  
Dim value As System.Integer
```

```
instance.MateAlignment = value
```

```
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData::MateAlignment](#).

Example

See the [IProfileCenterMateFeatureData](#) examples.

Remarks

If this property is set to swMateAlign_e:

- swMateAlignALIGNED, then vectors normal to the selected entities point in the same direction.
- swMateAlignANTI_ALIGNED, then vectors normal to the selected entities point in opposite directions.

See Also

[IProfileCenterMateFeatureData Interface](#)
[IProfileCenterMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (IProfileCenterMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileCenterMateFeatureData Interface](#) : OffsetDistance Property (IProfileCenterMateFeatureData)

Gets or sets the offset distance for this profile center mate.

.NET Syntax

Visual Basic (Declaration)

Property OffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IProfileCenterMateFeatureData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance

Visual Basic for Applications (VBA) Syntax

See [ProfileCenterMateFeatureData::OffsetDistance](#).

Example

See the [IProfileCenterMateFeatureData](#) examples.

See Also

[IProfileCenterMateFeatureData Interface](#)
[IProfileCenterMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IProfileGroupFolder (Type)

IProfileGroupFolder Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProfileGroupFolder Interface

Allows access to a structure system profile group folder.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IProfileGroupFolder
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
```

C#

```
public interface IProfileGroupFolder
```

C++/CLI

```
public interface class IProfileGroupFolder
```

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

Remarks

See the [IStructureSystemFolder](#) Remarks.

Accessors

[IStructureSystemFolder::GetProfileGroupFolders](#)

Access Diagram

[ProfileGroupFolder](#)

See Also

[IProfileGroupFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IProfileGroupFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProfileGroupFolder Interface

For a list of all members of this type, see [IProfileGroupFolder members](#).

Public Methods

Name	Description
 GetFeature	Gets the profile group feature.
 GetPlane	Gets the profile sketch plane.
 GetSketch	Gets the profile sketch.
 GetStructureSystemMemberCount	Gets the number of structure system members in this profile group folder.
 GetStructureSystemMembers	Gets the structure system members in this profile group folder.

[Top](#)

See Also

[IProfileGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IProfileGroupFolder Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IProfileGroupFolder Interface

The following tables list the members exposed by [IProfileGroupFolder](#).

Public Properties

Name	Description
 ProfileSize	Gets the profile size for this member profile group.
 ProfileStandard	Gets the profile standard for this member profile group.
 ProfileType	Gets the profile type for this member profile group.

[Top](#)

Public Methods

Name	Description
 GetFeature	Gets the profile group feature.
 GetPlane	Gets the profile sketch plane.
 GetSketch	Gets the profile sketch.
 GetStructureSystemMemberCount	Gets the number of structure system members in this profile group folder.
 GetStructureSystemMembers	Gets the structure system members in this profile group folder.

[Top](#)

See Also

[IProfileGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IProfileGroupFolder Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IProfileGroupFolder Interface

For a list of all members of this type, see [IProfileGroupFolder members](#).

Public Properties

Name	Description
 ProfileSize	Gets the profile size for this member profile group.
 ProfileStandard	Gets the profile standard for this member profile group.
 ProfileType	Gets the profile type for this member profile group.

[Top](#)

See Also

[IProfileGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFeature Method (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : GetFeature Method (IProfileGroupFolder)

Gets the profile group feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::GetFeature](#).

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPlane Method (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : GetPlane Method (IProfileGroupFolder)

Gets the profile sketch plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlane() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
Dim value As System.Object

value = instance.GetPlane()
```

C#

```
System.object GetPlane()
```

C++/CLI

```
System.Object^ GetPlane();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRefPlane](#)

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::GetPlane](#).

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSketch Method (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder interface](#) : GetSketch Method (IProfileGroupFolder)

Gets the profile sketch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
Dim value As System.Object

value = instance.GetSketch()
```

C#

```
System.object GetSketch()
```

C++/CLI

```
System.Object^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISketch](#)

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::GetSketch](#).

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStructureSystemMemberCount Method (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : GetStructureSystemMemberCount Method (IProfileGroupFolder)

Gets the number of structure system members in this profile group folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStructureSystemMemberCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder  
Dim value As System.Integer  
  
value = instance.GetStructureSystemMemberCount()
```

C#

```
System.int GetStructureSystemMemberCount()
```

C++/CLI

```
System.int GetStructureSystemMemberCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of members in this profile group folder

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::GetStructureSystemMemberCount](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStructureSystemMembers Method (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : GetStructureSystemMembers Method (IProfileGroupFolder)

Gets the structure system members in this profile group folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStructureSystemMembers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder  
Dim value As System.Object
```

```
value = instance.GetStructureSystemMembers()
```

C#

```
System.object GetStructureSystemMembers()
```

C++/CLI

```
System.Object^ GetStructureSystemMembers();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IStructureSystemMemberFeatureDatas](#)

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::GetStructureSystemMembers](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileSize Property (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : ProfileSize Property (IProfileGroupFolder)

Gets the profile size for this member profile group.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ProfileSize As System.String
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
Dim value As System.String

value = instance.ProfileSize
```

C#

```
System.string ProfileSize {get;}
```

C++/CLI

```
property System.String^ ProfileSize {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile size as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::ProfileSize](#).

Remarks

This property:

- is valid only if a [IProfileGroupFolder::ProfileType](#) is set.
- may be overridden by [IStructureSystemMemberProfile::ProfileSize](#) for individual members.

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles*
- or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileStandard Property (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : ProfileStandard Property (IProfileGroupFolder)

Gets the profile standard for this member profile group.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ProfileStandard As System.String
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
Dim value As System.String

value = instance.ProfileStandard
```

C#

```
System.string ProfileStandard {get;}
```

C++/CLI

```
property System.String^ ProfileStandard {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile standard as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::ProfileStandard](#).

Remarks

This property may be overridden by [IStructureSystemMemberProfile::ProfileStandard](#) for individual members.

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles*
- or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileType Property (IProfileGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProfileGroupFolder Interface](#) : ProfileType Property (IProfileGroupFolder)

Gets the profile type for this member profile group.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ProfileType As System.String
```

Visual Basic (Usage)



```
Dim instance As IProfileGroupFolder
Dim value As System.String

value = instance.ProfileType
```

C#

```
System.string ProfileType {get;}
```

C++/CLI

```
property System.String^ ProfileType {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weldment profile type as defined in a weldment profile

Visual Basic for Applications (VBA) Syntax

See [ProfileGroupFolder::ProfileType](#).

Remarks

This property:

- is valid only if a [IProfileGroupFolder::ProfileStandard](#) is set.
- may be overridden by [IStructureSystemMemberProfile::ProfileType](#) for individual members.

Specify this property using strings found in:

- SOLIDWORKS-supplied weldment profile (*.sldlfp) from *install_dir\lang\lang_name\weldment profiles*
 - or -
- custom weldment profile (*.sldlfp); see the SOLIDWORKS Help for details about custom weldment profiles

See Also

[IProfileGroupFolder Interface](#)
[IProfileGroupFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

IProjectionArrow (Type)

IProjectionArrow Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProjectionArrow Interface

Allows access to a projection arrow.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IProjectionArrow
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow
```

C#

```
public interface IProjectionArrow
```

C++/CLI

```
public interface class IProjectionArrow
```

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

Accessors

[IView::GetProjectArrow](#) and [IView::IGetProjectArrow](#)

[IView::GetProjectLines](#) and [IView::IGetProjectLines](#)

Access Diagram

[ProjectionArrow](#)

See Also

[IProjectionArrow Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IProjectionArrow Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProjectionArrow Interface

The following tables list the members exposed by [IProjectionArrow](#).

Public Properties

Name	Description
 Visible	Gets whether the projection arrow is visible.

 Public Methods

Name	Description
 GetCoordinates	Gets the location of this projection arrow's line and its label.
 GetLabel	Gets the label for this view's projection arrow.
 GetProjectedView	Gets the projected view.
 GetTextFormat	Gets the format of the text for this projection arrow.
 GetUseDocTextFormat	Gets whether the document default auxiliary text format is being used.
 GetView	Gets the base drawing view for this projection arrow.
 IGetCoordinates	Gets the location of this projection arrow's line and its label.
 IGetProjectedView	Gets the projected view.
 IGetTextFormat	Gets the format of the text for this projection arrow.
 IGetView	Gets the base drawing view for this projection arrow.
 SetLabel	Sets the label for this view's projection arrow.

 See Also

[IProjectionArrow Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

IProjectionArrow Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProjectionArrow Interface

For a list of all members of this type, see [IProjectionArrow members](#).

 Public Methods

Name	Description
 GetCoordinates	Gets the location of this projection arrow's line and its label.
 GetLabel	Gets the label for this view's projection arrow.
 GetProjectedView	Gets the projected view.
 GetTextFormat	Gets the format of the text for this projection arrow.
 GetUseDocTextFormat	Gets whether the document default auxiliary text format is being used.
 GetView	Gets the base drawing view for this projection arrow.
 IGetCoordinates	Gets the location of this projection arrow's line and its label.
 IGetProjectedView	Gets the projected view.
 IGetTextFormat	Gets the format of the text for this projection arrow.
 IGetView	Gets the base drawing view for this projection arrow.
 SetLabel	Sets the label for this view's projection arrow.

 See Also

[IProjectionArrow Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

IProjectionArrow Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProjectionArrow Interface

For a list of all members of this type, see [IProjectionArrow members](#).

Public Properties

Name	Description
 Visible	Gets whether the projection arrow is visible.

[Top](#)

See Also

[IProjectionArrow Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoordinates Method (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetCoordinates Method (IProjectionArrow)

Gets the location of this projection arrow's line and its label.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoordinates() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Object  
  
value = instance.GetCoordinates()
```

C#

```
System.object GetCoordinates()
```

C++/CLI

```
System.Object^ GetCoordinates();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 24 doubles containing starting and ending x,y,z points of the projection arrow and the x,y,z point for its label (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetCoordinates](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

Remarks

The doubles at indexes 0, 1, and 2 are the starting point of the projection arrow; the doubles at indexes 3, 4, and 5 are the ending point of the projection arrow. The doubles at indexes 21, 22, and 23 are the label location. All other doubles in the array are duplicates of these values.

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::IGetCoordinates Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLabel Method (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetLabel Method (IProjectionArrow)

Gets the label for this view's projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLabel() As System.String
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.String  
  
value = instance.GetLabel()
```

C#

```
System.string GetLabel()
```

C++/CLI

```
System.String^ GetLabel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Label for this projection arrow

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetLabel](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::SetLabel Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProjectedView Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetProjectedView Method (IProjectionArrow)

Gets the projected view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectedView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Object  
  
value = instance.GetProjectedView()
```

C#

```
System.object GetProjectedView()
```

C++/CLI

```
System.Object^ GetProjectedView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Projected [view](#) from which this projection arrow is referenced

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetProjectedView](#).

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::IGetProjectedView Method](#)
[IProjectionArrow::GetView Method](#)
[IProjectionArrow::IGetView Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFormat Method (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetTextFormat Method (IProjectionArrow)

Gets the format of the text for this projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Object  
  
value = instance.GetTextFormat()
```

C#

```
System.object GetTextFormat()
```

C++/CLI

```
System.Object^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Text format](#)

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetTextFormat](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetTextFormat Method](#)
[IProjectionArrow::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocTextFormat Method (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetUseDocTextFormat Method (IProjectionArrow)

Gets whether the document default auxiliary text format is being used.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the documents auxiliary text formatting is used, false if not

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetUseDocTextFormat](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetTextFormat Method](#)
[IProjectionArrow::IGetTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetView Method (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : GetView Method (IProjectionArrow)

Gets the base drawing view for this projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function GetView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Object  
  
value = instance.GetView()
```

C#

```
System.object GetView()
```

C++/CLI

```
System.Object^ GetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Base drawing [view](#) object from which this projection arrow is referenced

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::GetView](#).

Example

[Get Arrow in Projected View \(C#\)](#)
[Get Arrow in Projected View \(VB.NET\)](#)
[Get Arrow in Projected View \(VBA\)](#)

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::IGetView Method](#)
[IProjectionArrow::GetProjectedView Method](#)
[IProjectionArrow::IGetProjectedView Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetCoordinates Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : IGetCoordinates Method (IProjectionArrow)

Gets the location of this projection arrow's line and its label.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCoordinates() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Double  
  
value = instance.IGetCoordinates()
```

C#

```
System.double IGetCoordinates()
```

C++/CLI

```
System.double IGetCoordinates();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 24 doubles containing starting and ending x,y,z points of the projection arrow and the x,y,z point of its label (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The doubles at indexes 0, 1, and 2 are the starting point of the projection arrow; the doubles at indexes 3, 4, and 5 are the ending point of the projection arrow. The doubles at indexes 21, 22, and 23 are the label location. All other doubles in the array are duplicates of these values.

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetCoordinates Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetProjectedView Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : IGetProjectedView Method (IProjectionArrow)

Gets the projected view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProjectedView() As View
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow
Dim value As View

value = instance.IGetProjectedView()
```

C#

```
View IGetProjectedView()
```

C++/CLI

```
View^ IGetProjectedView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Projected [view](#) from which this projection arrow is referenced

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow.IGetProjectedView](#).

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetProjectedView Method](#)
[IProjectionArrow::GetView Method](#)
[IProjectionArrow::IGetView Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextFormat Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : IGetTextFormat Method (IProjectionArrow)

Gets the format of the text for this projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormat() As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow
Dim value As TextFormat

value = instance.IGetTextFormat()
```

C#

```
TextFormat IGetTextFormat()
```

C++/CLI

```
TextFormat^ IGetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Text format](#)

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::IGetTextFormat](#).

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetTextFormat Method](#)
[IProjectionArrow::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetView Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : IGetView Method (IProjectionArrow)

Gets the base drawing view for this projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetView() As View
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As View  
  
value = instance.IGetView()
```

C#

```
View IGetView()
```

C++/CLI

```
View^ IGetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Base drawing [view](#) object from which this projection arrow is referenced

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::IGetView](#).

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetView Method](#)
[IProjectionArrow::GetProjectedView Method](#)
[IProjectionArrow::IGetProjectedView Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLabel Method (IProjectionArrow)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : SetLabel Method (IProjectionArrow)

Sets the label for this view's projection arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLabel(_  
    ByVal Label As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim Label As System.String  
Dim value As System.Boolean  
  
value = instance.SetLabel(Label)
```

C#

```
System.bool SetLabel(  
    System.string Label  
)
```

C++/CLI

```
System.bool SetLabel(  
    & System.String^ Label  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Label

Label for this projection arrow

Return Value

True if setting the label is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow::SetLabel](#).

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)
[IProjectionArrow::GetLabel Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (IProjectionArrow)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionArrow Interface](#) : Visible Property (IProjectionArrow)

Gets whether the projection arrow is visible.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IProjectionArrow  
Dim value As System.Boolean
```

```
value = instance.Visible
```

C#

```
System.bool Visible {get;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if projection arrow is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [ProjectionArrow.Visible](#).

Example

[Is There a Projection Arrow and Is It Visible \(C#\)](#)
[Is There a Projection Arrow and Is It Visible \(VB.NET\)](#)
[Is There a Projection Arrow and Is It Visible \(VBA\)](#)

See Also

[IProjectionArrow Interface](#)
[IProjectionArrow Members](#)

Availability

SOLIDWORKS 2009 SP03, Revision Number 17.3