

SOLIDWORKS API (.NET VBA C#) — Reference (228/337): IProjectionCurveFeatureData- IPropertyManagerPage

SOLIDWORKS API Documentation (converted from CHM)

IProjectionCurveFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IProjectionCurveFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IProjectionCurveFeatureData Interface

Allows access to a projection curve feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IProjectionCurveFeatureData
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData
```

C#

```
public interface IProjectionCurveFeatureData
```

C++/CLI

```
public interface class IProjectionCurveFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData](#).

Example

[Get Projected Curve \(VBA\)](#)

Remarks

To create a projection curve feature:

1. Use [IModelDocExtension::SelectByID2](#) to pre-select the necessary entities using the following Marks:
 - target faces on which to project a sketch = 1
 - sketch to project = 2
 - target sketch on which to project a sketch = 4
 - projection direction entity = 8
2. Call [IFeatureManager::CreateDefinition\(swFmRefCurve\)](#) to access this interface.
3. Set non-entity properties on this interface.
4. Call [IFeatureManager::CreateFeature](#) to create the projection curve feature.

See the SOLIDWORKS Help for more information about projection curve features.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[ProjectionCurveFeatureData](#)

See Also

[IProjectionCurveFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IProjectionCurveFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IProjectionCurveFeatureData Interface

The following tables list the members exposed by [IProjectionCurveFeatureData](#).

Public Properties

Name	Description
 Bidirectional	Gets or sets whether the sketch is projected bidirectionally.
 FaceArray	Gets or sets the target faces for this projected curve.
 Reverse	Reverses the direction that the curve is projected.
 Sketch	Gets or sets the sketch to project in this projection curve feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the projected curve.
 GetFaceArrayCount	Gets the number of target faces for this projected curve.
 IAccessSelections	Obsolete. Superseded by IProjectionCurveFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections used to define the projected curve.
 IGetFaceArray	Gets a list of target faces for the projected curve.
 ISetFaceArray	Sets the target faces for the projected curve.
 ReleaseSelectionAccess	Releases access to the selections that created this projected curve.

[Top](#)

See Also

[IProjectionCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IProjectionCurveFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IProjectionCurveFeatureData Interface

For a list of all members of this type, see [IProjectionCurveFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the projected curve.
 GetFaceArrayCount	Gets the number of target faces for this projected curve.
 IAccessSelections	Obsolete. Superseded by IProjectionCurveFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections used to define the projected curve.
 IGetFaceArray	Gets a list of target faces for the projected curve.
 ISetFaceArray	Sets the target faces for the projected curve.
 ReleaseSelectionAccess	Releases access to the selections that created this projected curve.

[Top](#)

See Also

IProjectionCurveFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IProjectionCurveFeatureData Interface

For a list of all members of this type, see [IProjectionCurveFeatureData members](#).

Public Properties

Name	Description
 Bidirectional	Gets or sets whether the sketch is projected bidirectionally.
 FaceArray	Gets or sets the target faces for this projected curve.
 Reverse	Reverses the direction that the curve is projected.
 Sketch	Gets or sets the sketch to project in this projection curve feature.

[Top](#)

See Also

[IProjectionCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

AccessSelections Method (IProjectionCurveFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : AccessSelections Method (IProjectionCurveFeatureData)

Gains access to the selections used to define the projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
    & System.Object^ TopDoc,  
    & System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::AccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IProjectionCurveFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)
[IProjectionCurveFeatureData::IAccessSelections2 Method](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help [Send comments on this topic.](#)

Bidirectional Property (IProjectionCurveFeatureData)
[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : Bidirectional Property (IProjectionCurveFeatureData)

Gets or sets whether the sketch is projected bidirectionally.

 .NET Syntax

Visual Basic (Declaration)

Property Bidirectional As System.Boolean

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim value As System.Boolean
```

```
instance.Bidirectional = value  
value = instance.Bidirectional
```

C#

```
System.bool Bidirectional {get; set;}
```

C++/CLI

```
property System.bool Bidirectional {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if bidirectional, false if not

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::Bidirectional](#).

Example

See the [IProjectionCurveFeatureData](#) example.

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FaceArray Property (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : FaceArray Property (IProjectionCurveFeatureData)

Gets or sets the target faces for this projected curve.

.NET Syntax

Visual Basic (Declaration)

Property FaceArray As System.Object

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim value As System.Object
```

```
instance.FaceArray = value
```

```
value = instance.FaceArray
```

C#

```
System.Object FaceArray {get; set;}
```

C++/CLI

```
property System.Object^ FaceArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of faces that describe the projected curve

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::FaceArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)
[IProjectionCurveFeatureData::GetFaceArrayCount Method](#)
[IProjectionCurveFeatureData::IGetFaceArray Method](#)
[IProjectionCurveFeatureData::ISetFaceArray Method](#)
[IProjectionCurveFeatureData::Reverse Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceArrayCount Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : GetFaceArrayCount Method (IProjectionCurveFeatureData)

Gets the number of target faces for this projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceArrayCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim value As System.Integer  
  
value = instance.GetFaceArrayCount()
```

C#

```
System.int GetFaceArrayCount()
```

C++/CLI

```
System.int GetFaceArrayCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces for this projected curve

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::GetFaceArrayCount](#).

Remarks

Call this method before calling [IProjectionCurveFeatureData::IGetFaceArray](#).

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)
[IProjectionCurveFeatureData::ISetFaceArray Method](#)
[IProjectionCurveFeatureData::FaceArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : IAccessSelections Method (IProjectionCurveFeatureData)

Obsolete. Superseded by [IProjectionCurveFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::IAccessSelections](#).

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : IAccessSelections2 Method (IProjectionCurveFeatureData)

Gains access to the selections used to define the projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

```
Dim instance As IProjectionCurveFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections2(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IProjectionCurveFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IProjectionCurveFeatureData Interface](#)

[IProjectionCurveFeatureData Members](#)

[IProjectionCurveFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaceArray Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : IGetFaceArray Method (IProjectionCurveFeatureData)

Gets a list of target faces for the projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaceArray( _  
    ByVal FaceCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim FaceCount As System.Integer  
Dim value As System.Object  
  
value = instance.IGetFaceArray(FaceCount)
```

C#

```
System.object IGetFaceArray(  
    System.int FaceCount  
)
```

C++/CLI

```
System.Object^ IGetFaceArray(  
& System.int FaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of target faces

Return Value

- in-process, unmanaged C++: Pointer to an array of target faces of size FaceCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IProjectionCurveFeatureData::GetFaceArrayCount](#) before calling this method to get the value of FaceCount.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)
[IProjectionCurveFeatureData::ISetFaceArray Method](#)
[IProjectionCurveFeatureData::FaceArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFaceArray Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : ISetFaceArray Method (IProjectionCurveFeatureData)

Sets the target faces for the projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaceArray( _
    ByVal FaceCount As System.Integer, _
    ByRef ArrayDataIn As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData
Dim FaceCount As System.Integer
Dim ArrayDataIn As System.Object

instance.ISetFaceArray(FaceCount, ArrayDataIn)
```

C#

```
void ISetFaceArray(
    System.int FaceCount,
    ref System.object ArrayDataIn
)
```

C++/CLI

```
void ISetFaceArray(
    & System.int FaceCount,
    & System.Object^% ArrayDataIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of target faces

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of target faces of size FaceCount

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IProjectionCurveFeatureData Interface](#)

[IProjectionCurveFeatureData Members](#)

[IProjectionCurveFeatureData::GetFaceArrayCount Method](#)

[IProjectionCurveFeatureData::IGetFaceArray Method](#)

[IProjectionCurveFeatureData::FaceArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : ReleaseSelectionAccess Method (IProjectionCurveFeatureData)

Releases access to the selections that created this projected curve.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::ReleaseSelectionAccess](#).

Remarks

[IProjectionCurveFeatureData::AccessSelections](#) and [IProjectionCurveFeatureData::IAccessSelections2](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Reverse Property (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : Reverse Property (IProjectionCurveFeatureData)

Reverses the direction that the curve is projected.

.NET Syntax

Visual Basic (Declaration)

```
Property Reverse As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim value As System.Boolean  
  
instance.Reverse = value  
  
value = instance.Reverse
```

C#

```
System.bool Reverse {get; set;}
```

C++/CLI

```
property System.bool Reverse {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of this projected curve, false to not

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::Reverse](#).

Example

See the [IProjectionCurveFeatureData](#) example.

Remarks

If all faces in [IProjectionCurveFeatureData::FaceArray](#) are on the same side with respect to [IProjectionCurveFeatureData::Sketch](#), then this property is ignored. The projection direction is calculated from the selected sketches and faces.

You can reverse the direction in which the curve is projected when the selected face wraps around the plane of the curve. For example, if the sketch being projected is surrounded by a cylindrical face, then two possible projections exist. If this property is set to true, the direction based on the normal vector of the sketch is reversed. The default direction is along the sketch normal.

See Also

[IProjectionCurveFeatureData Interface](#)
[IProjectionCurveFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Sketch Property (IProjectionCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IProjectionCurveFeatureData Interface](#) : Sketch Property (IProjectionCurveFeatureData)

Gets or sets the sketch to project in this projection curve feature.

.NET Syntax

Visual Basic (Declaration)

Property Sketch As System.Object

Visual Basic (Usage)



```
Dim instance As IProjectionCurveFeatureData  
Dim value As System.Object
```

```
instance.Sketch = value
```

```
value = instance.Sketch
```

C#

```
System.object Sketch {get; set;}
```

C++/CLI

```
property System.Object^ Sketch {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[ISketch](#)

Visual Basic for Applications (VBA) Syntax

See [ProjectionCurveFeatureData::Sketch](#).

Remarks

You cannot use this property to get or set the target sketch for sketch-on-sketch projection curve features. You can only pre-select the target sketch before creating the feature. See the [IProjectionCurveFeatureData](#) Remarks.

Use [IFeature::GetSpecificFeature2](#) to get the ISketch object from the selected [IFeature](#) object.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IProjectionCurveFeatureData Interface](#)

[IProjectionCurveFeatureData Members](#)

[IProjectionCurveFeatureData::Reverse Property\(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IPropertyManagerPage (Type)

IPropertyManagerPage Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage Interface

Obsolete. Superseded by [IPropertyManagerPage2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPage
```

Visual Basic (Usage) [Copy Code](#)

```
Dim instance As IPropertyManagerPage
```

C#

```
public interface IPropertyManagerPage
```

C++/CLI

```
public interface class IPropertyManagerPage
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage](#).

See Also

[IPropertyManagerPage Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPage Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage Interface

For a list of all members of this type, see [IPropertyManagerPage members](#).

Public Methods

Name	Description
GetDialogWindow	Obsolete. Not superseded.
GetGroupExpanded	Obsolete. Not superseded.
GetGroupVisible	Obsolete. Not superseded.
SetButtons	Obsolete. Not superseded.
SetGroupExpanded	Obsolete. Not superseded.
SetGroupRange	Obsolete. Not superseded.
SetGroupVisible	Obsolete. Not superseded.
Show	Obsolete. Superseded by IPropertyManagerPage2.Show2 .

[Top](#)

See Also

IPropertyManagerPage Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage Interface

The following tables list the members exposed by [IPropertyManagerPage](#).

Public Methods

Name	Description
 GetDialogWindow	Obsolete. Not superseded.
 GetGroupExpanded	Obsolete. Not superseded.
 GetGroupVisible	Obsolete. Not superseded.
 SetButtons	Obsolete. Not superseded.
 SetGroupExpanded	Obsolete. Not superseded.
 SetGroupRange	Obsolete. Not superseded.
 SetGroupVisible	Obsolete. Not superseded.
 Show	Obsolete. Superseded by IPropertyManagerPage2.Show2 .

[Top](#)

See Also

[IPropertyManagerPage Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

GetDialogWindow Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : GetDialogWindow Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDialogWindow(  
    ByRef Status As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPage  
Dim Status As System.Integer  
Dim value As System.Integer  
  
value = instance.GetDialogWindow(Status)
```

C#

```
System.int GetDialogWindow(  
    out System.int Status  
)
```

C++/CLI

```
System.int GetDialogWindow(  
    & [Out] System.int Status  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Status

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::GetDialogWindow](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGroupExpanded Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : GetGroupExpanded Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGroupExpanded(  
    ByVal GroupID As System.Integer, _  
    ByRef Status As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim GroupID As System.Integer  
Dim Status As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetGroupExpanded(GroupID, Status)
```

C#

```
System.bool GetGroupExpanded(  
    System.int GroupID,  
    out System.int Status  
)
```

C++/CLI

```
System.bool GetGroupExpanded(  
& System.int GroupID,  
& [Out] System.int Status  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID

Status

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::GetGroupExpanded](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)

GetGroupVisible Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : GetGroupVisible Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGroupVisible( _  
    ByVal GroupID As System.Integer, _  
    ByRef Status As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim GroupID As System.Integer  
Dim Status As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetGroupVisible(GroupID, Status)
```

C#

```
System.bool GetGroupVisible(  
    System.int GroupID,  
    out System.int Status  
)
```

C++/CLI

```
System.bool GetGroupVisible(  
& System.int GroupID,  
& [Out] System.int Status  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID

Status

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::GetGroupVisible](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)

SetButtons Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : SetButtons Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function SetButtons( _  
    ByVal ButtonTypes As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim ButtonTypes As System.Integer  
Dim value As System.Integer  
  
value = instance.SetButtons(ButtonTypes)
```

C#

```
System.int SetButtons(  
    System.int ButtonTypes  
)
```

C++/CLI

```
System.int SetButtons(  
&    System.int ButtonTypes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ButtonTypes

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::SetButtons](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetGroupExpanded Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : SetGroupExpanded Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function SetGroupExpanded( _  
    ByVal GroupID As System.Integer, _  
    ByVal Expanded As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim GroupID As System.Integer  
Dim Expanded As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetGroupExpanded(GroupID, Expanded)
```

C#

```
System.int SetGroupExpanded(  
    System.int GroupID,  
    System.bool Expanded  
)
```

C++/CLI

```
System.int SetGroupExpanded(  
& System.int GroupID,  
& System.bool Expanded  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID

Expanded

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::SetGroupExpanded](#).

See Also

[IPropertyManagerPage Interface](#)

[IPropertyManagerPage Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetGroupRange Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : SetGroupRange Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function SetGroupRange( _  
    ByVal FirstGroupId As System.Integer, _  
    ByVal FirstCheckId As System.Integer, _  
    ByVal GroupCount As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim FirstGroupId As System.Integer  
Dim FirstCheckId As System.Integer  
Dim GroupCount As System.Integer  
Dim value As System.Integer
```

```
value = instance.SetGroupRange(FirstGroupId, FirstCheckId, GroupCount)
```

C#

```
System.int SetGroupRange(  
    System.int FirstGroupId,  
    System.int FirstCheckId,  
    System.int GroupCount  
)
```

C++/CLI

```
System.int SetGroupRange(  
& System.int FirstGroupId,
```

```
& System.int FirstCheckId,  
& System.int GroupCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstGroupId

FirstCheckId

GroupCount

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::SetGroupRange](#).

See Also

[IPropertyManagerPage Interface](#)

[IPropertyManagerPage Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetGroupVisible Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : SetGroupVisible Method (IPropertyManagerPage)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function SetGroupVisible(  
    ByVal GroupID As System.Integer, _  
    ByVal Visible As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim GroupID As System.Integer  
Dim Visible As System.Boolean  
Dim value As System.Integer
```

```
value = instance.SetGroupVisible(GroupID, Visible)
```

C#

```
System.int SetGroupVisible(  
    System.int GroupID,  
    System.bool Visible  
)
```

C++/CLI

```
System.int SetGroupVisible(  
& System.int GroupID,  
& System.bool Visible  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID

Visible

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::SetGroupVisible](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Show Method (IPropertyManagerPage)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage Interface](#) : Show Method (IPropertyManagerPage)

Obsolete. Superseded by [IPropertyManagerPage2::Show2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Show() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage  
Dim value As System.Integer  
  
value = instance.Show()
```

C#

```
System.int Show()
```

C++/CLI

```
System.int Show();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage::Show](#).

See Also

[IPropertyManagerPage Interface](#)
[IPropertyManagerPage Members](#)