

SOLIDWORKS API (.NET VBA C#) — Reference

(233/337): IPropertyManagerPageSlider-
IPunchTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IPropertyManagerPageSlider (Type)

IPropertyManagerPageSlider Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageSlider Interface

Allows you to access a [PropertyManager page](#) slider control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageSlider
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider
```

C#

```
public interface IPropertyManagerPageSlider
```

C++/CLI

```
public interface class IPropertyManagerPageSlider
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider](#).

Example

See the [IPropertyManagerPage2](#) examples.

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageSlider](#)

See Also

[IPropertyManagerPageSlider Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageSlider Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageSlider Interface

The following tables list the members exposed by [IPropertyManagerPageSlider](#).

Public Properties

Name	Description
 Height	Gets or sets the height of the slider control.
 LineSize	Gets or sets how much the slider moves when the arrow keys are used to move the slider.
 PageSize	Gets or sets how much the slider moves when the Page Up or Page Down keys are used to move the slider.
 Position	Gets or sets the current position of the slider.
 Style	Gets or sets the display properties of a slider control.
 TickFrequency	Gets or sets the frequency of tick marks on a slider.

[Top](#)

Public Methods

Name	Description
 GetRange	Gets the range of the slider.
 SetRange	Sets the range of a slider.

[Top](#)

See Also

[IPropertyManagerPageSlider Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageSlider Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageSlider Interface

For a list of all members of this type, see [IPropertyManagerPageSlider members](#).

Public Methods

Name	Description
 GetRange	Gets the range of the slider.
 SetRange	Sets the range of a slider.

[Top](#)

See Also

[IPropertyManagerPageSlider Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageSlider Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageSlider Interface

For a list of all members of this type, see [IPropertyManagerPageSlider members](#).

Public Properties

Name	Description
 Height	Gets or sets the height of the slider control.
 LineSize	Gets or sets how much the slider moves when the arrow keys are used to move the slider.
 PageSize	Gets or sets how much the slider moves when the Page Up or Page Down keys are used to move the slider.
 Position	Gets or sets the current position of the slider.
 Style	Gets or sets the display properties of a slider control.



[TickFrequency](#)

Gets or sets the frequency of tick marks on a slider.

[Top](#)

See Also

[IPropertyManagerPageSlider Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRange Method (IPropertyManagerPageSlider)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : GetRange Method (IPropertyManagerPageSlider)

Gets the range of the slider.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetRange( _  
    ByRef Min As System.Integer, _  
    ByRef Max As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider  
Dim Min As System.Integer  
Dim Max As System.Integer  
  
instance.GetRange(Min, Max)
```

C#

```
void GetRange(  
    out System.int Min,  
    out System.int Max  
)
```

C++/CLI

```
void GetRange(  
& [Out] System.int Min,  
& [Out] System.int Max  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Min
Minimum range of slider
Max
Maximum range of slider

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::GetRange](#).

Remarks

Use [IPropertyManagerPageSlider::SetRange](#) to set the range of the slider.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : Height Property (IPropertyManagerPageSlider)

Gets or sets the height of the slider control.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider  
Dim value As System.Short
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of slider control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider.Height](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

You can only set this property before the PropertyManager page is displayed.

Normally you should not use this property because SOLIDWORKS will size the slider appropriately based on its orientation and display properties. However, the complexity of the PropertyManager page's layout may make it necessary to use this property with [IPropertyManagerPageControl::Left](#), [IPropertyManagerPageControl::Top](#), and [IPropertyManagerPageControl::Width](#) to get the desired look.

This property is also for creating a small slider by clearing the [IPropertyManagerPageSlider::Style](#) swPropMgrPageSliderStyle_AutoTicks bit and setting Height to a value less than the default. A horizontal slider without tick marks has a default height of 16. This height is in dialog-box units. You can convert this value to screen units (pixels) by using the Windows MapDialogRect function.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LineSize Property (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : LineSize Property (IPropertyManagerPageSlider)

Gets or sets how much the slider moves when the arrow keys are used to move the slider.

Visual Basic Syntax

Visual Basic (Declaration)

Property LineSize As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider
Dim value As System.Integer
```

```
instance.LineSize = value
```

```
value = instance.LineSize
```

C#

```
System.int LineSize {get; set;}
```

C++/CLI

```
property System.int LineSize {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

How much the slider moves when arrow keys are used to move the slider

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::LineSize](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

If you do not set this property, the value defaults to 1.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PageSize Property (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : PageSize Property (IPropertyManagerPageSlider)

Gets or sets how much the slider moves when the Page Up or Page Down keys are used to move the slider.

.NET Syntax

Visual Basic (Declaration)

```
Property PageSize As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider  
Dim value As System.Integer
```

```
instance.PageSize = value
```

```
value = instance.PageSize
```

C#

```
System.int PageSize {get; set;}
```

C++/CLI

```
property System.int PageSize {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

How much the slider moves when the Page Up or Page Down keys are used to move the slider

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::PageSize](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

If this property is not used to specified how the slider moves when the Page Up or Page Down keys are used to move the slider, the value defaults to 2.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Position Property (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : Position Property (IPropertyManagerPageSlider)

Gets or sets the current position of the slider.

.NET Syntax

```
Property Position As System.Integer
```



```
Dim instance As IPropertyManagerPageSlider
Dim value As System.Integer

instance.Position = value

value = instance.Position
```

```
System.int Position {get; set;}
```

```
property System.int Position {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Current position of slider

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::Position](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

Position must be a value within the specified range. To get the range, use [IPropertyManagerPageSlider::GetRange](#); to set the range, use [IPropertyManagerPageSlider::SetRange](#).

If you do not set the initial position of a slider, then the value defaults to a position of 5.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SetRange Method (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : SetRange Method (IPropertyManagerPageSlider)

Sets the range of a slider.

.NET Syntax

```
Function SetRange( _
    ByVal Min As System.Integer, _
```



```
ByVal Max As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageSlider  
Dim Min As System.Integer  
Dim Max As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetRange(Min, Max)
```

C#

```
System.bool SetRange(  
    System.int Min,  
    System.int Max  
)
```

C++/CLI

```
System.bool SetRange(  
& System.int Min,  
& System.int Max  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Min

Minimum range of slider

Max

Maximum range of slider

Return Value

True if range is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::SetRange](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

If you do not use this method to specify the range, it will default to a range of 0 to 10. Use [IPropertyManagerPageStyle::GetRange](#) to get the current range of the slider.

See Also

[IPropertyManagerPageSlider Interface](#)

[IPropertyManagerPageSlider Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Style Property (IPropertyManagerPageSlider)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : Style Property (IPropertyManagerPageSlider)

Gets or sets the display properties of a slider control.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

```
Dim instance As IPropertyManagerPageSlider
Dim value As System.Integer

instance.Style = value

value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Display properties of slider control as defined in [swPropMgrPageSliderStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::Style](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

If you do not set the any display properties, then the value is set to 0, which means:

- Slider is horizontal.
- Slider has not ticks.
- Your application is only notified when the user is done dragging the slider to move it.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TickFrequency Property (IPropertyManagerPageSlider)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageSlider Interface](#) : TickFrequency Property (IPropertyManagerPageSlider)

Gets or sets the frequency of tick marks on a slider.

.NET Syntax

Visual Basic (Declaration)

```
Property TickFrequency As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageSlider
Dim value As System.Integer
```

```
instance.TickFrequency = value  
value = instance.TickFrequency
```

C#

```
System.int TickFrequency {get; set;}
```

C++/CLI

```
property System.int TickFrequency {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Frequency of tick marks on slider

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageSlider::TickFrequency](#).

Remarks

If you set the frequency to 1, then a tick mark appears on every increment in the [range](#). A value of 10 means that a tick mark appears every 10 increments in the range. If you do not set a frequency, then the frequency of tick marks default to 1.

[IPropertyManagerPageSlider::Style](#) must be set to swPropMgrPageSliderStyle_AutoTicks to set IPropertyManagerPageSlider::TickFrequency.

See Also

[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageSlider Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

IPropertyManagerPageTab (Type)

IPropertyManagerPageTab Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTab Interface

Allows you to access a [PropertyManager page](#) tab control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IPropertyManagerPageTab

Visual Basic (Usage)

Dim instance As [IPropertyManagerPageTab](#)

C#

public interface IPropertyManagerPageTab

C++/CLI

public interface class IPropertyManagerPageTab

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddTab](#)

Access Diagram

[PropertyManagerPageTab](#)

See Also

[IPropertyManagerPageTab Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageTab Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTab Interface

For a list of all members of this type, see [IPropertyManagerPageTab members](#).

Public Methods

Name	Description
Activate	Activates this tab in the PropertyManager page.

	AddControl	Obsolete. Superseded by IPropertyManagerPageTab::AddControl2 .
	AddControl2	Adds a control to this tab on a PropertyManager page.
	AddGroupBox	Adds a group box to this tab on a PropertyManager page.
	IAddControl	Obsolete. Superseded by IPropertyManagerPageTab::AddControl2 .
	IAddGroupBox	Adds a group box to this tab on a PropertyManager page.

[Top](#)

See Also

[IPropertyManagerPageTab Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageTab Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTab Interface

The following tables list the members exposed by [IPropertyManagerPageTab](#).

Public Properties

Name	Description
 Caption	Gets or sets the caption for this tab.

[Top](#)

Public Methods

Name	Description
 Activate	Activates this tab in the PropertyManager page.
 AddControl	Obsolete. Superseded by IPropertyManagerPageTab::AddControl2 .
 AddControl2	Adds a control to this tab on a PropertyManager page.
 AddGroupBox	Adds a group box to this tab on a PropertyManager page.
 IAddControl	Obsolete. Superseded by IPropertyManagerPageTab::AddControl2 .
 IAddGroupBox	Adds a group box to this tab on a PropertyManager page.

[Top](#)

See Also

[IPropertyManagerPageTab Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageTab Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTab Interface

For a list of all members of this type, see [IPropertyManagerPageTab members](#).

Public Properties

Name	Description
 Caption	Gets or sets the caption for this tab.

[Top](#)

See Also

Activate Method (IPropertyManagerPageTab)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : Activate Method (IPropertyManagerPageTab)

Activates this tab in the PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function Activate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab  
Dim value As System.Boolean  
  
value = instance.Activate()
```

C#

```
System.bool Activate()
```

C++/CLI

```
System.bool Activate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::Activate](#).

Example

[Activate PropertyManager Page Tab \(VBA\)](#)
[Activate PropertyManager Page Tab \(VB.NET\)](#)
[Activate PropertyManager Page Tab \(C#\)](#)

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)

Availability

SOLIDWORKS 2009 SP1, Revision Number 17.1

AddControl Method (IPropertyManagerPageTab)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : AddControl Method (IPropertyManagerPageTab)

Obsolete. Superseded by [IPropertyManagerPageTab::AddControl2](#).

Visual Basic (Declaration)

```
Function AddControl( _
    ByVal ID As System.Integer, _
    ByVal ControlType As System.Short, _
    ByVal Caption As System.String, _
    ByVal LeftAlign As System.Short, _
    ByVal Options As System.Integer, _
    ByVal Tip As System.String _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab
Dim ID As System.Integer
Dim ControlType As System.Short
Dim Caption As System.String
Dim LeftAlign As System.Short
Dim Options As System.Integer
Dim Tip As System.String
Dim value As System.Object

value = instance.AddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
System.object AddControl(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)
```

C++/CLI

```
System.Object^ AddControl(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of this control
ControlType
Type of control as defined in [swPropertyManagerPageControlType_e](#)
Caption
Caption of the control
LeftAlign
Left alignment of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)
Options
Options as defined in [swAddControlOptions_e](#) (see **Remarks**)
Tip
Tool tip text for the control

Return Value

Newly created [PropertyManager_page tab control](#)

See [PropertyManagerPageTab::AddControl](#).

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

This method associates controls with a tab. When a user clicks a tab, controls associated with that tab are automatically shown and controls not associated with that tab are automatically hidden.

However, any controls added to a tab using [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::!AddControl](#) are not associated with the tab; you must still hide and show those controls. But, because the name of this method and its parameters are identical to [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::!AddControl](#), switching to this method and cleaning up your handler code should be easy.

To add a control to a group box associated with a tab, add the controls from the [group box](#). Only use this method to add controls not associated with group boxes.

When you specify `swControlOptions_SmallGapAbove` for the Options parameter, gap is used between a new control and the previous control that is smaller than the typical gap.

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)
[IPropertyManagerPageTab::!AddControl Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddControl2 Method (IPropertyManagerPageTab)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : AddControl2 Method (IPropertyManagerPageTab)

Adds a control to this tab on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddControl2(  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short  
Dim Options As System.Integer  
Dim Tip As System.String  
Dim value As System.Object
```

```
value = instance.AddControl2(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
System.object AddControl2(  
    System.int ID,  
    System.short ControlType,  
    System.string Caption,  
    System.short LeftAlign,  
    System.int Options,  
    System.string Tip  
)
```



```

System.Object^ AddControl2(
& System.int ID,
& System.short ControlType,
& System.String^ Caption,
& System.short LeftAlign,
& System.int Options,
& System.String^ Tip
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Resource ID of this control

ControlType

Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption

Caption of the control

LeftAlign

Left alignment of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#) (see **Remarks**)

Tip

Tool tip text for the control

Return Value

Newly created [control for this PropertyManager page tab control](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::AddControl2](#).

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

This method associates controls with a tab. When a user clicks a tab, controls associated with that tab are automatically shown and controls not associated with that tab are automatically hidden. Any controls added to a tab using [IPropertyManagerPage2::AddControl2](#) are not associated with the tab; you must still hide and show those controls. But, because the name of this method and its parameters are identical to [IPropertyManagerPage2::AddControl2](#), switching to this method and cleaning up your handler code should be easy.

To add a control to a group box associated with a tab, add the controls from the [group box](#). Only use this method to add controls not associated with group boxes.

When you specify `swAddControlOptions_e.swControlOptions_SmallGapAbove` for the Options parameter, the gap created between a new control and the previous control is smaller than the typical gap. Also, the control is hidden unless you specify `swAddControlOptions_e.swControlOptions_Visible` for the Options parameter. In the previous versions of this method, [IPropertyManagerPageTab::AddControl](#) and [IPropertyManagerPageTab::!AddControl](#), the control was visible regardless if the Options parameter was set or not set to `swAddControlOptions_e.swControlOptions_Visible`.

See Also

[IPropertyManagerPageTab Interface](#)

[IPropertyManagerPageTab Members](#)

Availability

SOLIDWORKS 2014 SP1, Revision Number 22.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddGroupBox Method (IPropertyManagerPageTab)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : AddGroupBox Method (IPropertyManagerPageTab)

Adds a group box to this tab on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddGroupBox( _
    ByVal ID As System.Integer, _
    ByVal Caption As System.String, _
    ByVal Options As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab
Dim ID As System.Integer
Dim Caption As System.String
Dim Options As System.Integer
Dim value As System.Object

value = instance.AddGroupBox(ID, Caption, Options)
```

C#

```
System.object AddGroupBox(
    System.int ID,
    System.string Caption,
    System.int Options
)
```

C++/CLI

```
System.Object^ AddGroupBox(
    & System.int ID,
    & System.String^ Caption,
    & System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the group box
Caption
Title of the group box
Options
Options as defined in [swAddGroupBoxOptions_e](#)

Return Value

Newly created [PropertyManager Page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::AddGroupBox](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

To change the title of an existing group box, use [IPropertyManagerPageTab::Caption](#).

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)
[IPropertyManagerPageTab::AddGroupBox Method](#)

Availability

Caption Property (IPropertyManagerPageTab)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : Caption Property (IPropertyManagerPageTab)

Gets or sets the caption for this tab.

.NET Syntax

Visual Basic (Declaration)

Property Caption As System.String

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab
Dim value As System.String

instance.Caption = value
value = instance.Caption
```

C#

```
System.string Caption {get; set;}
```

C++/CLI

```
property System.String^ Caption {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

Text for tab caption

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::Caption](#).

Remarks

You can reset a tab caption regardless if the PropertyManager page is displayed or hidden.

Use [IPropertyManagerPage2::AddTab](#) to add any number of tabs to your PropertyManager page.

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

IAddControl Method (IPropertyManagerPageTab)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : IAddControl Method (IPropertyManagerPageTab)**Obsolete.** Superseded by [IPropertyManagerPageTab::AddControl2](#).

.NET Syntax

```

Function IAddControl( _
    ByVal ID As System.Integer, _
    ByVal ControlType As System.Short, _
    ByVal Caption As System.String, _
    ByVal LeftAlign As System.Short, _
    ByVal Options As System.Integer, _
    ByVal Tip As System.String _
) As PropertyManagerPageControl

```



```

Dim instance As IPropertyManagerPageTab
Dim ID As System.Integer
Dim ControlType As System.Short
Dim Caption As System.String
Dim LeftAlign As System.Short
Dim Options As System.Integer
Dim Tip As System.String
Dim value As PropertyManagerPageControl

value = instance.IAddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)

```

```

PropertyManagerPageControl IAddControl(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)

```

```

PropertyManagerPageControl^ IAddControl(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of this control

ControlType
Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption
Caption of the control

LeftAlign
Left align property of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options
Options as defined in [swAddControlOptions_e](#) (see **Remarks**)

Tip
Tool tip text for the control

Return Value

Newly created [PropertyManager_page_tab_control](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::IAddControl](#).

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

This method associates controls with a tab. When a user clicks a tab, controls associated with that tab are automatically shown and controls not associated with that tab are automatically hidden.

However, any controls added to a tab using [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#) are not associated with the tab; you must still hide and show those controls. But, because the name of this method and its parameters are identical to [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#), switching to this method and cleaning up your handler code should be easy.

To add a control to a group box associated with a tab, add the controls from the [group box](#). Only use this method to add controls not associated with group boxes.

When you specify `swControlOptions_SmallGapAbove` for the `Options` parameter, `gap` is used between a new control and the previous control that is smaller than the typical gap.

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)
[IPropertyManagerPageTab::AddControl Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddGroupBox Method (IPropertyManagerPageTab)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTab Interface](#) : IAddGroupBox Method (IPropertyManagerPageTab)

Adds a group box to this tab on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddGroupBox( _  
    ByVal ID As System.Integer, _  
    ByVal Caption As System.String, _  
    ByVal Options As System.Integer _  
) As PropertyManagerPageGroup
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTab  
Dim ID As System.Integer  
Dim Caption As System.String  
Dim Options As System.Integer  
Dim value As PropertyManagerPageGroup  
  
value = instance.IAddGroupBox(ID, Caption, Options)
```

C#

```
PropertyManagerPageGroup IAddGroupBox(  
    System.int ID,  
    System.string Caption,  
    System.int Options  
)
```

C++/CLI

```
PropertyManagerPageGroup^ IAddGroupBox(  
& System.int ID,  
& System.String^ Caption,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the group box
Caption
Title of the group box
Options
Options as defined in [swAddGroupBoxOptions_e](#)

Return Value

Newly created [PropertyManager Page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTab::AddGroupBox](#).

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

To change the title of an existing group box, use [IPropertyManagerPageTab::Caption](#).

See Also

[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTab Members](#)
[IPropertyManagerPageTab::AddGroupBox Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IPropertyManagerPageTextbox (Type)

IPropertyManagerPageTextbox Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTextbox Interface

Allows you to access a [PropertyManager page](#) text box control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageTextbox
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageTextbox
```

C#

```
public interface IPropertyManagerPageTextbox
```

C++/CLI

```
public interface class IPropertyManagerPageTextbox
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTextbox](#).

Example

[Set Focus on PropertyManager Page Control \(VBA\)](#)

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::AddControl](#)

Access Diagram

[PropertyManagerPageTextbox](#)

See Also

[IPropertyManagerPageTextbox Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageTextbox Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTextbox Interface

The following tables list the members exposed by [IPropertyManagerPageTextbox](#).

Public Properties

Name	Description
Height	Gets or sets the height of this PropertyManager text box.

[Style](#)

Gets or sets various style-related properties for this text box.

[Text](#)

Gets and sets the text that appears in the text box.

[Top](#)

See Also

[IPropertyManagerPageTextbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageTextbox Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageTextbox InterfaceFor a list of all members of this type, see [IPropertyManagerPageTextbox members](#).

Public Properties

Name	Description
 Height	Gets or sets the height of this PropertyManager text box.
 Style	Gets or sets various style-related properties for this text box.
 Text	Gets and sets the text that appears in the text box.

[Top](#)

See Also

[IPropertyManagerPageTextbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageTextbox)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTextbox Interface](#) : Height Property (IPropertyManagerPageTextbox)

Gets or sets the height of this PropertyManager text box.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTextbox
Dim value As System.Short
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTextbox::Height](#).

See Also

[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageTextbox Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IPropertyManagerPageTextbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTextbox Interface](#) : Style Property (IPropertyManagerPageTextbox)

Gets or sets various style-related properties for this text box.

.NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTextbox  
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Styles as defined by [swPropMgrPageTextBoxStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTextbox::Style](#).

See Also

[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageTextbox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

Text Property (IPropertyManagerPageTextbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageTextbox Interface](#) : Text Property (IPropertyManagerPageTextbox)

Gets and sets the text that appears in the text box.

.NET Syntax

Visual Basic (Declaration)

```
Property Text As System.String
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageTextbox  
Dim value As System.String  
  
instance.Text = value  
value = instance.Text
```

C#

```
System.string Text {get; set;}
```

C++/CLI

```
property System.String^ Text {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for the box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageTextbox::Text](#).

See Also

[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageTextbox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IPropertyManagerPageWindowFromHandle (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageWindowFromHandle Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageWindowFromHandle Interface

Allows you to access a [PropertyManager page](#) .NET control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageWindowFromHandle
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageWindowFromHandle
```

C#

```
public interface IPropertyManagerPageWindowFromHandle
```

C++/CLI

```
public interface class IPropertyManagerPageWindowFromHandle
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageWindowFromHandle](#).

Example

[Add .NET Controls to SOLIDWORKS using an Add-in \(C#\)](#)
[Add .NET Controls to SOLIDWORKS using an Add-in \(VB.NET\)](#)

Remarks

The add-in that deploys a .NET control in a PropertyManager page must implement the event handler [IPropertyManagerPage2Handler8::OnWindowFromHandleControlCreated](#). SOLIDWORKS populates the arguments of this handler when it attempts to create a .NET control on the PropertyManager page.

If SOLIDWORKS is unable to create a .NET control, it passes Status = false in the handler. When Status = false, the handler must return an action to take as defined in [swHandleWindowFromHandleCreationFailure_e](#).

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::!AddControl](#)

Access Diagram

[PropertyManagerPageWindowFromHandle](#)

See Also

[IPropertyManagerPageWindowFromHandle Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageWindowFromHandle Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageWindowFromHandle Interface

The following tables list the members exposed by [IPropertyManagerPageWindowFromHandle](#).

Public Properties

Name	Description
 Height	Gets or sets the height of this .NET control.

[Top](#)

Public Methods

Name	Description
 SetWindowHandle	Obsolete. Superseded by IPropertyManagerPageWindowFromHandle::SetWindowHandlex64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the handle of this .NET control.
 SetWindowHandlex64	Sets the handle of this .NET control on 64-bit machines.

[Top](#)

See Also

[IPropertyManagerPageWindowFromHandle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IPropertyManagerPageWindowFromHandle Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageWindowFromHandle Interface

For a list of all members of this type, see [IPropertyManagerPageWindowFromHandle members](#).

Public Methods

Name	Description
 SetWindowHandle	Obsolete. Superseded by IPropertyManagerPageWindowFromHandle::SetWindowHandlex64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the handle of this .NET control.
 SetWindowHandlex64	Sets the handle of this .NET control on 64-bit machines.

[Top](#)

See Also

[IPropertyManagerPageWindowFromHandle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IPropertyManagerPageWindowFromHandle Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageWindowFromHandle Interface

For a list of all members of this type, see [IPropertyManagerPageWindowFromHandle members](#).

Public Properties

Name	Description
 Height	Gets or sets the height of this .NET control.

[Top](#)

See Also

[IPropertyManagerPageWindowFromHandle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageWindowFromHandle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageWindowFromHandle Interface](#) : Height Property (IPropertyManagerPageWindowFromHandle)

Gets or sets the height of this .NET control.

.NET Syntax

Visual Basic (Declaration)

```
Property Height As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageWindowFromHandle  
Dim value As System.Integer
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.int Height {get; set;}
```

C++/CLI

```
property System.int Height {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of the control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageWindowFromHandle.Height](#).

Example

See the [IPropertyManagerPageWindowFromHandle](#) examples.

Remarks

This property only applies to some .NET controls.

The height is in dialog-box units. You can convert these values to screen units (pixels) by using the Windows MapDialogRect function.

See Also

[IPropertyManagerPageWindowFromHandle Interface](#)
[IPropertyManagerPageWindowFromHandle Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWindowHandle Method (IPropertyManagerPageWindowFromHandle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageWindowFromHandle Interface](#) : SetWindowHandle Method (IPropertyManagerPageWindowFromHandle)

Obsolete. Superseded by [IPropertyManagerPageWindowFromHandle::SetWindowHandle64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Sets the handle of this .NET control.

.NET Syntax

Visual Basic (Declaration)

```
Function SetWindowHandle( _  
    ByVal WindowHandle As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageWindowFromHandle  
Dim WindowHandle As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetWindowHandle(WindowHandle)
```

C#

```
System.bool SetWindowHandle(  
    System.int WindowHandle  
)
```

C++/CLI

```
System.bool SetWindowHandle(  
& System.int WindowHandle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WindowHandle
Handle of the .NET control

Return Value

True if handle is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageWindowFromHandle::SetWindowHandle](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

You must call this method to initialize the .NET control handle whenever you call [IPropertyManagerPage2::Show2](#), because .NET control handles are destroyed with their forms when the PropertyManager page closes.

See Also

[IPropertyManagerPageWindowFromHandle Interface](#)
[IPropertyManagerPageWindowFromHandle Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWindowHandlex64 Method (IPropertyManagerPageWindowFromHandle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageWindowFromHandle Interface](#) : SetWindowHandlex64 Method (IPropertyManagerPageWindowFromHandle)

Sets the handle of this .NET control on 64-bit machines.

.NET Syntax

Visual Basic (Declaration)

```
Function SetWindowHandlex64( _  
    ByVal WindowHandle As System.Long _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageWindowFromHandle  
Dim WindowHandle As System.Long  
Dim value As System.Boolean  
  
value = instance.SetWindowHandlex64(WindowHandle)
```

C#

```
System.bool SetWindowHandlex64(  
    System.long WindowHandle  
)
```

C++/CLI

```
System.bool SetWindowHandlex64(  
& System.int64 WindowHandle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WindowHandle
64-bit handle of the .NET control

Return Value

True if handle is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageWindowFromHandle::SetWindowHandlex64](#).

Example

See the [IPropertyManagerPageWindowFromHandle](#) examples.

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

You must call this method to initialize the .NET control handle whenever you call [IPropertyManagerPage2::Show2](#), because .NET control handle are destroyed with their forms when the PropertyManager page closes.

See Also

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IPunchTable (Type)

IPunchTable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPunchTable Interface

Allows access to punch table information and values.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPunchTable
```

Visual Basic (Usage)



```
Dim instance As IPunchTable
```

C#

```
public interface IPunchTable
```

C++/CLI

```
public interface class IPunchTable
```

Visual Basic for Applications (VBA) Syntax

See [PunchTable](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

Remarks

Punch tables contain information about the punches that are created by forming tools in sheet metal parts. A punch table contains the following information about pre-selected punches:

Column	Description
TAG	Datum tag added to each punch in the flat pattern view
PUNCH ID	Property of the forming tool or library feature
X Location	Distance from the x-axis to the point of insertion of the forming tool in the flat pattern view
Y Location	Distance from the y-axis to the point of insertion of the forming tool in the flat pattern view
ANGLE	Angle between the x-axis and the forming tool
QUANTITY	Number of times that the forming tool is used in the flat pattern view

Accessors

[IPunchTableAnnotation::PunchTable](#)

Access Diagram

[PunchTable](#)

See Also

[IPunchTable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTableAnnotation Interface](#)
[TableAnnotation Interface](#)

IPunchTable Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPunchTable Interface

For a list of all members of this type, see [IPunchTable members](#).

Public Methods

Name	Description
 GetFeature	Gets the IFeature object for this punch table.
 GetTableAnnotationCount	Gets the number of punch table annotations for this punch table.
 GetTableAnnotations	Gets the punch table annotations for this punch table feature.
 IGetTableAnnotations	Gets the punch table annotations for this punch table feature.

[Top](#)

See Also

[IPunchTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

IPunchTable Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPunchTable Interface

The following tables list the members exposed by [IPunchTable](#).

Public Properties

Name	Description
 CombineSameSize	Gets or sets whether to merge Punch ID column cells that have the same contents.
 CombineTags	Gets or sets whether to combine tags for punches having the same Punch ID.
 DualDimensions	Gets or sets whether to display dual dimensions in this punch table.
 ShowUnits	Gets or sets whether to show dual dimension units in this punch table.
 StartingValue	Gets or sets the starting value for the datum tags of this punch table.
 TagStyle	Gets or sets the tag style for this punch table.

[Top](#)

Public Methods

Name	Description
 GetFeature	Gets the IFeature object for this punch table.
 GetTableAnnotationCount	Gets the number of punch table annotations for this punch table.
 GetTableAnnotations	Gets the punch table annotations for this punch table feature.
 IGetTableAnnotations	Gets the punch table annotations for this punch table feature.

[Top](#)

See Also

[IPunchTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

IPunchTable Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPunchTable Interface

For a list of all members of this type, see [IPunchTable members](#).

 Public Properties

Name	Description
 CombineSameSize	Gets or sets whether to merge Punch ID column cells that have the same contents.
 CombineTags	Gets or sets whether to combine tags for punches having the same Punch ID.
 DualDimensions	Gets or sets whether to display dual dimensions in this punch table.
 ShowUnits	Gets or sets whether to show dual dimension units in this punch table.
 StartingValue	Gets or sets the starting value for the datum tags of this punch table.
 TagStyle	Gets or sets the tag style for this punch table.

[Top](#)

 See Also

[IPunchTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CombineSameSize Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : CombineSameSize Property (IPunchTable)

Gets or sets whether to merge Punch ID column cells that have the same contents.

 .NET Syntax

Visual Basic (Declaration)

Property CombineSameSize As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPunchTable
Dim value As System.Boolean

instance.CombineSameSize = value
value = instance.CombineSameSize
```

C#

```
System.bool CombineSameSize {get; set;}
```

C++/CLI

```
property System.bool CombineSameSize {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge Punch ID column cells that have the same contents, false to not; only valid if [IPunchTable::CombineTags](#) is false (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [PunchTable::CombineSameSize](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

Remarks

Set this property to true to create a punch table with a PUNCH ID column that contains column cells that have been merged because they contain the same value within each tag group (e.g., A1, A2, A3).

If this property is set to false, the punch table looks like this:

TAG	PUNCH ID	X LOCATION	Y LOCATION	ANGLE	QUANTITY
A1	135	107	300	90	1
A2	135	200	150	90	1
A3	135	300	200	90	1

If this property is set to true, the punch table looks like this:

TAG	PUNCH ID	X LOCATION	Y LOCATION	ANGLE	QUANTITY
A1	135	107	300	90	1
A2		200	150	90	1
A3		300	200	90	1

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CombineTags Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : CombineTags Property (IPunchTable)

Gets or sets whether to combine tags for punches having the same Punch ID.

.NET Syntax

Visual Basic (Declaration)

Property CombineTags As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPunchTable
Dim value As System.Boolean
```

```
instance.CombineTags = value
```

```
value = instance.CombineTags
```

C#

```
System.bool CombineTags {get; set;}
```

C++/CLI

```
property System.bool CombineTags {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to combine tags, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PunchTable::CombineTags](#).

Example

If this property is set to false, the punch table looks like this:

TAG	PUNCH ID	X LOCATION	Y LOCATION	ANGLE	QUANTITY
A1	135	107	300	90	1
A2	135	200	150	90	1
A3	135	300	200	90	1

If this property is set to true, the punch table looks like this:

TAG	PUNCH ID	QUANTITY
A	135	3

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunch::TagStyle Property](#)
[IPunchTable::CombineSameSize Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DualDimensions Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : DualDimensions Property (IPunchTable)

Gets or sets whether to display dual dimensions in this punch table.

.NET Syntax

Visual Basic (Declaration)

Property DualDimensions As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPunchTable
Dim value As System.Boolean

instance.DualDimensions = value

value = instance.DualDimensions
```

C#

```
System.bool DualDimensions {get; set;}
```

C++/CLI

```
property System.bool DualDimensions {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display dual dimensions, false to not

Visual Basic for Applications (VBA) Syntax

See [PunchTable::DualDimensions](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunchTable::ShowUnits Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFeature Method (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : GetFeature Method (IPunchTable)

Gets the [IFeature](#) object for this punch table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [PunchTable::GetFeature](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotationCount Method (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : GetTableAnnotationCount Method (IPunchTable)

Gets the number of punch table annotations for this punch table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim value As System.Integer  
  
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of punch table annotations for this punch table (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PunchTable::GetTableAnnotationCount](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

Remarks

Normally there is one punch table annotation per punch table feature. Split tables have two separate table annotations.

Call this method before calling [IPunchTable::IGetTableAnnotations](#) to get the total number of table annotations in the punch table, including split table annotations.

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunchTable::GetTableAnnotations Method](#)

Availability

GetTableAnnotations Method (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : GetTableAnnotations Method (IPunchTable)

Gets the punch table annotations for this punch table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPunchTable
Dim value As System.Object

value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IPunchTableAnnotation](#) objects for this punch table feature

Visual Basic for Applications (VBA) Syntax

See [PunchTable::GetTableAnnotations](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

Remarks

This method gets all of the table annotations of a split table. Many of the [ITableAnnotation](#) methods and properties get table annotation information that is common to all table annotations. You should apply these [ITableAnnotation](#) methods and properties to only one of the split table annotations returned by this method. Otherwise, you will get redundant data.

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunchTable::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IGetTableAnnotations Method (IPunchTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : IGetTableAnnotations Method (IPunchTable)

Gets the punch table annotations for this punch table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal Count As System.Integer _  
) As PunchTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim Count As System.Integer  
Dim value As PunchTableAnnotation  
  
value = instance.IGetTableAnnotations(Count)
```

C#

```
PunchTableAnnotation IGetTableAnnotations(  
    System.int Count  
)
```

C++/CLI

```
PunchTableAnnotation^ IGetTableAnnotations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of punch table annotations for this punch table feature (see **Remarks**)

Return Value

- In-process, unmanaged C++: Pointer to the [IPunchTableAnnotation](#) objects for this punch table feature
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method gets all of the table annotations of a split table. Many of the [ITableAnnotation](#) methods and properties get table annotation information that is common to all table annotations. You should apply these [ITableAnnotation](#) methods and properties to only one of the split table annotations returned by this method. Otherwise, you will get redundant data.

For example, if you change the thickness of the grid line, then changing it on one table annotation affects all splits of that table annotation. Thus, for this method, you might want to specify 1 for Count so that a single value is returned. Or, you can call [IPunchTable::GetTableAnnotationCount](#) if you want the total number of table annotations, including any splits, for this punch table feature.

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunchTable::GetTableAnnotations Method \(\)](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowUnits Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : ShowUnits Property (IPunchTable)

Gets or sets whether to show dual dimension units in this punch table.

.NET Syntax

Visual Basic (Declaration)

Property ShowUnits As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim value As System.Boolean  
  
instance.ShowUnits = value  
  
value = instance.ShowUnits
```

C#

```
System.bool ShowUnits {get; set;}
```

C++/CLI

```
property System.bool ShowUnits {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display dual dimension units in the punch table, false to not; valid only if [IPunchTable::DualDimensions](#) is true

Visual Basic for Applications (VBA) Syntax

See [PunchTable::ShowUnits](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingValue Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : StartingValue Property (IPunchTable)

Gets or sets the starting value for the datum tags of this punch table.

.NET Syntax

Visual Basic (Declaration)

Property StartingValue As System.String

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim value As System.String  
  
instance.StartingValue = value
```

```
value = instance.StartingValue
```

C#

```
System.string StartingValue {get; set;}
```

C++/CLI

```
property System.String^ StartingValue {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Letter from A to Z, if the template of this punch table uses letter tags; a positive integer, if it uses number tags (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PunchTable::StartingValue](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

Remarks

See [IView::InsertPunchTable](#) for more information about punch table templates.

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TagStyle Property (IPunchTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTable Interface](#) : TagStyle Property (IPunchTable)

Gets or sets the tag style for this punch table.

.NET Syntax

Visual Basic (Declaration)

```
Property TagStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPunchTable  
Dim value As System.Integer
```

```
instance.TagStyle = value
```

```
value = instance.TagStyle
```

C#

```
System.int TagStyle {get; set;}
```

```
property System.int TagStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tag style as defined by [swPunchTableTagStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PunchTable::TagStyle](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

See Also

[IPunchTable Interface](#)
[IPunchTable Members](#)
[IPunch::CombineTags Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IPunchTableAnnotation (Type)

IPunchTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPunchTableAnnotation Interface

Allows access to a punch table annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPunchTableAnnotation
```

Visual Basic (Usage)

```
Dim instance As IPunchTableAnnotation
```

C#

```
public interface IPunchTableAnnotation
```

C++/CLI

```
public interface class IPunchTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [PunchTableAnnotation](#).

Example

[Insert Punch Table \(VBA\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(C#\)](#)

Remarks

The IPunchTableAnnotation object is derived from the [ITableAnnotation](#) object.

Accessors

[IView::InsertPunchTable](#)
[IPunchTable::GetTableAnnotations](#) and [IPunchTable::!GetTableAnnotations](#)

Access Diagram

[PunchTableAnnotation](#)

See Also

[IPunchTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTable Interface](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)

IPunchTableAnnotation Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPunchTableAnnotation Interface

The following tables list the members exposed by [IPunchTableAnnotation](#).

Public Properties

Name	Description
 PunchTable	Gets the punch table feature for this table annotation.

[Top](#)

See Also

[IPunchTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTable Interface](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPunchTableAnnotation Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPunchTableAnnotation Interface

For a list of all members of this type, see [IPunchTableAnnotation members](#).

Public Properties

Name	Description
 PunchTable	Gets the punch table feature for this table annotation.

[Top](#)

See Also

[IPunchTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPunchTable Interface](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

PunchTable Property (IPunchTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPunchTableAnnotation Interface](#) : PunchTable Property (IPunchTableAnnotation)

Gets the punch table feature for this table annotation.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PunchTable As PunchTable

Visual Basic (Usage)



```
Dim instance As IPunchTableAnnotation  
Dim value As PunchTable  
  
value = instance.PunchTable
```

C#

```
PunchTable PunchTable {get;}
```

C++/CLI

```
property PunchTable^ PunchTable {  
    PunchTable^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IPunchTable](#)

Visual Basic for Applications (VBA) Syntax

See [PunchTableAnnotation::PunchTable](#).

Example

[Insert Punch Table \(C#\)](#)
[Insert Punch Table \(VB.NET\)](#)
[Insert Punch Table \(VBA\)](#)

See Also

[IPunchTableAnnotation Interface](#)
[IPunchTableAnnotation Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0