

SOLIDWORKS API (NET VBA C#) — Reference (234/337): IBackPinionMateFeatureData- IRayTraceRenderer

SOLIDWORKS API Documentation (converted from CHM)

IRackPinionMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRackPinionMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRackPinionMateFeatureData Interface

Allows access to a rack and pinion mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRackPinionMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As IRackPinionMateFeatureData
```

C#

```
public interface IRackPinionMateFeatureData
```

C++/CLI

```
public interface class IRackPinionMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RackPinionMateFeatureData](#).

Example

'VBA

' *****

' 1. Open *public_documents\samples\tutorial\api\MechanicalMates\Rack And Pinion.sldasm*.

' 2. Delete **RackPinionMate1** from the Mates folder of the FeatureManager design tree.

' 3. Run the macro.

' 4. Inspect the Mates folder in the FeatureManager design tree.

' *****

```
Dim swApp As SldWorks.SldWorks
```

```
Dim Part As SldWorks.ModelDoc2
```

```
Dim boolstatus As Boolean
```

```
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
```

```
    Set Part = swApp.ActiveDoc
```

```
    boolstatus = Part.Extension.SelectByRay(-4.63518983485187E-02, 0.061012999696942, -6.42963015610576E-03,  
-0.398796540128449, 0.236369842894561, -0.886053393962, 7.98486578462134E-04, 1, True, 64, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(7.90589165686129E-03, -9.93915877270979E-03, -4.38167267822109E-03,  
-0.398796540128449, 0.236369842894561, -0.886053393962, 7.98486578462134E-04, 2, True, 128, 0)
```

```
    ' Create RackPinionMateFeatureData
```

```
    Dim MateData As SldWorks.RackPinionMateFeatureData
```

```
    Set MateData = Part.CreateMateData(13)
```

```
    ' Set the mate diameter type
```

```
    MateData.DiameterType = 0
```

```
    ' Set the mate diameter value
```

```
    MateData.DiameterVal = 0.0254
```

```
    ' Set the mate orientation direction
```

```
    MateData.Reverse = False
```

```
    ' Create the mate
```

```
    Dim MateFeature As SldWorks.Feature
```

```
Set MateFeature = Part.CreateMate(MateData)
Part.ClearSelection2 True
Part.EditRebuild3
End Sub
```

 Example

[Create Rack and Pinion Mate \(C#\)](#)

 Remarks

A rack and pinion mate consists of two components where:

- One component (the rack) causes circular rotation in another component (the pinion) and vice versa.
- Neither component is required to have gear teeth.

[IMateFeatureData](#) is the parent of this mate interface.

To create a rack and pinion mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Use [IModelDocExtension::SelectByID2](#) to pre-select the entities using Mark = 64 for the rack edge and Mark = 128 for the pinion face.
3. Specify other properties of the RackPinionMateFeatureData object as required.

To edit a rack and pinion mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a RackPinionMateFeatureData object.
3. Modify the RackPinionMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this rack and pinion mate, use [IModelDocExtension::DeleteSelection2](#).

 Access Diagram

[RackPinionMateFeatureData](#)

 See Also

[IRackPinionMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRackPinionMateFeatureData Interface Members

[See Also](#) [Properties](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IRackPinionMateFeatureData Interface

The following tables list the members exposed by [IRackPinionMateFeatureData](#).

 Public Properties

Name	Description
 DiameterType	Gets or sets the type of diameter to set.
 DiameterVal	Gets or sets either the pinion pitch diameter or the rack translation distance per pinion revolution.
 EntitiesToMate	Gets or sets the entities to mate in this rack and pinion mate feature.
 Reverse	Gets or sets whether to change the direction of movement of the rack and pinion relative to one another.

[Top](#)

 See Also

[IRackPinionMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRackPinionMateFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IRackPinionMateFeatureData Interface

For a list of all members of this type, see [IRackPinionMateFeatureData members](#).

 Public Properties

Name	Description
 DiameterType	Gets or sets the type of diameter to set.
 DiameterVal	Gets or sets either the pinion pitch diameter or the rack translation distance per pinion revolution.
 EntitiesToMate	Gets or sets the entities to mate in this rack and pinion mate feature.
 Reverse	Gets or sets whether to change the direction of movement of the rack and pinion relative to one another.

[Top](#)

See Also

[IRackPinionMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DiameterType Property (IRackPinionMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRackPinionMateFeatureData Interface](#) : DiameterType Property (IRackPinionMateFeatureData)

Gets or sets the type of diameter to set.

.NET Syntax

Visual Basic (Declaration)

```
Property DiameterType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRackPinionMateFeatureData
Dim value As System.Integer
```

```
instance.DiameterType = value
```

```
value = instance.DiameterType
```

C#

```
System.int DiameterType {get; set;}
```

C++/CLI

```
property System.int DiameterType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of diameter to set as defined in [swRackPinionMateDistanceOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [RackPinionMateFeatureData::DiameterType](#).

Example

See the [IRackPinionMateFeatureData](#) example.

Remarks

For each full rotation of the pinion, the rack translates a distance = (pi * pinion pitch diameter). Use this property to set either the pinion pitch diameter or the rack translation distance per pinion revolution.

If this property is set to swRackPinionMateDistanceOptions_e:

- swPinionPitchDiameter, then set [IRackPinionMateFeatureData::DiameterVal](#) with the pinion pitch diameter.
- swRackTravelPerRevolution, then set IRackPinionMateFeatureData::DiameterVal with the rack translation distance per revolution of the pinion.

See Also

[IRackPinionMateFeatureData Interface](#)
[IRackPinionMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DiameterVal Property (IRackPinionMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRackPinionMateFeatureData Interface](#) : DiameterVal Property (IRackPinionMateFeatureData)

Gets or sets either the pinion pitch diameter or the rack translation distance per pinion revolution.

.NET Syntax

Visual Basic (Declaration)

```
Property DiameterVal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRackPinionMateFeatureData  
Dim value As System.Double
```

```
instance.DiameterVal = value
```

```
value = instance.DiameterVal
```

C#

```
System.double DiameterVal {get; set;}
```

C++/CLI

```
property System.double DiameterVal {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pinion pitch diameter or rack translation distance per pinion revolution (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RackPinionMateFeatureData::DiameterVal](#).

Example

See the [IRackPinionMateFeatureData](#) example.

Remarks

For each full rotation of the pinion, the rack translates a distance = (pi * pinion pitch diameter).

If [IRackPinionMateFeatureData::DiameterType](#) is set to [swRackPinionMateDistanceOptions_e](#):

- `swPinionPitchDiameter`, use this property to specify the pinion pitch diameter.
- `swRackTravelPerRevolution`, use this property to specify the rack translation distance per revolution of the pinion.

See Also

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EntitiesToMate Property (IRackPinionMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRackPinionMateFeatureData Interface](#) : EntitiesToMate Property (IRackPinionMateFeatureData)

Gets or sets the entities to mate in this rack and pinion mate feature.

.NET Syntax

Visual Basic (Declaration)

```
Property EntitiesToMate( _  
    ByVal EntityType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRackPinionMateFeatureData  
Dim EntityType As System.Integer  
Dim value As System.Object  
  
instance.EntitiesToMate(EntityType) = value  
  
value = instance.EntitiesToMate(EntityType)
```

C#

```
System.object EntitiesToMate(  
    System.int EntityType  
) {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get(System.int EntityType);  
    void set (System.int EntityType, System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityType

Entity type to mate as defined in [swRackPinionMateEntityType_e](#)

Property Value

Array of entities to mate (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RackPinionMateFeatureData::EntitiesToMate](#).

Remarks

If *EntityType* is set to `swRackPinionMateEntityType_e`:

- swRackPinionMateEntityType_Pinion, then set the array with a cylindrical [face](#), circular [edge](#) or [arc](#), sketch circle, [axis](#), or revolved [surface](#).
- swRackPinionMateEntityType_Rack, then set the array with a linear edge, [sketch line](#), [centerline](#), axis, or cylindrical face.

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 64 for the rack and Mark = 128 for the pinion. You can pre-select mate entities during mate creation, but not during mate editing.

See Also

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Reverse Property (IRackPinionMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRackPinionMateFeatureData Interface](#) : Reverse Property (IRackPinionMateFeatureData)

Gets or sets whether to change the direction of movement of the rack and pinion relative to one another.

.NET Syntax

Visual Basic (Declaration)

Property Reverse As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRackPinionMateFeatureData  
Dim value As System.Boolean
```

```
instance.Reverse = value
```

```
value = instance.Reverse
```

C#

```
System.bool Reverse {get; set;}
```

C++/CLI

```
property System.bool Reverse {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of movement of the rack and pinion, false to not

Visual Basic for Applications (VBA) Syntax

See [RackPinionMateFeatureData.Reverse](#).

Example

See the [IRackPinionMateFeatureData](#) example.

See Also

[IRackPinionMateFeatureData Interface](#)
[IRackPinionMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IRayTraceRenderer (Type)

IRayTraceRenderer Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRayTraceRenderer Interface

Allows access to ray-trace rendering engines.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRayTraceRenderer
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer
```

C#

```
public interface IRayTraceRenderer
```

C++/CLI

```
public interface class IRayTraceRenderer
```

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

Accessors

[ISldWorks::GetRayTraceRenderer](#) and [ISldWorks::!GetRayTraceRenderer](#)

Access Diagram

[RayTraceRenderer](#)

See Also

[IRayTraceRenderer Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRayTraceRendererOptions Interface](#)

IRayTraceRenderer Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRayTraceRenderer Interface

For a list of all members of this type, see [IRayTraceRenderer members](#).

Public Methods

Name	Description
 AbortFinalRender	Aborts the final render window.
 CloseFinalRenderWindow	Closes the final render window, but leaves the preview window open.

 CloseRayTraceRender	Closes both the preview and final render windows .
 DisplayPreviewWindow	Displays the preview render window.
 InvokeFinalRender	Invokes the final render window.
 RenderToFile	Saves the current view of the rendered model as an image to the specified file.

[Top](#)

 See Also

[IRayTraceRenderer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRayTraceRendererOptions Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRayTraceRenderer Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRayTraceRenderer Interface

The following tables list the members exposed by [IRayTraceRenderer](#).

 Public Properties

Name	Description
 RayTraceRendererOptions	Gets a ray-trace rendering engine's options.

[Top](#)

 Public Methods

Name	Description
 AbortFinalRender	Aborts the final render window.
 CloseFinalRenderWindow	Closes the final render window, but leaves the preview window open.
 CloseRayTraceRender	Closes both the preview and final render windows .
 DisplayPreviewWindow	Displays the preview render window.
 InvokeFinalRender	Invokes the final render window.
 RenderToFile	Saves the current view of the rendered model as an image to the specified file.

[Top](#)

 See Also

[IRayTraceRenderer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRayTraceRendererOptions Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRayTraceRenderer Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRayTraceRenderer Interface

For a list of all members of this type, see [IRayTraceRenderer members](#).

 Public Properties

Name	Description
 RayTraceRendererOptions	Gets a ray-trace rendering engine's options.

[Top](#)

 See Also

[IRayTraceRenderer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRayTraceRendererOptions Interface](#)

AbortFinalRender Method (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : AbortFinalRender Method (IRayTraceRenderer)

Aborts the final render window.

.NET Syntax

Visual Basic (Declaration)

```
Function AbortFinalRender() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer  
Dim value As System.Boolean  
  
value = instance.AbortFinalRender()
```

C#

```
System.bool AbortFinalRender()
```

C++/CLI

```
System.bool AbortFinalRender();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the final render window is aborted, false if not

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::AbortFinalRender](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)
[IRayTraceRenderer::InvokeFinalRender Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

CloseFinalRenderWindow Method (IRayTraceRenderer)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : CloseFinalRenderWindow Method (IRayTraceRenderer)

Closes the final render window, but leaves the [preview window](#) open.

.NET Syntax

Visual Basic (Declaration)

```
Function CloseFinalRenderWindow() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer
Dim value As System.Boolean

value = instance.CloseFinalRenderWindow()
```

C#

```
System.bool CloseFinalRenderWindow()
```

C++/CLI

```
System.bool CloseFinalRenderWindow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the final render window closed, false if it did not

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::CloseFinalRenderWindow](#).

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)
[IRayTraceRenderer::CloseRayTraceRender Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CloseRayTraceRender Method (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : CloseRayTraceRender Method (IRayTraceRenderer)

Closes both the [preview](#) and [final render windows](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CloseRayTraceRender() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer
Dim value As System.Boolean

value = instance.CloseRayTraceRender()
```

C#

```
System.bool CloseRayTraceRender()
```

C++/CLI

```
System.bool CloseRayTraceRender();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if both the [preview](#) and [final render windows](#) are closed, false if not

Visual Basic for Applications (VBA) Syntax

See [IRayTraceRenderer::CloseRayTraceRender](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

Remarks

When this method is called after calling [IRayTraceRenderer::Invoke FinalRender](#) or [IRayTraceRenderer::RenderToFile](#), then both the preview and final render windows are closed.

To leave the preview render window open, call [IRayTraceRenderer::CloseFinalRenderWindow](#) instead of calling [IRayTraceRenderer::CloseRayTraceRender](#).

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayPreviewWindow Method (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : DisplayPreviewWindow Method (IRayTraceRenderer)

Displays the preview render window.

.NET Syntax

Visual Basic (Declaration)

```
Function DisplayPreviewWindow() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer  
Dim value As System.Boolean  
  
value = instance.DisplayPreviewWindow()
```

C#

```
System.bool DisplayPreviewWindow()
```

C++/CLI

```
System.bool DisplayPreviewWindow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if preview render window is displayed, false if not

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::DisplayPreviewWindow](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)
[IRayTraceRendererOptions::PreviewRenderQuality Property](#)
[IRayTraceRenderer::CloseFinalRenderWindow Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InvokeFinalRender Method (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : InvokeFinalRender Method (IRayTraceRenderer)

Invokes the final render window.

.NET Syntax

Visual Basic (Declaration)

```
Function InvokeFinalRender() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer  
Dim value As System.Boolean  
  
value = instance.InvokeFinalRender()
```

C#

```
System.bool InvokeFinalRender()
```

C++/CLI

```
System.bool InvokeFinalRender();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if final render window is invoked, false if not

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::InvokeFinalRender](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)
[IRayTraceRendererOptions::UpdateGraphics Method](#)
[IRayTraceRendererOptions::FinalRenderQuality Property](#)
[IRayTraceRenderer::AbortFinalRender Method](#)
[IRayTraceRenderer::CloseRayTraceRender Method](#)
[IRayTraceRenderer::RenderToFile Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RayTraceRendererOptions Property (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : RayTraceRendererOptions Property (IRayTraceRenderer)

Gets a ray-trace rendering engine's options.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property RayTraceRendererOptions As RayTraceRendererOptions
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer  
Dim value As RayTraceRendererOptions  
  
value = instance.RayTraceRendererOptions
```

C#

```
RayTraceRendererOptions RayTraceRendererOptions {get;}
```

C++/CLI

```
property RayTraceRendererOptions^ RayTraceRendererOptions {  
    RayTraceRendererOptions^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Ray-trace rendering engine's options](#)

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::RayTraceRendererOptions](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RenderToFile Method (IRayTraceRenderer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRayTraceRenderer Interface](#) : RenderToFile Method (IRayTraceRenderer)

Saves the current view of the rendered model as an image to the specified file.

.NET Syntax

Visual Basic (Declaration)

```
Function RenderToFile( _  
    ByVal ImageFileName As System.String, _  
    ByVal Width As System.Integer, _
```

```
ByVal Height As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRayTraceRenderer  
Dim ImageFileName As System.String  
Dim Width As System.Integer  
Dim Height As System.Integer  
Dim value As System.Boolean  
  
value = instance.RenderToFile(ImageFileName, Width, Height)
```

C#

```
System.bool RenderToFile(  
    System.string ImageFileName,  
    System.int Width,  
    System.int Height  
)
```

C++/CLI

```
System.bool RenderToFile(  
    & System.String^ ImageFileName,  
    & System.int Width,  
    & System.int Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ImageFileName

File path and name (see **Remarks**)

Width

Width of image in pixels (see **Remarks**)

Height

Height of image in pixels (see **Remarks**)

Return Value

True if the current view of the rendered model is saved, false if not

Visual Basic for Applications (VBA) Syntax

See [RayTraceRenderer::RenderToFile](#).

Example

[Render Model \(C#\)](#)
[Render Model \(VB.NET\)](#)
[Render Model \(VBA\)](#)
[Include Note in Render File \(C#\)](#)
[Include Note in Render File \(VB.NET\)](#)
[Include Note in Render File \(VBA\)](#)

Remarks

Before calling this method:

- you can call [IRayTraceRendererOptions::ImageFormat](#) to specify the image format in which to save the model and omit the file format extension when specifying ImageFileName.
- set [IRayTraceRendererOptions::IncludeAnnotationsInRendering](#) to true to include annotations and dimensions visible in the model in the render file. You can also set [IRayTraceRendererOptions::RenderAnnotationsToSeparateImage](#) to true to render the annotations and dimensions visible in the model to a separate image file.

You can override the values set in [IRayTraceRendererOptions::ImageWidth](#) and [IRayTraceRendererOptions::ImageHeight](#) by calling this method with specific values for Width and Height. Set Width and Height to 0 to use values specified by [IRayTraceRendererOptions::ImageWidth](#) and [IRayTraceRendererOptions::ImageHeight](#).

After calling this method, call [IRayTraceRenderer::CloseRayTraceRender](#).

See Also

[IRayTraceRenderer Interface](#)
[IRayTraceRenderer Members](#)
[IRayTraceRenderer::InvokeFinalRender Method \(\)](#)
[IRayTraceRendererOptions::UpdateGraphics Method \(\)](#)

