

SOLIDWORKS API (.NET VBA C#) — Reference (236/337): IRefAxisFeatureData-IRefPlane

SOLIDWORKS API Documentation (converted from CHM)

IRefAxisFeatureData (Type)

IRefAxisFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefAxisFeatureData Interface

Allows access to reference axis feature data.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRefAxisFeatureData
```

Visual Basic (Usage)

```
Dim instance As IRefAxisFeatureData
```

C#

```
public interface IRefAxisFeatureData
```

C++/CLI

```
public interface class IRefAxisFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData](#).

Example

[Get Selections for Reference Axis Feature \(C#\)](#)
[Get Selections for Reference Axis Feature \(VB.NET\)](#)
[Get Selections for Reference Axis Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[RefAxisFeatureData](#)

See Also

[IRefAxisFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefAxis Interface](#)

IRefAxisFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefAxisFeatureData Interface

The following tables list the members exposed by [IRefAxisFeatureData](#).

Public Properties

Name	Description
 Type	Gets or sets the type of reference axis feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this reference axis feature.
 GetSelections	Gets the selected entities for this reference axis feature.
 GetSelectionsCount	Gets the number of selections that define this reference axis feature.
 IAccessSelections	Gains access to the selections that define this reference axis feature.
 IGetSelections	Gets the selected entities for this reference axis feature.
 ISetSelections	Sets the entities for this reference axis feature.
 ReleaseSelectionAccess	Releases access to the selections that define this reference axis feature.
 SetSelections	Sets the entities for this reference axis feature.

[Top](#)

See Also

[IRefAxisFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefAxis Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRefAxisFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefAxisFeatureData Interface

For a list of all members of this type, see [IRefAxisFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this reference axis feature.
 GetSelections	Gets the selected entities for this reference axis feature.
 GetSelectionsCount	Gets the number of selections that define this reference axis feature.
 IAccessSelections	Gains access to the selections that define this reference axis feature.
 IGetSelections	Gets the selected entities for this reference axis feature.
 ISetSelections	Sets the entities for this reference axis feature.
 ReleaseSelectionAccess	Releases access to the selections that define this reference axis feature.
 SetSelections	Sets the entities for this reference axis feature.

[Top](#)

See Also

[IRefAxisFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefAxis Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRefAxisFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefAxisFeatureData Interface

For a list of all members of this type, see [IRefAxisFeatureData members](#).

Public Properties

Name	Description
 Type	Gets or sets the type of reference axis feature.

[Top](#)

See Also

[IRefAxisFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefAxis Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IRefAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : AccessSelections Method (IRefAxisFeatureData)

Gains access to the selections that define this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::AccessSelections](#).

Example

[Get Selections for Reference Axis Feature \(C#\)](#)
[Get Selections for Reference Axis Feature \(VB.NET\)](#)
[Get Selections for Reference Axis Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [IRefAxisFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::!AccessSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSelections Method (IRefAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : GetSelections Method (IRefAxisFeatureData)

Gets the selected entities for this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelections( _
    ByRef EntitiesTypeVar As System.Object _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IRefAxisFeatureData
Dim EntitiesTypeVar As System.Object
Dim value As System.Object

value = instance.GetSelections(EntitiesTypeVar)
```

C#

```
System.object GetSelections(
    out System.object EntitiesTypeVar
)
```

C++/CLI

```
System.Object^ GetSelections(
    & [Out] System.Object^ EntitiesTypeVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntitiesTypeVar

Array of the types of selected entities for this reference axis feature as defined by [swSelectType_e](#)

Return Value

Array of the selected entities

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::GetSelections](#).

Example

[Get Selections for Reference Axis Feature \(C#\)](#)
[Get Selections for Reference Axis Feature \(VB.NET\)](#)
[Get Selections for Reference Axis Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::IGetSelections Method](#)
[IRefAxisFeatureData::GetSelectionsCount Method](#)
[IRefAxisFeatureData::ISetSelections Method](#)
[IRefAxisFeatureData::SetSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectionsCount Method (IRefAxisFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : GetSelectionsCount Method (IRefAxisFeatureData)

Gets the number of selections that define this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectionsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
Dim value As System.Integer  
  
value = instance.GetSelectionsCount()
```

C#

```
System.int GetSelectionsCount()
```

C++/CLI

```
System.int GetSelectionsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of selections that define this reference axis featu

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::GetSelectionsCount](#).

Remarks

Call this method before calling [IRefAxisFeatureData::IGetSelections](#).

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::GetSelections Method](#)
[IRefAxisFeatureData::ISetSelections Method](#)
[IRefAxisFeatureData::SetSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IRefAxisFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : IAccessSelections Method (IRefAxisFeatureData)

Gains access to the selections that define this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRefAxisFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [IRefAxisFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSelections Method (IRefAxisFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : IGetSelections Method (IRefAxisFeatureData)

Gets the selected entities for this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSelections( _
    ByVal Count As System.Integer, _
    ByRef TypeArr As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData
Dim Count As System.Integer
Dim TypeArr As System.Integer
Dim value As System.Object

value = instance.IGetSelections(Count, TypeArr)
```

C#

```
System.object IGetSelections(
    System.int Count,
    out System.int TypeArr
)
```

C++/CLI

```
System.Object^ IGetSelections(
    & System.int Count,
    & [Out] System.int TypeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected entities for this reference axis feature

TypeArr

Array of the types of selected entities for this reference axis feature as defined by [swSelectType_e](#)

Return Value

- in-process, unmanaged C++: Array of the selected entities
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRefAxisFeatureData::GetSelectionsCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::GetSelections Method](#)
[IRefAxisFeatureData::ISetSelections Method](#)
[IRefAxisFeatureData::SetSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetSelections Method (IRefAxisFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : ISetSelections Method (IRefAxisFeatureData)

Sets the entities for this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetSelections( _  
    ByVal Count As System.Integer, _  
    ByRef EntArr As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
Dim Count As System.Integer  
Dim EntArr As System.Object  
Dim value As System.Boolean  
  
value = instance.ISetSelections(Count, EntArr)
```

C#

```
System.bool ISetSelections(  
    System.int Count,  
    ref System.object EntArr  
)
```

C++/CLI

```
System.bool ISetSelections(  
& System.int Count,  
& System.Object^% EntArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of entities

EntArr

- in-process, unmanaged C++: Pointer to an array of entities for this reference axis feature
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the method executed, false if not

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::SetSelections Method](#)
[IRefAxisFeatureData::GetSelections Method](#)
[IRefAxisFeatureData::GetSelectionsCount Method](#)
[IRefAxisFeatureData::!GetSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IRefAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : ReleaseSelectionAccess Method (IRefAxisFeatureData)

Releases access to the selections that define this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::ReleaseSelectionAccess](#).

Example

[Get Selections for Reference Axis Feature \(C#\)](#)
[Get Selections for Reference Axis Feature \(VB.NET\)](#)
[Get Selections for Reference Axis Feature \(VBA\)](#)

Remarks

[IRefAxisFeatureData::AccessSelections](#) and [IRefAxisFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSelections Method (IRefAxisFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : SetSelections Method (IRefAxisFeatureData)

Sets the entities for this reference axis feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSelections( _  
    ByVal EntitiesVar As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
Dim EntitiesVar As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSelections(EntitiesVar)
```

C#

```
System.bool SetSelections(  
    System.object EntitiesVar  
)
```

C++/CLI

```
System.bool SetSelections(  
& System.Object^ EntitiesVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntitiesVar
Array of entities for this reference axis feature

Return Value

True if the method executed, false if not

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::SetSelections](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)
[IRefAxisFeatureData::SetSelections Method](#)
[IRefAxisFeatureData::GetSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IRefAxisFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefAxisFeatureData Interface](#) : Type Property (IRefAxisFeatureData)

Gets or sets the type of reference axis feature.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IRefAxisFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of reference axis feature as defined by [swRefAxisType_e](#)

Visual Basic for Applications (VBA) Syntax

See [RefAxisFeatureData::Type](#).

Example

[Get Reference Axis Data \(VBA\)](#)
[Get Reference Axis Data \(VB.NET\)](#)
[Get Reference Axis Data \(C#\)](#)

See Also

[IRefAxisFeatureData Interface](#)
[IRefAxisFeatureData Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

IReferenceCurve (Type)

IReferenceCurve Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReferenceCurve Interface

Allows access to reference curves.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IReferenceCurve
```

Visual Basic (Usage)

```
Dim instance As IReferenceCurve
```

C#

```
public interface IReferenceCurve
```

C++/CLI

```
public interface class IReferenceCurve
```

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve](#).

Example

[Get Curve Segments \(VBA\)](#)
[Get Reference Curve Information \(VBA\)](#)
[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)

Remarks

This includes the following types of curve features:

- 3D spline curves
- Curves from file
- Helix curves
- Imported curves

IReferenceCurve does not expose reference curve features (for example, projected curves).

Accessors

[IFeature::GetSpecificFeature2](#)
[IModelDoc2::FeatureReferenceCurve](#)

Access Diagram

[ReferenceCurve](#)

See Also

IReferenceCurve Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IReferenceCurve Interface

For a list of all members of this type, see [IReferenceCurve members](#).

Public Methods

Name	Description
 GetFirstSegment	Gets the first curve segment in a reference curve feature.
 GetNextSegment	Gets the next curve segment in the reference curve feature.
 GetSegmentCount	Gets the number of curve segments in a reference curve feature.
 GetSegments	Gets the segments in this reference curve.
 IGetFirstSegment	Gets the first curve segment in a reference curve feature.
 IGetNextSegment	Gets the next curve segment in the reference curve feature.
 IGetSegments	Gets the segments in this reference curve.
 SetColor	Sets the color of the reference curve feature.
 SetVisible	Hides or shows the reference curve feature.

[Top](#)

See Also

[IReferenceCurve Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IReferenceCurve Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IReferenceCurve Interface

The following tables list the members exposed by [IReferenceCurve](#).

Public Methods

Name	Description
 GetFirstSegment	Gets the first curve segment in a reference curve feature.
 GetNextSegment	Gets the next curve segment in the reference curve feature.
 GetSegmentCount	Gets the number of curve segments in a reference curve feature.
 GetSegments	Gets the segments in this reference curve.
 IGetFirstSegment	Gets the first curve segment in a reference curve feature.
 IGetNextSegment	Gets the next curve segment in the reference curve feature.
 IGetSegments	Gets the segments in this reference curve.
 SetColor	Sets the color of the reference curve feature.
 SetVisible	Hides or shows the reference curve feature.

[Top](#)

See Also

[IReferenceCurve Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

GetFirstSegment Method (IReferenceCurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : GetFirstSegment Method (IReferenceCurve)

Gets the first curve segment in a reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstSegment() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve  
Dim value As System.Object  
  
value = instance.GetFirstSegment()
```

C#

```
System.object GetFirstSegment()
```

C++/CLI

```
System.Object^ GetFirstSegment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [edge](#) for the segment

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::GetFirstSegment](#).

Example

[Get Curve Segments \(VBA\)](#)
[Get Reference Curve Information \(VBA\)](#)

Remarks

Because edges returned by this method are not selectable; you should not call any Select methods to get them. Select methods return NULL for any returned edges.

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::GetNextSegment Method](#)
[IReferenceCurve::GetSegmentCount Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::IGetNextSegment Method](#)
[IReferenceCurve::GetSegments Method](#)
[IReferenceCurve::IGetSegments Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextSegment Method (IReferenceCurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : GetNextSegment Method (IReferenceCurve)

Gets the next curve segment in the reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextSegment() As System.Object
```

```
Dim instance As IReferenceCurve
Dim value As System.Object

value = instance.GetNextSegment()
```

C#

```
System.object GetNextSegment()
```

C++/CLI

```
System.Object^ GetNextSegment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [edge](#) for the segment

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::GetNextSegment](#).

Example

[Get Curve Segments \(VBA\)](#)
[Get Reference Curve Information \(VBA\)](#)

Remarks

Because edges returned by this method are not selectable; you should not call any Select methods to get them. Select methods return NULL for any returned edges.

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::IGetNextSegment Method](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::GetSegmentCount Method](#)
[IReferenceCurve::GetSegments Method](#)
[IReferenceCurve::IGetSegments Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.
GetSegmentCount Method (IReferenceCurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : GetSegmentCount Method (IReferenceCurve)

Gets the number of curve segments in a reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSegmentCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IReferenceCurve
Dim value As System.Integer

value = instance.GetSegmentCount()
```

C#

```
System.int GetSegmentCount()
```

C++/CLI

```
System.int GetSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of segments in the curve

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::GetSegmentCount](#).

Example

[Get Curve Segments \(VBA\)](#)

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::GetNextSegment Method](#)
[IReferenceCurve::IGetNextSegment Method](#)
[IReferenceCurve::GetSegments Method](#)
[IReferenceCurve::IGetSegments Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSegments Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : GetSegments Method (IReferenceCurve)

Gets the segments in this reference curve.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSegments() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve
Dim value As System.Object

value = instance.GetSegments()
```

C#

```
System.object GetSegments()
```

C++/CLI

```
System.Object^ GetSegments();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [segments](#)

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::GetSegments](#).

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)

[IReferenceCurve::IGetSegments Method](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::GetNextSegment Method](#)
[IReferenceCurve::GetSegmentCount Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::IGetNextSegment Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstSegment Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : IGetFirstSegment Method (IReferenceCurve)

Gets the first curve segment in a reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstSegment() As Edge
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve  
Dim value As Edge  
  
value = instance.IGetFirstSegment()
```

C#

```
Edge IGetFirstSegment()
```

C++/CLI

```
Edge^ IGetFirstSegment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [edge](#) for the segment

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::IGetFirstSegment](#).

Remarks

Because edges returned by this method are not selectable; you should not call any Select methods to get them. Select methods return NULL for any returned edges.

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::GetSegmentCount Method](#)
[IReferenceCurve::GetNextSegment Method](#)
[IReferenceCurve::IGetNextSegment Method](#)
[IReferenceCurve::GetSegments Method](#)
[IReferenceCurve::IGetSegments Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextSegment Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : IGetNextSegment Method (IReferenceCurve)

Gets the next curve segment in the reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextSegment() As Edge
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve  
Dim value As Edge  
  
value = instance.IGetNextSegment()
```

C#

```
Edge IGetNextSegment()
```

C++/CLI

```
Edge^ IGetNextSegment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [edge](#) for the segment

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::IGetNextSegment](#).

Remarks

Because edges returned by this method are not selectable; you should not call any Select methods to get them. Select methods return NULL for any returned edges.

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::GetNextSegment Method](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::GetSegmentCount Method](#)
[IReferenceCurve::IGetSegments Method](#)
[IReferenceCurve::GetSegments Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSegments Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : IGetSegments Method (IReferenceCurve)

Gets the segments in this reference curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSegments( _  
    ByVal NumSegments As System.Integer _  
) As Edge
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve
Dim NumSegments As System.Integer
Dim value As Edge

value = instance.IGetSegments(NumSegments)
```

C#

```
Edge IGetSegments(
    System.int NumSegments
)
```

C++/CLI

```
Edge^ IGetSegments(
    & System.int NumSegments
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumSegments
Number of segments in the reference curve

Return Value

- in-process, unmanaged C++: Pointer to an array of [segments](#) in the reference curve
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IReferenceCurve::GetSegmentCount](#) to get NumSegments.

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)
[IReferenceCurve::GetSegments Method](#)
[IReferenceCurve::IGetFirstSegment Method](#)
[IReferenceCurve::IGetNextSegment Method](#)
[IReferenceCurve::GetFirstSegment Method](#)
[IReferenceCurve::GetNextSegment Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColor Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : SetColor Method (IReferenceCurve)

Sets the color of the reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetColor( _
    ByVal ColorIn As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IReferenceCurve
Dim ColorIn As System.Integer
Dim value As System.Boolean

value = instance.SetColor(ColorIn)
```

C#

```
System.bool SetColor(
    System.int ColorIn
)
```

C++/CLI

```
System.bool SetColor(
    & System.int ColorIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColorIn

COLORREF value of the color

Return Value

True if the color was set, false if not

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::SetColor](#).

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVisible Method (IReferenceCurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferenceCurve Interface](#) : SetVisible Method (IReferenceCurve)

Hides or shows the reference curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetVisible( _
    ByVal Visible As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IReferenceCurve
Dim Visible As System.Boolean
Dim value As System.Boolean

value = instance.SetVisible(Visible)
```

C#

```
System.bool SetVisible(
    System.bool Visible
)
```

C++/CLI

```
System.bool SetVisible(  
& System.bool Visible  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visible

True for visible, false for hidden

Return Value

True if set, false if not

Visual Basic for Applications (VBA) Syntax

See [ReferenceCurve::SetVisible](#).

See Also

[IReferenceCurve Interface](#)
[IReferenceCurve Members](#)

IReferencePointCurveFeatureData (Type)

IReferencePointCurveFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReferencePointCurveFeatureData Interface

Allows access to reference-point curve feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IReferencePointCurveFeatureData
```

Visual Basic (Usage)



```
Dim instance As IReferencePointCurveFeatureData
```

C#

```
public interface IReferencePointCurveFeatureData
```

C++/CLI

```
public interface class IReferencePointCurveFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData](#).

Example

[Create Curve Through Reference Points \(VBA\)](#)
[Create Curve Through Reference Points \(VB.NET\)](#)
[Create Curve Through Reference Points \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[ReferencePointCurveFeatureData](#)

See Also

[IReferencePointCurveFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IReferencePointCurveFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReferencePointCurveFeatureData Interface

The following tables list the members exposed by [IReferencePointCurveFeatureData](#).

Public Properties

Name	Description
 ClosedCurve	Gets or sets whether the curve is closed or not.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define a reference-point curve feature.
 GetThroughPointCount	Gets the number of points through which this curve passes.
 GetThroughPoints	Gets the points through which this curve passes.
 IGetThroughPoints	Gets the points through which this curve passes.
 ISetThroughPoints	Sets the points through which this curve passes.
 ReleaseSelectionAccess	Releases access to the selections that define this reference-point curve feature.
 SetThroughPoints	Sets the points through which this curve passes.

[Top](#)

See Also

[IReferencePointCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IReferencePointCurveFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReferencePointCurveFeatureData Interface

For a list of all members of this type, see [IReferencePointCurveFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define a reference-point curve feature.
 GetThroughPointCount	Gets the number of points through which this curve passes.
 GetThroughPoints	Gets the points through which this curve passes.
 IGetThroughPoints	Gets the points through which this curve passes.
 ISetThroughPoints	Sets the points through which this curve passes.
 ReleaseSelectionAccess	Releases access to the selections that define this reference-point curve feature.
 SetThroughPoints	Sets the points through which this curve passes.

[Top](#)

See Also

[IReferencePointCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IReferencePointCurveFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReferencePointCurveFeatureData Interface

For a list of all members of this type, see [IReferencePointCurveFeatureData members](#).

Public Properties

Name	Description
 ClosedCurve	Gets or sets whether the curve is closed or not.

[Top](#)

See Also

AccessSelections Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : AccessSelections Method (IReferencePointCurveFeatureData)

Gains access to the selections that define a reference-point curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IReferencePointCurveFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::AccessSelections](#).

Example

See the [IReferencePointCurveFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IReferencePointCurveFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClosedCurve Property (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : ClosedCurve Property (IReferencePointCurveFeatureData)

Gets or sets whether the curve is closed or not.

.NET Syntax

Visual Basic (Declaration)

Property ClosedCurve As System.Boolean

Visual Basic (Usage)



```
Dim instance As IReferencePointCurveFeatureData  
Dim value As System.Boolean
```

```
instance.ClosedCurve = value
```

```
value = instance.ClosedCurve
```

C#

```
System.bool ClosedCurve {get; set;}
```

C++/CLI

```
property System.bool ClosedCurve {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if curve is closed, false if not

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::ClosedCurve](#).

Example

See the [IReferencePointCurveFeatureData](#) examples.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)

Availability

GetThroughPointCount Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : GetThroughPointCount Method (IReferencePointCurveFeatureData)

Gets the number of points through which this curve passes.

.NET Syntax

Visual Basic (Declaration)

```
Function GetThroughPointCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IReferencePointCurveFeatureData  
Dim value As System.Integer
```

```
value = instance.GetThroughPointCount()
```

C#

```
System.int GetThroughPointCount()
```

C++/CLI

```
System.int GetThroughPointCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of points

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::GetThroughPointCount](#).

Example

See the [IReferencePointCurveFeatureData](#) examples.

Remarks

Call this method before calling [IReferencePointCurveFeatureData::GetThroughPoints](#).

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)
[IReferencePointCurveFeatureData::GetThroughPoints Method](#)
[IReferencePointCurveFeatureData::SetThroughPoints Method](#)
[IReferencePointCurveFeatureData::SetThroughPoints Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

GetThroughPoints Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : GetThroughPoints Method (IReferencePointCurveFeatureData)

Gets the points through which this curve passes.

.NET Syntax

Visual Basic (Declaration)

```
Function GetThroughPoints( _  
    ByRef Type As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IReferencePointCurveFeatureData  
Dim Type As System.Object  
Dim value As System.Object  
  
value = instance.GetThroughPoints(Type)
```

C#

```
System.object GetThroughPoints(  
    out System.object Type  
)
```

C++/CLI

```
System.Object^ GetThroughPoints(  
& [Out] System.Object^ Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of entities (sketch points or vertices) as defined by [swSelectType_e](#)

Return Value

Array of points

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::GetThroughPoints](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)
[IReferencePointCurveFeatureData::GetThroughPointCount Method](#)
[IReferencePointCurveFeatureData::IGetThroughPoints Method](#)
[IReferencePointCurveFeatureData::ISetThroughPoints Method](#)
[IReferencePointCurveFeatureData::SetThroughPoints Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetThroughPoints Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : IGetThroughPoints Method (IReferencePointCurveFeatureData)

Gets the points through which this curve passes.

.NET Syntax

```
Function IGetThroughPoints( _
    ByVal Count As System.Integer, _
    ByRef Type As System.Integer _
) As System.Object
```



```
Dim instance As IReferencePointCurveFeatureData
Dim Count As System.Integer
Dim Type As System.Integer
Dim value As System.Object

value = instance.IGetThroughPoints(Count, Type)
```

```
System.object IGetThroughPoints(
    System.int Count,
    out System.int Type
)
```

```
System.Object^ IGetThroughPoints(
    & System.int Count,
    & [Out] System.int Type
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of points

Type

Type of entities (sketch points or vertices) as defined by [swSelectType_e](#)

Return Value

- in-process, unmanaged C++: Pointer to an array of points
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IReferencePointCurveFeatureData::GetThroughPointCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)
[IReferencePointCurveFeatureData::GetThroughPoints Method](#)
[IReferencePointCurveFeatureData::ISetThroughPoints Method](#)
[IReferencePointCurveFeatureData::SetThroughPoints Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ISetThroughPoints Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : ISetThroughPoints Method (IReferencePointCurveFeatureData)

Sets the points through which this curve passes.

.NET Syntax

```
Sub ISetThroughPoints( _
    ByVal Count As System.Integer, _
    ByRef Pts As System.Object _
)
```



```
Dim instance As IReferencePointCurveFeatureData
Dim Count As System.Integer
Dim Pts As System.Object

instance.ISetThroughPoints(Count, Pts)
```

```
void ISetThroughPoints(
    System.int Count,
    ref System.object Pts
)
```

```
void ISetThroughPoints(
    & System.int Count,
    & System.Object^% Pts
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of points

Pts

- in-process, unmanaged C++: Pointer to an array of points
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)
[IReferencePointCurveFeatureData::SetThroughPoints Method](#)
[IReferencePointCurveFeatureData::GetThroughPoints Method](#)
[IReferencePointCurveFeatureData::IGetThroughPoints Method](#)
[IReferencePointCurveFeatureData::GetThroughPointCount Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : ReleaseSelectionAccess Method (IReferencePointCurveFeatureData)

Releases access to the selections that define this reference-point curve feature.

.NET Syntax

```
Sub ReleaseSelectionAccess()
```



```
Dim instance As IReferencePointCurveFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::ReleaseSelectionAccess](#).

Example

See the [IReferencePointCurveFeatureData](#) examples.

Remarks

[IReferencePointCurveFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetThroughPoints Method (IReferencePointCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReferencePointCurveFeatureData Interface](#) : SetThroughPoints Method (IReferencePointCurveFeatureData)

Sets the points through which this curve passes.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetThroughPoints( _  
    ByVal Pts As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IReferencePointCurveFeatureData  
Dim Pts As System.Object  
  
instance.SetThroughPoints(Pts)
```

C#

```
void SetThroughPoints(  
    System.object Pts  
)
```

C++/CLI

```
void SetThroughPoints(  
& System.Object^ Pts  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Pts

Array of points

Visual Basic for Applications (VBA) Syntax

See [ReferencePointCurveFeatureData::SetThroughPoints](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReferencePointCurveFeatureData Interface](#)
[IReferencePointCurveFeatureData Members](#)
[IReferencePointCurveFeatureData::!SetThroughPoints Method](#)
[IReferencePointCurveFeatureData::GetThroughPointCount Method](#)
[IReferencePointCurveFeatureData::GetThroughPoints Method](#)
[IReferencePointCurveFeatureData::!GetThroughPoints Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IRefPlane (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRefPlane Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefPlane Interface

Allows access to reference plane definitions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRefPlane
```

Visual Basic (Usage)

```
Dim instance As IRefPlane
```

C#

```
public interface IRefPlane
```

C++/CLI

```
public interface class IRefPlane
```

Visual Basic for Applications (VBA) Syntax

See [RefPlane](#).

Example

[Get Corner Points of Reference Plane \(VBA\)](#)
[Get Corner Points of Reference Plane \(VB.NET\)](#)
[Get Corner Points of Reference Plane \(C#\)](#)
[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Accessors

[IAdvancedHoleElementData::SelectionEntity](#)
[IAngleMateFeatureData::EntitiesToMate](#)
[IAngleMateFeatureData::ReferenceEntity](#)
[IBeltChainFeatureData::BeltLocationPlane](#)
[IBoundaryBossFeatureData::GetDirectionVector](#)
[IBoundingBoxFeatureData::PlanarEntity](#)
[IChainPatternFeatureData::Group1PathPlane](#)
[IChainPatternFeatureData::Group2PathPlane](#)
[IChainPatternFeatureData::PathReferencePlane](#)
[ICoincidentMateFeatureData::EntitiesToMate](#)
[ICosmeticThreadFeatureData::StartFromFacePlane](#)
[IDistanceMateFeatureData::EntitiesToMate](#)
[IFeature::GetSpecificFeature2](#)
[IFeatureManager::InsertRefPlane](#)
[IGroundPlaneFeatureData::PlanarEntity](#)
[IHingeMateFeatureData::EntitiesToMate](#)
[IIntersectFeatureData::GetIntersectionsTools](#)

[ILinearPatternFeatureData::D1Axis](#)
[ILinearPatternFeatureData::D1EndReference](#)
[ILinearPatternFeatureData::D1EndSeedReference](#)
[ILinearPatternFeatureData::D2Axis](#)
[ILinearPatternFeatureData::D2EndReference](#)
[ILinearPatternFeatureData::D2EndSeedReference](#)
[ILocalLinearPatternFeatureData::D1Axis](#)
[ILocalLinearPatternFeatureData::D1EndReference](#)
[ILocalLinearPatternFeatureData::D1EndSeedReference](#)
[ILocalLinearPatternFeatureData::D2Axis](#)
[ILocalLinearPatternFeatureData::D2EndReference](#)
[ILocalLinearPatternFeatureData::D2EndSeedReference](#)
[IMirrorComponentFeatureData::AlignmentReferences](#)
[IMirrorComponentFeatureData::MirrorPlane](#)
[IMirrorPartFeatureData::GetMirrorPlane](#)
[IModelDoc2::CreatePlaneAtAngle3](#) and [IModelDoc2::ICreatePlaneAtAngle3](#)
[IModelDoc2::CreatePlaneAtOffset3](#) and [IModelDoc2::ICreatePlaneAtOffset3](#)
[IModelDoc2::CreatePlaneAtSurface3](#) and [IModelDoc2::ICreatePlaneAtSurface3](#)
[IModelDoc2::CreatePlaneFixed2](#) and [IModelDoc2::ICreatePlaneFixed2](#)
[IModelDoc2::CreatePlanePerCurveAndPassPoint3](#) and [IModelDoc2::ICreatePlanePerCurveAndPassPoint3](#)
[IModelDoc2::CreatePlaneThru3Points3](#) and [IModelDoc2::ICreatePlaneThru3Points3](#)
[IModelDoc2::CreatePlaneThruLineAndPt](#) and [IModelDoc2::ICreatePlaneThruLineAndPt](#)
[IModelDoc2::CreatePlaneThruPtParallelToPlane](#) and [IModelDoc2::ICreatePlaneThruPtParallelToPlane](#)
[IMoveFaceFeatureData::GetDirectionReference](#)
[IMoveFaceFeatureData::GetEndConditionEntity](#)
[IMoveFaceFeatureData::GetFromEntity](#)
[IPartingLineFeatureData::PullDirectionBase](#)
[IPartingSurfaceFeatureData::PullDirectionBase](#)
[IPrimaryMemberFacePlaneIntersectionFeatureData::GetIntersectingPlanesAndFaces](#)
[IPrimaryMemberPointLengthFeatureData::EndPlane](#)
[IPrimaryMemberRefPlaneFeatureData::GetReferenceAxes](#)
[IPrimaryMemberRefPlaneFeatureData::GetReferenceLocations](#)
[IPrimaryMemberRefPlaneFeatureData::GetStartAndEndReferences](#)
[IProfileGroupFolder::GetPlane](#)
[ISMNormalCutFeatureData2::OffsetPlaneReference](#)
[ISplitLineFeatureData::IGetSplitTools](#)
[ISplitLineFeatureData::PullDirectionBase](#)
[ISplitLineFeatureData::SplitTools](#)
[IStructureSystemMemberProfile::ProfileAlignmentObject](#)
[ISweepFeatureData::EndDirectionVector](#)
[ISweepFeatureData::GetPathAlignmentDirectionVector](#)
[ISweepFeatureData::StartDirectionVector](#)
[ISymmetricMateFeatureData::EntitiesToMate](#)
[ISymmetricMateFeatureData::SymmetryPlane](#)
[IThreadFeatureData::GetEndConditionReference](#)
[IThreadFeatureData::StartEntity](#)
[IWrapSketchFeatureData::PullDirection](#)

[RefPlane](#)

 See Also

[IRefPlane Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefPlaneFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRefPlane Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefPlane Interface

The following tables list the members exposed by [IRefPlane](#).

 Public Properties

Name	Description
 BoundingBox	Gets the bounding box of the reference plane, the top-left and bottom-right points.
 CornerPoints	Gets the corner points of this reference plane.
 Transform	Gets the plane transform with respect to the world.

[Top](#)

 Public Methods

Name	Description
 GetRefPlaneParams	Obsolete. Superseded by IRefPlane.Transform .
 IGetBoundingBox	Gets the bounding box of the reference plane, the top-left and bottom-right points.
 IGetCornerPoints	Gets the corner points of this reference plane.
 IGetRefPlaneParams	Obsolete. Superseded by IRefPlane.Transform .

[Top](#)

 See Also

[IRefPlane Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefPlaneFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRefPlane Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefPlane Interface

For a list of all members of this type, see [IRefPlane members](#).

 Public Methods

Name	Description
 GetRefPlaneParams	Obsolete. Superseded by IRefPlane.Transform .
 IGetBoundingBox	Gets the bounding box of the reference plane, the top-left and bottom-right points.
 IGetCornerPoints	Gets the corner points of this reference plane.
 IGetRefPlaneParams	Obsolete. Superseded by IRefPlane.Transform .

[Top](#)

 See Also

[IRefPlane Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefPlaneFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRefPlane Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRefPlane Interface

For a list of all members of this type, see [IRefPlane members](#).

Public Properties

Name	Description
 BoundingBox	Gets the bounding box of the reference plane, the top-left and bottom-right points.
 CornerPoints	Gets the corner points of this reference plane.
 Transform	Gets the plane transform with respect to the world.

[Top](#)

See Also

[IRefPlane Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRefPlaneFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BoundingBox Property (IRefPlane)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : BoundingBox Property (IRefPlane)

Gets the bounding box of the reference plane, the top-left and bottom-right points.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property BoundingBox As System.Object

Visual Basic (Usage)



```
Dim instance As IRefPlane
Dim value As System.Object

value = instance.BoundingBox
```

C#

```
System.object BoundingBox {get;}
```

C++/CLI

```
property System.Object^ BoundingBox {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array containing bounding box, always two (2) [IMathpoint](#) objects

Visual Basic for Applications (VBA) Syntax

See [RefPlane::BoundingBox](#).

Example

[Get Coordinates of the Plane's Bounding Box \(C#\)](#)
[Get Coordinates of the Plane's Bounding Box \(VB.NET\)](#)
[Get Coordinates of the Plane's Bounding Box \(VBA\)](#)

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)
[IRefPlane::IGetBoundingBox Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerPoints Property (IRefPlane)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : CornerPoints Property (IRefPlane)

Gets the corner points of this reference plane.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CornerPoints As System.Object

Visual Basic (Usage)



```
Dim instance As IRefPlane  
Dim value As System.Object  
  
value = instance.CornerPoints
```

C#

```
System.Object CornerPoints {get;}
```

C++/CLI

```
property System.Object^ CornerPoints {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of four (4) [IMathpoint](#) objects

Visual Basic for Applications (VBA) Syntax

See [RefPlane::CornerPoints](#).

Example

[Get Corner Points of Reference Plane \(VBA\)](#)
[Get Corner Points of Reference Plane \(VB.NET\)](#)
[Get Corner Points of Reference Plane \(C#\)](#)

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)
[IRefPlane::IGetCornerPoints Method](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRefPlaneParams Method (IRefPlane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : GetRefPlaneParams Method (IRefPlane)

Obsolete. Superseded by [IRefPlane::Transform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRefPlaneParams() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRefPlane  
Dim value As System.Object  
  
value = instance.GetRefPlaneParams()
```

C#

```
System.object GetRefPlaneParams()
```

C++/CLI

```
System.Object^ GetRefPlaneParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RefPlane::GetRefPlaneParams](#).

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBoundingBox Method (IRefPlane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : IGetBoundingBox Method (IRefPlane)

Gets the bounding box of the reference plane, the top-left and bottom-right points.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBoundingBox() As MathPoint
```

Visual Basic (Usage)



```
Dim instance As IRefPlane  
Dim value As MathPoint  
  
value = instance.IGetBoundingBox()
```

C#

```
MathPoint IGetBoundingBox()
```

C++/CLI

```
MathPoint^ IGetBoundingBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array containing the bounding box, always two (2) [Mathpoint](#) objects

- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)
[IRefPlane::BoundingBox Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCornerPoints Method (IRefPlane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : IGetCornerPoints Method (IRefPlane)

Gets the corner points of this reference plane.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCornerPoints() As MathPoint
```

Visual Basic (Usage)



```
Dim instance As IRefPlane  
Dim value As MathPoint
```

```
value = instance.IGetCornerPoints()
```

C#

```
MathPoint IGetCornerPoints()
```

C++/CLI

```
MathPoint^ IGetCornerPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of four (4) [IMathpoint](#) objects
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)
[IRefPlane::CornerPoints Property](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRefPlaneParams Method (IRefPlane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : IGetRefPlaneParams Method (IRefPlane)

Obsolete. Superseded by [IRefPlane::Transform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRefPlaneParams() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRefPlane
Dim value As System.Double

value = instance.IGetRefPlaneParams()
```

C#

```
System.double IGetRefPlaneParams()
```

C++/CLI

```
System.double IGetRefPlaneParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RefPlane::IGetRefPlaneParams](#).

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Transform Property (IRefPlane)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRefPlane Interface](#) : Transform Property (IRefPlane)

Gets the plane transform with respect to the world.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Transform As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IRefPlane
Dim value As MathTransform

value = instance.Transform
```

C#

```
MathTransform Transform {get;}
```

C++/CLI

```
property MathTransform^ Transform {
    MathTransform^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [RefPlane::Transform](#).

Example

[Get the Normal and Origin of a Reference Plane Using Its Transform \(VBA\)](#)
[Get Transform of Plane \(VBA\)](#)

See Also

[IRefPlane Interface](#)
[IRefPlane Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4