

SOLIDWORKS API (.NET VBA C#) — Reference (240/337): IRenderMaterial (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IRenderMaterial (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GlobalIlluminationCast Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : GlobalIlluminationCast Property (IRenderMaterial)

Gets whether specular materials reflect photons for illuminating this appearance..

.NET Syntax

Visual Basic (Declaration)

Property GlobalIlluminationCast As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Boolean

instance.GlobalIlluminationCast = value
value = instance.GlobalIlluminationCast
```

C#

```
System.bool GlobalIlluminationCast {get; set;}
```

C++/CLI

```
property System.bool GlobalIlluminationCast {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if specular materials reflect photons, false if not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::GlobalIlluminationCast](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GlobalIlluminationReceive Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : GlobalIlluminationReceive Property (IRenderMaterial)

Gets or sets whether diffuse materials absorb photons for illuminating this appearance.

.NET Syntax

Visual Basic (Declaration)

Property GlobalIlluminationReceive As System.Boolean

```
Dim instance As IRenderMaterial
Dim value As System.Boolean

instance.GlobalIlluminationReceive = value

value = instance.GlobalIlluminationReceive
```

C#

```
System.bool GlobalIlluminationReceive {get; set;}
```

C++/CLI

```
property System.bool GlobalIlluminationReceive {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if diffuse materials absorb photons, false if not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::GlobalIlluminationReceive](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Glossy Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Glossy Property (IRenderMaterial)

Gets or sets the specular factor of the lights reflected by the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property Glossy As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.Glossy = value

value = instance.Glossy
```

C#

```
System.double Glossy {get; set;}
```

C++/CLI

```
property System.double Glossy {
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Specular factor of the lights reflected by the appearance

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Glossy](#).

Remarks

Increasing Glossy makes reflections more visible.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasDSPBRProperties Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : HasDSPBRProperties Property (IRenderMaterial)

Gets whether this appearance has DSPBR properties.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property HasDSPBRProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Boolean  
  
value = instance.HasDSPBRProperties
```

C#

```
System.bool HasDSPBRProperties {get;}
```

C++/CLI

```
property System.bool HasDSPBRProperties {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this appearance has DSPBR properties, false if not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::HasDSPBRProperties](#).

Remarks

If this property is true, use [IRenderMaterial::GetDSPBRMaterial](#) to obtain the DSPBRMaterial object.

See Also

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

Height Property (IRenderMaterial)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Height Property (IRenderMaterial)

Gets or sets the height for mapping this appearance texture.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.Height](#).

Example

[Get Surface-finish Image Path and File Name \(C#\)](#)
[Get Surface-finish Image Path and File Name \(VB.NET\)](#)
[Get Surface-finish Image Path and File Name \(VBA\)](#)

Remarks

Call [IRenderMaterial.Width](#) to set the width of the appearance texture. If [IRenderMaterial.FixedAspectRatio](#) is true, then the image is uniformly scaled when either the width or height is changed.

To have the height and width of the appearance texture automatically stretch to fit a selected entity, call [IRenderMaterial.FitHeight](#) and [IRenderMaterial.FitWidth](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HeightMirror Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : HeightMirror Property (IRenderMaterial)

Gets or sets whether to flip the appearance texture about the selected direction vertically.

.NET Syntax

Visual Basic (Declaration)

Property HeightMirror As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Boolean
```

```
instance.HeightMirror = value
```

```
value = instance.HeightMirror
```

C#

```
System.bool HeightMirror {get; set;}
```

C++/CLI

```
property System.bool HeightMirror {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the appearance texture about the selected direction vertically, false to not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.HeightMirror](#).

Remarks

Call [IRenderMaterial.WidthMirror](#) to flip the appearance texture about the selected direction horizontally.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleMeshSize Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : HoleMeshSize Property (IRenderMaterial)

Gets or sets the hole mesh size.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleMeshSize As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.HoleMeshSize = value
```

```
value = instance.HoleMeshSize
```

C#

```
System.double HoleMeshSize {get; set;}
```

C++/CLI

```
property System.double HoleMeshSize {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole mesh size

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::HoleMeshSize](#).

Remarks

This property is valid only if [IRenderMaterial::SurfaceFinishShaderType](#) is set to:

- [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_DiamondHoleMesh](#)
- OR -
- [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_CircularHoleMesh](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEntities Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : IGetEntities Method (IRenderMaterial)

Gets the entities on which this appearance is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IRenderMaterial  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetEntities(Count)
```

C#

```
System.object IGetEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetEntities(  
    & System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of entities

Return Value

- in-process, unmanaged C++: Pointer to an array of entities on which this appearance is applied
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IRenderMaterial::GetEntitiesCount](#) to get the value of Count.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetEntities Method](#)
[IRenderMaterial::AddEntity Method](#)
[IRenderMaterial::RemoveAllEntities Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreMissingFile Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : IgnoreMissingFile Property (IRenderMaterial)

Gets or sets whether to ignore any missing image file warnings.

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreMissingFile As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRenderMaterial  
Dim value As System.Boolean  
  
instance.IgnoreMissingFile = value  
  
value = instance.IgnoreMissingFile
```

C#

```
System.bool IgnoreMissingFile {get; set;}
```

C++/CLI

```
property System.bool IgnoreMissingFile {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to ignore any missing image file warnings, false to not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.IgnoreMissingFile](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IlluminationShaderType Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : IlluminationShaderType Property (IRenderMaterial)

Gets or sets the type of illumination of the appearance.

.NET Syntax

Visual Basic (Declaration)

Property IlluminationShaderType As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Integer
```

```
instance.IlluminationShaderType = value
```

```
value = instance.IlluminationShaderType
```

C#

```
System.int IlluminationShaderType {get; set;}
```

C++/CLI

```
property System.int IlluminationShaderType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of illumination as defined in [swRenderMaterialIlluminationTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.IlluminationShaderType](#).

See Also

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IndexOfRefraction Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : IndexOfRefraction Property (IRenderMaterial)

Gets or sets the index of refraction for illuminating this appearance.

.NET Syntax

Visual Basic (Declaration)

Property IndexOfRefraction As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.IndexOfRefraction = value  
value = instance.IndexOfRefraction
```

C#

```
System.double IndexOfRefraction {get; set;}
```

C++/CLI

```
property System.double IndexOfRefraction {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index of refraction

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::IndexOfRefraction](#).

Remarks

This property controls the bending of light as it passes through a transparent object. Although actually dependent on the ratio of indices between the transparent material entered and the material exited, in practice, the higher the index of refraction, the more the light is bent. Typical values are 1.0 for air, 1.33 for water, and 1.44 for glass.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KnurlAngle Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : KnurlAngle Property (IRenderMaterial)

Gets or sets the knurl angle of this appearance.

.NET Syntax

Visual Basic (Declaration)

Property KnurlAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.KnurlAngle = value
```

```
value = instance.KnurlAngle
```

C#

```
System.double KnurlAngle {get; set;}
```

C++/CLI

```
property System.double KnurlAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Knurl angle

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::KnurlAngle](#).

Remarks

This property is valid only if [IRenderMaterial::SurfaceFinishShaderType](#) is set to [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_Knurl](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

KnurlHeightCap Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : KnurlHeightCap Property (IRenderMaterial)

Gets or sets the maximum knurl height of this appearance.

.NET Syntax

Visual Basic (Declaration)

Property KnurlHeightCap As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.KnurlHeightCap = value
value = instance.KnurlHeightCap
```

C#

```
System.double KnurlHeightCap {get; set;}
```

C++/CLI

```
property System.double KnurlHeightCap {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Knurl height cap

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::KnurlHeightCap](#).

Remarks

This property is valid only if [IRenderMaterial::SurfaceFinishShaderType](#) is set to [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_Knurled](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

LinkToFile Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : LinkToFile Property (IRenderMaterial)

Gets or sets whether to link instances of the appearance to an appearance file (.p2m).

.NET Syntax

Visual Basic (Declaration)

```
Property LinkToFile As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Boolean

instance.LinkToFile = value
value = instance.LinkToFile
```

C#

```
System.bool LinkToFile {get; set;}
```

C++/CLI

```
property System.bool LinkToFile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link instances of the appearance to an appearance file (.p2m), false to not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.LinkToFile](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MappingType Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MappingType Property (IRenderMaterial)

Gets or sets the mapping type for this appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property MappingType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer
```

```
instance.MappingType = value
```

```
value = instance.MappingType
```

C#

```
System.int MappingType {get; set;}
```

C++/CLI

```
property System.int MappingType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = Surface
- 1 = Projection
- 2 = Spherical
- 3 = Cylindrical
- 4 = Automatic

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MappingType](#).

Example

See the "Add Decal" examples in [IRenderMaterial::FileName](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaterialID Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MaterialID Property (IRenderMaterial)

Not supported in SOLIDWORKS 2011 and later. Superseded by [IRenderMaterial::GetMaterialIds](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property MaterialID As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer  
  
value = instance.MaterialID
```

C#

```
System.int MaterialID {get;}
```

C++/CLI

```
property System.int MaterialID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Appearance ID

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MaterialID](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicAmplitude Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MetallicAmplitude Property (IRenderMaterial)

Gets or sets the amplitude of the metallic flakes for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property MetallicAmplitude As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.MetallicAmplitude = value

value = instance.MetallicAmplitude
```

C#

```
System.double MetallicAmplitude {get; set;}
```

C++/CLI

```
property System.double MetallicAmplitude {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Amplitude of the metallic flakes

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MetallicAmplitude](#).

Remarks

When the metallic amplitude is set to smaller values, the metallic flakes are flat. When set to larger values, the metallic flakes are irregular and high.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicFlakeMaterial Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MetallicFlakeMaterial Property (IRenderMaterial)

Gets or sets the metallic flake material for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property MetallicFlakeMaterial As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer  
  
instance.MetallicFlakeMaterial = value  
value = instance.MetallicFlakeMaterial
```

C#

```
System.int MetallicFlakeMaterial {get; set;}
```

C++/CLI

```
property System.int MetallicFlakeMaterial {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = Aluminum
- 1 = Copper
- 2 = Gold
- 3 = Silver

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.MetallicFlakeMaterial](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicMix Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MetallicMix Property (IRenderMaterial)

Gets or sets the metallic quality of a material for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property MetallicMix As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.MetallicMix = value  
value = instance.MetallicMix
```

C#

```
System.double MetallicMix {get; set;}
```

C++/CLI

```
property System.double MetallicMix {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Metallic quality

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MetallicMix](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicRoughness Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MetallicRoughness Property (IRenderMaterial)

Gets or sets the size (coarseness) any highlights on the surface for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property MetallicRoughness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.MetallicRoughness = value  
  
value = instance.MetallicRoughness
```

C#

```
System.double MetallicRoughness {get; set;}
```

C++/CLI

```
property System.double MetallicRoughness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Size of any highlights on the surface

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MetallicRoughness](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicScale Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : MetallicScale Property (IRenderMaterial)

Gets or sets the size of the metallic flakes in the metallic layer for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property MetallicScale As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.MetallicScale = value
```

```
value = instance.MetallicScale
```

C#

```
System.double MetallicScale {get; set;}
```

C++/CLI

```
property System.double MetallicScale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Size of the metallic flakes in the metallic layer

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::MetallicScale](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NSamples Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : NSamples Property (IRenderMaterial)

Gets or sets the number of samples used to calculate the contribution of the glossy component for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property NSamples As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.NSamples = value  
value = instance.NSamples
```

C#

```
System.double NSamples {get; set;}
```

C++/CLI

```
property System.double NSamples {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of samples used to calculate the contribution of the glossy component

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::NSamples](#).

Remarks

Increasing the sampling rate reduces artifacts but reduces performance. This property is available when the type of material is Satin Finish, Accurate reflections is selected, and Glossy is non-zero.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ObjectAreaLight Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : ObjectAreaLight Property (IRenderMaterial)

Gets or sets whether the appearance is an object area light or whether it has realistic falloff, or both.

.NET Syntax

Visual Basic (Declaration)

Property ObjectAreaLight As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer
```

```
instance.ObjectAreaLight = value  
value = instance.ObjectAreaLight
```

C#

```
System.int ObjectAreaLight {get; set;}
```

C++/CLI

```
property System.int ObjectAreaLight {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the appearance has an object area light or it has realistic falloff, or both; false if it does not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::ObjectAreaLight](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetLatitude Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : OffsetLatitude Property (IRenderMaterial)

Gets or sets the offset latitude value for a spherical mapping type.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetLatitude As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.OffsetLatitude = value
```

```
value = instance.OffsetLatitude
```

C#

```
System.double OffsetLatitude {get; set;}
```

C++/CLI

```
property System.double OffsetLatitude {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset latitude value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::OffsetLatitude](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetLongitude Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : OffsetLongitude Property (IRenderMaterial)

Gets or sets the offset longitude value for a spherical mapping type.

.NET Syntax

Visual Basic (Declaration)

Property OffsetLongitude As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.OffsetLongitude = value
```

```
value = instance.OffsetLongitude
```

C#

```
System.double OffsetLongitude {get; set;}
```

C++/CLI

```
property System.double OffsetLongitude {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset longitude value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::OffsetLongitude](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

PatternScale Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : PatternScale Property (IRenderMaterial)

Gets or sets the pattern scale of procedural textures for mapping the appearance.

.NET Syntax

Visual Basic (Declaration)

Property PatternScale As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.PatternScale = value
```

```
value = instance.PatternScale
```

C#

```
System.double PatternScale {get; set;}
```

C++/CLI

```
property System.double PatternScale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern scale

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::PatternScale](#).

Remarks

A procedural texture is one where you only have control over the colors in the material and the size of the material (for example, colored marble or cherry wood).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

PrimaryColor Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : PrimaryColor Property (IRenderMaterial)

Gets or sets the primary color of the appearance.

.NET Syntax

Visual Basic (Declaration)

Property PrimaryColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer  
  
instance.PrimaryColor = value  
value = instance.PrimaryColor
```

C#

```
System.int PrimaryColor {get; set;}
```

C++/CLI

```
property System.int PrimaryColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::PrimaryColor](#).

Remarks

This property corresponds to the **Current Color 1** control on the Color/Image tab of the Appearances PropertyManager page.

To get or set:

- **Current Color 2**, call [IRenderMaterial::SecondaryColor](#).
- **Current Color 3**, call [IRenderMaterial::TertiaryColor](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProjectionReference Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : ProjectionReference Property (IRenderMaterial)

Gets or sets the projection direction for mapping the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property ProjectionReference As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer
```

```
instance.ProjectionReference = value  
value = instance.ProjectionReference
```

C#

```
System.int ProjectionReference {get; set;}
```

C++/CLI

```
property System.int ProjectionReference {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = XY
- 1 = ZX
- 2 = YZ
- 3 = Current View
- 4 = Selected Reference

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::ProjectionReference](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Reflectivity Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Reflectivity Property (IRenderMaterial)

Gets or sets the reflectivity for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property Reflectivity As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.Reflectivity = value  
value = instance.Reflectivity
```

C#

```
System.double Reflectivity {get; set;}
```

C++/CLI

```
property System.double Reflectivity {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reflectivity

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Reflectivity](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveAllEntities Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : RemoveAllEntities Method (IRenderMaterial)

Removes the appearance from all entities on which it is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveAllEntities()
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
  
instance.RemoveAllEntities()
```

C#

```
void RemoveAllEntities()
```

C++/CLI

```
void RemoveAllEntities();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::RemoveAllEntities](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::AddEntity Method](#)
[IRenderMaterial::GetEntities Method](#)
[IRenderMaterial::GetEntitiesCount Method](#)
[IRenderMaterial::IGetEntities Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotationAngle Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : RotationAngle Property (IRenderMaterial)

Gets or sets the angle by which to rotate the texture relative to the axes for mapping this appearance.

.NET Syntax

Visual Basic (Declaration)

Property RotationAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.RotationAngle = value
```

```
value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle by which to rotate the texture relative to the axes

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::RotationAngle](#).

Remarks

This property is only valid when either a spherical or cylindrical [mapping type](#) is selected.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Roughness Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Roughness Property (IRenderMaterial)

Gets or sets the specular spread (roughness) of the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Roughness As System.Double

```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.Roughness = value

value = instance.Roughness
```

C#

```
System.double Roughness {get; set;}
```

C++/CLI

```
property System.double Roughness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Specular spread

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Roughness](#).

Remarks

This property controls the size of any highlights on a surface. It is also known as the specular exponent. Increasing Roughness makes highlights larger and softer.

The [specular](#) value must not be zero, the [specular color](#) must not be black, and at least one light other than an ambient light must be illuminating the model.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RoundSharpEdges Property (IRenderMaterial)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : RoundSharpEdges Property (IRenderMaterial)

Gets or sets the value by which to round sharp edges when rendering a model using a ray-trace rendering engine.

.NET Syntax

Visual Basic (Declaration)

```
Property RoundSharpEdges As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.RoundSharpEdges = value

value = instance.RoundSharpEdges
```

C#

```
System.double RoundSharpEdges {get; set;}
```

C++/CLI

```
property System.double RoundSharpEdges {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value by which to round sharp edges

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial:RoundSharpEdges](#).

Example

[Get Surface-finish Image Path and File Name \(C#\)](#)
[Get Surface-finish Image Path and File Name \(VB.NET\)](#)
[Get Surface-finish Image Path and File Name \(VBA\)](#)

Remarks

This method:

- is only available when a ray-trace rendering engine is loaded.
- does not change model geometry.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondaryColor Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SecondaryColor Property (IRenderMaterial)

Gets or sets the secondary color of the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property SecondaryColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer
```

```
instance.SecondaryColor = value
```

```
value = instance.SecondaryColor
```

C#

```
System.int SecondaryColor {get; set;}
```

C++/CLI

```
property System.int SecondaryColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.SecondaryColor](#).

Remarks

This property corresponds to the **Current Color 2** control on the Color/Image tab of the Appearances PropertyManager page.

To get or set:

- **Current Color 1**, call [IRenderMaterial::PrimaryColor](#).
- **Current Color 3**, call [IRenderMaterial::TertiaryColor](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCenterPoint Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetCenterPoint Method (IRenderMaterial)

Obsolete. Superseded by [IRenderMaterial.SetCenterPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCenterPoint(  
    ByRef CenterPt As System.Double  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim CenterPt As System.Double  
  
instance.SetCenterPoint(CenterPt)
```

C#

```
void SetCenterPoint(  
    ref System.double CenterPt  
)
```

C++/CLI

```
void SetCenterPoint(  
    & System.double% CenterPt  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CenterPt
Array of doubles (x, y, z) representing the centerpoint of the mapping for texture-based appearances

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.SetCenterPoint](#).

Remarks

This method is required to properly position a texture-based appearance (e.g., if you need a specific corner of a face to have the black square of a checkered-pattern appearance).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial.GetCenterPoint Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCenterPoint2 Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetCenterPoint2 Method (IRenderMaterial)

Sets the center point of the mapping for texture-based appearances.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCenterPoint2( _  
    ByVal CenterPt\_X As System.Double, _  
    ByVal CenterPt\_Y As System.Double, _  
    ByVal CenterPt\_Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim CenterPt_X As System.Double  
Dim CenterPt_Y As System.Double  
Dim CenterPt_Z As System.Double  
  
instance.SetCenterPoint2(CenterPt_X, CenterPt_Y, CenterPt_Z)
```

C#

```
void SetCenterPoint2(  
    System.double CenterPt\_X,  
    System.double CenterPt\_Y,  
    System.double CenterPt\_Z  
)
```

C++/CLI

```
void SetCenterPoint2(  
& System.double CenterPt\_X,  
& System.double CenterPt\_Y,  
& System.double CenterPt\_Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CenterPt_X
X coordinate of the center point
CenterPt_Y
Y coordinate of the center point
CenterPt_Z
Z coordinate of the center point

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetCenterPoint2](#).

Remarks

This method is required to properly position a texture-based appearance (e.g., if you need a specific corner of a face to have the black square of a checkered-pattern appearance).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetCenterPoint2 Method \(\)](#)

Availability

SOLIDWORKS 2013 SP05, Revision 21.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLinkedDisplayStates Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetLinkedDisplayStates Method (IRenderMaterial)

Sets the display states to which this appearance is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLinkedDisplayStates( _  
    ByVal DisplayStateOption As System.Integer, _  
    ByVal DisplayStateNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim DisplayStateOption As System.Integer  
Dim DisplayStateNames As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetLinkedDisplayStates(DisplayStateOption, DisplayStateNames)
```

C#

```
System.bool SetLinkedDisplayStates(  
    System.int DisplayStateOption,  
    System.object DisplayStateNames  
)
```

C++/CLI

```
System.bool SetLinkedDisplayStates(  
& System.int DisplayStateOption,  
& System.Object^ DisplayStateNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateOption

Display states as defined in [swDisplayStateOpts_e](#)
DisplayStateNames
Array of display state names

Return Value

True if display states successfully linked, false if not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetLinkedDisplayStates](#).

Example

See the [IRenderMaterial](#) examples.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetLinkedDisplayStates Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUDirection Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetUDirection Method (IRenderMaterial)

Obsolete. Superseded by [IRenderMaterial::SetUDirection2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetUDirection( _  
    ByRef UDir As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim UDir As System.Double  
  
instance.SetUDirection(UDir)
```

C#

```
void SetUDirection(  
    ref System.double UDir  
)
```

C++/CLI

```
void SetUDirection(  
    & System.double% UDir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UDir

Array of doubles representing the U direction for the texture-based appearance (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetUDirection](#).

Remarks

To specify the U direction in the X direction, set UDir to {1, 0, 0}.

Call [IRenderMaterial::SetVDirection](#) to set the V direction of the appearance.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetUDirection Method](#)
[IRenderMaterial::GetVDirection Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUDirection2 Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetUDirection2 Method (IRenderMaterial)

Sets the U direction of the texture-based appearance.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetUDirection2( _  
    ByVal UDir\_X As System.Double, _  
    ByVal UDir\_Y As System.Double, _  
    ByVal UDir\_Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim UDir_X As System.Double  
Dim UDir_Y As System.Double  
Dim UDir_Z As System.Double  
  
instance.SetUDirection2(UDir_X, UDir_Y, UDir_Z)
```

C#

```
void SetUDirection2(  
    System.double UDir\_X,  
    System.double UDir\_Y,  
    System.double UDir\_Z  
)
```

C++/CLI

```
void SetUDirection2(  
& System.double UDir\_X,  
& System.double UDir\_Y,  
& System.double UDir\_Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[UDir_X](#)
X coordinate of the U direction
[UDir_Y](#)
Y coordinate of the U direction
[UDir_Z](#)
Z coordinate of the U direction

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetUDirection2](#).

Remarks

To specify the U direction in the X direction, set:

1. UDir_X to 1.0.
2. UDir_Y to 0.0.
3. UDir_Z to 0.0.

Call [IRenderMaterial::SetVDirection2](#) to set the V direction of the appearance.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetUDirection2 Method \(\)](#)
[IRenderMaterial::GetVDirection2 Method \(\)](#)

Availability

SOLIDWORKS 2013 SP05, Revision 21.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVDirection Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetVDirection Method (IRenderMaterial)

Obsolete. Superseded by [IRenderMaterial::SetVDirection2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVDirection( _  
    ByRef VDir As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim VDir As System.Double  
  
instance.SetVDirection(VDir)
```

C#

```
void SetVDirection(  
    ref System.double VDir  
)
```

C++/CLI

```
void SetVDirection(  
& System.double% VDir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VDir

Array of doubles representing the V direction of the texture-based appearance (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetVDirection](#).

Remarks

To specify the V direction in the Y direction, set VDir to {0,1,0}.

The [mapping_type](#) (surface, projection, automatic, etc.) indirectly determines the V direction. This vector is perpendicular to the U direction.

Call [IRenderMaterial::SetUDirection](#) to set the U direction.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetUDirection Method](#)
[IRenderMaterial::GetVDirection Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVDirection2 Method (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SetVDirection2 Method (IRenderMaterial)

Sets the V direction of the texture-based appearance.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVDirection2( _  
    ByVal VDir\_X As System.Double, _  
    ByVal VDir\_Y As System.Double, _  
    ByVal VDir\_Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim VDir_X As System.Double  
Dim VDir_Y As System.Double  
Dim VDir_Z As System.Double  
  
instance.SetVDirection2(VDir_X, VDir_Y, VDir_Z)
```

C#

```
void SetVDirection2(  
    System.double VDir\_X,  
    System.double VDir\_Y,  
    System.double VDir\_Z  
)
```

C++/CLI

```
void SetVDirection2(  
& System.double VDir\_X,  
& System.double VDir\_Y,  
& System.double VDir\_Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[VDir_X](#)
X coordinate of the V direction
[VDir_Y](#)
Y coordinate of the V direction
[VDir_Z](#)
Z coordinate of the V direction

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SetVDirection2](#).

Remarks

To specify the V direction in the Y direction, set:

1. VDir_X to 0.0.
2. VDir_Y to 1.0.
3. VDir_Z to 0.0.

The [mapping_type](#) (surface, projection, automatic, etc.) indirectly determines the V direction. This vector is perpendicular to the U direction.

Call [IRenderMaterial::SetUDirection2](#) to set the U direction.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)
[IRenderMaterial::GetUDirection2 Method \(\)](#)
[IRenderMaterial::GetVDirection2 Method \(\)](#)

Availability

SOLIDWORKS 2013 SP05, Revision 21.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

Specular Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Specular Property (IRenderMaterial)

Gets or sets the intensity of the light surface for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Specular As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.Specular = value
```

```
value = instance.Specular
```

C#

```
System.double Specular {get; set;}
```

C++/CLI

```
property System.double Specular {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Intensity of the light surface

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Specular](#).

Remarks

This property depends on the position of the light source and the position of the viewer. Increasing Specular makes the material appear shinier. [IRenderMaterial::SpecularColor](#) must not be black, and at least one light other than an ambient light must be illuminating the model.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SpecularColor Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SpecularColor Property (IRenderMaterial)

Gets or sets the specular color for illuminating this appearance.

.NET Syntax

Visual Basic (Declaration)

Property SpecularColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Integer  
  
instance.SpecularColor = value  
value = instance.SpecularColor
```

C#

```
System.int SpecularColor {get; set;}
```

C++/CLI

```
property System.int SpecularColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SpecularColor](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfaceFinishFile Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SurfaceFinishFile Property (IRenderMaterial)

Gets or sets the path and file name of the pattern based on an image file for the surface finish of this appearance.

.NET Syntax

Visual Basic (Declaration)

Property SurfaceFinishFile As System.String

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.String

instance.SurfaceFinishFile = value

value = instance.SurfaceFinishFile
```

C#

```
System.string SurfaceFinishFile {get; set;}
```

C++/CLI

```
property System.String^ SurfaceFinishFile {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path to an image file for the surface finish

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SurfaceFinishFile](#).

Remarks

This property is valid only if [IRenderMaterial::SurfaceFinishShaderType](#) is set to [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_FromFile](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfaceFinishFileNormalMap Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SurfaceFinishFileNormalMap Property (IRenderMaterial)

Gets or sets whether to map the surface finish file image to the normal.

.NET Syntax

Visual Basic (Declaration)

Property SurfaceFinishFileNormalMap As System.Boolean

```
Dim instance As IRenderMaterial
Dim value As System.Boolean

instance.SurfaceFinishFileNormalMap = value

value = instance.SurfaceFinishFileNormalMap
```

C#

```
System.bool SurfaceFinishFileNormalMap {get; set;}
```

C++/CLI

```
property System.bool SurfaceFinishFileNormalMap {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to map the image to the normal, false to not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SurfaceFinishFileNormalMap](#).

Remarks

This property is valid only if [IRenderMaterial::SurfaceFinishShaderType](#) is set to [swAppearanceSurfaceFinishShaderTypes_e.swAppearanceSurfaceFinishShaderType_FromFile](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

SurfaceFinishShaderType Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : SurfaceFinishShaderType Property (IRenderMaterial)

Gets or sets the type of surface finish for the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property SurfaceFinishShaderType As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IRenderMaterial
Dim value As System.Integer

instance.SurfaceFinishShaderType = value

value = instance.SurfaceFinishShaderType
```

C#

```
System.int SurfaceFinishShaderType {get; set;}
```

C++/CLI

```
property System.int SurfaceFinishShaderType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Surface finish shader type as defined by [swAppearanceSurfaceFinishShaderTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::SurfaceFinishShaderType](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2025 FCS, Revision Number 33

SOLIDWORKS API Help

[Send comments on this topic.](#)

TertiaryColor Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : TertiaryColor Property (IRenderMaterial)

Gets or sets the tertiary color of the appearance.

.NET Syntax

Visual Basic (Declaration)

Property TertiaryColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Integer
```

```
instance.TertiaryColor = value
```

```
value = instance.TertiaryColor
```

C#

```
System.int TertiaryColor {get; set;}
```

C++/CLI

```
property System.int TertiaryColor {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::TertiaryColor](#).

Remarks

This property corresponds to the **Current Color 3** control on the Color/Image tab of the Appearances PropertyManager page.

To get or set:

- **Current Color 1**, call [IRenderMaterial::PrimaryColor](#).
- **Current Color 2**, call [IRenderMaterial::SecondaryColor](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureFilename Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : TextureFilename Property (IRenderMaterial)

Gets or sets the path and filename of the texture for this appearance.

.NET Syntax

Visual Basic (Declaration)

Property TextureFilename As System.String

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.String
```

```
instance.TextureFilename = value
```

```
value = instance.TextureFilename
```

C#

```
System.string TextureFilename {get; set;}
```

C++/CLI

```
property System.String^ TextureFilename {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and filename of the texture

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::TextureFilename](#).

Example

See the "Add Decal" examples in [IRenderMaterial::FileName](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ToonShaderTextureFilename Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : ToonShaderTextureFilename Property (IRenderMaterial)

Gets or sets the path and filename for the toon shader texture file.

.NET Syntax

Visual Basic (Declaration)

Property ToonShaderTextureFilename As System.String

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.String

instance.ToonShaderTextureFilename = value
value = instance.ToonShaderTextureFilename
```

C#

```
System.string ToonShaderTextureFilename {get; set;}
```

C++/CLI

```
property System.String^ ToonShaderTextureFilename {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and filename for the toon shader texture file

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.ToonShaderTextureFilename](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Translucency Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Translucency Property (IRenderMaterial)

Gets or sets the degree to which the material is able to filter and diffuse light for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Translucency As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.Translucency = value  
value = instance.Translucency
```

C#

```
System.double Translucency {get; set;}
```

C++/CLI

```
property System.double Translucency {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Degree to which the material is able to filter and diffuse light

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Translucency](#).

Remarks

Increasing Translucency gives the material more backlighting.

A light must be behind the model relative to the position of the viewer.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Transparency Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Transparency Property (IRenderMaterial)

Gets or sets the degree to which a material allows light to pass through for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property Transparency As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double  
  
instance.Transparency = value
```

```
value = instance.Transparency
```

C#

```
System.double Transparency {get; set;}
```

C++/CLI

```
property System.double Transparency {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Degree to which a material allows light to pass through

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial.Transparency](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Width Property (IRenderMaterial)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : Width Property (IRenderMaterial)

Gets or sets the width for mapping this appearance texture.

.NET Syntax

Visual Basic (Declaration)

```
Property Width As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.double Width {get; set;}
```

C++/CLI

```
property System.double Width {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::Width](#).

Example

[Get Surface-finish Image Path and File Name \(C#\)](#)
[Get Surface-finish Image Path and File Name \(VB.NET\)](#)
[Get Surface-finish Image Path and File Name \(VBA\)](#)

Remarks

Call [IRenderMaterial::Height](#) to set the height of the appearance texture. If [IRenderMaterial::FixedAspectRatio](#) is true, then the image is uniforml scaled when either the width or height is changed.

To have the height and width of the appearance texture automatically stretch to fit a selected entity, call [IRenderMaterial::FitHeight](#) and [IRenderMaterial::FitWidth](#).

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WidthMirror Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : WidthMirror Property (IRenderMaterial)

Gets or sets whether to flip the appearance texture about the selected direction horizontally.

.NET Syntax

Visual Basic (Declaration)

```
Property WidthMirror As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Boolean
```

```
instance.WidthMirror = value
```

```
value = instance.WidthMirror
```

C#

```
System.bool WidthMirror {get; set;}
```

C++/CLI

```
property System.bool WidthMirror {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the appearance texture about the selected direction horizontally, false to not

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::WidthMirror](#).

Remarks

Call [IRenderMaterial::HeightMirror](#) to flip the appearance texture about the selected direction vertically.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

XPosition Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : XPosition Property (IRenderMaterial)

Gets or sets the X offset direction for the appearance.

.NET Syntax

Visual Basic (Declaration)

Property XPosition As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial
Dim value As System.Double

instance.XPosition = value
value = instance.XPosition
```

C#

```
System.double XPosition {get; set;}
```

C++/CLI

```
property System.double XPosition {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

X offset direction

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::XPosition](#).

Remarks

This property offsets the appearance from its original position.

Call [IRenderMaterial::YPosition](#) to set the Y offset direction for the appearance.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

YPosition Property (IRenderMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRenderMaterial Interface](#) : YPosition Property (IRenderMaterial)

Gets or sets the Y offset direction for the appearance.

.NET Syntax

Visual Basic (Declaration)

Property YPosition As System.Double

Visual Basic (Usage)



```
Dim instance As IRenderMaterial  
Dim value As System.Double
```

```
instance.YPosition = value
```

```
value = instance.YPosition
```

C#

```
System.double YPosition {get; set;}
```

C++/CLI

```
property System.double YPosition {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Y offset direction

Visual Basic for Applications (VBA) Syntax

See [RenderMaterial::YPosition](#).

Remarks

This property offsets the appearance from its original position.

Call [IRenderMaterial::XPosition](#) to set the X coordinate for the appearance.

See Also

[IRenderMaterial Interface](#)
[IRenderMaterial Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0