

SOLIDWORKS API (NET VBA C#) — Reference (241/337): IReplaceFaceFeatureData- IRevisionTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IReplaceFaceFeatureData (Type)

IReplaceFaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReplaceFaceFeatureData Interface

Allows access to Replace Face feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IReplaceFaceFeatureData
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData
```

C#

```
public interface IReplaceFaceFeatureData
```

C++/CLI

```
public interface class IReplaceFaceFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData](#).

Example

[Create Replace Face Feature \(VBA\)](#)
[Create Replace Face Feature \(VB.NET\)](#)
[Create Replace Face Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[ReplaceFaceFeatureData](#)

See Also

[IReplaceFaceFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertFeatureReplaceFace Method \(\)](#)

IReplaceFaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IReplaceFaceFeatureData Interface

The following tables list the members exposed by [IReplaceFaceFeatureData](#).

Public Properties

Name	Description
 FacesForReplacement	Gets or sets the faces to replace for this feature.
 ReplacementSurfaces	Gets or sets the replacement surfaces for this feature.

 Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this Replace Face feature.
 GetFacesForReplacementCount	Gets the number of faces to replace in this feature.
 GetReplacementSurfacesCount	Gets the number of replacement surfaces for this feature.
 IAccessSelections	Accesses the selections that define this Replace Face feature.
 IGetFacesForReplacement	Gets the faces to replace in this feature.
 IGetReplacementSurfaces	Gets the replacement surfaces for this feature.
 ISetFacesForReplacement	Sets the faces to replace for this feature.
 ISetReplacementSurfaces	Sets the replacement surfaces for this feature.
 ReleaseSelectionAccess	Releases access to the selections in this feature.

 See Also

[IReplaceFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertFeatureReplaceFace Method \(\)](#)

IReplaceFaceFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IReplaceFaceFeatureData Interface

For a list of all members of this type, see [IReplaceFaceFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this Replace Face feature.
 GetFacesForReplacementCount	Gets the number of faces to replace in this feature.
 GetReplacementSurfacesCount	Gets the number of replacement surfaces for this feature.
 IAccessSelections	Accesses the selections that define this Replace Face feature.
 IGetFacesForReplacement	Gets the faces to replace in this feature.
 IGetReplacementSurfaces	Gets the replacement surfaces for this feature.
 ISetFacesForReplacement	Sets the faces to replace for this feature.
 ISetReplacementSurfaces	Sets the replacement surfaces for this feature.
 ReleaseSelectionAccess	Releases access to the selections in this feature.

 See Also

[IReplaceFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertFeatureReplaceFace Method \(\)](#)

IReplaceFaceFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IReplaceFaceFeatureData Interface

For a list of all members of this type, see [IReplaceFaceFeatureData members](#).

Public Properties

Name	Description
 FacesForReplacement	Gets or sets the faces to replace for this feature.
 ReplacementSurfaces	Gets or sets the replacement surfaces for this feature.

[Top](#)

See Also

[IReplaceFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertFeatureReplaceFace Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : AccessSelections Method (IReplaceFaceFeatureData)

Accesses the selections that define this Replace Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
    & System.Object^ TopDoc,  
    & System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::AccessSelections](#).

Example

See the [IReplaceFaceFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IReplaceFaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FacesForReplacement Property (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : FacesForReplacement Property (IReplaceFaceFeatureData)

Gets or sets the faces to replace for this feature.

.NET Syntax

Visual Basic (Declaration)

Property FacesForReplacement As System.Object

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim value As System.Object
```

```
instance.FacesForReplacement = value
```

```
value = instance.FacesForReplacement
```

C#

```
System.object FacesForReplacement {get; set;}
```

C++/CLI

```
property System.Object^ FacesForReplacement {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) to replace

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::FacesForReplacement](#).

Example

See the [IReplaceFaceFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::GetFacesForReplacementCount Method](#)
[IReplaceFaceFeatureData::!GetFacesForReplacement Method](#)
[IReplaceFaceFeatureData::!SetFacesForReplacement Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesForReplacementCount Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : GetFacesForReplacementCount Method (IReplaceFaceFeatureData)

Gets the number of faces to replace in this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesForReplacementCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetFacesForReplacementCount()
```

C#

```
System.int GetFacesForReplacementCount()
```

C++/CLI

```
System.int GetFacesForReplacementCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces to replace

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::GetFacesForReplacementCount](#).

Example

See the [IReplaceFaceFeatureData](#) examples.

Remarks

Call this method before calling [IReplaceFaceFeatureData::!GetFacesForReplacement](#).

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::!SetFacesForReplacement Method](#)
[IReplaceFaceFeatureData::FacesForReplacement Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReplacementSurfacesCount Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : GetReplacementSurfacesCount Method (IReplaceFaceFeatureData)

Gets the number of replacement surfaces for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReplacementSurfacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetReplacementSurfacesCount()
```

C#

```
System.int GetReplacementSurfacesCount()
```

C++/CLI

```
System.int GetReplacementSurfacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of replacement surfaces

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::GetReplacementSurfacesCount](#).

Example

See the [IReplaceFaceFeatureData](#) examples.

Remarks

Call this method before calling [IReplaceFaceFeatureData::!GetReplacementSurfaces](#).

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::!SetReplacementSurfaces Method](#)
[IReplaceFaceFeatureData::ReplacementSurfaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IAccessSelections Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : IAccessSelections Method (IReplaceFaceFeatureData)

Accesses the selections that define this Replace Face feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IReplaceFaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFacesForReplacement Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : IGetFacesForReplacement Method (IReplaceFaceFeatureData)

Gets the faces to replace in this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacesForReplacement( _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim Count As System.Integer  
Dim value As Face2
```

```
value = instance.IGetFacesForReplacement(Count)
```

C#

```
Face2 IGetFacesForReplacement(  
    System.int Count  
)
```

C++/CLI

```
Face2^ IGetFacesForReplacement(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces to replace

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) to replace of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IReplaceFaceFeatureData::GetFacesForReplacementCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::ISetFacesForReplacement Method](#)
[IReplaceFaceFeatureData::FacesForReplacement Property](#)

Availability

IGetReplacementSurfaces Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : IGetReplacementSurfaces Method (IReplaceFaceFeatureData)

Gets the replacement surfaces for this feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetReplacementSurfaces( _  
    ByVal Count As System.Integer _  
) As Feature
```

Visual Basic (Usage)

```
Dim instance As IReplaceFaceFeatureData  
Dim Count As System.Integer  
Dim value As Feature  
  
value = instance.IGetReplacementSurfaces(Count)
```

C#

```
Feature IGetReplacementSurfaces(  
    System.int Count  
)
```

C++/CLI

```
Feature^ IGetReplacementSurfaces(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of replacement surfaces

Return Value

- in-process, unmanaged C++: Pointer to an array of [replacement surfaces](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IReplaceFaceFeatureData::GetReplacementSurfaces](#) before calling this method to get the size of Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::ISetReplacementSurfaces Method](#)
[IReplaceFaceFeatureData::ReplacementSurfaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

ISetFacesForReplacement Method (IReplaceFaceFeatureData)

[See Also](#)



Sets the faces to replace for this feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetFacesForReplacement( _  
    ByVal Count As System.Integer, _  
    ByRef SurfDisp As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim Count As System.Integer  
Dim SurfDisp As Face2  
  
instance.ISetFacesForReplacement(Count, SurfDisp)
```

C#

```
void ISetFacesForReplacement(  
    System.int Count,  
    ref Face2 SurfDisp  
)
```

C++/CLI

```
void ISetFacesForReplacement(  
& System.int Count,  
& Face2^% SurfDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces to replace

SurfDisp

- in-process, unmanaged C++: Pointer to an array of [faces](#) to replace of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::GetReplacementSurfacesCount Method](#)
[IReplaceFaceFeatureData::IGetReplacementSurfaces Method](#)
[IReplaceFaceFeatureData::ReplacementSurfaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Sets the replacement surfaces for this feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetReplacementSurfaces( _  
    ByVal Count As System.Integer, _  
    ByRef SurfDisp As Feature _  
)
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim Count As System.Integer  
Dim SurfDisp As Feature  
  
instance.ISetReplacementSurfaces(Count, SurfDisp)
```

C#

```
void ISetReplacementSurfaces(  
    System.int Count,  
    ref Feature SurfDisp  
)
```

C++/CLI

```
void ISetReplacementSurfaces(  
& System.int Count,  
& Feature^% SurfDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of replacement surfaces

SurfDisp

- in-process, unmanaged C++: Pointer to an array of [replacement surfaces](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::GetReplacementSurfacesCount Method](#)
[IReplaceFaceFeatureData::IGetReplacementSurfaces Method](#)
[IReplaceFaceFeatureData::ReplacementSurfaces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : ReleaseSelectionAccess Method (IReplaceFaceFeatureData)

Releases access to the selections in this feature.

Visual Basic Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::ReleaseSelectionAccess](#).

Example

See the [IReplaceFaceFeatureData](#) examples.

Remarks

[IReplaceFaceFeatureData::AccessSelections](#) and [IReplaceFaceFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReplacementSurfaces Property (IReplaceFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IReplaceFaceFeatureData Interface](#) : ReplacementSurfaces Property (IReplaceFaceFeatureData)

Gets or sets the replacement surfaces for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReplacementSurfaces As System.Object
```

Visual Basic (Usage)



```
Dim instance As IReplaceFaceFeatureData  
Dim value As System.Object  
  
instance.ReplacementSurfaces = value  
value = instance.ReplacementSurfaces
```

C#

```
System.Object ReplacementSurfaces {get; set;}
```

C++/CLI

```
property System.Object^ ReplacementSurfaces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of replacement surfaces

Visual Basic for Applications (VBA) Syntax

See [ReplaceFaceFeatureData::ReplacementSurfaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IReplaceFaceFeatureData Interface](#)
[IReplaceFaceFeatureData Members](#)
[IReplaceFaceFeatureData::GetReplacementSurfacesCount Method](#)
[IReplaceFaceFeatureData::IGetReplacementSurfaces Method](#)
[IReplaceFaceFeatureData::ISetReplacementSurfaces Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IRevisionCloud (Type)

IRevisionCloud Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionCloud Interface

Allows access to a revision cloud annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IRevisionCloud

Visual Basic (Usage)



Dim instance As [IRevisionCloud](#)

C#

public interface IRevisionCloud

C++/CLI

public interface class IRevisionCloud

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud](#).

Example

[Insert Revision Cloud into a Drawing \(VBA\)](#)
[Insert Revision Cloud into a Drawing \(VB.NET\)](#)
[Insert Revision Cloud into a Drawing \(C#\)](#)

Remarks

To create a revision cloud in a drawing document, call:

- [IDrawingDoc::InsertRevisionCloud](#) or [IDrawingDoc::InsertRevisionCloud](#).
- [IRevisionCloud::GetAnnotation](#) or [IRevisionCloud::IGetAnnotation](#) to get the annotation object for the revision cloud.
- [IAnnotation::SetPosition](#) to set the revision cloud position point on the drawing. If you eliminate this step, the revision cloud is rendered starting at the drawing origin of x=0, y=0, z=0. Set the revision cloud position point as follows:

For revision cloud shape...	Set the revision cloud position point to...
Ellipse	The center of the revision cloud.
Rectangle	A corner of the revision cloud.
Polygon	One of the points on the revision cloud.
Freehand	One of the points on the revision cloud.

- [IRevisionCloud::ArcRadius](#) to set the arc radius of the revision cloud.
- [IRevisionCloud::SetPathPointAtIndex](#) one or more times with Index = -1 to create points on the revision cloud as follows:

For revision cloud shape...	Call IRevisionCloud::SetPathPointAtIndex...
Ellipse	Once, specifying the coordinates of a corner of the ellipse-inscribed rectangle.
Rectangle	Once, specifying the coordinates of a corner opposite the revision cloud position point.
Polygon	(Number of polygon sides + 1) times, such that the first and last points coincide with the revision cloud position point.
Freehand	Indefinite number of times, such that the first and last points coincide with the revision cloud position point.

- [IRevisionCloud::Finalize](#) to close the revision cloud path. Once the revision cloud path is closed, you can no longer add points to it.
- [IRevisionCloud::SetPathPointAtIndex](#) to modify the position of an existing point on the revision cloud.

Accessors

[IDrawingDoc::InsertRevisionCloud](#) and [IDrawingDoc::InsertRevisionCloud](#)
[IRevisionCloud::GetNext](#) and [IRevisionCloud::IGetNext](#)

[IView::GetFirstRevisionCloud](#) and [IView::!GetFirstRevisionCloud](#)
[IView::GetRevisionClouds](#) and [IView::!GetRevisionClouds](#)

 Access Diagram

[RevisionCloud](#)

 See Also

[IRevisionCloud Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRevisionCloud Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionCloud Interface

For a list of all members of this type, see [IRevisionCloud members](#).

 Public Methods

Name	Description
 Finalize	Finalizes the creation of this revision cloud annotation.
 GetAnnotation	Gets the annotation object for this revision cloud.
 GetNext	Gets the next revision cloud in a drawing view or sheet.
 GetPathPointAtIndex	Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.
 GetPathPointCount	Gets the number of points on the path of this revision cloud annotation.
 IGetAnnotation	Gets the annotation object for this revision cloud.
 IGetNext	Gets the next revision cloud in a drawing view or sheet.
 IGetPathPointAtIndex	Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.
 SetPathPointAtIndex	Sets the specified coordinates of a point at the specified index on the path of this revision cloud annotation.

[Top](#)

 See Also

[IRevisionCloud Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRevisionCloud Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionCloud Interface

The following tables list the members exposed by [IRevisionCloud](#).

 Public Properties

Name	Description
 Angle	Gets or sets the rotation angle of this revision cloud annotation.
 ArcRadius	Gets or sets the maximum arc radius of this revision cloud annotation.
 Shape	Gets the shape of this revision cloud annotation.

[Top](#)

 Public Methods

Name	Description
 Finalize	Finalizes the creation of this revision cloud annotation.
 GetAnnotation	Gets the annotation object for this revision cloud.

		
	GetNext	Gets the next revision cloud in a drawing view or sheet.
	GetPathPointAtIndex	Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.
	GetPathPointCount	Gets the number of points on the path of this revision cloud annotation.
	IGetAnnotation	Gets the annotation object for this revision cloud.
	IGetNext	Gets the next revision cloud in a drawing view or sheet.
	IGetPathPointAtIndex	Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.
	SetPathPointAtIndex	Sets the specified coordinates of a point at the specified index on the path of this revision cloud annotation.

[Top](#)

See Also

[IRevisionCloud Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRevisionCloud Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionCloud Interface

For a list of all members of this type, see [IRevisionCloud members](#).

Public Properties

Name	Description
 Angle	Gets or sets the rotation angle of this revision cloud annotation.
 ArcRadius	Gets or sets the maximum arc radius of this revision cloud annotation.
 Shape	Gets the shape of this revision cloud annotation.

[Top](#)

See Also

[IRevisionCloud Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : Angle Property (IRevisionCloud)

Gets or sets the rotation angle of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IRevisionCloud
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rotation angle in radians of this revision cloud annotation

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::Angle](#).

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ArcRadius Property (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : ArcRadius Property (IRevisionCloud)

Gets or sets the maximum arc radius of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

Property ArcRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As System.Double
```

```
instance.ArcRadius = value
```

```
value = instance.ArcRadius
```

C#

```
System.double ArcRadius {get; set;}
```

C++/CLI

```
property System.double ArcRadius {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum arc radius

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::ArcRadius](#).

Example

See [IRevisionCloud](#) examples.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Finalize Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : Finalize Method (IRevisionCloud)

Finalizes the creation of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function Finalize() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As System.Boolean
```

```
value = instance.Finalize()
```

C#

```
System.bool Finalize()
```

C++/CLI

```
System.bool Finalize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this revision cloud was successfully finalized, false if not

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud.Finalize](#).

Example

See [IRevisionCloud](#) examples.

Remarks

You must call this method after all revision cloud path points have been added to the annotation. After finalizing the revision cloud annotation, no new points can be added to the cloud path. The positions of existing cloud path points can be modified at any time.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : GetAnnotation Method (IRevisionCloud)

Gets the annotation object for this revision cloud.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud
Dim value As System.Object

value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::GetAnnotation](#).

Example

See [IRevisionCloud](#) examples.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)
[IRevisionCloud::IGetAnnotation Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : GetNext Method (IRevisionCloud)

Gets the next revision cloud in a drawing view or sheet.

.NET Syntax

Visual Basic (Declaration)

Function GetNext() As System.Object

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IRevisionCloud](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::GetNext](#).

Remarks

You can traverse the revision cloud annotations in a drawing view as follows:

1. Call [IView::GetFirstRevisionCloud](#) to get the first revision cloud.
2. Call this method [IView::GetRevisionCloudCount](#) times to access the other revision clouds.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)
[IView::GetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPathPointAtIndex Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : GetPathPointAtIndex Method (IRevisionCloud)

Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathPointAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim Index As System.Integer  
Dim value As System.Object
```

```
value = instance.GetPathPointAtIndex(Index)
```

C#

```
System.Object GetPathPointAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetPathPointAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of a point on the path of this revision cloud annotation (see **Remarks**)

Return Value

Array of doubles of the x, y, and z coordinates of a point on the path of this revision cloud annotation

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::GetPathPointAtIndex](#).

Remarks

To get the range of values for Index, call [IRevisionCloud::GetPathPointCount](#) to get the total number of points on the path of this revision cloud annotation.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)
[IRevisionCloud::IGetPathPointAtIndex Method \(\)](#)
[IRevisionCloud::SetPathPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPathPointCount Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : GetPathPointCount Method (IRevisionCloud)

Gets the number of points on the path of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathPointCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As System.Integer  
  
value = instance.GetPathPointCount()
```

C#

```
System.int GetPathPointCount()
```

C++/CLI

```
System.int GetPathPointCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of points on the path of this revision cloud annotation

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::GetPathPointCount](#).

See Also

[IRRevisionCloud Interface](#)
[IRRevisionCloud Members](#)
[IRRevisionCloud::GetPathPointAtIndex Method \(\)](#)
[IRRevisionCloud::IGetPathPointAtIndex Method \(\)](#)
[IRRevisionCloud::SetPathPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotation Method (IRRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRRevisionCloud Interface](#) : IGetAnnotation Method (IRRevisionCloud)

Gets the annotation object for this revision cloud.

.NET Syntax

Visual Basic (Declaration)

Function IGetAnnotation() As Annotation

Visual Basic (Usage)



```
Dim instance As IRRevisionCloud  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

Annotation IGetAnnotation()

C++/CLI

Annotation^ IGetAnnotation();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an [Annotation](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IRRevisionCloud Interface](#)
[IRRevisionCloud Members](#)
[IRRevisionCloud::GetAnnotation Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (IRRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : IGetNext Method (IRevisionCloud)

Gets the next revision cloud in a drawing view or sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As RevisionCloud
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As RevisionCloud
```

```
value = instance.IGetNext()
```

C#

```
RevisionCloud IGetNext()
```

C++/CLI

```
RevisionCloud^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an [IRevisionCloud](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

You can traverse the revision cloud annotations in a drawing view as follows:

1. Call [IView::IGetFirstRevisionCloud](#) to get the first revision cloud.
2. Call this method [IView::GetRevisionCloudCount](#) times to access the other revision clouds.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)
[IView::IGetRevisionClouds Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPathPointAtIndex Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : IGetPathPointAtIndex Method (IRevisionCloud)

Gets the coordinates of a point with the specified index on the path of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPathPointAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim Index As System.Integer
```



```
Dim value As System.Double

value = instance.IGetPathPointAtIndex(Index)
```

C#

```
System.double IGetPathPointAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double IGetPathPointAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of a point on the path of this revision cloud annotation (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles of x, y, and z coordinates of a point on the path of this revision cloud annotation
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

To get the range of values for Index, call [IRevisionCloud::GetPathPointCount](#) to get the total number of points on the path of this revision cloud annotation.

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)
[IRevisionCloud::GetPathPointAtIndex Method \(\)](#)
[IRevisionCloud::SetPathPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPathPointAtIndex Method (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : SetPathPointAtIndex Method (IRevisionCloud)

Sets the specified coordinates of a point at the specified index on the path of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPathPointAtIndex( _
    ByVal Index As System.Integer, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRevisionCloud
Dim Index As System.Integer
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean
```



```
value = instance.SetPathPointAtIndex(Index, X, Y, Z)
```

C#

```
System.bool SetPathPointAtIndex(  
    System.int Index,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool SetPathPointAtIndex(  
    & System.int Index,  
    & System.double X,  
    & System.double Y,  
    & System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of an existing point on the path of this revision cloud annotation; -1 if creating a new point (see **Remarks**)

X

x coordinate of the point

Y

y coordinate of the point

Z

z coordinate of the point

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::SetPathPointAtIndex](#).

Example

See [IRevisionCloud](#) examples.

Remarks

To get the range of values for Index, call [IRevisionCloud::GetPathPointCount](#) to get the total number of points on the path of this revision cloud annotation.

You can create a new path point by calling this method, setting Index to -1. You can create new path points any time after [IDrawingDoc::InsertRevisionCloud](#) or [IDrawingDoc::IInsertRevisionCloud](#) is called. You cannot create new path points after [IRevisionCloud::Finalize](#) is called.

You can call this method at any time to change the position of existing path points.

See Also

[IRevisionCloud Interface](#)

[IRevisionCloud Members](#)

[IRevisionCloud::GetPathPointAtIndex Method \(\)](#)

[IRevisionCloud::IGetPathPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Shape Property (IRevisionCloud)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionCloud Interface](#) : Shape Property (IRevisionCloud)

Gets the shape of this revision cloud annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Shape As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionCloud  
Dim value As System.Integer
```

```
value = instance.Shape
```

C#

```
System.int Shape {get;}
```

C++/CLI

```
property System.int Shape {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Revision cloud annotation shape as defined in [swRevisionCloudShape_e](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionCloud::Shape](#).

See Also

[IRevisionCloud Interface](#)
[IRevisionCloud Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

IRevisionTableAnnotation (Type)

IRevisionTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableAnnotation Interface

Accesses the revision table annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRevisionTableAnnotation
```

Visual Basic (Usage)

```
Dim instance As IRevisionTableAnnotation
```

C#

```
public interface IRevisionTableAnnotation
```

C++/CLI

```
public interface class IRevisionTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation](#).

Example

[Create Drawing Sheet Zones \(VBA\)](#),
[Create Drawing Sheet Zones \(VB.NET\)](#),
[Create Drawing Sheet Zones \(C#\)](#).

Remarks

An IRevisionTableAnnotation object is derived from an [ITableAnnotation](#) object.

Accessors

[IRevisionTableFeature::GetTableAnnotations](#) and [IRevisionTableFeature::!GetTableAnnotations](#)
[ISheet::InsertRevisionTable](#)
[ISheet::RevisionTable](#)

Access Diagram

[RevisionTableAnnotation](#)

See Also

[IRevisionTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRevisionTableFeature Interface](#)

IRevisionTableAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableAnnotation Interface

The following tables list the members exposed by [IRevisionTableAnnotation](#).

Public Properties

Name	Description
 CurrentRevision	Gets the latest revision of this revision table annotation.
 RevisionTableFeature	Gets the revision table for this revision table annotation.

[Top](#)

Public Methods

Name	Description
 AddRevision	Adds a revision to this revision table.
 DeleteRevision	Deletes a revision from this revision table.
 GetAllCustomProperties	Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.
 GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that can be used for a custom properties column in this revision table annotation.
 GetColumnCustomProperty	Gets the custom property used for the values in a specified user-defined column.
 GetIdForRowNumber	Gets the revision ID for the specified row number.
 GetRevisionForId	Gets the revision text for the specified revision ID.
 GetRevisionSymbolCount	Gets the number of revision symbols associated with the specified revision ID.
 GetRevisionSymbols	Gets the revision symbols associated with the specified revision ID.
 GetRowNumberForId	Gets the row number in the table for the specified revision ID.
 GetSheet	Gets the drawing sheet on which this revision ID exists.
 IGetAllCustomProperties	Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.
 IGetRevisionSymbols	Gets the revision symbols associated with the specified revision ID.
 SetColumnCustomProperty	Sets the custom property used for the values in a specified user-defined column.

[Top](#)

See Also

[IRevisionTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRevisionTableFeature Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRevisionTableAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableAnnotation Interface

For a list of all members of this type, see [IRevisionTableAnnotation members](#).

Public Methods

Name	Description
 AddRevision	Adds a revision to this revision table.
 DeleteRevision	Deletes a revision from this revision table.
 GetAllCustomProperties	Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.
 GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that can be used for a custom properties column in this revision table annotation.
 GetColumnCustomProperty	Gets the custom property used for the values in a specified user-defined column.
 GetIdForRowNumber	Gets the revision ID for the specified row number.
 GetRevisionForId	Gets the revision text for the specified revision ID.
 GetRevisionSymbolCount	Gets the number of revision symbols associated with the specified revision ID.
 GetRevisionSymbols	Gets the revision symbols associated with the specified revision ID.

 GetRowNumberForId	Gets the row number in the table for the specified revision ID.
 GetSheet	Gets the drawing sheet on which this revision ID exists.
 IGetAllCustomProperties	Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.
 IGetRevisionSymbols	Gets the revision symbols associated with the specified revision ID.
 SetColumnCustomProperty	Sets the custom property used for the values in a specified user-defined column.

[Top](#)

 See Also

[IRevisionTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRevisionTableFeature Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRevisionTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableAnnotation Interface

For a list of all members of this type, see [IRevisionTableAnnotation members](#).

 Public Properties

Name	Description
 CurrentRevision	Gets the latest revision of this revision table annotation.
 RevisionTableFeature	Gets the revision table for this revision table annotation.

[Top](#)

 See Also

[IRevisionTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRevisionTableFeature Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

AddRevision Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : AddRevision Method (IRevisionTableAnnotation)

Adds a revision to this revision table.

 .NET Syntax

Visual Basic (Declaration)

```
Function AddRevision( _  
    ByVal Revision As System.String _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IRevisionTableAnnotation  
Dim Revision As System.String  
Dim value As System.Integer  
  
value = instance.AddRevision(Revision)
```

C#

```
System.int AddRevision(  
    System.string Revision  
)
```

C++/CLI



```
System.int AddRevision(  
& System.String^ Revision  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Revision
Revision

Return Value

Revision ID

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::AddRevision](#).

Example

See the [IRevisionTableAnnotation](#) examples.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetRevisionForId Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)
[IRevisionTableAnnotation::GetIdForRowIndex Method](#)
[IRevisionTableAnnotation::GetRowIndexForId Method](#)
[IRevisionTableAnnotation::DeleteRevision Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurrentRevision Property (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : CurrentRevision Property (IRevisionTableAnnotation)

Gets the latest revision of this revision table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CurrentRevision As System.String
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim value As System.String
```

```
value = instance.CurrentRevision
```

C#

```
System.string CurrentRevision {get;}
```

C++/CLI

```
property System.String^ CurrentRevision {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::CurrentRevision](#).

Example

See the [IRevisionTableAnnotation](#) examples.

Remarks

Use [IRevisionTableAnnotation::AddRevision](#) to add a revision and get its revision ID.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::DeleteRevision Method](#)
[IRevisionTableAnnotation::GetIdForRowIndex Method](#)
[IRevisionTableAnnotation::GetRevisionForId Method](#)
[IRevisionTableAnnotation::GetRowIndexForId Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteRevision Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : DeleteRevision Method (IRevisionTableAnnotation)

Deletes a revision from this revision table.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteRevision( _  
    ByVal RevisionId As System.Integer, _  
    ByVal DeleteSymbols As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RevisionId As System.Integer  
Dim DeleteSymbols As System.Boolean  
Dim value As System.Boolean  
  
value = instance.DeleteRevision(RevisionId, DeleteSymbols)
```

C#

```
System.bool DeleteRevision(  
    System.int RevisionId,  
    System.bool DeleteSymbols  
)
```

C++/CLI

```
System.bool DeleteRevision(  
&    System.int RevisionId,  
&    System.bool DeleteSymbols  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID
DeleteSymbols
True to delete all associated symbols, false to not

Return Value

True if revision ID is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::DeleteRevision](#).

Remarks

This method deletes the row in which the revision ID exists.

See Also

[IRRevisionTableAnnotation Interface](#)
[IRRevisionTableAnnotation Members](#)
[IRRevisionTableAnnotation::AddRevision Method](#)
[IRRevisionTableAnnotation::GetIdForRowIndex Method](#)
[IRRevisionTableAnnotation::GetRevisionForId Method](#)
[IRRevisionTableAnnotation::GetRowIndexForId Method](#)
[IRRevisionTableAnnotation::CurrentRevision Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomProperties Method (IRRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRRevisionTableAnnotation Interface](#) : GetAllCustomProperties Method (IRRevisionTableAnnotation)

Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomProperties() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRRevisionTableAnnotation  
Dim value As System.Object  
  
value = instance.GetAllCustomProperties()
```

C#

```
System.object GetAllCustomProperties()
```

C++/CLI

```
System.Object^ GetAllCustomProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings of available custom properties

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetAllCustomProperties](#).

Remarks

This method only works for SOLIDWORKS documents created or saved in SOLIDWORKS 2005 or later.

The list of available custom properties includes all of the items in the revision table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetColumnCustomProperty Method](#)
[IRevisionTableAnnotation::GetAllCustomProperties Method](#)
[IRevisionTableAnnotation::SetColumnCustomProperty Method](#)
[IRevisionTableAnnotation::GetAllCustomPropertiesCount Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomPropertiesCount Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetAllCustomPropertiesCount Method (IRevisionTableAnnotation)

Gets the number of items in the list of available custom properties that can be used for a custom properties column in this revision table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomPropertiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim value As System.Integer  
  
value = instance.GetAllCustomPropertiesCount()
```

C#

```
System.int GetAllCustomPropertiesCount()
```

C++/CLI

```
System.int GetAllCustomPropertiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of available custom properties

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetAllCustomPropertiesCount](#).

Remarks

Call this method before calling [IRevisionTableAnnotation::IRevisionTableAnnotation::GetAllCustomProperties](#) to get the value of Count.

The list of available custom properties includes all of the items in the revision table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetAllCustomProperties Method](#)
[IRevisionTableAnnotation::GetColumnCustomProperty Method](#)
[IRevisionTableAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColumnCustomProperty Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetColumnCustomProperty Method (IRevisionTableAnnotation)

Gets the custom property used for the values in a specified user-defined column.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnCustomProperty( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetColumnCustomProperty(Index)
```

C#

```
System.string GetColumnCustomProperty(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetColumnCustomProperty(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Column from which to get the custom property

Return Value

Custom property used for the values in this user-defined column

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetColumnCustomProperty](#).

Remarks

This method returns an empty string if the column is not a user-defined column.

To get the list of custom properties, use [IRevisionTableAnnotation::GetAllCustomProperties](#) or [IRevisionTableAnnotation::IGetAllCustomProperties](#). The list of available custom properties includes all of the items in the revision table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetAllCustomPropertiesCount Method](#)
[IRevisionTableAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetIdForRowIndex Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetIdForRowIndex Method (IRevisionTableAnnotation)

Gets the revision ID for the specified row number.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetIdForRowIndex( _  
    ByVal RowIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.GetIdForRowIndex(RowIndex)
```

C#

```
System.int GetIdForRowIndex(  
    System.int RowIndex  
)
```

C++/CLI

```
System.int GetIdForRowIndex(  
& System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
0-based index for this row number

Return Value

Revision ID

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetIdForRowIndex](#).

Remarks

This method is useful when working with a row via the [ITableAnnotation](#) object.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::AddRevision Method](#)
[IRevisionTableAnnotation::DeleteRevision Method](#)
[IRevisionTableAnnotation::GetRevisionForId Method](#)
[IRevisionTableAnnotation::GetRowIndexForId Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

Availability

GetRevisionForId Method (IRevisionTableAnnotation)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetRevisionForId Method (IRevisionTableAnnotation)

Gets the revision text for the specified revision ID.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetRevisionForId( _
    ByVal RevisionId As System.Integer _
) As System.String
```

Visual Basic (Usage)

```
Dim instance As IRevisionTableAnnotation
Dim RevisionId As System.Integer
Dim value As System.String

value = instance.GetRevisionForId(RevisionId)
```

C#

```
System.string GetRevisionForId(
    System.int RevisionId
)
```

C++/CLI

```
System.String^ GetRevisionForId(
    & System.int RevisionId
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID

Return Value

Revision text

 Visual Basic for Applications (VBA) SyntaxSee [RevisionTableAnnotation::GetRevisionForId](#). RemarksCall [IRevisionTableAnnotation::GetIdForRowNumber](#) to get the revision ID for the row in which the revision text exists. See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::AddRevision Method](#)
[IRevisionTableAnnotation::DeleteRevision Method](#)
[IRevisionTableAnnotation::GetRowNumberForId Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

 Availability

GetRevisionSymbolCount Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetRevisionSymbolCount Method (IRevisionTableAnnotation)

Gets the number of revision symbols associated with the specified revision ID.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevisionSymbolCount( _  
    ByVal RevisionId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RevisionId As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetRevisionSymbolCount(RevisionId)
```

C#

```
System.int GetRevisionSymbolCount(  
    System.int RevisionId  
)
```

C++/CLI

```
System.int GetRevisionSymbolCount(  
& System.int RevisionId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID

Return Value

Number of revision symbols for this revision ID

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetRevisionSymbolCount](#).

Remarks

Call this method before calling [IRevisionTableAnnotation::IGetRevisionSymbols](#) to get the size of the array for that method.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetRevisionSymbols Method](#)
[IRevisionTableAnnotation::IGetRevisionSymbols Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRevisionSymbols Method (IRevisionTableAnnotation)

[See Also](#)



Gets the revision symbols associated with the specified revision ID.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetRevisionSymbols( _  
    ByVal RevisionId As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RevisionId As System.Integer  
Dim value As System.Object  
  
value = instance.GetRevisionSymbols(RevisionId)
```

C#

```
System.object GetRevisionSymbols(  
    System.int RevisionId  
)
```

C++/CLI

```
System.Object^ GetRevisionSymbols(  
& System.int RevisionId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID

Return Value

Array of revision symbols

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetRevisionSymbols](#).

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetRevisionSymbolCount Method](#)
[IRevisionTableAnnotation::IGetRevisionSymbols Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRowNumberForId Method (IRevisionTableAnnotation)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IRevisionTableAnnotation Interface : GetRowNumberForId Method (IRevisionTableAnnotation)

Gets the row number in the table for the specified revision ID.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetRowNumberForId( _  
    ByVal RevisionId As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RevisionId As System.Integer  
Dim value As System.Integer  
  
value = instance.GetRowNumberForId(RevisionId)
```

C#

```
System.int GetRowNumberForId(  
    System.int RevisionId  
)
```

C++/CLI

```
System.int GetRowNumberForId(  
& System.int RevisionId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID

Return Value

Row number in the table for this revision ID

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetRowNumberForId](#).

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::AddRevision Method](#)
[IRevisionTableAnnotation::DeleteRevision Method](#)
[IRevisionTableAnnotation::GetIdForRowNumber Method](#)
[IRevisionTableAnnotation::GetRevisionForId Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheet Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : GetSheet Method (IRevisionTableAnnotation)

Gets the drawing sheet on which this revision ID exists.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheet() As Sheet
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim value As Sheet
```



```
value = instance.GetSheet()
```

C#

```
Sheet GetSheet()
```

C++/CLI

```
Sheet^ GetSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sheet](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::GetSheet](#).

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAllCustomProperties Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : IGetAllCustomProperties Method (IRevisionTableAnnotation)

Gets a list of available custom properties that can be used for a custom properties column in this revision table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAllCustomProperties( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim Count As System.Integer  
Dim value As System.String
```

```
value = instance.IGetAllCustomProperties(Count)
```

C#

```
System.string IGetAllCustomProperties(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetAllCustomProperties(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of available custom properties

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of available custom properties
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

This method only works for SOLIDWORKS documents created or saved in SOLIDWORKS 2005 or later.

Before calling this method, call [IRevisionTableAnnotation::GetAllCustomPropertiesCount](#) to get the number of available custom properties.

The list of available custom properties includes all of the items in the revision table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetAllCustomProperties Method](#)
[IRevisionTableAnnotation::GetColumnCustomProperty Method](#)
[IRevisionTableAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRevisionSymbols Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : IGetRevisionSymbols Method (IRevisionTableAnnotation)

Gets the revision symbols associated with the specified revision ID.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRevisionSymbols( _  
    ByVal RevisionId As System.Integer, _  
    ByVal Count As System.Integer _  
    ) As Note
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim RevisionId As System.Integer  
Dim Count As System.Integer  
Dim value As Note
```

```
value = instance.IGetRevisionSymbols(RevisionId, Count)
```

C#

```
Note IGetRevisionSymbols(  
    System.int RevisionId,  
    System.int Count  
)
```

C++/CLI

```
Note^ IGetRevisionSymbols(  
& System.int RevisionId,  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RevisionId
Revision ID
Count
Number of revision symbols

Return Value

- in-process, unmanaged C++: Pointer to an array of revision symbols
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRevisionTableAnnotation::GetRevisionSymbolCount](#) before calling this method to get the value of Count.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetRevisionSymbols Method](#)
[IRevisionTableAnnotation::CurrentRevision Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevisionTableFeature Property (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : RevisionTableFeature Property (IRevisionTableAnnotation)

Gets the revision table for this revision table annotation.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property RevisionTableFeature As RevisionTableFeature

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim value As RevisionTableFeature  
  
value = instance.RevisionTableFeature
```

C#

```
RevisionTableFeature RevisionTableFeature {get;}
```

C++/CLI

```
property RevisionTableFeature^ RevisionTableFeature {  
    RevisionTableFeature^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Revision table](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::RevisionTableFeature](#).

Example

See the [IRevisionTableAnnotation](#) examples.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetColumnCustomProperty Method (IRevisionTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableAnnotation Interface](#) : SetColumnCustomProperty Method (IRevisionTableAnnotation)

Sets the custom property used for the values in a specified user-defined column.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetColumnCustomProperty( _  
    ByVal Index As System.Integer, _  
    ByVal CustomProp As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableAnnotation  
Dim Index As System.Integer  
Dim CustomProp As System.String  
Dim value As System.Boolean
```

```
value = instance.SetColumnCustomProperty(Index, CustomProp)
```

C#

```
System.bool SetColumnCustomProperty(  
    System.int Index,  
    System.string CustomProp  
)
```

C++/CLI

```
System.bool SetColumnCustomProperty(  
& System.int Index,  
& System.String^ CustomProp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Column for which to get the custom property

CustomProp

Custom property used for the values in this user-defined column

Return Value

True if custom property is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [RevisionTableAnnotation::SetColumnCustomProperty](#).

Remarks

Use this method to create a user-defined column where each row in the column is automatically filled in with the custom property value. The default title for the column is the name of the custom property. If the specified custom property is not a valid custom property, then each row in the column remains empty.

To create a user-defined column that is not attached to a custom property; for example, you want to fill in each row of the column yourself, use this method with the CustomProp value specified as the title of the column.

To get the list of available custom properties, use [IRevisionTableAnnotation::GetAllCustomProperties](#) or [IRevisionTableAnnotation::IGetAllCustomProperties](#). The list of possible custom properties includes all of the items in the revision table, which includes items from the file summary items and file custom properties that have been set.

This method returns false if the column is not a user-defined column, and no action is taken.

See Also

[IRevisionTableAnnotation Interface](#)
[IRevisionTableAnnotation Members](#)
[IRevisionTableAnnotation::GetAllCustomPropertiesCount Method](#)
[IRevisionTableAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0