

SOLIDWORKS API (.NET VBA C#) — Reference

(242/337): IRevisionTableFeature- IRevolveFeatureData2

SOLIDWORKS API Documentation (converted from CHM)

IRevisionTableFeature (Type)

IRevisionTableFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableFeature Interface

Allows access to the revision table feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRevisionTableFeature
```

Visual Basic (Usage)

```
Dim instance As IRevisionTableFeature
```

C#

```
public interface IRevisionTableFeature
```

C++/CLI

```
public interface class IRevisionTableFeature
```

Visual Basic for Applications (VBA) Syntax

See [RevisionTableFeature](#).

Example

[Create Drawing Sheet Zones \(VBA\)](#),
[Create Drawing Sheet Zones \(VB.NET\)](#),
[Create Drawing Sheet Zones \(C#\)](#).

Accessors

[IRevisionTableAnnotation::RevisionTableFeature](#)

Access Diagram

[RevisionTableFeature](#)

See Also

[IRevisionTableFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRevisionTableAnnotation Interface](#)

IRevisionTableFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevisionTableFeature Interface

The following tables list the members exposed by [IRevisionTableFeature](#).

Public Methods

Name	Description
 GetFeature	Gets the revision table feature.
 GetTableAnnotationCount	Gets the number of revision table annotations for this revision table.

 GetTableAnnotations	Gets the revision table annotations for this revision table.
 IGetTableAnnotations	Gets the revision table annotations for this revision table.

[Top](#)

 See Also

[IRRevisionTableFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRRevisionTableAnnotation Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRRevisionTableFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRRevisionTableFeature Interface

For a list of all members of this type, see [IRRevisionTableFeature members](#).

 Public Methods

Name	Description
 GetFeature	Gets the revision table feature.
 GetTableAnnotationCount	Gets the number of revision table annotations for this revision table.
 GetTableAnnotations	Gets the revision table annotations for this revision table.
 IGetTableAnnotations	Gets the revision table annotations for this revision table.

[Top](#)

 See Also

[IRRevisionTableFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IRRevisionTableAnnotation Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

GetFeature Method (IRRevisionTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRRevisionTableFeature Interface](#) : GetFeature Method (IRRevisionTableFeature)

Gets the revision table feature.

 .NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As IRRevisionTableFeature  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

Feature GetFeature()

C++/CLI

Feature^ GetFeature();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionTableFeature::GetFeature](#).

Example

See the [IRevisionTableFeature](#) examples.

See Also

[IRevisionTableFeature Interface](#)
[IRevisionTableFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotationCount Method (IRevisionTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableFeature Interface](#) : GetTableAnnotationCount Method (IRevisionTableFeature)

Gets the number of revision table annotations for this revision table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableFeature  
Dim value As System.Integer  
  
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of revision table annotations

Visual Basic for Applications (VBA) Syntax

See [RevisionTableFeature::GetTableAnnotationCount](#).

Example

See the [IRevisionTableFeature](#) examples.

Remarks

Call this method before calling [IRevisionTableFeature::IGetTableAnnotations](#) to get the size of the array for that method.

See Also

[IRevisionTableFeature Interface](#)
[IRevisionTableFeature Members](#)
[IRevisionTableFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IRevisionTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableFeature Interface](#) : GetTableAnnotations Method (IRevisionTableFeature)

Gets the revision table annotations for this revision table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableFeature  
Dim value As System.Object  
  
value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the [revision table annotations](#)

Visual Basic for Applications (VBA) Syntax

See [RevisionTableFeature::GetTableAnnotations](#).

See Also

[IRevisionTableFeature Interface](#)
[IRevisionTableFeature Members](#)
[IRevisionTableFeature::GetTableAnnotationCount Method](#)
[IRevisionTableFeature::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTableAnnotations Method (IRevisionTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevisionTableFeature Interface](#) : IGetTableAnnotations Method (IRevisionTableFeature)

Gets the revision table annotations for this revision table.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal Count As System.Integer _  
    ) As RevisionTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IRevisionTableFeature  
Dim Count As System.Integer  
Dim value As RevisionTableAnnotation  
  
value = instance.IGetTableAnnotations(Count)
```

C#

```
RevisionTableAnnotation IGetTableAnnotations(  
    System.int Count  
)
```

C++/CLI

```
RevisionTableAnnotation^ IGetTableAnnotations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of revision table annotations

Return Value

- in-process, unmanaged C++: Pointer to an array of the [revision table annotations](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRevisionTableFeature::GetTableAnnotationCount](#) before calling this method to get the value of Count.

See Also

[IRevisionTableFeature Interface](#)
[IRevisionTableFeature Members](#)
[IRevisionTableFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

IRevolveFeatureData (Type)

IRevolveFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData Interface

Obsolete. Superseded by [IRevolveFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRevolveFeatureData
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData
```

C#

```
public interface IRevolveFeatureData
```

C++/CLI

```
public interface class IRevolveFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData](#).

See Also

[IRevolveFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRevolveFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData Interface

For a list of all members of this type, see [IRevolveFeatureData members](#).

Public Methods

Name	Description
GetRevolutionAngle	Obsolete. Superseded by IRevolveFeatureData2::GetRevolutionAngle .
GetWallThickness	Obsolete. Superseded by IRevolveFeatureData2::GetWallThickness .
IsBossFeature	Obsolete. Superseded by IRevolveFeatureData2::IsBossFeature .
IsThinFeature	Obsolete. Superseded by IRevolveFeatureData2::IsThinFeature .
SetRevolutionAngle	Obsolete. Superseded by IRevolveFeatureData2::SetRevolutionAngle .
SetWallThickness	Obsolete. Superseded by IRevolveFeatureData2::SetWallThickness .

[Top](#)

See Also

[IRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRevolveFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData Interface

The following tables list the members exposed by [IRevolveFeatureData](#).

 Public Properties

Name	Description
 ReverseDirection	Obsolete. Superseded by IRevolveFeatureData2::ReverseDirection .
 Type	Obsolete. Superseded by IRevolveFeatureData2::Type .

[Top](#)

 Public Methods

Name	Description
 GetRevolutionAngle	Obsolete. Superseded by IRevolveFeatureData2::GetRevolutionAngle .
 GetWallThickness	Obsolete. Superseded by IRevolveFeatureData2::GetWallThickness .
 IsBossFeature	Obsolete. Superseded by IRevolveFeatureData2::IsBossFeature .
 IsThinFeature	Obsolete. Superseded by IRevolveFeatureData2::IsThinFeature .
 SetRevolutionAngle	Obsolete. Superseded by IRevolveFeatureData2::SetRevolutionAngle .
 SetWallThickness	Obsolete. Superseded by IRevolveFeatureData2::SetWallThickness .

[Top](#)

 See Also

[IRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRevolveFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData Interface

For a list of all members of this type, see [IRevolveFeatureData members](#).

 Public Properties

Name	Description
 ReverseDirection	Obsolete. Superseded by IRevolveFeatureData2::ReverseDirection .
 Type	Obsolete. Superseded by IRevolveFeatureData2::Type .

[Top](#)

 See Also

[IRevolveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRevolutionAngle Method (IRevolveFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : GetRevolutionAngle Method (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::GetRevolutionAngle](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function GetRevolutionAngle( _  
    ByVal Forward As System.Boolean _
```

```
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData
Dim Forward As System.Boolean
Dim value As System.Double

value = instance.GetRevolutionAngle(Forward)
```

C#

```
System.double GetRevolutionAngle(
    System.bool Forward
)
```

C++/CLI

```
System.double GetRevolutionAngle(
    & System.bool Forward
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::GetRevolutionAngle](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetWallThickness Method (IRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : GetWallThickness Method (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::GetWallThickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness( _
    ByVal Forward As System.Boolean _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData
Dim Forward As System.Boolean
Dim value As System.Double

value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(
    System.bool Forward
)
```

C++/CLI

```
System.double GetWallThickness(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::GetWallThickness](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBossFeature Method (IRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : IsBossFeature Method (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::IsBossFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim value As System.Boolean
```

```
value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::IsBossFeature](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsThinFeature Method (IRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : IsThinFeature Method (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::IsThinFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim value As System.Boolean  
  
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::IsThinFeature](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseDirection Property (IRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : ReverseDirection Property (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::ReverseDirection](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::ReverseDirection](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetRevolutionAngle Method (IRevolveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData Interface](#) : SetRevolutionAngle Method (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::SetRevolutionAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRevolutionAngle( _  
    ByVal Forward As System.Boolean, _  
    ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim Forward As System.Boolean  
Dim Angle As System.Double  
  
instance.SetRevolutionAngle(Forward, Angle)
```

C#

```
void SetRevolutionAngle(  
    System.bool Forward,  
    System.double Angle  
)
```

C++/CLI

```
void SetRevolutionAngle(  
& System.bool Forward,  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Angle

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::SetRevolutionAngle](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetWallThickness Method (IRevolveFeatureData)

[See Also](#)



Obsolete. Superseded by [IRevolveFeatureData2::SetWallThickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _  
    ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
&    System.bool Forward,  
&    System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

WallThickness

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::SetWallThickness](#).

See Also

[IRevolveFeatureData Interface](#)
[IRevolveFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IRevolveFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IRevolveFeatureData Interface : Type Property (IRevolveFeatureData)

Obsolete. Superseded by [IRevolveFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData::Type](#).

See Also

[IRvolveFeatureData Interface](#)
[IRvolveFeatureData Members](#)

IRevolveFeatureData2 (Type)

IRevolveFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData2 Interface

Allows access to a revolve feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRevolveFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2
```

C#

```
public interface IRevolveFeatureData2
```

C++/CLI

```
public interface class IRevolveFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2](#).

Example

[Create 360-degree Revolve Feature \(VBA\)](#)
[Create 360-degree Revolve Feature \(VB.NET\)](#)
[Create 360-degree Revolve Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[RevolveFeatureData2](#)

See Also

[IRevolveFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureRevolve Method](#)
[IFeatureManager::FeatureRevolveCut2 Method](#)
[IFeatureManager::FeatureRevolveThin Method](#)
[IFeatureManager::FeatureRevolveThinCut Method](#)

IRevolveFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData2 Interface

The following tables list the members exposed by [IRevolveFeatureData2](#).

Public Properties

Name	Description
 AssemblyFeatureScope	Gets or sets whether to use scope for this assembly revolve feature.

 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the revolve feature to affect in a multibody body.
 AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly revolve feature affects in model.
 Axis	Gets or sets the axis of revolution for this revolve feature.
 Contours	Gets and sets the selected contours on this revolve feature.
 FeatureScope	Gets or sets whether to use scope for the revolve feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the revolve feature affects in a multibody part.
 Merge	Gets or sets whether to merge the results of this revolve feature in a multibody part.
 PropagateFeatureToParts	Gets whether to propagate this assembly revolve feature to the parts that it affects in this model.
 ReverseDirection	Gets or sets whether the direction of the revolution feature should be reversed.
 ThinWallType	Gets and sets the thin wall type for a thin revolve feature.
 Type	Gets or sets the revolution feature type.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this revolve feature.
 GetAxisType	Gets the type of axis of revolution for this revolve feature.
 GetContoursCount	Gets the number of selected contours for this revolve feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the revolve feature in a multibody part.
 GetRevolutionAngle	Gets the angle of the revolve feature in Direction 1 or Direction 2.
 GetWallThickness	Gets the wall thickness of the thin revolution feature in forward or reverse direction.
 IAccessSelections	Gains access to the selections that define this revolve feature.
 IGetContours	Gets the selected contours for this revolve feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the revolve feature affects in a multibody part.
 IsBossFeature	Gets whether the revolution is a boss feature.
 ISetContours	Sets the selected contours for this revolve feature.
 ISetFeatureScopeBodies	Sets the solid bodies that the revolve feature affects in a multibody part.
 IsThinFeature	Gets whether the revolution is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections that define this revolve feature.
 SetRevolutionAngle	Sets the angle of the revolve feature in Direction 1 or Direction 2.
 SetWallThickness	Sets the wall thickness of the thin revolution feature in forward/reverse direction.

[Top](#)

See Also

[IRevolveFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureRevolve Method](#)
[IFeatureManager::FeatureRevolveCut2 Method](#)
[IFeatureManager::FeatureRevolveThin Method](#)
[IFeatureManager::FeatureRevolveThinCut Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRevolveFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRevolveFeatureData2 Interface

For a list of all members of this type, see [IRevolveFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this revolve feature.
 GetAxisType	Gets the type of axis of revolution for this revolve feature.
 GetContoursCount	Gets the number of selected contours for this revolve feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the revolve feature in a multibody part.
 GetRevolutionAngle	Gets the angle of the revolve feature in Direction 1 or Direction 2.
 GetWallThickness	Gets the wall thickness of the thin revolution feature in forward or reverse direction.
 IAccessSelections	Gains access to the selections that define this revolve feature.
 IGetContours	Gets the selected contours for this revolve feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the revolve feature affects in a multibody part.
 IsBossFeature	Gets whether the revolution is a boss feature.
 ISetContours	Sets the selected contours for this revolve feature.
 ISetFeatureScopeBodies	Sets the solid bodies that the revolve feature affects in a multibody part.
 IsThinFeature	Gets whether the revolution is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections that define this revolve feature.
 SetRevolutionAngle	Sets the angle of the revolve feature in Direction 1 or Direction 2.
 SetWallThickness	Sets the wall thickness of the thin revolution feature in forward/reverse direction.

[Top](#)

See Also

[IRvolveFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureRevolve Method](#)
[IFeatureManager::FeatureRevolveCut2 Method](#)
[IFeatureManager::FeatureRevolveThin Method](#)
[IFeatureManager::FeatureRevolveThinCut Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRvolveFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRvolveFeatureData2 Interface

For a list of all members of this type, see [IRvolveFeatureData2 members](#).

Public Properties

Name	Description
 AssemblyFeatureScope	Gets or sets whether to use scope for this assembly revolve feature.
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the revolve feature to affect in a multibody body.
 AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly revolve feature affects in model.
 Axis	Gets or sets the axis of revolution for this revolve feature.
 Contours	Gets and sets the selected contours on this revolve feature.
 FeatureScope	Gets or sets whether to use scope for the revolve feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the revolve feature affects in a multibody part.
 Merge	Gets or sets whether to merge the results of this revolve feature in a multibody part.
 PropagateFeatureToParts	Gets whether to propagate this assembly revolve feature to the parts that it affects in this model.
 ReverseDirection	Gets or sets whether the direction of the revolution feature should be reversed.
 ThinWallType	Gets and sets the thin wall type for a thin revolve feature.
 Type	Gets or sets the revolution feature type.

[Top](#)

See Also

[IRevolveFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureRevolve Method](#)
[IFeatureManager::FeatureRevolveCut2 Method](#)
[IFeatureManager::FeatureRevolveThin Method](#)
[IFeatureManager::FeatureRevolveThinCut Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : AccessSelections Method (IRevolveFeatureData2)

Gains access to the selections that define this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRevolveFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AssemblyFeatureScope Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : AssemblyFeatureScope Property (IRevolveFeatureData2)

Gets or sets whether to use scope for this assembly revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Property AssemblyFeatureScope As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Boolean
```

```
instance.AssemblyFeatureScope = value
```

```
value = instance.AssemblyFeatureScope
```

C#

```
System.bool AssemblyFeatureScope {get; set;}
```

C++/CLI

```
property System.bool AssemblyFeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use feature scope, false to not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::AssemblyFeatureScope](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::AutoSelect Property](#)
[IRevolveFeatureData2::AutoSelectComponents Property](#)
[IRevolveFeatureData2::PropagateFeatureToParts Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

AutoSelect Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : AutoSelect Property (IRevolveFeatureData2)

Gets or sets whether to automatically select all or only specific bodies for the revolve feature to affect in a multibody body.

.NET Syntax

Visual Basic (Declaration)

Property AutoSelect As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2
Dim value As System.Boolean

instance.AutoSelect = value

value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies for [IRevolveFeatureData2::FeatureScopeBodies](#) or [IRevolveFeatureData2::!SetFeatureScopeBodies](#)

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::AutoSelect](#).

Remarks

This property is only available when the [IRevolveFeatureData2::FeatureScope](#) property is true. The revolve feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IRevolveFeatureData2::!GetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

AutoSelectComponents Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : AutoSelectComponents Property (IRevolveFeatureData2)

Gets or sets whether to auto-select all components that this assembly revolve feature affects in model.

.NET Syntax

```
Property AutoSelectComponents As System.Boolean
```

```
Dim instance As IRevolveFeatureData2
Dim value As System.Boolean

instance.AutoSelectComponents = value
value = instance.AutoSelectComponents
```

```
System.bool AutoSelectComponents {get; set;}
```

```
property System.bool AutoSelectComponents {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to auto-select all affected components, false to not (use the selected components only or set [IRevolveFeatureData2::AutoSelect](#) to true)

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::AutoSelectComponents](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::AssemblyFeatureScope Property](#)
[IRevolveFeatureData2::PropagateFeatureToParts Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Axis Property (IRevolveFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : Axis Property (IRevolveFeatureData2)

Gets or sets the axis of revolution for this revolve feature.

.NET Syntax

```
Property Axis As System.Object
```

```
Dim instance As IRevolveFeatureData2
Dim value As System.Object

instance.Axis = value
value = instance.Axis
```

```
System.Object Axis {get; set;}
```

C++/CLI

```
property System.Object^ Axis {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Axis](#), [edge](#), or [sketch segment](#)

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::Axis](#).

Example

[Get Axis of Revolve Feature \(VBA\)](#)

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::GetAxisType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Contours Property (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : Contours Property (IRvolveFeatureData2)

Gets and sets the selected contours on this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Contours As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim value As System.Object
```

```
instance.Contours = value
```

```
value = instance.Contours
```

C#

```
System.Object Contours {get; set;}
```

C++/CLI

```
property System.Object^ Contours {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of selected contours ([sketch contours](#) and [sketch regions](#))

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::Contours](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::GetContoursCount Method](#)
[IRvolveFeatureData2::IGetContours Method](#)
[IRvolveFeatureData2::ISetContours Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : FeatureScope Property (IRvolveFeatureData2)

Gets or sets whether to use scope for the revolve feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if only the specified bodies in the multibody part are affected by the feature, false if all of the bodies in the multibody part are affected by the revolve feature

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::FeatureScope](#).

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::AutoSelect Property](#)
[IRvolveFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IRvolveFeatureData2::IGetFeatureScopeBodies Method](#)
[IRvolveFeatureData2::ISetFeatureScopeBodies Method](#)
[IRvolveFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : FeatureScopeBodies Property (IRvolveFeatureData2)

Gets or sets the solid bodies that the revolve feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim value As System.Object
```

```
instance.FeatureScopeBodies = value
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::FeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::AutoSelect Property](#)
[IRvolveFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IRvolveFeatureData2::IGetFeatureScopeBodies Method](#)
[IRvolveFeatureData2::ISetFeatureScopeBodies Method](#)
[IRvolveFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

GetAxisType Method (IRevolveFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : GetAxisType Method (IRevolveFeatureData2)

Gets the type of axis of revolution for this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAxisType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Integer  
  
value = instance.GetAxisType()
```

C#

```
System.int GetAxisType()
```

C++/CLI

```
System.int GetAxisType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of axis as defined in [swSelectType_e](#):

- swSelDATUMAXES
- swSelEDGES
- swSelSKETCHSEGS

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::GetAxisType](#).

Example

[Get Axis of Revolve Feature \(VBA\)](#)

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::Axis Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GetContoursCount Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : GetContoursCount Method (IRevolveFeatureData2)

Gets the number of selected contours for this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetContoursCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetContoursCount()
```

C#

```
System.int GetContoursCount()
```

C++/CLI

```
System.int GetContoursCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of selected contours

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::GetContoursCount](#).

Remarks

This method returns the total number of sketch contours and sketch regions used in the base sketch for this feature.
Call this method before calling [IRevolveFeatureData2::IGetContours](#) to get the size of the array for that method.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::ISetContours Method](#)
[IRevolveFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : GetFeatureScopeBodiesCount Method (IRevolveFeatureData2)

Gets the number of solid bodies affected by the revolve feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::GetFeatureScopeBodiesCount](#).

Remarks

Call this method before calling [IRvolveFeatureData2::IGetFeatureScopeBodies](#) to get the size of the array for that method.

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::IGetFeatureScopeBodies Method](#)
[IRvolveFeatureData2::FeatureScope Property](#)
[IRvolveFeatureData2::FeatureScopeBodies Property](#)
[IRvolveFeatureData2::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRevolutionAngle Method (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : GetRevolutionAngle Method (IRvolveFeatureData2)

Gets the angle of the revolve feature in Direction 1 or Direction 2.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevolutionAngle( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetRevolutionAngle(Forward)
```

C#

```
System.double GetRevolutionAngle(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetRevolutionAngle(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True gets the angle in Direction 1, false gets the angle in Direction 2

Return Value

Angle of revolution

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::GetRevolutionAngle](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::SetRevolutionAngle Method](#)
[IRevolveFeatureData2::ReverseDirection Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWallThickness Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : GetWallThickness Method (IRevolveFeatureData2)

Gets the wall thickness of the thin revolution feature in forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness(  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetWallThickness(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward feature direction, false for reverse

Return Value

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::GetWallThickness](#).

Remarks

This method only affects thin features.

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::IsThinFeature Method](#)
[IRvolveFeatureData2::SetWallThickness Method](#)
[IRvolveFeatureData2::ThinWallType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : IAccessSelections Method (IRvolveFeatureData2)

Gains access to the selections that define this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRvolveFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetContours Method (IRvolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : IGetContours Method (IRvolveFeatureData2)

Gets the selected contours for this revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetContours( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2  
Dim Count As System.Integer  
Dim value As System.Object
```

```
value = instance.IGetContours(Count)
```

C#

```
System.object IGetContours(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetContours(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected contours

Return Value

- in-process, unmanaged C++: Pointer to an array of selected contours ([sketch contours](#) and [sketch regions](#)) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRevolveFeatureData2::GetContoursCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::ISetContours Method](#)
[IRevolveFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFeatureScopeBodies Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : IGetFeatureScopeBodies Method (IRevolveFeatureData2)

Gets the solid bodies that the revolve feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRevolveFeatureData2::GetFeatureScopeBodiesCount](#) before calling this method to get the value of Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::IsFeatureScopeBodies Method](#)
[IRevolveFeatureData2::FeatureScope Property](#)
[IRevolveFeatureData2::FeatureScopeBodies Property](#)
[IRevolveFeatureData2::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBossFeature Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : IsBossFeature Method (IRevolveFeatureData2)

Gets whether the revolution is a boss feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Boolean  
  
value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if revolution is a boss feature, false if not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::IsBossFeature](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::IsThinFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetContours Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : ISetContours Method (IRevolveFeatureData2)

Sets the selected contours for this revolve feature.

VB.NET Syntax

Visual Basic (Declaration)

```
Sub ISetContours(  
    ByVal Count As System.Integer, _  
    ByRef Contours As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Count As System.Integer  
Dim Contours As System.Object  
  
instance.ISetContours(Count, Contours)
```

C#

```
void ISetContours(  
    System.int Count,  
    ref System.object Contours  
)
```

C++/CLI

```
void ISetContours(  
& System.int Count,  
& System.Object^% Contours  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected contours

Contours

- in-process, unmanaged C++: Pointer to an array of selected contours ([sketch contours](#) and [sketch regions](#)) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::GetContoursCount Method](#)
[IRevolveFeatureData2::IGetContours Method](#)
[IRevolveFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatureScopeBodies Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : ISetFeatureScopeBodies Method (IRevolveFeatureData2)

Sets the solid bodies that the revolve feature affects in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Count As System.Integer  
Dim BodyArr As Body2  
  
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetFeatureScopeBodies(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size count

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IRevolveFeatureData2::IGetFeatureScopeBodies Method](#)
[IRevolveFeatureData2::FeatureScope Property](#)
[IRevolveFeatureData2::FeatureScopeBodies Property](#)
[IRevolveFeatureData2::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsThinFeature Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : IsThinFeature Method (IRevolveFeatureData2)

Gets whether the revolution is a thin feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Boolean
```

```
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if revolution is a thin feature, false if not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::IsThinFeature](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::GetWallThickness Method](#)
[IRevolveFeatureData2::IsBossFeature Method](#)
[IRevolveFeatureData2::SetWallThickness Method](#)
[IRevolveFeatureData2::ThinWallType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : Merge Property (IRevolveFeatureData2)

Gets or sets whether to merge the results of this revolve feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property Merge As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the merge results option, false disables it

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::Merge](#).

Remarks

SOLIDWORKS 2003 FCS, Revision Number 11.0

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateFeatureToParts Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : PropagateFeatureToParts Property (IRevolveFeatureData2)

Gets whether to propagate this assembly revolve feature to the parts that it affects in this model.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFeatureToParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2
Dim value As System.Boolean

instance.PropagateFeatureToParts = value
value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate this assembly revolve feature to the parts that it affects in the model, false to not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::PropagateFeatureToParts](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::AssemblyFeatureScope Property](#)
[IRevolveFeatureData2::AutoSelect Property](#)
[IRevolveFeatureData2::AutoSelectComponents Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IRevolveFeatureData2)

Releases access to the selections that define this revolve feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::ReleaseSelectionAccess](#).

Remarks

[IRevolveFeatureData2::AccessSelections](#) and [IRevolveFeatureData2::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : ReverseDirection Property (IRevolveFeatureData2)

Gets or sets whether the direction of the revolution feature should be reversed.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the direction of the revolution feature is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::ReverseDirection](#).

See Also

[IRevolveFeatureData2 Interface](#)
[IRevolveFeatureData2 Members](#)
[IRevolveFeatureData2::GetRevolutionAngle Method](#)
[IRevolveFeatureData2::SetRevolutionAngle Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetRevolutionAngle Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : SetRevolutionAngle Method (IRevolveFeatureData2)

Sets the angle of the revolve feature in Direction 1 or Direction 2.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRevolutionAngle( _  
    ByVal Forward As System.Boolean, _  
    ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Forward As System.Boolean  
Dim Angle As System.Double  
  
instance.SetRevolutionAngle(Forward, Angle)
```

C#

```
void SetRevolutionAngle(  
    System.bool Forward,  
    System.double Angle  
)
```

C++/CLI

```
void SetRevolutionAngle(  
& System.bool Forward,  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True sets the angle in Direction 1, false sets the angle in Direction 2

Angle

Angle of revolution

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::SetRevolutionAngle](#).

See Also

[IRevolveFeatureData2 Interface](#)

[IRevolveFeatureData2 Members](#)

[IRevolveFeatureData2::GetRevolutionAngle Method](#)

[IRevolveFeatureData2::ReverseDirection Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWallThickness Method (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : SetWallThickness Method (IRevolveFeatureData2)

Sets the wall thickness of the thin revolution feature in forward/reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _  
    ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
& System.bool Forward,  
& System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward feature direction, false for reverse

WallThickness

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::SetWallThickness](#).

Remarks

This method only affects thin features.

See Also

[IRevolveFeatureData2 Interface](#)

[IRevolveFeatureData2 Members](#)

[IRevolveFeatureData2::GetWallThickness Method](#)

[IRevolveFeatureData2::IsThinFeature Method](#)

[IRevolveFeatureData2::ThinWallType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWallType Property (IRevolveFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRevolveFeatureData2 Interface](#) : ThinWallType Property (IRevolveFeatureData2)

Gets and sets the thin wall type for a thin revolve feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinWallType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRevolveFeatureData2
```

```
Dim value As System.Integer
```

```
instance.ThinWallType = value
```

```
value = instance.ThinWallType
```

C#

```
System.int ThinWallType {get; set;}
```

C++/CLI

```
property System.int ThinWallType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type and direction as defined in [swThinWallType_e](#)

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::ThinWallType](#).

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)
[IRvolveFeatureData2::IsThinFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IRvolveFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRvolveFeatureData2 Interface](#) : Type Property (IRvolveFeatureData2)

Gets or sets the revolution feature type.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IRvolveFeatureData2
Dim value As System.Integer

instance.Type = value
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of revolution as defined in [swRevolveType_e](#)

Visual Basic for Applications (VBA) Syntax

See [RevolveFeatureData2::Type](#).

Example

[Create 360-degree Revolve Feature \(VBA\)](#)
[Create 360-degree Revolve Feature \(VB.NET\)](#)
[Create 360-degree Revolve Feature \(C#\)](#)

See Also

[IRvolveFeatureData2 Interface](#)
[IRvolveFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0