

SOLIDWORKS API (.NET VBA C#) — Reference (243/337): IRibFeatureData-IRipFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IRibFeatureData (Type)

IRibFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData Interface

Obsolete. Superseded by [IRibFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRibFeatureData
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData
```

C#

```
public interface IRibFeatureData
```

C++/CLI

```
public interface class IRibFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData](#).

See Also

[IRibFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRibFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData Interface

For a list of all members of this type, see [IRibFeatureData members](#).

Public Methods

Name	Description
NextReference	Obsolete. Superseded by IRibFeatureData2::NextReference .

[Top](#)

See Also

[IRibFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRibFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData Interface

The following tables list the members exposed by [IRibFeatureData](#).

Public Properties

Name	Description
 DraftAngle	Obsolete. Superseded by IRibFeatureData2::DraftAngle .
 DraftOutward	Obsolete. Superseded by IRibFeatureData2::DraftOutward .
 EnableDraft	Obsolete. Superseded by IRibFeatureData2::EnableDraft .
 FlipSide	Obsolete. Superseded by IRibFeatureData2::FlipSide .
 IsTwoSided	Obsolete. Superseded by IRibFeatureData2::IsTwoSided .
 RefSketchIndex	Obsolete. Superseded by IRibFeatureData2::RefSketchIndex .
 ReverseThicknessDir	Obsolete. Superseded by IRibFeatureData2::ReverseThicknessDir .
 Thickness	Obsolete. Superseded by IRibFeatureData2::Thickness .

[Top](#)

 Public Methods

Name	Description
 NextReference	Obsolete. Superseded by IRibFeatureData2::NextReference .

[Top](#)

 See Also

[IRibFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRibFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData Interface

For a list of all members of this type, see [IRibFeatureData members](#).

 Public Properties

Name	Description
 DraftAngle	Obsolete. Superseded by IRibFeatureData2::DraftAngle .
 DraftOutward	Obsolete. Superseded by IRibFeatureData2::DraftOutward .
 EnableDraft	Obsolete. Superseded by IRibFeatureData2::EnableDraft .
 FlipSide	Obsolete. Superseded by IRibFeatureData2::FlipSide .
 IsTwoSided	Obsolete. Superseded by IRibFeatureData2::IsTwoSided .
 RefSketchIndex	Obsolete. Superseded by IRibFeatureData2::RefSketchIndex .
 ReverseThicknessDir	Obsolete. Superseded by IRibFeatureData2::ReverseThicknessDir .
 Thickness	Obsolete. Superseded by IRibFeatureData2::Thickness .

[Top](#)

 See Also

[IRibFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftAngle Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : DraftAngle Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::DraftAngle](#).

 .NET Syntax

Visual Basic (Declaration)

Property DraftAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Double
```

```
instance.DraftAngle = value
```

```
value = instance.DraftAngle
```

C#

```
System.double DraftAngle {get; set;}
```

C++/CLI

```
property System.double DraftAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::DraftAngle](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftOutward Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : DraftOutward Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::DraftOutward](#).

.NET Syntax

Visual Basic (Declaration)

Property DraftOutward As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Boolean
```

```
instance.DraftOutward = value
```

```
value = instance.DraftOutward
```

C#

```
System.bool DraftOutward {get; set;}
```

C++/CLI

```
property System.bool DraftOutward {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::DraftOutward](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnableDraft Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : EnableDraft Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::EnableDraft](#).

.NET Syntax

Visual Basic (Declaration)

Property EnableDraft As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Boolean
```

```
instance.EnableDraft = value
```

```
value = instance.EnableDraft
```

C#

```
System.bool EnableDraft {get; set;}
```

C++/CLI

```
property System.bool EnableDraft {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::EnableDraft](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlipSide Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : FlipSide Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::FlipSide](#).

.NET Syntax

Visual Basic (Declaration)

Property FlipSide As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Boolean
```

```
instance.FlipSide = value
```

```
value = instance.FlipSide
```

C#

```
System.bool FlipSide {get; set;}
```

C++/CLI

```
property System.bool FlipSide {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::FlipSide](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsTwoSided Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : IsTwoSided Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::IsTwoSided](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IsTwoSided As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Boolean
```

```
instance.IsTwoSided = value
```

```
value = instance.IsTwoSided
```

C#

```
System.bool IsTwoSided {get; set;}
```

C++/CLI

```
property System.bool IsTwoSided {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::IsTwoSided](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

NextReference Method (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : NextReference Method (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::NextReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function NextReference() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Integer  
  
value = instance.NextReference()
```

C#

```
System.int NextReference()
```

C++/CLI

```
System.int NextReference();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::NextReference](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RefSketchIndex Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : RefSketchIndex Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::RefSketchIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Property RefSketchIndex As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Integer  
  
instance.RefSketchIndex = value  
  
value = instance.RefSketchIndex
```

C#

```
System.int RefSketchIndex {get; set;}
```

C++/CLI

```
property System.int RefSketchIndex {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::RefSketchIndex](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseThicknessDir Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : ReverseThicknessDir Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::ReverseThicknessDir](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseThicknessDir As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseThicknessDir = value
```

```
value = instance.ReverseThicknessDir
```

C#

```
System.bool ReverseThicknessDir {get; set;}
```

C++/CLI

```
property System.bool ReverseThicknessDir {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::ReverseThicknessDir](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Thickness Property (IRibFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData Interface](#) : Thickness Property (IRibFeatureData)

Obsolete. Superseded by [IRibFeatureData2::Thickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Thickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData  
Dim value As System.Double
```

```
instance.Thickness = value
```

```
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData::Thickness](#).

See Also

[IRibFeatureData Interface](#)
[IRibFeatureData Members](#)

IRibFeatureData2 (Type)

IRibFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData2 Interface

Allows access to a rib feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRibFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2
```

C#

```
public interface IRibFeatureData2
```

C++/CLI

```
public interface class IRibFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2](#).

Example

[Get Rib Feature Data \(VBA\)](#)
[Get Rib Feature Data \(VB.NET\)](#)
[Get Rib Feature Data \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[RibFeatureData2](#)

See Also

[IRibFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRib Method](#)

IRibFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData2 Interface

For a list of all members of this type, see [IRibFeatureData2 members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the the selections for this rib feature.
IAccessSelections	Gains access to the the selections for this rib feature.

	NextReference	Cycles through the possible sketch entities that can be used to define the draft, if it is used, for ribs with multiple contours.
	ReleaseSelectionAccess	Releases access to the selections that define this rib feature.

[Top](#)

See Also

[IRibFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRib Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRibFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData2 Interface

The following tables list the members exposed by [IRibFeatureData2](#).

Public Properties

Name	Description
 Body	Gets or sets the body where the rib is created.
 DraftAngle	Gets or sets the draft angle for the rib.
 DraftFromWall	Gets or sets whether to draft the rib from the wall interface or the sketch plane.
 DraftOutward	Gets or sets whether the rib has an outward draft.
 EnableDraft	Gets or sets whether the rib has an associated draft.
 ExtrusionDirection	Gets or sets the direction in which to extrude the rib.
 FlipSide	Gets or sets whether material is added to the reverse side of the rib.
 IsTwoSided	Gets or sets whether the rib is created on two sides of the midplane or in a single direction (see IRibFeatureData2::ReverseThicknessDir).
 RefSketchIndex	Gets or sets which sketch segment defines the draft direction of the rib feature.
 ReverseThicknessDir	Gets or sets whether the extrusion is on the reverse side of this single-sided rib.
 Thickness	Gets or set the overall thickness of the rib.
 Type	Gets or sets the type of rib.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the the selections for this rib feature.
 IAccessSelections	Gains access to the the selections for this rib feature.
 NextReference	Cycles through the possible sketch entities that can be used to define the draft, if it is used, for ribs with multiple contours.
 ReleaseSelectionAccess	Releases access to the selections that define this rib feature.

[Top](#)

See Also

[IRibFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRib Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRibFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRibFeatureData2 Interface

For a list of all members of this type, see [IRibFeatureData2 members](#).

Public Properties

Name	Description
 Body	Gets or sets the body where the rib is created.
 DraftAngle	Gets or sets the draft angle for the rib.
 DraftFromWall	Gets or sets whether to draft the rib from the wall interface or the sketch plane.
 DraftOutward	Gets or sets whether the rib has an outward draft.
 EnableDraft	Gets or sets whether the rib has an associated draft.
 ExtrusionDirection	Gets or sets the direction in which to extrude the rib.
 FlipSide	Gets or sets whether material is added to the reverse side of the rib.
 IsTwoSided	Gets or sets whether the rib is created on two sides of the midplane or in a single direction (see IRibFeatureData2.ReverseThicknessDir).
 RefSketchIndex	Gets or sets which sketch segment defines the draft direction of the rib feature.
 ReverseThicknessDir	Gets or sets whether the extrusion is on the reverse side of this single-sided rib.
 Thickness	Gets or set the overall thickness of the rib.
 Type	Gets or sets the type of rib.

[Top](#)

See Also

[IRibFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRib Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : AccessSelections Method (IRibFeatureData2)

Gains access to the the selections for this rib feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,
```

```
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [IRibFeatureData2::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the <code>IModelDoc2</code> object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRibFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IRibFeatureData2 Interface](#)

[IRibFeatureData2 Members](#)

[IRibFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Body Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : Body Property (IRibFeatureData2)

Gets or sets the body where the rib is created.

.NET Syntax

Visual Basic (Declaration)

```
Property Body As Body2
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2
Dim value As Body2
```

```
instance.Body = value
```

```
value = instance.Body
```

C#

```
Body2 Body {get; set;}
```

C++/CLI

```
property Body2^ Body {
    Body2^ get();
    void set ( & Body2^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Body](#) where rib is created

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::Body](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftAngle Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : DraftAngle Property (IRibFeatureData2)

Gets or sets the draft angle for the rib.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2
Dim value As System.Double
```

```
instance.DraftAngle = value
```

```
value = instance.DraftAngle
```

C#

```
System.double DraftAngle {get; set;}
```

C++/CLI

```
property System.double DraftAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle for the draft

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::DraftAngle](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) is called.

This property is valid only when [IRibFeatureData2::EnableDraft](#) is set to true.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)
[IRibFeatureData2::RefSketchIndex Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DraftFromWall Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : DraftFromWall Property (IRibFeatureData2)

Gets or sets whether to draft the rib from the wall interface or the sketch plane.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftFromWall As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Boolean
```

```
instance.DraftFromWall = value
```

```
value = instance.DraftFromWall
```

C#

```
System.bool DraftFromWall {get; set;}
```

C++/CLI

```
property System.bool DraftFromWall {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft from the sketch plane, false to draft from the wall interface

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::DraftFromWall](#).

Remarks

This property is valid only when [IRibFeatureData2::EnableDraft](#) is set to true.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DraftOutward Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : DraftOutward Property (IRibFeatureData2)

Gets or sets whether the rib has an outward draft.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftOutward As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Boolean
```

```
instance.DraftOutward = value
```

```
value = instance.DraftOutward
```

C#

```
System.bool DraftOutward {get; set;}
```

C++/CLI

```
property System.bool DraftOutward {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the draft is outward, false if inward

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::DraftOutward](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) is called.

This property is valid only when [IRibFeatureData2::EnableDraft](#) is set to true.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)
[IRibFeatureData2::RefSketchIndex Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnableDraft Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : EnableDraft Property (IRibFeatureData2)

Gets or sets whether the rib has an associated draft.

.NET Syntax

Visual Basic (Declaration)

Property EnableDraft As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Boolean
```

```
instance.EnableDraft = value
```

```
value = instance.EnableDraft
```

C#

```
System.bool EnableDraft {get; set;}
```

C++/CLI

```
property System.bool EnableDraft {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the rib has a draft, false if not

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::EnableDraft](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) is called.

Use [IRibFeatureData2::DraftOutward](#) and [IRibFeatureData2::DraftAngle](#) for additional draft control.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)
[IRibFeatureData2::RefSketchIndex Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExtrusionDirection Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : ExtrusionDirection Property (IRibFeatureData2)

Gets or sets the direction in which to extrude the rib.

.NET Syntax

Visual Basic (Declaration)

Property ExtrusionDirection As System.Integer

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2
Dim value As System.Integer

instance.ExtrusionDirection = value

value = instance.ExtrusionDirection
```

C#

```
System.int ExtrusionDirection {get; set;}
```

C++/CLI

```
property System.int ExtrusionDirection {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Direction as defined in [swRibExtrusionDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::ExtrusionDirection](#).

Example

See the [IRibFeatureData2](#) examples.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlipSide Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : FlipSide Property (IRibFeatureData2)

Gets or sets whether material is added to the reverse side of the rib.

.NET Syntax

Visual Basic (Declaration)

Property FlipSide As System.Boolean

```
Dim instance As IRibFeatureData2
Dim value As System.Boolean

instance.FlipSide = value

value = instance.FlipSide
```

C#

```
System.bool FlipSide {get; set;}
```

C++/CLI

```
property System.bool FlipSide {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the material is added to the reverse side of the rib, false if not

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::FlipSide](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) is called.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : IAccessSelections Method (IRibFeatureData2)

Gains access to the the selections for this rib feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRibFeatureData2
Dim TopDoc As ModelDoc2
```

```
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRibFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)
[IRibFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsTwoSided Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : IsTwoSided Property (IRibFeatureData2)

Gets or sets whether the rib is created on two sides of the midplane or in a single direction (see [IRibFeatureData2::ReverseThicknessDir](#)).

.NET Syntax

Visual Basic (Declaration)

```
Property IsTwoSided As System.Boolean
```

```
Dim instance As IRibFeatureData2
Dim value As System.Boolean

instance.IsTwoSided = value

value = instance.IsTwoSided
```

C#

```
System.bool IsTwoSided {get; set;}
```

C++/CLI

```
property System.bool IsTwoSided {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the rib is extruded either side of the midplane, false if it is single-sided

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::IsTwoSided](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) is called.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NextReference Method (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : NextReference Method (IRibFeatureData2)

Cycles through the possible sketch entities that can be used to define the draft, if it is used, for ribs with multiple contours.

.NET Syntax

Visual Basic (Declaration)

```
Function NextReference() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IRibFeatureData2
Dim value As System.Integer

value = instance.NextReference()
```

C#

```
System.int NextReference()
```

C++/CLI

```
System.int NextReference();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Index of the entity that is used

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::NextReference](#).

Remarks

This method cycles through the entities. It starts at the beginning again once the last entity is reached.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RefSketchIndex Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : RefSketchIndex Property (IRibFeatureData2)

Gets or sets which sketch segment defines the draft direction of the rib feature.

.NET Syntax

Visual Basic (Declaration)

```
Property RefSketchIndex As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Integer
```

```
instance.RefSketchIndex = value
```

```
value = instance.RefSketchIndex
```

C#

```
System.int RefSketchIndex {get; set;}
```

C++/CLI

```
property System.int RefSketchIndex {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index of the sketch segment that defines the draft direction

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::RefSketchIndex](#).

Remarks

This property is valid only when [IRibFeatureData2::EnableDraft](#) is set to true.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)
[IRibFeatureData2::DraftAngle Property](#)
[IRibFeatureData2::DraftOutward Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IRibFeatureData2)

Releases access to the selections that define this rib feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::ReleaseSelectionAccess](#).

Remarks

[IRibFeatureData2::AccessSelections](#) and [IRibFeatureData2::IAccessSelections](#) put the model in a rollback state to allow access to the selection that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseThicknessDir Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : ReverseThicknessDir Property (IRibFeatureData2)

Gets or sets whether the extrusion is on the reverse side of this single-sided rib.

.NET Syntax

Visual Basic (Declaration)

Property ReverseThicknessDir As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2
Dim value As System.Boolean

instance.ReverseThicknessDir = value
value = instance.ReverseThicknessDir
```

C#

```
System.bool ReverseThicknessDir {get; set;}
```

C++/CLI

```
property System.bool ReverseThicknessDir {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this single-sided rib is extruded on the reverse side, false if not

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::ReverseThicknessDir](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

This property is valid only when [IRibFeatureData2::IsTwoSided](#) is set to false.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Thickness Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : Thickness Property (IRibFeatureData2)

Gets or set the overall thickness of the rib.

.NET Syntax

Visual Basic (Declaration)

```
Property Thickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Double
```

```
instance.Thickness = value
```

```
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness of the rib

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::Thickness](#).

Example

See the [IRibFeatureData2](#) examples.

Remarks

Changing the value of this property does not affect geometry until [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) is called.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IRibFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRibFeatureData2 Interface](#) : Type Property (IRibFeatureData2)

Gets or sets the type of rib.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IRibFeatureData2  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type as defined by [swRibType_e](#)

Visual Basic for Applications (VBA) Syntax

See [RibFeatureData2::Type](#).

Example

See the [IRibFeatureData2](#) examples.

See Also

[IRibFeatureData2 Interface](#)
[IRibFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IRipFeatureData (Type)

IRipFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRipFeatureData Interface

Allows access to a rip feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRipFeatureData
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData
```

C#

```
public interface IRipFeatureData
```

C++/CLI

```
public interface class IRipFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData](#).

Example

[Access Edges on Rip Feature \(VBA\)](#)
[Access Edges on Rip Feature \(VB.NET\)](#)
[Access Edges on Rip Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[RipFeatureData](#)

See Also

[IRipFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRip Method](#)

IRipFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRipFeatureData Interface

The following tables list the members exposed by [IRipFeatureData](#).

Public Properties

Name	Description
 Edges	Gets or sets the edges for this rip feature.
 Gap	Gets or sets the gap for this rip feature.

Public Methods

Name	Description
 AccessSelections	Gains access to the selections for this rip feature.
 GetDirection	Gets the rip direction for the specified edge.
 GetEdgesCount	Gets the number of edges for this rip feature.
 IAccessSelections	Gains access to the selections for this rip feature.
 IGetEdges	Gets the edges for this rip feature.
 ISetEdges	Sets the edges for this rip feature.
 ReleaseSelectionAccess	Releases access to the selections for this rip feature.
 SetDirection	Sets the direction for this rip feature.

See Also

[IRipFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRip Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRipFeatureData Interface Methods

[See Also](#)


SolidWorks.Interop.sldworks Namespace : IRipFeatureData Interface

For a list of all members of this type, see [IRipFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections for this rip feature.
 GetDirection	Gets the rip direction for the specified edge.
 GetEdgesCount	Gets the number of edges for this rip feature.
 IAccessSelections	Gains access to the selections for this rip feature.
 IGetEdges	Gets the edges for this rip feature.
 ISetEdges	Sets the edges for this rip feature.
 ReleaseSelectionAccess	Releases access to the selections for this rip feature.
 SetDirection	Sets the direction for this rip feature.

See Also

[IRipFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRip Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IRipFeatureData Interface Properties

[See Also](#)


SolidWorks.Interop.sldworks Namespace : IRipFeatureData Interface

For a list of all members of this type, see [IRipFeatureData members](#).

Public Properties

Name	Description
------	-------------

[Edges](#)

Gets or sets the edges for this rip feature.

[Gap](#)

Gets or sets the gap for this rip feature.

[Top](#)

See Also

[IRipFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertRip Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IRipFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : AccessSelections Method (IRipFeatureData)

Gains access to the selections for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean
```

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*TopDoc*Top-level document (see **Remarks**)*Component*Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::AccessSelections](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRipFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edges Property (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : Edges Property (IRipFeatureData)

Gets or sets the edges for this rip feature.

.NET Syntax

Visual Basic (Declaration)

Property Edges As System.Object

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim value As System.Object
```

```
instance.Edges = value
```

```
value = instance.Edges
```

C#

```
System.object Edges {get; set;}
```

C++/CLI

```
property System.Object^ Edges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#)

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::Edges](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::GetEdgesCount Method](#)
[IRipFeatureData::IGetEdges Method](#)
[IRipFeatureData::ISetEdges Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Gap Property (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : Gap Property (IRipFeatureData)

Gets or sets the gap for this rip feature.

.NET Syntax

Visual Basic (Declaration)

Property Gap As System.Double

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim value As System.Double
```

```
instance.Gap = value
```

```
value = instance.Gap
```

C#

```
System.double Gap {get; set;}
```

C++/CLI

```
property System.double Gap {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::Gap](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

If...

Then SOLIDWORKS returns...

No value is set	1
Using the default gap	-1

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDirection Method (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : GetDirection Method (IRipFeatureData)

Gets the rip direction for the specified edge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirection( _
    ByVal Edge As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData
Dim Edge As System.Object
Dim value As System.Integer

value = instance.GetDirection(Edge)
```

C#

```
System.int GetDirection(
    System.object Edge
)
```

C++/CLI

```
System.int GetDirection(
    & System.Object^ Edge
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Edge
[Edge](#)

Return Value

Direction of the rip feature for the specified edge:

- 0 = this direction
- 1 = other direction
- 2 = both directions

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::GetDirection](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::SetDirection Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgesCount Method (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : GetEdgesCount Method (IRipFeatureData)

Gets the number of edges for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim value As System.Integer  
  
value = instance.GetEdgesCount()
```

C#

```
System.int GetEdgesCount()
```

C++/CLI

```
System.int GetEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::GetEdgesCount](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

Call this method before calling [IRipFeatureData::IGetEdges](#) to get the size of the array for that method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::ISetEdges Method](#)
[IRipFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : IAccessSelections Method (IRipFeatureData)

Gains access to the selections for this rip feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRipFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : IGetEdges Method (IRipFeatureData)

Gets the edges for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges( _  
    ByVal EdgeCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim EdgeCount As System.Integer  
Dim value As System.Object  
  
value = instance.IGetEdges(EdgeCount)
```

C#

```
System.object IGetEdges(  
    System.int EdgeCount  
)
```

C++/CLI

```
System.Object^ IGetEdges(  
& System.int EdgeCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount

Number of edges

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size EdgeCount
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRipFeatureData::GetEdgesCount](#) before calling this method to get the value for EdgeCount.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEdges Method (IRipFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : ISetEdges Method (IRipFeatureData)

Sets the edges for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal EdgeCount As System.Integer, _  
    ByRef EdgeArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
Dim EdgeCount As System.Integer  
Dim EdgeArr As System.Object  
  
instance.ISetEdges(EdgeCount, EdgeArr)
```

C#

```
void ISetEdges(  
    System.int EdgeCount,  
    ref System.object EdgeArr  
)
```

C++/CLI

```
void ISetEdges(  
& System.int EdgeCount,  
& System.Object^% EdgeArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount
Number of edges

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size EdgeCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::GetEdgesCount Method](#)
[IRipFeatureData::IGetEdges Method](#)
[IRipFeatureData::Edges Property](#)

Availability

ReleaseSelectionAccess Method (IRipFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : ReleaseSelectionAccess Method (IRipFeatureData)

Releases access to the selections for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::ReleaseSelectionAccess](#).

Example

See the [IRipFeatureData](#) examples.

Remarks

[IRipFeatureData::AccessSelections](#) and [IRipFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SetDirection Method (IRipFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRipFeatureData Interface](#) : SetDirection Method (IRipFeatureData)

Sets the direction for this rip feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDirection( _
    ByVal Edge As System.Object, _
    ByVal Dir As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IRipFeatureData
Dim Edge As System.Object
Dim Dir As System.Integer

instance.SetDirection(Edge, Dir)
```

C#

```
void SetDirection(
    System.object Edge,
    System.int Dir
)
```

C++/CLI

```
void SetDirection(
    & System.Object^ Edge,
    & System.int Dir
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Edge

Rip feature [edge](#)

Dir

Direction of rip feature:

- 0 = this direction
- 1 = other direction
- 2 = both directions

Visual Basic for Applications (VBA) Syntax

See [RipFeatureData::SetDirection](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRipFeatureData Interface](#)
[IRipFeatureData Members](#)
[IRipFeatureData::GetDirection Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1