

SOLIDWORKS API (NET VBA C#) — Reference

(244/337): IRoutingSettings- IRuledSurfaceFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IRoutingSettings (Type)

IRoutingSettings Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRoutingSettings Interface

Allows access to various routing settings including those specified in **Tools > Options > System Options > Routing**.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRoutingSettings
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings
```

C#

```
public interface IRoutingSettings
```

C++/CLI

```
public interface class IRoutingSettings
```

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings](#).

Example

[Get and Save Routing Settings \(VBA\)](#)
[Get and Save Routing Settings \(VB.NET\)](#)
[Get and Save Routing Settings \(C#\)](#)

Accessors

[ISldWorks::GetRoutingSettings](#)

Access Diagram

[RoutingSettings](#)

See Also

[IRoutingSettings Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IRoutingSettings Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRoutingSettings Interface

For a list of all members of this type, see [IRoutingSettings members](#).

Public Methods

Name	Description
 GetFromToListHeaderDefinitions	Gets the headers from a routing from-to list.
 GetRoutingUserPreferenceDoubleValue	Gets the double value of the specified routing user preference.
GetRoutingUserPreferenceIntegerValue	Gets the integer value of the specified routing user preference.

		
	GetRoutingUserPreferenceStringValue	Gets the string value of the specified routing user preference.
	GetRoutingUserPreferenceToggle	Gets whether the specified routing user preference is turned on.
	LoadDefaultRoutingSettings	Loads the default routing settings.
	LoadRoutingSettingsFromFile	Loads routing settings from the specified file.
	SaveRoutingSettingsToFile	Saves routing settings to the specified file.
	SetFromToListHeaderDefinitions	Sets the headers in a routing from-to list.
	SetRoutingUserPreferenceDoubleValue	Sets a double value for the specified routing user preference.
	SetRoutingUserPreferenceIntegerValue	Sets an integer value for the specified routing user preference.
	SetRoutingUserPreferenceStringValue	Sets a string value for the specified routing user preference.
	SetRoutingUserPreferenceToggle	Sets whether the specified routing user preference is turned on or off.

[Top](#)

See Also

[IRoutingSettings Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRoutingSettings Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRoutingSettings Interface

The following tables list the members exposed by [IRoutingSettings](#).

Public Methods

Name	Description
 GetFromToListHeaderDefinitions	Gets the headers from a routing from-to list.
 GetRoutingUserPreferenceDoubleValue	Gets the double value of the specified routing user preference.
 GetRoutingUserPreferenceIntegerValue	Gets the integer value of the specified routing user preference.
 GetRoutingUserPreferenceStringValue	Gets the string value of the specified routing user preference.
 GetRoutingUserPreferenceToggle	Gets whether the specified routing user preference is turned on.
 LoadDefaultRoutingSettings	Loads the default routing settings.
 LoadRoutingSettingsFromFile	Loads routing settings from the specified file.
 SaveRoutingSettingsToFile	Saves routing settings to the specified file.
 SetFromToListHeaderDefinitions	Sets the headers in a routing from-to list.
 SetRoutingUserPreferenceDoubleValue	Sets a double value for the specified routing user preference.
 SetRoutingUserPreferenceIntegerValue	Sets an integer value for the specified routing user preference.
 SetRoutingUserPreferenceStringValue	Sets a string value for the specified routing user preference.
 SetRoutingUserPreferenceToggle	Sets whether the specified routing user preference is turned on or off.

[Top](#)

See Also

[IRoutingSettings Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFromToListHeaderDefinitions Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : GetFromToListHeaderDefinitions Method (IRoutingSettings)

Gets the headers from a routing from-to list.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFromToListHeaderDefinitions( _  
    ByRef WireNameHdr As System.String, _  
    ByRef FromRefHdr As System.String, _  
    ByRef FromPinHdr As System.String, _  
    ByRef FromPartnoHdr As System.String, _  
    ByRef ToRefHdr As System.String, _  
    ByRef ToPinHdr As System.String, _  
    ByRef ToPartnoHdr As System.String, _  
    ByRef CableNameHdr As System.String, _  
    ByRef CoreNameHdr As System.String, _  
    ByRef ColourHdr As System.String, _  
    ByRef WireSpecHdr As System.String, _  
    ByRef OtherAttribHdr As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim WireNameHdr As System.String  
Dim FromRefHdr As System.String  
Dim FromPinHdr As System.String  
Dim FromPartnoHdr As System.String  
Dim ToRefHdr As System.String  
Dim ToPinHdr As System.String  
Dim ToPartnoHdr As System.String  
Dim CableNameHdr As System.String  
Dim CoreNameHdr As System.String  
Dim ColourHdr As System.String  
Dim WireSpecHdr As System.String  
Dim OtherAttribHdr As System.String  
Dim value As System.Boolean  
  
value = instance.GetFromToListHeaderDefinitions(WireNameHdr, FromRefHdr, FromPinHdr,  
FromPartnoHdr, ToRefHdr, ToPinHdr, ToPartnoHdr, CableNameHdr, CoreNameHdr, ColourHdr, WireSpecHdr,  
OtherAttribHdr)
```

C#

```
System.bool GetFromToListHeaderDefinitions(  
    out System.string WireNameHdr,  
    out System.string FromRefHdr,  
    out System.string FromPinHdr,  
    out System.string FromPartnoHdr,  
    out System.string ToRefHdr,  
    out System.string ToPinHdr,  
    out System.string ToPartnoHdr,  
    out System.string CableNameHdr,  
    out System.string CoreNameHdr,  
    out System.string ColourHdr,  
    out System.string WireSpecHdr,  
    out System.string OtherAttribHdr  
)
```

C++/CLI

```
System.bool GetFromToListHeaderDefinitions(  
& [Out] System.String^ WireNameHdr,  
& [Out] System.String^ FromRefHdr,  
& [Out] System.String^ FromPinHdr,  
& [Out] System.String^ FromPartnoHdr,  
& [Out] System.String^ ToRefHdr,  
& [Out] System.String^ ToPinHdr,  
& [Out] System.String^ ToPartnoHdr,
```

```

& [Out] System.String^ CableNameHdr,
& [Out] System.String^ CoreNameHdr,
& [Out] System.String^ ColourHdr,
& [Out] System.String^ WireSpecHdr,
& [Out] System.String^ OtherAttribHdr
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WireNameHdr
 Wire name header
FromRefHdr
 "From" reference header
FromPinHdr
 "From" pin header
FromPartnoHdr
 "From" part number header
ToRefHdr
 "To" reference header
ToPinHdr
 "To" pin header
ToPartnoHdr
 "To" part number header
CableNameHdr
 Cable name header
CoreNameHdr
 Core name header
ColourHdr
 Color header
WireSpecHdr
 Wire specification header
OtherAttribHdr
 Miscellaneous header

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::GetFromToListHeaderDefinitions](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::SetFromToListHeaderDefinitions Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : GetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)

Gets the double value of the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```

Function GetRoutingUserPreferenceDoubleValue( _
    ByVal UserPreferenceValue As System.Integer _
) As System.Double

```

Visual Basic (Usage)

```

Dim instance As IRoutingSettings
Dim UserPreferenceValue As System.Integer

```



```
Dim value As System.Double
```

```
value = instance.GetRoutingUserPreferenceDoubleValue(UserPreferenceValue)
```

C#

```
System.double GetRoutingUserPreferenceDoubleValue(  
    System.int UserPreferenceValue  
)
```

C++/CLI

```
System.double GetRoutingUserPreferenceDoubleValue(  
& System.int UserPreferenceValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference as defined in [swUserPreferenceRoutingDouble_e](#)

Return Value

User preference

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::GetRoutingUserPreferenceDoubleValue](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)

[IRoutingSettings Members](#)

[IRoutingSettings::SetRoutingUserPreferenceDoubleValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : GetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)

Gets the integer value of the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRoutingUserPreferenceIntegerValue( _  
    ByVal UserPreferenceValue As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim UserPreferenceValue As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetRoutingUserPreferenceIntegerValue(UserPreferenceValue)
```

C#

```
System.int GetRoutingUserPreferenceIntegerValue(  
    System.int UserPreferenceValue  
)
```

C++/CLI

```
System.int GetRoutingUserPreferenceIntegerValue(  
& System.int UserPreferenceValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference as defined in [swUserPreferenceRoutingInteger_e](#)

Return Value

User preference

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::GetRoutingUserPreferenceIntegerValue](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)

[IRoutingSettings Members](#)

[IRoutingSettings::GetRoutingUserPreferenceIntegerValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRoutingUserPreferenceStringValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : GetRoutingUserPreferenceStringValue Method (IRoutingSettings)

Gets the string value of the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRoutingUserPreferenceStringValue( _  
    ByVal UserPreference As System.Integer, _  
    ByVal UseDefaultVal As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim UserPreference As System.Integer  
Dim UseDefaultVal As System.Boolean  
Dim value As System.String
```

```
value = instance.GetRoutingUserPreferenceStringValue(UserPreference, UseDefaultVal)
```

C#

```
System.string GetRoutingUserPreferenceStringValue(  
    System.int UserPreference,
```

```
        System.bool UseDefaultVal
    )
```

C++/CLI

```
System.String^ GetRoutingUserPreferenceStringValue(
& System.int UserPreference,
& System.bool UseDefaultVal
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreference
User preference as defined in [swUserPreferenceRoutingFileLocations](#) e
UseDefaultVal
True to use the default, false to not

Return Value

User preference

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::GetRoutingUserPreferenceStringValue](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::SetRoutingUserPreferenceStringValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRoutingUserPreferenceToggle Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : GetRoutingUserPreferenceToggle Method (IRoutingSettings)

Gets whether the specified routing user preference is turned on.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRoutingUserPreferenceToggle( _
    ByVal UserPreferenceToggle As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings
Dim UserPreferenceToggle As System.Integer
Dim value As System.Boolean
```

```
value = instance.GetRoutingUserPreferenceToggle(UserPreferenceToggle)
```

C#

```
System.bool GetRoutingUserPreferenceToggle(
    System.int UserPreferenceToggle
)
```

C++/CLI

```
System.bool GetRoutingUserPreferenceToggle(  
& System.int UserPreferenceToggle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceToggle
User preference as defined in [swUserPreferenceRoutingToggle_e](#)

Return Value

True if on, false if off

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::GetRoutingUserPreferenceToggle](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::SetRoutingUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LoadDefaultRoutingSettings Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : LoadDefaultRoutingSettings Method (IRoutingSettings)

Loads the default routing settings.

.NET Syntax

Visual Basic (Declaration)

```
Sub LoadDefaultRoutingSettings()
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
instance.LoadDefaultRoutingSettings()
```

C#

```
void LoadDefaultRoutingSettings()
```

C++/CLI

```
void LoadDefaultRoutingSettings();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::LoadDefaultRoutingSettings](#).

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::LoadRoutingSettingsFromFile Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadRoutingSettingsFromFile Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : LoadRoutingSettingsFromFile Method (IRoutingSettings)

Loads routing settings from the specified file.

.NET Syntax

Visual Basic (Declaration)

```
Function LoadRoutingSettingsFromFile( _  
    ByVal RoutingSettingsFilename As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim RoutingSettingsFilename As System.String  
Dim value As System.Boolean  
  
value = instance.LoadRoutingSettingsFromFile(RoutingSettingsFilename)
```

C#

```
System.bool LoadRoutingSettingsFromFile(  
    System.string RoutingSettingsFilename  
)
```

C++/CLI

```
System.bool LoadRoutingSettingsFromFile(  
    & System.String^ RoutingSettingsFilename  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RoutingSettingsFilename

Full path name of the .sqy file from which to load the routing settings

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::LoadRoutingSettingsFromFile](#).

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::LoadDefaultRoutingSettings Method](#)
[IRoutingSettings::SaveRoutingSettingsToFile Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveRoutingSettingsToFile Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : [SaveRoutingSettingsToFile Method \(IRoutingSettings\)](#)

Saves routing settings to the specified file.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveRoutingSettingsToFile( _  
    ByVal RoutingSettingsFilename As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim RoutingSettingsFilename As System.String  
Dim value As System.Boolean  
  
value = instance.SaveRoutingSettingsToFile(RoutingSettingsFilename)
```

C#

```
System.bool SaveRoutingSettingsToFile(  
    System.string RoutingSettingsFilename  
)
```

C++/CLI

```
System.bool SaveRoutingSettingsToFile(  
& System.String^ RoutingSettingsFilename  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RoutingSettingsFilename

Full path name of file to which to save routing settings; file name must have an extension of **.sqy**

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SaveRoutingSettingsToFile](#).

Example

See the [IRoutingSettings](#) examples.

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::LoadRoutingSettingsFromFile Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFromToListHeaderDefinitions Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : [SetFromToListHeaderDefinitions Method \(IRoutingSettings\)](#)

Sets the headers in a routing from-to list.

Visual Basic (Declaration)

```
Function SetFromToListHeaderDefinitions( _
    ByVal WireNameHdr As System.String, _
    ByVal FromRefHdr As System.String, _
    ByVal FromPinHdr As System.String, _
    ByVal FromPartnoHdr As System.String, _
    ByVal ToRefHdr As System.String, _
    ByVal ToPinHdr As System.String, _
    ByVal ToPartnoHdr As System.String, _
    ByVal CableNameHdr As System.String, _
    ByVal CoreNameHdr As System.String, _
    ByVal ColourHdr As System.String, _
    ByVal WireSpecHdr As System.String, _
    ByVal OtherAttribHdr As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings
Dim WireNameHdr As System.String
Dim FromRefHdr As System.String
Dim FromPinHdr As System.String
Dim FromPartnoHdr As System.String
Dim ToRefHdr As System.String
Dim ToPinHdr As System.String
Dim ToPartnoHdr As System.String
Dim CableNameHdr As System.String
Dim CoreNameHdr As System.String
Dim ColourHdr As System.String
Dim WireSpecHdr As System.String
Dim OtherAttribHdr As System.String
Dim value As System.Boolean
```

```
value = instance.SetFromToListHeaderDefinitions(WireNameHdr, FromRefHdr, FromPinHdr,
FromPartnoHdr, ToRefHdr, ToPinHdr, ToPartnoHdr, CableNameHdr, CoreNameHdr, ColourHdr, WireSpecHdr,
OtherAttribHdr)
```

C#

```
System.bool SetFromToListHeaderDefinitions(
    System.string WireNameHdr,
    System.string FromRefHdr,
    System.string FromPinHdr,
    System.string FromPartnoHdr,
    System.string ToRefHdr,
    System.string ToPinHdr,
    System.string ToPartnoHdr,
    System.string CableNameHdr,
    System.string CoreNameHdr,
    System.string ColourHdr,
    System.string WireSpecHdr,
    System.string OtherAttribHdr
)
```

C++/CLI

```
System.bool SetFromToListHeaderDefinitions(
    & System.String^ WireNameHdr,
    & System.String^ FromRefHdr,
    & System.String^ FromPinHdr,
    & System.String^ FromPartnoHdr,
    & System.String^ ToRefHdr,
    & System.String^ ToPinHdr,
    & System.String^ ToPartnoHdr,
    & System.String^ CableNameHdr,
    & System.String^ CoreNameHdr,
```

```
& System.String^ ColourHdr,
& System.String^ WireSpecHdr,
& System.String^ OtherAttribHdr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WireNameHdr
Wire name header
FromRefHdr
"From" reference header
FromPinHdr
"From" pin header
FromPartnoHdr
"From" part number header
ToRefHdr
"To" reference header
ToPinHdr
"To" pin header
ToPartnoHdr
"To" part number header
CableNameHdr
Cable name header
CoreNameHdr
Core name header
ColourHdr
Color header
WireSpecHdr
Wire specification header
OtherAttribHdr
Miscellaneous header

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SetFromToListHeaderDefinitions](#).

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::GetFromToListHeaderDefinitions Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : SetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)

Sets a double value for the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRoutingUserPreferenceDoubleValue( _
    ByVal UserPreferenceValue As System.Integer, _
    ByVal Value As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRoutingSettings
Dim UserPreferenceValue As System.Integer
Dim Value As System.Double
Dim value As System.Boolean
```

```
value = instance.SetRoutingUserPreferenceDoubleValue(UserPreferenceValue, Value)
```

C#



```
System.bool SetRoutingUserPreferenceDoubleValue(  
    System.int UserPreferenceValue,  
    System.double Value  
)
```

C++/CLI

```
System.bool SetRoutingUserPreferenceDoubleValue(  
& System.int UserPreferenceValue,  
& System.double Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference as defined in [swUserPreferenceRoutingDouble_e](#)

Value

Double value of the specified user preference

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SetRoutingUserPreferenceDoubleValue](#).

See Also

[IRoutingSettings Interface](#)

[IRoutingSettings Members](#)

[IRoutingSettings::GetRoutingUserPreferenceDoubleValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : SetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)

Sets an integer value for the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRoutingUserPreferenceIntegerValue( _  
    ByVal UserPreferenceValue As System.Integer, _  
    ByVal Value As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim UserPreferenceValue As System.Integer  
Dim Value As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetRoutingUserPreferenceIntegerValue(UserPreferenceValue, Value)
```

C#

```
System.bool SetRoutingUserPreferenceIntegerValue(  
    System.int UserPreferenceValue,  
    System.int Value  
)
```

C++/CLI

```
System.bool SetRoutingUserPreferenceIntegerValue(  
& System.int UserPreferenceValue,  
& System.int Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference as defined in [swUserPreferenceRoutingInteger_e](#)

Value

Integer value of the specified user preference

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SetRoutingUserPreferenceIntegerValue](#).

See Also

[IRoutingSettings Interface](#)

[IRoutingSettings Members](#)

[IRoutingSettings::GetRoutingUserPreferenceIntegerValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRoutingUserPreferenceStringValue Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : SetRoutingUserPreferenceStringValue Method (IRoutingSettings)

Sets a string value for the specified routing user preference.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRoutingUserPreferenceStringValue( _  
    ByVal UserPreference As System.Integer, _  
    ByVal Value As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim UserPreference As System.Integer  
Dim Value As System.String  
Dim value As System.Boolean
```

```
value = instance.SetRoutingUserPreferenceStringValue(UserPreference, Value)
```

C#

```
System.bool SetRoutingUserPreferenceStringValue(  
    System.int UserPreference,  
    System.string Value  
)
```

C++/CLI

```
System.bool SetRoutingUserPreferenceStringValue(  
& System.int UserPreference,  
& System.String^ Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreference
User preference as defined in [swUserPreferenceRoutingFileLocations](#) e
Value
String value of the specified user preference

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SetRoutingUserPreferenceStringValue](#).

See Also

[IRoutingSettings Interface](#)
[IRoutingSettings Members](#)
[IRoutingSettings::GetRoutingUserPreferenceStringValue Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetRoutingUserPreferenceToggle Method (IRoutingSettings)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRoutingSettings Interface](#) : SetRoutingUserPreferenceToggle Method (IRoutingSettings)

Sets whether the specified routing user preference is turned on or off.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRoutingUserPreferenceToggle( _  
    ByVal UserPreferenceValue As System.Integer, _  
    ByVal OnFlag As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IRoutingSettings  
Dim UserPreferenceValue As System.Integer  
Dim OnFlag As System.Boolean  
  
instance.SetRoutingUserPreferenceToggle(UserPreferenceValue, OnFlag)
```

C#

```
void SetRoutingUserPreferenceToggle(  
    System.int UserPreferenceValue,  
    System.bool OnFlag  
)
```

```
void SetRoutingUserPreferenceToggle(  
& System.int UserPreferenceValue,  
& System.bool OnFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

User preference as defined in [swUserPreferenceRoutingToggle_e](#)

OnFlag

True to turn on, false to turn off

Visual Basic for Applications (VBA) Syntax

See [RoutingSettings::SetRoutingUserPreferenceToggle](#).

See Also

[IRoutingSettings Interface](#)

[IRoutingSettings Members](#)

[IRoutingSettings::GetRoutingUserPreferenceToggle Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

IRuledSurfaceFeatureData (Type)

IRuledSurfaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRuledSurfaceFeatureData Interface

Allows access to a ruled-surface feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IRuledSurfaceFeatureData
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData
```

C#

```
public interface IRuledSurfaceFeatureData
```

C++/CLI

```
public interface class IRuledSurfaceFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData](#).

Example

[Get Ruled-Surface Feature Data \(VBA\)](#)
[Get Ruled-Surface Feature Data \(VB.NET\)](#)
[Get Ruled-Surface Feature Data \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[RuledSurfaceFeatureData](#)

See Also

[IRuledSurfaceFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRuledSurfaceFromEdge2 Method](#)

IRuledSurfaceFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRuledSurfaceFeatureData Interface

For a list of all members of this type, see [IRuledSurfaceFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this ruled-surface feature.
 GetDirectionReference	Gets the direction of this ruled-surface feature.

	GetEdges	Gets the edges to used as the base for this ruled-surface feature.
	GetEdgesCount	Gets the number of edges to use as a base for this ruled-surface feature.
	IGetEdges	Gets the edges to used as the base for this ruled-surface feature.
	ISetEdges	Sets the edge to use as the base for this ruled-surface feature.
	ReleaseSelectionAccess	Releases access to the selections that define this ruled-surface feature.
	SetDirectionReference	Sets the direction of the extrusion for this ruled-surface feature.
	SetEdges	Sets the edge to use as the base for this ruled-surface feature.

[Top](#)

See Also

[IRuledSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRuledSurfaceFromEdge2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRuledSurfaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IRuledSurfaceFeatureData Interface

The following tables list the members exposed by [IRuledSurfaceFeatureData](#).

Public Properties

Name	Description
 Angle	Gets or sets the taper angle of this ruled-surface feature.
 Connect	Gets or sets whether or not to connect the surfaces of this ruled-surface feature.
 DirectionVector	Gets or sets the reference vector for this ruled-surface feature.
 Distance	Gets or sets the distance, in meters, to extend the ruled-surface feature.
 TrimAndKnit	Gets or sets whether to trim and knit the surfaces of this ruled-surface feature.
 Type	Gets or sets the type of ruled-surface feature.
 UseVector	Gets or sets whether or not use a reference vector for this ruled-surface feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this ruled-surface feature.
 GetDirectionReference	Gets the direction of this ruled-surface feature.
 GetEdges	Gets the edges to used as the base for this ruled-surface feature.
 GetEdgesCount	Gets the number of edges to use as a base for this ruled-surface feature.
 IGetEdges	Gets the edges to used as the base for this ruled-surface feature.
 ISetEdges	Sets the edge to use as the base for this ruled-surface feature.
 ReleaseSelectionAccess	Releases access to the selections that define this ruled-surface feature.
 SetDirectionReference	Sets the direction of the extrusion for this ruled-surface feature.
 SetEdges	Sets the edge to use as the base for this ruled-surface feature.

[Top](#)

See Also

[IRuledSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertRuledSurfaceFromEdge2 Method](#)

IRuledSurfaceFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IRuledSurfaceFeatureData Interface

For a list of all members of this type, see [IRuledSurfaceFeatureData members](#).

Public Properties

Name	Description
 Angle	Gets or sets the taper angle of this ruled-surface feature.
 Connect	Gets or sets whether or not to connect the surfaces of this ruled-surface feature.
 DirectionVector	Gets or sets the reference vector for this ruled-surface feature.
 Distance	Gets or sets the distance, in meters, to extend the ruled-surface feature.
 TrimAndKnit	Gets or sets whether to trim and knit the surfaces of this ruled-surface feature.
 Type	Gets or sets the type of ruled-surface feature.
 UseVector	Gets or sets whether or not use a reference vector for this ruled-surface feature.

[Top](#)

See Also

[IRuledSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertRuledSurfaceFromEdge2 Method](#)

AccessSelections Method (IRuledSurfaceFeatureData)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : AccessSelections Method (IRuledSurfaceFeatureData)

Gains access to the selections that define this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IRuledSurfaceFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
    & ModelDoc2^ TopDoc,  
    & Component2^ Component  
)
```



Copy Code

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::AccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IRuledSurfaceFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

 Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : Angle Property (IRuledSurfaceFeatureData)

Gets or sets the taper angle of this ruled-surface feature.

 .NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim value As System.Double  
  
instance.Angle = value  
  
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::Angle](#).

Remarks

This property is only available when [IRuledSurfaceFeatureData::Type](#) is set to [swRuledSurfaceType_e.swRuledSurfaceType_TaperedToVector](#).

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Connect Property (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : Connect Property (IRuledSurfaceFeatureData)

Gets or sets whether or not to connect the surfaces of this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

Property Connect As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.Connect = value
```

```
value = instance.Connect
```

C#

```
System.bool Connect {get; set;}
```

C++/CLI

```
property System.bool Connect {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to connect surfaces, false to remove connecting surfaces

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::Connect](#).

Remarks

Connecting surfaces are usually created between sharp corners.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DirectionVector Property (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : DirectionVector Property (IRuledSurfaceFeatureData)

Gets or sets the reference vector for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

Property DirectionVector As MathVector

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim value As MathVector
```

```
instance.DirectionVector = value
```

```
value = instance.DirectionVector
```

C#

```
MathVector DirectionVector {get; set;}
```

C++/CLI

```
property MathVector^ DirectionVector {  
    MathVector^ get();  
    void set ( & MathVector^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Reference vector](#)

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::DirectionVector](#).

Remarks

This property is only available when [IRuledSurfaceFeatureData::Type](#) is set to swRuledSurfaceType_Sweep.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::UseVector Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Distance Property (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : Distance Property (IRuledSurfaceFeatureData)

Gets or sets the distance, in meters, to extend the ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::Distance](#).

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDirectionReference Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : GetDirectionReference Method (IRuledSurfaceFeatureData)

Gets the direction of this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionReference( _
    ByRef Ref1 As System.Object, _
    ByRef Type1 As System.Integer, _
    ByRef Ref2 As System.Object, _
    ByRef Type2 As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData
Dim Ref1 As System.Object
Dim Type1 As System.Integer
Dim Ref2 As System.Object
Dim Type2 As System.Integer
Dim value As System.Integer

value = instance.GetDirectionReference(Ref1, Type1, Ref2, Type2)
```

C#

```
System.int GetDirectionReference(
    out System.object Ref1,
    out System.int Type1,
    out System.object Ref2,
    out System.int Type2
)
```

C++/CLI

```
System.int GetDirectionReference(
    & [Out] System.Object^ Ref1,
    & [Out] System.int Type1,
    & [Out] System.Object^ Ref2,
    & [Out] System.int Type2
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Ref1
First reference entity (see **Remarks**)

Type1
Type of reference entity as defined by [swSelectType_e](#) (see **Remarks**)

Ref2
Second reference entity (see **Remarks**)

Type2
Type of reference entity as defined by [swSelectType_e](#) (see **Remarks**)

Return Value

Number of reference entities used to define the direction of the ruled surface (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::GetDirectionReference](#).

Remarks

This method is only available when [IRuledSurfaceFeatureData::Type](#) is set to swRuledSurfaceType_TaperedToVector, swRuledSurfaceType_PerpendicularToVector, or swRuledSurfaceType_Sweep.

Sometimes one reference entity defines a direction; for example, an edge or axis. Other times, two reference entities define a direction; for example, two vertices or two sketch points.

If...	Then...
One reference entity defined the direction	Ref2 is NULL and the return value is 1
Two reference entities defined the direction	Both Ref1 and Ref2 are non-NULL and the return value is 2

Valid reference entities for type1 and type2:

- line segment
- edge
- axis
- vertex
- face
- plane
- sketch point

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::SetDirectionReference Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdges Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : GetEdges Method (IRuledSurfaceFeatureData)

Gets the edges to used as the base for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetEdges( _  
    ByRef Edges As System.Object, _  
    ByRef SideFlags As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim Edges As System.Object  
Dim SideFlags As System.Object  
  
instance.GetEdges(Edges, SideFlags)
```

C#

```
void GetEdges(  
    out System.object Edges,  
    out System.object SideFlags  
)
```

C++/CLI

```
void GetEdges(  
& [Out] System.Object^ Edges,  
& [Out] System.Object^ SideFlags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Edges

Array of [edges](#)

SideFlags

Array of flags indicating which side of each edge to create the ruled-surface feature

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::GetEdges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::GetEdgesCount Method](#)
[IRuledSurfaceFeatureData::IGetEdges Method](#)
[IRuledSurfaceFeatureData::ISetEdges Method](#)
[IRuledSurfaceFeatureData::SetEdges Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgesCount Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : GetEdgesCount Method (IRuledSurfaceFeatureData)

Gets the number of edges to use as a base for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetEdgesCount()
```

C#

```
System.int GetEdgesCount()
```

C++/CLI

```
System.int GetEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::GetEdgesCount](#).

Remarks

Call this method before calling [IRuledSurfaceFeatureData::IGetEdges](#) to get the size of the array for that method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::GetEdges Method](#)
[IRuledSurfaceFeatureData::ISetEdges Method](#)
[IRuledSurfaceFeatureData::SetEdges Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : IGetEdges Method (IRuledSurfaceFeatureData)

Gets the edges to be used as the base for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetEdges( _  
    ByVal Count As System.Integer, _  
    ByRef Entities As System.Object, _  
    ByRef SideFlags As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim Count As System.Integer  
Dim Entities As System.Object  
Dim SideFlags As System.Integer  
  
instance.IGetEdges(Count, Entities, SideFlags)
```

C#

```
void IGetEdges(  
    System.int Count,  
    out System.object Entities,  
    out System.int SideFlags  
)
```

C++/CLI

```
void IGetEdges(  
& System.int Count,  
& [Out] System.Object^ Entities,  
& [Out] System.int SideFlags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges

Entities

Array of [edges](#)

SideFlags

- in-process, unmanaged C++: Pointer to an array of flags indicating which side of each edge to create the ruled-surface feature

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IRuledSurfaceFeatureData::GetEdgesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)

[IRuledSurfaceFeatureData Members](#)

[IRuledSurfaceFeatureData::GetEdges Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEdges Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : ISetEdges Method (IRuledSurfaceFeatureData)

Sets the edge to use as the base for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal Count As System.Integer, _  
    ByRef Entities As System.Object, _  
    ByRef SideFlags As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim Count As System.Integer  
Dim Entities As System.Object  
Dim SideFlags As System.Integer  
  
instance.ISetEdges(Count, Entities, SideFlags)
```

C#

```
void ISetEdges(  
    System.int Count,  
    ref System.object Entities,  
    ref System.int SideFlags  
)
```

C++/CLI

```
void ISetEdges(  
& System.int Count,  
& System.Object^% Entities,  
& System.int% SideFlags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges

Entities

Array of [edges](#)

SideFlags

- in-process, unmanaged C++: Pointer to an array of flags indicating which side of each edge to create the ruled-surface feature
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

[IRuledSurfaceFeatureData::SetEdges Method](#)
[IRuledSurfaceFeatureData::GetEdges Method](#)
[IRuledSurfaceFeatureData::GetEdgesCount Method](#)
[IRuledSurfaceFeatureData::!GetEdges Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : ReleaseSelectionAccess Method (IRuledSurfaceFeatureData)

Releases access to the selections that define this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::ReleaseSelectionAccess](#).

Remarks

[IRuledSurfaceFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDirectionReference Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : SetDirectionReference Method (IRuledSurfaceFeatureData)

Sets the direction of the extrusion for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDirectionReference( _  
    ByVal Ref1 As System.Object, _  
    ByVal Ref2 As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim Ref1 As System.Object  
Dim Ref2 As System.Object  
  
instance.SetDirectionReference(Ref1, Ref2)
```

C#

```
void SetDirectionReference(  
    System.object Ref1,  
    System.object Ref2  
)
```

C++/CLI

```
void SetDirectionReference(  
& System.Object^ Ref1,  
& System.Object^ Ref2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Ref1

First reference entity (see **Remarks**)

Ref2

Second reference entity (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::SetDirectionReference](#).

Remarks

Sometimes one reference entity can sufficiently define a direction; for example, an edge or axis. Other times, two reference entities are required to define a direction; for example, two vertices or two sketch points.

If...	Then...
One reference entity can sufficiently define the direction	Ref2 is NULL
Two reference entities are required to define the direction	Both Ref1 and Ref2 are non-NULL

Valid reference entities for type1 and type2:

- line segment
- edge
- axis
- vertex
- face
- plane
- sketch point

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)

[IRuledSurfaceFeatureData Members](#)

[IRuledSurfaceFeatureData::GetDirectionReference Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEdges Method (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : SetEdges Method (IRuledSurfaceFeatureData)

Sets the edge to use as the base for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEdges( _  
    ByVal Edges As System.Object, _  
    ByVal SideFlags As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData  
Dim Edges As System.Object  
Dim SideFlags As System.Object  
  
instance.SetEdges(Edges, SideFlags)
```

C#

```
void SetEdges(  
    System.object Edges,  
    System.object SideFlags  
)
```

C++/CLI

```
void SetEdges(  
& System.Object^ Edges,  
& System.Object^ SideFlags  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Edges
Array of [edges](#)
SideFlags
Array of flags indicating which side of each edge to create the ruled-surface feature

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::SetEdges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::ISetEdges Method](#)
[IRuledSurfaceFeatureData::GetEdges Method](#)
[IRuledSurfaceFeatureData::GetEdgesCount Method](#)
[IRuledSurfaceFeatureData::IGetEdges Method](#)

Availability

TrimAndKnit Property (IRuledSurfaceFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : TrimAndKnit Property (IRuledSurfaceFeatureData)

Gets or sets whether to trim and knit the surfaces of this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

Property TrimAndKnit As System.Boolean

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData
Dim value As System.Boolean

instance.TrimAndKnit = value

value = instance.TrimAndKnit
```

C#

```
System.bool TrimAndKnit {get; set;}
```

C++/CLI

```
property System.bool TrimAndKnit {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to trim and knit surfaces, false to not

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::TrimAndKnit](#).

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Type Property (IRuledSurfaceFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : Type Property (IRuledSurfaceFeatureData)

Gets or sets the type of ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData
Dim value As System.Integer

instance.Type = value

value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of ruled-surface feature as defined in [swRuledSurfaceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::Type](#).

Example

[Get Ruled-Surface Feature Data \(VBA\)](#)
[Get Ruled-Surface Feature Data \(VB.NET\)](#)
[Get Ruled-Surface Feature Data \(C#\)](#)

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::GetDirectionReference Method](#)
[IRuledSurfaceFeatureData::Angle Property](#)
[IRuledSurfaceFeatureData::DirectionVector Property](#)
[IRuledSurfaceFeatureData::UseVector Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseVector Property (IRuledSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IRuledSurfaceFeatureData Interface](#) : UseVector Property (IRuledSurfaceFeatureData)

Gets or sets whether or not use a reference vector for this ruled-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseVector As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IRuledSurfaceFeatureData
Dim value As System.Boolean

instance.UseVector = value

value = instance.UseVector
```

C#

```
System.bool UseVector {get; set;}
```

C++/CLI

```
property System.bool UseVector {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use a reference vector, false to not

Visual Basic for Applications (VBA) Syntax

See [RuledSurfaceFeatureData::UseVector](#).

Remarks

This property is only available when [IRuledSurfaceFeatureData::Type](#) is set to `swRuledSurfaceType_Sweep`.

See Also

[IRuledSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Members](#)
[IRuledSurfaceFeatureData::DirectionVector Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0