

SOLIDWORKS API (.NET VBA C#) — Reference (246/337): IScaleFeatureData- ISecondaryMemberSupportPlaneFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IScaleFeatureData (Type)

IScaleFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IScaleFeatureData Interface

Allows access to a scale feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IScaleFeatureData
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData
```

C#

```
public interface IScaleFeatureData
```

C++/CLI

```
public interface class IScaleFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData](#).

Example

[Get Data for Scale Feature \(VBA\)](#)
[Get Data for Scale Feature \(VB.NET\)](#)
[Get Data for Scale Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[ScaleFeatureData](#)

See Also

[IScaleFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertScale Method](#)

IScaleFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IScaleFeatureData Interface

The following tables list the members exposed by [IScaleFeatureData](#).

Public Properties

Name	Description
 Bodies	Gets or sets whether the bodies are scaled in a multibody part.
 CoordinateSystem	Gets or sets the coordinate system of the scale feature.

 IsUniform	Gets or sets uniform scaling for this scale feature.
 ScaleUniform	Gets or sets the uniform scaling factor for this scale feature when uniform scaling is enabled.
 ScaleX	Gets or sets the scaling factor in the X direction when uniform scaling is disabled.
 ScaleY	Gets or sets the scaling factor in the Y direction when uniform scaling is disabled.
 ScaleZ	Gets or sets the scaling factor in the Z direction when uniform scaling is disabled.
 Type	Gets or sets the scale type.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this scale feature.
 GetBodiesCount	Gets the number of scaled bodies for this scale feature.
 GetScale	Gets the scale factor for this scale feature in x, y, and z directions.
 IAccessSelections	Allows access to a scale feature.
 IGetBodies	Gets the bodies that are scaled in a multibody part.
 ISetBodies	Sets the bodies that are scaled in a multibody part.
 ReleaseSelectionAccess	Releases access to the selections used to define the scale feature.
 SetScale	Sets the scale factor for this scale feature in the x, y, and z directions.

[Top](#)

See Also

[IScaleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertScale Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IScaleFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IScaleFeatureData Interface

For a list of all members of this type, see [IScaleFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this scale feature.
 GetBodiesCount	Gets the number of scaled bodies for this scale feature.
 GetScale	Gets the scale factor for this scale feature in x, y, and z directions.
 IAccessSelections	Allows access to a scale feature.
 IGetBodies	Gets the bodies that are scaled in a multibody part.
 ISetBodies	Sets the bodies that are scaled in a multibody part.
 ReleaseSelectionAccess	Releases access to the selections used to define the scale feature.
 SetScale	Sets the scale factor for this scale feature in the x, y, and z directions.

[Top](#)

See Also

[IScaleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertScale Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IScaleFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IScaleFeatureData Interface

For a list of all members of this type, see [IScaleFeatureData members](#).

Public Properties

Name	Description
 Bodies	Gets or sets whether the bodies are scaled in a multibody part.
 CoordinateSystem	Gets or sets the coordinate system of the scale feature.
 IsUniform	Gets or sets uniform scaling for this scale feature.
 ScaleUniform	Gets or sets the uniform scaling factor for this scale feature when uniform scaling is enabled.
 ScaleX	Gets or sets the scaling factor in the X direction when uniform scaling is disabled.
 ScaleY	Gets or sets the scaling factor in the Y direction when uniform scaling is disabled.
 ScaleZ	Gets or sets the scaling factor in the Z direction when uniform scaling is disabled.
 Type	Gets or sets the scale type.

[Top](#)

See Also

[IScaleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertScale Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IScaleFeatureData)

[See Also](#) [Example](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : AccessSelections Method (IScaleFeatureData)

Gains access to the selections that define this scale feature.

.NET Syntax

Visual Basic (Declaration)
<pre>Function AccessSelections(ByVal TopDoc As System.Object, ByVal Component As System.Object) As System.Boolean</pre>
Visual Basic (Usage)  Copy Code
<pre>Dim instance As IScaleFeatureData Dim TopDoc As System.Object Dim Component As System.Object Dim value As System.Boolean value = instance.AccessSelections(TopDoc, Component)</pre>
C#
<pre>System.bool AccessSelections(System.object TopDoc, System.object Component)</pre>
C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::AccessSelections](#).

Example

[Get Faces Affected By Scale Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IScaleFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Bodies Property (IScaleFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : Bodies Property (IScaleFeatureData)

Gets or sets whether the bodies are scaled in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property Bodies As System.Object

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Object
```

```
instance.Bodies = value
```

```
value = instance.Bodies
```

C#

```
System.Object Bodies {get; set;}
```

C++/CLI

```
property System.Object^ Bodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) that are scaled

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::Bodies](#).

Example

[Get Faces Affected By Scale Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::GetBodiesCount Method](#)
[IScaleFeatureData::IGetBodies Method](#)
[IScaleFeatureData::ISetBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CoordinateSystem Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : CoordinateSystem Property (IScaleFeatureData)

Gets or sets the coordinate system of the scale feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CoordinateSystem As System.Object
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Object
```

```
instance.CoordinateSystem = value
```

```
value = instance.CoordinateSystem
```

C#

```
System.Object CoordinateSystem {get; set;}
```

C++/CLI

```
property System.Object^ CoordinateSystem {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the coordinate system [feature](#)

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::CoordinateSystem](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)

Availability

SolidWorks 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBodiesCount Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : GetBodiesCount Method (IScaleFeatureData)

Gets the number of scaled bodies for this scale feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Integer  
  
value = instance.GetBodiesCount()
```

C#

```
System.int GetBodiesCount()
```

C++/CLI

```
System.int GetBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies that are scaled

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::GetBodiesCount](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

Call this method before calling [IScaleFeatureData::IGetBodies](#) to get the size of the array for that method.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::IGetBodies Method](#)
[IScaleFeatureData::ISetBodies Method](#)
[IScaleFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetScale Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : GetScale Method (IScaleFeatureData)

Gets the scale factor for this scale feature in x, y, and z directions.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetScale( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef Uniform As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Uniform As System.Boolean  
  
instance.GetScale(X, Y, Z, Uniform)
```

C#

```
void GetScale(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.bool Uniform  
)
```

C++/CLI

```
void GetScale(  
    & [Out] System.double X,
```

```
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.bool Uniform  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X-direction scale factor

Y
Y-direction scale factor

Z
Z-direction scale factor

Uniform
True for uniform scaling, false for non-uniform scaling

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::GetScale](#).

Example

See [IScaleFeatureData](#) examples.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[SetScale Method](#)
[IScaleFeatureData::ScaleX Property](#)
[IScaleFeatureData::ScaleY Property](#)
[IScaleFeatureData::ScaleZ Property](#)
[IScaleFeatureData::ScaleUniform Property](#)
[IScaleFeatureData::IsUniform Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : IAccessSelections Method (IScaleFeatureData)

Allows access to a scale feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IScaleFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,
```



Component2 [Component](#)
)

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IScaleFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IScaleFeatureData Interface](#)

[IScaleFeatureData Members](#)

[IScaleFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBodies Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : IGetBodies Method (IScaleFeatureData)

Gets the bodies that are scaled in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim Count As System.Integer  
Dim value As Body2
```

```
value = instance.IGetBodies(Count)
```

C#

```
Body2 IGetBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies that are scaled

Return Value

- in-process, unmanaged C++: Pointer to an array of [bodies](#) that are scaled of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IScaleFeatureData::GetBodiesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::ISetBodies Method](#)
[IScaleFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetBodies Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ISetBodies Method (IScaleFeatureData)

Sets the bodies that are scaled in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)

```
Dim instance As IScaleFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2
```

```
instance.ISetBodies(Count, BodyArr)
```

C#



```
void ISetBodies(
    System.int Count,
    ref Body2 BodyArr
)
```

C++/CLI

```
void ISetBodies(
    & System.int Count,
    & Body2^% BodyArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies that are scaled

BodyArr

- in-process, unmanaged C++: Pointer to an array of [bodies](#) that are scaled of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IScaleFeatureData Interface](#)

[IScaleFeatureData Members](#)

[IScaleFeatureData::GetBodiesCount Method](#)

[IScaleFeatureData::IGetBodies Method](#)

[IScaleFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsUniform Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : IsUniform Property (IScaleFeatureData)

Gets or sets uniform scaling for this scale feature.

.NET Syntax

Visual Basic (Declaration)

```
Property IsUniform As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData
Dim value As System.Boolean
```

```
instance.IsUniform = value
```

```
value = instance.IsUniform
```

C#

```
System.bool IsUniform {get; set;}
```

C++/CLI

```
property System.bool IsUniform {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for uniform scaling, false for non-uniform scaling

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::IsUniform](#).

Example

See [IScaleFeatureData](#) examples.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::GetScale Method](#)
[IScaleFeatureData::SetScale Method](#)
[IScaleFeatureData::ScaleUniform Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IScaleFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ReleaseSelectionAccess Method (IScaleFeatureData)

Releases access to the selections used to define the scale feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::ReleaseSelectionAccess](#).

Example

[Get Faces Affected By Scale Feature \(VBA\)](#)

Remarks

[IScaleFeatureData::AccessSelections](#) and [IScaleFeatureData::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleUniform Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ScaleUniform Property (IScaleFeatureData)

Gets or sets the uniform scaling factor for this scale feature when uniform scaling is enabled.

.NET Syntax

Visual Basic (Declaration)

Property ScaleUniform As System.Double

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Double
```

```
instance.ScaleUniform = value
```

```
value = instance.ScaleUniform
```

C#

```
System.double ScaleUniform {get; set;}
```

C++/CLI

```
property System.double ScaleUniform {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for the uniform scaling factor

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::ScaleUniform](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

You can use:

- [IScaleFeatureData::IsUniform](#) to enable or disable uniform scaling.
- or -
- [IScaleFeatureData::GetScale](#) or [IScaleFeatureData::SetScale](#) to get or set all of the scaling-related values, including uniform scaling, in the same call.

NOTE: If uniform scaling is disabled, then use these properties to get or set the individual scaling values:

- [IScaleFeatureData::ScaleX](#)
- [IScaleFeatureData::ScaleY](#)
- [IScaleFeatureData::ScaleZ](#)

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleX Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ScaleX Property (IScaleFeatureData)

Gets or sets the scaling factor in the X direction when uniform scaling is disabled.

.NET Syntax

Visual Basic (Declaration)

```
Property ScaleX As System.Double
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Double
```

```
instance.ScaleX = value
```

```
value = instance.ScaleX
```

C#

```
System.double ScaleX {get; set;}
```

C++/CLI

```
property System.double ScaleX {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

X-direction scale factor

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::ScaleX](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

To get or set...	Use...
Uniform scaling	IScaleFeatureData::IsUniform
All scale-related values in the same call	IScaleFeatureData::GetScale or IScaleFeatureData::SetScale

NOTE: To get or set the scaling factor when uniform scaling is enabled, use [IScaleFeatureData::ScaleUniform](#).

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::ScaleY Property](#)
[IScaleFeatureData::ScaleZ Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleY Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ScaleY Property (IScaleFeatureData)

Gets or sets the scaling factor in the Y direction when uniform scaling is disabled.

.NET Syntax

Visual Basic (Declaration)

Property ScaleY As System.Double

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Double
```

```
instance.ScaleY = value
```

```
value = instance.ScaleY
```

C#

```
System.double ScaleY {get; set;}
```

C++/CLI

```
property System.double ScaleY {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Y-direction scale factor

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::ScaleY](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

To get or set...	Use...
Uniform scaling	IScaleFeatureData::IsUniform
All scale-related values in the same call	IScaleFeatureData::GetScale or IScaleFeatureData::SetScale

NOTE: To get or set the scaling factor when uniform scaling is enabled, use [IScaleFeatureData::ScaleUniform](#).

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::ScaleX Property](#)
[IScaleFeatureData::ScaleZ Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleZ Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : ScaleZ Property (IScaleFeatureData)

Gets or sets the scaling factor in the Z direction when uniform scaling is disabled.

.NET Syntax

Visual Basic (Declaration)

Property ScaleZ As System.Double

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim value As System.Double
```

```
instance.ScaleZ = value
```

```
value = instance.ScaleZ
```

C#

```
System.double ScaleZ {get; set;}
```

C++/CLI

```
property System.double ScaleZ {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Z-direction scale factor

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::ScaleZ](#).

Example

See [IScaleFeatureData](#) examples.

Remarks

To get or set...	Use...
Uniform scaling	IScaleFeatureData::IsUniform
All scale-related values in the same call	IScaleFeatureData::GetScale or IScaleFeatureData::SetScale

NOTE: To get or set the scaling factor when uniform scaling is enabled, use [IScaleFeatureData::ScaleUniform](#).

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)
[IScaleFeatureData::ScaleX Property](#)
[IScaleFeatureData::ScaleY Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetScale Method (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : SetScale Method (IScaleFeatureData)

Sets the scale factor for this scale feature in the x, y, and z directions.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetScale(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Uniform As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Uniform As System.Boolean  
  
instance.SetScale(X, Y, Z, Uniform)
```

C#

```
void SetScale(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool Uniform  
)
```

C++/CLI

```
void SetScale(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool Uniform  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X-direction scale factor

Y

Y-direction scale factor

Z

Z-direction scale factor

Uniform

True for uniform scaling, false for non-uniform scaling

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::SetScale](#).

See Also

[IScaleFeatureData Interface](#)

[IScaleFeatureData Members](#)

[IScaleFeatureData::GetScale Method](#)

[IScaleFeatureData::IsUniform Property](#)

[IScaleFeatureData::ScaleUniform Property](#)

[IScaleFeatureData::ScaleX Property](#)

[IScaleFeatureData::ScaleY Property](#)

[IScaleFeatureData::ScaleZ Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IScaleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScaleFeatureData Interface](#) : Type Property (IScaleFeatureData)

Gets or sets the scale type.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IScaleFeatureData
```

```
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of scale as defined in [swScaleType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ScaleFeatureData::Type](#).

Example

See [IScaleFeatureData](#) examples.

See Also

[IScaleFeatureData Interface](#)
[IScaleFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IScrewMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IScrewMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IScrewMateFeatureData Interface

Allows access to a screw mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IScrewMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As IScrewMateFeatureData
```

C#

```
public interface IScrewMateFeatureData
```

C++/CLI

```
public interface class IScrewMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData](#).

Example

`VBA

` *****

` 1. Open *public_documents\samples\tutorial\api\MechanicalMates\Gearbox.sldasm*.

` 2. Delete Screw2 from the Mates folder of the FeatureManager design tree.

` 3. Run the macro.

` 4. Inspect the Mates folder in the FeatureManager design tree.

` *****

```
Dim swApp As SldWorks.SldWorks
```

```
Dim Part As SldWorks.ModelDoc2
```

```
Dim boolstatus As Boolean
```

```
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
```

```
    Set Part = swApp.ActiveDoc
```

```
    boolstatus = Part.Extension.SelectByRay(6.13295661213442E-03, 6.89560082602441E-02, 7.45357419147012E-02,  
-0.540837135649095, -0.258416475165147, -0.800447448659875, 7.89884801245894E-04, 2, True, 1, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(-6.75539884355203E-04, 7.95322044607474E-02, 1.28285894949158E-02,  
-0.540837135649095, -0.258416475165147, -0.800447448659875, 7.89884801245894E-04, 1, True, 1, 0)
```

```
    ' Create ScrewMateFeatureData
```

```
    Dim MateData As SldWorks.ScrewMateFeatureData
```

```
    Set MateData = Part.CreateMateData(17)
```

```
    ' Set the entities To mate
```

```
    Dim EntitiesToMate(1) As Object
```

```
    Set EntitiesToMate(0) = Part.SelectionManager.GetSelectedObject6(1, -1)
```

```
    Set EntitiesToMate(1) = Part.SelectionManager.GetSelectedObject6(2, -1)
```

```
    Dim EntitiesToMateVar As Variant
```

```
    EntitiesToMateVar = EntitiesToMate
```

```
    MateData.EntitiesToMate = (EntitiesToMateVar)
```

```
    ' Set the mate revolution type
```

```
    MateData.RevolutionType = 0
```

```
' Set the mate revolution value
MateData.RevolutionVal = 1

' Set the mate orientation direction
MateData.Reverse = True

' Create the mate
Dim MateFeature As SldWorks.Feature
Set MateFeature = Part.CreateMate(MateData)
Part.ClearSelection2 True
Part.EditRebuild3

End Sub
```

Example

[Create Screw Mate \(C#\)](#)

Remarks

A screw mate consists of two components, where:

- Components are concentric.
- Translation of one component along the axis causes rotation of the other component according to a pitch relationship.
- Rotation of one component causes translation of the other component.

[IMateFeatureData](#) is the parent of this mate interface.

To create a screw mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IScrewMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectById2](#) to pre-select the entities using Mark = 1.
3. Specify other properties of the ScrewMateFeatureData object, as required.

To edit a screw mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a ScrewMateFeatureData object.
3. Modify the ScrewMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this screw mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[ScrewMateFeatureData](#)

See Also

[IScrewMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IScrewMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IScrewMateFeatureData Interface

The following tables list the members exposed by [IScrewMateFeatureData](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this screw mate feature.
 MateAlignment	Gets or sets the alignment of this screw mate.
 Reverse	Gets or sets whether to change the direction of movement of the components relative to one another.
 RevolutionType	Gets or sets the type of revolution to specify for this screw mate.
 RevolutionVal	Gets or sets either the number of revolutions one component makes for each unit length that the other component translates or the distance that one component translates for each revolution of the other component.

[Top](#)

See Also

[IScrewMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IScrewMateFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IScrewMateFeatureData Interface

For a list of all members of this type, see [IScrewMateFeatureData members](#).

Public Properties

Name	Description
 EntitiesToMate	Gets or sets the entities to mate in this screw mate feature.
 MateAlignment	Gets or sets the alignment of this screw mate.
 Reverse	Gets or sets whether to change the direction of movement of the components relative to one another.
 RevolutionType	Gets or sets the type of revolution to specify for this screw mate.
 RevolutionVal	Gets or sets either the number of revolutions one component makes for each unit length that the other component translates or the distance that one component translates for each revolution of the other component.

[Top](#)

See Also

[IScrewMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

EntitiesToMate Property (IScrewMateFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IScrewMateFeatureData Interface](#) : EntitiesToMate Property (IScrewMateFeatureData)

Gets or sets the entities to mate in this screw mate feature.

.NET Syntax

Visual Basic (Declaration)

```
Property EntitiesToMate As System.Object
```

Visual Basic (Usage)

```
Dim instance As IScrewMateFeatureData  
Dim value As System.Object  
  
instance.EntitiesToMate = value  
  
value = instance.EntitiesToMate
```

C#

```
System.object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of two cylindrical [faces](#) of the two components to mate (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData::EntitiesToMate](#).

Example

See the [IScrewMateFeatureData](#) example.

Remarks

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1 for each entity. You can pre-select mate entities during mate creation, but not during mate editing.

See Also

[IScrewMateFeatureData Interface](#)
[IScrewMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (IScrewMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScrewMateFeatureData Interface](#) : MateAlignment Property (IScrewMateFeatureData)

Gets or sets the alignment of this screw mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IScrewMateFeatureData  
Dim value As System.Integer  
  
instance.MateAlignment = value  
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData::MateAlignment](#).

See Also

[IScrewMateFeatureData Interface](#)
[IScrewMateFeatureData Members](#)

Availability

Reverse Property (IScrewMateFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IScrewMateFeatureData Interface](#) : Reverse Property (IScrewMateFeatureData)

Gets or sets whether to change the direction of movement of the components relative to one another.

.NET Syntax

Visual Basic (Declaration)

Property Reverse As System.Boolean

Visual Basic (Usage)



```
Dim instance As IScrewMateFeatureData
Dim value As System.Boolean
```

```
instance.Reverse = value
```

```
value = instance.Reverse
```

C#

```
System.bool Reverse {get; set;}
```

C++/CLI

```
property System.bool Reverse {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of movement of the components, false to not

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData.Reverse](#).

Example

See the [IScrewMateFeatureData](#) example.

See Also

[IScrewMateFeatureData Interface](#)
[IScrewMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

RevolutionType Property (IScrewMateFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IScrewMateFeatureData Interface](#) : RevolutionType Property (IScrewMateFeatureData)

Gets or sets the type of revolution to specify for this screw mate.

.NET Syntax

Visual Basic (Declaration)

Property RevolutionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IScrewMateFeatureData
Dim value As System.Integer

instance.RevolutionType = value

value = instance.RevolutionType
```

C#

```
System.int RevolutionType {get; set;}
```

C++/CLI

```
property System.int RevolutionType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of revolution as defined in [swScrewMateDistanceOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData::RevolutionType](#).

Example

See the [IScrewMateFeatureData](#) example.

Remarks

If you set this property to swScrewMateDistanceOptions_e:

- swDistancePerRevolution, then specify [IScrewMateFeatureData::RevolutionVal](#) with the distance that one component translates for each revolution of the other component.
- swRevolutionsPerUnitLength, then specify [IScrewMateFeatureData::RevolutionVal](#) with the number of revolutions of one component for each unit length that the other component translates.

See Also

[IScrewMateFeatureData Interface](#)
[IScrewMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevolutionVal Property (IScrewMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IScrewMateFeatureData Interface](#) : RevolutionVal Property (IScrewMateFeatureData)

Gets or sets either the number of revolutions one component makes for each unit length that the other component translates or the distance that one component translates for each revolution of the other component.

.NET Syntax

Visual Basic (Declaration)

```
Property RevolutionVal As System.Double
```

Visual Basic (Usage)

```
Dim instance As IScrewMateFeatureData  
Dim value As System.Double  
  
instance.RevolutionVal = value  
  
value = instance.RevolutionVal
```

C#

```
System.double RevolutionVal {get; set;}
```

C++/CLI

```
property System.double RevolutionVal {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Revolution value (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ScrewMateFeatureData::RevolutionVal](#).

Example

See the [IScrewMateFeatureData](#) example.

Remarks

If [IScrewMateFeatureData::RevolutionType](#) is set to [swScrewMateDistanceOptions_e](#):

- [swDistancePerRevolution](#), then specify this property with the distance that one component translates for each revolution of the other component.
- [swRevolutionsPerUnitLength](#), then specify this property with the number of revolutions of one component for each unit length that the other component translates. Set [swUserPreferencesIntegerValue_e](#).swUnitsLinear to a unit length as defined in [swLengthUnit_e](#).

See Also

[IScrewMateFeatureData Interface](#)
[IScrewMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

ISecondaryMemberBetweenPointsFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberBetweenPointsFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberBetweenPointsFeatureData Interface

Allows access to a secondary structure system member that is created between the end points on primary structure system member pairs.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISecondaryMemberBetweenPointsFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData
```

C#

```
public interface ISecondaryMemberBetweenPointsFeatureData
```

C++/CLI

```
public interface class ISecondaryMemberBetweenPointsFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData](#).

Example

'VBA

'This example demonstrates how to add these secondary structure system members to a primary structure system:

- ' - Between points
- ' - On plane
- ' - Up to members

'=====

'Preconditions:

- '1. Ensure the specified part template exists.
- '2. Open an Immediate window.
- '3. Press F5.

'

'Postconditions:

- '1. Creates **Sketch1** containing two sketch segments.
- '2. Configures the start/end extensions and the member profile.
- '3. Selects the two sketch segments.
- '4. Creates primary **Structure System1** with two primary path segment members (**Member1** and **Member2**).
- '5. Inspect the structure system in the graphics area.
- '6. Press F5 to add a secondary support plane member.
- ' Creates secondary **Structure System2 (Member3)**.
- '7. Press F5 to edit the support plane member.
- '8. Press F5 to add a secondary between points member.
- ' Creates secondary **Structure System3 (Member4)**.
- '9. Press F5 to edit the between points member.
- '10. Press F5 to add a secondary structure system up to member.
- '11. When the macro stops, multi-select a Member1 vertex
- ' in the graphics area and Member2 in the FeatureManager Design tree.
- '12. Press F5 to create secondary Structure System4 (Member5).
- '13. Inspect the Immediate window.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim modDoc As SldWorks.ModelDoc2
Dim swFeatMgr As SldWorks.FeatureManager
Dim swSelMgr As SldWorks.SelectionMgr
```

```

Dim modDocExt As SldWorks.ModelDocExtension
Dim structMemDef As SldWorks.StructureSystemMemberFeatureData
Dim profDef As SldWorks.StructureSystemMemberProfile
Dim PrimDef As SldWorks.PrimaryStructuralMemberFeatureData
Dim memPathSegDef As PrimaryMemberPathSegmentFeatureData
Dim memBetweenPointsSecDef As SldWorks.SecondaryMemberBetweenPointsFeatureData
Dim secMemDatTochange As SldWorks.SecondaryMemberBetweenPointsFeatureData
Dim memSupportPlaneSecDef As SldWorks.SecondaryMemberSupportPlaneFeatureData
Dim segments(2) As Object
Dim stat As Boolean
Dim memData(0) As SldWorks.StructureSystemMemberFeatureData
Dim memDataArray As Variant
Dim structSys As SldWorks.Feature
Dim baseSecondarySystem As SldWorks.StructureSystemFolder
Dim structSysDef As SldWorks.StructureSystemFolder
Dim structSysSecDef As SldWorks.StructureSystemFolder
Dim feat As SldWorks.Feature
Dim structSysModDef As SldWorks.StructureSystemFolder
Dim outProfiles As Variant
Dim MemberData As SldWorks.StructureSystemMemberFeatureData
Dim memberArray As Variant
Dim profileGrpFeat As SldWorks.Feature
Dim profileGrp As SldWorks.ProfileGroupFolder
Dim memTochange As SldWorks.StructureSystemMemberFeatureData
Dim i As Long
Dim j As Long
Dim secDef As SldWorks.SecondaryStructuralMemberFeatureData
Dim UpToMemDef As SldWorks.SecondaryMemberUpToMembersFeatureData
Dim point As Object
Dim Members(0) As Object

```

Option Explicit

Sub main()

```

    Set swApp = Application.SldWorks

    Dim swSheetWidth As Double
    swSheetWidth = 0
    Dim swSheetHeight As Double
    swSheetHeight = 0
    Set modDoc = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS 2023\templates\Part.PRTDOT", 0, swSheetWidth,
swSheetHeight)

    Set modDocExt = modDoc.Extension

    modDoc.SketchManager.InsertSketch True
    stat = modDocExt.SelectByID2("Front Plane", "PLANE", -0.077188654347454, 0.054268560279924, 3.86214196026222E-03, False, 0,
Nothing, 0)
    modDoc.ClearSelection2 True

    Dim skSegment As Object
    Set skSegment = modDoc.SketchManager.CreateLine(-0.168061, 0.084736, 0#, -0.168061, -0.077684, 0#)
    Set skSegment = modDoc.SketchManager.CreateLine(0.075216, 0.107771, 0#, 0.075216, -0.006699, 0#)
    modDoc.ClearSelection2 True

    stat = modDocExt.SelectByID2("Top Plane", "PLANE", 0, 0, 0, True, 0, Nothing, 0)
    Dim myRefPlane As SldWorks.RefPlane
    Set myRefPlane = modDoc.FeatureManager.InsertRefPlane(8, 0.03, 0, 0, 0, 0)
    modDoc.ClearSelection2 True
    stat = modDocExt.SelectByID2("Top Plane", "PLANE", 0, 0, 0, False, 0, Nothing, 0)
    modDoc.ClearSelection2 True
    modDoc.SketchManager.InsertSketch True

    stat = modDocExt.SelectByID2("Line1@Sketch1", "EXTSKETCHSEGMENT", -0.168061313304597, 5.44142573846353E-02, 0, False, 0,
Nothing, 0)
    stat = modDocExt.SelectByID2("Line2@Sketch1", "EXTSKETCHSEGMENT", 7.52162521083513E-02, 5.32390034454423E-02, 0, True, 0,
Nothing, 0)

    'Create primary structure system path segment members
    Set structMemDef = modDocExt.CreateStructureSystemMemberData(0)
    Debug.Print "Type of structure system member as defined by swStructureSystemMemberType_e: " &
structMemDef.StructureSystemMemberType

    structMemDef.StartEndExtendD1 = 1#
    structMemDef.StartEndExtendD2 = 2#

    Set profDef = structMemDef.MemberProfile

    profDef.ProfileStandard = "ansi inch"

```

```

profDef.ProfileType = "c channel"
profDef.ProfileSize = "3 x 5"

Set PrimDef = structMemDef
Debug.Print "Structure system primary member creation type as defined by swStructureSystemMemberCreationType_e: " &
PrimDef.PrimaryMemberType

Set memPathSegDef = PrimDef
memPathSegDef.MergeTangentMembers = True

Set swSelMgr = modDoc.SelectionManager

Dim segments(1) As Object
Set segments(0) = swSelMgr.GetSelectedObject6(1, 0)
Set segments(1) = swSelMgr.GetSelectedObject6(2, 0)

stat = memPathSegDef.SetPathSegments(segments)
Debug.Print "Path segments successfully set: " & stat

Dim PrimMemData(0) As SldWorks.StructureSystemMemberFeatureData
Set PrimMemData(0) = structMemDef

Dim PrimMemDatArray As Variant
PrimMemDatArray = PrimMemData

Dim structSysFeat As SldWorks.Feature
Set structSysFeat = modDocExt.CreateStructureSystem(PrimMemDatArray, Nothing)

modDoc.ViewZoomtofit

Stop

Set structSysDef = structSysFeat.GetSpecificFeature2
Debug.Print "Number of profile group folders: " & structSysDef.GetProfileGroupFoldersCount

Dim outProfiles As Variant
outProfiles = structSysDef.GetProfileGroupFolders()

Dim memberArray As Variant

If (Not IsEmpty(outProfiles)) Then
    For I = 0 To UBound(outProfiles)
        Set profileGrpFeat = outProfiles(I)
        Set profileGrp = profileGrpFeat.GetSpecificFeature2
        If Not profileGrp Is Nothing Then
            Debug.Print "Number of members in profile group: " & profileGrp.GetStructureSystemMemberCount
            memberArray = profileGrp.GetStructureSystemMembers()
            If (Not IsEmpty(memberArray)) Then
                Exit For
            End If
        End If
    Next
End If

'Create secondary structure system support plane member

Dim structSecMemDef As SldWorks.StructureSystemMemberFeatureData
Set structSecMemDef = modDocExt.CreateStructureSystemMemberData(4) 'Secondary Support Plane

Debug.Print "Type of structure system member as defined by swStructureSystemMemberType_e: " &
structMemDef.StructureSystemMemberType

structSecMemDef.StartEndExtendD1 = 0.5
structSecMemDef.StartEndExtendD2 = 0.5

Dim secProfDef As SldWorks.StructureSystemMemberProfile
Set secProfDef = structSecMemDef.MemberProfile

secProfDef.ProfileStandard = "ansi inch"
secProfDef.ProfileType = "c channel"
secProfDef.ProfileSize = "3 x 5"

Dim SecDef As SecondaryStructuralMemberFeatureData
Set SecDef = structSecMemDef
Debug.Print "Structure system secondary member creation type as defined by swStructureSystemMemberCreationType_e: " &
SecDef.SecondaryMemberType; ""

Set memSupportPlaneSecDef = SecDef

stat = memSupportPlaneSecDef.SetMemberPairs(memberArray)

```

```

Debug.Print "Member pairs set successfully: " & stat

stat = modDocExt.SelectByID2("Plane1", "PLANE", 0, 0, 0, True, 0, Nothing, 0)
Dim Planes(0) As Object
Set Planes(0) = swSelMgr.GetSelectedObject6(1, 0)

stat = memSupportPlaneSecDef.SetIntersectingPlanesAndFaces(Planes)
Debug.Print "Intersecting plane set successfully: " & stat

Dim secMemData(0) As SldWorks.StructureSystemMemberFeatureData
Set secMemData(0) = structSecMemDef

Dim secMemDatArray As Variant
secMemDatArray = secMemData

Dim structSysFeat2 As SldWorks.Feature
Set structSysFeat2 = modDocExt.CreateStructureSystem(Nothing, secMemDatArray)

modDoc.ViewZoomtofit

Stop

'Edit secondary support plane member by changing start/end extensions

Set baseSecondarySystem = structSysFeat2.GetSpecificFeature2
Debug.Print "Number of profile group folders: " & baseSecondarySystem.GetProfileGroupFoldersCount

outProfiles = baseSecondarySystem.GetProfileGroupFolders()

Dim secMemberData As Object
Dim SecMemberArray As Variant
Dim secProfileGrpFeat As SldWorks.Feature
Dim secProfileGrp As SldWorks.ProfileGroupFolder
If (Not IsEmpty(outProfiles)) Then
    For I = 0 To UBound(outProfiles)
        Set secProfileGrpFeat = outProfiles(I)
        Set secProfileGrp = secProfileGrpFeat.GetSpecificFeature2
        If Not secProfileGrp Is Nothing Then
            Debug.Print "Number of members in profile group: " & secProfileGrp.GetStructureSystemMemberCount
            SecMemberArray = secProfileGrp.GetStructureSystemMembers()
            If (Not IsEmpty(SecMemberArray)) Then
                For j = 0 To UBound(SecMemberArray)
                    Set secMemberData = SecMemberArray(j)
                    Exit For
                Next
            End If
        End If
    Next
End If

Dim memTochange As SldWorks.StructureSystemMemberFeatureData
Set memTochange = secMemberData
Dim SecMemFeat As SldWorks.Feature
Set SecMemFeat = memTochange.GetFeature()
memTochange.StartEndExtendD1 = 0.2
memTochange.StartEndExtendD2 = 0.1

stat = SecMemFeat.ModifyDefinition(secMemberData, modDoc, Nothing)

Stop

'Create secondary between points member

Set structSecMemDef = modDocExt.CreateStructureSystemMemberData(5)
Debug.Print "Type of structure system member as defined by swStructureSystemMemberType_e: " &
structMemDef.StructureSystemMemberType

Set secProfDef = structSecMemDef.MemberProfile

secProfDef.ProfileStandard = "ansi inch"
secProfDef.ProfileType = "c channel"
secProfDef.ProfileSize = "3 x 5"

Set SecDef = structSecMemDef
Debug.Print "Structure system secondary member creation type as defined by swStructureSystemMemberCreationType_e: " &
SecDef.SecondaryMemberType

Set memBetweenPointsSecDef = SecDef

stat = memBetweenPointsSecDef.SetMemberPairs(memberArray)
Debug.Print "Member pairs successfully set: " & stat

```

```

memBetweenPointsSecDef.SecondaryMemberOffsetType = 0
memBetweenPointsSecDef.DistanceMember1 = 0.5
memBetweenPointsSecDef.DistanceMember2 = 0.4
memBetweenPointsSecDef.RevDirectionDistanceMember1 = False
memBetweenPointsSecDef.RevDirectionDistanceMember2 = False

Set secMemData(0) = structSecMemDef

secMemDatArray = secMemData

Set structSysFeat2 = modDocExt.CreateStructureSystem(Nothing, secMemDatArray)

Stop

'Edit between points member by changing start/end extensions and offset type

Set structSysSecDef = structSysFeat2.GetSpecificFeature2
Debug.Print "Number of profile group folders: " & structSysSecDef.GetProfileGroupFoldersCount

Dim outSecProfiles As Variant
outSecProfiles = structSysSecDef.GetProfileGroupFolders()

If (Not IsEmpty(outSecProfiles)) Then
    For I = 0 To UBound(outSecProfiles)
        Set secProfileGrpFeat = outSecProfiles(I)
        Set secProfileGrp = secProfileGrpFeat.GetSpecificFeature2
        If Not secProfileGrp Is Nothing Then
            Debug.Print "Number of members in profile group: " & secProfileGrp.GetStructureSystemMemberCount
            SecMemberArray = secProfileGrp.GetStructureSystemMembers()
            If (Not IsEmpty(SecMemberArray)) Then
                For j = 0 To UBound(SecMemberArray)
                    Set secMemberData = SecMemberArray(j)
                Next
            End If
        End If
    Next
End If

Set memTochange = secMemberData

Set SecMemFeat = memTochange.GetFeature()
memTochange.StartEndExtendD1 = 0.2
memTochange.StartEndExtendD2 = 0.1

Set secMemDatTochange = memTochange
secMemDatTochange.SecondaryMemberOffsetType = 1
secMemDatTochange.LengthRatioMember1 = 0.1
secMemDatTochange.LengthRatioMember2 = 0.2
stat = SecMemFeat.ModifyDefinition(secMemberData, modDoc, Nothing)

'Create secondary structure system up to member

Set structMemDef = modDocExt.CreateStructureSystemMemberData(6)

Debug.Print "Structure system member type as defined by swStructureSystemMemberType_e: " &
structMemDef.StructureSystemMemberType

structMemDef.StartEndExtendD1 = 0#
Debug.Print "Start/end direction 1: " & structMemDef.StartEndExtendD1
structMemDef.StartEndExtendD2 = 0#
Debug.Print "Start/end direction 2: " & structMemDef.StartEndExtendD2

Set profDef = structMemDef.MemberProfile

profDef.ProfileStandard = "ansi inch"
profDef.ProfileType = "pipe"
profDef.ProfileSize = "0.5 sch 40"

Set secDef = structMemDef
Debug.Print "Secondary member type as defined by swStructureSystemMemberCreationType_e: " & secDef.SecondaryMemberType

Set UpToMemDef = secDef

UpToMemDef.MemberPointParametersType =
swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_FromPoint

Stop 'Multi-select a Member1 vertex in the graphics area and Member2 in the FeatureManager Design tree

Set point = swSelMgr.GetSelectedObject6(1, 0)
Set Members(0) = swSelMgr.GetSelectedObject6(2, 0)

```

```
Call UpToMemDef.SetFromPoint(point)
UpToMemDef.SetFromPointMembers(Members)

UpToMemDef.SecondaryMemberOffsetType = swSecondaryMemberUpToMembersDistanceFromEndType_Distance
UpToMemDef.DistanceMember = 0.1
UpToMemDef.RevDirectionDistanceMember = False

Set memData(0) = structMemDef
memDataArray = memData

Dim structSysFeat3 As SldWorks.Feature
Set structSysFeat3 = modDocExt.CreateStructureSystem(Nothing, memDataArray)

End Sub
```

 Example

[Create Secondary Structure System Members \(VB.NET\)](#)
[Create Secondary Structure System Members \(C#\)](#)

 Remarks

See the [IStructureSystemFolder](#) Remarks.

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Secondary Member PropertyManager** topic.

 Accessors

Cast [ISecondaryStructuralMemberFeatureData](#) or [IStructureSystemMemberFeatureData](#) to this interface.

 Access Diagram

[SecondaryMemberBetweenPointsFeatureData](#)

 See Also

[ISecondaryMemberBetweenPointsFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISecondaryMemberBetweenPointsFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberBetweenPointsFeatureData Interface

The following tables list the members exposed by [ISecondaryMemberBetweenPointsFeatureData](#).

 Public Properties

Name	Description
 DistanceMember1	Gets and sets the offset from the end of the first member of the primary structure system member pair.
 DistanceMember2	Gets and sets the offset from the end of the second member of the primary structure system member pair.
 LengthRatioMember1	Gets and sets the length ratio offset from the end of the first member of the primary structure system member pair.
 LengthRatioMember2	Gets and sets the length ratio offset from the end of the second member of the primary structure system member pair.
 RevDirectionDistanceMember1	Gets and sets whether to reverse the direction of the offset for the first member of the primary structure system member pair.
 RevDirectionDistanceMember2	Gets and sets whether to reverse the direction of the offset for the second member of the primary structure system member pair.
 RevDirectionLengthRatioMember1	Gets and sets whether to reverse the direction of the length ratio offset for the first member of the primary structure system member pair.
 RevDirectionLengthRatioMember2	Gets and sets whether to reverse the direction of the length ratio offset for the second member of the primary structure system member pair.
 SecondaryMemberOffsetType	Gets and sets the offset type of this secondary structure system member.
 UnChainMemberPairs	Gets and sets whether to chain member pairs to create this secondary structure system member.

[Top](#)

Public Methods

Name	Description
 GetMemberPairs	Gets the primary structure system members that pair together to create this secondary structure system member.
 SetMemberPairs	Sets the primary structure system members that pair together to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberBetweenPointsFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberBetweenPointsFeatureData Interface

For a list of all members of this type, see [ISecondaryMemberBetweenPointsFeatureData members](#).

Public Methods

Name	Description
 GetMemberPairs	Gets the primary structure system members that pair together to create this secondary structure system member.
 SetMemberPairs	Sets the primary structure system members that pair together to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberBetweenPointsFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberBetweenPointsFeatureData Interface

For a list of all members of this type, see [ISecondaryMemberBetweenPointsFeatureData members](#).

Public Properties

Name	Description
 DistanceMember1	Gets and sets the offset from the end of the first member of the primary structure system member pair.
 DistanceMember2	Gets and sets the offset from the end of the second member of the primary structure system member pair.
 LengthRatioMember1	Gets and sets the length ratio offset from the end of the first member of the primary structure system member pair.
 LengthRatioMember2	Gets and sets the length ratio offset from the end of the second member of the primary structure system member pair.
 RevDirectionDistanceMember1	Gets and sets whether to reverse the direction of the offset for the first member of the primary structure system member pair.
 RevDirectionDistanceMember2	Gets and sets whether to reverse the direction of the offset for the second member of the primary structure system member pair.
 RevDirectionLengthRatioMember1	Gets and sets whether to reverse the direction of the length ratio offset for the first member of the primary structure system member pair.
 RevDirectionLengthRatioMember2	Gets and sets whether to reverse the direction of the length ratio offset for the second member of the primary structure system member pair.
 SecondaryMemberOffsetType	Gets and sets the offset type of this secondary structure system member.
 UnChainMemberPairs	Gets and sets whether to chain member pairs to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

DistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : DistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets the offset from the end of the first member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

Property DistanceMember1 As System.Double

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Double
```

```
instance.DistanceMember1 = value
```

```
value = instance.DistanceMember1
```

C#

```
System.double DistanceMember1 {get; set;}
```

C++/CLI

```
property System.double DistanceMember1 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Offset from end of first member <= length of Member 1

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::DistanceMember1](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e](#).swSecondaryMemberBetweenPointsDistanceFromEndType_Distance.

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

DistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : DistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets the offset from the end of the second member of the primary structure system member pair.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property DistanceMember2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Double  
  
instance.DistanceMember2 = value  
  
value = instance.DistanceMember2
```

C#

```
System.double DistanceMember2 {get; set;}
```

C++/CLI

```
property System.double DistanceMember2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Offset from end of second member <= length of Member 2

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData.DistanceMember2](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData.SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_Distance](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : GetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)

Gets the primary structure system members that pair together to create this secondary structure system member.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetMemberPairs() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Object  
  
value = instance.GetMemberPairs()
```

C#

```
System.Object GetMemberPairs()
```

C++/CLI

```
System.Object^ GetMemberPairs();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IStructureSystemMemberFeatureData](#)s

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::GetMemberPairs](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

LengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : LengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets the length ratio offset from the end of the first member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

```
Property LengthRatioMember1 As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Double  
  
instance.LengthRatioMember1 = value  
  
value = instance.LengthRatioMember1
```

C#

```
System.double LengthRatioMember1 {get; set;}
```

C++/CLI

```
property System.double LengthRatioMember1 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Length ratio offset from the end of the first member <= 1.0

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::LengthRatioMember1](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

LengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : LengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets the length ratio offset from the end of the second member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

Property LengthRatioMember2 As System.Double

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Double
```

```
instance.LengthRatioMember2 = value
```

```
value = instance.LengthRatioMember2
```

C#

```
System.double LengthRatioMember2 {get; set;}
```

C++/CLI

```
property System.double LengthRatioMember2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Length ratio offset from the end of the second member <= 1.0

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::LengthRatioMember2](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevDirectionDistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : RevDirectionDistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets whether to reverse the direction of the offset for the first member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

Property RevDirectionDistanceMember1 As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Boolean
```

```
instance.RevDirectionDistanceMember1 = value
```

```
value = instance.RevDirectionDistanceMember1
```

C#

```
System.bool RevDirectionDistanceMember1 {get; set;}
```

C++/CLI

```
property System.bool RevDirectionDistanceMember1 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the offset from the end of the first member, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::RevDirectionDistanceMember1](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_Distance](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevDirectionDistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : RevDirectionDistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets whether to reverse the direction of the offset for the second member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

Property RevDirectionDistanceMember2 As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Boolean
```

```
instance.RevDirectionDistanceMember2 = value
```

```
value = instance.RevDirectionDistanceMember2
```

C#

```
System.bool RevDirectionDistanceMember2 {get; set;}
```

C++/CLI

```
property System.bool RevDirectionDistanceMember2 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the offset from the end of the second member, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::RevDirectionDistanceMember2](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_Distance](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevDirectionLengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : RevDirectionLengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets whether to reverse the direction of the length ratio offset for the first member of the primary structure system member pair.

.NET Syntax

Visual Basic (Declaration)

Property RevDirectionLengthRatioMember1 As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData
Dim value As System.Boolean
```

```
instance.RevDirectionLengthRatioMember1 = value
```

```
value = instance.RevDirectionLengthRatioMember1
```

C#

```
System.bool RevDirectionLengthRatioMember1 {get; set;}
```

C++/CLI

```
property System.bool RevDirectionLengthRatioMember1 {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the length ratio offset from the end of the first member, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::RevDirectionLengthRatioMember1](#).

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevDirectionLengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : RevDirectionLengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets whether to reverse the direction of the length ratio offset for the second member of the primary structure system member pair.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property RevDirectionLengthRatioMember2 As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData
Dim value As System.Boolean

instance.RevDirectionLengthRatioMember2 = value
value = instance.RevDirectionLengthRatioMember2
```

C#

```
System.bool RevDirectionLengthRatioMember2 {get; set;}
```

C++/CLI

```
property System.bool RevDirectionLengthRatioMember2 {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the length ratio offset from the end of the second member, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::RevDirectionLengthRatioMember2](#).

Remarks

This property is valid only if [ISecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberBetweenPointsDistanceFromEndType_e.swSecondaryMemberBetweenPointsDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondaryMemberOffsetType Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : SecondaryMemberOffsetType Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets the offset type of this secondary structure system member.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property SecondaryMemberOffsetType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData
Dim value As System.Integer
```

```
instance.SecondaryMemberOffsetType = value  
value = instance.SecondaryMemberOffsetType
```

C#

```
System.int SecondaryMemberOffsetType {get; set;}
```

C++/CLI

```
property System.int SecondaryMemberOffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset type as defined by [swSecondaryMemberBetweenPointsDistanceFromEndType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::SecondaryMemberOffsetType](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : SetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)

Sets the primary structure system members that pair together to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMemberPairs( _  
    ByVal Pairs As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim Pairs As System.Object  
Dim value As System.Boolean  
  
value = instance.SetMemberPairs(Pairs)
```

C#

```
System.bool SetMemberPairs(  
    System.object Pairs  
)
```

C++/CLI

```
System.bool SetMemberPairs(  
& System.Object^ Pairs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Pairs
Array of [IStructureSystemMemberFeatureData](#)s

Return Value

True if member pairs successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberBetweenPointsFeatureData::SetMemberPairs](#).

Example

See the [SecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

During editing, Pairs can contain only two objects.

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnChainMemberPairs Property (ISecondaryMemberBetweenPointsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberBetweenPointsFeatureData Interface](#) : UnChainMemberPairs Property (ISecondaryMemberBetweenPointsFeatureData)

Gets and sets whether to chain member pairs to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Property UnChainMemberPairs As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberBetweenPointsFeatureData  
Dim value As System.Boolean
```

```
instance.UnChainMemberPairs = value
```

```
value = instance.UnChainMemberPairs
```

C#

```
System.bool UnChainMemberPairs {get; set;}
```

C++/CLI

```
property System.bool UnChainMemberPairs {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to pair each member passed in [ISecondaryMemberBetweenPointsFeatureData::SetMemberPairs](#) to the previous member passed, false to pair consecutive members only

Visual Basic for Applications (VBA) Syntax

See [ISecondaryMemberBetweenPointsFeatureData::UnChainMemberPairs](#).

Remarks

If this property is set to true, each primary member passed to [ISecondaryMemberBetweenPointsFeatureData::SetMemberPairs](#) pairs with the previous primary member to create a new member pair.

For the list of members A,B,C,D,E,F:

If this property is set to true, then 5 member pairs are created:

A -- B

B -- C

C -- D

D -- E

E -- F

If this property is set to false, then only 3 member pairs are created:

A -- B

C -- D

E -- F

See Also

[ISecondaryMemberBetweenPointsFeatureData Interface](#)
[ISecondaryMemberBetweenPointsFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

ISecondaryMemberSupportPlaneFeatureData (Type)

ISecondaryMemberSupportPlaneFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberSupportPlaneFeatureData Interface

Allows access to a secondary structure system member that is created on a plane between primary structure system member pairs.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISecondaryMemberSupportPlaneFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISecondaryMemberSupportPlaneFeatureData
```

C#

```
public interface ISecondaryMemberSupportPlaneFeatureData
```

C++/CLI

```
public interface class ISecondaryMemberSupportPlaneFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

See the [IStructureSystemFolder](#) Remarks.

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Secondary Member PropertyManager** topic.

Accessors

Cast [ISecondaryStructuralMemberFeatureData](#) or [IStructureSystemMemberFeatureData](#) to this interface.

Access Diagram

[SecondaryMemberSupportPlaneFeatureData](#)

See Also

[ISecondaryMemberSupportPlaneFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISecondaryMemberSupportPlaneFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberSupportPlaneFeatureData Interface

The following tables list the members exposed by [ISecondaryMemberSupportPlaneFeatureData](#).

Public Properties

Name	Description
 UnChainMemberPairs	Gets and sets whether to chain member pairs to create this secondary structure system member.

[Top](#)

Public Methods

Name	Description
 GetIntersectingObjectTypes	Gets the types of support plane entities used to create this secondary structure system member.
 GetIntersectingPlanesAndFaces	Gets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.
 GetMemberPairs	Gets the primary structure system members that pair together to create this secondary structure system member.
 SetIntersectingPlanesAndFaces	Sets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.
 SetMemberPairs	Sets the primary structure system members that pair together to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberSupportPlaneFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberSupportPlaneFeatureData Interface

For a list of all members of this type, see [ISecondaryMemberSupportPlaneFeatureData members](#).

Public Methods

Name	Description
 GetIntersectingObjectTypes	Gets the types of support plane entities used to create this secondary structure system member.
 GetIntersectingPlanesAndFaces	Gets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.
 GetMemberPairs	Gets the primary structure system members that pair together to create this secondary structure system member.
 SetIntersectingPlanesAndFaces	Sets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.
 SetMemberPairs	Sets the primary structure system members that pair together to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberSupportPlaneFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberSupportPlaneFeatureData Interface

For a list of all members of this type, see [ISecondaryMemberSupportPlaneFeatureData members](#).

Public Properties

Name	Description
 UnChainMemberPairs	Gets and sets whether to chain member pairs to create this secondary structure system member.

[Top](#)

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

GetIntersectingObjectTypes Method (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : GetIntersectingObjectTypes Method (ISecondaryMemberSupportPlaneFeatureData)

Gets the types of support plane entities used to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectingObjectTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData  
Dim value As System.Object
```

```
value = instance.GetIntersectingObjectTypes()
```

C#

```
System.object GetIntersectingObjectTypes()
```

C++/CLI

```
System.Object^ GetIntersectingObjectTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of entities as defined by swSelectType_e:

- swSelFACES
- swSelREFFACES
- swSelDATUMPLANES

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::GetIntersectingObjectTypes](#).

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[ISecondaryMemberSupportPlaneFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

GetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : GetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

Gets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectingPlanesAndFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData  
Dim value As System.Object
```

```
value = instance.GetIntersectingPlanesAndFaces()
```

C#

```
System.Object GetIntersectingPlanesAndFaces()
```

C++/CLI

```
System.Object^ GetIntersectingPlanesAndFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IRefPlanes](#), [ISurfaces](#), and/or [IFace2s](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::GetIntersectingPlanesAndFaces](#).

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[ISecondaryMemberSupportPlaneFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : GetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)

Gets the primary structure system members that pair together to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMemberPairs() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData  
Dim value As System.Object
```

```
value = instance.GetMemberPairs()
```

C#

```
System.Object GetMemberPairs()
```

C++/CLI

```
System.Object^ GetMemberPairs();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IStructureSystemMemberFeatureData](#)s

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::GetMemberPairs](#).

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[ISecondaryMemberSupportPlaneFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : SetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

Sets the planar entities that intersect the primary structure system member pairs used to create this secondary structure system member.

NET Syntax

Visual Basic (Declaration)

```
Function SetIntersectingPlanesAndFaces( _  
    ByVal RefArray As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData  
Dim RefArray As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetIntersectingPlanesAndFaces(RefArray)
```

C#

```
System.bool SetIntersectingPlanesAndFaces(  
    System.object RefArray  
)
```

C++/CLI

```
System.bool SetIntersectingPlanesAndFaces(  
& System.Object^ RefArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RefArray

Array of [IRefPlanes](#), [ISurfaces](#), and/or [IFace2s](#)

Return Value

True if intersecting planes and faces successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::SetIntersectingPlanesAndFaces](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

During editing, RefArray can hold only one entity.

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : SetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)

Sets the primary structure system members that pair together to create this secondary structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMemberPairs( _  
    ByVal Pairs As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData  
Dim Pairs As System.Object  
Dim value As System.Boolean  
  
value = instance.SetMemberPairs(Pairs)
```

C#

```
System.bool SetMemberPairs(  
    System.object Pairs  
)
```

C++/CLI

```
System.bool SetMemberPairs(  
& System.Object^ Pairs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Pairs

Array of [IStructureSystemMemberFeatureData](#)s

Return Value

True if member pairs successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::SetMemberPairs](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

During editing, the array can contain only two objects.

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnChainMemberPairs Property (ISecondaryMemberSupportPlaneFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberSupportPlaneFeatureData Interface](#) : UnChainMemberPairs Property (ISecondaryMemberSupportPlaneFeatureData)

Gets and sets whether to chain member pairs to create this secondary structure system member.

Visual Basic Syntax

Visual Basic (Declaration)

Property UnChainMemberPairs As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberSupportPlaneFeatureData
Dim value As System.Boolean
```

```
instance.UnChainMemberPairs = value
```

```
value = instance.UnChainMemberPairs
```

C#

```
System.bool UnChainMemberPairs {get; set;}
```

C++/CLI

```
property System.bool UnChainMemberPairs {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to pair each member passed in [ISecondaryMemberSupportPlaneFeatureData::SetMemberPairs](#) to the previous member passed, false to pair consecutive members only

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberSupportPlaneFeatureData::UnChainMemberPairs](#).

Remarks

If this property is set to true, each primary member passed to [ISecondaryMemberSupportPlaneFeatureData::SetMemberPairs](#) pairs with the previous primary member in the list to create a new member pair.

For the list of members A,B,C,D,E,F:

If this property is set to true, then 5 member pairs are created:

A -- B

B -- C

C -- D

D -- E

E -- F

If this property is set to false, then only 3 member pairs are created:

A -- B

C -- D

E -- F

See Also

[ISecondaryMemberSupportPlaneFeatureData Interface](#)
[ISecondaryMemberSupportPlaneFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30