

SOLIDWORKS API (.NET, VBA, C#) — Reference

(2471337):

ISecundaryMemberUpToMembersFeatureData-

ISecundaryStructuralMemberFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISecondaryMemberUpToMembersFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberUpToMembersFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberUpToMembersFeatureData Interface

Allows access to a secondary structure system up-to member that is created between a selected point and one or more primary structure system members or between one or more point-member pairs.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISecondaryMemberUpToMembersFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData
```

C#

```
public interface ISecondaryMemberUpToMembersFeatureData
```

C++/CLI

```
public interface class ISecondaryMemberUpToMembersFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Secondary Members > Creating Secondary Members with the Up to Members Method** topic.

Accessors

Cast [ISecondaryStructuralMemberFeatureData](#) or [IStructureSystemMemberFeatureData](#) to this interface.

Access Diagram

[SecondaryMemberUpToMembersFeatureData](#)

See Also

[ISecondaryMemberUpToMembersFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberUpToMembersFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberUpToMembersFeatureData Interface

The following tables list the members exposed by [ISecondaryMemberUpToMembersFeatureData](#).

Public Properties

Name	Description
DistanceMember	Gets or sets the distance with which to offset this secondary structure system up-to member.

[LengthRatioMember](#)

Gets or sets the length ratio with which to offset this secondary structure system up-to member.

[MemberPointParametersType](#)

Gets or sets the point parameter used to create this secondary structure system up-to member.

[RevDirectionDistanceMember](#)

Gets or sets whether to flip the direction of the distance offset for this secondary structure system up-to member.

[RevDirectionLengthRatioMember](#)

Gets or sets whether to flip the direction of the length ratio offset of this secondary structure system up-to member.

[SecondaryMemberOffsetType](#)

Gets or sets the distance from end type for this secondary structure system up-to member.

[Top](#)

Public Methods

Name	Description
 GetFromPoint	Gets the point from which to extend this secondary structure system up-to member.
 GetFromPointMembers	Gets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.
 GetPointMemberPairs	Gets the point-member pair(s) used to create one or more secondary structure system up-to members.
 SetFromPoint	Sets the point from which to extend this secondary structure system up-to member.
 SetFromPointMembers	Sets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.
 SetPointMemberPairs	Sets the point-member pair(s) used to create one or more secondary structure system up-to members.

[Top](#)

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberUpToMembersFeatureData Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberUpToMembersFeatureData InterfaceFor a list of all members of this type, see [ISecondaryMemberUpToMembersFeatureData members](#).

Public Methods

Name	Description
 GetFromPoint	Gets the point from which to extend this secondary structure system up-to member.
 GetFromPointMembers	Gets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.
 GetPointMemberPairs	Gets the point-member pair(s) used to create one or more secondary structure system up-to members.
 SetFromPoint	Sets the point from which to extend this secondary structure system up-to member.
 SetFromPointMembers	Sets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.
 SetPointMemberPairs	Sets the point-member pair(s) used to create one or more secondary structure system up-to members.

[Top](#)

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryMemberUpToMembersFeatureData Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryMemberUpToMembersFeatureData InterfaceFor a list of all members of this type, see [ISecondaryMemberUpToMembersFeatureData members](#).

Public Properties

Name	Description
DistanceMember	Gets or sets the distance with which to offset this secondary structure system up-to member.



[LengthRatioMember](#)

Gets or sets the length ratio with which to offset this secondary structure system up-to member.



[MemberPointParametersType](#)

Gets or sets the point parameter used to create this secondary structure system up-to member.



[RevDirectionDistanceMember](#)

Gets or sets whether to flip the direction of the distance offset for this secondary structure system up-to member.



[RevDirectionLengthRatioMember](#)

Gets or sets whether to flip the direction of the length ratio offset of this secondary structure system up-to member.



[SecondaryMemberOffsetType](#)

Gets or sets the distance from end type for this secondary structure system up-to member.

[Top](#)

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DistanceMember Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : DistanceMember Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets the distance with which to offset this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

Property DistanceMember As System.Double

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData
Dim value As System.Double

instance.DistanceMember = value

value = instance.DistanceMember
```

C#

```
System.double DistanceMember {get; set;}
```

C++/CLI

```
property System.double DistanceMember {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code.](#)

Property Value

Distance in meters

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::DistanceMember](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberUpToMembersFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberUpToMembersDistanceFromEndType_e.swSecondaryMemberUpToMembersDistanceFromEndType_Distance](#).

See Also

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFromPoint Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : GetFromPoint Method (ISecondaryMemberUpToMembersFeatureData)

Gets the point from which to extend this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFromPoint( _  
    ByRef Point As System.Object, _  
    ByRef PointType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim Point As System.Object  
Dim PointType As System.Integer  
  
instance.GetFromPoint(Point, PointType)
```

C#

```
void GetFromPoint(  
    out System.object Point,  
    out System.int PointType  
)
```

C++/CLI

```
void GetFromPoint(  
& [Out] System.Object^ Point,  
& [Out] System.int PointType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

[IVertex](#) or [ISketchPoint](#)

PointType

Type of Point as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::GetFromPoint](#).

Remarks

This method is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_FromPoint](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

GetFromPointMembers Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : GetFromPointMembers Method (ISecondaryMemberUpToMembersFeatureData)

Gets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFromPointMembers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim value As System.Object  
  
value = instance.GetFromPointMembers()
```

C#

```
System.object GetFromPointMembers()
```

C++/CLI

```
System.Object^ GetFromPointMembers();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IStructureSystemMemberFeatureDatas](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::GetFromPointMembers](#).

Remarks

This method is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_FromPoint](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

GetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : GetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData)

Gets the point-member pair(s) used to create one or more secondary structure system up-to members.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetPointMemberPairs( _  
    ByRef Points As System.Object, _  
    ByRef Members As System.Object, _  
    ByRef PointTypes As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim Points As System.Object  
Dim Members As System.Object  
Dim PointTypes As System.Object  
  
instance.GetPointMemberPairs(Points, Members, PointTypes)
```

C#

```
void GetPointMemberPairs(  
    out System.object Points,  
    out System.object Members,  
    out System.object PointTypes  
)
```

C++/CLI

```
void GetPointMemberPairs(  
& [Out] System.Object^ Points,  
& [Out] System.Object^ Members,  
& [Out] System.Object^ PointTypes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Points

Array of [Vertexes](#) or [ISketchPoints](#)

Members

Array of [IStructureSystemMemberFeatureData](#)s

PointTypes

Array of Points types as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::GetPointMemberPairs](#).

Remarks

Points and Members arrays are ordered to create point-member pairs.

This method is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_PointMemberPair](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)

[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

LengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : LengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets the length ratio with which to offset this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

Property LengthRatioMember As System.Double

Visual Basic (Usage)

```
Dim instance As ISecondaryMemberUpToMembersFeatureData
Dim value As System.Double

instance.LengthRatioMember = value
value = instance.LengthRatioMember
```

C#

```
System.double LengthRatioMember {get; set;}
```

C++/CLI

```
property System.double LengthRatioMember {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Length ratio <= 1.0

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData.LengthRatioMember](#).

Remarks

This property is valid only if [ISecondaryMemberUpToMembersFeatureData.SecondaryMemberOffsetType](#) is set to [swSecondaryMemberUpToMembersDistanceFromEndType_e.swSecondaryMemberUpToMembersDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

MemberPointParametersType Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : MemberPointParametersType Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets the point parameter used to create this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Property MemberPointParametersType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData
Dim value As System.Integer

instance.MemberPointParametersType = value
value = instance.MemberPointParametersType
```

C#

```
System.int MemberPointParametersType {get; set;}
```

C++/CLI

```
property System.int MemberPointParametersType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Point parameter as defined by [swSecondaryMemberUpToMembersMemberPointParameters_e](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

The setter of this method is valid only during creation. As in the user interface, you cannot change the member point parameters type after the secondary structure system member is created.

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic](#).

RevDirectionDistanceMember Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : RevDirectionDistanceMember Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets whether to flip the direction of the distance offset for this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Property RevDirectionDistanceMember As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData
Dim value As System.Boolean

instance.RevDirectionDistanceMember = value

value = instance.RevDirectionDistanceMember
```

C#

```
System.bool RevDirectionDistanceMember {get; set;}
```

C++/CLI

```
property System.bool RevDirectionDistanceMember {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the direction of the offset, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::RevDirectionDistanceMember](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberUpToMembersFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberUpToMembersDistanceFromEndType_e.swSecondaryMemberUpToMembersDistanceFromEndType_Distance](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

RevDirectionLengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : RevDirectionLengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets whether to flip the direction of the length ratio offset of this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Property RevDirectionLengthRatioMember As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim value As System.Boolean  
  
instance.RevDirectionLengthRatioMember = value  
  
value = instance.RevDirectionLengthRatioMember
```

C#

```
System.bool RevDirectionLengthRatioMember {get; set;}
```

C++/CLI

```
property System.bool RevDirectionLengthRatioMember {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the direction of the offset, false to not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::RevDirectionLengthRatioMember](#).

Remarks

This property is valid only if [ISecondaryMemberUpToMembersFeatureData::SecondaryMemberOffsetType](#) is set to [swSecondaryMemberUpToMembersDistanceFromEndType_e.swSecondaryMemberUpToMembersDistanceFromEndType_LengthRatio](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondaryMemberOffsetType Property (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : SecondaryMemberOffsetType Property (ISecondaryMemberUpToMembersFeatureData)

Gets or sets the distance from end type for this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Property SecondaryMemberOffsetType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim value As System.Integer  
  
instance.SecondaryMemberOffsetType = value  
  
value = instance.SecondaryMemberOffsetType
```

C#

```
System.int SecondaryMemberOffsetType {get; set;}
```

C++/CLI

```
property System.int SecondaryMemberOffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from end type as defined by [swSecondaryMemberUpToMembersDistanceFromEndType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::SecondaryMemberOffsetType](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFromPoint Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



Sets the point from which to extend this secondary structure system up-to member.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFromPoint( _  
    ByVal Point As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim Point As System.Object  
Dim value As System.Boolean  
  
value = instance.SetFromPoint(Point)
```

C#

```
System.bool SetFromPoint(  
    System.object Point  
)
```

C++/CLI

```
System.bool SetFromPoint(  
& System.Object^ Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point
[IVertex](#) or [ISketchPoint](#)

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::SetFromPoint](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This method is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_FromPoint](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SetFromPointMembers Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



Sets the structure system member(s) connected to a from point to create one or more secondary structure system up-to members.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFromPointMembers( _  
    ByVal Members As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim Members As System.Object  
Dim value As System.Boolean  
  
value = instance.SetFromPointMembers(Members)
```

C#

```
System.bool SetFromPointMembers(  
    System.object Members  
)
```

C++/CLI

```
System.bool SetFromPointMembers(  
& System.Object^ Members  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Members

Array of [IStructureSystemMemberFeatureData](#)s

Return Value

True if From point member successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::SetFromPointMembers](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This property is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_FromPoint](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)
[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic](#).

SetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryMemberUpToMembersFeatureData Interface](#) : SetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData)

Sets the point-member pair(s) used to create one or more secondary structure system up-to members.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPointMemberPairs( _  
    ByVal Points As System.Object, _
```

```
ByVal Members As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISecondaryMemberUpToMembersFeatureData  
Dim Points As System.Object  
Dim Members As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetPointMemberPairs(Points, Members)
```

C#

```
System.bool SetPointMemberPairs(  
    System.object Points,  
    System.object Members  
)
```

C++/CLI

```
System.bool SetPointMemberPairs(  
& System.Object^ Points,  
& System.Object^ Members  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Points

Array of [IVertexes](#) or [ISketchPoints](#)

Members

Array of [IStructureSystemMemberFeatureData](#)s

Visual Basic for Applications (VBA) Syntax

See [SecondaryMemberUpToMembersFeatureData::SetPointMemberPairs](#).

Remarks

Points and Members arrays must be ordered to create point-member pairs.

This method is valid only if [ISecondaryMemberUpToMembersFeatureData::MemberPointParametersType](#) is set to [swSecondaryMemberUpToMembersMemberPointParameters_e.swSecondaryMemberUpToMembersMemberPointParameters_PointMemberPair](#).

See Also

[ISecondaryMemberUpToMembersFeatureData Interface](#)

[ISecondaryMemberUpToMembersFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

ISecondaryStructuralMemberFeatureData (Type)

ISecondaryStructuralMemberFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryStructuralMemberFeatureData Interface

Allows access to a secondary structure system member.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISecondaryStructuralMemberFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISecondaryStructuralMemberFeatureData
```

C#

```
public interface ISecondaryStructuralMemberFeatureData
```

C++/CLI

```
public interface class ISecondaryStructuralMemberFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SecondaryStructuralMemberFeatureData](#).

Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This interface is a superclass of the following interfaces, i.e., you can cast this interface to either of the following:

- [ISecondaryMemberBetweenPointsFeatureData](#)
- [ISecondaryMemberSupportPlaneFeatureData](#)
- [ISecondaryMemberUpToMembersFeatureData](#)

See the [IStructureSystemFolder](#) Remarks.

Accessors

Cast [IStructureSystemMemberFeatureData](#) to this interface.

Access Diagram

[SecondaryStructuralMemberFeatureData](#)

See Also

[ISecondaryStructuralMemberFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISecondaryStructuralMemberFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISecondaryStructuralMemberFeatureData Interface

The following tables list the members exposed by [ISecondaryStructuralMemberFeatureData](#).

Public Properties

Name	Description
 SecondaryMemberType	Gets the type of this secondary structure system member.

[Top](#)

 See Also

[ISecondaryStructuralMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISecondaryStructuralMemberFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISecondaryStructuralMemberFeatureData Interface

For a list of all members of this type, see [ISecondaryStructuralMemberFeatureData members](#).

 Public Properties

Name	Description
 SecondaryMemberType	Gets the type of this secondary structure system member.

[Top](#)

 See Also

[ISecondaryStructuralMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondaryMemberType Property (ISecondaryStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISecondaryStructuralMemberFeatureData Interface](#) : SecondaryMemberType Property (ISecondaryStructuralMemberFeatureData)

Gets the type of this secondary structure system member.

 .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SecondaryMemberType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISecondaryStructuralMemberFeatureData  
Dim value As System.Integer  
  
value = instance.SecondaryMemberType
```

C#

```
System.int SecondaryMemberType {get;}
```

C++/CLI

```
property System.int SecondaryMemberType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Secondary structure system member type as defined by [swStructureSystemMemberCreationType_e](#)

 Visual Basic for Applications (VBA) Syntax

See [SecondaryStructuralMemberFeatureData::SecondaryMemberType](#).

 Example

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

 See Also

[ISecondaryStructuralMemberFeatureData Interface](#)
[ISecondaryStructuralMemberFeatureData Members](#)

 Availability

SOLIDWORKS 2022 FCS, Revision Number 30