

SOLIDWORKS API (.NET VBA C#) — Reference (248/337): ISectionViewData-ISelectData

SOLIDWORKS API Documentation (converted from CHM)

ISectionViewData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISectionViewData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISectionViewData Interface

Allows you to create and access section views in parts and assemblies.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISectionViewData
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
```

C#

```
public interface ISectionViewData
```

C++/CLI

```
public interface class ISectionViewData
```

Visual Basic for Applications (VBA) Syntax

See [SectionViewData](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)
[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

A section view is defined by multiple planes, colors, offsets, etc.

To create a section view in a part or assembly:

1. Use [IModelViewManager::CreateSectionViewData](#) to create the ISectionViewData object.
2. Set the properties of ISectionViewData.
3. Use [IModelViewManager::CreateSectionView](#) to create the section view. IModelViewManager::CreateSectionView returns whether it successfully created the section view; it does not return whether it successfully created valid section bodies. Set [ISectionViewData::Redraw](#) to true to have IModelViewManager::CreateSectionView validate and return a status for section bodies instead of section views.

Accessors

[IModelViewManager::CreateSectionViewData](#)

[IModelViewManager::GetSectionViewData](#)

Access Diagram

[SectionViewData](#)

See Also

ISectionViewData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISectionViewData Interface

The following tables list the members exposed by [ISectionViewData](#).

Public Properties

Name	Description
ExcludeSelectedItems	Gets or sets whether to exclude or include the specific bodies in the multibody part or specific components in the assembly in selective sectioning in this section view.
FirstColor	Gets or sets the first color of the section view in the part or assembly.
FirstOffset	Gets or sets the first offset distance of the section view for this part or assembly.
FirstPlane	Gets or sets the section plane for the first section of the section view for the part or assembly.
FirstReverseDirection	Gets or sets whether to reverse the first direction of the section view for this part or assembly.
FirstRotationX	Gets or sets the first x rotation of the section view in the part or assembly.
FirstRotationY	Gets or sets the first y rotation of the section view in the part or assembly.
GraphicsOnlySection	Gets or sets whether to generate a graphics-only section view.
KeepCapColor	Gets or sets whether to color the caps of section views.
Redraw	Gets or sets whether to have IModelViewManager.CreateSectionView validate and return a status for section bodies instead of section views.
SecondColor	Gets or sets the second color of the section view in the part or assembly.
SecondOffset	Gets or sets the second offset distance of the section view for this part or assembly.
SecondPlane	Gets or sets the section plane for the second section of the section view for the part or assembly.
SecondReverseDirection	Gets or sets whether to reverse the second direction of the section view for this part or assembly.
SecondRotationX	Gets or sets the second x rotation of the section view in the part or assembly.
SecondRotationY	Gets or sets the second y rotation of the section view in the part or assembly.
SectionedZones	Gets or sets the intersection zones that define how to section this section view.
SectionTransparentItemsTransparent	Gets or sets whether the specified sectioned bodies in the multibody part or the specified sectioned components in the assembly are transparently sectioned in this section view.
SelectiveSection	Gets or sets whether selective sectioning is enabled in this section view.
SelectiveSectioningList	Gets or sets the bodies in the multibody part or the components in the assembly for selective sectioning in this section view.
ShowSectionCap	Gets or sets whether to cap the section views.
ThirdColor	Gets or sets the third color of the section view in this part or assembly.
ThirdOffset	Gets or sets the third offset distance of the section view for this part or assembly.
ThirdPlane	Gets or sets the section plane for the third section of the section view for the part or assembly.
ThirdReverseDirection	Gets or sets whether to reverse the third direction of the section view for this part or assembly.
ThirdRotationX	Gets or sets the third x rotation of the section view in the part or assembly.
ThirdRotationY	Gets or sets the third y rotation of the section view in the part or assembly.
TransparencyList	Gets or sets the sectioned bodies in the multibody part or the sectioned components in the assembly to transparently section in this section view.
TransparencyValue	Gets or sets the level of transparency for the specified transparently sectioned bodies in the multibody part or the specified transparently sectioned components in the assembly in this section view.
TransparentSection	Gets or sets whether transparent sectioning is enabled in this section view.
ZonalSection	Gets or sets whether the section method is zonal or planar.

[Top](#)

Public Methods

Name	Description
 GetDynamicCenterTransform	Gets the translation between the center of the model and the plane in the specified section in this section view.
 GetFirstPlaneParameters	Gets the first transformed plane's parameters for this section view.
 GetSecondPlaneParameters	Gets the second transformed plane's parameters for this section view.
 GetThirdPlaneParameters	Gets the third transformed plane's parameters for this section view.

[Top](#)

 See Also

[ISectionViewData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrSection Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

ISectionViewData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISectionViewData Interface

For a list of all members of this type, see [ISectionViewData members](#).

 Public Methods

Name	Description
 GetDynamicCenterTransform	Gets the translation between the center of the model and the plane in the specified section in this section view.
 GetFirstPlaneParameters	Gets the first transformed plane's parameters for this section view.
 GetSecondPlaneParameters	Gets the second transformed plane's parameters for this section view.
 GetThirdPlaneParameters	Gets the third transformed plane's parameters for this section view.

[Top](#)

 See Also

[ISectionViewData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrSection Interface](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

ISectionViewData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISectionViewData Interface

For a list of all members of this type, see [ISectionViewData members](#).

 Public Properties

Name	Description
 ExcludeSelectedItems	Gets or sets whether to exclude or include the specific bodies in the multibody part or specific components in the assembly in selective sectioning in this section view.
 FirstColor	Gets or sets the first color of the section view in the part or assembly.
 FirstOffset	Gets or sets the first offset distance of the section view for this part or assembly.
 FirstPlane	Gets or sets the section plane for the first section of the section view for the part or assembly.
 FirstReverseDirection	Gets or sets whether to reverse the first direction of the section view for this part or assembly.
 FirstRotationX	Gets or sets the first x rotation of the section view in the part or assembly.
 FirstRotationY	Gets or sets the first y rotation of the section view in the part or assembly.
 GraphicsOnlySection	Gets or sets whether to generate a graphics-only section view.
 KeepCapColor	Gets or sets whether to color the caps of section views.
 Redraw	Gets or sets whether to have IModelViewManager.CreateSectionView validate and return a status for section bodies instead of section views.
 SecondColor	Gets or sets the second color of the section view in the part or assembly.
SecondOffset	Gets or sets the second offset distance of the section view for this part or assembly.

SecondPlane	Gets or sets the section plane for the second section of the section view for the part or assembly.
SecondReverseDirection	Gets or sets whether to reverse the second direction of the section view for this part or assembly.
SecondRotationX	Gets or sets the second x rotation of the section view in the part or assembly.
SecondRotationY	Gets or sets the second y rotation of the section view in the part or assembly.
SectionedZones	Gets or sets the intersection zones that define how to section this section view.
SectionTransparentItemsTransparent	Gets or sets whether the specified sectioned bodies in the multibody part or the specified sectioned components in the assembly are transparently sectioned in this section view.
SelectiveSection	Gets or sets whether selective sectioning is enabled in this section view.
SelectiveSectioningList	Gets or sets the bodies in the multibody part or the components in the assembly for selective sectioning in this section view.
ShowSectionCap	Gets or sets whether to cap the section views.
ThirdColor	Gets or sets the third color of the section view in this part or assembly.
ThirdOffset	Gets or sets the third offset distance of the section view for this part or assembly.
ThirdPlane	Gets or sets the section plane for the third section of the section view for the part or assembly.
ThirdReverseDirection	Gets or sets whether to reverse the third direction of the section view for this part or assembly.
ThirdRotationX	Gets or sets the third x rotation of the section view in the part or assembly.
ThirdRotationY	Gets or sets the third y rotation of the section view in the part or assembly.
TransparencyList	Gets or sets the sectioned bodies in the multibody part or the sectioned components in the assembly to transparently section in this section view.
TransparencyValue	Gets or sets the level of transparency for the specified transparently sectioned bodies in the multibody part or the specified transparently sectioned components in the assembly in this section view.
TransparentSection	Gets or sets whether transparent sectioning is enabled in this section view.
ZonalSection	Gets or sets whether the section method is zonal or planar.

[Top](#)

See Also

[ISectionViewData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrSection Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExcludeSelectedItems Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ExcludeSelectedItems Property (ISectionViewData)

Gets or sets whether to exclude or include the specific bodies in the multibody part or specific components in the assembly in selective sectioning in this section view.

.NET Syntax

Visual Basic (Declaration)

Property ExcludeSelectedItems As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean

instance.ExcludeSelectedItems = value

value = instance.ExcludeSelectedItems
```

C#

```
System.bool ExcludeSelectedItems {get; set;}
```

C++/CLI

```
property System.bool ExcludeSelectedItems {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to exclude specific bodies in the multibody part or specific components in the assembly in selective sectioning, false to include only the specific bodies in the part or the specific component in the assembly in selective sectioning (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ExcludeSelectedItems](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

Before calling this property, call [ISectionViewData::SelectiveSectioningList](#) to specify the bodies in the multibody part or the components in the assembly to exclude or include in selective sectioning.

ISectionViewData::ExcludeSelectedItems is only available if [ISectionViewData::SelectiveSection](#) is true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstColor Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstColor Property (ISectionViewData)

Gets or sets the first color of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property FirstColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Integer

instance.FirstColor = value

value = instance.FirstColor
```

C#

```
System.int FirstColor {get; set;}
```

C++/CLI

```
property System.int FirstColor {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value of the first color

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstColor](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

Use [ISectionViewData::ShowSectionCap](#) to display the caps of section views and [ISectionView::KeepCapColor](#) to color them.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::SecondColor Property](#)
[ISectionViewData::ThirdColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstOffset Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstOffset Property (ISectionViewData)

Gets or sets the first offset distance of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property FirstOffset As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.FirstOffset = value
```

```
value = instance.FirstOffset
```

C#

```
System.double FirstOffset {get; set;}
```

C++/CLI

```
property System.double FirstOffset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

First offset distance

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstOffset](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::SecondOffset Property](#)
[ISectionViewData::ThirdOffset Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FirstPlane Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstPlane Property (ISectionViewData)

Gets or sets the section plane for the first section of the section view for the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property FirstPlane As System.Object

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Object
```

```
instance.FirstPlane = value
```

```
value = instance.FirstPlane
```

C#

```
System.object FirstPlane {get; set;}
```

C++/CLI

```
property System.Object^ FirstPlane {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#) or [planar face](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstPlane](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

To select the section plane for the first section, specify 1 for Mark for [IModelDocExtension::SelectByID2](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::GetFirstPlaneParameters Method](#)
[ISectionViewData::GetSecondPlaneParameters Method](#)
[ISectionViewData::GetThirdPlaneParameters Method](#)
[ISectionViewData::SecondPlane Property](#)
[ISectionViewData::ThirdPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstReverseDirection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstReverseDirection Property (ISectionViewData)

Gets or sets whether to reverse the first direction of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property FirstReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Boolean  
  
instance.FirstReverseDirection = value  
  
value = instance.FirstReverseDirection
```

C#

```
System.bool FirstReverseDirection {get; set;}
```

C++/CLI

```
property System.bool FirstReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the first direction of the section view, false to not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstReverseDirection](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::SecondReverseDirection Property](#)
[ISectionViewData::ThirdReverseDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstRotationX Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstRotationX Property (ISectionViewData)

Gets or sets the first x rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property FirstRotationX As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Double
```

```
instance.FirstRotationX = value
```

```
value = instance.FirstRotationX
```

C#

```
System.double FirstRotationX {get; set;}
```

C++/CLI

```
property System.double FirstRotationX {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

First x rotation of the section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstRotationX](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationY Property](#)
[ISectionViewData::SecondRotationX Property](#)
[ISectionViewData::SecondRotationY Property](#)
[ISectionViewData::ThirdRotationX Property](#)
[ISectionViewData::ThirdRotationY Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FirstRotationY Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : FirstRotationY Property (ISectionViewData)

Gets or sets the first y rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property FirstRotationY As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.FirstRotationY = value
```

```
value = instance.FirstRotationY
```

C#

```
System.double FirstRotationY {get; set;}
```

C++/CLI

```
property System.double FirstRotationY {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

First y rotation of the section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::FirstRotationY](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationX Property](#)
[ISectionViewData::SecondRotationX Property](#)
[ISectionViewData::SecondRotationY Property](#)
[ISectionViewData::ThirdRotationX Property](#)
[ISectionViewData::ThirdRotationY Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDynamicCenterTransform Method (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : GetDynamicCenterTransform Method (ISectionViewData)

Gets the translation between the center of the model and the plane in the specified section in this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDynamicCenterTransform( _  
    ByVal Index As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim Index As System.Integer  
Dim value As MathTransform  
  
value = instance.GetDynamicCenterTransform(Index)
```

C#

```
MathTransform GetDynamicCenterTransform(  
    System.int Index  
)
```

C++/CLI

```
MathTransform^ GetDynamicCenterTransform(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Section (see **Remarks**)

Return Value

[Translation](#) between the center of the model and the plane in the section specified for Index

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::GetDynamicCenterTransform](#).

Example

[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

This method is only valid for section views having more than one section. Specify:

- 1 for Section 1
- 2 for Section 2
- 3 for Section 3

If the section view contains only one section and you specify 1 for Index, then this method returns Nothing or null.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2015 SP2, Revision Number 23.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstPlaneParameters Method (ISectionViewData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : GetFirstPlaneParameters Method (ISectionViewData)

Gets the first transformed plane's parameters for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFirstPlaneParameters( _  
    ByRef PlaneCenter As MathPoint, _  
    ByRef PlaneVector As MathVector _  
)
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim PlaneCenter As MathPoint  
Dim PlaneVector As MathVector  
  
instance.GetFirstPlaneParameters(PlaneCenter, PlaneVector)
```

C#

```
void GetFirstPlaneParameters(  
    out MathPoint PlaneCenter,  
    out MathVector PlaneVector  
)
```

C++/CLI

```
void GetFirstPlaneParameters(  
    & [Out] MathPoint^ PlaneCenter,  
    & [Out] MathVector^ PlaneVector  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PlaneCenter
[Plane center point](#)
PlaneVector
[Plane normal vector](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::GetFirstPlaneParameters](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::GetSecondPlaneParameters Method](#)
[ISectionViewData::GetThirdPlaneParameters Method](#)
[ISectionViewData::FirstPlane Property](#)
[ISectionViewData::SecondPlane Property](#)
[ISectionViewData::ThirdPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSecondPlaneParameters Method (ISectionViewData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : GetSecondPlaneParameters Method (ISectionViewData)

Gets the second transformed plane's parameters for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetSecondPlaneParameters( _  
    ByRef PlaneCenter As MathPoint, _  
    ByRef PlaneVector As MathVector _  
)
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim PlaneCenter As MathPoint  
Dim PlaneVector As MathVector  
  
instance.GetSecondPlaneParameters(PlaneCenter, PlaneVector)
```

C#

```
void GetSecondPlaneParameters(  
    out MathPoint PlaneCenter,  
    out MathVector PlaneVector  
)
```

C++/CLI

```
void GetSecondPlaneParameters(  
& [Out] MathPoint^ PlaneCenter,  
& [Out] MathVector^ PlaneVector  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PlaneCenter
[Plane center point](#)
PlaneVector
[Plane normal vector](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::GetSecondPlaneParameters](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::GetFirstPlaneParameters Method](#)
[ISectionViewData::GetThirdPlaneParameters Method](#)
[ISectionViewData::FirstPlane Property](#)
[ISectionViewData::SecondPlane Property](#)
[ISectionViewData::ThirdPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetThirdPlaneParameters Method (ISectionViewData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : GetThirdPlaneParameters Method (ISectionViewData)

Gets the third transformed plane's parameters for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetThirdPlaneParameters( _  
    ByRef PlaneCenter As MathPoint, _  
    ByRef PlaneVector As MathVector _  
)
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim PlaneCenter As MathPoint  
Dim PlaneVector As MathVector  
  
instance.GetThirdPlaneParameters(PlaneCenter, PlaneVector)
```

C#

```
void GetThirdPlaneParameters(  
    out MathPoint PlaneCenter,  
    out MathVector PlaneVector  
)
```

C++/CLI

```
void GetThirdPlaneParameters(  
& [Out] MathPoint^ PlaneCenter,  
& [Out] MathVector^ PlaneVector  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PlaneCenter
[Plane center point](#)
PlaneVector
[Plane normal vector](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::GetThirdPlaneParameters](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::GetFirstPlaneParameters Method](#)
[ISectionViewData::GetSecondPlaneParameters Method](#)
[ISectionViewData::FirstPlane Property](#)
[ISectionViewData::SecondPlane Property](#)
[ISectionViewData::ThirdPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GraphicsOnlySection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : GraphicsOnlySection Property (ISectionViewData)

Gets or sets whether to generate a graphics-only section view.

.NET Syntax

Visual Basic (Declaration)

```
Property GraphicsOnlySection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean

instance.GraphicsOnlySection = value
value = instance.GraphicsOnlySection
```

C#

```
System.bool GraphicsOnlySection {get; set;}
```

C++/CLI

```
property System.bool GraphicsOnlySection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to generate a graphics-only section view, false to not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::GraphicsOnlySection](#).

Example

[Create Section View in Model \(VBA\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(C#\)](#)

Remarks

This property corresponds to the **Graphics-only section** check box on the Section View PropertyManager page.

When a section view is created, the model is rebuilt. If the model is very large and complex, rebuilding the model slows down the creation of the section view. This property indicates whether to rebuild the model when a section view is created. When this property is set to true:

- **Keep cap color** check box is selected and inactivated on the Section View PropertyManager page.
- [ISectionViewData::KeepCapColor](#) returns only true; setting to false is ignored.
- Model is not rebuilt, and the section view is quickly generated.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepCapColor Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : KeepCapColor Property (ISectionViewData)

Gets or sets whether to color the caps of section views.

.NET Syntax

Property KeepCapColor As System.Boolean



```
Dim instance As ISectionViewData
Dim value As System.Boolean
```

```
instance.KeepCapColor = value
```

```
value = instance.KeepCapColor
```

```
System.bool KeepCapColor {get; set;}
```

```
property System.bool KeepCapColor {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to color the caps of section views, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::KeepCapColor](#).

Example

[Create Section View in Model \(VBA\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(C#\)](#)

Remarks

This property is valid only if [ISectionViewData::ShowSectionCap](#) is true and [ISectionViewData::GraphicsOnlySection](#) is false.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

Redraw Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : Redraw Property (ISectionViewData)

Gets or sets whether to have [IModelViewManager::CreateSectionView](#) validate and return a status for section bodies instead of section views.

.NET Syntax

Property Redraw As System.Boolean



```
Dim instance As ISectionViewData  
Dim value As System.Boolean
```

```
instance.Redraw = value
```

```
value = instance.Redraw
```

C#

```
System.bool Redraw {get; set;}
```

C++/CLI

```
property System.bool Redraw {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to validate and return a status for newly created section bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::Redraw](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)

Remarks

By default, [IModelViewManager::CreateSectionView](#) returns whether it successfully created a section view. Set this property to true to have [IModelViewManager::CreateSectionView](#) check and return whether it successfully created the section bodies.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondColor Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondColor Property (ISectionViewData)

Gets or sets the second color of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property SecondColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Integer  
  
instance.SecondColor = value
```

```
value = instance.SecondColor
```

C#

```
System.int SecondColor {get; set;}
```

C++/CLI

```
property System.int SecondColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value of the second color

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondColor](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

Use [ISectionViewData::ShowSectionCap](#) to display the caps of section views and [ISectionView::KeepCapColor](#) to color them.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstColor Property](#)
[ISectionViewData::ThirdColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondOffset Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondOffset Property (ISectionViewData)

Gets or sets the second offset distance of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property SecondOffset As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.SecondOffset = value
```

```
value = instance.SecondOffset
```

C#

```
System.double SecondOffset {get; set;}
```

C++/CLI

```
property System.double SecondOffset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Second offset distance

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondOffset](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstOffset Property](#)
[ISectionViewData::ThirdOffset Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SecondPlane Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondPlane Property (ISectionViewData)

Gets or sets the section plane for the second section of the section view for the part or assembly.

Visual Basic .NET Syntax

Visual Basic (Declaration)

```
Property SecondPlane As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Object
```

```
instance.SecondPlane = value
```

```
value = instance.SecondPlane
```

C#

```
System.object SecondPlane {get; set;}
```

C++/CLI

```
property System.Object^ SecondPlane {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#) or [planar face](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondPlane](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

To select the section plane for the second section, specify 2 for Mark for [IModelDocExtension::SelectById2](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstPlane Property](#)
[ISectionViewData::ThirdPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SecondReverseDirection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondReverseDirection Property (ISectionViewData)

Gets or sets whether to reverse the second direction of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property SecondReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Boolean
```

```
instance.SecondReverseDirection = value
```

```
value = instance.SecondReverseDirection
```

C#

```
System.bool SecondReverseDirection {get; set;}
```

C++/CLI

```
property System.bool SecondReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the second direction of the section view, false to not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondReverseDirection](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstReverseDirection Property](#)
[ISectionViewData::ThirdReverseDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SecondRotationX Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondRotationX Property (ISectionViewData)

Gets or sets the second x rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property SecondRotationX As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Double
```

```
instance.SecondRotationX = value
```

```
value = instance.SecondRotationX
```

C#

```
System.double SecondRotationX {get; set;}
```

C++/CLI

```
property System.double SecondRotationX {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Second x rotation of the section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondRotationX](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationX Property](#)
[ISectionViewData::FirstRotationY Property](#)
[ISectionViewData::SecondRotationY Property](#)
[ISectionViewData::ThirdRotationX Property](#)
[ISectionViewData::ThirdRotationY Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

[SOLIDWORKS API Help](#)

[Send comments](#) on this topic.

SecondRotationY Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SecondRotationY Property (ISectionViewData)

Gets or sets the second y rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property SecondRotationY As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Double
```

```
instance.SecondRotationY = value
```

```
value = instance.SecondRotationY
```

C#

```
System.double SecondRotationY {get; set;}
```

C++/CLI

```
property System.double SecondRotationY {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Second y rotation of the section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SecondRotationY](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)

[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationX Property](#)
[ISectionViewData::FirstRotationY Property](#)
[ISectionViewData::SecondRotationX Property](#)
[ISectionViewData::ThirdRotationX Property](#)
[ISectionViewData::ThirdRotationY Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SectionedZones Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SectionedZones Property (ISectionViewData)

Gets or sets the intersection zones that define how to section this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property SectionedZones As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Integer
```

```
instance.SectionedZones = value
```

```
value = instance.SectionedZones
```

C#

```
System.int SectionedZones {get; set;}
```

C++/CLI

```
property System.int SectionedZones {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Intersection zones as defined in [swZonalSectionViewZones_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SectionedZones](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

In the SOLIDWORKS API, zones are defined by the intersections of the sectioning planes. This table describes the intersection zones and the enumerators to which they correspond.

Number of sectioning planes	Zones	Intersection zones	swZonalSectionViewZones_e enumerators
1	1	Front side of sectioning plane 1	swZonalSectionViewZones_swZonalSectionViewZone_1
	2	Back side of sectioning plane 2	swZonalSectionViewZones_swZonalSectionViewZone_2
2	1	- Front side of sectioning plane 1 - Front side of sectioning plane 2	swZonalSectionViewZones_swZonalSectionViewZone_1
	2	- Back side of sectioning plane 1 - Front side of sectioning plane 2	swZonalSectionViewZones_swZonalSectionViewZone_2
	3	- Front side of sectioning plane 1 - Back side of sectioning plane 2	swZonalSectionViewZones_swZonalSectionViewZone_3
	4	- Back side of sectioning plane 1 - Back side of sectioning plane 2	swZonalSectionViewZones_swZonalSectionViewZone_4
3	1	- Front side of sectioning plane 1 - Front side of sectioning plane 2 - Front side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_1
	2	- Back side of sectioning plane 1 - Front side of sectioning plane 2 - Front side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_2
	3	- Front side of sectioning plane 1 - Back side of sectioning plane 2 - Front side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_3
	4	- Back side of sectioning plane 1 - Back side of sectioning plane 2 - Front side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_4
	5	- Front side of sectioning plane 1 - Front side of sectioning plane 2 - Back side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_5
	6	- Back side of sectioning plane 1 - Front side of sectioning plane 2 - Back side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_6
	7	- Front side of sectioning plane 1 - Back side of sectioning plane 2 - Back side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_7
	8	- Back side of sectioning plane 1 - Back side of sectioning plane 2 - Back side of sectioning plane 3	swZonalSectionViewZones_swZonalSectionViewZone_8

This property is only available if [ISectionViewData::ZonalSection](#) is true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SectionTransparentItemsTransparent Property (ISectionViewData)

[See Also](#)
[Example](#)



SolidWorks.Interop.sldworks Namespace > [ISectionViewData Interface](#) : SectionTransparentItemsTransparent Property (ISectionViewData)

Gets or sets whether the specified sectioned bodies in the multibody part or the specified sectioned components in the assembly are transparently sectioned in this section view.

.NET Syntax

Visual Basic (Declaration)

Property SectionTransparentItemsTransparent As System.Boolean

Visual Basic (Usage)



```

Dim instance As ISectionViewData
Dim value As System.Boolean

instance.SectionTransparentItemsTransparent = value

value = instance.SectionTransparentItemsTransparent
```

C#

```

System.bool SectionTransparentItemsTransparent {get; set;}
```

C++/CLI

```
property System.bool SectionTransparentItemsTransparent {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the specified sectioned bodies in the multibody part or the specified sectioned components in the assembly are transparently sectioned in this section view; false if all sectioned bodies in the multibody part or all sectioned components in the assembly, except for the specified sectioned bodies or the specified sectioned components, are transparently sectioned in this section view (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SectionTransparentItemsTransparent](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

Before calling this property, call [ISectionViewData::TransparencyList](#) to specify the sectioned bodies in the multibody part or the sectioned components in the assembly to transparently section. Call [ISectionViewData::TransparencyValue](#) to set the level of transparency of the sectioned bodies in the multibody part or the sectioned components in the assembly.

This property is only available if [ISectionViewData::ZonalSection](#) and [ISectionViewData::TransparentSection](#) are true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectiveSection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SelectiveSection Property (ISectionViewData)

Gets or sets whether selective sectioning is enabled in this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectiveSection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean
```

```
instance.SelectiveSection = value
```

```
value = instance.SelectiveSection
```

C#

```
System.bool SelectiveSection {get; set;}
```

C++/CLI

```
property System.bool SelectiveSection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if selective sectioning is enabled, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SelectiveSection](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

If this property is...	Then...
True	You can specify which bodies in the multibody part or which components in the assembly to selectively section. Call: ISectionViewData::SelectiveSectioningList to specify the bodies or components to selectively section. ISectionViewData::ExcludeSelectedItems to specify the bodies or components to exclude or include in selective sectioning.
False	All bodies in the multibody part and all components in the assembly are sectioned.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::TransparentSection Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectiveSectioningList Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : SelectiveSectioningList Property (ISectionViewData)

Gets or sets the bodies in the multibody part or the components in the assembly for selective sectioning in this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectiveSectioningList As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Object

instance.SelectiveSectioningList = value
value = instance.SelectiveSectioningList
```

C#

```
System.object SelectiveSectioningList {get; set;}
```

C++/CLI

```
property System.Object^ SelectiveSectioningList {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) in the multibody part or an array of [components](#) in the assembly to selectively section (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::SelectiveSectioningList](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

To select each body in a multibody part or each component in an assembly for selective sectioning, specify a Mark of 8 for [IModelDocExtension::SelectById2](#). Select the section planes after selecting the bodies or components.

Call [ISectionViewData::ExcludeSelectedItems](#) to exclude or include the specified bodies in the multibody part or the specified components in the assembly in selective sectioning.

ISectionViewData::SelectiveSectioningList is only available if [ISectionViewData::SelectiveSection](#) is true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstPlane Property \(\)](#)
[ISectionViewData::SecondPlane Property \(\)](#)
[ISectionViewData::ThirdPlane Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowSectionCap Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ShowSectionCap Property (ISectionViewData)

Gets or sets whether to cap the section views.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowSectionCap As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean
```

```
instance.ShowSectionCap = value
```

```
value = instance.ShowSectionCap
```

C#

```
System.bool ShowSectionCap {get; set;}
```

C++/CLI

```
property System.bool ShowSectionCap {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to cap the section views, false to see inside the model (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ShowSectionCap](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

After setting this property to true, specify whether to color the caps by setting [ISectionViewData::KeepCapColor](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThirdColor Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdColor Property (ISectionViewData)

Gets or sets the third color of the section view in this part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property ThirdColor As System.Integer

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Integer  
  
instance.ThirdColor = value  
value = instance.ThirdColor
```

C#

```
System.int ThirdColor {get; set;}
```

C++/CLI

```
property System.int ThirdColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Third RGB value of the color

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdColor](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

Use [ISectionViewData::ShowSectionCap](#) to display the caps of section views and [ISectionView::KeepCapColor](#) to color them.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstColor Property](#)
[ISectionViewData::SecondColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThirdOffset Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdOffset Property (ISectionViewData)

Gets or sets the third offset distance of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property ThirdOffset As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.ThirdOffset = value
```

```
value = instance.ThirdOffset
```

C#

```
System.double ThirdOffset {get; set;}
```

C++/CLI

```
property System.double ThirdOffset {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Third offset distance

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdOffset](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstOffset Property](#)
[ISectionViewData::SecondOffset Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThirdPlane Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdPlane Property (ISectionViewData)

Gets or sets the section plane for the third section of the section view for the part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property ThirdPlane As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Object
```

```
instance.ThirdPlane = value
```

```
value = instance.ThirdPlane
```

C#

```
System.object ThirdPlane {get; set;}
```

C++/CLI

```
property System.Object^ ThirdPlane {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#) or [planar face](#)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdPlane](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

Remarks

To select the section plane for the third section, specify a mark of 4 for [IModelDocExtension::SelectByID2](#).

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::GetFirstPlaneParameters Method](#)
[ISectionViewData::GetSecondPlaneParameters Method](#)
[ISectionViewData::GetThirdPlaneParameters Method](#)
[ISectionViewData::FirstPlane Property](#)
[ISectionViewData::SecondPlane Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThirdReverseDirection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdReverseDirection Property (ISectionViewData)

Gets or sets whether to reverse the third direction of the section view for this part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Property ThirdReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean

instance.ThirdReverseDirection = value

value = instance.ThirdReverseDirection
```

C#

```
System.bool ThirdReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ThirdReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the third direction of the section view, false to not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdReverseDirection](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstReverseDirection Property](#)
[ISectionViewData::SecondReverseDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThirdRotationX Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdRotationX Property (ISectionViewData)

Gets or sets the third x rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property ThirdRotationX As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.ThirdRotationX = value
```

```
value = instance.ThirdRotationX
```

C#

```
System.double ThirdRotationX {get; set;}
```

C++/CLI

```
property System.double ThirdRotationX {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Third x rotation of the section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdRotationX](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationX Property](#)
[ISectionViewData::FirstRotationY Property](#)
[ISectionViewData::SecondRotationX Property](#)
[ISectionViewData::SecondRotationY Property](#)
[ISectionViewData::ThirdRotationY Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThirdRotationY Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ThirdRotationY Property (ISectionViewData)

Gets or sets the third y rotation of the section view in the part or assembly.

.NET Syntax

Visual Basic (Declaration)

Property ThirdRotationY As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData  
Dim value As System.Double
```

```
instance.ThirdRotationY = value
```

```
value = instance.ThirdRotationY
```

C#

```
System.double ThirdRotationY {get; set;}
```

C++/CLI

```
property System.double ThirdRotationY {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Third y rotation for section view

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ThirdRotationY](#).

Example

[Create Section View in Model \(C#\)](#)
[Create Section View in Model \(VB.NET\)](#)
[Create Section View in Model \(VBA\)](#)
[Get Section View Data \(C#\)](#)
[Get Section View Data \(VB.NET\)](#)
[Get Section View Data \(VBA\)](#)

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstRotationX Property](#)
[ISectionViewData::FirstRotationY Property](#)
[ISectionViewData::SecondRotationX Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransparencyList Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : TransparencyList Property (ISectionViewData)

Gets or sets the sectioned bodies in the multibody part or the sectioned components in the assembly to transparently section in this section view.

.NET Syntax

Visual Basic (Declaration)

Property TransparencyList As System.Object

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Object

instance.TransparencyList = value
value = instance.TransparencyList
```

C#

```
System.object TransparencyList {get; set;}
```

C++/CLI

```
property System.Object^ TransparencyList {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) in the multibody part or an array of [components](#) to transparently section (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::TransparencyList](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

Call this property before calling [ISectionViewData::SectionTransparentItemsTransparent](#) to specify which sectioned bodies in the multibody part or which sectioned components in the assembly to transparently section.

To select each sectioned body or component, specify a Mark of 32 for [IModelDocExtension::SelectByID2](#). Select the section planes after selecting the sectioned bodies or components.

This property is only available if [ISectionViewData::ZonalSection](#) and [ISectionViewData::TransparentSection](#) are true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::FirstPlane Property \(\)](#)

[ISectionViewData::SecondPlane Property \(\)](#)
[ISectionViewData::ThirdPlane Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransparencyValue Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : TransparencyValue Property (ISectionViewData)

Gets or sets the level of transparency for the specified transparently sectioned bodies in the multibody part or the specified transparently sectioned components in the assembly in this section view.

.NET Syntax

Visual Basic (Declaration)

Property TransparencyValue As System.Double

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Double
```

```
instance.TransparencyValue = value
```

```
value = instance.TransparencyValue
```

C#

```
System.double TransparencyValue {get; set;}
```

C++/CLI

```
property System.double TransparencyValue {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.01 (least transparent) to 1.0 (most transparent)

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::TransparencyValue](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

To specify the sectioned bodies in the multibody part or the sectioned components in the assembly to transparently section, call [ISectionViewData::TransparencyList](#) and [ISectionViewData::SectionTransparentItemsTransparent](#).

This property is only available if [ISectionViewData::ZonalSection](#) and [ISectionViewData::TransparentSection](#) are true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransparentSection Property (ISectionViewData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : TransparentSection Property (ISectionViewData)

Gets or sets whether transparent sectioning is enabled in this section view.

.NET Syntax

Visual Basic (Declaration)

Property TransparentSection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean

instance.TransparentSection = value
value = instance.TransparentSection
```

C#

```
System.bool TransparentSection {get; set;}
```

C++/CLI

```
property System.bool TransparentSection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if transparent sectioning is enabled, false if not

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::TransparentSection](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

You can specify which sectioned bodies in multibody parts or which sectioned components in assemblies to transparently section. See [ISectionViewData::TransparencyList](#) and [ISectionViewData::SectionTransparentItemsTransparent](#).

ISectionViewData::TransparentSection is only available if [ISectionViewData::ZonalSection](#) is true.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)
[ISectionViewData::TransparencyValue Property\(\)](#)
[ISectionViewData::SelectiveSection Property\(\)](#)

Availability

ZonalSection Property (ISectionViewData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISectionViewData Interface](#) : ZonalSection Property (ISectionViewData)

Gets or sets whether the section method is zonal or planar.

.NET Syntax

Visual Basic (Declaration)

Property ZonalSection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISectionViewData
Dim value As System.Boolean
```

```
instance.ZonalSection = value
```

```
value = instance.ZonalSection
```

C#

```
System.bool ZonalSection {get; set;}
```

C++/CLI

```
property System.bool ZonalSection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

True if the section method is zonal, false if it is planar

Visual Basic for Applications (VBA) Syntax

See [SectionViewData::ZonalSection](#).

Example

[Selectively and Transparently Section a Section View \(C#\)](#)
[Selectively and Transparently Section a Section View \(VB.NET\)](#)
[Selectively and Transparently Section a Section View \(VBA\)](#)

Remarks

Call [ISectionViewData::SectionedZones](#) to specify the section zones.ISectionViewData::ZonalSection must be true for [transparent sectioning](#).**NOTE:** Zonal sectioning is only supported on graphics cards that support OpenGL 4.0; zonal sectioning is not supported in Software Only OpenGL.

See Also

[ISectionViewData Interface](#)
[ISectionViewData Members](#)

Availability

ISelectData (Type)

ISelectData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectData Interface

Allows you to select objects.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISelectData
```

Visual Basic (Usage)



```
Dim instance As ISelectData
```

C#

```
public interface ISelectData
```

C++/CLI

```
public interface class ISelectData
```

Visual Basic for Applications (VBA) Syntax

See [SelectData](#).

Example

[Select Multiple Objects for Selection Boxes \(C#\)](#)
[Select Multiple Objects for Selection Boxes \(VB.NET\)](#)
[Select Multiple Objects for Selection Boxes \(VBA\)](#)
[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Accessors

[ISelectionMgr::CreateSelectData](#)

Access Diagram

[SelectData](#)

See Also

[ISelectData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISelectData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectData Interface

The following tables list the members exposed by [ISelectData](#).

Public Properties

Name	Description
 Callout	Gets or sets the callout to attach to the selected object.

 Mark	Gets or sets the value to use to mark the selected object.
 View	Gets or sets the drawing view that contains the selected object.
 X	Gets or sets the X coordinate for the selection point.
 Y	Gets or sets the Y coordinate for the selection point.
 Z	Gets or sets the Z coordinate for the selection point.

[Top](#)

 Public Methods

Name	Description
 GetCellRange	Gets the specified range of table cells for this selection.
 SetCellRange	Sets the specified range of table cells for this selection.

[Top](#)

 See Also

[ISelectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectData Interface Methods

[See Also](#)

	
SolidWorks.Interop.sldworks Namespace	: ISelectData Interface

For a list of all members of this type, see [ISelectData members](#).

 Public Methods

Name	Description
 GetCellRange	Gets the specified range of table cells for this selection.
 SetCellRange	Sets the specified range of table cells for this selection.

[Top](#)

 See Also

[ISelectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectData Interface Properties

[See Also](#)

	
SolidWorks.Interop.sldworks Namespace	: ISelectData Interface

For a list of all members of this type, see [ISelectData members](#).

 Public Properties

Name	Description
 Callout	Gets or sets the callout to attach to the selected object.
 Mark	Gets or sets the value to use to mark the selected object.
 View	Gets or sets the drawing view that contains the selected object.
 X	Gets or sets the X coordinate for the selection point.
 Y	Gets or sets the Y coordinate for the selection point.
 Z	Gets or sets the Z coordinate for the selection point.

[Top](#)

See Also

[ISelectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Callout Property (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : Callout Property (ISelectData)

Gets or sets the callout to attach to the selected object.

.NET Syntax

Visual Basic (Declaration)

Property Callout As Callout

Visual Basic (Usage)



```
Dim instance As ISelectData
Dim value As Callout
```

```
instance.Callout = value
```

```
value = instance.Callout
```

C#

```
Callout Callout {get; set;}
```

C++/CLI

```
property Callout^ Callout {
    Callout^ get();
    void set ( & Callout^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Callout](#) to which to attach the selected object

Visual Basic for Applications (VBA) Syntax

See [SelectData::Callout](#).

Remarks

This property is not used by [IModelDocExtension::MultiSelect](#) or [IModelDocExtension::IMultiSelect](#).

See Also

[ISelectData Interface](#)
[ISelectData Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCellRange Method (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : GetCellRange Method (ISelectData)

Gets the specified range of table cells for this selection.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetCellRange( _  
    ByRef FirstRow As System.Integer, _  
    ByRef LastRow As System.Integer, _  
    ByRef FirstColumn As System.Integer, _  
    ByRef LastColumn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ISelectData  
Dim FirstRow As System.Integer  
Dim LastRow As System.Integer  
Dim FirstColumn As System.Integer  
Dim LastColumn As System.Integer  
  
instance.GetCellRange(FirstRow, LastRow, FirstColumn, LastColumn)
```

C#

```
void GetCellRange(  
    out System.int FirstRow,  
    out System.int LastRow,  
    out System.int FirstColumn,  
    out System.int LastColumn  
)
```

C++/CLI

```
void GetCellRange(  
& [Out] System.int FirstRow,  
& [Out] System.int LastRow,  
& [Out] System.int FirstColumn,  
& [Out] System.int LastColumn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstRow

0-based row number at the beginning of the selection range

LastRow

0-based row number at the end of the selection range

FirstColumn

0-based column number at the beginning of the selection range

LastColumn

0-based column number at the end of the selection range

Return Value

Visual Basic for Applications (VBA) Syntax

See [SelectData::GetCellRange](#).

Remarks

The range of table cells are only used for a selection made in a table. For all other types of selections, these values are ignored.

By default, the value for FirstRow, LastRow, FirstColumn, and LastColumn is -1, which indicates that the entire table is selected.

See Also

[ISelectData Interface](#)
[ISelectData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Mark Property (ISelectData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : Mark Property (ISelectData)

Gets or sets the value to use to mark the selected object.

.NET Syntax

Visual Basic (Declaration)

Property Mark As System.Integer

Visual Basic (Usage)



```
Dim instance As ISelectData
Dim value As System.Integer
```

```
instance.Mark = value
```

```
value = instance.Mark
```

C#

```
System.int Mark {get; set;}
```

C++/CLI

```
property System.int Mark {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for the mark

Visual Basic for Applications (VBA) Syntax

See [SelectData::Mark](#).

Example

[Edit Mate \(VBA\)](#)
[Insert Coordinate System at Center of Mass \(VBA\)](#)
[Move Bodies \(C#\)](#)
[Move Bodies \(VB.NET\)](#)
[Move Bodies \(VBA\)](#)
[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

See Also

[ISelectData Interface](#)
[ISelectData Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCellRange Method (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : SetCellRange Method (ISelectData)

Sets the specified range of table cells for this selection.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCellRange( _  
    ByVal FirstRow As System.Integer, _  
    ByVal LastRow As System.Integer, _  
    ByVal FirstColumn As System.Integer, _  
    ByVal LastColumn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ISelectData  
Dim FirstRow As System.Integer  
Dim LastRow As System.Integer  
Dim FirstColumn As System.Integer  
Dim LastColumn As System.Integer  
  
instance.SetCellRange(FirstRow, LastRow, FirstColumn, LastColumn)
```

C#

```
void SetCellRange(  
    System.int FirstRow,  
    System.int LastRow,  
    System.int FirstColumn,  
    System.int LastColumn  
)
```

C++/CLI

```
void SetCellRange(  
& System.int FirstRow,  
& System.int LastRow,  
& System.int FirstColumn,  
& System.int LastColumn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FirstRow
0-based row number at the beginning of the selection range
LastRow
0-based row number at the end of the selection range
FirstColumn
0-based row column at the beginning of the selection range
LastColumn
0-based row column at the end of the selection range

Visual Basic for Applications (VBA) Syntax

See [SelectData::SetCellRange](#).

Remarks

The range of table cells are only used for a selection made in a table. For all other types of selections, these values are ignored.
By default, the value for FirstRow, LastRow, FirstColumn, and LastColumn is -1, which indicates that the entire table is selected.

To select an entire...	Set...
Row	- FirstColumn and LastColumn to value values - FirstRow LastRow to -1

- | | |
|--------|---|
| Column | <ul style="list-style-type: none">• FirstRow and LastRow to valid values• FirstColumn and LastColumn to -1 |
|--------|---|

See Also

[ISelectData Interface](#)
[ISelectData Members](#)
[ISelectData::GetCellRange Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

View Property (ISelectData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : View Property (ISelectData)

Gets or sets the drawing view that contains the selected object.

.NET Syntax

Visual Basic (Declaration)

Property View As View

Visual Basic (Usage)



```
Dim instance As ISelectData  
Dim value As View
```

```
instance.View = value
```

```
value = instance.View
```

C#

```
View View {get; set;}
```

C++/CLI

```
property View^ View {  
    View^ get();  
    void set ( & View^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[View](#) that contains the selected object

Visual Basic for Applications (VBA) Syntax

See [SelectData::View](#).

Example

[Set Body for View \(C#\)](#)
[Set Body for View \(VB.NET\)](#)
[Set Body for View \(VBA\)](#)

See Also

[ISelectData Interface](#)
[ISelectData Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

X Property (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : X Property (ISelectData)

Gets or sets the X coordinate for the selection point.

.NET Syntax

Visual Basic (Declaration)

Property X As System.Double

Visual Basic (Usage)



```
Dim instance As ISelectData
Dim value As System.Double
```

```
instance.X = value
```

```
value = instance.X
```

C#

```
System.double X {get; set;}
```

C++/CLI

```
property System.double X {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

X coordinate for the selection point

Visual Basic for Applications (VBA) Syntax

See [SelectData.X](#).

See Also

[ISelectData Interface](#)
[ISelectData Members](#)
[ISelectData::Y Property](#)
[ISelectData::Z Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Y Property (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : Y Property (ISelectData)

Gets or sets the Y coordinate for the selection point.

.NET Syntax

Visual Basic (Declaration)

Property Y As System.Double

Visual Basic (Usage)



```
Dim instance As ISelectData  
Dim value As System.Double
```

```
instance.Y = value
```

```
value = instance.Y
```

C#

```
System.double Y {get; set;}
```

C++/CLI

```
property System.double Y {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Y coordinate for the selection point

Visual Basic for Applications (VBA) Syntax

See [SelectData::Y](#).

See Also

[ISelectData Interface](#)
[ISelectData Members](#)
[ISelectData::X Property](#)
[ISelectData::Z Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Z Property (ISelectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectData Interface](#) : Z Property (ISelectData)

Gets or sets the Z coordinate for the selection point.

.NET Syntax

Visual Basic (Declaration)

Property Z As System.Double

Visual Basic (Usage)



```
Dim instance As ISelectData  
Dim value As System.Double
```

```
instance.Z = value
```

```
value = instance.Z
```

C#

```
System.double Z {get; set;}
```

```
property System.double Z {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Z coordinate for the selection point

Visual Basic for Applications (VBA) Syntax

See [SelectData::Z](#).

See Also

[ISelectData Interface](#)
[ISelectData Members](#)
[ISelectData::X Property](#)
[ISelectData::Y Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0