

SOLIDWORKS API (.NET VBA C#) — Reference

(252/337): ISFSymbol

SOLIDWORKS API Documentation (converted from CHM)

ISFSymbol (Type)

ISFSymbol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISFSymbol Interface

Allows access to display information for surface finish symbols.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ISFSymbol
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
```

C#

```
public interface ISFSymbol
```

C++/CLI

```
public interface class ISFSymbol
```

Visual Basic for Applications (VBA) Syntax

See [SFSymbol](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::!GetSpecificAnnotation](#)
[IModelDocExtension::InsertSurfacefinishSymbol3](#)
[ISFSymbol::GetNext](#) and [ISFSymbol::!GetNext](#)
[IView::GetFirstSFSymbol](#) and [IView::!GetFirstSFSymbol](#)
[IView::GetSFSymbols](#) and [IView::!GetSFSymbols](#)

Access Diagram

[SFSymbol](#)

See Also

[ISFSymbol Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

ISFSymbol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISFSymbol Interface

The following tables list the members exposed by [ISFSymbol](#).

Public Properties

Name	Description
 GOSTDefaultSymbol	Gets whether the GOST Add default symbol option is set.
 GOSTNotation	Gets whether the GOST Use for notation option is set.
 Grinding	Obsolete. Superseded by ISFSymbol.GetSymbolSurfaceTexture .
 Orientation	Gets whether the orientation of this surface finish symbol is relative to the model or entity to which it is attached.
 ProfileAngle	Gets or sets the profile angle of this surface finish symbol.
 ProfileDirection	Gets or sets the profile direction of this surface finish symbol.
 Rotated	Obsolete. Superseded by ISFSymbol.Orientation .

[Top](#)

Public Methods

Name	Description
 GetAngle	Gets the angle of this surface finish symbol.
 GetAnnotation	Gets the annotation for this surface finish symbol.
 GetArcAtIndex	Gets information for the specified arc.
 GetArcCount	Gets the number of arcs in this surface finish symbol.
 GetArrowHeadAtIndex	Gets information on the specified arrow head in this surface finish symbol.
 GetArrowHeadCount	Gets the number of arrow heads in the surface finish symbol.
 GetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
 GetDirectionOfLay	Gets the direction of lay value for this surface finish symbol.
 GetLeaderAtIndex	Gets information about the specified leader on this surface finish symbol.
 GetLeaderCount	Gets the number of leaders on this surface finish symbol.
 GetLineAtIndex	Gets information for the specified line.
 GetLineCount	Gets number of line items in this surface finish symbol.
 GetNext	Gets the next surface finish symbol in the view.
 GetSymbol	Gets the type of symbol for this surface finish symbol.
 GetSymbolAllAround	Gets whether this symbol is All Around or Local for this surface finish symbol.
 GetSymbolSurfaceTexture	Gets the symbol surface texture type for this surface finish symbol.
 GetSymbolType	Obsolete. Superseded by ISFSymbol.GetSymbol .
 GetText	Gets the specified text string in this surface finish symbol.
 GetTextAngleAtIndex	Gets the text angle for the specified text in this surface finish symbol.
 GetTextAtIndex	Gets the specified text string from this surface finish symbol.
 GetTextCount	Gets the number of text items in the surface finish symbol.
 GetTextFontAtIndex	Gets the font used by the specified text item in this surface finish symbol.
 GetTextHeightAtIndex	Gets the text height for the specified piece of text in this surface finish symbol.
 GetTextInvertAtIndex	Gets the specified text item's invert flag.
 GetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
 GetTextRefPositionAtIndex	Gets the specified text item's reference position in this note, for example, upper left, lower left, center, and so on.
 GetTriangleAtIndex	Gets the triangle at the specified index.
 GetTriangleCount	Gets the number of triangles in this surface finish symbol.
 HasExtraLeader	Gets whether this surface finish symbol has an extra leader line.
 IGetAnnotation	Gets the annotation for this surface finish symbol.
 IGetArcAtIndex	Gets information for the specified arc.
 IGetArrowHeadAtIndex	Gets information on the specified arrow head in this surface finish symbol.

	IGetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	IGetLeaderAtIndex	Gets information about the specified leader on this surface finish symbol.
	IGetLineAtIndex	Gets information for the specified line.
	IGetNext	Gets the next surface finish symbol in the view.
	IGetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
	IGetTriangleAtIndex	Gets the triangle at the specified index.
	IsAttached	Gets whether the leader line for this surface finish symbol is attached.
	SetAngle	Sets the angle for this surface finish symbol.
	SetDirectionOfLay	Sets the direction of lay value for this surface finish symbol.
	SetSymbol	Sets the type of symbol for this surface finish symbol.
	SetSymbolType	Obsolete. Superseded by ISFSymbol.SetSymbol .
	SetText	Sets a text string in this surface finish symbol.

[Top](#)

See Also

[ISFSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISFSymbol Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISFSymbol Interface

For a list of all members of this type, see [ISFSymbol members](#).

Public Methods

Name	Description
	GetAngle Gets the angle of this surface finish symbol.
	GetAnnotation Gets the annotation for this surface finish symbol.
	GetArcAtIndex Gets information for the specified arc.
	GetArcCount Gets the number of arcs in this surface finish symbol.
	GetArrowHeadAtIndex Gets information on the specified arrow head in this surface finish symbol.
	GetArrowHeadCount Gets the number of arrow heads in the surface finish symbol.
	GetArrowHeadInfo Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	GetDirectionOfLay Gets the direction of lay value for this surface finish symbol.
	GetLeaderAtIndex Gets information about the specified leader on this surface finish symbol.
	GetLeaderCount Gets the number of leaders on this surface finish symbol.
	GetLineAtIndex Gets information for the specified line.
	GetLineCount Gets number of line items in this surface finish symbol.
	GetNext Gets the next surface finish symbol in the view.
	GetSymbol Gets the type of symbol for this surface finish symbol.
	GetSymbolAllAround Gets whether this symbol is All Around or Local for this surface finish symbol.
	GetSymbolSurfaceTexture Gets the symbol surface texture type for this surface finish symbol.
	GetSymbolType Obsolete. Superseded by ISFSymbol.GetSymbol .
	GetText Gets the specified text string in this surface finish symbol.
	GetTextAngleAtIndex Gets the text angle for the specified text in this surface finish symbol.

	GetTextAtIndex	Gets the specified text string from this surface finish symbol.
	GetTextCount	Gets the number of text items in the surface finish symbol.
	GetTextFontAtIndex	Gets the font used by the specified text item in this surface finish symbol.
	GetTextHeightAtIndex	Gets the text height for the specified piece of text in this surface finish symbol.
	GetTextInvertAtIndex	Gets the specified text item's invert flag.
	GetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
	GetTextRefPositionAtIndex	Gets the specified text item's reference position in this note, for example, upper left, lower left, center, and so on.
	GetTriangleAtIndex	Gets the triangle at the specified index.
	GetTriangleCount	Gets the number of triangles in this surface finish symbol.
	HasExtraLeader	Gets whether this surface finish symbol has an extra leader line.
	IGetAnnotation	Gets the annotation for this surface finish symbol.
	IArcAtIndex	Gets information for the specified arc.
	IArrowHeadAtIndex	Gets information on the specified arrow head in this surface finish symbol.
	IArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	ILeaderAtIndex	Gets information about the specified leader on this surface finish symbol.
	ILineAtIndex	Gets information for the specified line.
	IGetNext	Gets the next surface finish symbol in the view.
	ITextPositionAtIndex	Gets the text item's offset relative to note's text point.
	ITriangleAtIndex	Gets the triangle at the specified index.
	IsAttached	Gets whether the leader line for this surface finish symbol is attached.
	SetAngle	Sets the angle for this surface finish symbol.
	SetDirectionOfLay	Sets the direction of lay value for this surface finish symbol.
	SetSymbol	Sets the type of symbol for this surface finish symbol.
	SetSymbolType	Obsolete. Superseded by ISFSymbol.SetSymbol .
	SetText	Sets a text string in this surface finish symbol.

[Top](#)

 See Also

[ISFSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISFSymbol Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISFSymbol Interface

For a list of all members of this type, see [ISFSymbol members](#).

 Public Properties

Name	Description
 GOSTDefaultSymbol	Gets whether the GOST Add default symbol option is set.
 GOSTNotation	Gets whether the GOST Use for notation option is set.
 Grinding	Obsolete. Superseded by ISFSymbol.GetSymbolSurfaceTexture
 Orientation	Gets whether the orientation of this surface finish symbol is relative to the model or entity to which it is attached.
 ProfileAngle	Gets or sets the profile angle of this surface finish symbol.
 ProfileDirection	Gets or sets the profile direction of this surface finish symbol.



Rotated

Obsolete. Superseded by [ISFSymbol.Orientation](#).

[Top](#)

See Also

[ISFSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAngle Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetAngle Method (ISFSymbol)

Gets the angle of this surface finish symbol.

NET Syntax

Visual Basic (Declaration)

```
Function GetAngle() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Double  
  
value = instance.GetAngle()
```

C#

```
System.double GetAngle()
```

C++/CLI

```
System.double GetAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Symbol angle

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetAngle](#).

Remarks

See [ISFSymbol::Orientation](#) and [ISFSymbol::SetAngle](#) for details on how to set the angle of a surface finish symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (ISFSymbol)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetAnnotation Method (ISFSymbol)

Gets the annotation for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

This method gets the owning [IAnnotation](#) object, which is a higher-level object that contains methods that are general to all types of annotations.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetArcAtIndex Method (ISFSymbol)

Gets information for the specified arc.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex(  
    ByVal Index As System.Integer  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetArcAtIndex(Index)
```

C#

```
System.Object GetArcAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetArcAtIndex](#).

Remarks

Call [ISFSymbol::GetArcCount](#) before calling this method to get the number of arcs in this surface finish symbol.

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3], \textit{centerPt}[3], \textit{rotationDir}]$

where:

<i>lineType</i>	= Line type as defined in swLineTypes_e enumeration
<i>startPt</i> [3]	= XYZ arc start point
<i>endPt</i> [3]	= XYZ arc end point
<i>centerPt</i> [3]	= XYZ arc center point
<i>rotationDir</i>	= Value is a boolean returned as a double and represents the rotation direction, where CCW = True and CW = FALS

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcCount Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetArcCount Method (ISFSymbol)

Gets the number of arcs in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim value As System.Integer

value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetArcCount](#).

Remarks

Call this method before calling [ISFSymbol::GetArcAtIndex](#) and [ISFSymbol::IGetArcAtIndex](#) to find out the number of arcs in this surface finish symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetArrowHeadAtIndex Method (ISFSymbol)

Gets information on the specified arrow head in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arrow head where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetArrowHeadAtIndex](#).

Remarks

Call [ISFSymbol::GetArrowHeadCount](#) before calling this method to get the number of arrow heads for this surface finish symbol.

The return value is the following array of doubles :

[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt</i> [3]	= XYZ arrow head tip location
<i>arrowHeadDir</i> [3]	= XYZ arrow head direction
<i>arrowHeadWidth</i>	= Arrow head width where the width is measured along the arrow head direction
<i>arrowHeadHeight</i>	= Arrow head height
<i>arrowHeadStyle</i>	= Arrow head style (for example, open or closed) as defined in swArrowStyle_e

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArrowHeadCount Method](#)
[ISFSymbol::GetArrowHeadInfo Method](#)
[ISFSymbol::!GetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadCount Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetArrowHeadCount Method (ISFSymbol)

Gets the number of arrow heads in the surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrow heads

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetArrowHeadCount](#).

Remarks

Call this method before calling [ISFSymbol::GetArrowHeadAtIndex](#) and [ISFSymbol::!GetArrowHeadAtIndex](#) to find out the number of arrow heads for this surface finish symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArrowHeadInfo Method](#)
[ISFSymbol::!GetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadInfo Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetArrowHeadInfo Method (ISFSymbol)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Object  
  
value = instance.GetArrowHeadInfo()
```

C#

```
System.object GetArrowHeadInfo()
```

C++/CLI

```
System.Object^ GetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles describing format (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetArrowHeadInfo](#).

Remarks

Format of return information is the following array of doubles:

<i>retval</i> [0]	= Arrow length (leader into arrowhead)
<i>retval</i> [1]	= Arrowhead length
<i>retval</i> [2]	= Arrowhead width

`retval[3]` = Arrowhead style as defined in [swArrowStyle_e](#)

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArrowHeadAtIndex Method](#)
[ISFSymbol::GetArrowHeadCount Method](#)
[ISFSymbol::IGetArrowHeadAtIndex Method](#)
[ISFSymbol::IGetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDirectionOfLay Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetDirectionOfLay Method (ISFSymbol)

Gets the direction of lay value for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionOfLay() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetDirectionOfLay()
```

C#

```
System.int GetDirectionOfLay()
```

C++/CLI

```
System.int GetDirectionOfLay();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Direction of lay as defined in [swSFLaySym_e](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetDirectionOfLay](#).

Remarks

To set the direction of lay value, use [ISFSymbol::SetDirectionOfLay](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLeaderAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetLeaderAtIndex Method (ISFSymbol)

Gets information about the specified leader on this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLeaderAtIndex(Index)
```

C#

```
System.object GetLeaderAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLeaderAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of leader

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetLeaderAtIndex](#).

Remarks

There can be 0, 1 or 2 lines used with the leader line. If the surface-finish symbol is not attached then, there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on [ISFSymbol::IsAttached](#) and [ISFSymbol::HasExtraLeader](#).

- `ISFSymbol::IsAttached == false` implies no leaderline and no leaderline points (*PointCount*=0).
- `ISFSymbol::HasExtraLeader == false` means that this is a straight leaderline and 1 line (*PointCount*=2)
- `ISFSymbol::HasExtraLeader == true` means that this is a bent leaderline and 2 lines (*PointCount*=3)

Format of return information is the following array of doubles:

retval[0] = x-coordinate of first leader point

retval[1] = y-coordinate of first leader point

retval[2] = z-coordinate of first leader point

retval[3] = x-coordinate of second leader point

retval[4] = y-coordinate of second leader point

retval[5] = z-coordinate of second leader point

retval[6] = x-coordinate of third leader point

retval[7] = y-coordinate of third leader point

retval[8] = z-coordinate of third leader point

Use [ISFSymbol::GetLeaderCount](#) to see how many leaders there are on the [ISFSymbol](#) object.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetLeaderAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderCount Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetLeaderCount Method (ISFSymbol)

Gets the number of leaders on this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetLeaderCount()
```

C#

```
System.int GetLeaderCount()
```

C++/CLI

```
System.int GetLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of leaders on the symbol

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetLeaderCount](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetLeaderAtIndex Method](#)
[ISFSymbol::IGetLeaderAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetLineAtIndex Method (ISFSymbol)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLineAtIndex(Index)
```

C#

```
System.Object GetLineAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetLineAtIndex](#).

Remarks

Call [ISFSymbol::GetLineCount](#) before calling this method to get the number of lines in this surface finish symbol.

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3]]$

where:

<i>lineType</i>	= Line type as defined in swLineTypes_e
<i>startPt</i> [3]	= XYZ line start point
<i>endPt</i> [3]	= XYZ line end point

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineCount Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetLineCount Method (ISFSymbol)

Gets number of line items in this surface finish symbol.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim value As System.Integer

value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of lines

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetLineCount](#).

Remarks

Call this method before calling [ISFSymbol::GetLineAtIndex](#) and [ISFSymbol::IGetLineAtIndex](#) to get the number of lines in this surface finish symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetNext Method (ISFSymbol)

Gets the next surface finish symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim value As System.Object

value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [surface finish symbol](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetNext](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetNext Method](#)
[IView::IGetFirstSFSymbol Method](#)
[IView::GetFirstSFSymbol Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSymbol Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetSymbol Method (ISFSymbol)

Gets the type of symbol for this surface finish symbol.

NET Syntax

Visual Basic (Declaration)

```
Function GetSymbol() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetSymbol()
```

C#

```
System.int GetSymbol()
```

C++/CLI

```
System.int GetSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of symbol as defined in [swSFSymType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetSymbol](#).

Remarks

This method returns one of the following values from the [swSFSymType_e](#) enumeration: swSFBasic, swSFMachining_Req, swSFDont_Machine, swSFJIS_No_Machining, swSFJIS_Basic, or swSFJIS_Machining_Req.

If the symbol is...	Then use...
swSFJIS_No_Machining or swSFJIS_Basic	ISFSymbol::GetSymbolSurfaceTexture to retrieve more information about the symbol. It returns one of these values from the swSFSymType_e enumeration: swSFJIS_Surface_Texture_1, swSFJIS_Surface_Texture_2, swSFJIS_Surface_Texture_3, or swSFJIS_Surface_Texture_4.
swSFBasic, swSFMachining_Req, or swSFDont_Machine	ISFSymbol::GetSymbolAllAround to retrieve more information about the symbol. This method returns a Boolean indicating whether this is an All Around or Local symbol.

To set the symbol type, use [ISFSymbol::SetSymbol](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSymbolAllAround Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetSymbolAllAround Method (ISFSymbol)

Gets whether this symbol is All Around or Local for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSymbolAllAround() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean  
  
value = instance.GetSymbolAllAround()
```

C#

```
System.bool GetSymbolAllAround()
```

C++/CLI

```
System.bool GetSymbolAllAround();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if All Around symbol, false if Local symbol

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetSymbolAllAround](#).

Remarks

[ISFSymbol::GetSymbol](#) returns one of the following values from the [swSFSymType_e](#) enumeration: swSFBasic, swSFMachining_Req, swSFDont_Machine, swSFJIS_No_Machining, swSFJIS_Basic, or swSFJIS_Machining_Req.

If the symbol is...	Then use...
swSFJIS_No_Machining or swSFJIS_Basic	ISFSymbol::GetSymbolSurfaceTexture to retrieve more information about the symbol. It returns one of these values from the swSFSymType_e enumeration: swSFJIS_Surface_Texture_1, swSFJIS_Surface_Texture_2, swSFJIS_Surface_Texture_3, or swSFJIS_Surface_Texture_4.
swSFBasic, swSFMachining_Req, or swSFDont_Machine	ISFSymbol::GetSymbolAllAround to retrieve more information about the symbol. This method returns a Boolean indicating whether this is an All Around or Local symbol.

To set the symbol type, use [ISFSymbol::SetSymbol](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

GetSymbolSurfaceTexture Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetSymbolSurfaceTexture Method (ISFSymbol)

Gets the symbol surface texture type for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSymbolSurfaceTexture() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetSymbolSurfaceTexture()
```

C#

```
System.int GetSymbolSurfaceTexture()
```

C++/CLI

```
System.int GetSymbolSurfaceTexture();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Symbol surface texture type as defined in [swSFSymType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetSymbolSurfaceTexture](#).

Remarks

[ISFSymbol::GetSymbol](#) returns one of the following values from the [swSFSymType_e](#) enumeration: swSFBasic, swSFMachining_Req, swSFDont_Machine, swSFJIS_No_Machining, swSFJIS_Basic, or swSFJIS_Machining_Req.

If the symbol is...	Then use...
swSFJIS_No_Machining or swSFJIS_Basic	ISFSymbol::GetSymbolSurfaceTexture to retrieve more information about the symbol. It returns one of these values from the swSFSymType_e enumeration: swSFJIS_Surface_Texture_1, swSFJIS_Surface_Texture_2, swSFJIS_Surface_Texture_3, or swSFJIS_Surface_Texture_4.
swSFBasic, swSFMachining_Req, or swSFDont_Machine	ISFSymbol::GetSymbolAllAround to retrieve more information about the symbol. This method returns a Boolean indicating whether this is an All Around or Local symbol.

To set the symbol type, use [ISFSymbol::SetSymbol](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

GetSymbolType Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetSymbolType Method (ISFSymbol)

Obsolete. Superseded by [ISFSymbol::GetSymbol](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSymbolType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetSymbolType()
```

C#

```
System.int GetSymbolType()
```

C++/CLI

```
System.int GetSymbolType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetSymbolType](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetText Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetText Method (ISFSymbol)

Gets the specified text string in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText( _  
    ByVal WhichOne As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim WhichOne As System.Integer  
Dim value As System.String  
  
value = instance.GetText(WhichOne)
```

C#

```
System.string GetText(  
    System.int WhichOne  
)
```

C++/CLI

```
System.String^ GetText(  
& System.int WhichOne  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

Text item to get as defined in [swSurfaceFinishSymbolText_e](#)

Return Value

Text string

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetText](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

To set the text strings, use [ISFSymbol::SetText](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextCount Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAngleAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextAngleAtIndex Method (ISFSymbol)

Gets the text angle for the specified text in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Text angle for the text in radians; the angle is measured CCW from the X axis

Visual Basic for Applications (VBA) Syntax

See [ISFSymbol::GetTextAngleAtIndex](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::ISetText Method](#)
[ISFSymbol::GetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextAtIndex Method (ISFSymbol)

Gets the specified text string from this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex(  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text where the index begins at 0

Return Value

Text string for the text

 Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextAtIndex](#).

 Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

 See Also

- [ISFSymbol Interface](#)
- [ISFSymbol Members](#)
- [ISFSymbol::GetText Method](#)
- [ISFSymbol::GetTextAngleAtIndex Method](#)
- [ISFSymbol::GetTextFontAtIndex Method](#)
- [ISFSymbol::GetTextHeightAtIndex Method](#)
- [ISFSymbol::GetTextInvertAtIndex Method](#)
- [ISFSymbol::GetTextPositionAtIndex Method](#)
- [ISFSymbol::GetTextRefPositionAtIndex Method](#)
- [ISFSymbol::IGetTextPositionAtIndex Method](#)
- [ISFSymbol::SetText Method](#)

GetTextCount Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextCount Method (ISFSymbol)

Gets the number of text items in the surface finish symbol.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items

 Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextCount](#).

 Remarks

Call this method before calling the following methods to get the number of text items in this surface finish symbol:

- [ISFSymbol::GetText](#)
- [ISFSymbol::GetTextAngleAtIndex](#)
- [ISFSymbol::GetTextFontAtIndex](#)
- [ISFSymbol::GetTextHeightAtIndex](#)
- [ISFSymbol::GetTextInvertAtIndex](#)
- [ISFSymbol::GetTextPositionAtIndex](#) and [ISFSymbol::IGetTextPositionAtIndex](#)
- [ISFSymbol::GetTextRefPositionAtIndex](#)

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFontAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextFontAtIndex Method (ISFSymbol)

Gets the font used by the specified text item in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFontAtIndex( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextFontAtIndex(Index)
```

C#

```
System.string GetTextFontAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextFontAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Font name used by this surface finish symbol

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextFontAtIndex](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextHeightAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextHeightAtIndex Method (ISFSymbol)

Gets the text height for the specified piece of text in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex(  
    ByVal Index As System.Integer  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Text height for the specified piece of text in meters

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextHeightAtIndex](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)

GetTextInvertAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextInvertAtIndex Method (ISFSymbol)

Gets the specified text item's invert flag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex(  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Text item's invert flag

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextInvertAtIndex](#).

Remarks

The invert flag specifies whether the text has been mirrored (reflected) about the X axis. Any reflection is applied after text rotation.

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)

GetTextPositionAtIndex Method (ISFSymbol)

[See Also](#)



Gets the text item's offset relative to note's text point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.object GetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextPositionAtIndex](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

The return value is the following array of doubles :

$\left[\text{textPtX}, \text{textPtY}, \text{textPtZ} \right]$

where these text position values are offset values from the origin of this [ISFSymbol](#) object.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTextRefPositionAtIndex Method (ISFSymbol)

Gets the specified text item's reference position in this note, for example, upper left, lower left, center, and so on.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

Reference position of the specified text item as defined in [swTextPosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTextRefPositionAtIndex](#).

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::IGetTextPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTriangleAtIndex Method (ISFSymbol)

Gets the triangle at the specified index.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTriangleAtIndex(Index)
```

C#

```
System.object GetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the triangle where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTriangleAtIndex](#).

Remarks

Call [ISFSymbol::GetTriangleCount](#) before calling this method to get the number of triangles in this surface finish symbol.

The return value is the following array of doubles :

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	= First XYZ vertex point
<i>vertexPt2</i> [3]	= Second XYZ vertex point
<i>vertexPt3</i> [3]	= Third XYZ vertex point
<i>isFilled</i>	= BOOLEAN returned as a double; True if triangle is filled, false if not
<i>lineType</i>	= Line type as defined in swLineTypes_e .

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTriangleAtIndex Method](#)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GetTriangleCount Method (ISFSymbol)

Gets the number of triangles in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of triangles

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GetTriangleCount](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTriangleAtIndex Method](#)
[ISFSymbol::IGetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GOSTDefaultSymbol Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GOSTDefaultSymbol Property (ISFSymbol)

Gets whether the GOST **Add default symbol** option is set.

.NET Syntax

Visual Basic (Declaration)

```
Property GOSTDefaultSymbol As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean  
  
instance.GOSTDefaultSymbol = value  
value = instance.GOSTDefaultSymbol
```

C#

```
System.bool GOSTDefaultSymbol {get; set;}
```

C++/CLI

```
property System.bool GOSTDefaultSymbol {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the GOST **Add default symbol** option is set, false if it is not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GOSTDefaultSymbol](#).

Remarks

[ISFSymbol::GOSTNotation](#) must be True to set this property.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GOSTNotation Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : GOSTNotation Property (ISFSymbol)

Gets whether the GOST **Use for notation** option is set.

.NET Syntax

Visual Basic (Declaration)

```
Property GOSTNotation As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim value As System.Boolean

instance.GOSTNotation = value
value = instance.GOSTNotation
```

C#

```
System.bool GOSTNotation {get; set;}
```

C++/CLI

```
property System.bool GOSTNotation {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the GOST **Use for notation** option is set, false if it is not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::GOSTNotation](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GOSTDefaultSymbol Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Grinding Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : Grinding Property (ISFSymbol)

Obsolete. Superseded by [ISFSymbol::GetSymbolSurfaceTexture](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Grinding As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean  
  
instance.Grinding = value  
value = instance.Grinding
```

C#

```
System.bool Grinding {get; set;}
```

C++/CLI

```
property System.bool Grinding {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::Grinding](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasExtraLeader Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : HasExtraLeader Method (ISFSymbol)

Gets whether this surface finish symbol has an extra leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function HasExtraLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean
```

```
value = instance.HasExtraLeader()
```

C#

```
System.bool HasExtraLeader()
```

C++/CLI

```
System.bool HasExtraLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if extra leader line exists, false if not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::HasExtraLeader](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetLeaderAtIndex Method](#)
[ISFSymbol::IGetLeaderAtIndex Method](#)
[ISFSymbol::IsAttached Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotation Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetAnnotation Method (ISFSymbol)

Gets the annotation for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ISFSymbol  
Dim value As Annotation
```

```
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::IGetAnnotation](#).

Remarks

This method gets the owning [IAnnotation](#) object, which is a higher-level object that contains methods that are general to all types of annotations.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetArcAtIndex Method (ISFSymbol)

Gets information for the specified arc.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISFSymbol::GetArcCount](#) before calling this method to get the number of arcs in this surface finish symbol.

The return value is the following array of doubles :

$[\textit{lineType}, \textit{startPt}[3], \textit{endPt}[3], \textit{centerPt}[3], \textit{rotationDir}]$

where:

<i>lineType</i>	= Line type as defined in swLineTypes_e enumeration
<i>startPt</i> [3]	= XYZ arc start point
<i>endPt</i> [3]	= XYZ arc end point

<i>centerPt</i> [3]	= XYZ arc center point
<i>rotationDir</i>	= Value is a boolean returned as a double and represents the rotation direction, where CCW = True and CW = FALS

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArcAtIndex Method](#)

IGetArrowHeadAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetArrowHeadAtIndex Method (ISFSymbol)

Gets information on the specified arrow head in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [in-process Methods](#) for details about this type of method.

Remarks

Call [ISFSymbol::GetArrowHeadCount](#) before calling this method to get the number of arrow heads for this surface finish symbol.
The return value is the following array of doubles :

[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt</i> [3]	= XYZ arrow head tip location
<i>arrowHeadDir</i> [3]	= XYZ arrow head direction

<i>arrowHeadWidth</i>	= Arrow head width where the width is measured along the arrow head direction
<i>arrowHeadHeight</i>	= Arrow head height
<i>arrowHeadStyle</i>	= Arrow head style (for example, open or closed) as defined in swArrowStyle_e

 See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArrowHeadAtIndex Method](#)
[ISFSymbol::GetArrowHeadInfo Method](#)
[ISFSymbol::IGetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowHeadInfo Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetArrowHeadInfo Method (ISFSymbol)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Double
```

```
value = instance.IGetArrowHeadInfo()
```

C#

```
System.double IGetArrowHeadInfo()
```

C++/CLI

```
System.double IGetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

 Remarks

Format of return information is the following array of doubles:

<i>retval</i> [0]	= Arrow length (leader into arrowhead)
<i>retval</i> [1]	= Arrowhead length
<i>retval</i> [2]	= Arrowhead width
<i>retval</i> [3]	= Arrowhead style as defined in swArrowStyle_e

 See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetArrowHeadAtIndex Method](#)
[ISFSymbol::GetArrowHeadInfo Method](#)
[ISFSymbol::IGetArrowHeadAtIndex Method](#)
[ISFSymbol::GetArrowHeadCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLeaderAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetLeaderAtIndex Method (ISFSymbol)

Gets information about the specified leader on this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderAtIndex( _  
    ByVal Index As System.Integer, _  
    ByRef PointCount As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim PointCount As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLeaderAtIndex(Index, PointCount)
```

C#

```
System.double IGetLeaderAtIndex(  
    System.int Index,  
    out System.int PointCount  
)
```

C++/CLI

```
System.double IGetLeaderAtIndex(  
& System.int Index,  
& [Out] System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line where the index begins at 0

PointCount

Number of (x,y,z) points returned in the array

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

There can be 0, 1 or 2 lines used with the leader line. If the surface-finish symbol is not attached then, there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on [ISFSymbol::IsAttached](#) and [ISFSymbol::HasExtraLeader](#).

- ISFSymbol::IsAttached == false implies no leaderline and no leaderline points (*PointCount*=0).
- ISFSymbol::HasExtraLeader == false means that this is a straight leaderline and 1 line (*PointCount*=2)
- ISFSymbol::HasExtraLeader == true means that this is a bent leaderline and 2 lines (*PointCount*=3)

Format of return information is the following array of doubles:

retval[0] = x-coordinate of first leader point

retval[1] = y-coordinate of first leader point

retval[2] = z-coordinate of first leader point

<i>retval[3]</i> = x-coordinate of second leader point
<i>retval[4]</i> = y-coordinate of second leader point
<i>retval[5]</i> = z-coordinate of second leader point
<i>retval[6]</i> = x-coordinate of third leader point
<i>retval[7]</i> = y-coordinate of third leader point
<i>retval[8]</i> = z-coordinate of third leader point

Use [ISFSymbol::GetLeaderCount](#) to see how many leaders there are on the [ISFSymbol](#) object.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetLeaderAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetLineAtIndex Method (ISFSymbol)

Gets information for the specified line.

NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex( _
    ByVal Index As System.Integer _
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double IGetLineAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line where the index begins at 0

Return Value

- in-process, unmanaged C++; Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISFSymbol::GetLineCount](#) before calling this method to get the number of lines in this surface finish symbol.

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3]]

where:

<i>lineType</i>	= Line type as defined in swLineTypes_e
<i>startPt</i> [3]	= XYZ line start point
<i>endPt</i> [3]	= XYZ line end point

 See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetNext Method (ISFSymbol)

Gets the next surface finish symbol in the view.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As SFSymbol
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As SFSymbol  
  
value = instance.IGetNext()
```

C#

```
SFSymbol IGetNext()
```

C++/CLI

```
SFSymbol^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [surface finish symbol](#)

 Visual Basic for Applications (VBA) Syntax

See [SFSymbol::IGetNext](#).

 See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetNext Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextPositionAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetTextPositionAtIndex Method (ISFSymbol)

Gets the text item's offset relative to note's text point.

 .NET Syntax

```
Function IGetTextPositionAtIndex( _
    ByVal Index As System.Integer _
) As System.Double
```

```
Dim instance As ISFSymbol
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetTextPositionAtIndex(Index)
```

```
System.double IGetTextPositionAtIndex(
    System.int Index
)
```

```
System.double IGetTextPositionAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

The return value is the following array of doubles :

$[\text{textPtX}, \text{textPtY}, \text{textPtZ}]$

where these text position values are offset values from the origin of this [ISFSymbol](#) object.

Call [ISFSymbol::GetTextCount](#) before calling this method to get the number of text items.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTextPositionAtIndex Method](#)
[ISFSymbol::GetText Method](#)
[ISFSymbol::GetTextAngleAtIndex Method](#)
[ISFSymbol::GetTextAtIndex Method](#)
[ISFSymbol::GetTextFontAtIndex Method](#)
[ISFSymbol::GetTextHeightAtIndex Method](#)
[ISFSymbol::GetTextInvertAtIndex Method](#)
[ISFSymbol::GetTextRefPositionAtIndex Method](#)
[ISFSymbol::SetText Method](#)

IGetTriangleAtIndex Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IGetTriangleAtIndex Method (ISFSymbol)

Gets the triangle at the specified index.

.NET Syntax

```
Function IGetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the triangle where the index begins at 0

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISFSymbol::GetTriangleCount](#) before calling this method to get the number of triangles in this surface finish symbol.

The return value is the following array of doubles :

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	= First XYZ vertex point
<i>vertexPt2</i> [3]	= Second XYZ vertex point
<i>vertexPt3</i> [3]	= Third XYZ vertex point
<i>isFilled</i>	= BOOLEAN returned as a double; True if triangle is filled, false if not
<i>lineType</i>	= Line type as defined in swLineTypes e .

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::GetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsAttached Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : IsAttached Method (ISFSymbol)

Gets whether the leader line for this surface finish symbol is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function IsAttached() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean  
  
value = instance.IsAttached()
```

C#

```
System.bool IsAttached()
```

C++/CLI

```
System.bool IsAttached();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a leaderline is attached, false if not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol.IsAttached](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)
[ISFSymbol::HasExtraLeader Method](#)
[ISFSymbol::GetLeaderAtIndex Method](#)
[ISFSymbol::GetLeaderCount Method](#)
[ISFSymbol::!GetLeaderAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Orientation Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : Orientation Property (ISFSymbol)

Gets whether the orientation of this surface finish symbol is relative to the model or entity to which it is attached.

.NET Syntax

Visual Basic (Declaration)

```
Property Orientation As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
instance.Orientation = value  
value = instance.Orientation
```

C#

```
System.int Orientation {get; set;}
```

C++/CLI

```
property System.int Orientation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Orientation as defined in [swSurfaceFinishSymbolOrientation](#) e

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::Orientation](#).

Remarks

If setting the value to `swSFOrientation_UserDefined`, then the angle at which the symbol is displayed does not change. Instead, use [ISFSymbol::SetAngle](#) to set the symbol to a user-specified angle, which automatically sets the orientation to `swSFOrientation_UserDefined`.

Use [ISFSymbol::GetAngle](#) to get the angle of the symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileAngle Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : ProfileAngle Property (ISFSymbol)

Gets or sets the profile angle of this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol
Dim value As System.Double

instance.ProfileAngle = value
value = instance.ProfileAngle
```

C#

```
System.double ProfileAngle {get; set;}
```

C++/CLI

```
property System.double ProfileAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Profile angle

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::ProfileAngle](#).

See Also

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileDirection Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : ProfileDirection Property (ISFSymbol)

Gets or sets the profile direction of this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileDirection As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Integer  
  
instance.ProfileDirection = value  
  
value = instance.ProfileDirection
```

C#

```
System.int ProfileDirection {get; set;}
```

C++/CLI

```
property System.int ProfileDirection {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Profile direction as defined by [swSFProfileDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::ProfileDirection](#).

Remarks

If this property sets `swSFProfileDirection_e.swSFProfileDirectionDefinedAngle`, then use [ISFSymbol::ProfileAngle](#) to specify the angle.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

Rotated Property (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : Rotated Property (ISFSymbol)

Obsolete. Superseded by [ISFSymbol::Orientation](#).

.NET Syntax

Visual Basic (Declaration)

Property Rotated As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim value As System.Boolean  
  
instance.Rotated = value  
value = instance.Rotated
```

C#

```
System.bool Rotated {get; set;}
```

C++/CLI

```
property System.bool Rotated {  
    System.bool get();  
    void set ( &    System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SFSymbol.Rotated](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAngle Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : SetAngle Method (ISFSymbol)

Sets the angle for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAngle( _  
    ByVal Angle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Angle As System.Double  
Dim value As System.Boolean  
  
value = instance.SetAngle(Angle)
```

C#

```
System.bool SetAngle(  
    System.double Angle  
)
```

C++/CLI

```
System.bool SetAngle(  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle
Angle in radians

Return Value

True if the angle is set, false if it is not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::SetAngle](#).

Remarks

This method automatically sets the orientation to swSFOrientation_UserDefined. See [ISFSymbol::Orientation](#) for details.

Use [ISFSymbol::GetAngle](#) to get the angle of the symbol.

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDirectionOfLay Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : SetDirectionOfLay Method (ISFSymbol)

Sets the direction of lay value for this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDirectionOfLay(  
    ByVal Direction As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Direction As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetDirectionOfLay(Direction)
```

C#

```
System.bool SetDirectionOfLay(  
    System.int Direction  
)
```

C++/CLI

```
System.bool SetDirectionOfLay(  
& System.int Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction of lay value as defined in [swSFLaySym_e](#)

Return Value

True if the direction of lay value is set, false if not

 Visual Basic for Applications (VBA) Syntax

See [SFSymbol::SetDirectionOfLay](#).

 Remarks

If an invalid direction of lay value is specified, the symbol is not changed, and false is returned.

To see the model or drawing changes caused by running this method, you must redraw your window. See [IModelDoc2::GraphicsRedraw2](#) for details.

To get the direction of lay value, use [ISFSymbol::GetDirectionOfLay](#).

 See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

 Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSymbol Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : SetSymbol Method (ISFSymbol)

Sets the type of symbol for this surface finish symbol.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetSymbol( _  
    ByVal Symbol As System.Integer, _  
    ByVal SurfaceTexture As System.Integer, _  
    ByVal AllAround As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim Symbol As System.Integer  
Dim SurfaceTexture As System.Integer  
Dim AllAround As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetSymbol(Symbol, SurfaceTexture, AllAround)
```

C#

```
System.bool SetSymbol(  
    System.int Symbol,  
    System.int SurfaceTexture,  
    System.bool AllAround  
)
```

C++/CLI

```
System.bool SetSymbol(  
& System.int Symbol,  
& System.int SurfaceTexture,  
& System.bool AllAround  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Symbol

Type of symbol as defined in [swSFSymType_e](#)

SurfaceTexture

Symbol surface text type as defined in [swSFSymType_e](#)

AllAround

True if symbol is All Around, false if symbol is Local

Return Value

True if symbol is set, false if it is not

Visual Basic for Applications (VBA) Syntax

See [ISFSymbol::SetSymbol](#).

Remarks

The Symbol argument must be one of the following values from the [swSFSymType_e](#) enumeration: swSFBasic, swSFMachining_Req, swSFDont_Machine, swSFJIS_No_Machining, swSFJIS_Basic, or swSFJIS_Machining_Req.

[ISFSymbol::GetSymbol](#) will get this value.

If the symbol is...	Then...
swSFJIS_No_Machining or swSFJIS_Basic	SurfaceTexture argument must be one of these values from the swSFSymType enumeration: swSFJIS_Surface_Texture_1, swSFJIS_Surface_Texture_2, swSFJIS_Surface_Texture_3, or swSFJIS_Surface_Texture_4. For any other symbol types, this argument is ignored, and 0 should be passed in. The ISFSymbol::GetSymbolSurfaceTexture method will get this value.
swSFBasic, swSFMachining_Req, or swSFDont_Machine	AllAround argument indicates whether this is an All Around or Local symbol. Use ISFSymbol::GetSymbolAllAround to get this value.

See Also

[ISFSymbol Interface](#)

[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSymbolType Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : SetSymbolType Method (ISFSymbol)

Obsolete. Superseded by [ISFSymbol::SetSymbol](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetSymbolType( _  
    ByVal SymbolType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISFSymbol  
Dim SymbolType As System.Integer  
Dim value As System.Boolean
```

 Copy Code

```
value = instance.SetSymbolType(SymbolType)
```

C#

```
System.bool SetSymbolType(  
    System.int SymbolType  
)
```

C++/CLI

```
System.bool SetSymbolType(  
& System.int SymbolType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SymbolType

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::SetSymbolType](#).

See Also

[ISFSymbol Interface](#)
[ISFSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetText Method (ISFSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISFSymbol Interface](#) : SetText Method (ISFSymbol)

Sets a text string in this surface finish symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetText( _  
    ByVal WhichOne As System.Integer, _  
    ByVal Text As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISFSymbol  
Dim WhichOne As System.Integer  
Dim Text As System.String  
Dim value As System.Boolean  
  
value = instance.SetText(WhichOne, Text)
```

C#

```
System.bool SetText(  
    System.int WhichOne,  
    System.string Text  
)
```

C++/CLI

```
System.bool SetText(  
& System.int WhichOne,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

Text item to set as defined in [swSurfaceFinishSymbolText_e](#)

Text

Text string

Return Value

True if the text string is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SFSymbol::SetText](#).

Remarks

If an invalid text item is specified, the symbol is not changed, and false is returned.

To see the model or drawing changes caused by running this method, you must redraw your window. See [IModelDoc2::GraphicsRedraw2](#) for details.

To get the text strings, use [ISFSymbol::GetText](#).

See Also

[ISFSymbol Interface](#)

[ISFSymbol Members](#)

[ISFSymbol::GetTextAngleAtIndex Method](#)

[ISFSymbol::GetTextAtIndex Method](#)

[ISFSymbol::GetTextCount Method](#)

[ISFSymbol::GetTextFontAtIndex Method](#)

[ISFSymbol::GetTextHeightAtIndex Method](#)

[ISFSymbol::GetTextInvertAtIndex Method](#)

[ISFSymbol::GetTextPositionAtIndex Method](#)

[ISFSymbol::GetTextRefPositionAtIndex Method](#)

[ISFSymbol::!GetTextPositionAtIndex Method](#)