

SOLIDWORKS API (.NET VBA C#) — Reference

(253/337): ISheet

SOLIDWORKS API Documentation (converted from CHM)

ISheet (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISheet Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheet Interface

Allows access to a sheet and objects on the sheet such as [BOM tables](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISheet
```

Visual Basic (Usage)



```
Dim instance As ISheet
```

C#

```
public interface ISheet
```

C++/CLI

```
public interface class ISheet
```

Visual Basic for Applications (VBA) Syntax

See [Sheet](#).

Example

[Get Sheet Properties and Insert Object \(C++\)](#)
[Copy and Paste Drawing Sheet \(C#\)](#)
[Copy and Paste Drawing Sheet \(VB.NET\)](#)
[Copy and Paste Drawing Sheet \(VBA\)](#)
[Get and Set Sheet Properties \(VBA\)](#)
[Activate Each View on Current Sheet \(VBA\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)

Remarks

A drawing document can consist of one or more sheets. Each sheet typically contains one or more [drawing views](#). Each drawing view is an oriented snapshot of a particular SOLIDWORKS model and a particular [configuration](#) of the model.

Accessors

[IDrawingDoc::GetCurrentSheet](#) and [IDrawingDoc::IGetCurrentSheet](#)
[IDrawingDoc::Sheet](#)
[IFamilyTableAnnotation::GetSheet](#)
[IR RevisionTableAnnotation::GetSheet](#)
[IView::Sheet](#)

Access Diagram

[Sheet](#)

See Also

[ISheet Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISheet Interface Members

[See Also](#) [Properties](#) [Methods](#)[SolidWorks.Interop.sldworks Namespace](#) : ISheet InterfaceThe following tables list the members exposed by [ISheet](#). Public Properties

Name	Description
 CustomPropertyView	Gets or sets the drawing view to use to set the custom information for this drawing sheet.
 FocusLocked	Gets or sets whether focus is locked on this sheet.
 IPageSetup	Gets the page setup for this sheet.
 PageSetup	Gets the page setup for this sheet.
 RevisionTable	Gets the revision table annotation for this drawing sheet.
 SheetFormatVisible	Gets or sets whether the sheet format is currently visible in this drawing sheet.
 TableAnchor	Gets the specified table anchor.
 TitleBlock	Gets the title block in this sheet.

[Top](#) Public Methods

Name	Description
 CreateOLEObject	Obsolete. Superseded by IModelDocExtension.CreateOLEObject and IModelDocExtension.CreateOLEObject .
 GetBomTable	Obsolete. Superseded by IView.GetBOMTable .
 GetDrawingZone	Gets the name of the drawing zone for the specified x and y coordinates on the sheet.
 GetID	Gets the ID of this drawing sheet.
 GetMagneticLines	Gets the magnetic lines on this drawing sheet.
 GetMagneticLinesCount	Gets the number of magnetic lines on this drawing sheet.
 GetName	Gets the name of the sheet.
 GetOLEObjectCount	Obsolete. Superseded by IModelDocExtension.GetOLEObjectCount .
 GetOLEObjectData	Obsolete. Superseded by ISwOLEObject .
 GetOLEObjectSettings	Obsolete. Superseded by ISwOLEObjectAspect , ISwOLEObject.Boundaries , ISwOLEObject.GetBoundaries , ISwOLEObject.SetBoundaries , ISwOLEObject.GetBuffer , and ISwOLEObject.Buffer .
 GetProperties	Obsolete. Superseded by ISheet.GetProperties2 .
 GetProperties2	Gets the properties for this sheet.
 GetSheetFormatName	Gets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.
 GetSize	Gets the size of the sheet and the corresponding standard sheet size.
 GetTemplateName	Gets the name of the template used by this sheet.
 GetTemplateSketch	Gets the sheet format sketch for this drawing sheet.
 GetViews	Gets the drawing views on this sheet.
 GetZoneMargin	Gets the specified zone margin.
 GetZoneSizeDistribution	Gets the zone size distribution.
 GetZoneSizeRegion	Gets the type of zone size region.
 ICreateOLEObject	Obsolete. Superseded by IModelDocExtension.CreateOLEObject and IModelDocExtension.CreateOLEObject .
 IGetBomTable	Obsolete. Superseded by IView.IGetBOMTable .
 IGetMagneticLines	Gets the magnetic lines on this drawing sheet.
 IGetOLEObjectData	Obsolete. Superseded by ISwOLEObject .

	
	IGetOLEObjectSettings Obsolete. Superseded by ISwOLEObjectAspect, ISwOLEObject.Boundaries, ISwOLEObject.IGetBoundaries, ISwOLEObject.ISetBoundaries, ISwOLEObject.IGetBuffer, and ISwOLEObject.Buffer.
	IGetProperties Obsolete. Superseded by ISheet.GetProperties2.
	InsertFamilyTable Inserts a family table in this drawing sheet.
	InsertMagneticLine Inserts a magnetic line at the specified start and end points on this drawing sheet.
	InsertRevisionTable Obsolete. Superseded by ISheet.InsertRevisionTable2
	InsertRevisionTable2 Inserts a revision table in this drawing sheet.
	InsertTitleBlock Inserts a title block into this drawing sheet.
	IsLoaded Gets whether this sheet is loaded.
	ReloadTemplate Reloads the sheet format from the original sheet format template.
	SaveFormat Saves the sheet format in the specified file.
	SetAsTableAnchor Sets the anchor for the specified table at a selected point in the sheet format.
	SetName Sets the sheet name.
	SetProperties Obsolete. Superseded by ISheet.SetProperties2.
	SetProperties2 Sets the properties for this sheet.
	SetScale Sets the scale for this drawing sheet.
	SetSheetFormatName Sets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.
	SetSize Sets the standard sheet size and the size of the sheet so that the drawing looks correct.
	SetTemplateName Sets the template name for the sheet format.
	SetZoneMargin Sets the specified zone margin.
	SetZoneSizeDistribution Sets the zone size distribution.
	SetZoneSizeRegion Sets the type of zone size region.

[Top](#)

 See Also

[ISheet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISheet Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISheet Interface

For a list of all members of this type, see [ISheet members](#).

 Public Methods

Name	Description
	CreateOLEObject Obsolete. Superseded by IModelDocExtension.CreateOLEObject and IModelDocExtension.CreateOLEObject.
	GetBomTable Obsolete. Superseded by IView.GetBOMTable.
	GetDrawingZone Gets the name of the drawing zone for the specified x and y coordinates on the sheet.
	GetID Gets the ID of this drawing sheet.
	GetMagneticLines Gets the magnetic lines on this drawing sheet.
	GetMagneticLinesCount Gets the number of magnetic lines on this drawing sheet.
	GetName Gets the name of the sheet.
	GetOLEObjectCount Obsolete. Superseded by IModelDocExtension.GetOLEObjectCount.
	GetOLEObjectData Obsolete. Superseded by ISwOLEObject.

	GetObjectSettings	Obsolete. Superseded by ISwOLEObjectAspect , ISwOLEObject-Boundaries , ISwOLEObject-IGetBoundaries , ISwOLEObject-ISetBoundaries , ISwOLEObject-IGetBuffer , and ISwOLEObject-Buffer .
	GetProperties	Obsolete. Superseded by ISheet-GetProperties2 .
	GetProperties2	Gets the properties for this sheet.
	GetSheetFormatName	Gets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.
	GetSize	Gets the size of the sheet and the corresponding standard sheet size.
	GetTemplateName	Gets the name of the template used by this sheet.
	GetTemplateSketch	Gets the sheet format sketch for this drawing sheet.
	GetViews	Gets the drawing views on this sheet.
	GetZoneMargin	Gets the specified zone margin.
	GetZoneSizeDistribution	Gets the zone size distribution.
	GetZoneSizeRegion	Gets the type of zone size region.
	ICreateOLEObject	Obsolete. Superseded by IModelDocExtension-CreateOLEObject and IModelDocExtension-ICreateOLEObject .
	IGetBomTable	Obsolete. Superseded by IView-IGetBomTable .
	IGetMagneticLines	Gets the magnetic lines on this drawing sheet.
	IGetOLEObjectData	Obsolete. Superseded by ISwOLEObject .
	IGetOLEObjectSettings	Obsolete. Superseded by ISwOLEObjectAspect , ISwOLEObject-Boundaries , ISwOLEObject-IGetBoundaries , ISwOLEObject-ISetBoundaries , ISwOLEObject-IGetBuffer , and ISwOLEObject-Buffer .
	IGetProperties	Obsolete. Superseded by ISheet-GetProperties2 .
	InsertFamilyTable	Inserts a family table in this drawing sheet.
	InsertMagneticLine	Inserts a magnetic line at the specified start and end points on this drawing sheet.
	InsertRevisionTable	Obsolete. Superseded by ISheet-InsertRevisionTable2 .
	InsertRevisionTable2	Inserts a revision table in this drawing sheet.
	InsertTitleBlock	Inserts a title block into this drawing sheet.
	IsLoaded	Gets whether this sheet is loaded.
	ReloadTemplate	Reloads the sheet format from the original sheet format template.
	SaveFormat	Saves the sheet format in the specified file.
	SetAsTableAnchor	Sets the anchor for the specified table at a selected point in the sheet format.
	SetName	Sets the sheet name.
	SetProperties	Obsolete. Superseded by ISheet-SetProperties2 .
	SetProperties2	Sets the properties for this sheet.
	SetScale	Sets the scale for this drawing sheet.
	SetSheetFormatName	Sets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.
	SetSize	Sets the standard sheet size and the size of the sheet so that the drawing looks correct.
	SetTemplateName	Sets the template name for the sheet format.
	SetZoneMargin	Sets the specified zone margin.
	SetZoneSizeDistribution	Sets the zone size distribution.
	SetZoneSizeRegion	Sets the type of zone size region.

[Top](#)

See Also

[ISheet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISheet Interface

For a list of all members of this type, see [ISheet members](#).

 Public Properties

Name	Description
 CustomPropertyView	Gets or sets the drawing view to use to set the custom information for this drawing sheet.
 FocusLocked	Gets or sets whether focus is locked on this sheet.
 IPageSetup	Gets the page setup for this sheet.
 PageSetup	Gets the page setup for this sheet.
 RevisionTable	Gets the revision table annotation for this drawing sheet.
 SheetFormatVisible	Gets or sets whether the sheet format is currently visible in this drawing sheet.
 TableAnchor	Gets the specified table anchor.
 TitleBlock	Gets the title block in this sheet.

[Top](#)

 See Also

[ISheet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateOLEObject Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : CreateOLEObject Method (ISheet)

Obsolete. Superseded by [IModelDocExtension::CreateOLEObject](#) and [IModelDocExtension::ICreateOLEObject](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function CreateOLEObject(  
    ByVal Aspect As System.Integer, _  
    ByVal Position As System.Object, _  
    ByVal Buffer As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Aspect As System.Integer  
Dim Position As System.Object  
Dim Buffer As System.Object  
Dim value As System.Boolean  
  
value = instance.CreateOLEObject(Aspect, Position, Buffer)
```

C#

```
System.bool CreateOLEObject(  
    System.int Aspect,  
    System.object Position,  
    System.object Buffer  
)
```

C++/CLI

```
System.bool CreateOLEObject(  
& System.int Aspect,
```

```
& System.Object^ Position,  
& System.Object^ Buffer  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Aspect

Position

Buffer

Visual Basic for Applications (VBA) Syntax

See [Sheet::CreateOLEObject](#).

See Also

[ISheet Interface](#)

[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomPropertyView Property (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : CustomPropertyView Property (ISheet)

Gets or sets the drawing view to use to set the custom information for this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Property CustomPropertyView As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.String  
  
instance.CustomPropertyView = value  
  
value = instance.CustomPropertyView
```

C#

```
System.string CustomPropertyView {get; set;}
```

C++/CLI

```
property System.String^ CustomPropertyView {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the drawing view from which to get the custom information

Visual Basic for Applications (VBA) Syntax

See [Sheet::CustomPropertyView](#).

Remarks

You can also use [IDrawingDoc::SetupSheet4](#) to set the name of the drawing view to use to set the custom information for this drawing sheet.

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2001Plus SP5, Revision Number 10.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

FocusLocked Property (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : FocusLocked Property (ISheet)

Gets or sets whether focus is locked on this sheet.

.NET Syntax

Visual Basic (Declaration)

Property FocusLocked As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Boolean  
  
instance.FocusLocked = value  
value = instance.FocusLocked
```

C#

```
System.bool FocusLocked {get; set;}
```

C++/CLI

```
property System.bool FocusLocked {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if focus locked on sheet, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::FocusLocked](#).

Example

[Insert Spline in Drawing_\(C++\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[IView::FocusLocked Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBomTable Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetBomTable Method (ISheet)

Obsolete. Superseded by [IView::GetBOMTable](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomTable() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object  
  
value = instance.GetBomTable()
```

C#

```
System.object GetBomTable()
```

C++/CLI

```
System.Object^ GetBomTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetBomTable](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDrawingZone Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetDrawingZone Method (ISheet)

Gets the name of the drawing zone for the specified x and y coordinates on the sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDrawingZone(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim X As System.Double  
Dim Y As System.Double  
Dim value As System.String  
  
value = instance.GetDrawingZone(X, Y)
```

C#

```
System.string GetDrawingZone(  
    System.double X,
```

```
        System.double Y  
    )
```

C++/CLI

```
System.String^ GetDrawingZone(  
&    System.double X,  
&    System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate
Y
y coordinate

Return Value

Name of the drawing zone

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetDrawingZone](#).

Example

[Get Name of Drawing Zone \(C#\)](#)
[Get Name of Drawing Zone \(VB.NET\)](#)
[Get Name of Drawing Zone \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[IDrawingDoc::NewSheet4 Method \(\)](#)
[IDrawingDoc::SetupSheet6 Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetID Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetID Method (ISheet)

Gets the ID of this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Integer  
  
value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ID of the drawing sheet

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetID](#).

Example

[Get ID of Active Configuration or Current Drawing Sheet \(VB.NET\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(VBA\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(C#\)](#)

Remarks

Each drawing sheet:

- is assigned a unique ID. This ID does not change if you change the name of the drawing sheet.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMagneticLines Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetMagneticLines Method (ISheet)

Gets the magnetic lines on this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMagneticLines() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object  
  
value = instance.GetMagneticLines()
```

C#

```
System.object GetMagneticLines()
```

C++/CLI

```
System.Object^ GetMagneticLines();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IMagneticLines](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetMagneticLines](#).

Remarks

Call [ISheet::GetMagneticLinesCount](#) to get the number of magnetic lines returned by this method.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetMagneticLines Method](#)
[ISheet::InsertMagneticLine Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetMagneticLinesCount Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetMagneticLinesCount Method (ISheet)

Gets the number of magnetic lines on this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMagneticLinesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Integer  
  
value = instance.GetMagneticLinesCount()
```

C#

```
System.int GetMagneticLinesCount()
```

C++/CLI

```
System.int GetMagneticLinesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of magnetic lines on this sheet

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetMagneticLinesCount](#).

Example

[Insert Magnetic Line \(VBA\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(C#\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::InsertMagneticLine Method](#)
[ISheet::GetMagneticLines Method](#)
[ISheet::GetMagneticLines Method](#)

Availability

GetName Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetName Method (ISheet)

Gets the name of the sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim value As System.String

value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sheet name

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetName](#).

Example

[Copy and Paste Drawing Sheet \(C#\)](#)
[Copy and Paste Drawing Sheet \(VB.NET\)](#)
[Copy and Paste Drawing Sheet \(VBA\)](#)
[Get and Set Sheet Properties \(VBA\)](#)
[Get Drawing View Names and Types \(VBA\)](#)
[Get Name of Drawing Sheet Template \(VBA\)](#)
[Get Sheet Numbers and Names \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(VB.NET\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(C#\)](#)

Remarks

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetSheetFormatName Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetName Method](#)
[ISheet::SetSheetFormatName Method](#)
[ISheet::SetTemplateName Method](#)

GetOLEObjectCount Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetOLEObjectCount Method (ISheet)

Obsolete. Superseded by [IModelDocExtension::GetOLEObjectCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetOLEObjectCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Integer  
  
value = instance.GetOLEObjectCount()
```

C#

```
System.int GetOLEObjectCount()
```

C++/CLI

```
System.int GetOLEObjectCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Sheet.GetOLEObjectCount](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetOLEObjectData Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetOLEObjectData Method (ISheet)

Obsolete. Superseded by [ISwOLEObject](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetOLEObjectData( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetOLEObjectData(Index)
```

C#

```
System.object GetOLEObjectData(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetOLEObjectData(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetOLEObjectData](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOLEObjectSettings Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetOLEObjectSettings Method (ISheet)

Obsolete. Superseded by [ISwOLEObjectAspect](#), [ISwOLEObject::Boundaries](#), [ISwOLEObject::IGetBoundaries](#), [ISwOLEObject::ISetBoundaries](#), [ISwOLEObject::IGetBuffer](#), and [ISwOLEObject::Buffer](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetOLEObjectSettings( _  
    ByVal Index As System.Integer, _  
    ByRef ByteCount As System.Integer, _  
    ByRef Aspect As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Index As System.Integer  
Dim ByteCount As System.Integer  
Dim Aspect As System.Integer  
Dim value As System.Object  
  
value = instance.GetOLEObjectSettings(Index, ByteCount, Aspect)
```

C#

```
System.object GetOLEObjectSettings(  
    System.int Index,  
    out System.int ByteCount,  
    out System.int Aspect  
)
```

C++/CLI

```
System.Object^ GetOLEObjectSettings(  
& System.int Index,  
& [Out] System.int ByteCount,  
& [Out] System.int Aspect  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

ByteCount

Aspect

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetOLEObjectSettings](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetProperties Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetProperties Method (ISheet)

Obsolete. Superseded by [ISheet::GetProperties2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetProperties() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object  
  
value = instance.GetProperties()
```

C#

```
System.object GetProperties()
```

C++/CLI

```
System.Object^ GetProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetProperties](#).

Example

[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)
[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)

Remarks

The return value is the following array of seven doubles:

[*paperSize*, *templateIn*, *scale1*, *scale2*, *firstAngle*, *width*, *height*, *sameCustomPrp*]

where:

paperSize = Paper size; this value is a long or integer packed into a double and is represented by the [swDwgPaperSizes_e](#) enumeration

templateIn = Template index; this value is a long or integer packed into a double and is represented by the [swDwgTemplates_e](#) enumeration

scale1 = Scale numerator

scale2 = Scale denominator

firstAngle = Value is a boolean packed into a double and returns true if the sheet is using first angle projection and false if not

width = Paper width

height = Paper height

NOTE: To ensure a correct return value, open the document as read-write or read-only. Insufficient information is available if you open the document as view-only.

You can also use [ISheet::GetSize](#) to get the size of the sheet and the standard sheet size.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::SetProperties Method](#)
[ISheet::GetSize Method](#)
[ISheet::SetSize Method](#)
[ISheet::SetScale Method](#)
[ISheet::PageSetup Property](#)
[ISheet::IPageSetup Property](#)
[ISheet::SetTemplateName Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::GetTemplateName Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProperties2 Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetProperties2 Method (ISheet)

Gets the properties for this sheet.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetProperties2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object  
  
value = instance.GetProperties2()
```

C#

```
System.object GetProperties2()
```

C++/CLI

```
System.Object^ GetProperties2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetProperties2](#).

Example

[Set Drawing Sheet Properties \(C#\)](#)
[Set Drawing Sheet Properties \(VB.NET\)](#)
[Set Drawing Sheet Properties \(VBA\)](#)

Remarks

The return value is the following array of eight doubles:

[*paperSize*, *templateIn*, *scale1*, *scale2*, *firstAngle*, *width*, *height*, *sameCustomProp*]

where:

paperSize = Paper size; this value is a long or integer packed into a double and is represented by the [swDwgPaperSizes_e](#) enumeration

templateIn = Template index; this value is a long or integer packed into a double and is represented by the [swDwgTemplates_e](#) enumeration

scale1 = Scale numerator

scale2 = Scale denominator

firstAngle = Value is a boolean packed into a double and returns true if the sheet is using first angle projection; false if not

width = Paper width

height = Paper height

sameCustomProp = Value is a boolean packed into a double and returns true if the **Same as sheet specified in Document Properties** in the Sheet Properties dialog is selected, false if not

NOTES:

- To ensure a correct return value, open the document as read-write or read-only. Insufficient information is available if you open the document as view-only.
- You can also use [ISheet::GetSize](#) to get the size of the sheet and the standard sheet size.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::SetProperties2 Method \(\)](#)
[ISheet::PageSetup Property \(\)](#)
[ISheet::GetSize Method \(\)](#)
[ISheet::SetSize Method \(\)](#)
[ISheet::GetTemplateName Method \(\)](#)
[ISheet::SetTemplateName Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetFormatName Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetSheetFormatName Method (ISheet)

Gets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetFormatName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.String  
  
value = instance.GetSheetFormatName()
```

C#

```
System.string GetSheetFormatName()
```

C++/CLI

```
System.String^ GetSheetFormatName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the sheet format

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetSheetFormatName](#).

Remarks

If the sheet does not have a sheet format, an empty string is returned.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetName Method](#)
[ISheet::SetName Method](#)
[ISheet::SetSheetFormatName Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetTemplateName Method](#)
[ISheet::SheetFormatVisible Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSize Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetSize Method (ISheet)

Gets the size of the sheet and the corresponding standard sheet size.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSize(  
    ByRef Width As System.Double, _  
    ByRef Height As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.Integer  
  
value = instance.GetSize(Width, Height)
```

C#

```
System.int GetSize(  
    out System.double Width,  
    out System.double Height  
)
```

C++/CLI

```
System.int GetSize(  
& [Out] System.double Width,  
& [Out] System.double Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Width
Width of sheet
Height
Height of sheet

Return Value

Paper size as defined in [swDwgPaperSizes](#) e

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetSize](#).

Example

[Get the Number of Lines Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)
[Get the Number of Lines Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get the Number of Lines Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetProperties Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::SetProperties Method](#)
[ISheet::SetSize Method](#)
[ISheet::IPageSetup Property](#)
[ISheet::PageSetup Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTemplateName Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetTemplateName Method (ISheet)

Gets the name of the template used by this sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTemplateName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.String  
  
value = instance.GetTemplateName()
```

C#

```
System.string GetTemplateName()
```

C++/CLI

```
System.String^ GetTemplateName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Template path name

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetTemplateName](#).

Example

[Get Name of Drawing Sheet Template \(VBA\)](#)
[Modify and Reload Sheet Format Template \(C#\)](#)
[Modify and Reload Sheet Format Template \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(VBA\)](#)

Remarks

To ensure a correct return value, open the document in edit mode.

If the sheet does not use a template, i.e., uses a custom layout, this method returns `"*.drt"`.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetTemplateSketch Method](#)
[ISheet::SetTemplateName Method](#)
[ISheet::GetProperties Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::SetProperties Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTemplateSketch Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetTemplateSketch Method (ISheet)

Gets the sheet format sketch for this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

Function GetTemplateSketch() As Sketch

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As Sketch
```

```
value = instance.GetTemplateSketch()
```

C#

```
Sketch GetTemplateSketch()
```

C++/CLI

```
Sketch^ GetTemplateSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetTemplateSketch](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetTemplateName Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetViews Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetViews Method (ISheet)

Gets the drawing views on this sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetViews() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object  
  
value = instance.GetViews()
```

C#

```
System.object GetViews()
```

C++/CLI

```
System.Object^ GetViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of drawing [views](#) on this sheet

Visual Basic for Applications (VBA) Syntax

See [Sheet.GetViews](#).

Example

[Get and Set Table Anchor of Hole Table \(C#\)](#)
[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
[Get and Set Table Anchor of Hole Table \(VBA\)](#)

Remarks

If this sheet is:

- Active, this method returns the drawing views, standard orientation views selected when the view was created, and any named views.
- Not active, this method returns only the drawing views.

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetZoneMargin Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetZoneMargin Method (ISheet)

Gets the specified zone margin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetZoneMargin( _  
    ByVal ZoneMargin As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim ZoneMargin As System.Integer  
Dim value As System.Double  
  
value = instance.GetZoneMargin(ZoneMargin)
```

C#

```
System.double GetZoneMargin(  
    System.int ZoneMargin  
)
```

C++/CLI

```
System.double GetZoneMargin(  
    & System.int ZoneMargin  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ZoneMargin
Margin type to retrieve as defined in [swZoneMargin_e](#)

Return Value

Zone margin

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetZoneMargin](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetZoneSizeDistribution Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetZoneSizeDistribution Method (ISheet)

Gets the zone size distribution.

.NET Syntax

Visual Basic (Declaration)

```
Function GetZoneSizeDistribution( _  
    ByRef Rows As System.Integer, _  
    ByRef Columns As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```

Dim instance As ISheet
Dim Rows As System.Integer
Dim Columns As System.Integer
Dim value As System.Integer

value = instance.GetZoneSizeDistribution(Rows, Columns)

```

C#

```

System.int GetZoneSizeDistribution(
    out System.int Rows,
    out System.int Columns
)

```

C++/CLI

```

System.int GetZoneSizeDistribution(
& [Out] System.int Rows,
& [Out] System.int Columns
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Rows

Zone rows; Nothing or null if the zone size distribution is swZoneSizeDistribution_e.swZoneSizeDistribution_50mmFromCenter

Columns

Zone columns; Nothing or null if the zone size distribution is swZoneSizeDistribution_e.swZoneSizeDistribution_50mmFromCenter

Return Value

Zone size distribution as defined by [swZoneSizeDistribution_e](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetZoneSizeDistribution](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetZoneSizeRegion Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : GetZoneSizeRegion Method (ISheet)

Gets the type of zone size region.

.NET Syntax

Visual Basic (Declaration)

```

Function GetZoneSizeRegion() As System.Integer

```

Visual Basic (Usage)



```

Dim instance As ISheet
Dim value As System.Integer

value = instance.GetZoneSizeRegion()

```

C#

```
System.int GetZoneSizeRegion()
```

C++/CLI

```
System.int GetZoneSizeRegion();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of zone size region as defined by [swRegionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::GetZoneSizeRegion](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateOLEObject Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : ICreateOLEObject Method (ISheet)

Obsolete. Superseded by [IModelDocExtension::CreateOLEObject](#) and [IModelDocExtension::ICreateOLEObject](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateOLEObject( _  
    ByVal Aspect As System.Integer, _  
    ByRef Position As System.Double, _  
    ByVal ByteCount As System.Integer, _  
    ByRef Buffer As System.Byte _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Aspect As System.Integer  
Dim Position As System.Double  
Dim ByteCount As System.Integer  
Dim Buffer As System.Byte  
Dim value As System.Boolean
```

```
value = instance.ICreateOLEObject(Aspect, Position, ByteCount, Buffer)
```

C#

```
System.bool ICreateOLEObject(  
    System.int Aspect,  
    ref System.double Position,  
    System.int ByteCount,  
    ref System.byte Buffer  
)
```

C++/CLI

```
System.bool ICreateOLEObject(  
& System.int Aspect,
```

```
& System.double% Position,  
& System.int ByteCount,  
& System.byte% Buffer  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Aspect

Position

ByteCount

Buffer

Visual Basic for Applications (VBA) Syntax

See [Sheet::ICreateOLEObject](#).

See Also

[ISheet Interface](#)

[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBomTable Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : IGetBomTable Method (ISheet)

Obsolete. Superseded by [IView::IGetBomTable](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBomTable() As BomTable
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As BomTable  
  
value = instance.IGetBomTable()
```

C#

```
BomTable IGetBomTable()
```

C++/CLI

```
BomTable^ IGetBomTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Sheet::IGetBomTable](#).

See Also

[ISheet Interface](#)

[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetMagneticLines Method (ISheet)

[See Also](#)



Gets the magnetic lines on this drawing sheet.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetMagneticLines( _  
    ByVal Count As System.Integer _  
) As MagneticLine
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Count As System.Integer  
Dim value As MagneticLine  
  
value = instance.IGetMagneticLines(Count)
```

C#

```
MagneticLine IGetMagneticLines(  
    System.int Count  
)
```

C++/CLI

```
MagneticLine^ IGetMagneticLines(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of magnetic lines returned by this method

Return Value

- In-process, unmanaged C++: Array of [IMagneticLines](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Example

Before calling this method, call [ISheet::GetMagneticLinesCount](#) to get the value for Count.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetMagneticLines Method](#)
[ISheet::InsertMagneticLine Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IGetOLEObjectData Method (ISheet)

[See Also](#)



Obsolete. Superseded by [ISwOLEObject](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetOLEObjectData( _
    ByVal Index As System.Integer, _
    ByRef Buffer As System.Byte _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim Index As System.Integer
Dim Buffer As System.Byte
Dim value As System.Boolean

value = instance.IGetOLEObjectData(Index, Buffer)
```

C#

```
System.bool IGetOLEObjectData(
    System.int Index,
    out System.byte Buffer
)
```

C++/CLI

```
System.bool IGetOLEObjectData(
    & System.int Index,
    & [Out] System.byte Buffer
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Buffer

Visual Basic for Applications (VBA) Syntax

See [Sheet::IGetOLEObjectData](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetOLEObjectSettings Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : IGetOLEObjectSettings Method (ISheet)

Obsolete. Superseded by [ISwOLEObjectAspect](#), [ISwOLEObject::Boundaries](#), [ISwOLEObject::IGetBoundaries](#), [ISwOLEObject::ISetBoundaries](#), [ISwOLEObject::IGetBuffer](#), and [ISwOLEObject::Buffer](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetOLEObjectSettings( _
    ByVal Index As System.Integer, _
    ByRef ByteCount As System.Integer, _
    ByRef Aspect As System.Integer, _
    ByRef Position As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim Index As System.Integer
```

```
Dim ByteCount As System.Integer
Dim Aspect As System.Integer
Dim Position As System.Double
Dim value As System.Boolean

value = instance.IGetOLEObjectSettings(Index, ByteCount, Aspect, Position)
```

C#

```
System.bool IGetOLEObjectSettings(
    System.int Index,
    out System.int ByteCount,
    out System.int Aspect,
    out System.double Position
)
```

C++/CLI

```
System.bool IGetOLEObjectSettings(
    & System.int Index,
    & [Out] System.int ByteCount,
    & [Out] System.int Aspect,
    & [Out] System.double Position
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

ByteCount

Aspect

Position

Visual Basic for Applications (VBA) Syntax

See [Sheet::IGetOLEObjectSettings](#).

See Also

[ISheet Interface](#)

[ISheet Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetProperties Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : IGetProperties Method (ISheet)

Obsolete. Superseded by [ISheet::GetProperties2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProperties() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim value As System.Double
```

```
value = instance.IGetProperties()
```

C#

```
System.double IGetProperties()
```

C++/CLI

```
System.double IGetProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of seven doubles:

```
[ paperSize, templateIn, scale1, scale2, firstAngle, width, height ]
```

where:

paperSize = Paper size. This value is a long or integer packed into a double and is represented by the [swDwgPaperSizes_e](#) enumeration.

templateIn = Template index. This value is a long or integer packed into a double and is represented by the [swDwgTemplates_e](#) enumeration.

scale1 = Scale numerator.

scale2 = Scale denominator.

firstAngle = Value is a Boolean packed into a double and returns true if the sheet is using first angle projection and false if not.

width = Paper width.

height = Paper height.

NOTE: To ensure a correct return value, open the document as read-write or read-only. Insufficient information is available if you open the document as view-only.

You can also use [ISheet::GetSize](#) to get the size of the sheet and the standard sheet size.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetProperties Method](#)
[ISheet::GetSize Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetProperties Method](#)
[ISheet::SetScale Method](#)
[ISheet::SetSize Method](#)
[ISheet::SetTemplateName Method](#)
[ISheet::IPageSetup Property](#)
[ISheet::PageSetup Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertFamilyTable Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : InsertFamilyTable Method (ISheet)

Inserts a family table in this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertFamilyTable( _  
    ByVal AttachToAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal ModelName As System.String, _  
    ByVal TableTemplateName As System.String, _  
    ByVal DimColumnType As System.Integer, _
```

```

    ByVal UseAllConfigs As System.Boolean, _
    ByVal ConfigArray As System.Object, _
    ByVal ItemNumberStart As System.Integer, _
    ByVal ItemNumberIncrement As System.Integer, _
    ByVal FollowConfigTreeOrder As System.Boolean _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As ISheet
Dim AttachToAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim ModelName As System.String
Dim TableTemplateName As System.String
Dim DimColumnType As System.Integer
Dim UseAllConfigs As System.Boolean
Dim ConfigArray As System.Object
Dim ItemNumberStart As System.Integer
Dim ItemNumberIncrement As System.Integer
Dim FollowConfigTreeOrder As System.Boolean
Dim value As System.Object

value = instance.InsertFamilyTable(AttachToAnchorPoint, X, Y, ModelName, TableTemplateName,
DimColumnType, UseAllConfigs, ConfigArray, ItemNumberStart, ItemNumberIncrement,
FollowConfigTreeOrder)

```

C#

```

System.object InsertFamilyTable(
    System.bool AttachToAnchorPoint,
    System.double X,
    System.double Y,
    System.string ModelName,
    System.string TableTemplateName,
    System.int DimColumnType,
    System.bool UseAllConfigs,
    System.object ConfigArray,
    System.int ItemNumberStart,
    System.int ItemNumberIncrement,
    System.bool FollowConfigTreeOrder
)

```

C++/CLI

```

System.Object^ InsertFamilyTable(
    & System.bool AttachToAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.String^ ModelName,
    & System.String^ TableTemplateName,
    & System.int DimColumnType,
    & System.bool UseAllConfigs,
    & System.Object^ ConfigArray,
    & System.int ItemNumberStart,
    & System.int ItemNumberIncrement,
    & System.bool FollowConfigTreeOrder
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AttachToAnchorPoint

True to insert the family table at the existing family table anchor point, false to anchor the table at the point specified by X and Y

X

X coordinate for the placement of the family table annotation

Y

Y coordinate for the placement of the family table annotation

ModelName

Name of part or assembly on whose drawing sheet to insert the family table

TableTemplateName

Path and filename of the template that corresponds to this type of table (see **Remarks**)

DimColumnType

Dimension column type as defined by [swFamilyTableDimColumnType_e](#)

UseAllConfigs
True to use all configurations, false to only use ConfigArray configurations
ConfigArray
Array of configurations to use; valid only if UseAllConfigs is false
ItemNumberStart
Starting item number
ItemNumberIncrement
Item number increment
FollowConfigTreeOrder
True to follow the configuration tree order, false to not

Return Value

[IFamilyTableAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet.InsertFamilyTable](#).

Remarks

Family tables display the variations in part and assembly configurations or custom properties in table format.

By default, the family table templates are in *install_dir\lang\language* and have a filename extension of **.sldfamtblt**. The template and table must be of the same type. For example, you must specify TableTemplate with *install_dir\lang\English\family-standard.sldfamtblt* if you want to insert the English version of a family table.

For more information about family tables, see the **SOLIDWORKS Design user-interface Help > Detailing and Drawings > Tables > Family Tables** topics.

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertMagneticLine Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : InsertMagneticLine Method (ISheet)

Inserts a magnetic line at the specified start and end points on this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertMagneticLine( _  
    ByVal StartPoint As MathPoint, _  
    ByVal EndPoint As MathPoint _  
) As MagneticLine
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim StartPoint As MathPoint  
Dim EndPoint As MathPoint  
Dim value As MagneticLine
```

```
value = instance.InsertMagneticLine(StartPoint, EndPoint)
```

C#

```
MagneticLine InsertMagneticLine(  
    MathPoint StartPoint,  
    MathPoint EndPoint  
)
```

C++/CLI

```
MagneticLine^ InsertMagneticLine(  
& MathPoint^ StartPoint,  
& MathPoint^ EndPoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[StartPoint](#)
[IMathPoint](#)
[EndPoint](#)
[IMathPoint](#)

Return Value

[IMagneticLine](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::InsertMagneticLine](#).

Example

[Insert Magnetic Line \(C#\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetMagneticLines Method](#)
[ISheet::GetMagneticLinesCount Method](#)
[ISheet::IGetMagneticLines Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRevisionTable Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : InsertRevisionTable Method (ISheet)

Obsolete. Superseded by [ISheet::InsertRevisionTable2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRevisionTable( _  
    ByVal UseAnchorPoint As System.Boolean, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal TableTemplate As System.String _  
) As RevisionTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim UseAnchorPoint As System.Boolean  
Dim X As System.Double  
Dim Y As System.Double  
Dim AnchorType As System.Integer  
Dim TableTemplate As System.String  
Dim value As RevisionTableAnnotation
```

```
value = instance.InsertRevisionTable(UseAnchorPoint, X, Y, AnchorType, TableTemplate)
```

C#

```
RevisionTableAnnotation InsertRevisionTable(  
    System.bool UseAnchorPoint,  
    System.double X,  
    System.double Y,  
    System.int AnchorType,  
    System.string TableTemplate  
)
```

C++/CLI

```
RevisionTableAnnotation^ InsertRevisionTable(  
& System.bool UseAnchorPoint,  
& System.double X,  
& System.double Y,  
& System.int AnchorType,  
& System.String^ TableTemplate  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

If true and the appropriate sheet format anchor point exists, then insert table at this point; if false, then use the values specified for the X and Y arguments as the insertion point

X

X coordinate for the placement of the revision table annotation

Y

Y coordinate for the placement of this revision table annotation

AnchorType

Anchor type as defined by [swBOMConfigurationAnchorType_e](#)

TableTemplate

Path and filename of the template that you want to use that corresponds to this type of table (see **Remarks**)

Return Value

[Revision table](#) or null if a revision table on the sheet already exists

Visual Basic for Applications (VBA) Syntax

See [Sheet::InsertRevisionTable](#).

Remarks

By default, the revision table templates are in the <install_dir>\lang\<language> folder and have a filename extension of .sldrevtbt. The template and table must be of the same type. For example, you would specify **C:\Program Files\SOLIDWORKS\lang\English\standard revision block.sldrevtbt** for TableTemplate if you wanted to insert an English-version of the revision block table template.

See Also

[ISheet Interface](#)

[ISheet Members](#)

[ISheet::RevisionTable Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRevisionTable2 Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : InsertRevisionTable2 Method (ISheet)

Inserts a revision table in this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRevisionTable2( _
    ByVal UseAnchorPoint As System.Boolean, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal AnchorType As System.Integer, _
    ByVal TableTemplate As System.String, _
    ByVal Shape As System.Integer, _
    ByVal AutoUpdateZoomCells As System.Boolean _
) As RevisionTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim TableTemplate As System.String
Dim Shape As System.Integer
Dim AutoUpdateZoomCells As System.Boolean
Dim value As RevisionTableAnnotation
```

```
value = instance.InsertRevisionTable2(UseAnchorPoint, X, Y, AnchorType, TableTemplate, Shape,
AutoUpdateZoomCells)
```

C#

```
RevisionTableAnnotation InsertRevisionTable2(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string TableTemplate,
    System.int Shape,
    System.bool AutoUpdateZoomCells
)
```

C++/CLI

```
RevisionTableAnnotation^ InsertRevisionTable2(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.String^ TableTemplate,
    & System.int Shape,
    & System.bool AutoUpdateZoomCells
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

True to insert the revision table at the existing revision table anchor point, false to anchor the table at the point specified by X and Y

X

X coordinate for the placement of the revision table annotation

Y

Y coordinate for the placement of this revision table annotation

AnchorType

Anchor type as defined by [swBOMConfigurationAnchorType_e](#)

TableTemplate

Path and filename of the template that corresponds to this type of table (see **Remarks**)

Shape

Revision symbol shape as defined in [swRevisionTableSymbolShape_e](#)

AutoUpdateZoomCells

True to automatically update zone cells, false to not

Return Value

[Revision table](#) or null if a revision table already exists

Example

[Create Drawing Sheet Zones \(VBA\)](#)
[Create Drawing Sheet Zones \(VB.NET\)](#)
[Create Drawing Sheet Zones \(C#\)](#)

Remarks

By default, the revision table templates are in *install_dir\lang\language* and have a filename extension of **.sldrevtbt**. The template and table must be of the same type. For example, you must specify TableTemplate with *install_dir\lang\English\standard revision block.sldrevtbt* if you want to insert the English version of a revision block table.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::RevisionTable Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertTitleBlock Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : InsertTitleBlock Method (ISheet)

Inserts a title block into this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertTitleBlock( _  
    ByVal Notes As System.Object _  
) As TitleBlock
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Notes As System.Object  
Dim value As TitleBlock  
  
value = instance.InsertTitleBlock(Notes)
```

C#

```
TitleBlock InsertTitleBlock(  
    System.object Notes  
)
```

C++/CLI

```
TitleBlock^ InsertTitleBlock(  
& System.Object^ Notes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Notes

Array of notes or nothing (see **Remarks**)

Return Value

[Title block](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::InsertTitleBlock](#).

Example

[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)

Remarks

The Notes parameter can contain one or more more notes or nothing. If the Notes parameter contains a note, or notes, then the note, or notes, is expected to be a Dispatch pointer, or pointers, to the [INote](#) object, or objects, to include as part of the title block being created.

Only one title block can exist in a sheet.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::TitleBlock Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPageSetup Property (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : IPageSetup Property (ISheet)

Gets the page setup for this sheet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property IPageSetup As PageSetup

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As PageSetup  
  
value = instance.IPageSetup
```

C#

```
PageSetup IPageSetup {get;}
```

C++/CLI

```
property PageSetup^ IPageSetup {  
    PageSetup^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Page setup](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::IPageSetup](#).

Remarks

Page setup values are overridden on a sheet by sheet basis.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::PageSetup Property](#)
[ISheet::GetProperties Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::SetProperties Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsLoaded Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : IsLoaded Method (ISheet)

Gets whether this sheet is loaded.

.NET Syntax

Visual Basic (Declaration)

```
Function IsLoaded() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Boolean  
  
value = instance.IsLoaded()
```

C#

```
System.bool IsLoaded()
```

C++/CLI

```
System.bool IsLoaded();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the sheet is loaded, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::IsLoaded](#).

Example

[Get Loaded Sheets \(C#\)](#)
[Get Loaded Sheets \(VB.NET\)](#)
[Get Loaded Sheets \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2009 SP3, Revision Number 17.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PageSetup Property (ISheet)

[See Also](#)



Gets the page setup for this sheet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PageSetup As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Object
```

```
value = instance.PageSetup
```

C#

```
System.Object PageSetup {get;}
```

C++/CLI

```
property System.Object^ PageSetup {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Page setup](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::PageSetup](#).

Remarks

Page setup values are overridden on a sheet by sheet basis.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::IPageSetup Property](#)
[ISheet::GetProperties Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::SetProperties Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ReloadTemplate Method (ISheet)

[See Also](#) [Example](#)



Reloads the sheet format from the original sheet format template.

.NET Syntax

Visual Basic (Declaration)

```
Function ReloadTemplate(  
    ByVal KeepNoteChanges As System.Boolean  
) As System.Integer
```

```
Dim instance As ISheet
Dim KeepNoteChanges As System.Boolean
Dim value As System.Integer

value = instance.ReloadTemplate(KeepNoteChanges)
```

C#

```
System.int ReloadTemplate(
    System.bool KeepNoteChanges
)
```

C++/CLI

```
System.int ReloadTemplate(
    & System.bool KeepNoteChanges
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

KeepNoteChanges

True to keep note modifications made to the sheet format and reload all other elements from the original sheet format template, false to reload all elements from the original sheet format template and discard any note modifications made to the sheet format

Return Value

Status as defined in [swReloadTemplateResult](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::ReloadTemplate](#).

Example

[Modify and Reload Sheet Format Template \(C#\)](#)
[Modify and Reload Sheet Format Template \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(VBA\)](#)

Remarks

If new notes are added or existing notes modified or deleted on the sheet format, then specifying true for KeepNoteChanges:

- adds the new notes to the sheet format template, but does not duplicate the new notes on the sheet format.
- restores any deleted notes from the sheet format template on the sheet format.
- duplicates all other notes in their original position from the sheet format template on the sheet format.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[IDrawingDoc::EditTemplate Method \(\)](#)
[ISheet::SaveFormat Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RevisionTable Property (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : RevisionTable Property (ISheet)

Gets the revision table annotation for this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property RevisionTable As RevisionTableAnnotation

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As RevisionTableAnnotation  
  
value = instance.RevisionTable
```

C#

```
RevisionTableAnnotation RevisionTable {get;}
```

C++/CLI

```
property RevisionTableAnnotation^ RevisionTable {  
    RevisionTableAnnotation^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Revision table annotation](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::RevisionTable](#).

Example

[Get Revision Table Annotation \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::InsertRevisionTable Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SaveFormat Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SaveFormat Method (ISheet)

Saves the sheet format in the specified file.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveFormat(  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.SaveFormat(FileName)
```

C#

```
System.bool SaveFormat(  
    System.string FileName  
)
```

C++/CLI

```
System.bool SaveFormat(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and file name to which to save the sheet format (see **Remarks**)

Return Value

True if the sheet format is saved to the specified file, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SaveFormat](#).

Example

[Modify and Reload Sheet Format Template \(C#\)](#)
[Modify and Reload Sheet Format Template \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(VBA\)](#)

Remarks

You must specify the path, file name, and filename extension to which to save the sheet format. Use **.slddrt** for the filename extension.

Before calling this method, use [IDrawingDoc::ActivateSheet](#) to make the sheet active.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[IDrawingDoc::EditTemplate Method \(\)](#)
[ISheet::ReloadTemplate Method \(\)](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAsTableAnchor Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetAsTableAnchor Method (ISheet)

Sets the anchor for the specified table at a selected point in the sheet format.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAsTableAnchor( _  
    ByVal TableType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISheet  
Dim TableType As System.Integer  
Dim value As System.Object
```



```
value = instance.SetAsTableAnchor(TableType)
```

C#

```
System.object SetAsTableAnchor(  
    System.int TableType  
)
```

C++/CLI

```
System.Object^ SetAsTableAnchor(  
& System.int TableType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableType
Table for which an anchor is required as defined in [swTableAnnotationType_e](#)

Return Value

[ITableAnchor](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetAsTableAnchor](#).

Example

[Set Table Anchors in Sheet Formats \(VBA\)](#)
[Set Table Anchors in Sheet Formats \(VB.NET\)](#)
[Set Table Anchors in Sheet Formats \(C#\)](#)

Remarks

Before calling this method, you must call:

1. [IDrawingDoc::EditTemplate](#) to edit the sheet format.
2. [IModelDoc2::EditSketch](#) to create a sketch.
3. [ISketchManager::CreatePoint](#) to create a sketch point where to position the table anchor.

If an anchor already exists for the table, then this method moves the anchor of that table to the selected position.

After calling this method you must call:

1. [IDrawingDoc::EditSheet](#)
2. [IModelDoc2::EditSketch](#)
3. [IModelDoc2::ForceRebuild3](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::TableAnchor Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetName Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetName Method (ISheet)

Sets the sheet name.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetName( _  
    ByVal NameIn As System.String _
```

)

Visual Basic (Usage)



```
Dim instance As ISheet
Dim NameIn As System.String

instance.SetName(NameIn)
```

C#

```
void SetName(
    System.string NameIn
)
```

C++/CLI

```
void SetName(
    & System.String^ NameIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn

Name for the sheet

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetName](#).

Example

[Get ID of Active Configuration or Current Drawing Sheet \(VB.NET\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(VBA\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(C#\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetName Method](#)
[ISheet::GetSheetFormatName Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetSheetFormatName Method](#)
[ISheet::SetTemplateName Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetProperties Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetProperties Method (ISheet)

Obsolete. Superseded by [ISheet::SetProperties2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetProperties( _
    ByVal PaperSz As System.Integer, _
    ByVal Templ As System.Integer, _
    ByVal Scale1 As System.Double, _
    ByVal Scale2 As System.Double, _
    ByVal FirstAngle As System.Boolean, _
    ByVal Width As System.Double, _
    ByVal Height As System.Double _
)
```

Visual Basic (Usage)



```

Dim instance As ISheet
Dim PaperSz As System.Integer
Dim Templ As System.Integer
Dim Scale1 As System.Double
Dim Scale2 As System.Double
Dim FirstAngle As System.Boolean
Dim Width As System.Double
Dim Height As System.Double

```

```
instance.SetProperties(PaperSz, Templ, Scale1, Scale2, FirstAngle, Width, Height)
```

C#

```

void SetProperties(
    System.int PaperSz,
    System.int Templ,
    System.double Scale1,
    System.double Scale2,
    System.bool FirstAngle,
    System.double Width,
    System.double Height
)

```

C++/CLI

```

void SetProperties(
    & System.int PaperSz,
    & System.int Templ,
    & System.double Scale1,
    & System.double Scale2,
    & System.bool FirstAngle,
    & System.double Width,
    & System.double Height
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PaperSz

Paper size as defined in [swDwgPaperSizes_e](#)

Templ

Template as defined in [swDwgTemplates_e](#)

Scale1

Scale numerator

Scale2

Scale denominator

FirstAngle

True if you want first angle projection, false if not

Width

Custom paper width if PaperSz = swDwgPaperSizes_e.swDwgPapersUserDefined

Height

Custom paper height if PaperSz = swDwgPaperSizes_e.swDwgPapersUserDefined

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetProperties](#).

Remarks

If you specify a custom template, then the current custom template is used by this sheet until you call [ISheet::SetTemplateName](#) and pass in a different custom template name.

NOTE: If Templ does not match the PaperSz specification, then you get a template that does not fit the paper size. This parameter does not override the PaperSz setting. Also, if you change the scale of the sheet using Scale1 and Scale2, then any drawing view that is set to use the sheet's scale takes the new scale setting.

You can also use [ISheet::SetSize](#) to set the size of the sheet and the standard sheet size.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetProperties Method](#)
[ISheet::IGetProperties Method](#)
[ISheet::GetSize Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::IPageSetup Property](#)
[ISheet::PageSetup Property](#)
[ISheet::SetTemplateName Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetProperties2 Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetProperties2 Method (ISheet)

Sets the properties for this sheet.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetProperties2( _  
    ByVal PaperSz As System.Integer, _  
    ByVal Templ As System.Integer, _  
    ByVal Scale1 As System.Double, _  
    ByVal Scale2 As System.Double, _  
    ByVal FirstAngle As System.Boolean, _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double, _  
    ByVal SameCustomPropAsSheetInDocProp As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim PaperSz As System.Integer  
Dim Templ As System.Integer  
Dim Scale1 As System.Double  
Dim Scale2 As System.Double  
Dim FirstAngle As System.Boolean  
Dim Width As System.Double  
Dim Height As System.Double  
Dim SameCustomPropAsSheetInDocProp As System.Boolean
```

```
instance.SetProperties2(PaperSz, Templ, Scale1, Scale2, FirstAngle, Width, Height,  
SameCustomPropAsSheetInDocProp)
```

C#

```
void SetProperties2(  
    System.int PaperSz,  
    System.int Templ,  
    System.double Scale1,  
    System.double Scale2,  
    System.bool FirstAngle,  
    System.double Width,  
    System.double Height,  
    System.bool SameCustomPropAsSheetInDocProp  
)
```

C++/CLI

```
void SetProperties2(  
& System.int PaperSz,  
& System.int Templ,
```

```
& System.double Scale1,
& System.double Scale2,
& System.bool FirstAngle,
& System.double Width,
& System.double Height,
& System.bool SameCustomPropAsSheetInDocProp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PaperSz
Paper size as defined in [swDwgPaperSizes_e](#) (see **Remarks**)

Templ
Template as defined in [swDwgTemplates_e](#) (see **Remarks**)

Scale1
Scale numerator (see **Remarks**)
Scale2
Scale denominator (see **Remarks**)
FirstAngle

True if you want first angle projection, false if not

Width
Custom paper width if PaperSz = swDwgPaperSizes_e.swDwgPaperUserDefined (see **Remarks**)
Height
Custom paper height if PaperSz = swDwgPaperSizes_e.swDwgPaperUserDefined (see **Remarks**)
SameCustomPropAsSheetInDocProp
True to select the **Same as sheet specified in Document Properties** check box in the Sheet Properties dialog, false to not (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [Sheet::SetProperties2](#).

 Example

[Set Drawing Sheet Properties \(C#\)](#)
[Set Drawing Sheet Properties \(VB.NET\)](#)
[Set Drawing Sheet Properties \(VBA\)](#)

 Remarks

If you...	Then...
Specify a custom template	The current custom template is used by this sheet until you call ISheet::SetTemplateName and pass in a different custom template name.
Specify a value for Templ that does not match PaperSz	The template does not fit the paper size. Templ does not override the PaperSz setting.
Change the scale of the sheet using Scale1 and Scale2	Any drawing view that is set to use the sheet's scale takes the new scale setting.
Set SameCustomPropAsSheetInDocProp to true	The Tools > Options > Document Properties > Drawing Sheets > Use custom property values from the sheet check box must be preselected.

NOTE: You can also use [ISheet::SetSize](#) to set the size of the sheet and the standard sheet size.

 See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetProperties2 Method \(\)](#)
[ISheet::GetTemplateName Method \(\)](#)
[ISheet::SetTemplateName Method \(\)](#)
[ISheet::GetSize Method \(\)](#)
[ISheet::PageSetup Property \(\)](#)

 Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetScale Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetScale Method (ISheet)

Sets the scale for this drawing sheet.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetScale( _
    ByVal Numerator As System.Double, _
    ByVal Denominator As System.Double, _
    ByVal ScaleAnnoPosition As System.Boolean, _
    ByVal ScaleAnnoTextHeight As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet
Dim Numerator As System.Double
Dim Denominator As System.Double
Dim ScaleAnnoPosition As System.Boolean
Dim ScaleAnnoTextHeight As System.Boolean
Dim value As System.Boolean

value = instance.SetScale(Numerator, Denominator, ScaleAnnoPosition, ScaleAnnoTextHeight)
```

C#

```
System.bool SetScale(
    System.double Numerator,
    System.double Denominator,
    System.bool ScaleAnnoPosition,
    System.bool ScaleAnnoTextHeight
)
```

C++/CLI

```
System.bool SetScale(
    & System.double Numerator,
    & System.double Denominator,
    & System.bool ScaleAnnoPosition,
    & System.bool ScaleAnnoTextHeight
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Numerator

First value in the scale ratio (n : n)

Denominator

Second value in the scale ratio (n : n)

ScaleAnnoPosition

True if the position of the annotations is scaled, false if not

ScaleAnnoTextHeight

True if the text height of the annotations is scaled, false if not

Return Value

True if the scale is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetScale](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

You can get the two scale values from the sheet by using [ISheet::GetProperties](#) or [ISheet::IGetProperties](#).

You can also set the two scale values by using [IDrawingDoc::SetupSheet4](#) or [ISheet::SetProperties](#). However, you cannot specify the scaling of the position or text height of the annotations. Instead, both of these methods automatically scale the position of the annotations but do not scale the text height of the annotations when the drawing is changed.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetSize Method](#)

Availability

SOLIDWORKS 2001Plus SP5, Revision Number 10.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSheetFormatName Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetSheetFormatName Method (ISheet)

Sets the name of the sheet format of this drawing sheet, as displayed in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSheetFormatName( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SetSheetFormatName(Name)
```

C#

```
System.bool SetSheetFormatName(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetSheetFormatName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of the sheet format

Return Value

True if the name of the sheet format is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetSheetFormatName](#).

Remarks

The name that you specify must:

- be unique in the FeatureManager design tree.
- Not contain any of the SOLIDWORKS reserved special characters.

If either of these conditions is not met, then this method returns false, and the name is not changed. If this sheet does not have a sheet format, this method has no effect.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetName Method](#)
[ISheet::GetSheetFormatName Method](#)
[ISheet::GetTemplateName Method](#)
[ISheet::SetName Method](#)
[ISheet::SetTemplateName Method](#)
[ISheet::SheetFormatVisible Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSize Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetSize Method (ISheet)

Sets the standard sheet size and the size of the sheet so that the drawing looks correct.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSize( _  
    ByVal Size As System.Integer, _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Size As System.Integer  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.Boolean  
  
value = instance.SetSize(Size, Width, Height)
```

C#

```
System.bool SetSize(  
    System.int Size,  
    System.double Width,  
    System.double Height  
)
```

C++/CLI

```
System.bool SetSize(  
& System.int Size,  
& System.double Width,  
& System.double Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Size
Paper size as defined in [swDwgPaperSizes_e](#)
Width
Width of sheet
Height
Height of sheet

Return Value

True if the size of the sheet is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetSize](#).

Example

[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetSize Method](#)
[ISheet::GetProperties Method](#)
[ISheet::PageSetup Property](#)
[ISheet::IPageSetup Property](#)
[ISheet::SetProperties Method](#)
[ISheet::IGetProperties Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTemplateName Method (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetTemplateName Method (ISheet)

Sets the template name for the sheet format.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTemplateName( _  
    ByVal NameIn As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim NameIn As System.String  
  
instance.SetTemplateName(NameIn)
```

C#

```
void SetTemplateName(  
    System.string NameIn  
)
```

C++/CLI

```
void SetTemplateName(  
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Path name of the sheet format template

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetTemplateName](#).

Example

[Get and Set Whether to Hide Cutting Line Shoulders \(C#\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VB.NET\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VBA\)](#)

Remarks

If you want to use:

- a custom template name, before calling this method, call [ISheet::SetProperties](#) and specify `swDwgTemplates_e.swDwgTemplateCustom` for the `Templ` parameter.
- one of the standard templates provided by SOLIDWORKS, then there is no need to call `ISheet::SetTemplateName`. Instead, call `ISheet::SetProperties` and specify the appropriate enumerator for the `Templ` parameter.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetTemplateName Method](#)
[ISheet::GetTemplateSketch Method](#)
[ISheet::GetProperties Method](#)
[ISheet::!GetProperties Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetZoneMargin Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetZoneMargin Method (ISheet)

Sets the specified zone margin.

.NET Syntax

Visual Basic (Declaration)

```
Function SetZoneMargin( _  
    ByVal ZoneMarginType As System.Integer, _  
    ByVal MarginValue As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim ZoneMarginType As System.Integer  
Dim MarginValue As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetZoneMargin(ZoneMarginType, MarginValue)
```

C#

```
System.bool SetZoneMargin(  
    System.int ZoneMarginType,  
    System.double MarginValue  
)
```

C++/CLI

```
System.bool SetZoneMargin(  
& System.int ZoneMarginType,  
& System.double MarginValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ZoneMarginType
Margin type as defined in [swZoneMargin_e](#)
MarginValue
Margin

Return Value

True if zone margin successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetZoneMargin](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetZoneSizeDistribution Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetZoneSizeDistribution Method (ISheet)

Sets the zone size distribution.

.NET Syntax

Visual Basic (Declaration)

```
Function SetZoneSizeDistribution( _  
    ByVal Type As System.Integer, _  
    ByVal Rows As System.Integer, _  
    ByVal Column As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim Type As System.Integer  
Dim Rows As System.Integer  
Dim Column As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetZoneSizeDistribution(Type, Rows, Column)
```

C#

```
System.bool SetZoneSizeDistribution(  
    System.int Type,  
    System.int Rows,  
    System.int Column  
)
```

C++/CLI

```
System.bool SetZoneSizeDistribution(  
& System.int Type,  
& System.int Rows,  
& System.int Column  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of zone size distribution as defined by [swZoneSizeDistribution_e](#)

Rows

Number of zone rows; valid only if Type is swZoneSizeDistribution.swZoneSizeDistribution_EvenlySized

Column

Number of zone columns; valid only if Type is swZoneSizeDistribution.swZoneSizeDistribution_EvenlySized

Return Value

True if zone size distribution successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetZoneSizeDistribution](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetZoneSizeRegion Method (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SetZoneSizeRegion Method (ISheet)

Sets the type of zone size region.

.NET Syntax

Visual Basic (Declaration)

```
Function SetZoneSizeRegion( _  
    ByVal RegionType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim RegionType As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetZoneSizeRegion(RegionType)
```

C#

```
System.bool SetZoneSizeRegion(  
    System.int RegionType  
)
```

C++/CLI

```
System.bool SetZoneSizeRegion(  
& System.int RegionType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RegionType

Type of zone size region as defined by [swRegionType_e](#)

Return Value

True if zone size region successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SetZoneSizeRegion](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SheetFormatVisible Property (ISheet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : SheetFormatVisible Property (ISheet)

Gets or sets whether the sheet format is currently visible in this drawing sheet.

.NET Syntax

Visual Basic (Declaration)

Property SheetFormatVisible As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As System.Boolean  
  
instance.SheetFormatVisible = value  
value = instance.SheetFormatVisible
```

C#

```
System.bool SheetFormatVisible {get; set;}
```

C++/CLI

```
property System.bool SheetFormatVisible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the sheet format is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [Sheet::SheetFormatVisible](#).

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::GetSheetFormatName Method](#)
[ISheet::SetSheetFormatName Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TableAnchor Property (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : TableAnchor Property (ISheet)

Gets the specified table anchor.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TableAnchor( _  
    ByVal TableType As System.Integer _  
) As TableAnchor
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim TableType As System.Integer  
Dim value As TableAnchor  
  
value = instance.TableAnchor(TableType)
```

C#

```
TableAnchor TableAnchor(  
    System.int TableType  
) {get;}
```

C++/CLI

```
property TableAnchor^ TableAnchor {  
    TableAnchor^ get(System.int TableType);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableType
Table type as defined in [swTableAnnotationType_e](#)

Property Value

[Table anchor](#)

Visual Basic for Applications (VBA) Syntax

See [Sheet::TableAnchor](#).

Example

[Get and Set Table Anchor of Hole Table \(C#\)](#)
[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
[Get and Set Table Anchor of Hole Table \(VBA\)](#)

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::SetAsTableAnchor Method \(\)](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TitleBlock Property (ISheet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheet Interface](#) : TitleBlock Property (ISheet)

Gets the title block in this sheet.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TitleBlock As TitleBlock
```

Visual Basic (Usage)



```
Dim instance As ISheet  
Dim value As TitleBlock  
  
value = instance.TitleBlock
```

C#

```
TitleBlock TitleBlock {get;}
```

C++/CLI

```
property TitleBlock^ TitleBlock {  
    TitleBlock^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Title block](#) in this sheet

Visual Basic for Applications (VBA) Syntax

See [Sheet::TitleBlock](#).

Example

[Get Notes from New or Existing Title Block \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)

Remarks

Only one title block can exist in a sheet. This property gets that title block, if it exists.

See Also

[ISheet Interface](#)
[ISheet Members](#)
[ISheet::TitleBlock Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0