

SOLIDWORKS API (.NET VBA C#) — Reference

(254/337): ISheetMetalFeatureData- ISheetMetalGaugeTableParameters

SOLIDWORKS API Documentation (converted from CHM)

ISheetMetalFeatureData (Type)

ISheetMetalFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFeatureData Interface

Allows access to a sheet metal feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISheetMetalFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData
```

C#

```
public interface ISheetMetalFeatureData
```

C++/CLI

```
public interface class ISheetMetalFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

To obtain sheet metal feature data from sheet metal models created in SOLIDWORKS 2013 or later, follow the examples of [IModelDocExtension::GetTemplateSheetMetal](#).

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SheetMetalFeatureData](#)

See Also

[ISheetMetalFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBaseFlangeFeatureData Interface](#)
[IBendsFeatureData Interface](#)
[IBreakCornerFeatureData Interface](#)
[IClosedCornerFeatureData Interface](#)
[ICustomBendAllowance Interface](#)
[IEdgeFlangeFeatureData Interface](#)
[IFlatPatternFeatureData Interface](#)
[IFoldsFeatureData Interface](#)
[IHemFeatureData Interface](#)
[IJogFeatureData Interface](#)
[ILoftedBendsFeatureData Interface](#)
[IMiterFlangeFeatureData Interface](#)
[IOneBendFeatureData Interface](#)
[IRipFeatureData Interface](#)
[ISketchedBendFeatureData Interface](#)
[IFeatureManager::InsertSheetMetalBaseFlange2 Method](#)
[IFeatureManager::InsertSheetMetalHem2 Method](#)

ISheetMetalFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFeatureData Interface

The following tables list the members exposed by [ISheetMetalFeatureData](#).

Public Properties

Name	Description
AutoReliefType	Gets or sets the sheet metal bend relief type.
BendAllowance	Obsolete. Superseded by ISheetMetalFeatureData.GetCustomBendAllowance and ISheetMetalFeatureData.SetCustomBendAllowance .
BendAllowanceType	Obsolete. Superseded by ISheetMetalFeatureData.GetCustomBendAllowance and ISheetMetalFeatureData.SetCustomBendAllowance .
BendRadius	Gets or sets the sheet metal bend radius.
BendTableFile	Obsolete. Superseded by ISheetMetalFeatureData.GetCustomBendAllowance and ISheetMetalFeatureData.SetCustomBendAllowance .
FixedReference	Gets or sets the fixed face or edge for this sheet metal feature.
KFactor	Obsolete. Superseded by ISheetMetalFeatureData.GetCustomBendAllowance and ISheetMetalFeatureData.SetCustomBendAllowance .
ReliefRatio	Gets or sets the relief ratio for this sheet metal feature.
Thickness	Gets or sets the sheet metal thickness.
UseAutoRelief	Gets or sets whether this sheet metal feature uses auto relief.
UseMaterialSheetMetalParameters	Gets or sets whether to use the properties of the material applied when creating this sheet metal feature.

[Top](#)

Public Methods

Name	Description
AccessSelections	Gains access to the selections that define this sheet metal feature.
GetCustomBendAllowance	Gets custom bend allowance for this sheet metal feature.
GetOverrideDefaultParameter	Obsolete. Superseded by ISheetMetalFeatureData.GetOverrideDefaultParameter2 .
GetOverrideDefaultParameter2	Gets whether the specified default parameter is overridden in this sheet metal feature in a multibody sheet metal part.
GetUseGaugeTable	Gets whether to use a sheet metal feature gauge table.
IAccessSelections	Obsolete. Superseded by ISheetMetalFeatureData.IAccessSelections2 .
IAccessSelections2	Gains access to the selections that define this sheet metal feature.
ReleaseSelectionAccess	Releases access to selections used to define the sheet metal feature.
SetCustomBendAllowance	Sets the custom bend allowance for this sheet metal feature.
SetOverrideDefaultParameter	Obsolete. Superseded by ISheetMetalFeatureData.SetOverrideDefaultParameter2 .
SetOverrideDefaultParameter2	Sets whether to override the specified default parameter in this sheet metal feature in a multibody sheet metal part.
SetUseGaugeTable	Sets whether to use a sheet metal feature gauge table.

[Top](#)

See Also

[ISheetMetalFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBaseFlangeFeatureData Interface](#)
[IBendsFeatureData Interface](#)
[IBreakCornerFeatureData Interface](#)
[IClosedCornerFeatureData Interface](#)
[ICustomBendAllowance Interface](#)
[IEdgeFlangeFeatureData Interface](#)
[IFlatPatternFeatureData Interface](#)
[IFoldsFeatureData Interface](#)
[IHemFeatureData Interface](#)
[IJogFeatureData Interface](#)
[ILoftedBendsFeatureData Interface](#)
[IMiterFlangeFeatureData Interface](#)
[IOneBendFeatureData Interface](#)
[IRipFeatureData Interface](#)

ISheetMetalFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFeatureData Interface

For a list of all members of this type, see [ISheetMetalFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this sheet metal feature.
 GetCustomBendAllowance	Gets custom bend allowance for this sheet metal feature.
 GetOverrideDefaultParameter	Obsolete. Superseded by ISheetMetalFeatureData::GetOverrideDefaultParameter2 .
 GetOverrideDefaultParameter2	Gets whether the specified default parameter is overridden in this sheet metal feature in a multibody sheet metal part.
 GetUseGaugeTable	Gets whether to use a sheet metal feature gauge table.
 IAccessSelections	Obsolete. Superseded by ISheetMetalFeatureData::IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that define this sheet metal feature.
 ReleaseSelectionAccess	Releases access to selections used to define the sheet metal feature.
 SetCustomBendAllowance	Sets the custom bend allowance for this sheet metal feature.
 SetOverrideDefaultParameter	Obsolete. Superseded by ISheetMetalFeatureData::SetOverrideDefaultParameter2 .
 SetOverrideDefaultParameter2	Sets whether to override the specified default parameter in this sheet metal feature in a multibody sheet metal part.
 SetUseGaugeTable	Sets whether to use a sheet metal feature gauge table.

[Top](#)

See Also

[ISheetMetalFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBaseFlangeFeatureData Interface](#)
[IBendsFeatureData Interface](#)
[IBreakCornerFeatureData Interface](#)
[IClosedCornerFeatureData Interface](#)
[ICustomBendAllowance Interface](#)
[IEdgeFlangeFeatureData Interface](#)
[IFlatPatternFeatureData Interface](#)
[IFoldsFeatureData Interface](#)
[IHemFeatureData Interface](#)
[IJogFeatureData Interface](#)
[ILoftedBendsFeatureData Interface](#)
[IMiterFlangeFeatureData Interface](#)
[IOneBendFeatureData Interface](#)
[IRipFeatureData Interface](#)
[ISketchdBendFeatureData Interface](#)
[IFeatureManager::InsertSheetMetalBaseFlange2 Method](#)
[IFeatureManager::InsertSheetMetalHem2 Method](#)

ISheetMetalFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFeatureData Interface

For a list of all members of this type, see [ISheetMetalFeatureData members](#).

Public Properties

Name	Description
 AutoReliefType	Gets or sets the sheet metal bend relief type.
 BendAllowance	Obsolete. Superseded by ISheetMetalFeatureData::GetCustomBendAllowance and ISheetMetalFeatureData::SetCustomBendAllowance .
 BendAllowanceType	Obsolete. Superseded by ISheetMetalFeatureData::GetCustomBendAllowance and ISheetMetalFeatureData::SetCustomBendAllowance .
 BendRadius	Gets or sets the sheet metal bend radius.

 BendTableFile	Obsolete. Superseded by ISheetMetalFeatureData::GetCustomBendAllowance and ISheetMetalFeatureData::SetCustomBendAllowance .
 FixedReference	Gets or sets the fixed face or edge for this sheet metal feature.
 KFactor	Obsolete. Superseded by ISheetMetalFeatureData::GetCustomBendAllowance and ISheetMetalFeatureData::SetCustomBendAllowance .
 ReliefRatio	Gets or sets the relief ratio for this sheet metal feature.
 Thickness	Gets or sets the sheet metal thickness.
 UseAutoRelief	Gets or sets whether this sheet metal feature uses auto relief.
 UseMaterialSheetMetalParameters	Gets or sets whether to use the properties of the material applied when creating this sheet metal feature.

[Top](#)

See Also

[ISheetMetalFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBaseFlangeFeatureData Interface](#)
[IBendsFeatureData Interface](#)
[IBreakCornerFeatureData Interface](#)
[IClosedCornerFeatureData Interface](#)
[ICustomBendAllowance Interface](#)
[IEdgeFlangeFeatureData Interface](#)
[IFlatPatternFeatureData Interface](#)
[IFoldsFeatureData Interface](#)
[IHemFeatureData Interface](#)
[IJogFeatureData Interface](#)
[ILoftedBendsFeatureData Interface](#)
[IMiterFlangeFeatureData Interface](#)
[IOneBendFeatureData Interface](#)
[IRipFeatureData Interface](#)
[ISketchedBendFeatureData Interface](#)
[IFeatureManager::InsertSheetMetalBaseFlange2 Method](#)
[IFeatureManager::InsertSheetMetalHem2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : AccessSelections Method (ISheetMetalFeatureData)

Gains access to the selections that define this sheet metal feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISheetMetalFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::AccessSelections](#).

Example

[Change Bend Radius of Sheet Metal Part \(VBA\)](#)
[Get Fixed Face of Sheet Metal Part \(VBA\)](#)

Remarks

To access sheet metal feature data in sheet metal models created in SOLIDWORKS 2013 or later, follow the examples of [IModelDocExtension::GetTemplateSheetMetal](#).

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [ISheetMetalFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::!AccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help [Send comments on this topic.](#)

AutoReliefType Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : AutoReliefType Property (ISheetMetalFeatureData)

Gets or sets the sheet metal bend relief type.

.NET Syntax

Visual Basic (Declaration)

Property AutoReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Integer
```

```
instance.AutoReliefType = value
```

```
value = instance.AutoReliefType
```

C#

```
System.int AutoReliefType {get; set;}
```

C++/CLI

```
property System.int AutoReliefType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief type as defined in [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::AutoReliefType](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::ReliefRatio Property](#)
[ISheetMetalFeatureData::UseAutoRelief Property](#)
[IBaseFlangeFeatureData::Initialize Method \(\)](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendAllowance Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : BendAllowance Property (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::GetCustomBendAllowance](#) and [ISheetMetalFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BendAllowance As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Double
```

```
instance.BendAllowance = value
```

```
value = instance.BendAllowance
```

C#

```
System.double BendAllowance {get; set;}
```

C++/CLI

```
property System.double BendAllowance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::BendAllowance](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAllowanceType Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : BendAllowanceType Property (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::GetCustomBendAllowance](#) and [ISheetMetalFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BendAllowanceType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Integer
```

```
instance.BendAllowanceType = value
```

```
value = instance.BendAllowanceType
```

C#

```
System.int BendAllowanceType {get; set;}
```

C++/CLI

```
property System.int BendAllowanceType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::BendAllowanceType](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : BendRadius Property (ISheetMetalFeatureData)

Gets or sets the sheet metal bend radius.

.NET Syntax

Visual Basic (Declaration)

```
Property BendRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Double
```

```
instance.BendRadius = value  
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for the bend radius

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::BendRadius](#).

Example

See [ISheetMetalFeatureData](#) examples.

Example

[Change Bend Radius of Sheet Metal Part \(VBA\)](#)

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendTableFile Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : BendTableFile Property (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::GetCustomBendAllowance](#) and [ISheetMetalFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BendTableFile As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.String
```

```
instance.BendTableFile = value
```

```
value = instance.BendTableFile
```

C#

```
System.string BendTableFile {get; set;}
```

C++/CLI

```
property System.String^ BendTableFile {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::BendTableFile](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FixedReference Property (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : FixedReference Property (ISheetMetalFeatureData)

Gets or sets the fixed face or edge for this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FixedReference As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Object
```

```
instance.FixedReference = value
```

```
value = instance.FixedReference
```

C#

```
System.object FixedReference {get; set;}
```

C++/CLI

```
property System.Object^ FixedReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fixed reference entity (edge or face)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::FixedReference](#).

Example

[Get Fixed Face of Sheet Metal Part \(VBA\)](#)

Remarks

To access the fixed reference of a sheet metal feature in sheet metal models created in SOLIDWORKS 2013 or later, follow the examples of [IModelDocExtension::GetTemplateSheetMetal](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : GetCustomBendAllowance Method (ISheetMetalFeatureData)

Gets custom bend allowance for this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As CustomBendAllowance  
  
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::GetCustomBendAllowance](#).

Example

See the [ISheetMetalFeatureData](#) examples.

See the [IBaseFlangeFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOverrideDefaultParameter Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : GetOverrideDefaultParameter Method (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::GetOverrideDefaultParameter2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetOverrideDefaultParameter( _  
    ByRef OverrideDefaultParameter As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim OverrideDefaultParameter As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetOverrideDefaultParameter(OverrideDefaultParameter)
```

C#

```
System.int GetOverrideDefaultParameter(  
    out System.bool OverrideDefaultParameter  
)
```

C++/CLI

```
System.int GetOverrideDefaultParameter(  
& [Out] System.bool OverrideDefaultParameter  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OverrideDefaultParameter

True if the default parameters are overridden, false if not

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::GetOverrideDefaultParameter](#).

See Also

[ISheetMetalFeatureData Interface](#)

[ISheetMetalFeatureData Members](#)

[ISheetMetalFeatureData::SetOverrideDefaultParameter Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOverrideDefaultParameter2 Method (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : GetOverrideDefaultParameter2 Method (ISheetMetalFeatureData)

Gets whether the specified default parameter is overridden in this sheet metal feature in a multibody sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOverrideDefaultParameter2( _  
    ByVal Parameter As System.Integer, _  
    ByRef OverrideDefaultParameter As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim Parameter As System.Integer  
Dim OverrideDefaultParameter As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetOverrideDefaultParameter2(Parameter, OverrideDefaultParameter)
```

C#

```
System.int GetOverrideDefaultParameter2(  
    System.int Parameter,  
    out System.bool OverrideDefaultParameter  
)
```

C++/CLI

```
System.int GetOverrideDefaultParameter2(  
& System.int Parameter,  
& [Out] System.bool OverrideDefaultParameter  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Parameter

Default parameter as defined in [swSheetMetalOverrideDefaultParameters_e](#)
OverrideDefaultParameter
True if Parameter is overridden, false if not

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::GetOverrideDefaultParameter2](#).

Example

[Set Override Option for Auto Relief Default Parameters \(C#\)](#)
[Set Override Option for Auto Relief Default Parameters \(VB.NET\)](#)
[Set Override Option for Auto Relief Default Parameters \(VBA\)](#)

Remarks

This property is only valid for multibody sheet metal parts created in SOLIDWORKS 2013 and later.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::SetOverrideDefaultParameter2 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

GetUseGaugeTable Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : GetUseGaugeTable Method (ISheetMetalFeatureData)

Gets whether to use a sheet metal feature gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseGaugeTable( _  
    ByRef UseGaugeTable As System.Boolean, _  
    ByRef GaugeTableFile As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim UseGaugeTable As System.Boolean  
Dim GaugeTableFile As System.String  
Dim value As System.Integer  
  
value = instance.GetUseGaugeTable(UseGaugeTable, GaugeTableFile)
```

C#

```
System.int GetUseGaugeTable(  
    out System.bool UseGaugeTable,  
    out System.string GaugeTableFile  
)
```

C++/CLI

```
System.int GetUseGaugeTable(  
& [Out] System.bool UseGaugeTable,  
& [Out] System.String^ GaugeTableFile  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseGaugeTable

True to use a gauge table, false to not

GaugeTableFile

Gauge table file name; valid only if UseGaugeTable is true

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::GetUseGaugeTable](#).

Example

See [ISheetMetalFeatureData](#) examples.

See Also

[ISheetMetalFeatureData Interface](#)

[ISheetMetalFeatureData Members](#)

[ISheetMetalFeatureData::SetUseGaugeTable Method \(\)](#)

Availability

IAccessSelections Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : IAccessSelections Method (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc, _
    ByVal Component As Component _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData
Dim TopDoc As ModelDoc
Dim Component As Component
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc TopDoc,
    Component Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc^ TopDoc,
    & Component^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::IAccessSelections](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

IAccessSelections2 Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : IAccessSelections2 Method (ISheetMetalFeatureData)

Gains access to the selections that define this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections2(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::IAccessSelections2](#).

Remarks

To access sheet metal feature data in sheet metal models created in SOLIDWORKS 2013 or later, follow the examples of [IModelDocExtension::GetTemplateSheetMetal](#).

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISheetMetalFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Pus FCS, Revision Number 10.0

KFactor Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : KFactor Property (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::GetCustomBendAllowance](#) and [ISheetMetalFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property KFactor As System.Double

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Double
```

```
instance.KFactor = value
```

```
value = instance.KFactor
```

C#

```
System.double KFactor {get; set;}
```

C++/CLI

```
property System.double KFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::KFactor](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : ReleaseSelectionAccess Method (ISheetMetalFeatureData)

Releases access to selections used to define the sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::ReleaseSelectionAccess](#).

Example

[Get Fixed Face of Sheet Metal Part \(VBA\)](#)

Remarks

To release access to sheet metal feature data in sheet metal models created in SOLIDWORKS 2013 or later, follow the examples of [IModelDocExtension::GetTemplateSheetMetal](#).

[ISheetMetalFeatureData::AccessSelections](#) and [ISheetMetalFeatureData::IAccessSelections2](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : ReliefRatio Property (ISheetMetalFeatureData)

Gets or sets the relief ratio for this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Double  
  
instance.ReliefRatio = value  
  
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the relief ratio

Visual Basic for Applications (VBA) Syntax

See [ISheetMetalFeatureData::ReliefRatio](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::UseAutoRelief Property](#)
[ISheetMetalFeatureData::AutoReliefType Property](#)
[IBaseFlangeFeatureData::Initialize Method \(\)](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : SetCustomBendAllowance Method (ISheetMetalFeatureData)

Sets the custom bend allowance for this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData
[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::GetCustomBendAllowance Method](#)
[IBaseFlangeFeatureData::Initialize Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetOverrideDefaultParameter Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : SetOverrideDefaultParameter Method (ISheetMetalFeatureData)

Obsolete. Superseded by [ISheetMetalFeatureData::SetOverrideDefaultParameter2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetOverrideDefaultParameter( _  
    ByVal OverrideDefaultParameter As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim OverrideDefaultParameter As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetOverrideDefaultParameter(OverrideDefaultParameter)
```

C#

```
System.int SetOverrideDefaultParameter(  
    System.bool OverrideDefaultParameter  
)
```

C++/CLI

```
System.int SetOverrideDefaultParameter(  
& System.bool OverrideDefaultParameter  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OverrideDefaultParameter
True to override the default parameters, false to not

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::SetOverrideDefaultParameter](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::GetOverrideDefaultParameter Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetOverrideDefaultParameter2 Method (ISheetMetalFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : SetOverrideDefaultParameter2 Method (ISheetMetalFeatureData)

Sets whether to override the specified default parameter in this sheet metal feature in a multibody sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Function SetOverrideDefaultParameter2( _  
    ByVal Parameter As System.Integer, _  
    ByVal OverrideDefaultParameter As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISheetMetalFeatureData  
Dim Parameter As System.Integer  
Dim OverrideDefaultParameter As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetOverrideDefaultParameter2(Parameter, OverrideDefaultParameter)
```

C#

```
System.int SetOverrideDefaultParameter2(  
    System.int Parameter,  
    System.bool OverrideDefaultParameter  
)
```

C++/CLI

```
System.int SetOverrideDefaultParameter2(  
& System.int Parameter,  
& System.bool OverrideDefaultParameter  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Parameter

Default parameter as defined in [swSheetMetalOverrideDefaultParameters_e](#)
OverrideDefaultParameter

True to override Parameter, false to not

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::SetOverrideDefaultParameter2](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Example

[Set Override Option for Auto Relief Default Parameters \(C#\)](#)
[Set Override Option for Auto Relief Default Parameters \(VB.NET\)](#)
[Set Override Option for Auto Relief Default Parameters \(VBA\)](#)

Remarks

This property is only valid for multibody sheet metal parts created in SOLIDWORKS 2013 and later.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::GetOverrideDefaultParameter2 Method \(\)](#)
[IBaseFlangeFeatureData::Initialize Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUseGaugeTable Method (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : SetUseGaugeTable Method (ISheetMetalFeatureData)

Sets whether to use a sheet metal feature gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetUseGaugeTable( _  
    ByVal UseGaugeTable As System.Boolean, _  
    ByVal GaugeTableFile As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim UseGaugeTable As System.Boolean  
Dim GaugeTableFile As System.String  
Dim value As System.Integer  
  
value = instance.SetUseGaugeTable(UseGaugeTable, GaugeTableFile)
```

C#

```
System.int SetUseGaugeTable(  
    System.bool UseGaugeTable,  
    System.string GaugeTableFile  
)
```

C++/CLI

```
System.int SetUseGaugeTable(  
& System.bool UseGaugeTable,  
& System.String^ GaugeTableFile  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseGaugeTable
True to use a gauge table, false to not
GaugeTableFile
Gauge table file name; valid only if UseGaugeTable is true

Return Value

Result code as defined in [swSheetMetalModifierError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::SetUseGaugeTable](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::GetUseGaugeTable Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Thickness Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : Thickness Property (ISheetMetalFeatureData)

Gets or sets the sheet metal thickness.

.NET Syntax

Visual Basic (Declaration)

Property Thickness As System.Double

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Double  
  
instance.Thickness = value  
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the thickness

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::Thickness](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseAutoRelief Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : UseAutoRelief Property (ISheetMetalFeatureData)

Gets or sets whether this sheet metal feature uses auto relief.

.NET Syntax

Visual Basic (Declaration)

Property UseAutoRelief As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Boolean  
  
instance.UseAutoRelief = value  
value = instance.UseAutoRelief
```

C#

```
System.bool UseAutoRelief {get; set;}
```

C++/CLI

```
property System.bool UseAutoRelief {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use auto relief, false to not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::UseAutoRelief](#).

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[ISheetMetalFeatureData::AutoReliefType Property](#)
[ISheetMetalFeatureData::ReliefRatio Property](#)

Availability

SOLIDWORKS 2001 Sp1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseMaterialSheetMetalParameters Property (ISheetMetalFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFeatureData Interface](#) : UseMaterialSheetMetalParameters Property (ISheetMetalFeatureData)

Gets or sets whether to use the properties of the material applied when creating this sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

Property UseMaterialSheetMetalParameters As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISheetMetalFeatureData  
Dim value As System.Boolean  
  
instance.UseMaterialSheetMetalParameters = value  
value = instance.UseMaterialSheetMetalParameters
```

C#

```
System.bool UseMaterialSheetMetalParameters {get; set;}
```

C++/CLI

```
property System.bool UseMaterialSheetMetalParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the material sheet metal parameters, false to not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFeatureData::UseMaterialSheetMetalParameters](#).

Remarks

This property is valid only when [ISheetMetalFeatureData::GetUseGaugeTable](#) returns false.

See Also

[ISheetMetalFeatureData Interface](#)
[ISheetMetalFeatureData Members](#)
[IBaseFlangeFeatureData::Initialize Method \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

ISheetMetalFolder (Type)

ISheetMetalFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFolder Interface

Allows access to a sheet metal folder feature in the FeatureManager design tree.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISheetMetalFolder
```

Visual Basic (Usage)

```
Dim instance As ISheetMetalFolder
```

C#

```
public interface ISheetMetalFolder
```

C++/CLI

```
public interface class ISheetMetalFolder
```

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFolder](#).

Example

[Get Sheet Metal Folder Feature \(VBA\)](#)
[Get Sheet Metal Folder Feature \(VB.NET\)](#)
[Get Sheet Metal Folder Feature \(C#\)](#)

Remarks

The FeatureManager design tree of a multi-body sheet metal part created in SOLIDWORKS 2013 and later contains a sheet metal folder with multiple sheet metal features. This interface allows access to the sheet metal folder.

Accessors

[IFeature::GetSpecificFeature2](#)
[IFeatureManager::GetSheetMetalFolder](#)

Access Diagram

[SheetMetalFolder](#)

See Also

[ISheetMetalFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISheetMetalFolder Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFolder Interface

The following tables list the members exposed by [ISheetMetalFolder](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this sheet metal folder.
 GetSheetMetalCount	Gets the number of sheet metal features in this folder.
 GetSheetMetals	Gets the sheet metal features in this folder.

[Top](#)

See Also

[ISheetMetalFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISheetMetalFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalFolder Interface

For a list of all members of this type, see [ISheetMetalFolder members](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this sheet metal folder.
 GetSheetMetalCount	Gets the number of sheet metal features in this folder.
 GetSheetMetals	Gets the sheet metal features in this folder.

[Top](#)

See Also

[ISheetMetalFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (ISheetMetalFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFolder Interface](#) : GetFeature Method (ISheetMetalFolder)

Gets the feature for this sheet metal folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFolder  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFolder::GetFeature](#).

Example

See [ISheetMetalFolder](#) examples.

See Also

[ISheetMetalFolder Interface](#)
[ISheetMetalFolder Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetMetalCount Method (ISheetMetalFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFolder Interface](#) : GetSheetMetalCount Method (ISheetMetalFolder)

Gets the number of sheet metal features in this folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetMetalCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFolder  
Dim value As System.Integer  
  
value = instance.GetSheetMetalCount()
```

C#

```
System.int GetSheetMetalCount()
```

C++/CLI

```
System.int GetSheetMetalCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sheet metal features in this folder

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFolder::GetSheetMetalCount](#).

Example

See [ISheetMetalFolder](#) examples.

See Also

[ISheetMetalFolder Interface](#)
[ISheetMetalFolder Members](#)
[ISheetMetalFolder::GetSheetMetals Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetMetals Method (ISheetMetalFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalFolder Interface](#) : GetSheetMetals Method (ISheetMetalFolder)

Gets the sheet metal features in this folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetMetals() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalFolder  
Dim value As System.Object  
  
value = instance.GetSheetMetals()
```

C#

```
System.Object GetSheetMetals()
```

C++/CLI

```
System.Object^ GetSheetMetals();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [SheetMetalFolder::GetSheetMetals](#).

Example

See [ISheetMetalFolder](#) examples.

See Also

[ISheetMetalFolder Interface](#)
[ISheetMetalFolder Members](#)
[ISheetMetalFolder::GetSheetMetalCount Method\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

ISheetMetalGaugeTableParameters (Type)

ISheetMetalGaugeTableParameters Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalGaugeTableParameters Interface

Allows access to sheet metal gauge table parameters.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISheetMetalGaugeTableParameters

Visual Basic (Usage)

Dim instance As [ISheetMetalGaugeTableParameters](#)

C#

public interface ISheetMetalGaugeTableParameters

C++/CLI

public interface class ISheetMetalGaugeTableParameters

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters](#).

Example

```
'VBA
'This example demonstrates how to create a swept flange using a bend table in a non-sheet-metal part.
'=====
'Preconditions:
'1. Ensure that the paths to templates and gauge tables are valid.
'2. Open an Immediate window.
'3. Press F5 repeatedly and inspect the Immediate window and FeatureManager design tree as instructed.
'
'Postconditions:
'1. Creates Sketch1 for the sweep path.
'2. Creates Sketch2 for the sweep profile.
'3. Creates Swept Flange1 using a gauge table installed with SOLIDWORKS.
'4. Displays gauge table parameters.
'5. Modifies Swept Flange1 to override the gauge number, bend radius, and gauge thickness.
'6. Displays new gauge parameters.
'=====
Option Explicit

Dim swApp As SldWorks.SldWorks
Dim swPart As PartDoc
Dim swModel As SldWorks.ModelDoc2
Dim swFeat As SldWorks.Feature
Dim swFeatMgr As SldWorks.FeatureManager
Dim swSweptFlangeFeatureData As SldWorks.SweptFlangeFeatureData
Dim featData As SldWorks.SweptFlangeFeatureData
Dim smGaugeTableParam As SheetMetalGaugeTableParameters
Dim skSegment As SldWorks.SketchSegment
```

```

Dim myRefPlane As SldWorks.RefPlane
Dim swFeatNameID As Long
Dim swSketch As SldWorks.Feature
Dim oPath(0) As Object
Dim boolstatus As Boolean
Dim errCode As Long
Dim swSheetWidth As Double
Dim swSheetHeight As Double
Dim vPath As Variant
Dim gaugePath As String
Dim gaugeCount As Long
Dim gaugeNumbers As Variant
Dim i As Long
Dim radiiCount As Long
Dim radii As Variant
Dim newgaugePath As String

Sub main()

    Set swApp = Application.SldWorks

    swSheetWidth = 0
    swSheetHeight = 0
    Set swModel = swApp.NewDocument("C:\Program Files\SOLIDWORKS Corp\SOLIDWORKS\lang\english\Tutorial\part.prtdot", 0,
swSheetWidth, swSheetHeight)

    Set swPart = swModel
    Set swModel = swApp.ActiveDoc

    Set skSegment = swModel.SketchManager.Create3PointArc(-0.058601, -0.015313, 0#, -0.003828, -0.021603, 0#, 0.002265, -0.05642, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True 'Sketch1
    swModel.ClearSelection2 True

    boolstatus = swModel.Extension.SelectByID2(Point2@Sketch1, "EXTSKETCHPOINT", -0.003828, -0.021603, 0, True, 0, Nothing, 0)
    boolstatus = swModel.Extension.SelectByID2(Arc1@Sketch1, "EXTSKETCHSEGMENT", 2.85760095397308E-03, -3.42380271903227E-02,
0, True, 1, Nothing, 0)

    Set myRefPlane = swModel.FeatureManager.InsertRefPlane(4, 0, 2, 0, 0, 0)

    boolstatus = swModel.Extension.SelectByID2("Plane1", "PLANE", 1.03901931573406E-02, -9.17038599747196E-03, -6.22490227027586E-
03, True, 0, Nothing, 0)

    swModel.SketchManager.InsertSketch True
    Set skSegment = swModel.SketchManager.CreateLine(0#, 0#, 0#, 0#, 0.018316, 0#)
    Set skSegment = swModel.SketchManager.CreateLine(0#, 0.018316, 0#, 0.008362, 0.035435, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True 'Sketch2

    swFeatNameID = swFeatureNameID_e.swFmSweptFlange
    Set swFeatMgr = swModel.FeatureManager
    Set swSweptFlangeFeatureData = swFeatMgr.CreateDefinition(swFeatNameID)

    swModel.ClearSelection2 True

    'Select the sweep path
    boolstatus = swModel.Extension.SelectByID2("Sketch1", "SKETCH", 0, 0, 0, False, 0, Nothing, 0)
    Set swSketch = swModel.SelectionManager.GetSelectedObject6(1, -1)

    Set oPath(0) = swSketch
    vPath = oPath
    swSweptFlangeFeatureData.Path = vPath

    'Select the sweep profile
    boolstatus = swModel.Extension.SelectByID2("Sketch2", "SKETCH", 0, 0, 0, False, 0, Nothing, 0)
    Set swSketch = swModel.SelectionManager.GetSelectedObject6(1, -1)
    swSweptFlangeFeatureData.Profile = swSketch

    errCode = swSweptFlangeFeatureData.GetErrorCodes
    Debug.Print "Swept flange definition error code: " + CStr(errCode)

    Stop 'Inspect the Immediate window for the swept flange definition error

    swSweptFlangeFeatureData.UseMaterialSheetMetalParameters = False
    swSweptFlangeFeatureData.UseGaugeTable = True

    Debug.Print "Use Gauge Table?" + CStr(swSweptFlangeFeatureData.UseGaugeTable)

    Set smGaugeTableParam = swSweptFlangeFeatureData.GetGaugeTableParameters
    boolstatus = smGaugeTableParam.GetGaugeTablePath(gaugePath)

    If boolstatus = False Then
        smGaugeTableParam.SetGaugeTablePath ("C:\Program Files\SOLIDWORKS Corp\SOLIDWORKS\LANG\ENGLISH\SHEET METAL

```

```

GAUGE TABLES\BEND ALLOWANCE MM SAMPLE.XLS")
End If

boolstatus = smGaugeTableParam.GetGaugeTablePath(gaugePath)
Debug.Print "Got gauge table path? " + CStr(boolstatus)
Debug.Print "Gauge Table Path: " + gaugePath
Debug.Print "Process: " + smGaugeTableParam.Process

gaugeCount = smGaugeTableParam.GetGaugeNumberCount()
Debug.Print "Gauge Number Count: " + CStr(gaugeCount)

Debug.Print "Available gauge numbers: "

gaugeNumbers = smGaugeTableParam.GetAvailableGaugeNumbers()

For i = 0 To gaugeCount - 1
    Debug.Print gaugeNumbers(i)
Next
Debug.Print "Current Gauge Number: " + smGaugeTableParam.GetCurrentGaugeNumber()

Stop 'Inspect the Immediate window for the current gauge number

radiiCount = smGaugeTableParam.GetRadiiCount()
Debug.Print "Bend Radii Count: " + CStr(smGaugeTableParam.GetRadiiCount())

Debug.Print "Available bend radii: "
radii = smGaugeTableParam.GetAvailableRadii()
For i = 0 To radiiCount - 1
    Debug.Print radii(i)
Next
Debug.Print "Current Bend Radius: " + CStr(smGaugeTableParam.GetCurrentRadius)

Debug.Print "Thickness: " + CStr(smGaugeTableParam.GetThickness)
Debug.Print "Override Thickness? " + CStr(smGaugeTableParam.OverrideThickness)
Debug.Print "Override Bend Radius? " + CStr(smGaugeTableParam.OverrideRadius)
Debug.Print "Reverse Direction? " + CStr(smGaugeTableParam.ReverseDirection)

Stop 'Inspect the Immediate window for current bend radius and current gauge thickness

swSweptFlangeFeatureData.SetGaugeTableParameters smGaugeTableParam

Set swFeat = swFeatMgr.CreateFeature(swSweptFlangeFeatureData)

errCode = swSweptFlangeFeatureData.GetErrorCodes
Debug.Print "Swept flange creation error code: " + CStr(errCode)
swModel.ClearSelection2 True

Stop 'Inspect the Immediate window for the swept flange creation status
'Observe Sheet-Metal, Swept Flange1, and Flat-Pattern in the FeatureManager design tree

'Set new gauge number and override gauge thickness and bend radius
Set featData = swFeat.GetDefinition()
Set smGaugeTableParam = featData.GetGaugeTableParameters

smGaugeTableParam.ReverseDirection = True
smGaugeTableParam.SetCurrentGaugeNumber "Gauge 3"
smGaugeTableParam.SetThickness 0.006, True
smGaugeTableParam.SetRadius 0.006, True

featData.SetGaugeTableParameters smGaugeTableParam
boolstatus = swFeat.ModifyDefinition(featData, swModel, Nothing)
Debug.Print "Swept flange modification status: " + CStr(boolstatus)

Stop 'Inspect the Immediate window for the swept flange modification status

'Get new gauge number
boolstatus = featData.AccessSelections(swModel, Nothing)
Set smGaugeTableParam = featData.GetGaugeTableParameters

boolstatus = smGaugeTableParam.GetGaugeTablePath(newgaugePath)
Debug.Print "Got gauge table path? " + CStr(boolstatus)
Debug.Print "Gauge Table Path: " + newgaugePath

Debug.Print "Process: " + smGaugeTableParam.Process

gaugeCount = smGaugeTableParam.GetGaugeNumberCount()
Debug.Print "Gauge Number Count: " + CStr(gaugeCount)
Debug.Print "Available gauge numbers: "
gaugeNumbers = smGaugeTableParam.GetAvailableGaugeNumbers()

```

```

For i = 0 To gaugeCount - 1
    Debug.Print gaugeNumbers(i)
Next
Debug.Print "Current Gauge Number: " + smGaugeTableParam.GetCurrentGaugeNumber()

Stop 'Inspect the Immediate window for the new gauge number

'Get new bend radius and gauge thickness
radiiCount = smGaugeTableParam.GetRadiiCount()
Debug.Print "Bend Radii Count: " + CStr(radiiCount)

Debug.Print "Available bend radii: "
radii = smGaugeTableParam.GetAvailableRadii()
For i = 0 To radiiCount - 1
    Debug.Print radii(i)
Next
Debug.Print "Current Bend Radius: " + CStr(smGaugeTableParam.GetCurrentRadius)

Debug.Print "Thickness: " + CStr(smGaugeTableParam.GetThickness)
Debug.Print "Override Thickness? " + CStr(smGaugeTableParam.OverrideThickness)
Debug.Print "Override Bend Radius? " + CStr(smGaugeTableParam.OverrideRadius)
Debug.Print "Reverse Direction? " + CStr(smGaugeTableParam.ReverseDirection)

featData.ReleaseSelectionAccess

Stop 'Inspect the Immediate window for the new bend radius and gauge thickness
End Sub

```

Example

[Create Swept Flange Using Gauge Table \(C#\)](#)
[Create Swept Flange Using Gauge Table \(VB.NET\)](#)

Remarks

For more information about sheet metal gauge tables, read the **SOLIDWORKS Help > Sheet Metal > Sheet Metal Parts > Sheet Metal Gauge Tables** topic.

Accessors

[ISweptFlangeFeatureData::GetGaugeTableParameters](#)

Access Diagram

[SheetMetalGaugeTableParameters](#)

See Also

[ISheetMetalGaugeTableParameters Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISheetMetalGaugeTableParameters Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalGaugeTableParameters Interface

For a list of all members of this type, see [ISheetMetalGaugeTableParameters members](#).

Public Methods

Name	Description
GetAvailableGaugeNumbers	Gets the available gauge numbers in this gauge table.
GetAvailableRadii	Gets the available bend radii for the gauge number currently selected from this gauge table.
GetCurrentGaugeNumber	Gets the gauge number currently selected from this gauge table.
GetCurrentRadius	Gets the current bend radius for the gauge number currently selected from this gauge table.
GetGaugeNumberCount	Gets the number of gauges in this gauge table.
GetGaugeTablePath	Gets the full path name of this gauge table.
GetRadiiCount	Gets the number of bend radii for the gauge number currently selected from this gauge table.

		
	GetThickness	Gets the gauge thickness for the gauge number currently selected from this gauge table.
	SetCurrentGaugeNumber	Sets the current gauge number in this gauge table.
	SetGaugeTablePath	Sets the full path name of this gauge table.
	SetRadius	Sets the bend radius in this gauge table.
	SetThickness	Sets the gauge thickness in this gauge table.

[Top](#)

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISheetMetalGaugeTableParameters Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalGaugeTableParameters Interface

The following tables list the members exposed by [ISheetMetalGaugeTableParameters](#).

Public Properties

Name	Description
 OverrideRadius	Gets whether the bend radius of this gauge table is overridden.
 OverrideThickness	Gets whether the gauge thickness of this gauge table is overridden.
 Process	Gets the sheet metal process of this gauge table.
 ReverseDirection	Gets or sets whether to reverse the direction of gauge thickness in this gauge table.

[Top](#)

Public Methods

Name	Description
 GetAvailableGaugeNumbers	Gets the available gauge numbers in this gauge table.
 GetAvailableRadii	Gets the available bend radii for the gauge number currently selected from this gauge table.
 GetCurrentGaugeNumber	Gets the gauge number currently selected from this gauge table.
 GetCurrentRadius	Gets the current bend radius for the gauge number currently selected from this gauge table.
 GetGaugeNumberCount	Gets the number of gauges in this gauge table.
 GetGaugeTablePath	Gets the full path name of this gauge table.
 GetRadiiCount	Gets the number of bend radii for the gauge number currently selected from this gauge table.
 GetThickness	Gets the gauge thickness for the gauge number currently selected from this gauge table.
 SetCurrentGaugeNumber	Sets the current gauge number in this gauge table.
 SetGaugeTablePath	Sets the full path name of this gauge table.
 SetRadius	Sets the bend radius in this gauge table.
 SetThickness	Sets the gauge thickness in this gauge table.

[Top](#)

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISheetMetalGaugeTableParameters Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISheetMetalGaugeTableParameters Interface

For a list of all members of this type, see [ISheetMetalGaugeTableParameters members](#).

Public Properties

Name	Description
OverrideRadius	Gets whether the bend radius of this gauge table is overridden.
OverrideThickness	Gets whether the gauge thickness of this gauge table is overridden.
Process	Gets the sheet metal process of this gauge table.
ReverseDirection	Gets or sets whether to reverse the direction of gauge thickness in this gauge table.

[Top](#)

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAvailableGaugeNumbers Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetAvailableGaugeNumbers Method (ISheetMetalGaugeTableParameters)

Gets the available gauge numbers in this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAvailableGaugeNumbers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Object  
  
value = instance.GetAvailableGaugeNumbers()
```

C#

```
System.object GetAvailableGaugeNumbers()
```

C++/CLI

```
System.Object^ GetAvailableGaugeNumbers();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of gauge number name strings

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetAvailableGaugeNumbers](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetCurrentGaugeNumber Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetGaugeNumberCount Method \(\)](#)

[ISheetMetalGaugeTableParameters::SetCurrentGaugeNumber Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAvailableRadii Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetAvailableRadii Method (ISheetMetalGaugeTableParameters)

Gets the available bend radii for the gauge number currently selected from this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAvailableRadii() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Object  
  
value = instance.GetAvailableRadii()
```

C#

```
System.Object GetAvailableRadii()
```

C++/CLI

```
System.Object^ GetAvailableRadii();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of bend radii strings

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetAvailableRadii](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetCurrentRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetRadiiCount Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::OverrideRadius Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentGaugeNumber Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetCurrentGaugeNumber Method (ISheetMetalGaugeTableParameters)

Gets the gauge number currently selected from this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentGaugeNumber() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.String  
  
value = instance.GetCurrentGaugeNumber()
```

C#

```
System.string GetCurrentGaugeNumber()
```

C++/CLI

```
System.String^ GetCurrentGaugeNumber();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Currently selected gauge number

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetCurrentGaugeNumber](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetAvailableGaugeNumbers Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetGaugeNumberCount Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetCurrentGaugeNumber Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCurrentRadius Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetCurrentRadius Method (ISheetMetalGaugeTableParameters)

Gets the current bend radius for the gauge number currently selected from this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentRadius() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Double  
  
value = instance.GetCurrentRadius()
```

C#

```
System.double GetCurrentRadius()
```

C++/CLI

```
System.double GetCurrentRadius();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current bend radius

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetCurrentRadius](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::OverrideRadius Property \(\)](#)
[ISheetMetalGaugeTableParameters::SetRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetAvailableRadii Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetRadiiCount Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGaugeNumberCount Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetGaugeNumberCount Method (ISheetMetalGaugeTableParameters)

Gets the number of gauges in this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGaugeNumberCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Integer  
  
value = instance.GetGaugeNumberCount()
```

C#

```
System.int GetGaugeNumberCount()
```

C++/CLI

```
System.int GetGaugeNumberCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of gauges in the gauge table

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetGaugeNumberCount](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetAvailableGaugeNumbers Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetCurrentGaugeNumber Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetCurrentGaugeNumber Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGaugeTablePath Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetGaugeTablePath Method (ISheetMetalGaugeTableParameters)

Gets the full path name of this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGaugeTablePath( _  
    ByRef GaugeTablePath As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim GaugeTablePath As System.String  
Dim value As System.Boolean  
  
value = instance.GetGaugeTablePath(GaugeTablePath)
```

C#

```
System.bool GetGaugeTablePath(  
    out System.string GaugeTablePath  
)
```

C++/CLI

```
System.bool GetGaugeTablePath(  
& [Out] System.String^ GaugeTablePath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GaugeTablePath
Full path name of the gauge table

Return Value

True if gauge table path successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetGaugeTablePath](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::SetGaugeTablePath Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRadiiCount Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetRadiiCount Method (ISheetMetalGaugeTableParameters)

Gets the number of bend radii for the gauge number currently selected from this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadiiCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Integer
```

```
value = instance.GetRadiiCount()
```

C#

```
System.int GetRadiiCount()
```

C++/CLI

```
System.int GetRadiiCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bend radii

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetRadiiCount](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetAvailableRadii Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetCurrentRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::OverrideRadius Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetThickness Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : GetThickness Method (ISheetMetalGaugeTableParameters)

Gets the gauge thickness for the gauge number currently selected from this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetThickness() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Double  
  
value = instance.GetThickness()
```

C#

```
System.double GetThickness()
```

C++/CLI

```
System.double GetThickness();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Gauge thickness

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::GetThickness](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)
[ISheetMetalGaugeTableParameters::OverrideThickness Property \(\)](#)
[ISheetMetalGaugeTableParameters::ReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideRadius Property (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : OverrideRadius Property (ISheetMetalGaugeTableParameters)

Gets whether the bend radius of this gauge table is overridden.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OverrideRadius As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters
Dim value As System.Boolean

value = instance.OverrideRadius
```

C#

```
System.bool OverrideRadius {get;}
```

C++/CLI

```
property System.bool OverrideRadius {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if gauge table bend radius is overridden, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters.OverrideRadius](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters.SetRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters.GetAvailableRadii Method \(\)](#)
[ISheetMetalGaugeTableParameters.GetCurrentRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters.GetRadiiCount Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

OverrideThickness Property (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : OverrideThickness Property (ISheetMetalGaugeTableParameters)

Gets whether the gauge thickness of this gauge table is overridden.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OverrideThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters
Dim value As System.Boolean

value = instance.OverrideThickness
```

C#

```
System.bool OverrideThickness {get;}
```

C++/CLI

```
property System.bool OverrideThickness {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if gauge thickness is overridden, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::OverrideThickness](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::ReverseDirection Property \(\)](#)
[ISheetMetalGaugeTableParameters::GetThickness Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments](#) on this topic.

Process Property (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : Process Property (ISheetMetalGaugeTableParameters)

Gets the sheet metal process of this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Process As System.String
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.String
```

```
value = instance.Process
```

C#

```
System.string Process {get;}
```

C++/CLI

```
property System.String^ Process {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheet metal process of this gauge table

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::Process](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : ReverseDirection Property (ISheetMetalGaugeTableParameters)

Gets or sets whether to reverse the direction of gauge thickness in this gauge table.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse direction of gauge thickness, false to not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::ReverseDirection](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetThickness Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)
[ISheetMetalGaugeTableParameters::OverrideThickness Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCurrentGaugeNumber Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : SetCurrentGaugeNumber Method (ISheetMetalGaugeTableParameters)

Sets the current gauge number in this gauge table.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetCurrentGaugeNumber( _  
    ByVal GaugeNumber As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim GaugeNumber As System.String  
Dim value As System.Boolean  
  
value = instance.SetCurrentGaugeNumber(GaugeNumber)
```

C#

```
System.bool SetCurrentGaugeNumber(  
    System.string GaugeNumber  
)
```

C++/CLI

```
System.bool SetCurrentGaugeNumber(  
& System.String^ GaugeNumber  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GaugeNumber
Gauge number string (see **Remarks**)

Return Value

True if current gauge number successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::SetCurrentGaugeNumber](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

Use [ISheetMetalGaugeTableParameters::GetAvailableGaugeNumbers](#) to determine GaugeNumber.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetCurrentGaugeNumber Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetGaugeNumberCount Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetGaugeTablePath Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : SetGaugeTablePath Method (ISheetMetalGaugeTableParameters)

Sets the full path name of this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetGaugeTablePath( _  
    ByVal GaugeTablePath As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim GaugeTablePath As System.String  
Dim value As System.Boolean  
  
value = instance.SetGaugeTablePath(GaugeTablePath)
```

C#

```
System.bool SetGaugeTablePath(  
    System.string GaugeTablePath  
)
```

C++/CLI

```
System.bool SetGaugeTablePath(  
& System.String^ GaugeTablePath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GaugeTablePath
Full path name

Return Value

True if gauge table path successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::SetGaugeTablePath](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

Installed sheet metal gauge tables are located in *install_dir\lang\english\Sheet Metal Gauge Tables*.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetGaugeTablePath Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRadius Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : SetRadius Method (ISheetMetalGaugeTableParameters)

Sets the bend radius in this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRadius( _  
    ByVal Radius As System.Double, _  
    ByVal Override As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim Radius As System.Double  
Dim Override As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetRadius(Radius, Override)
```

C#

```
System.bool SetRadius(  
    System.double Radius,  
    System.bool Override  
)
```

C++/CLI

```
System.bool SetRadius(  
& System.double Radius,  
& System.bool Override  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Radius

Bend radius

Override

True to override an existing value, false to not (see **Remarks**)

Return Value

True if bend radius successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::SetRadius](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

If Override is:

- true, then specify an override bend radius in Radius.
- false, then specify Radius using one of the default bend radii for the current gauge number from the gauge table. Use [ISheetMetalGaugeTableParameters::GetAvailableRadii](#) to choose a value for Radius.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::OverrideRadius Property \(\)](#)
[ISheetMetalGaugeTableParameters::GetCurrentRadius Method \(\)](#)
[ISheetMetalGaugeTableParameters::GetRadiiCount Method \(\)](#)
[ISheetMetalGaugeTableParameters::SetThickness Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetThickness Method (ISheetMetalGaugeTableParameters)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISheetMetalGaugeTableParameters Interface](#) : SetThickness Method (ISheetMetalGaugeTableParameters)

Sets the gauge thickness in this gauge table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetThickness( _  
    ByVal Thickness As System.Double, _  
    ByVal Override As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISheetMetalGaugeTableParameters  
Dim Thickness As System.Double  
Dim Override As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetThickness(Thickness, Override)
```

C#

```
System.bool SetThickness(  
    System.double Thickness,  
    System.bool Override  
)
```

C++/CLI

```
System.bool SetThickness(  
& System.double Thickness,  
& System.bool Override  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness
Gauge thickness
Override
True to override an existing value, false to not (see **Remarks**)

Return Value

True if gauge thickness successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SheetMetalGaugeTableParameters::SetThickness](#).

Example

See the [ISheetMetalGaugeTableParameters](#) examples.

Remarks

If Override is:

- true, then specify Thickness using an override gauge thickness. You should also use [ISheetMetalGaugeTableParameters::SetRadius](#) to override the bend radius.
- false, instead of calling this method use [ISheetMetalGaugeTableParameters::GetAvailableGaugeNumbers](#) and [ISheetMetalGaugeTableParameters::SetCurrentGaugeNumber](#) to change the current gauge number. Each gauge number has a default thickness.

See Also

[ISheetMetalGaugeTableParameters Interface](#)
[ISheetMetalGaugeTableParameters Members](#)
[ISheetMetalGaugeTableParameters::GetThickness Method \(\)](#)
[ISheetMetalGaugeTableParameters::OverrideThickness Property \(\)](#)
[ISheetMetalGaugeTableParameters::ReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29