

SOLIDWORKS API (.NET VBA C#) — Reference (256/337): ISimpleCornerTreatmentFeatureData- ISimpleFilletFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISimpleCornerTreatmentFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISimpleCornerTreatmentFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISimpleCornerTreatmentFeatureData Interface

Allows access to a simple corner treatment feature of a structure system.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISimpleCornerTreatmentFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISimpleCornerTreatmentFeatureData
```

C#

```
public interface ISimpleCornerTreatmentFeatureData
```

C++/CLI

```
public interface class ISimpleCornerTreatmentFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

This interface is:

- derived from [ICornerTreatmentFeatureData](#).
- valid only if [ICornerTreatmentFeatureData.IgnoreCornerTreatment](#) is false.

A simple corner is the position in a structure system where the ends of two members meet either in a body trim or a planar trim fashion.

In the SOLIDWORKS Design user interface, the Simple Corner PropertyManager contains two lists that you can manage using the APIs in this interface and elsewhere:

- [Corner groups](#)
- [User defined trim](#) faces

For more information, see:

- SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Corner Management > Editing Simple Corners
- SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Simple Corner PropertyManager

Accessors

Cast an ICornerTreatmentFeatureData object to this interface.

Access Diagram

[SimpleCornerTreatmentFeatureData](#)

See Also

[ISimpleCornerTreatmentFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISimpleCornerTreatmentFeatureData Interface Members

[See Also](#) [Properties](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISimpleCornerTreatmentFeatureData Interface

The following tables list the members exposed by [ISimpleCornerTreatmentFeatureData](#).

Public Properties

Name	Description
 CornerTreatmentTrimType	Gets and sets the corner treatment trim type for this simple corner treatment feature.
 PlanarTrimOption	Gets and sets the planar trim option for this simple corner treatment feature.
 PlanarTrimToolType	Gets and sets the planar trim tool type for this simple corner treatment feature.
 UserDefinedTrimFaces	Gets and sets the user-defined trim faces for this simple corner treatment feature.
 WeldTrimGap	Gets and sets the weld trim gap of this simple corner treatment feature.

[Top](#)

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

ISimpleCornerTreatmentFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISimpleCornerTreatmentFeatureData Interface

For a list of all members of this type, see [ISimpleCornerTreatmentFeatureData members](#).

Public Properties

Name	Description
 CornerTreatmentTrimType	Gets and sets the corner treatment trim type for this simple corner treatment feature.
 PlanarTrimOption	Gets and sets the planar trim option for this simple corner treatment feature.
 PlanarTrimToolType	Gets and sets the planar trim tool type for this simple corner treatment feature.
 UserDefinedTrimFaces	Gets and sets the user-defined trim faces for this simple corner treatment feature.
 WeldTrimGap	Gets and sets the weld trim gap of this simple corner treatment feature.

[Top](#)

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

CornerTreatmentTrimType Property (ISimpleCornerTreatmentFeatureData)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [ISimpleCornerTreatmentFeatureData Interface](#) : CornerTreatmentTrimType Property (ISimpleCornerTreatmentFeatureData)

Gets and sets the corner treatment trim type for this simple corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

Property CornerTreatmentTrimType As System.Integer

Visual Basic (Usage)



Dim instance As [ISimpleCornerTreatmentFeatureData](#)
Dim value As System.Integer

```
instance.CornerTreatmentTrimType = value  
value = instance.CornerTreatmentTrimType
```

C#

```
System.int CornerTreatmentTrimType {get; set;}
```

C++/CLI

```
property System.int CornerTreatmentTrimType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner treatment trim type as defined by [swCornerTreatmentTrimType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData::CornerTreatmentTrimType](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

This property is valid only for swCornerTreatmentTrimType_e.:

- swCornerTreatmentTrim_BodyTrim
- swCornerTreatmentTrim_PlanarTrim

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[ISimpleCornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlanarTrimOption Property (ISimpleCornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleCornerTreatmentFeatureData Interface](#) : PlanarTrimOption Property (ISimpleCornerTreatmentFeatureData)

Gets and sets the planar trim option for this simple corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PlanarTrimOption As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleCornerTreatmentFeatureData  
Dim value As System.Integer  
  
instance.PlanarTrimOption = value  
value = instance.PlanarTrimOption
```

C#

```
System.int PlanarTrimOption {get; set;}
```

C++/CLI

```
property System.int PlanarTrimOption {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Planar trim option as defined by [swCornerTreatmentPlanarTrimOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData::PlanarTrimOption](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

This property is valid only if:

- [ISimpleCornerTreatmentFeatureData::CornerTreatmentTrimType](#) is set to [swCornerTreatmentTrimType_e.swCornerTreatmentTrim_PlanarTrim](#).
- and -
- [ISimpleCornerTreatmentFeatureData::PlanarTrimToolType](#) is set to [swCornerTreatmentPlanarTrimToolType_e.swCornerTreatmentPlanarTrimTool_Automatic](#).

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[ISimpleCornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlanarTrimToolType Property (ISimpleCornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleCornerTreatmentFeatureData Interface](#) : PlanarTrimToolType Property (ISimpleCornerTreatmentFeatureData)

Gets and sets the planar trim tool type for this simple corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PlanarTrimToolType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleCornerTreatmentFeatureData  
Dim value As System.Integer
```

```
instance.PlanarTrimToolType = value
```

```
value = instance.PlanarTrimToolType
```

C#

```
System.int PlanarTrimToolType {get; set;}
```

C++/CLI

```
property System.int PlanarTrimToolType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Planar trim tool type as defined by [swCornerTreatmentPlanarTrimToolType](#) e

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData.PlanarTrimToolType](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[ISimpleCornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

UserDefinedTrimFaces Property (ISimpleCornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleCornerTreatmentFeatureData Interface](#) : UserDefinedTrimFaces Property (ISimpleCornerTreatmentFeatureData)

Gets and sets the user-defined trim faces for this simple corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UserDefinedTrimFaces As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleCornerTreatmentFeatureData
Dim value As System.Object

instance.UserDefinedTrimFaces = value

value = instance.UserDefinedTrimFaces
```

C#

```
System.object UserDefinedTrimFaces {get; set;}
```

C++/CLI

```
property System.Object^ UserDefinedTrimFaces {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData::UserDefinedTrimFaces](#).

Remarks

This property is valid only if [ISimpleCornerTreatmentFeatureData::PlanarTrimToolType](#) is set to [swCornerTreatmentPlanarTrimToolType_e.CornerTreatmentPlanarTrimTool_UserDefined](#).

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[ISimpleCornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

WeldTrimGap Property (ISimpleCornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleCornerTreatmentFeatureData Interface](#) : WeldTrimGap Property (ISimpleCornerTreatmentFeatureData)

Gets and sets the weld trim gap of this simple corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

Property WeldTrimGap As System.Double

Visual Basic (Usage)



```
Dim instance As ISimpleCornerTreatmentFeatureData  
Dim value As System.Double  
  
instance.WeldTrimGap = value  
  
value = instance.WeldTrimGap
```

C#

```
System.double WeldTrimGap {get; set;}
```

C++/CLI

```
property System.double WeldTrimGap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld trim gap between members

Visual Basic for Applications (VBA) Syntax

See [SimpleCornerTreatmentFeatureData::WeldTrimGap](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ISimpleCornerTreatmentFeatureData Interface](#)
[ISimpleCornerTreatmentFeatureData Members](#)

ISimpleFilletFeatureData (Type)

ISimpleFilletFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData Interface

Obsolete. Superseded by [ISimpleFilletFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISimpleFilletFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData
```

C#

```
public interface ISimpleFilletFeatureData
```

C++/CLI

```
public interface class ISimpleFilletFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData](#).

See Also

[ISimpleFilletFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISimpleFilletFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData Interface

For a list of all members of this type, see [ISimpleFilletFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Obsolete. Superseded by ISimpleFilletFeatureData2.AccessSelections .
GetFilletItemAtIndex	Obsolete. Superseded by ISimpleFilletFeatureData2.GetFilletItemAtIndex .
GetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2.GetRadius .
IAccessSelections	Obsolete. Superseded by ISimpleFilletFeatureData2.IAccessSelections .
IGetFilletItemAtIndex	Obsolete. Superseded by ISimpleFilletFeatureData2.IGetFilletItemAtIndex .
IGetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2.IGetRadius .
ISetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2.ISetRadius .
ReleaseSelectionAccess	Obsolete. Superseded by ISimpleFilletFeatureData2.ReleaseSelectionAccess .
SetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2.SetRadius .

[Top](#)

See Also

ISimpleFilletFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData Interface

The following tables list the members exposed by [ISimpleFilletFeatureData](#).

Public Properties

Name	Description
 DefaultRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::DefaultRadius .
 FilletItemsCount	Obsolete. Superseded by ISimpleFilletFeatureData2::FilletItemsCount .
 IsMultipleRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::IsMultipleRadius .
 OverflowType	Obsolete. Superseded by ISimpleFilletFeatureData2::OverflowType .
 PropagateToTangentFaces	Obsolete. Superseded by ISimpleFilletFeatureData2::PropagateToTangentFaces .
 RoundCorners	Obsolete. Superseded by ISimpleFilletFeatureData2::RoundCorners .
 Type	Obsolete. Superseded by ISimpleFilletFeatureData2::Type .

[Top](#)

Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by ISimpleFilletFeatureData2::AccessSelections .
 GetFilletItemAtIndex	Obsolete. Superseded by ISimpleFilletFeatureData2::GetFilletItemAtIndex .
 GetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::GetRadius .
 IAccessSelections	Obsolete. Superseded by ISimpleFilletFeatureData2::IAccessSelections .
 IGetFilletItemAtIndex	Obsolete. Superseded by ISimpleFilletFeatureData2::IGetFilletItemAtIndex .
 IGetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::IGetRadius .
 ISetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::ISetRadius .
 ReleaseSelectionAccess	Obsolete. Superseded by ISimpleFilletFeatureData2::ReleaseSelectionAccess .
 SetRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::SetRadius .

[Top](#)

See Also

[ISimpleFilletFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISimpleFilletFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData Interface

For a list of all members of this type, see [ISimpleFilletFeatureData members](#).

Public Properties

Name	Description
 DefaultRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::DefaultRadius .
 FilletItemsCount	Obsolete. Superseded by ISimpleFilletFeatureData2::FilletItemsCount .
 IsMultipleRadius	Obsolete. Superseded by ISimpleFilletFeatureData2::IsMultipleRadius .
 OverflowType	Obsolete. Superseded by ISimpleFilletFeatureData2::OverflowType .

 PropagateToTangentFaces	Obsolete. Superseded by ISimpleFilletFeatureData2::PropagateToTangentFaces .
 RoundCorners	Obsolete. Superseded by ISimpleFilletFeatureData2::RoundCorners .
 Type	Obsolete. Superseded by ISimpleFilletFeatureData2::Type .

[Top](#)

See Also

[ISimpleFilletFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : AccessSelections Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::AccessSelections](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::AccessSelections](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DefaultRadius Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : DefaultRadius Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::DefaultRadius](#).

.NET Syntax

Visual Basic (Declaration)

```
Property DefaultRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Double
```

```
instance.DefaultRadius = value
```

```
value = instance.DefaultRadius
```

C#

```
System.double DefaultRadius {get; set;}
```

C++/CLI

```
property System.double DefaultRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::DefaultRadius](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FilletItemsCount Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : FilletItemsCount Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::FilletItemsCount](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FilletItemsCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Integer
```

```
value = instance.FilletItemsCount
```

C#

```
System.int FilletItemsCount {get;}
```

C++/CLI

```
property System.int FilletItemsCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::FilletItemsCount](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFilletItemAtIndex Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : GetFilletItemAtIndex Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFilletItemAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetFilletItemAtIndex(Index)
```

C#

```
System.object GetFilletItemAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetFilletItemAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::GetFilletItemAtIndex](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRadius Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : GetRadius Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::GetRadius](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadius( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.GetRadius(PFilletItem)
```

C#

```
System.double GetRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::GetRadius](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : IAccessSelections Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::IAccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As ISimpleFilletFeatureData
Dim TopDoc As ModelDoc
Dim Component As Component
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)

```

C#

```

System.bool IAccessSelections(
    ModelDoc TopDoc,
    Component Component
)

```

C++/CLI

```

System.bool IAccessSelections(
    & ModelDoc^ TopDoc,
    & Component^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::IAccessSelections](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFilletItemAtIndex Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : IGetFilletItemAtIndex Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::IGetFilletAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetFilletItemAtIndex( _
    ByVal Index As System.Integer _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As ISimpleFilletFeatureData
Dim Index As System.Integer
Dim value As System.Object

value = instance.IGetFilletItemAtIndex(Index)

```

C#

```

System.object IGetFilletItemAtIndex(
    System.int Index
)

```

C++/CLI

```
System.Object^ IGetFilletItemAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::IGetFilletItemAtIndex](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetRadius Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : IGetRadius Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::IGetRadius](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRadius(  
    ByVal PFilletItem As System.Object  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.IGetRadius(PFilletItem)
```

C#

```
System.double IGetRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double IGetRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::IGetRadius](#).

See Also

ISetRadius Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : ISetRadius Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::ISetRadius](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal Radius As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim PFilletItem As System.Object  
Dim Radius As System.Double  
  
instance.ISetRadius(PFilletItem, Radius)
```

C#

```
void ISetRadius(  
    System.object PFilletItem,  
    System.double Radius  
)
```

C++/CLI

```
void ISetRadius(  
& System.Object^ PFilletItem,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Radius

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::ISetRadius](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

IsMultipleRadius Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : IsMultipleRadius Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::IsMultipleRadius](#).

.NET Syntax

Visual Basic (Declaration)

Property IsMultipleRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Boolean
```

```
instance.IsMultipleRadius = value
```

```
value = instance.IsMultipleRadius
```

C#

```
System.bool IsMultipleRadius {get; set;}
```

C++/CLI

```
property System.bool IsMultipleRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::IsMultipleRadius](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

OverflowType Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : OverflowType Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::OverflowType](#).

.NET Syntax

Visual Basic (Declaration)

Property OverflowType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Integer
```

```
instance.OverflowType = value
```

```
value = instance.OverflowType
```

C#

```
System.int OverflowType {get; set;}
```

C++/CLI

```
property System.int OverflowType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::OverflowType](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

PropagateToTangentFaces Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : PropagateToTangentFaces Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::PropagateToTangentFaces](#).

.NET Syntax

Visual Basic (Declaration)

Property PropagateToTangentFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateToTangentFaces = value
```

```
value = instance.PropagateToTangentFaces
```

C#

```
System.bool PropagateToTangentFaces {get; set;}
```

C++/CLI

```
property System.bool PropagateToTangentFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::PropagateToTangentFaces](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : ReleaseSelectionAccess Method (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::ReleaseSelectionAccess](#).

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::ReleaseSelectionAccess](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RoundCorners Property (ISimpleFilletFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : RoundCorners Property (ISimpleFilletFeatureData)

Obsolete. Superseded by [ISimpleFilletFeatureData2::RoundCorners](#).

.NET Syntax

Visual Basic (Declaration)

```
Property RoundCorners As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Boolean  
  
instance.RoundCorners = value  
value = instance.RoundCorners
```

C#

```
System.bool RoundCorners {get; set;}
```

C++/CLI

```
property System.bool RoundCorners {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::RoundCorners](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

SetRadius Method (ISimpleFilletFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : SetRadius Method (ISimpleFilletFeatureData)**Obsolete.** Superseded by [ISimpleFilletFeatureData2::SetRadius](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRadius( _
    ByVal PFilletItem As System.Object, _
    ByVal Radius As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData
Dim PFilletItem As System.Object
Dim Radius As System.Double

instance.SetRadius(PFilletItem, Radius)
```

C#

```
void SetRadius(
    System.object PFilletItem,
    System.double Radius
)
```

C++/CLI

```
void SetRadius(
    & System.Object^ PFilletItem,
    & System.double Radius
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*PFilletItem**Radius*

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::SetRadius](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)

Type Property (ISimpleFilletFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData Interface](#) : Type Property (ISimpleFilletFeatureData)**Obsolete.** Superseded by [ISimpleFilletFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type As System.Integer
```

```
Dim instance As ISimpleFilletFeatureData  
Dim value As System.Integer  
  
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData::Type](#).

See Also

[ISimpleFilletFeatureData Interface](#)
[ISimpleFilletFeatureData Members](#)