

SOLIDWORKS API (.NET VBA C#) — Reference

(269/337): ISketch BendFeatureData- ISketchEllipse

SOLIDWORKS API Documentation (converted from CHM)

ISketchdBendFeatureData (Type)

ISketchdBendFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchdBendFeatureData Interface

Allows access to a sheet metal sketched bend feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchdBendFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISketchdBendFeatureData
```

C#

```
public interface ISketchdBendFeatureData
```

C++/CLI

```
public interface class ISketchdBendFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SketchdBendFeatureData](#).

Example

For examples that demonstrate the remodeled feature creation of sheet metal sketched bends, see [ISketchdBendFeatureData::OverrideValue](#) and [ISketchdBendFeatureData::UseGaugeTabl](#)

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

For details about sheet metal sketched bends, see the **SOLIDWORKS Design user-interface help > Sheet Metal > Using Sheet Metal Tools > Sketched Bends** topic.

Accessors

[IFeature::GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[SketchdBendFeatureData](#)

See Also

[ISketchdBendFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

ISketchdBendFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchedBendFeatureData Interface

For a list of all members of this type, see [ISketchedBendFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this sketched bend.
 GetCustomBendAllowance	Gets the custom bend allowance for this sketched bend.
 GetFixedFace	Gets the fixed face from this sketched bend.
 IAccessSelections	Obsolete. Superseded by ISketchedBendFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections that describe this sketched bend feature.
 ReleaseSelectionAccess	Releases access to selections that describe this sketched bend.
 SetCustomBendAllowance	Sets the custom bend allowance for this sketched bend.
 SetFixedFace	Sets the fixed face of this sketched bend.

[Top](#)

See Also

[ISketchedBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchedBendFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchedBendFeatureData Interface

The following tables list the members exposed by [ISketchedBendFeatureData](#).

Public Properties

Name	Description
 BendAngle	Gets or sets the bend angle of this sketched bend.
 BendRadius	Gets or sets the bend radius of this sketched bend.
 OverrideValue	Gets whether the bend angle of this sketched bend is overridden by a custom bend angle.
 PositionType	Gets or sets the bend position of this sketched bend.
 ReverseDirection	Gets or sets whether the direction of the sketched bend angle is reversed.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this sketched bend.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius of this sketched bend.
 UseGaugeTable	Gets or sets whether to use available bend radius values from a gauge table for this sketched bend.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this sketched bend.
 GetCustomBendAllowance	Gets the custom bend allowance for this sketched bend.
 GetFixedFace	Gets the fixed face from this sketched bend.
 IAccessSelections	Obsolete. Superseded by ISketchedBendFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections that describe this sketched bend feature.
 ReleaseSelectionAccess	Releases access to selections that describe this sketched bend.
 SetCustomBendAllowance	Sets the custom bend allowance for this sketched bend.

 [SetFixedFace](#)

Sets the fixed face of this sketched bend.

[Top](#)

See Also

[ISketchedBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchedBendFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISketchedBendFeatureData Interface

For a list of all members of this type, see [ISketchedBendFeatureData members](#).

Public Properties

Name	Description
 BendAngle	Gets or sets the bend angle of this sketched bend.
 BendRadius	Gets or sets the bend radius of this sketched bend.
 OverrideValue	Gets whether the bend angle of this sketched bend is overridden by a custom bend angle.
 PositionType	Gets or sets the bend position of this sketched bend.
 ReverseDirection	Gets or sets whether the direction of the sketched bend angle is reversed.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this sketched bend.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius of this sketched bend.
 UseGaugeTable	Gets or sets whether to use available bend radius values from a gauge table for this sketched bend.

[Top](#)

See Also

[ISketchedBendFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : AccessSelections Method (ISketchedBendFeatureData)

Gains access to the selections that describe this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::AccessSelections](#).

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISketchedBendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)
[ISketchedBendFeatureData::AccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAngle Property (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : BendAngle Property (ISketchedBendFeatureData)

Gets or sets the bend angle of this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Property BendAngle As System.Double
```

```
Dim instance As ISketchedBendFeatureData
Dim value As System.Double

instance.BendAngle = value

value = instance.BendAngle
```

C#

```
System.double BendAngle {get; set;}
```

C++/CLI

```
property System.double BendAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.261799 <= Bend angle in increments of 0.261799 radians (15 degrees) <= 1.5708

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::BendAngle](#).

Example

See the [ISketchedBendFeatureData::OverrideValue](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : BendRadius Property (ISketchedBendFeatureData)

Gets or sets the bend radius of this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Property BendRadius As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISketchedBendFeatureData
Dim value As System.Double

instance.BendRadius = value
```

```
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius in meters

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::BendRadius](#).

Example

See the [ISketchedBendFeatureData](#) and [ISketchedBendFeatureData::UseGaugeTable](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

This property is valid only if [ISketchedBendFeatureData::UseDefaultBendRadius](#) is false.

To use something other than the default bend radius, set:

- [ISketchedBendFeatureData::UseDefaultBendRadius](#) to false
- and -
- [ISketchedBendFeatureData::UseGaugeTable](#) to false.

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : GetCustomBendAllowance Method (ISketchedBendFeatureData)

Gets the custom bend allowance for this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
Dim value As CustomBendAllowance
```

```
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::GetCustomBendAllowance](#).

Example

See [ISketchedBendFeatureData](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)
[Set Custom Bend Deduction \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)
[ISketchedBendFeatureData::SetCustomBendAllowance Method](#)
[ISketchedBendFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFixedFace Method (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : GetFixedFace Method (ISketchedBendFeatureData)

Gets the fixed face from this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFixedFace( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISketchedBendFeatureData  
Dim X As System.Double  
Dim Y As System.Double
```



```
Dim Z As System.Double
Dim value As System.Object

value = instance.GetFixedFace(X, Y, Z)
```

C#

```
System.Object GetFixedFace(
    out System.double X,
    out System.double Y,
    out System.double Z
)
```

C++/CLI

```
System.Object^ GetFixedFace(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X location

Y
Y location

Z
Z location

Return Value

Fixed [IFace2](#) that does not move as a result of the bend

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::GetFixedFace](#).

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

The location is a point on the fixed face, but in the space of the sketch used to define the sketched-bend feature. Thus, the z location is always C

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)
[ISketchedBendFeatureData::SetFixedFace Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISketchedBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : IAccessSelections Method (ISketchedBendFeatureData)

Obsolete. Superseded by [ISketchedBendFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::IAccessSelections](#).

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (ISketchedBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : IAccessSelections2 Method (ISketchedBendFeatureData)

Gains access to the selections that describe this sketched bend feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISketchBendFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISketchBendFeatureData Interface](#)

[ISketchBendFeatureData Members](#)

[ISketchBendFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideValue Property (ISketchBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchBendFeatureData Interface](#) : OverrideValue Property (ISketchBendFeatureData)

Gets whether the bend angle of this sketched bend is overridden by a custom bend angle.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property OverrideValue As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData
Dim value As System.Boolean
```

```
value = instance.OverrideValue
```

C#

```
System.bool OverrideValue {get;}
```

C++/CLI

```
property System.bool OverrideValue {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the bend angle is overridden by a custom bend angle, false if the bend angle is from a gauge table

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData.OverrideValue](#).

Example

'VBA

'=====

'This example demonstrates how setting BendAngle influences the read-only OverrideValue property.

,

'Preconditions:

'1. Ensure the specified paths exist.

'2. Open an Immediate window.

,

'Postconditions:

'1. A part with **Sheet-Metal**, **Base-Flange1**, and **Sketched Bend1** features is created.

'2. Inspect the Immediate window.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim Part As SldWorks.ModelDoc2
Dim swPart As SldWorks.PartDoc
Dim myModelView As SldWorks.ModelView
Dim vSkLines As Variant
Dim swFeat As SldWorks.Feature
Dim swFeatMgr As SldWorks.FeatureManager
Dim customBendAllowanceData As SldWorks.CustomBendAllowance
Dim skSegment As SldWorks.SketchSegment
Dim CBAObject As SldWorks.CustomBendAllowance
Dim myFeature As SldWorks.Feature
Dim swFeatData As SldWorks.BaseFlangeFeatureData
Dim skBendFeatData As SldWorks.SketchedBendFeatureData
Dim myFeatData As SldWorks.SketchedBendFeatureData
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long
Dim swSheetWidth As Double
Dim swSheetHeight As Double
Option Explicit
Sub main()

    Set swApp = Application.SldWorks

    swSheetWidth = 0
    swSheetHeight = 0
    Set Part = swApp.NewDocument("D:\Program Files\SOLIDWORKS Corp\SOLIDWORKS (2)\DATA\Templates\Part.prtdot", 0, swSheetWidth, swSheetHeight)

    Set swPart = Part
    swApp.ActivateDoc2 "Part2", False, longstatus
    Set Part = swApp.ActiveDoc

    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    boolstatus = Part.Extension.SelectByID2("Front Plane", "PLANE", -6.40395151030158E-02, 5.21578791231543E-02, 4.49083628119237E-03, False, 0, Nothing, 0)
```

```

Part.SketchManager.InsertSketch True
Part.ClearSelection2 True
boolstatus = Part.Extension.SelectByID2("Front Plane", "PLANE", -2.96114446516235E-02, 3.44357811398094E-02, 0, False, 0, Nothing, 0)
Part.ClearSelection2 True
boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstToRectEntity,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, False)
boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstLineDiagonalType,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, True)

vSkLines = Part.SketchManager.CreateCornerRectangle(-5.22359192169088E-02, 3.27722168335384E-02, 0, 0.077854809533482,
-4.14227512261475E-02, 0)
Part.ClearSelection2 True
Part.SketchManager.InsertSketch True

Part.ShowNamedView2 ""Trimetric", 8
Part.ViewZoomtofit2
Part.SketchManager.InsertSketch True
Part.CloseFamilyTable
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Part.CloseFamilyTable

Set customBendAllowanceData = Part.FeatureManager.CreateCustomBendAllowance()

Set swFeatMgr = Part.FeatureManager

'Create a sheet metal base flange

Set swFeatData = swFeatMgr.CreateDefinition(swFeatureNameID_e.swFmBaseFlange)
swFeatData.Initialize False, True, customBendAllowanceData, True, 1, True, 0.5, 0.0001, 0.0001
swFeatData.BendRadius = 0.00635
swFeatData.D1EndConditionDistance = 0.02
swFeatData.D1EndConditionType = 1
swFeatData.D1ReverseOffset = False
swFeatData.D2EndConditionDistance = 0.01
swFeatData.D2EndConditionType = 1
swFeatData.D2ReverseOffset = False
swFeatData.OffsetDirections = 1
swFeatData.ReverseDirection = False
swFeatData.ReverseThickness = False
swFeatData.Thickness = 0.00531368
swFeatData.UseGaugeTable = True
swFeatData.GaugeTablePath = "D:\Program Files\SOLIDWORKS Corp\SOLIDWORKS (2)\lang\english\Sheet Metal Gauge Tables\bend
allowance mm sample.xlsx"
Set swFeat = swFeatMgr.CreateFeature(swFeatData)
Part.ClearSelection2 True
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized
Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized

Part.GraphicsRedraw2
boolstatus = Part.Extension.SelectByRay(-1.81805886692246E-02, 2.58328472214089E-02, 0, -0.400036026779312, -0.515038074910024,
-0.758094294050284, 1.07315913654528E-03, 2, False, 0, 0)
Part.SketchManager.InsertSketch True
Part.ClearSelection2 True
boolstatus = Part.Extension.SelectByRay(-3.71158985098665E-02, 2.32231794094294E-02, 0, 0, 0, -1, 6.76279555664225E-04, 2, False, 0,
0)
Part.ClearSelection2 True

Set skSegment = Part.SketchManager.CreateLine(-0.007678, 0.057833, 0#, -0.059393, -0.042615, 0#)
Part.ClearSelection2 True
Part.SketchManager.InsertSketch True
Part.SketchManager.InsertSketch True
boolstatus = Part.Extension.SelectByRay(-3.97811503331896E-03, 1.40228554924494E-02, 0, 0, 0, -1, 6.76279555664225E-04, 2, True, 0,
0)

'Create a sheet metal sketched bend

```

```

Set skBendFeatData = Part.FeatureManager.CreateDefinition(swFmSketchBend)

skBendFeatData.BendAngle = 1.6
skBendFeatData.UseDefaultBendRadius = False
skBendFeatData.BendRadius = 0.001
skBendFeatData.ReverseDirection = False

Set CBAObject = skBendFeatData.GetCustomBendAllowance()
CBAObject.BendAllowance = 0.003
Call skBendFeatData.SetCustomBendAllowance(CBAObject)

Set myFeature = Part.FeatureManager.CreateFeature(skBendFeatData)

'Modify feature
Set myFeatData = myFeature.GetDefinition()

'Is the bend angle overridden?
Debug.Print "Bend angle is overridden? " & myFeatData.OverrideValue
'If OverrideValue is true, then the bend angle is a custom value not in the current gauge table

'Set a new value for bend angle in radians
myFeatData.BendAngle = 1.5707963267949

boolstatus = myFeature.ModifyDefinition(myFeatData, Part, Nothing)

Set myFeatData = myFeature.GetDefinition()

'Is the bend angle in the gauge table or is it overridden?
Debug.Print "Bend angle is overridden? " & myFeatData.OverrideValue
'If OverrideValue is false, then the bend angle is in the current gauge table

End Sub

```

Remarks

This property:

- is valid only when a sheet metal gauge table has been selected for a parent sheet metal feature (e.g., lofted bend, swept flange, or base flange).
- cannot be set. Rather, it is calculated from the bend angle value. If the bend angle is in the gauge table, then this property is set to false. If the bend angle is not in the gauge table, then it is considered a custom value, and this property is set to true.

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)
[ISketchedBendFeatureData::BendAngle Property\(\)](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionType Property (ISketchedBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : PositionType Property (ISketchedBendFeatureData)

Gets or sets the bend position of this sketched bend.

.NET Syntax

Visual Basic (Declaration)

Property PositionType As System.Integer

Visual Basic (Usage)



```

Dim instance As ISketchedBendFeatureData
Dim value As System.Integer

```

```
instance.PositionType = value
```

```
value = instance.PositionType
```

C#

```
System.int PositionType {get; set;}
```

C++/CLI

```
property System.int PositionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend position as defined in [swFlangePositionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::PositionType](#).

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ISketchedBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : ReleaseSelectionAccess Method (ISketchedBendFeatureData)

Releases access to selections that describe this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISketchdBendFeatureData::AccessSelections](#) and [ISketchdBendFeatureData::IAccessSelections2](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISketchdBendFeatureData Interface](#)
[ISketchdBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISketchdBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchdBendFeatureData Interface](#) : ReverseDirection Property (ISketchdBendFeatureData)

Gets or sets whether the direction of the sketched bend angle is reversed.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchdBendFeatureData
Dim value As System.Boolean

instance.ReverseDirection = value

value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the bend angle, false to not

Visual Basic for Applications (VBA) Syntax

See [SketchdBendFeatureData::ReverseDirection](#).

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

See Also

[ISketchdBendFeatureData Interface](#)
[ISketchdBendFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (ISketchBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchBendFeatureData Interface](#) : SetCustomBendAllowance Method (ISketchBendFeatureData)

Sets the custom bend allowance for this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchBendFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData
[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [SketchBendFeatureData::SetCustomBendAllowance](#).

Example

[Set Custom Bend Deduction \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchBendFeatureData Interface](#)
[ISketchBendFeatureData Members](#)
[ISketchBendFeatureData::GetCustomBendAllowance Method](#)
[ISketchBendFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SetFixedFace Method (ISketchedBendFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : SetFixedFace Method (ISketchedBendFeatureData)

Sets the fixed face of this sketched bend.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFixedFace( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal EdgeArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim EdgeArray As System.Object  
  
instance.SetFixedFace(X, Y, Z, EdgeArray)
```

C#

```
void SetFixedFace(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.object EdgeArray  
)
```

C++/CLI

```
void SetFixedFace(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.Object^ EdgeArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X location

Y

Y location

Z

Z location

EdgeArray

Array of edges

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::SetFixedFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchdBendFeatureData Interface](#)
[ISketchdBendFeatureData Members](#)
[ISketchdBendFeatureData::GetFixedFace Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (ISketchdBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchdBendFeatureData Interface](#) : UseDefaultBendAllowance Property (ISketchdBendFeatureData)

Gets or sets whether to use the default bend allowance for this sketched bend.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchdBendFeatureData
Dim value As System.Boolean

instance.UseDefaultBendAllowance = value
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend allowance, false does not

Visual Basic for Applications (VBA) Syntax

See [SketchdBendFeatureData::UseDefaultBendAllowance](#).

Example

See [ISketchdBendFeatureData](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)
[Set Custom Bend Deduction \(VBA\)](#)

See Also

[ISketchdBendFeatureData Interface](#)
[ISketchdBendFeatureData Members](#)
[ISketchdBendFeatureData::GetCustomBendAllowance Method](#)
[ISketchdBendFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRadius Property (ISketchBendFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchBendFeatureData Interface](#) : UseDefaultBendRadius Property (ISketchBendFeatureData)

Gets or sets whether to use the default bend radius of this sketched bend.

Visual Basic Syntax

Visual Basic (Declaration)

Property UseDefaultBendRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchBendFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRadius = value
```

```
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend radius, false to specify another bend radius

Visual Basic for Applications (VBA) Syntax

See [SketchBendFeatureData::UseDefaultBendRadius](#).

Example

See [ISketchBendFeatureData](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

This property takes precedence over [SketchBendFeatureData::UseGaugeTable](#). If this property is set to true, then ISketchBendFeatureData::UseGaugeTable is set to false and cannot be changed.

See Also

[ISketchBendFeatureData Interface](#)
[ISketchBendFeatureData Members](#)
[ISketchBendFeatureData::BendRadius Property](#)

Availability

UseGaugeTable Property (ISketchedBendFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISketchedBendFeatureData Interface](#) : UseGaugeTable Property (ISketchedBendFeatureData)

Gets or sets whether to use available bend radius values from a gauge table for this sketched bend.

.NET Syntax

Visual Basic (Declaration)

Property UseGaugeTable As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchedBendFeatureData
Dim value As System.Boolean
```

```
instance.UseGaugeTable = value
```

```
value = instance.UseGaugeTable
```

C#

```
System.bool UseGaugeTable {get; set;}
```

C++/CLI

```
property System.bool UseGaugeTable {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

True to use available bend radius values from a gauge table, false to not

Visual Basic for Applications (VBA) Syntax

See [SketchedBendFeatureData::UseGaugeTable](#).

Example

'VBA

'=====

```
'This example demonstrates how to set the bend radius of a sketched bend
'by setting UseGaugeTable to false.
```

'

'Preconditions:

- '1. Ensure the specified paths exist.
- '2. Open an Immediate window.

'

'Postconditions:

- '1. A part with **Sheet-Metal**, **Base-Flange1**, and **Sketched Bend1** features is created.
- '2. Inspect the Immediate window.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim Part As SldWorks.ModelDoc2
Dim swPart As SldWorks.PartDoc
Dim myModelView As SldWorks.ModelView
Dim vSkLines As Variant
Dim swFeat As SldWorks.Feature
Dim swFeatMgr As SldWorks.FeatureManager
Dim customBendAllowanceData As SldWorks.CustomBendAllowance
Dim skSegment As SldWorks.SketchSegment
Dim CBAObject As SldWorks.CustomBendAllowance
Dim myFeature As SldWorks.Feature
Dim swFeatData As SldWorks.BaseFlangeFeatureData
```

```

Dim skBendFeatData As SldWorks.SketchedBendFeatureData
Dim myFeatData As SldWorks.SketchedBendFeatureData
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long
Dim swSheetWidth As Double
Dim swSheetHeight As Double
Option Explicit

Sub main()

    Set swApp = Application.SldWorks

    swSheetWidth = 0
    swSheetHeight = 0
    Set Part = swApp.NewDocument("D:\Program Files\SOLIDWORKS Corp\SOLIDWORKS (2)\DATA\Templates\Part.prtdot", 0, swSheetWidth,
swSheetHeight)

    Set swPart = Part
    swApp.ActivateDoc2 "Part2", False, longstatus
    Set Part = swApp.ActiveDoc

    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    boolstatus = Part.Extension.SelectByID2("Front Plane", "PLANE", -6.40395151030158E-02, 5.21578791231543E-02, 4.49083628119237E-
03, False, 0, Nothing, 0)
    Part.SketchManager.InsertSketch True
    Part.ClearSelection2 True
    boolstatus = Part.Extension.SelectByID2("Front Plane", "PLANE", -2.96114446516235E-02, 3.44357811398094E-02, 0, False, 0, Nothing, 0)
    Part.ClearSelection2 True
    boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstToRectEntity,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, False)
    boolstatus = Part.Extension.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstLineDiagonalType,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, True)

    vSkLines = Part.SketchManager.CreateCornerRectangle(-5.22359192169088E-02, 3.27722168335384E-02, 0, 0.077854809533482,
-4.14227512261475E-02, 0)
    Part.ClearSelection2 True
    Part.SketchManager.InsertSketch True

    Part.ShowNamedView2 "**Trimetric", 8
    Part.ViewZoomtofit2
    Part.SketchManager.InsertSketch True
    Part.CloseFamilyTable
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized
    Part.CloseFamilyTable

    Set customBendAllowanceData = Part.FeatureManager.CreateCustomBendAllowance()

    Set swFeatMgr = Part.FeatureManager

    Set swFeatData = swFeatMgr.CreateDefinition(swFeatureNameID_e.swFmBaseFlange)
    swFeatData.Initialize False, True, customBendAllowanceData, True, 1, True, 0.5, 0.0001, 0.0001
    swFeatData.BendRadius = 0.00635
    swFeatData.D1EndConditionDistance = 0.02
    swFeatData.D1EndConditionType = 1
    swFeatData.D1ReverseOffset = False
    swFeatData.D2EndConditionDistance = 0.01
    swFeatData.D2EndConditionType = 1
    swFeatData.D2ReverseOffset = False
    swFeatData.OffsetDirections = 1
    swFeatData.ReverseDirection = False
    swFeatData.ReverseThickness = False
    swFeatData.Thickness = 0.00531368
    swFeatData.UseGaugeTable = True
    swFeatData.GaugeTablePath = "D:\Program Files\SOLIDWORKS Corp\SOLIDWORKS (2)\lang\english\Sheet Metal Gauge Tables\bend
allowance mm sample.xlsx"
    Set swFeat = swFeatMgr.CreateFeature(swFeatData)
    Part.ClearSelection2 True
    Set myModelView = Part.ActiveView
    myModelView.FrameState = swWindowState_e.swWindowMaximized

```

```

Set myModelView = Part.ActiveView
myModelView.FrameState = swWindowState_e.swWindowMaximized

Part.GraphicsRedraw2
boolstatus = Part.Extension.SelectByRay(-1.81805886692246E-02, 2.58328472214089E-02, 0, -0.400036026779312, -0.515038074910024,
-0.758094294050284, 1.07315913654528E-03, 2, False, 0, 0)
Part.SketchManager.InsertSketch True
Part.ClearSelection2 True
boolstatus = Part.Extension.SelectByRay(-3.71158985098665E-02, 2.32231794094294E-02, 0, 0, 0, -1, 6.76279555664225E-04, 2, False, 0,
0)
Part.ClearSelection2 True

Set skSegment = Part.SketchManager.CreateLine(-0.007678, 0.057833, 0#, -0.059393, -0.042615, 0#)
Part.ClearSelection2 True
Part.SketchManager.InsertSketch True
Part.SketchManager.InsertSketch True
boolstatus = Part.Extension.SelectByRay(-3.97811503331896E-03, 1.40228554924494E-02, 0, 0, 0, -1, 6.76279555664225E-04, 2, True, 0,
0)

Set skBendFeatData = Part.FeatureManager.CreateDefinition(swFmSketchBend)

skBendFeatData.BendAngle = 1.5707963267949

'If using a default bend radius, you cannot set the bend radius
skBendFeatData.UseDefaultBendRadius = False
skBendFeatData.BendRadius = 0.001
skBendFeatData.ReverseDirection = False

'UseGaugeTable is valid only if UseDefaultBendRadius is false
skBendFeatData.UseGaugeTable = True

Set CBAObject = skBendFeatData.GetCustomBendAllowance()
CBAObject.BendAllowance = 0.003
Call skBendFeatData.SetCustomBendAllowance(CBAObject)

Set myFeature = Part.FeatureManager.CreateFeature(skBendFeatData)
Debug.Print "Sketched bend type name: " & myFeature.GetTypeName2()

'Make some modifications
Set myFeatData = myFeature.GetDefinition()

'If using a gauge table, you cannot set the bend radius
Debug.Print "Use gauge table? " & myFeatData.UseGaugeTable

'Do not use gauge table, so you can set the bend radius
myFeatData.UseGaugeTable = False
myFeatData.BendRadius = 0.00635

Debug.Print "Bend radius set to: " & myFeatData.BendRadius

boolstatus = myFeature.ModifyDefinition(myFeatData, Part, Nothing)

End Sub

```

Remarks

This property:

- is valid only if a gauge table is specified in a parent sheet metal feature (e.g., lofted bend, swept flange, base flange).
- is valid only if [ISketchedBendFeatureData::UseDefaultBendRadius](#) is set to false.
- is automatically set to false and cannot be changed if [ISketchedBendFeatureData::UseDefaultBendRadius](#) is set to true.
- must be set to false in order to set [ISketchedBendFeatureData::BendRadius](#).

See Also

[ISketchedBendFeatureData Interface](#)
[ISketchedBendFeatureData Members](#)

Availability

ISketchEllipse (Type)

ISketchEllipse Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchEllipse Interface

Provides access to sketched ellipse entities.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchEllipse
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
```

C#

```
public interface ISketchEllipse
```

C++/CLI

```
public interface class ISketchEllipse
```

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse](#).

Example

[Create Ellipse \(VBA\)](#)
[Create Ellipse \(VB.NET\)](#)
[Create Ellipse \(C#\)](#)

Accessors

[ISketchManager::CreateEllipse](#)

Access Diagram

[SketchEllipse](#)

See Also

[ISketchEllipse Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISketchEllipse Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchEllipse Interface

For a list of all members of this type, see [ISketchEllipse members](#).

Public Methods

Name	Description
GetCenterPoint	Obsolete. Superseded by ISketchEllipse::GetCenterPoint2 and ISketchEllipse::IGetCenterPoint2 .
GetCenterPoint2	Gets the sketch point for the center point of the ellipse.
GetEndPoint	Obsolete. Superseded by ISketchEllipse::GetEndPoint2 and ISketchEllipse::IGetEndPoint2 .

		
	GetEndPoint	Gets the sketch point for the end point of the ellipse.
	GetMajorPoint	Obsolete. Superseded by ISketchEllipse::GetMajorPoint2 and ISketchEllipse::IGetMajorPoint2
	GetMajorPoint2	Gets the sketch point for the major point of the ellipse.
	GetMinorPoint	Obsolete. Superseded by ISketchEllipse::GetMinorPoint2 and ISketch Ellipse::IGetMinorPoint2
	GetMinorPoint2	Gets the sketch point for the minor point of the ellipse.
	GetRotationDir	Gets the rotation direction for this sketch ellipse segment.
	GetStartPoint	Obsolete. Superseded by ISketchEllipse::GetStartPoint2 and ISketchEllipse::IGetStartPoint2
	GetStartPoint2	Gets the sketch point for the start point of the ellipse.
	IGetCenterPoint	Obsolete. Superseded by ISketchEllipse::GetCenterPoint2 and ISketch Ellipse::IGetCenterPoint2
	IGetCenterPoint2	Gets the sketch point for the center point of the ellipse.
	IGetEndPoint	Obsolete. Superseded by ISketchEllipse::GetEndPoint2 and ISketch Ellipse::IGetEndPoint2
	IGetEndPoint2	Gets the sketch point for the end point of the ellipse.
	IGetMajorPoint	Obsolete. Superseded by ISketchEllipse::GetMajorPoint2 and ISketch Ellipse::IGetMajorPoint2
	IGetMajorPoint2	Gets the sketch point for the major point of the ellipse.
	IGetMinorPoint	Obsolete. Superseded by ISketchEllipse::GetMinorPoint2 and ISketch Ellipse::IGetMinorPoint2
	IGetMinorPoint2	Gets the sketch point for the minor point of the ellipse.
	IGetStartPoint	Obsolete. Superseded by ISketchEllipse::GetStartPoint2 and ISketchEllipse::IGetStartPoint2
	IGetStartPoint2	Gets the sketch point for the start point of the ellipse.

[Top](#)

See Also

[ISketchEllipse Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchEllipse Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchEllipse Interface

The following tables list the members exposed by [ISketchEllipse](#).

Public Methods

Name	Description
 GetCenterPoint	Obsolete. Superseded by ISketchEllipse::GetCenterPoint2 and ISketch Ellipse::IGetCenterPoint2
 GetCenterPoint2	Gets the sketch point for the center point of the ellipse.
 GetEndPoint	Obsolete. Superseded by ISketchEllipse::GetEndPoint2 and ISketch Ellipse::IGetEndPoint2
 GetEndPoint2	Gets the sketch point for the end point of the ellipse.
 GetMajorPoint	Obsolete. Superseded by ISketchEllipse::GetMajorPoint2 and ISketch Ellipse::IGetMajorPoint2
 GetMajorPoint2	Gets the sketch point for the major point of the ellipse.
 GetMinorPoint	Obsolete. Superseded by ISketchEllipse::GetMinorPoint2 and ISketch Ellipse::IGetMinorPoint2
 GetMinorPoint2	Gets the sketch point for the minor point of the ellipse.
 GetRotationDir	Gets the rotation direction for this sketch ellipse segment.
 GetStartPoint	Obsolete. Superseded by ISketchEllipse::GetStartPoint2 and ISketch Ellipse::IGetStartPoint2
 GetStartPoint2	Gets the sketch point for the start point of the ellipse.
 IGetCenterPoint	Obsolete. Superseded by ISketchEllipse::GetCenterPoint2 and ISketch Ellipse::IGetCenterPoint2

	IGetCenterPoint2	Gets the sketch point for the center point of the ellipse.
	IGetEndPoint	Obsolete. Superseded by ISketchEllipse::GetEndPoint2 and ISketch Ellipse::IGetEndPoint2 .
	IGetEndPoint2	Gets the sketch point for the end point of the ellipse.
	IGetMajorPoint	Obsolete. Superseded by ISketchEllipse::GetMajorPoint2 and ISketch Ellipse::IGetMajorPoint2 .
	IGetMajorPoint2	Gets the sketch point for the major point of the ellipse.
	IGetMinorPoint	Obsolete. Superseded by ISketchEllipse::GetMinorPoint2 and ISketch Ellipse::IGetMinorPoint2 .
	IGetMinorPoint2	Gets the sketch point for the minor point of the ellipse.
	IGetStartPoint	Obsolete. Superseded by ISketchEllipse::GetStartPoint2 and ISketch Ellipse::IGetStartPoint2 .
	IGetStartPoint2	Gets the sketch point for the start point of the ellipse.

[Top](#)

See Also

[ISketchEllipse Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCenterPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetCenterPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetCenterPoint2](#) and [ISketch Ellipse::IGetCenterPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Object

value = instance.GetCenterPoint()
```

C#

```
System.object GetCenterPoint()
```

C++/CLI

```
System.Object^ GetCenterPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetCenterPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCenterPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetCenterPoint2 Method (ISketchEllipse)

Gets the sketch point for the center point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetCenterPoint2()
```

C#

```
System.object GetCenterPoint2()
```

C++/CLI

```
System.Object^ GetCenterPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Center [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetCenterPoint2](#).

Example

See the [ISketchEllipse](#) examples.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::IGetCenterPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetEndPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetEndPoint2](#) and [ISketch Ellipse::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetEndPoint()
```

C#

```
System.object GetEndPoint()
```

C++/CLI

```
System.Object^ GetEndPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetEndPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetEndPoint2 Method (ISketchEllipse)

Gets the sketch point for the end point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetEndPoint2()
```

C#

```
System.object GetEndPoint2()
```

C++/CLI

```
System.Object^ GetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetEndPoint2](#).

Example

See the [ISketchEllipse](#) examples.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::IGetEndPoint2 Method](#)

Availability

GetMajorPoint Method (ISketchEllipse)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetMajorPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetMajorPoint2](#) and [ISketchEllipse::IGetMajorPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetMajorPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetMajorPoint()
```

C#

```
System.object GetMajorPoint()
```

C++/CLI

```
System.Object^ GetMajorPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetMajorPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

GetMajorPoint2 Method (ISketchEllipse)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetMajorPoint2 Method (ISketchEllipse)

Gets the sketch point for the major point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMajorPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetMajorPoint2()
```

C#

```
System.object GetMajorPoint2()
```

C++/CLI

```
System.Object^ GetMajorPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Major [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetMajorPoint2](#).

Example

See the [ISketchEllipse](#) examples.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::IGetMajorPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMinorPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetMinorPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetMinorPoint2](#) and [ISketch Ellipse::IGetMinorPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetMinorPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetMinorPoint()
```

C#

```
System.object GetMinorPoint()
```

C++/CLI

```
System.Object^ GetMinorPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetMinorPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMinorPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetMinorPoint2 Method (ISketchEllipse)

Gets the sketch point for the minor point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMinorPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Object

value = instance.GetMinorPoint2()
```

C#

```
System.object GetMinorPoint2()
```

C++/CLI

```
System.Object^ GetMinorPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Minor [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetMinorPoint2](#).

Example

See the [ISketchEllipse](#) examples.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::IGetMinorPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRotationDir Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetRotationDir Method (ISketchEllipse)

Gets the rotation direction for this sketch ellipse segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRotationDir() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Integer

value = instance.GetRotationDir()
```

C#

```
System.int GetRotationDir()
```

C++/CLI

```
System.int GetRotationDir();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Rotation direction (counterclockwise = 1, clockwise = -1)

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetRotationDir](#).

Remarks

This method determines the direction (counterclockwise or clockwise) that the sketch entity proceeds around the ellipse, beginning at its start point and ending at its ending point if the sketch entity is not a complete ellipse.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStartPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetStartPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetStartPoint2](#) and [ISketchEllipse::IGetStartPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetStartPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Object

value = instance.GetStartPoint()
```

C#

```
System.object GetStartPoint()
```

C++/CLI

```
System.Object^ GetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetStartPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStartPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : GetStartPoint2 Method (ISketchEllipse)

Gets the sketch point for the start point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStartPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Object  
  
value = instance.GetStartPoint2()
```

C#

```
System.object GetStartPoint2()
```

C++/CLI

```
System.Object^ GetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::GetStartPoint2](#).

Example

See the [ISketchEllipse](#) examples.

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::IGetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCenterPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetCenterPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetCenterPoint2](#) and [ISketchEllipse::IGetCenterPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCenterPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Double  
  
value = instance.IGetCenterPoint()
```

C#

```
System.double IGetCenterPoint()
```

C++/CLI

```
System.double IGetCenterPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse.IGetCenterPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCenterPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetCenterPoint2 Method (ISketchEllipse)

Gets the sketch point for the center point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCenterPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As SketchPoint  
  
value = instance.IGetCenterPoint2()
```

C#

```
SketchPoint IGetCenterPoint2()
```

C++/CLI

```
SketchPoint^ IGetCenterPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Center [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetCenterPoint2](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::GetCenterPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetEndPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetEndPoint2](#) and [ISketch Ellipse::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Double  
  
value = instance.IGetEndPoint()
```

C#

```
System.double IGetEndPoint()
```

C++/CLI

```
System.double IGetEndPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetEndPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetEndPoint2 Method (ISketchEllipse)

Gets the sketch point for the end point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As SketchPoint

value = instance.IGetEndPoint2()
```

C#

```
SketchPoint IGetEndPoint2()
```

C++/CLI

```
SketchPoint^ IGetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse.IGetEndPoint2](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::GetEndPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMajorPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetMajorPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetMajorPoint2](#) and [ISketchEllipse::IGetMajorPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMajorPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Double

value = instance.IGetMajorPoint()
```

C#

```
System.double IGetMajorPoint()
```

C++/CLI

```
System.double IGetMajorPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse.IGetMajorPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetMajorPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetMajorPoint2 Method (ISketchEllipse)

Gets the sketch point for the major point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMajorPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As SketchPoint  
  
value = instance.IGetMajorPoint2()
```

C#

```
SketchPoint IGetMajorPoint2()
```

C++/CLI

```
SketchPoint^ IGetMajorPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Major [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetMajorPoint2](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::GetMajorPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetMinorPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetMinorPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetMinorPoint2](#) and [ISketch Ellipse::IGetMinorPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMinorPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As System.Double

value = instance.IGetMinorPoint()
```

C#

```
System.double IGetMinorPoint()
```

C++/CLI

```
System.double IGetMinorPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetMinorPoint](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMinorPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetMinorPoint2 Method (ISketchEllipse)

Gets the sketch point for the minor point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMinorPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse
Dim value As SketchPoint

value = instance.IGetMinorPoint2()
```

C#

```
SketchPoint IGetMinorPoint2()
```

C++/CLI

```
SketchPoint^ IGetMinorPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Minor [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetMinorPoint2](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::GetMinorPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetStartPoint Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetStartPoint Method (ISketchEllipse)

Obsolete. Superseded by [ISketchEllipse::GetStartPoint2](#) and [ISketchEllipse::IGetStartPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As System.Double  
  
value = instance.IGetStartPoint()
```

C#

```
System.double IGetStartPoint()
```

C++/CLI

```
System.double IGetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse.IGetStartPoint](#).

See Also

[ISketchEllipse Interface](#)

[ISketchEllipse Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetStartPoint2 Method (ISketchEllipse)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchEllipse Interface](#) : IGetStartPoint2 Method (ISketchEllipse)

Gets the sketch point for the start point of the ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchEllipse  
Dim value As SketchPoint  
  
value = instance.IGetStartPoint2()
```

C#

```
SketchPoint IGetStartPoint2()
```

```
SketchPoint^ IGetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchEllipse::IGetStartPoint2](#).

See Also

[ISketchEllipse Interface](#)
[ISketchEllipse Members](#)
[ISketchEllipse::GetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0