

SOLIDWORKS API (.NET VBA C#) — Reference

(270/337): ISketchHatch-ISketchLine

SOLIDWORKS API Documentation (converted from CHM)

ISketchHatch (Type)

ISketchHatch Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchHatch Interface

Represents an area hatch, which is inserted into a SOLIDWORKS drawing polygon or component face when you click **Insert > Annotations > Area Hatch/Fill** in a SOLIDWORKS drawing.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchHatch
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch
```

C#

```
public interface ISketchHatch
```

C++/CLI

```
public interface class ISketchHatch
```

Visual Basic for Applications (VBA) Syntax

See [SketchHatch](#).

Example

[Get Area Hatch Data \(VBA\)](#)
[Get Area Hatch Data \(VB.NET\)](#)
[Get Area Hatch Data \(C#\)](#)

Accessors

[IEnumerableSketchHatches::Next](#)
[ILayer::GetItems](#)
[ISketch::GetSketchHatches](#)

Access Diagram

[SketchHatch](#)

See Also

[ISketchHatch Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumerableSketchHatches Interface](#)

ISketchHatch Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchHatch Interface

The following tables list the members exposed by [ISketchHatch](#).

Public Properties

Name	Description
------	-------------

 Angle	Gets or sets the hatch angle.
 Color	Gets or sets the sketch hatch line color.
 Layer	Gets or sets the layer used by this sketch hatch.
 LayerOverride	Gets or sets whether the sketch hatch has properties that override the default properties of the layer.
 Pattern	Gets or sets the hatch pattern (also called type or name) of the sketch hatch (for example, "Stars" or "Honeycomb"), which is a string from the sldwks.ptn file.
 PatternId	Gets the pattern ID for this sketch hatch.
 Scale	Obsolete. Superseded by ISketchHatch::Scale2.
 Scale2	Gets or sets the hatch pattern scale.
 SolidFill	Gets or sets whether to enable solid fill for the sketch hatch.

[Top](#)

Public Methods

Name	Description
 Deselect	Deselects the sketch hatch.
 GetFace	Gets the face associated with this sketch hatch.
 GetID	Gets the ID for this sketch hatch.
 GetSketch	Gets the sketch for the current sketch hatch.
 IGetFace	Obsolete. Superseded by ISketchHatch::IGetFace2.
 IGetFace2	Gets the face associated with this sketch hatch.
 IGetID	Gets the ID for this sketch hatch.
 Select	Obsolete. Superseded by ISketchHatch::Select4.
 Select2	Obsolete. Superseded by ISketchHatch::Select4.
 Select3	Obsolete. Superseded by ISketchHatch::Select4.
 Select4	Selects the sketch hatch and marks it.
 SelectByMark	Obsolete. Superseded by ISketchHatch::Select4.

[Top](#)

See Also

[ISketchHatch Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumSketchHatches Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchHatch Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchHatch Interface

For a list of all members of this type, see [ISketchHatch members](#).

Public Methods

Name	Description
 Deselect	Deselects the sketch hatch.
 GetFace	Gets the face associated with this sketch hatch.
 GetID	Gets the ID for this sketch hatch.
 GetSketch	Gets the sketch for the current sketch hatch.
 IGetFace	Obsolete. Superseded by ISketchHatch::IGetFace2.
 IGetFace2	Gets the face associated with this sketch hatch.
 IGetID	Gets the ID for this sketch hatch.

		
 Select	Obsolete. Superseded by ISketchHatch.Select4	
 Select2	Obsolete. Superseded by ISketchHatch.Select4	
 Select3	Obsolete. Superseded by ISketchHatch.Select4	
 Select4	Selects the sketch hatch and marks it.	
 SelectByMark	Obsolete. Superseded by ISketchHatch.Select4	

[Top](#)

See Also

[ISketchHatch Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumerableSketchHatches Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchHatch Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISketchHatch Interface

For a list of all members of this type, see [ISketchHatch members](#).

Public Properties

Name	Description
 Angle	Gets or sets the hatch angle.
 Color	Gets or sets the sketch hatch line color.
 Layer	Gets or sets the layer used by this sketch hatch.
 LayerOverride	Gets or sets whether the sketch hatch has properties that override the default properties of the layer.
 Pattern	Gets or sets the hatch pattern (also called type or name) of the sketch hatch (for example, "Stars" or "Honeycomb"), which is a string from the sldwks.ptn file.
 PatternId	Gets the pattern ID for this sketch hatch.
 Scale	Obsolete. Superseded by ISketchHatch.Scale2
 Scale2	Gets or sets the hatch pattern scale.
 SolidFill	Gets or sets whether to enable solid fill for the sketch hatch.

[Top](#)

See Also

[ISketchHatch Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumerableSketchHatches Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Angle Property (ISketchHatch)

Gets or sets the hatch angle.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Double
```

```
instance.Angle = value  
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hatch angle in radians

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Angle](#).

Example

See the [ISketchHatch](#) examples.

Remarks

If the hatch is not in the active drawing view, you must rebuild to see the hatch at its new angle.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Color Property (ISketchHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Color Property (ISketchHatch)

Gets or sets the sketch hatch line color.

.NET Syntax

Visual Basic (Declaration)

```
Property Color As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value

Visual Basic for Applications (VBA) Syntax

See [SketchHatch.Color](#).

Example

See the [ISketchHatch](#) examples.

Example

[Override Layer Color for Area Hatch \(VBA\)](#)

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeSelect Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : DeSelect Method (ISketchHatch)

Deselects the sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Function DeSelect() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch
Dim value As System.Boolean

value = instance.DeSelect()
```

C#

```
System.bool DeSelect()
```

C++/CLI

```
System.bool DeSelect();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the sketch hatch is deselected, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::DeSelect](#).

Remarks

This method does not work well when a PropertyManager page is open or a command is running. Use [IModelDoc2::DeSelectByID](#) instead of using this method. IModelDoc2::DeSelectByID handles selection correctly whether or not a command is running.

To select or deselect a sketch hatch, the owning document of the ISketchHatch object needs to be open and visible.

ISketchHatch selections are accessible through the [ISelectionMgr](#) of the owning document of the [ISketchHatch](#) object, even if the owning document is not active.

Selection or deselection does not work for a sketch hatch in a component within an assembly. Selection or deselection does not work for a sketch hatch in a document within a drawing. Selection or deselection of sketch hatches owned by the top-level assembly or drawing works, but only if the assembly document or the drawing document is active.

If the owning sketch of a sketch hatch is active (inactive) when the sketch hatch is obtained, then it must be active (inactive) to deselect it. For example, if the owning sketch of a sketch hatch was active when the sketch hatch was obtained, then the owning sketch must be active to select or deselect the sketch hatch. Likewise, if the owning sketch of a sketch hatch was inactive when the sketch hatch was obtained, then the owning sketch must be inactive to select or deselect the sketch hatch.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::Select4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFace Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : GetFace Method (ISketchHatch)

Gets the face associated with this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Object  
  
value = instance.GetFace()
```

C#

```
System.Object GetFace()
```

C++/CLI

```
System.Object^ GetFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Face](#) associated with the sketch hatch or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::GetFace](#).

Example

See the [ISketchHatch](#) examples.

Remarks

This method returns the face in the space of the sketch or drawing view. You should not select the returned face. Only use the returned face for getting the geometry of the sketch hatch: loops, edges, equations for the edges, and so on. Do not hold on to the pointer to the face after it is used as the face is transient.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::IGetFace2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetID Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : GetID Method (ISketchHatch)

Gets the ID for this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Object
```

```
value = instance.GetID()
```

C#

```
System.object GetID()
```

C++/CLI

```
System.Object^ GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array with two longs or two integers (see [Long vs. Integer](#)) identifying this sketch hatch ID (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::GetID](#).

Example

See the [ISketchHatch](#) examples.

Remarks

The ID of the sketch hatch:

- is an ordered pair (i1, i2). The combination of these two numbers is always unique within a specific sketch.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#).

Each entity within a specific sketch has a unique ID. However, a sketch line can have the same ID values as a sketch arc within the same sketch. Likewise, in a second sketch, you may find a different sketch element with the same ID. Therefore, your application must keep track of:

- sketch element type (that is, point, line, arc, spline, and so on)
- owning sketch name
- sketch element ID to uniquely identify a sketched item

You can determine the sketch element type by using [ISketchSegment::GetType](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::IGetID Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketch Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : GetSketch Method (ISketchHatch)

Gets the sketch for the current sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As Sketch
```

```
value = instance.GetSketch()
```

C#

```
Sketch GetSketch()
```

C++/CLI

```
Sketch^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::GetSketch](#).

Remarks

You can use the [ISketch](#) interface for extracting information about geometry in the sketch.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFace Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : IGetFace Method (ISketchHatch)

Obsolete. Superseded by [ISketchHatch::IGetFace2](#).

.NET Syntax

Visual Basic (Declaration)

Function IGetFace() As Face

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As Face  
  
value = instance.IGetFace()
```

C#

Face IGetFace()

C++/CLI

Face^ IGetFace();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::IGetFace](#).

See Also

[ISketchHatch Interface](#)

[ISketchHatch Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFace2 Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : IGetFace2 Method (ISketchHatch)

Gets the face associated with this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

Function IGetFace2() As Face2

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As Face2  
  
value = instance.IGetFace2()
```

C#

Face2 IGetFace2()

C++/CLI

```
Face2^ IGetFace2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Face](#) associated with the sketch hatch or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::IGetFace2](#).

Remarks

You should not select the returned face. Only use the returned face for getting the geometry of the sketch hatch: loops, edges, equations for the edges, and so on. Do not hold onto the pointer the face after it is used as the face is transient.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::GetFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetID Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : IGetID Method (ISketchHatch)

Gets the ID for this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Integer
```

```
value = instance.IGetID()
```

C#

```
System.int IGetID()
```

C++/CLI

```
System.int IGetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array with two longs or integers (see [Long vs. Integer](#)) identifying this sketch hatch ID (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::IGetID](#).

Remarks

The ID of the sketch hatch:

- is an ordered pair (i1, i2). The combination of these two numbers is always unique within a specific sketch.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#).

Each entity within a specific sketch has a unique ID. However, a sketch line can have the same ID values as a sketch arc within the same sketch. Likewise, in a second sketch, you may find a different sketch element with the same ID. Therefore, your application must keep track of:

- sketch element type (that is, point, line, arc, spline, and so on)
- owning sketch name
- sketch element ID to uniquely identify a sketched item

You can determine the sketch element type by using [ISketchSegment::GetType](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::GetID Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layer Property (ISketchHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Layer Property (ISketchHatch)

Gets or sets the layer used by this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

Property Layer As System.String

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the layer for this sketch hatch

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Layer](#).

Example

See the [ISketchHatch](#) examples.

Example

[Override Layer Color for Area Hatch \(VBA\)](#)

Remarks

In drawing documents, sketch hatches can be created on a specific layer. Only drawing documents support layers.

The return value can be an empty string because an old document may not contain layers. This can also occur if sketch hatches have been generated in a new document in which layers have not been defined.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::LayerOverride Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

LayerOverride Property (ISketchHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : LayerOverride Property (ISketchHatch)

Gets or sets whether the sketch hatch has properties that override the default properties of the layer.

.NET Syntax

Visual Basic (Declaration)

Property LayerOverride As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Integer  
  
instance.LayerOverride = value  
value = instance.LayerOverride
```

C#

```
System.int LayerOverride {get; set;}
```

C++/CLI

```
property System.int LayerOverride {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Properties that have been overridden or should be overridden as defined in [swLayerOverride_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::LayerOverride](#).

Example

See the [ISketchHatch](#) examples.

Example

[Override Layer Color for Area Hatch \(VBA\)](#)

Remarks

Only drawing documents support layers.

Sketch hatches can be created on a layer that has specific visual properties. By default, the sketch hatches take on the visual properties defined by the layer. However, for specific sketch hatches, these visual properties can be overridden (see [ISketchHatch::Color](#)). This property gets or sets whether the default visual properties of the layer should be used by this sketch hatch.

When the sketch hatch is not on any layer, the value this property returns is undefined. You can use the [ISketchHatch::Layer](#) property to determine the name of the layer, if any, that this sketch hatch is on. If an empty string is returned by the ISketchHatch::Layer property, then this property is not used.

Sketch hatches currently support only the color visual property. Therefore, the only bit value that will currently be used by this function would be 0x1 which indicates a color override. If this property returns 0x1, this indicates that the color of this sketch hatch has been specifically set by the user and may not match the default color value associated with this sketch hatch's layer. If you pass 0 to this property, then you are indicating that the color should be reset to use the default color associated with this item's layer.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Pattern Property (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Pattern Property (ISketchHatch)

Gets or sets the hatch pattern (also called type or name) of the sketch hatch (for example, "Stars" or "Honeycomb"), which is a string from the **sldwks.ptn** file.

.NET Syntax

Visual Basic (Declaration)

Property Pattern As System.String

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.String
```

```
instance.Pattern = value
```

```
value = instance.Pattern
```

C#

```
System.string Pattern {get; set;}
```

C++/CLI

```
property System.String^ Pattern {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the hatch pattern

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Pattern](#).

Example

See the [ISketchHatch](#) examples.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::PatternId Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternId Property (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : PatternId Property (ISketchHatch)

Gets the pattern ID for this sketch hatch.

.NET Syntax

Visual Basic (Declaration)

Property PatternId As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchHatch
Dim value As System.Integer

instance.PatternId = value

value = instance.PatternId
```

C#

```
System.int PatternId {get; set;}
```

C++/CLI

```
property System.int PatternId {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern ID as defined in `install_dir\lang\language\SLDWRKS.PTN`

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::PatternId](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)
[ISketchHatch::Pattern Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale Property (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Scale Property (ISketchHatch)

Obsolete. Superseded by [ISketchHatch::Scale2](#).

.NET Syntax

Visual Basic (Declaration)

Property Scale As System.Double

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Double
```

```
instance.Scale = value
```

```
value = instance.Scale
```

C#

```
System.double Scale {get; set;}
```

C++/CLI

```
property System.double Scale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Scale](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale2 Property (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Scale2 Property (ISketchHatch)

Gets or sets the hatch pattern scale.

.NET Syntax

Visual Basic (Declaration)

Property Scale2 As System.Double

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Double
```

```
instance.Scale2 = value
```



```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hatch pattern scale

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Scale2](#).

Example

See the [ISketchHatch](#) examples.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Select Method (ISketchHatch)

Obsolete. Superseded by [ISketchHatch::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.Select(AppendFlag)
```

C#

```
System.bool Select(  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool Select(  
& System.bool AppendFlag.  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Select](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select2 Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Select2 Method (ISketchHatch)

Obsolete. Superseded by [ISketchHatch::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select2( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean
```

```
value = instance.Select2(Append, Mark)
```

C#

```
System.bool Select2(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Select2](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select3 Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Select3 Method (ISketchHatch)

Obsolete. Superseded by [ISketchHatch::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select3( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer, _  
    ByVal Callout As Callout _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim Callout As Callout  
Dim value As System.Boolean  
  
value = instance.Select3(Append, Mark, Callout)
```

C#

```
System.bool Select3(  
    System.bool Append,  
    System.int Mark,  
    Callout Callout  
)
```

C++/CLI

```
System.bool Select3(  
& System.bool Append,  
& System.int Mark,  
& Callout^ Callout  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Callout

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Select3](#).

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Select4 Method (ISketchHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchHatch Interface](#) : Select4 Method (ISketchHatch)

Selects the sketch hatch and marks it.

.NET Syntax

Visual Basic (Declaration)

```
Function Select4( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select4(Append, Data)
```

C#

```
System.bool Select4(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select4(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the selection to the selection list, false replaces the selection list with this selection

Data

[ISelectData](#) object

Return Value

True if the sketch hatch is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::Select4](#).

See Also

[ISketchHatch Interface](#)

[ISketchHatch Members](#)

[ISketchHatch::DeSelect Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SelectByMark Method (ISketchHatch)

[See Also](#)



Obsolete. Superseded by [ISketchHatch::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByMark( _  
    ByVal AppendFlag As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim AppendFlag As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.SelectByMark(AppendFlag, Mark)
```

C#

```
System.bool SelectByMark(  
    System.bool AppendFlag,  
    System.int Mark  
)
```

C++/CLI

```
System.bool SelectByMark(  
& System.bool AppendFlag,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Mark

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::SelectByMark](#).

See Also

[ISketchHatch Interface](#)

[ISketchHatch Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SolidFill Property (ISketchHatch)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [ISketchHatch Interface](#) : SolidFill Property (ISketchHatch)

Gets or sets whether to enable solid fill for the sketch hatch.

.NET Syntax

Visual Basic (Declaration)

```
Property SolidFill As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchHatch  
Dim value As System.Boolean
```

```
instance.SolidFill = value
```

```
value = instance.SolidFill
```

C#

```
System.bool SolidFill {get; set;}
```

C++/CLI

```
property System.bool SolidFill {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable solid fill, false to not

Visual Basic for Applications (VBA) Syntax

See [SketchHatch::SolidFill](#).

Example

See the [ISketchHatch](#) examples.

See Also

[ISketchHatch Interface](#)
[ISketchHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ISketchLine (Type)

ISketchLine Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchLine Interface

Provides access to sketched line entities.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchLine
```

Visual Basic (Usage)

```
Dim instance As ISketchLine
```

C#

```
public interface ISketchLine
```

C++/CLI

```
public interface class ISketchLine
```

Visual Basic for Applications (VBA) Syntax

See [SketchLine](#).

Example

[Create Imported Surface Body From Sketch \(C#\)](#)
[Autodimension All Sketches \(VBA\)](#)
[Get Direction of Bendline \(C#\)](#)
[Get Direction of Bendline \(VB.NET\)](#)
[Get Direction of Bendline \(VBA\)](#)

Accessors

- [IAngleMateFeatureData::EntitiesToMate](#)
- [ICoincidentMateFeatureData::EntitiesToMate](#)
- [ICurveDrivenPatternFeatureData::D1Direction](#)
- [ICurveDrivenPatternFeatureData::D2Direction](#)
- [ILinearPatternFeatureData::D1Axis](#)
- [ILinearPatternFeatureData::D2Axis](#)
- [ILocalCurvePatternFeatureData::D1Direction](#)
- [ILocalCurvePatternFeatureData::D2Direction](#)
- [ILocalLinearPatternFeatureData::D1Axis](#)
- [ILocalLinearPatternFeatureData::D2Axis](#)
- [ILocalLinearPatternFeatureData::RotationAxis](#)
- [IRackPinionMateFeatureData::EntitiesToMate](#)
- [IStructureSystemMemberProfile::ProfileAlignmentObject](#)
- [ISweepFeatureData::EndDirectionVector](#)
- [ISweepFeatureData::GuideCurves](#)
- [ISweepFeatureData::StartDirectionVector](#)
- [ISymmetricMateFeatureData::EntitiesToMate](#)

Access Diagram

[SketchLine](#)

See Also

[ISketchLine Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchLine Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchLine Interface

For a list of all members of this type, see [ISketchLine members](#).

Public Methods

Name	Description
 GetBendLineDirection	Gets whether the sketch line is a bendline, and, if it is, the direction of the bendline.
 GetEndPoint	Obsolete. Superseded by ISketchLine.GetEndPoint2 and ISketchLine.IGetEndPoint2 .
 GetEndPoint2	Gets the sketch point for the end point of the line.
 GetStartPoint	Obsolete. Superseded by ISketchLine.GetStartPoint2 and ISketchLine.IGetStartPoint2 .
 GetStartPoint2	Gets the sketch point for the start point of the line.
 IGetEndPoint	Obsolete. Superseded by ISketchLine.GetEndPoint2 and ISketchLine.IGetEndPoint2 .
 IGetEndPoint2	Gets the sketch point for the end point of the line.
 IGetStartPoint	Obsolete. Superseded by ISketchLine.GetStartPoint2 and ISketchLine.IGetStartPoint2 .
 IGetStartPoint2	Gets the sketch point for the start point of the line.
 MakeInfinite	Makes a line infinite.

[Top](#)

See Also

[ISketchLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchLine Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchLine Interface

The following tables list the members exposed by [ISketchLine](#).

Public Properties

Name	Description
 Angle	Gets or sets the angle of the line.
 Infinite	Gets whether the line is infinite or finite. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 GetBendLineDirection	Gets whether the sketch line is a bendline, and, if it is, the direction of the bendline.
 GetEndPoint	Obsolete. Superseded by ISketchLine.GetEndPoint2 and ISketchLine.IGetEndPoint2 .

 GetEndPoint2	Gets the sketch point for the end point of the line.
 GetEndPoint	Obsolete. Superseded by ISketchLine::GetStartPoint2 and ISketchLine::IGetStartPoint2 .
 GetStartPoint2	Gets the sketch point for the start point of the line.
 IGetEndPoint	Obsolete. Superseded by ISketchLine::GetEndPoint2 and ISketchLine::IGetEndPoint2 .
 IGetEndPoint2	Gets the sketch point for the end point of the line.
 IGetStartPoint	Obsolete. Superseded by ISketchLine::GetStartPoint2 and ISketchLine::IGetStartPoint2 .
 IGetStartPoint2	Gets the sketch point for the start point of the line.
 MakeInfinite	Makes a line infinite.

[Top](#)

 See Also

[ISketchLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchLine Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchLine Interface

For a list of all members of this type, see [ISketchLine members](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle of the line.
 Infinite	Gets whether the line is infinite or finite. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[ISketchLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : Angle Property (ISketchLine)

Gets or sets the angle of the line.

 .NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [SketchLine::Angle](#).

Example

[Make Line Infinite \(VBA\)](#)

Remarks

This property does not support lines in 3D sketches.

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBendLineDirection Method (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : GetBendLineDirection Method (ISketchLine)

Gets whether the sketch line is a bendline, and, if it is, the direction of the bendline.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendLineDirection() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Integer  
  
value = instance.GetBendLineDirection()
```

C#

```
System.int GetBendLineDirection()
```

C++/CLI

```
System.int GetBendLineDirection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Bendline direction as defined in [swBendLineDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchLine::GetBendLineDirection](#).

Example

[Get Direction of Bendline \(C#\)](#)
[Get Direction of Bendline \(VB.NET\)](#)
[Get Direction of Bendline \(VBA\)](#)

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndPoint Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : GetEndPoint Method (ISketchLine)

Obsolete. Superseded by [ISketchLine::GetEndPoint2](#) and [ISketchLine::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

Function GetEndPoint() As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Object  
  
value = instance.GetEndPoint()
```

C#

System.object GetEndPoint()

C++/CLI

System.Object^ GetEndPoint();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchLine::GetEndPoint](#).

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndPoint2 Method (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : GetEndPoint2 Method (ISketchLine)

Gets the sketch point for the end point of the line.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetEndPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Object  
  
value = instance.GetEndPoint2()
```

C#

```
System.Object GetEndPoint2()
```

C++/CLI

```
System.Object^ GetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchLine::GetEndPoint2](#).

Example

[Create Imported Surface Body From Sketch \(C#\)](#)
[Get All Elements of Sketch \(VBA\)](#)
[Get Names of Sketch Segments \(VBA\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Autodimension All Sketches \(C#\)](#)
[Autodimension All Sketches \(VB.NET\)](#)
[Autodimension All Sketches \(VBA\)](#)

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::IGetEndPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStartPoint Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : GetStartPoint Method (ISketchLine)

Obsolete. Superseded by [ISketchLine::GetStartPoint2](#) and [ISketchLine::IGetStartPoint2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetStartPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Object
```

```
value = instance.GetStartPoint()
```

C#

```
System.object GetStartPoint()
```

C++/CLI

```
System.Object^ GetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchLine::GetStartPoint](#).

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStartPoint2 Method (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : GetStartPoint2 Method (ISketchLine)

Gets the sketch point for the start point of the line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStartPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Object
```

```
value = instance.GetStartPoint2()
```

C#

```
System.object GetStartPoint2()
```

C++/CLI

```
System.Object^ GetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or NULL if operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchLine::GetStartPoint2](#).

Example

[Create Imported Surface Body From Sketch \(C#\)](#)
[Get All Elements of Sketch \(VBA\)](#)
[Get Names of Sketch Segments \(VBA\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Autodimension All Sketches \(C#\)](#)
[Autodimension All Sketches \(VB.NET\)](#)
[Autodimension All Sketches \(VBA\)](#)

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::IGetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : IGetEndPoint Method (ISketchLine)

Obsolete. Superseded by [ISketchLine::GetEndPoint2](#) and [ISketchLine::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Double  
  
value = instance.IGetEndPoint()
```

C#

```
System.double IGetEndPoint()
```

C++/CLI

```
System.double IGetEndPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchLine.IGetEndPoint](#).

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint2 Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : IGetEndPoint2 Method (ISketchLine)

Gets the sketch point for the end point of the line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As SketchPoint
```

```
value = instance.IGetEndPoint2()
```

C#

```
SketchPoint IGetEndPoint2()
```

C++/CLI

```
SketchPoint^ IGetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchLine::IGetEndPoint2](#).

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::GetEndPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetStartPoint Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : IGetStartPoint Method (ISketchLine)

Obsolete. Superseded by [ISketchLine::GetStartPoint2](#) and [ISketchLine::IGetStartPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As System.Double
```

```
value = instance.IGetStartPoint()
```

C#

```
System.double IGetStartPoint()
```

C++/CLI

```
System.double IGetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchLine::IGetStartPoint](#).

See Also

IGetStartPoint2 Method (ISketchLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : IGetStartPoint2 Method (ISketchLine)

Gets the sketch point for the start point of the line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchLine  
Dim value As SketchPoint
```

```
value = instance.IGetStartPoint2()
```

C#

```
SketchPoint IGetStartPoint2()
```

C++/CLI

```
SketchPoint^ IGetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or NULL if operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchLine::IGetStartPoint2](#).

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::GetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

Infinite Property (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : Infinite Property (ISketchLine)

Gets whether the line is infinite or finite.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Infinite As System.Boolean
```

Visual Basic (Usage)




```
Dim instance As ISketchLine
Dim value As System.Boolean

value = instance.Infinite
```

C#

```
System.bool Infinite {get;}
```

C++/CLI

```
property System.bool Infinite {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the line is infinite, false (finite) if not

Visual Basic for Applications (VBA) Syntax

See [SketchLine.Infinite](#).

Example

[Make Line Infinite \(VBA\)](#)

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::MakeInfinite Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MakeInfinite Method (ISketchLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchLine Interface](#) : MakeInfinite Method (ISketchLine)

Makes a line infinite.

.NET Syntax

Visual Basic (Declaration)

```
Function MakeInfinite() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchLine
Dim value As System.Boolean

value = instance.MakeInfinite()
```

C#

```
System.bool MakeInfinite()
```

C++/CLI

```
System.bool MakeInfinite();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the line is changed to infinite, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchLine::MakeInfinite](#).

Example

[Make Line Infinite \(VBA\)](#)

Remarks

When you change a line from finite to infinite, you cannot change it back to finite.

See Also

[ISketchLine Interface](#)
[ISketchLine Members](#)
[ISketchLine::Infinite Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0