

SOLIDWORKS API (.NET, VBA, C#) — Reference (275/337): ISketchPatternFeatureData- ISketchPicture

SOLIDWORKS API Documentation (converted from CHM)

ISketchPatternFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPatternFeatureData Interface

Allows access to a sketch-driven pattern feature in a part.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
```

C#

```
public interface ISketchPatternFeatureData
```

C++/CLI

```
public interface class ISketchPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData](#).

Example

[Get Properties of Sketch Pattern Feature \(VBA\)](#)
[Get Properties of Sketch Pattern Feature \(VB.NET\)](#)
[Get Properties of Sketch Pattern Feature \(C#\)](#)

Remarks

Read [Pattern Features and their Feature Data Objects](#).

Before calling `IFeatureManager::CreateDefinition`, you must use [IModelDocExtension::SelectByID2](#) to pre-select the entities needed to create the circular pattern feature.

To select the required entities, use these selection Marks:

- features = 4
- points = 32
- sketches = 64
- faces = 128
- bodies = 256

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create a sketch-driven pattern.

For more information, see the **Sketch Driven Patterns** topic in the SOLIDWORKS Help.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[SketchPatternFeatureData](#)

See Also

[ISketchPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPatternFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPatternFeatureData Interface

For a list of all members of this type, see [ISketchPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the sketch pattern feature.
 GetBasePoint	Gets the base point data from which this sketch pattern is created.
 GetPatternBodyCount	Gets the number of seed bodies in the sketch pattern feature.
 GetPatternFaceCount	Gets the number of patterned faces.
 GetPatternFeatureCount	Gets the number of seed features for this sketch pattern feature.
 GetReferencePointType	Gets the type of reference point for this sketch pattern feature.
 GetTransform	Gets the transform for the specified instance of this sketch pattern feature.
 IAccessSelections	Obsolete. Superseded by ISketchPatternFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to selections used to define the sketch pattern feature.
 IGetBasePoint	Gets the base point data from which this sketch pattern is created.
 IGetPatternBodyArray	Gets the seed bodies for the sketch pattern feature.
 IGetPatternFaceArray	Gets the patterned faces for the sketch pattern feature.
 IGetPatternFeatureArray	Gets the seed features for the sketch pattern.
 ISetPatternBodyArray	Sets the seed bodies for the sketch pattern feature.
 ISetPatternFaceArray	Sets the patterned faces for the sketch pattern feature.
 ISetPatternFeatureArray	Sets the seed features for the sketch pattern feature.
 ReleaseSelectionAccess	Releases access to the selections that created this sketch pattern feature.
 SetFeatureScope	Sets the feature scope, whether to autoselect the affected bodies, and the affected bodies in this sketch pattern feature.

[Top](#)

See Also

[ISketchPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPatternFeatureData Interface

The following tables list the members exposed by [ISketchPatternFeatureData](#).

Public Properties

Name	Description
 AutoSelect	Gets whether to automatically select all bodies in a multibody part intersected by this sketch-driven pattern feature.
 BodyPattern	Gets or sets whether to base this sketch pattern feature on bodies or features and faces.
 FeatureScope	Gets which bodies in this multibody part are affected by this sketch-driven pattern feature.
 FeatureScopeBodies	Gets the bodies in this multibody part to be affected by this sketch-driven pattern feature.

 GeometryPattern	Gets or sets whether to create the pattern using only the geometry (faces and edges) of the feature.
 PatternBodyArray	Gets and sets the bodies to pattern for this sketch pattern feature.
 PatternElement	Gets or sets the type of entities to base this sketch pattern feature.
 PatternFaceArray	Gets or sets the patterned faces for the sketch pattern feature.
 PatternFeatureArray	Gets or sets the seed features for the sketch pattern feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (i.e., colors to all pattern instances).
 ReferencePoint	Gets or sets the reference point for this sketch pattern feature.
 Sketch	Gets or sets the sketch from which that this sketch pattern feature is created.
 UseCentroid	Gets or sets whether to use a centroid for this sketch pattern feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the sketch pattern feature.
 GetBasePoint	Gets the base point data from which this sketch pattern is created.
 GetPatternBodyCount	Gets the number of seed bodies in the sketch pattern feature.
 GetPatternFaceCount	Gets the number of patterned faces.
 GetPatternFeatureCount	Gets the number of seed features for this sketch pattern feature.
 GetReferencePointType	Gets the type of reference point for this sketch pattern feature.
 GetTransform	Gets the transform for the specified instance of this sketch pattern feature.
 IAccessSelections	Obsolete. Superseded by ISketchPatternFeatureData.IAccessSelections2.
 IAccessSelections2	Gains access to selections used to define the sketch pattern feature.
 IGetBasePoint	Gets the base point data from which this sketch pattern is created.
 IGetPatternBodyArray	Gets the seed bodies for the sketch pattern feature.
 IGetPatternFaceArray	Gets the patterned faces for the sketch pattern feature.
 IGetPatternFeatureArray	Gets the seed features for the sketch pattern.
 ISetPatternBodyArray	Sets the seed bodies for the sketch pattern feature.
 ISetPatternFaceArray	Sets the patterned faces for the sketch pattern feature.
 ISetPatternFeatureArray	Sets the seed features for the sketch pattern feature.
 ReleaseSelectionAccess	Releases access to the selections that created this sketch pattern feature.
 SetFeatureScope	Sets the feature scope, whether to autoselect the affected bodies, and the affected bodies in this sketch pattern feature.

[Top](#)

See Also

[ISketchPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchPatternFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [ISketchPatternFeatureData Interface](#)

For a list of all members of this type, see [ISketchPatternFeatureData members](#).

Public Properties

Name	Description
 AutoSelect	Gets whether to automatically select all bodies in a multibody part intersected by this sketch-driven pattern feature.

 BodyPattern	Gets or sets whether to base this sketch pattern feature on bodies or features and faces.
 FeatureScope	Gets which bodies in this multibody part are affected by this sketch-driven pattern feature.
 FeatureScopeBodies	Gets the bodies in this multibody part to be affected by this sketch-driven pattern feature.
 GeometryPattern	Gets or sets whether to create the pattern using only the geometry (faces and edges) of the feature.
 PatternBodyArray	Gets and sets the bodies to pattern for this sketch pattern feature.
 PatternElement	Gets or sets the type of entities to base this sketch pattern feature.
 PatternFaceArray	Gets or sets the patterned faces for the sketch pattern feature.
 PatternFeatureArray	Gets or sets the seed features for the sketch pattern feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (i.e., colors to all pattern instances).
 ReferencePoint	Gets or sets the reference point for this sketch pattern feature.
 Sketch	Gets or sets the sketch from which that this sketch pattern feature is created.
 UseCentroid	Gets or sets whether to use a centroid for this sketch pattern feature.

[Top](#)

See Also

[ISketchPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : AccessSelections Method (ISketchPatternFeatureData)

Gains access to selections used to define the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::AccessSelections](#).

 Example

See the [ISketchPatternFeatureData](#) examples.

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISketchPatternFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::IAccessSelections2 Method](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

AutoSelect Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : AutoSelect Property (ISketchPatternFeatureData)

Gets whether to automatically select all bodies in a multibody part intersected by this sketch-driven pattern feature.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property AutoSelect As System.Boolean

Visual Basic (Usage)

```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Boolean  
  
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();  
}
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies intersected by this sketch-driven pattern feature, false to specify affected bodies (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::AutoSelect](#).

Remarks

This property is valid only if [ISketchPatternFeatureData::GeometryPattern](#) is true.

Call [ISketchPatternFeatureData::SetFeatureScope](#) to set this property.

For more information, see the **Sketch Driven Patterns PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BodyPattern Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : BodyPattern Property (ISketchPatternFeatureData)

Gets or sets whether to base this sketch pattern feature on bodies or features and faces.

.NET Syntax

Visual Basic (Declaration)

Property BodyPattern As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Boolean
```

```
instance.BodyPattern = value
```

```
value = instance.BodyPattern
```

C#

```
System.bool BodyPattern {get; set;}
```

C++/CLI

```
property System.bool BodyPattern {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for bodies, false for features and faces

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::BodyPattern](#).

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::PatternElement Property \(\)](#)
[ISketchPatternFeatureData::PatternBodyArray Property \(\)](#)
[ISketchPatternFeatureData::PatternFaceArray Property \(\)](#)
[ISketchPatternFeatureData::PatternFeatureArray Property \(\)](#)
[ISketchPatternFeatureData::IGetPatternBodyArray Method \(\)](#)
[ISketchPatternFeatureData::IGetPatternFaceArray Method \(\)](#)
[ISketchPatternFeatureData::IGetPatternFeatureArray Method \(\)](#)
[ISketchPatternFeatureData::ISetPatternBodyArray Method \(\)](#)
[ISketchPatternFeatureData::ISetPatternFaceArray Method \(\)](#)
[ISketchPatternFeatureData::ISetPatternFeatureArray Method \(\)](#)
[ISketchPatternFeatureData::GeometryPattern Property \(\)](#)

Availability

SOLIDWORKS 2015 SP4, Revision Number 23.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : FeatureScope Property (ISketchPatternFeatureData)

Gets which bodies in this multibody part are affected by this sketch-driven pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FeatureScope As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Boolean  
  
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to specify affected bodies, false to apply the pattern to all bodies every time the feature regenerates

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::FeatureScope](#).

Remarks

This property is valid only if [ISketchPatternFeatureData::GeometryPattern](#) is true.

Call [ISketchPatternFeatureData::SetFeatureScope](#) to set this property.

For more information, see the **Sketch Driven Patterns PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : FeatureScopeBodies Property (ISketchPatternFeatureData)

Gets the bodies in this multibody part to be affected by this sketch-driven pattern feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Object
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) to be affected

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::FeatureScopeBodies](#).

Remarks

This property is valid only if [ISketchPatternFeatureData::GeometryPattern](#) is true.

Call [ISketchPatternFeatureData::SetFeatureScope](#) to set this property.

For more information, see the **Sketch Driven Patterns PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GeometryPattern Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GeometryPattern Property (ISketchPatternFeatureData)

Gets or sets whether to create the pattern using only the geometry (faces and edges) of the feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property GeometryPattern As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Boolean

instance.GeometryPattern = value
value = instance.GeometryPattern
```

C#

```
System.bool GeometryPattern {get; set;}
```

C++/CLI

```
property System.bool GeometryPattern {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to create the pattern using only the geometry of the feature, false to pattern the entire feature

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GeometryPattern](#).

Example

See the [ISketchPatternFeatureData](#) examples.

Remarks

This property is valid only if [ISketchPatternFeatureData::BodyPattern](#) is false.

If this property is set to true, you can call [ISketchPatternFeatureData::SetFeatureScope](#).

For more information, see the **Sketch Driven Patterns** topic in the SOLIDWORKS Help.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBasePoint Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetBasePoint Method (ISketchPatternFeatureData)

Gets the base point data from which this sketch pattern is created.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetBasePoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Object
```

```
value = instance.GetBasePoint()
```

C#

```
System.object GetBasePoint()
```

C++/CLI

```
System.Object^ GetBasePoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles describing the x, y, and z values of the base point

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetBasePoint](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::IGetBasePoint Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPatternBodyCount Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetPatternBodyCount Method (ISketchPatternFeatureData)

Gets the number of seed bodies in the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternBodyCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetPatternBodyCount()
```

C#

```
System.int GetPatternBodyCount()
```

C++/CLI

```
System.int GetPatternBodyCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of seed bodies

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetPatternBodyCount](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::IGetPatternBodyArray Method](#)
[ISketchPatternFeatureData::PatternBodyArray Property](#)
[ISketchPatternFeatureData::ISetPatternBodyArray Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPatternFaceCount Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetPatternFaceCount Method (ISketchPatternFeatureData)

Gets the number of patterned faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetPatternFaceCount()
```

C#

```
System.int GetPatternFaceCount()
```

C++/CLI

```
System.int GetPatternFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of patterned faces

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetPatternFaceCount](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData:IGetPatternFaceArray Method](#)
[ISketchPatternFeatureData:ISetPatternFaceArray Method](#)
[ISketchPatternFeatureData:PatternFaceArray Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatternFeatureCount Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetPatternFeatureCount Method (ISketchPatternFeatureData)

Gets the number of seed features for this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetPatternFeatureCount()
```

C#

```
System.int GetPatternFeatureCount()
```

C++/CLI

```
System.int GetPatternFeatureCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of features used to create this pattern

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetPatternFeatureCount](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData:IGetPatternFeatureArray Method](#)
[ISketchPatternFeatureData:ISetPatternFeatureArray Method](#)
[ISketchPatternFeatureData:PatternFeatureArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReferencePointType Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetReferencePointType Method (ISketchPatternFeatureData)

Gets the type of reference point for this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencePointType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetReferencePointType()
```

C#

```
System.int GetReferencePointType()
```

C++/CLI

```
System.int GetReferencePointType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of reference point:

- -1 = centroid
- 0 = closed curve
- 1 = sketch point
- 2 = vertex

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetReferencePointType](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::ReferencePoint Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : GetTransform Method (ISketchPatternFeatureData)

Gets the transform for the specified instance of this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTransform( _  
    ByVal Instance As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim Instance As System.Integer  
Dim value As MathTransform  
  
value = instance.GetTransform(Instance)
```

C#

```
MathTransform GetTransform(  
    System.int Instance  
)
```

C++/CLI

```
MathTransform^ GetTransform(  
& System.int Instance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance

Index of one repeating element in this pattern (see **Remarks**)

Return Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::GetTransform](#).

Example

See the [ISketchPatternFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : IAccessSelections Method (ISketchPatternFeatureData)

Obsolete. Superseded by [ISketchPatternFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::IAccessSelections](#).

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : IAccessSelections2 Method (ISketchPatternFeatureData)

Gains access to selections used to define the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```



```
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISketchPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISketchPatternFeatureData Interface](#)

[ISketchPatternFeatureData Members](#)

[ISketchPatternFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBasePoint Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : IGetBasePoint Method (ISketchPatternFeatureData)

Gets the base point data from which this sketch pattern is created.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBasePoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Double

value = instance.IGetBasePoint()
```

C#

```
System.double IGetBasePoint()
```

C++/CLI

```
System.double IGetBasePoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles describing the x, y, and z coordinates of the base point
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::IGetBasePoint](#).

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetBasePoint Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPatternBodyArray Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : IGetPatternBodyArray Method (ISketchPatternFeatureData)

Gets the seed bodies for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternBodyArray() As Body2
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As Body2

value = instance.IGetPatternBodyArray()
```

C#

```
Body2 IGetPatternBodyArray()
```

C++/CLI

```
Body2^ IGetPatternBodyArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of seed [bodies](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternBodyCount Method](#)
[ISketchPatternFeatureData::ISetPatternBodyArray Method](#)
[ISketchPatternFeatureData::PatternBodyArray Property](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPatternFaceArray Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : IGetPatternFaceArray Method (ISketchPatternFeatureData)

Gets the patterned faces for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternFaceArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Object  
  
value = instance.IGetPatternFaceArray()
```

C#

```
System.object IGetPatternFaceArray()
```

C++/CLI

```
System.Object^ IGetPatternFaceArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of seed [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::PatternFaceArray Property](#)
[ISketchPatternFeatureData::ISetPatternFaceArray Method](#)
[ISketchPatternFeatureData::GetPatternFaceCount Method](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

IGetPatternFeatureArray Method (ISketchPatternFeatureData)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [ISketchPatternFeatureData Interface](#) : IGetPatternFeatureArray Method (ISketchPatternFeatureData)

Gets the seed features for the sketch pattern.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternFeatureArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Object

value = instance.IGetPatternFeatureArray()
```

C#

```
System.object IGetPatternFeatureArray()
```

C++/CLI

```
System.Object^ IGetPatternFeatureArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [seed features](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternFeatureCount Method \(\)](#)
[ISketchPatternFeatureData::ISetPatternFaceArray Method \(\)](#)
[ISketchPatternFeatureData::PatternFeatureArray Property \(\)](#)
[ISketchPatternFeatureData::BodyPattern Property \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

ISetPatternBodyArray Method (ISketchPatternFeatureData)

[See Also](#)SolidWorks.Interop.sldworks Namespace > [ISketchPatternFeatureData Interface](#) : ISetPatternBodyArray Method (ISketchPatternFeatureData)

Sets the seed bodies for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPatternBodyArray( _
    ByVal BodyCount As System.Integer, _
```

```
ByRef ArrayDataIn As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim BodyCount As System.Integer  
Dim ArrayDataIn As Body2  
  
instance.ISetPatternBodyArray(BodyCount, ArrayDataIn)
```

C#

```
void ISetPatternBodyArray(  
    System.int BodyCount,  
    ref Body2 ArrayDataIn  
)
```

C++/CLI

```
void ISetPatternBodyArray(  
& System.int BodyCount,  
& Body2^% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyCount

Number of seed bodies

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of seed [bodies](#) of size BodyCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternBodyCount Method](#)
[ISketchPatternFeatureData::IGetPatternBodyArray Method](#)
[ISketchPatternFeatureData::PatternBodyArray Property](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPatternFaceArray Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : ISetPatternFaceArray Method (ISketchPatternFeatureData)

Sets the patterned faces for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPatternFaceArray( _  
    ByVal FaceCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim FaceCount As System.Integer
Dim ArrayDataIn As System.Object

instance.ISetPatternFaceArray(FaceCount, ArrayDataIn)
```

C#

```
void ISetPatternFaceArray(
    System.int FaceCount,
    ref System.object ArrayDataIn
)
```

C++/CLI

```
void ISetPatternFaceArray(
    & System.int FaceCount,
    & System.Object^% ArrayDataIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size FaceCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternFaceCount Method](#)
[ISketchPatternFeatureData::IGetPatternFaceArray Method](#)
[ISketchPatternFeatureData::PatternFaceArray Property](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPatternFeatureArray Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : ISetPatternFeatureArray Method (ISketchPatternFeatureData)

Sets the seed features for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPatternFeatureArray( _
    ByVal FeatCount As System.Integer, _
    ByRef ArrayDataIn As System.Object _
)
```

Visual Basic (Usage)

```
Dim instance As ISketchPatternFeatureData
Dim FeatCount As System.Integer
Dim ArrayDataIn As System.Object
```



```
instance.ISetPatternFeatureArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetPatternFeatureArray(  
    System.int FeatCount,  
    ref System.object ArrayDataIn  
)
```

C++/CLI

```
void ISetPatternFeatureArray(  
& System.int FeatCount,  
& System.Object^% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of seed features used to create this sketch pattern feature

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of seed [features](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternFeatureCount Method](#)
[ISketchPatternFeatureData::IGetPatternFeatureArray Method](#)
[ISketchPatternFeatureData::PatternFeatureArray Property](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternBodyArray Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : PatternBodyArray Property (ISketchPatternFeatureData)

Gets and sets the bodies to pattern for this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternBodyArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Object
```

```
instance.PatternBodyArray = value
```

```
value = instance.PatternBodyArray
```

C#

```
System.object PatternBodyArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternBodyArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of bodies to pattern

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::PatternBodyArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternBodyCount Method](#)
[ISketchPatternFeatureData::!GetPatternBodyArray Method](#)
[ISketchPatternFeatureData::!SetPatternBodyArray Method](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternElement Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : PatternElement Property (ISketchPatternFeatureData)

Gets or sets the type of entities to base this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternElement As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Integer
```

```
instance.PatternElement = value
```

```
value = instance.PatternElement
```

C#

```
System.int PatternElement {get; set;}
```

C++/CLI

```
property System.int PatternElement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of entities to base this sketch pattern feature as defined in [swPatternElementSelection_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::PatternElement](#).

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::BodyPattern Property_0](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternFaceArray Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : PatternFaceArray Property (ISketchPatternFeatureData)

Gets or sets the patterned faces for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property PatternFaceArray As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Object
```

```
instance.PatternFaceArray = value
```

```
value = instance.PatternFaceArray
```

C#

```
System.object PatternFaceArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternFaceArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of faces

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::PatternFaceArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternFaceCount Method](#)
[ISketchPatternFeatureData::GetPatternFaceArray Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternFeatureArray Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : PatternFeatureArray Property (ISketchPatternFeatureData)

Gets or sets the seed features for the sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property PatternFeatureArray As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Object
```

```
instance.PatternFeatureArray = value
```

```
value = instance.PatternFeatureArray
```

C#

```
System.object PatternFeatureArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternFeatureArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of features

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::PatternFeatureArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::GetPatternFeatureCount Method](#)
[ISketchPatternFeatureData::IGetPatternFeatureArray Method](#)
[ISketchPatternFeatureData::ISetPatternFeatureArray Method](#)
[ISketchPatternFeatureData::BodyPattern Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateVisualProperty Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : PropagateVisualProperty Property (ISketchPatternFeatureData)

Gets or sets whether to propagate visual properties (i.e., colors to all pattern instances).

.NET Syntax

Visual Basic (Declaration)

Property PropagateVisualProperty As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Boolean
```

```
instance.PropagateVisualProperty = value
value = instance.PropagateVisualProperty
```

C#

```
System.bool PropagateVisualProperty {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperty {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate visual properties, false to not

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::PropagateVisualProperty](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferencePoint Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : ReferencePoint Property (ISketchPatternFeatureData)

Gets or sets the reference point for this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ReferencePoint As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
Dim value As System.Object

instance.ReferencePoint = value
value = instance.ReferencePoint
```

C#

```
System.Object ReferencePoint {get; set;}
```

C++/CLI

```
property System.Object^ ReferencePoint {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference point for this sketch pattern feature

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::ReferencePoint](#).

Remarks

This property is valid only if [ISketchPatternFeatureData::GetReferencePointType](#) does not return -1.

Before calling this property, call [ISketchPatternFeatureData::AccessSelections](#) or [ISketchPatternFeatureData::IAccessSelections2](#) to access the reference point.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (ISketchPatternFeatureData)

Releases access to the selections that created this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISketchPatternFeatureData](#) examples.

Remarks

[ISketchPatternFeatureData::AccessSelections](#) and [ISketchPatternFeatureData::IAccessSelections2](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFeatureScope Method (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : SetFeatureScope Method (ISketchPatternFeatureData)

Sets the feature scope, whether to autoselect the affected bodies, and the affected bodies in this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFeatureScope( _  
    ByVal FeatureScopeOption As System.Boolean, _  
    ByVal AutoSelectBodies As System.Boolean, _  
    ByVal Bodies As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISketchPatternFeatureData  
Dim FeatureScopeOption As System.Boolean  
Dim AutoSelectBodies As System.Boolean  
Dim Bodies As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetFeatureScope(FeatureScopeOption, AutoSelectBodies, Bodies)
```

C#

```
System.bool SetFeatureScope(  
    System.bool FeatureScopeOption,  
    System.bool AutoSelectBodies,  
    System.object Bodies  
)
```

C++/CLI



```
System.bool SetFeatureScope(  
& System.bool FeatureScopeOption,  
& System.bool AutoSelectBodies,  
& System.Object^ Bodies  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatureScopeOption

True to specify affected bodies, false to apply the pattern to all bodies every time the feature regenerates (see **Remarks**)

AutoSelectBodies

True to automatically select all bodies intersected by this pattern feature, false to specify affected bodies (see **Remarks**)

Bodies

Array of [bodies](#) to be affected; valid only if FeatureScopeOption is true and AutoSelectBodies is false

Return Value

True if feature scope set successfully, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::SetFeatureScope](#).

Remarks

If this method returns false, then default values for FeatureScopeOption and AutoSelectBodies are set. A subsequent call to [IFeatureManager::CreateFeature](#) creates the feature with a FeatureScopeOption of true and an AutoSelectBodies of true.

After calling IFeature::ModifyDefinition, call [IFeature::GetErrorCode2](#) to determine what's wrong and then take necessary remedial action.

For more information, see the **Sketch Driven Patterns PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See Also

[ISketchPatternFeatureData Interface](#)

[ISketchPatternFeatureData Members](#)

[ISketchPatternFeatureData::AutoSelect Property \(\)](#)

[ISketchPatternFeatureData::FeatureScope Property \(\)](#)

[ISketchPatternFeatureData::FeatureScopeBodies Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Sketch Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : Sketch Property (ISketchPatternFeatureData)

Gets or sets the sketch from which that this sketch pattern feature is created.

.NET Syntax

Visual Basic (Declaration)

```
Property Sketch As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData
```

```
Dim value As System.Object
```

```
instance.Sketch = value
```

```
value = instance.Sketch
```

C#

```
System.Object Sketch {get; set;}
```

C++/CLI

```
property System.Object^ Sketch {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sketch](#) for this pattern

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::Sketch](#).

Example

See the [ISketchPatternFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseCentroid Property (ISketchPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPatternFeatureData Interface](#) : UseCentroid Property (ISketchPatternFeatureData)

Gets or sets whether to use a centroid for this sketch pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseCentroid As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPatternFeatureData  
Dim value As System.Boolean
```

```
instance.UseCentroid = value
```

```
value = instance.UseCentroid
```

C#

```
System.bool UseCentroid {get; set;}
```

C++/CLI

```
property System.bool UseCentroid {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to a centroid, false to use a reference point

Visual Basic for Applications (VBA) Syntax

See [SketchPatternFeatureData::UseCentroid](#).

Example

See the [ISketchPatternFeatureData](#) examples.

See Also

[ISketchPatternFeatureData Interface](#)
[ISketchPatternFeatureData Members](#)
[ISketchPatternFeatureData::ReferencePoint Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

ISketchPicture (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPicture Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPicture Interface

Provides access to pictures on sketches (i.e., .bmp, .gif, .jpg, .jpeg, .tif, and .wmf).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchPicture
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture
```

C#

```
public interface ISketchPicture
```

C++/CLI

```
public interface class ISketchPicture
```

Visual Basic for Applications (VBA) Syntax

See [SketchPicture](#).

Example

[Flip Sketch Picture \(VBA\)](#)
[Flip Sketch Picture \(VB.NET\)](#)
[Flip Sketch Picture \(C#\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)
[ISketch::GetSketchPictures](#) and [ISketch::!GetSketchPictures](#)
[ISketchManager::InsertSketchPicture](#)
[IView::GetSketchPictures](#) and [IView::!GetSketchPictures](#)

Access Diagram

[SketchPicture](#)

See Also

[ISketchPicture Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPicture Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPicture Interface

For a list of all members of this type, see [ISketchPicture members](#).

Public Methods

Name	Description
 Flip	Flips the picture, in its same position, either side to side or top to bottom.
 GetFeature	Gets the feature associated with this sketch picture.
 GetOrigin	Gets the origin of the picture on the sketch.
 GetPixelmap	Gets the picture pixels.
 GetPixelmapSize	Gets the size of the array for the picture pixels.
 GetPointOnSketchFromPixel	Gets the sketch coordinate for the specified pixel.
 GetSize	Gets the size of the picture on the sketch.
 GetTransparency	Gets transparency parameters for this picture.
 IGetPixelmap	Gets the picture pixels.
 SetOrigin	Sets the origin of the picture of the sketch.
 SetSize	Sets the size of the picture on the sketch.
 SetTransparency	Sets the transparency parameters of this picture on the sketch.

[Top](#)

 See Also

[ISketchPicture Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPicture Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPicture Interface

The following tables list the members exposed by [ISketchPicture](#).

 Public Properties

Name	Description
 Angle	Gets or sets the rotation angle of the picture in the sketch.
 Flipped	Gets whether the picture has been flipped in the sketch.

[Top](#)

 Public Methods

Name	Description
 Flip	Flips the picture, in its same position, either side to side or top to bottom.
 GetFeature	Gets the feature associated with this sketch picture.
 GetOrigin	Gets the origin of the picture on the sketch.
 GetPixelmap	Gets the picture pixels.
 GetPixelmapSize	Gets the size of the array for the picture pixels.
 GetPointOnSketchFromPixel	Gets the sketch coordinate for the specified pixel.
 GetSize	Gets the size of the picture on the sketch.
 GetTransparency	Gets transparency parameters for this picture.
 IGetPixelmap	Gets the picture pixels.
 SetOrigin	Sets the origin of the picture of the sketch.
 SetSize	Sets the size of the picture on the sketch.
 SetTransparency	Sets the transparency parameters of this picture on the sketch.

[Top](#)

See Also

[ISketchPicture Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchPicture Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPicture Interface

For a list of all members of this type, see [ISketchPicture members](#).

Public Properties

Name	Description
 Angle	Gets or sets the rotation angle of the picture in the sketch.
 Flipped	Gets whether the picture has been flipped in the sketch.

[Top](#)

See Also

[ISketchPicture Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : Angle Property (ISketchPicture)

Gets or sets the rotation angle of the picture in the sketch.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rotation angle in radians of the picture; counter-clockwise from the positive X

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::Angle](#).

Example

See the [ISketchPicture](#) examples.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Flip Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : Flip Method (ISketchPicture)

Flips the picture, in its same position, either side to side or top to bottom.

.NET Syntax

Visual Basic (Declaration)

```
Function Flip(  
    ByVal SideToSide As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim SideToSide As System.Boolean  
Dim value As System.Boolean  
  
value = instance.Flip(SideToSide)
```

C#

```
System.bool Flip(  
    System.bool SideToSide  
)
```

C++/CLI

```
System.bool Flip(  
& System.bool SideToSide  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SideToSide

True to flip the picture side to side, false to flip the picture top to bottom (see **Remarks**)

Return Value

True if the picture is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::Flip](#).

Example

See the [ISketchPicture](#) examples.

Remarks

If you flip the picture...

side to side

top to bottom

side to side and top to bottom

Then the [angle](#)...

remains the same and the [ISketchPicture::Flipped](#) property returns true.

increments by 180 and the ISketchPicture::Flipped property returns true.

rotates 180 and ISketchPicture::Flipped returns false.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Flipped Property (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : Flipped Property (ISketchPicture)

Gets whether the picture has been flipped in the sketch.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Flipped As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim value As System.Boolean
```

```
value = instance.Flipped
```

C#

```
System.bool Flipped {get;}
```

C++/CLI

```
property System.bool Flipped {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the picture has been flipped either side to side or top to bottom, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::Flipped](#).

Example

See the [ISketchPicture](#) examples.

Remarks

When a picture has not been flipped, as when you initially insert it, the bottom of the picture is defined by starting at the origin and proceeding in the direction of the [angle](#). If a picture has been flipped, then the bottom of the picture is defined by starting at the origin and proceeding in a

direction opposite the angle. In other words, the picture is mirrored or reflected, but not duplicated.

If a picture has been [flipped](#) both side to side and top to bottom, then this property returns false.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetOrigin Method](#)
[ISketchPicture::SetOrigin Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetFeature Method (ISketchPicture)

Gets the feature associated with this sketch picture.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim value As Feature
```

```
value = instance.GetFeature()
```

C#

Feature GetFeature()

C++/CLI

Feature^ GetFeature();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetFeature](#).

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOrigin Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetOrigin Method (ISketchPicture)

Gets the origin of the picture on the sketch.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetOrigin( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim X As System.Double  
Dim Y As System.Double  
  
instance.GetOrigin(X, Y)
```

C#

```
void GetOrigin(  
    out System.double X,  
    out System.double Y  
)
```

C++/CLI

```
void GetOrigin(  
& [Out] System.double X,  
& [Out] System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate
Y
y coordinate

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetOrigin](#).

Remarks

The coordinates in meters indicate the position of the lower-left corner of the picture in sketch space.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::SetOrigin Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPixelmap Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetPixelmap Method (ISketchPicture)

Gets the picture pixels.

.NET Syntax

Visual Basic (Declaration)

Function GetPixelmap() As System.Object

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim value As System.Object
```

```
value = instance.GetPixelmap()
```

C#

```
System.object GetPixelmap()
```

C++/CLI

```
System.Object^ GetPixelmap();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array containing groups of three or four values (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetPixelmap](#).

Remarks

The array contains groups of three, the Red, Green, Blue (RGB) components of pixel color, and optionally a fourth value that indicates the transparency of the pixel, which can be a value from 0 (transparent) to 255 (opaque).

To determine the format of the data, you need the information returned by [ISketchPicture::GetPixelmapSize](#):

Number of items per pixel = size / (rows * columns)

Each group of three or four goes across each pixel in a row of the bitmap. The next row follows in the array.

This raw data does not include translation, scaling, rotation, and flipping. SOLIDWORKS Design applies these properties to the raw bitmap data to draw it in the sketch.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::IGetPixelmap Method](#)
[ISketchPicture::GetPointOnSketchFromPixel Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPixelmapSize Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetPixelmapSize Method (ISketchPicture)

Gets the size of the array for the picture pixels.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPixelmapSize(  
    ByRef Width As System.Integer, _  
    ByRef Height As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)


```
Dim instance As ISketchPicture
Dim Width As System.Integer
Dim Height As System.Integer
Dim value As System.Integer

value = instance.GetPixelmapSize(Width, Height)
```

C#

```
System.int GetPixelmapSize(
    out System.int Width,
    out System.int Height
)
```

C++/CLI

```
System.int GetPixelmapSize(
& [Out] System.int Width,
& [Out] System.int Height
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Width
Number of columns in the pixel map
Height
Number of rows in the pixel map

Return Value

Size of the array of the picture pixels

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetPixelmapSize](#).

Remarks

Call this method before calling [ISketchPicture::IGetPixelmap](#) to get the size of the array for that method.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetPixelmap Method](#)
[ISketchPicture::GetPointOnSketchFromPixel Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPointOnSketchFromPixel Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetPointOnSketchFromPixel Method (ISketchPicture)

Gets the sketch coordinate for the specified pixel.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPointOnSketchFromPixel( _
    ByVal Row As System.Integer, _
    ByVal Column As System.Integer _
) As MathPoint
```

```
Dim instance As ISketchPicture
Dim Row As System.Integer
Dim Column As System.Integer
Dim value As MathPoint

value = instance.GetPointOnSketchFromPixel(Row, Column)
```

C#

```
MathPoint GetPointOnSketchFromPixel(
    System.int Row,
    System.int Column
)
```

C++/CLI

```
MathPoint^ GetPointOnSketchFromPixel(
    & System.int Row,
    & System.int Column
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
Row for this pixel
Column
Column for this pixel

Return Value

[Point](#) in the sketch space

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetPointOnSketchFromPixel](#).

Remarks

This method gets a point in the sketch space for the specified 0-based row and column indices from the pixel map. Because the bitmap data is raw data, this method helps determine where a point on the sketch is for the pixel after all of the transformation information has been applied. This method helps connect the raw data to its sketch.

See [ISketchPicture::GetPixelmap](#) or [ISketchPicture::IGetPixelmap](#) for more information about the pixel map.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetPixelmapSize Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSize Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetSize Method (ISketchPicture)

Gets the size of the picture on the sketch.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetSize( _
    ByRef Width As System.Double, _
    ByRef Height As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture
Dim Width As System.Double
Dim Height As System.Double

instance.GetSize(Width, Height)
```

C#

```
void GetSize(
    out System.double Width,
    out System.double Height
)
```

C++/CLI

```
void GetSize(
    & [Out] System.double Width,
    & [Out] System.double Height
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Width
Width of the picture in meters
Height
Height of the picture in meters

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetSize](#).

Example

See the [ISketchPicture](#) examples.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::SetSize Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTransparency Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : GetTransparency Method (ISketchPicture)

Gets transparency parameters for this picture.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetTransparency( _
    ByRef Style As System.Integer, _
    ByRef Transparency As System.Double, _
```

```
ByRef MatchingColor As System.Integer, _
ByRef MatchingTolerance As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture
Dim Style As System.Integer
Dim Transparency As System.Double
Dim MatchingColor As System.Integer
Dim MatchingTolerance As System.Double

instance.GetTransparency(Style, Transparency, MatchingColor, MatchingTolerance)
```

C#

```
void GetTransparency(
    out System.int Style,
    out System.double Transparency,
    out System.int MatchingColor,
    out System.double MatchingTolerance
)
```

C++/CLI

```
void GetTransparency(
    & [Out] System.int Style,
    & [Out] System.double Transparency,
    & [Out] System.int MatchingColor,
    & [Out] System.double MatchingTolerance
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style as defined by [swSketchPictureTransparencyStyle_e](#)

Transparency

- 0 = opaque
- 1 = transparent

describing the relative transparency depending on the value of Style

MatchingColor

RGB color used as the transparent color when Style is swSketchPictureTransparencyUserDefined

MatchingTolerance

- 0 = exact match
- 1 = less exact match

indicating how closely MatchingColor must be to be considered a transparent color when Style is swSketchPictureTransparencyUserDefined

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::GetTransparency](#).

See Also

[ISketchPicture Interface](#)

[ISketchPicture Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPixelmap Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : IGetPixelmap Method (ISketchPicture)

Gets the picture pixels.

.NET Syntax

```
Function IGetPixelmap( _
    ByVal Count As System.Integer _
) As System.Short
```



```
Dim instance As ISketchPicture
Dim Count As System.Integer
Dim value As System.Short

value = instance.IGetPixelmap(Count)
```

```
System.short IGetPixelmap(
    System.int Count
)
```

```
System.short IGetPixelmap(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of the array

Return Value

- in-process, unmanaged C++: Pointer to an array containing groups of 3 or 4 values (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The array contains groups of three, the Red, Green, Blue (RGB) components of pixel color, and optionally, a fourth value that indicates the transparency of the pixel, which can be a value from 0 (transparent) to 255 (opaque).

Before calling this method, call [ISketchPicture::GetPixelmapSize](#) to get the value of Count.

To determine the format of the data, you need the information returned by [ISketchPicture::GetPixelmapSize](#):

Number of items per pixel = size / (rows * columns)

Each group of three or four goes across each pixel in a row of the bitmap. The next row follows in the array.

This raw data does not include translation, scaling, rotation, and flipping. SOLIDWORKS Design applies these properties to the raw bitmap data to draw it in the sketch.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetPixelmap Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SetOrigin Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : SetOrigin Method (ISketchPicture)

Sets the origin of the picture of the sketch.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetOrigin( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim X As System.Double  
Dim Y As System.Double  
Dim value As System.Boolean  
  
value = instance.SetOrigin(X, Y)
```

C#

```
System.bool SetOrigin(  
    System.double X,  
    System.double Y  
)
```

C++/CLI

```
System.bool SetOrigin(  
& System.double X,  
& System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate
Y
y coordinate

Return Value

True if the origin is set, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::SetOrigin](#).

Remarks

The coordinates in meters indicate the position of the lower-left corner of the picture in sketch space.

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetOrigin Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSize Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : SetSize Method (ISketchPicture)

Sets the size of the picture on the sketch.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetSize( _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double, _  
    ByVal AspectRatioLocked As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim Width As System.Double  
Dim Height As System.Double  
Dim AspectRatioLocked As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetSize(Width, Height, AspectRatioLocked)
```

C#

```
System.bool SetSize(  
    System.double Width,  
    System.double Height,  
    System.bool AspectRatioLocked  
)
```

C++/CLI

```
System.bool SetSize(  
& System.double Width,  
& System.double Height,  
& System.bool AspectRatioLocked  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Width

Width of the picture in meters

Height

Height of the picture in meters

AspectRatioLocked

True to keep a fixed width and height aspect ratio, false to not

Return Value

True if the size of the picture is set, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::SetSize](#).

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetSize Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTransparency Method (ISketchPicture)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPicture Interface](#) : SetTransparency Method (ISketchPicture)

Sets the transparency parameters of this picture on the sketch.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTransparency( _  
    ByVal Style As System.Integer, _  
    ByVal Transparency As System.Double, _  
    ByVal MatchingColor As System.Integer, _  
    ByVal MatchingTolerance As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPicture  
Dim Style As System.Integer  
Dim Transparency As System.Double  
Dim MatchingColor As System.Integer  
Dim MatchingTolerance As System.Double  
Dim value As System.Boolean  
  
value = instance.SetTransparency(Style, Transparency, MatchingColor, MatchingTolerance)
```

C#

```
System.bool SetTransparency(  
    System.int Style,  
    System.double Transparency,  
    System.int MatchingColor,  
    System.double MatchingTolerance  
)
```

C++/CLI

```
System.bool SetTransparency(  
& System.int Style,  
& System.double Transparency,  
& System.int MatchingColor,  
& System.double MatchingTolerance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style as defined by [swSketchPictureTransparencyStyle_e](#)

Transparency

- 0 = opaque
- 1 = transparent

describing the relative transparency depending on the value of Style

MatchingColor

RGB color used as the transparent color when Style is swSketchPictureTransparencyUserDefined

MatchingTolerance

- 0 = exact match
- 1 = less exact match

indicating how closely MatchingColor must be to be considered a transparent color when Style is swSketchPictureTransparencyUserDefined

Return Value

True if transparency is set, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPicture::SetTransparency](#).

See Also

[ISketchPicture Interface](#)
[ISketchPicture Members](#)
[ISketchPicture::GetOrigin Method](#)

