

SOLIDWORKS API (.NET, VBA, C#) — Reference (283/337): ISldWorks (part 3 of 8)

SOLIDWORKS API Documentation (converted from CHM)

ISldWorks (part 3 of 8) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ExportHoleWizardItem Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ExportHoleWizardItem Method (ISldWorks)

Exports data for the specified Hole Wizard standard.

.NET Syntax

Visual Basic (Declaration)

```
Function ExportHoleWizardItem(  
    ByVal StdToExport As System.String, _  
    ByVal DestinationFolderPath As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim StdToExport As System.String  
Dim DestinationFolderPath As System.String  
Dim value As System.Integer  
  
value = instance.ExportHoleWizardItem(StdToExport, DestinationFolderPath)
```

C#

```
System.int ExportHoleWizardItem(  
    System.string StdToExport,  
    System.string DestinationFolderPath  
)
```

C++/CLI

```
System.int ExportHoleWizardItem(  
& System.String^ StdToExport,  
& System.String^ DestinationFolderPath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StdToExport

Standard to export (see **Remarks**)

DestinationFolderPath

Path where to export the data (see **Remarks**)

Return Value

0 if successful, 1 if errors

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ExportHoleWizardItem](#).

Example

'VBA Preconditions'

'Open a part.

'Ensure that c:\temp exists.

```
Dim swApp As SldWorks.SldWorks  
Dim SourceHWItem As String  
Dim DestinationFoldeName As String
```

```

Dim longstatus As Long
Option Explicit

Sub Main()

    Set swApp = Application.SldWorks

    SourceHWItem = "ansi inch\Counterbore Holes\Hex Bolt"

    DestinationFolderName = "C:\temp"

    longstatus = swApp.ExportHoleWizardItem(SourceHWItem, DestinationFolderName)

    Exit Sub

End Sub

```

Remarks

Specify StdToImport with the path and file name as shown on the Hole Wizard tab of the Toolbox, e.g., "**ansi inch\Counterbore Holes\Hex Bolt**".

Specify DestinationFolderPath with the path where to create the Excel Workbook (*.xlsx). The data is exported to a file whose name is formatted as follows:

standard_hole class_hole type.xlsx

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks.ImportHoleWizardItem Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ExportToolboxItem Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ExportToolboxItem Method (ISldWorks)

Exports data for the specified Toolbox standard.

.NET Syntax

Visual Basic (Declaration)

```

Function ExportToolboxItem( _
    ByVal StdToExport As System.String, _
    ByVal DestinationFolderPath As System.String _
) As System.Integer

```

Visual Basic (Usage)

```

Dim instance As ISldWorks
Dim StdToExport As System.String
Dim DestinationFolderPath As System.String
Dim value As System.Integer

value = instance.ExportToolboxItem(StdToExport, DestinationFolderPath)

```

C#

```

System.int ExportToolboxItem(
    System.string StdToExport,

```



```
        System.string DestinationFolderPath  
    )
```

C++/CLI

```
System.int ExportToolboxItem(  
& System.String^ StdToExport,  
& System.String^ DestinationFolderPath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StdToExport

Standard to export (see **Remarks**)

DestinationFolderPath

Path where to export the data (see **Remarks**)

Return Value

0 if successful, 1 if errors

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ExportToolboxItem](#).

Example

```
'VBA Preconditions'  
  
'Open a part.  
'Ensure that c:\temp exists.  
  
Dim swApp As SldWorks.SldWorks  
Dim SourceHWItem As String  
Dim DestinationFolderName As String  
Dim longstatus As Long  
  
Option Explicit  
  
Sub Main()  
  
    Set swApp = Application.SldWorks  
  
    SourceHWItem = "ansi inch\bolts and screws\hex head\heavy hex bolt_ai.sldprt"  
  
    DestinationFolderName = "C:\temp"  
  
    longstatus = swApp.ExportToolboxItem(SourceHWItem, DestinationFolderName)  
  
    Exit Sub  
  
End Sub
```

Remarks

Specify StdToImport with the path and file name beneath **C:\SOLIDWORKS Datalbrowser**, e.g., "ansi inch\bolts and screws\hex head\heavy hex bolt_ai.sldprt".

Specify DestinationFolderPath with the path where to export the Excel Workbook (*.xlsx). The data is exported to a file whose name is formatted as follows:

standard_hole class_hole type.xlsx

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::ImportToolboxItem Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Frame Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : Frame Method (ISldWorks)

Gets the SOLIDWORKS main frame.

.NET Syntax

Visual Basic (Declaration)

```
Function Frame() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Object  
  
value = instance.Frame()
```

C#

```
System.Object Frame()
```

C++/CLI

```
System.Object^ Frame();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[SOLIDWORKS main frame](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::Frame](#).

Example

[Switch Documents \(C#\)](#)
[Switch Documents \(VB.NET\)](#)
[Switch Documents \(VBA\)](#)
[Add Button to Context-sensitive Menu \(C#\)](#)
[Add Button to Context-sensitive Menu \(VB.NET\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameHeight Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : FrameHeight Property (ISldWorks)

Get or sets the height of the SOLIDWORKS window.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameHeight As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISldWorks
Dim value As System.Integer

instance.FrameHeight = value

value = instance.FrameHeight
```

C#

```
System.int FrameHeight {get; set;}
```

C++/CLI

```
property System.int FrameHeight {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of the SOLIDWORKS window in pixels

Visual Basic for Applications (VBA) Syntax

See [SldWorks::FrameHeight](#).

Example

Visual Basic for Applications (VBA)

```
Option Explicit
```

```
Dim swApp As SldWorks.SldWorks
```

```
Sub main()
```

```
Set swApp = Application.SldWorks
```

```
' Set the SOLIDWORKS window the specified height, width, state, and location
```

```
swApp.FrameHeight = 500
```

```
swApp.FrameLeft = 100
```

```
swApp.FrameState = swWindowNormal
```

```
swApp.FrameTop = 100
```

```
swApp.FrameWidth = 500
```

```
End Sub
```

Remarks

This property is valid only if [ISldWorks::FrameState](#) is [swWindowState_e.swWindowNormal](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::FrameLeft Property](#)
[ISldWorks::FrameTop Property](#)
[ISldWorks::FrameWidth Property](#)
[IModelView::FrameHeight Property](#)
[IModelView::FrameLeft Property](#)
[IModelView::FrameState Property](#)
[IModelView::FrameTop Property](#)
[IModelView::FrameWidth Property](#)

Availability

FrameLeft Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : FrameLeft Property (ISldWorks)

Gets or sets the left position of the SOLIDWORKS window.

.NET Syntax

Visual Basic (Declaration)

Property FrameLeft As System.Integer

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Integer

instance.FrameLeft = value

value = instance.FrameLeft
```

C#

```
System.int FrameLeft {get; set;}
```

C++/CLI

```
property System.int FrameLeft {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Left position of SOLIDWORKS window in pixels

Visual Basic for Applications (VBA) Syntax

See [SldWorks::FrameLeft](#).

Example

Visual Basic for Applications (VBA)

```
Option Explicit
```

```
Dim swApp As SldWorks.SldWorks
```

```
Sub main()
```

```
Set swApp = Application.SldWorks
```

```
' Set the SOLIDWORKS window the specified height, width, state, and location
```

```
swApp.FrameHeight = 500
```

```
swApp.FrameLeft = 100
```

```
swApp.FrameState = swWindowNormal
```

```
swApp.FrameTop = 100
```

```
swApp.FrameWidth = 500
```

```
End Sub
```

Remarks

This property is valid only if [ISldWorks::FrameState](#) is [swWindowState_e.swWindowNormal](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::FrameHeight Property](#)
[ISldWorks::FrameTop Property](#)
[ISldWorks::FrameWidth Property](#)
[FrameHeight Property](#)
[IModelView::FrameLeft Property](#)
[IModelView::FrameState Property](#)
[IModelView::FrameTop Property](#)
[IModelView::FrameWidth Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameState Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : FrameState Property (ISldWorks)

Gets or sets the window state (minimum, maximum, or normal) for the SOLIDWORKS window.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameState As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
instance.FrameState = value  
  
value = instance.FrameState
```

C#

```
System.int FrameState {get; set;}
```

C++/CLI

```
property System.int FrameState {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Window state as defined in [swWindowState_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::FrameState](#).

Example

Visual Basic for Applications (VBA)

```
Option Explicit
```

```
Dim swApp As SldWorks.SldWorks
```

```
Sub main()
```

```

Set swApp = Application.SldWorks
' Set the SOLIDWORKS window the specified height, width, state, and location
swApp.FrameHeight = 500
swApp.FrameLeft = 100
swApp.FrameState = swWindowNormal
swApp.FrameTop = 100
swApp.FrameWidth = 500

```

End Sub

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::FrameHeight Property](#)
[ISldWorks::FrameLeft Property](#)
[ISldWorks::FrameTop Property](#)
[ISldWorks::FrameWidth Property](#)
[IModelView::FrameHeight Property](#)
[IModelView::FrameLeft Property](#)
[IModelView::FrameState Property](#)
[IModelView::FrameTop Property](#)
[IModelView::FrameWidth Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameTop Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : FrameTop Property (ISldWorks)

Gets or sets the top position of the SOLIDWORKS window.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameTop As System.Integer
```

Visual Basic (Usage)

```

Dim instance As ISldWorks
Dim value As System.Integer

instance.FrameTop = value
value = instance.FrameTop

```

C#

```
System.int FrameTop {get; set;}
```

C++/CLI

```

property System.int FrameTop {
    System.int get();
    void set ( & System.int value);
}

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Top position of the SOLIDWORKS window in pixels

Visual Basic for Applications (VBA) Syntax

See [SldWorks::FrameTop](#).

Example

Visual Basic for Applications (VBA)

Option Explicit

```
Dim swApp As SldWorks.SldWorks
```

```
Sub main()
```

```
Set swApp = Application.SldWorks
```

```
' Set the SOLIDWORKS window the specified height, width, state, and location
```

```
swApp.FrameHeight = 500
```

```
swApp.FrameLeft = 100
```

```
swApp.FrameState = swWindowNormal
```

```
swApp.FrameTop = 100
```

```
swApp.FrameWidth = 500
```

```
End Sub
```

Remarks

This property is valid only if [ISldWorks::FrameState](#) is [swWindowState_e.swWindowNormal](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::FrameHeight Property](#)
[ISldWorks::FrameLeft Property](#)
[ISldWorks::FrameWidth Property](#)
[IModelView::FrameHeight Property](#)
[IModelView::FrameLeft Property](#)
[IModelView::FrameState Property](#)
[IModelView::FrameTop Property](#)
[IModelView::FrameWidth Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameWidth Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : FrameWidth Property (ISldWorks)

Gets or sets the width of the frame of the SOLIDWORKS window.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameWidth As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
instance.FrameWidth = value
```

```
value = instance.FrameWidth
```

C#

```
System.int FrameWidth {get; set;}
```

C++/CLI

```
property System.int FrameWidth {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width of the SOLIDWORKS window in pixels

Visual Basic for Applications (VBA) Syntax

See [SldWorks::FrameWidth](#).

Example

Visual Basic for Applications (VBA)

```
Option Explicit
```

```
Dim swApp As SldWorks.SldWorks
```

```
Sub main()
```

```
Set swApp = Application.SldWorks
```

```
' Set the SOLIDWORKS window the specified height, width, state, and location
```

```
swApp.FrameHeight = 500
```

```
swApp.FrameLeft = 100
```

```
swApp.FrameState = swWindowNormal
```

```
swApp.FrameTop = 100
```

```
swApp.FrameWidth = 500
```

```
End Sub
```

Remarks

This property is valid only if [ISldWorks::FrameState](#) is [swWindowState_e.swWindowNormal](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::FrameHeight Property](#)

[ISldWorks::FrameLeft Property](#)

[ISldWorks::FrameTop Property](#)

[IModelView::FrameHeight Property](#)

[IModelView::FrameLeft Property](#)

[IModelView::FrameState Property](#)

[IModelView::FrameTop Property](#)

[IModelView::FrameWidth Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : Get3DExperienceState Method (ISldWorks)

Gets the current state of [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get3DExperienceState() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
value = instance.Get3DExperienceState()
```

C#

```
System.int Get3DExperienceState()
```

C++/CLI

```
System.int Get3DExperienceState();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

State of SOLIDWORKS Design connected to the 3DEXPERIENCE platform as defined by [sw3DExperienceState_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::Get3DExperienceState](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2022 SP02, Revision Number 30.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetActiveConfigurationName Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetActiveConfigurationName Method (ISldWorks)

Gets the name of the active configuration in the specified SOLIDWORKS document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveConfigurationName( _  
    ByVal FilePathName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePathName As System.String  
Dim value As System.String  
  
value = instance.GetActiveConfigurationName(FilePathName)
```

C#

```
System.string GetActiveConfigurationName(  
    System.string FilePathName  
)
```

C++/CLI

```
System.String^ GetActiveConfigurationName(  
& System.String^ FilePathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePathName

Path for the SOLIDWORKS document

Return Value

Name of the active configuration

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetActiveConfigurationName](#).

Example

[Get Name of Active Configuration \(VBA\)](#)

Remarks

The SOLIDWORKS document does not need to be open. The configuration that was active when the SOLIDWORKS document was closed is returned. If the SOLIDWORKS document is open, then the name of the active configuration is returned.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetConfigurationCount Method](#)
[ISldWorks::GetConfigurationNames Method](#)
[ISldWorks::IGetConfigurationNames Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::GetConfigurationNames Method](#)
[IConfiguration::Name Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetActiveDisplayPane Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetActiveDisplayPane Method (ISldWorks)

Gets the active Display Pane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveDisplayPane() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer
```

```
value = instance.GetActiveDisplayPane()
```

C#

```
System.int GetActiveDisplayPane()
```

C++/CLI

```
System.int GetActiveDisplayPane();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Active display pane as defined by [swDisplayPaneIndex_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetActiveDisplayPane](#).

Example

[Create Task Pane View Add-in \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IModelDocExtension::IsDisplayPaneVisible Method \(\)](#)

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAddInObject Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetAddInObject Method (ISldWorks)

Gets an add-in object for the specified SOLIDWORKS add-in.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAddInObject( _  
    ByVal Clsid As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Clsid As System.String  
Dim value As System.Object  
  
value = instance.GetAddInObject(Clsid)
```

C#

```
System.object GetAddInObject(  
    System.string Clsid  
)
```

C++/CLI

```
System.Object^ GetAddInObject(  
& System.String^ Clsid  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Clsid

GUID or ProgID of the add-in as registered with SOLIDWORKS (see **Remarks**)

Return Value

Your add-in object

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetAddInObject](#).

Remarks

To specify Clsid with:

- a ProgID, read [Accessing SOLIDWORKS Add-in Objects](#).
- a GUID, use curly brackets as in "{GUID}", or the string is interpreted as a ProgID.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::LoadAddIn Method](#)
[ISldWorks::UnloadAddIn Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetApplySelectionFilter Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetApplySelectionFilter Method (ISldWorks)

Gets the current state of the selection filter.

.NET Syntax

Visual Basic (Declaration)

```
Function GetApplySelectionFilter() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Boolean  
  
value = instance.GetApplySelectionFilter()
```

C#

```
System.bool GetApplySelectionFilter()
```

C++/CLI

```
System.bool GetApplySelectionFilter();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selection filter is active, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetApplySelectionFilter](#).

Example

Remarks

If the selection filter is active, then the settings found in [ISldWorks::GetSelectionFilter](#) and [ISldWorks::GetSelectionFilters](#) or [ISldWorks::!GetSelectionFilters](#) apply.

Use...	To...
ISldWorks::SetApplySelectionFilter	Activate or deactivate the selection filter
ISldWorks::SetSelectionFilter and ISldWorks::SetSelectionFilters or ISldWorks::!SetSelectionFilters	Change the current filters in use

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::!GetSelectionFiltersCount Method](#)
[ISldWorks::SetApplySelectionFilter Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBatchUploadedFilesInfo Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetBatchUploadedFilesInfo Method (ISldWorks)

Gets the files uploaded to 3DEXPERIENCE during a batch process.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBatchUploadedFilesInfo( _  
    ByRef ProcessedFileNames As System.Object, _  
    ByRef NonProcessedFileNames As System.Object, _  
    ByRef FailedFileNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim ProcessedFileNames As System.Object  
Dim NonProcessedFileNames As System.Object  
Dim FailedFileNames As System.Object  
Dim value As System.Boolean  
  
value = instance.GetBatchUploadedFilesInfo(ProcessedFileNames, NonProcessedFileNames,  
FailedFileNames)
```

C#

```
System.bool GetBatchUploadedFilesInfo(  
    out System.object ProcessedFileNames,  
    out System.object NonProcessedFileNames,  
    out System.object FailedFileNames  
)
```

C++/CLI

```
System.bool GetBatchUploadedFilesInfo(
& [Out] System.Object^ ProcessedFileNames,
& [Out] System.Object^ NonProcessedFileNames,
& [Out] System.Object^ FailedFileNames
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProcessedFileNames
Array of processed file names
NonProcessedFileNames
Array of unprocessed file names
FailedFileNames
Array of file names that failed to upload

Return Value

True if retrieval successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::GetBatchUploadedFilesInfo](#).

Remarks

This method is valid only for [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

Before using this method, call [ISldWorks::RunBatchSaveProcess](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2022 SP03, Revision Number 30.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBuildNumbers Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetBuildNumbers Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::GetBuildNumbers2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub GetBuildNumbers( _
    ByRef BaseVersion As System.String, _
    ByRef CurrentVersion As System.String _
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim BaseVersion As System.String
Dim CurrentVersion As System.String

instance.GetBuildNumbers(BaseVersion, CurrentVersion)
```

C#

```
void GetBuildNumbers(
    out System.string BaseVersion,
```

```
        out System.string CurrentVersion
    )
```

C++/CLI

```
void GetBuildNumbers(
& [Out] System.String^ BaseVersion,
& [Out] System.String^ CurrentVersion
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BaseVersion
SOLIDWORKS major revision number
CurrentVersion
SOLIDWORKS build number

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetBuildNumbers](#).

Example

Visual Basic for Applications (VBA)

```
'-----
Option Explicit
Dim swApp as SldWorks.SldWorks
Dim BaseVersion as String
Dim CurrentVersion as String

Sub main()

Set swApp = Application.SldWorks
swApp.GetBuildNumbers BaseVersion, CurrentVersion
Debug.Print "SOLIDWORKS major revision number: " & BaseVersion
Debug.Print "SOLIDWORKS build number: " & CurrentVersion

End Sub
'-----
```

Output

SOLIDWORKS major revision number: SW2009_a1
SOLIDWORKS build number: d080407.062

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::VersionHistory Method](#)
[ISldWorks::IGetVersionHistoryCount Method](#)
[ISldWorks::VersionHistory Method](#)
[ISldWorks::RevisionNumber Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

GetBuildNumbers2 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetBuildNumbers2 Method (ISldWorks)

Gets the build, major revision, and hot fix numbers of the SOLIDWORKS Design application.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetBuildNumbers2( _  
    ByRef BaseVersion As System.String, _  
    ByRef CurrentVersion As System.String, _  
    ByRef HotFixes As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim BaseVersion As System.String  
Dim CurrentVersion As System.String  
Dim HotFixes As System.String  
  
instance.GetBuildNumbers2(BaseVersion, CurrentVersion, HotFixes)
```

C#

```
void GetBuildNumbers2(  
    out System.string BaseVersion,  
    out System.string CurrentVersion,  
    out System.string HotFixes  
)
```

C++/CLI

```
void GetBuildNumbers2(  
& [Out] System.String^ BaseVersion,  
& [Out] System.String^ CurrentVersion,  
& [Out] System.String^ HotFixes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BaseVersion
Major revision number
CurrentVersion
Build number
HotFixes
Hot fix numbers

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetBuildNumbers2](#).

Example

[Get Build Numbers \(VBA\)](#)
[Get Build Numbers \(VB.NET\)](#)
[Get Build Numbers \(C#\)](#)

Remarks

Example outputs:

SOLIDWORKS major revision number: SW2009_a1

SOLIDWORKS build number: d080407.062

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::VersionHistory Method](#)
[ISldWorks::IVersionHistory Method](#)
[ISldWorks::IGetVersionHistoryCount Method](#)
[ISldWorks::RevisionNumber Method](#)

Availability

SOLIDWORKS 2011 SP05, Revision Number 19.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetButtonPosition Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetButtonPosition Method (ISldWorks)

Gets the center coordinates of the specified SOLIDWORKS toolbar button.

.NET Syntax

Visual Basic (Declaration)

```
Function GetButtonPosition( _  
    ByVal PointAt As System.Integer, _  
    ByRef LocX As System.Integer, _  
    ByRef LocY As System.Integer _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim PointAt As System.Integer  
Dim LocX As System.Integer  
Dim LocY As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetButtonPosition(PointAt, LocX, LocY)
```

C#

```
System.bool GetButtonPosition(  
    System.int PointAt,  
    out System.int LocX,  
    out System.int LocY  
)
```

C++/CLI

```
System.bool GetButtonPosition(  
& System.int PointAt,  
& [Out] System.int LocX,  
& [Out] System.int LocY  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointAt

Command ID for SOLIDWORKS toolbar button as defined in [swCommands_e](#)

LocX

x coordinate of the center of the specified SOLIDWORKS toolbar button

LocY

y coordinate of the center of the specified SOLIDWORKS toolbar button

Return Value

True if method call is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetButtonPosition](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::AddToolBar5 Method \(\)](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCollisionDetectionManager Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCollisionDetectionManager Method (ISldWorks)

Gets the collision detection manager.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCollisionDetectionManager() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Object  
  
value = instance.GetCollisionDetectionManager()
```

C#

```
System.object GetCollisionDetectionManager()
```

C++/CLI

```
System.Object^ GetCollisionDetectionManager();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICollisionDetectionManager](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCollisionDetectionManager](#).

Example

See the ICollisionDetectionManager examples.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2019 FCS Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColorTable Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetColorTable Method (ISldWorks)

Gets a color table from the SOLIDWORKS Design application.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColorTable() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Object  
  
value = instance.GetColorTable()
```

C#

```
System.object GetColorTable()
```

C++/CLI

```
System.Object^ GetColorTable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Color table](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetColorTable](#).

Example

[Get COLORREF Values of Standard User-interface Elements \(C#\)](#)
[Get COLORREF Values of Standard User-interface Elements \(VB.NET\)](#)
[Get COLORREF Values of Standard User-interface Elements \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::IGetColorTable Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCommandID Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCommandID Method (ISldWorks)

Gets the SOLIDWORKS command ID for an instance of an add-in's control (e.g., an add-in's toolbar button).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCommandID( _  
    ByVal Clsid As System.String, _  
    ByVal UserCmdID As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Clsid As System.String  
Dim UserCmdID As System.Integer  
Dim value As System.Integer  
  
value = instance.GetCommandID(Clsid, UserCmdID)
```

C#

```
System.int GetCommandID(  
    System.string Clsid,  
    System.int UserCmdID  
)
```

C++/CLI

```
System.int GetCommandID(  
& System.String^ Clsid,  
& System.int UserCmdID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Clsid

Add-in's class ID

UserCmdID

User-defined command ID for the add-in's control (see **Remarks**)

Return Value

Actual runtime value that SOLIDWORKS assigned the add-in's control

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCommandID](#).

Remarks

UserCmdId is the same user-defined command ID specified when you created the add-in control using [ICommandGroup::AddCommandItem2](#). You need the SOLIDWORKS command ID if you want to do something like cause an add-in's toolbar button to flash when visible in SOLIDWORKS.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ICommandGroup::CommandID Property](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCommandManager Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCommandManager Method (ISldWorks)

Gets the CommandManager for the specified add-in.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCommandManager( _  
    ByVal Cookie As System.Integer _  
) As CommandManager
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Cookie As System.Integer  
Dim value As CommandManager  
  
value = instance.GetCommandManager(Cookie)
```

C#

```
CommandManager GetCommandManager(  
    System.int Cookie  
)
```

C++/CLI

```
CommandManager^ GetCommandManager(  
& System.int Cookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie
Cookie specified in [ISwAddin::ConnectToSW](#)

Return Value

[CommandManager](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCommandManager](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

See [CommandManager and CommandGroups](#) for details.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationCount Method (ISldWorks)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetConfigurationCount Method (ISldWorks)

Gets the number of configurations in the SOLIDWORKS document, whether the document is opened or closed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationCount(  
    ByVal FilePathName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePathName As System.String  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount(FilePathName)
```

C#

```
System.int GetConfigurationCount(  
    System.string FilePathName  
)
```

C++/CLI

```
System.int GetConfigurationCount(  
& System.String^ FilePathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePathName

Path and file name for the SOLIDWORKS document

Return Value

Number of configurations in SOLIDWORKS document

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetConfigurationCount](#).

Example

[Work With Configurations \(VBA\)](#)

Remarks

Call this method before calling [ISldWorks::IGetConfigurationNames](#) to get the size of the array for that method.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetConfigurationNames Method](#)
[ISldWorks::IGetConfigurationNames Method](#)
[ISldWorks::GetActiveConfigurationName Method](#)
[IConfiguration Interface](#)
[IConfigurationManager Interface](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationNames Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetConfigurationNames Method (ISldWorks)

Gets the names of the configuration in this SOLIDWORKS Design document, whether the document is opened or closed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationNames(  
    ByVal FilePathName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePathName As System.String  
Dim value As System.Object  
  
value = instance.GetConfigurationNames(FilePathName)
```

C#

```
System.Object GetConfigurationNames(  
    System.string FilePathName  
)
```

C++/CLI

```
System.Object^ GetConfigurationNames(  
& System.String^ FilePathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePathName

Path and file name for the SOLIDWORKS Design document

Return Value

Array of strings containing the names of the configurations in this SOLIDWORKS Design document

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetConfigurationNames](#).

Example

[Work With Configurations \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetActiveConfigurationName Method](#)
[ISldWorks::GetConfigurationCount Method](#)
[ISldWorks::IGetConfigurationNames Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IModelDoc2::IGetConfigurationNames Method](#)
[IConfiguration Interface](#)
[IConfigurationManager Interface](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentFileUser Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentFileUser Method (ISldWorks)

Gets the name of the user who has the the specified document open.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentFileUser( _  
    ByVal FilePathName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePathName As System.String  
Dim value As System.String  
  
value = instance.GetCurrentFileUser(FilePathName)
```

C#

```
System.string GetCurrentFileUser(  
    System.string FilePathName  
)
```

C++/CLI

```
System.String^ GetCurrentFileUser(  
& System.String^ FilePathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePathName
Full path and filename of the document

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCurrentFileUser](#).

Example

Visual Basic for Applications (VBA)

```
'-----  
Option Explicit  
  
Dim swApp As SldWorks.SldWorks  
  
Sub main()  
  
Set swApp = Application.SldWorks  
' Substitute your path and filename  
Debug.Print swApp.GetCurrentFileUser("C:\temp\b&r.sldprt")  
  
End Sub  
'-----
```

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentLanguage Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentLanguage Method (ISldWorks)

Gets the current language used by SOLIDWORKS Design.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentLanguage() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.String
```

```
value = instance.GetCurrentLanguage()
```

C#

```
System.string GetCurrentLanguage()
```

C++/CLI

```
System.String^ GetCurrentLanguage();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current language

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCurrentLanguage](#).

Example

[Get Language and Localized Menu Names \(VBA\)](#)

Remarks

Possible return values are:

- | | | |
|----------------------|------------|------------------------|
| . chinese | . german | . portuguese-brazilian |
| . chinese-simplified | . italian | . russian |
| . czech | . japanese | . spanish |
| . english | . korean | . turkish |
| . french | . polish | |

You can see the current language in use by the SOLIDWORKS Design application in the SOLIDWORKS Design resources (dialogs, menus, and so on).

You can use the return value to set your local resource usage.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentLicenseType Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentLicenseType Method (ISldWorks)

Gets the type of license for the current SOLIDWORKS Design session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentLicenseType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
value = instance.GetCurrentLicenseType()
```

C#

```
System.int GetCurrentLicenseType()
```

C++/CLI

```
System.int GetCurrentLicenseType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of SOLIDWORKS Design license as defined in [swLicenseType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCurrentLicenseType](#).

Example

[Get License Types of SOLIDWORKS \(C#\)](#)
[Get License Types of SOLIDWORKS \(VB.NET\)](#)
[Get License Types of SOLIDWORKS \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IModelDocExtension::GetLicenseType Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentMacroPathFolder Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentMacroPathFolder Method (ISldWorks)

Gets the name of the folder where the macro resides.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentMacroPathFolder() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.String  
  
value = instance.GetCurrentMacroPathFolder()
```

C#

```
System.string GetCurrentMacroPathFolder()
```

C++/CLI

```
System.String^ GetCurrentMacroPathFolder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the folder where the macro resides

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCurrentMacroPathFolder](#).

Example

[Save Solid Body to File \(C#\)](#)
[Save Solid Body to File \(VB.NET\)](#)
[Save Solid Body to File \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCurrentMacroPathName Method](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::GetMacroMethods Method](#)
[ISldWorks::RunMacro Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCurrentMacroPathName Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentMacroPathName Method (ISldWorks)

Gets the path name for the macro currently running.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentMacroPathName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.String  
  
value = instance.GetCurrentMacroPathName()
```

C#

```
System.string GetCurrentMacroPathName()
```

C++/CLI

```
System.String^ GetCurrentMacroPathName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Path name for the macro currently running

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetCurrentMacroPathName](#).

Example

[Create Macro Feature Subfeature \(VBA\)](#)
[Import Models As Solids \(VBA\)](#)
[Copy Document and Its Dependencies \(VBA\)](#)
[Copy Document and Its Dependencies \(VB.NET\)](#)
[Copy Document and Its Dependencies \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCurrentMacroPathFolder Method](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::RunMacro Method](#)
[ISldWorks::GetMacroMethods Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentWorkingDirectory Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetCurrentWorkingDirectory Method (ISldWorks)

Gets the current working directory being used by the SOLIDWORKS Design application.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentWorkingDirectory() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.String
```

```
value = instance.GetCurrentWorkingDirectory()
```

C#

```
System.string GetCurrentWorkingDirectory()
```

C++/CLI

```
System.String^ GetCurrentWorkingDirectory();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current working directory with trailing backslash

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::GetCurrentWorkingDirectory](#).

Remarks

The current working directory is used when opening documents containing references. If explicit search folders are not set (see [ISldWorks::SetSearchFolders](#)), then the SOLIDWORKS Design application initially tries to locate file references (for example, assembly component parts) in the current working directory. Interactively, the current working directory is used by the **File Open** dialog and is set when you choose the **Open** dialog button.

The most current [ISldWorks::OpenDoc6](#) method does not set the current working directory. Therefore, you might want to set the current working directory programmatically (see [ISldWorks::SetCurrentWorkingDirectory](#)) before opening a file containing references. By doing this, your application behaves as if the file was opened interactively using the File Open dialog.

For more information on the search criteria used by the SOLIDWORKS Design application when loading file references, see SOLIDWORKS Design user-interface help.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCurrentMacroPathFolder Method](#)
[ISldWorks::GetCurrentMacroPathName Method](#)
[ISldWorks::SetCurrentWorkingDirectory Method](#)
[ISldWorks::GetExecutablePath Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1999087

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDataFolder Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDataFolder Method (ISldWorks)

Gets the data directory name currently used by SOLIDWORKS Design.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDataFolder( _  
    ByVal BShowErrorMsg As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim BShowErrorMsg As System.Boolean  
Dim value As System.String  
  
value = instance.GetDataFolder(BShowErrorMsg)
```

C#

```
System.string GetDataFolder(  
    System.bool BShowErrorMsg  
)
```

C++/CLI

```
System.String^ GetDataFolder(  
    & System.bool BShowErrorMsg  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BShowErrorMsg

True to show any error messages in a dialog or false to avoid these dialogs (that is, data directory could not be found messages)

Return Value

Data directory currently used by the SOLIDWORKS Design application

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDataFolder](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::SetCurrentWorkingDirectory Method](#)
[ISldWorks::GetExecutablePath Method](#)
[ISldWorks::GetSearchFolders Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDocumentCount Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentCount Method (ISldWorks)

Gets the number of open documents in the current SOLIDWORKS Design session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
value = instance.GetDocumentCount()
```

C#

```
System.int GetDocumentCount()
```

C++/CLI

```
System.int GetDocumentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of open documents

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDocumentCount](#).

Example

[Get Paths of Open Documents \(C#\)](#)
[Get Paths of Open Documents \(VB.NET\)](#)
[Get Paths of Open Documents \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetDocuments Method](#)
[ISldWorks::IGetDocuments Method](#)
[ISldWorks::GetFirstDocument Method](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::CloseDoc Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDocumentDependencies Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentDependencies Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::GetDocumentDependencies2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentDependencies( _  
    ByVal Document As System.String, _  
    ByVal Traverseflag As System.Integer, _  
    ByVal Searchflag As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Document As System.String  
Dim Traverseflag As System.Integer  
Dim Searchflag As System.Integer  
Dim value As System.Object  
  
value = instance.GetDocumentDependencies(Document, Traverseflag, Searchflag)
```

C#

```
System.object GetDocumentDependencies(  
    System.string Document,  
    System.int Traverseflag,  
    System.int Searchflag  
)
```

C++/CLI

```
System.Object^ GetDocumentDependencies(  
& System.String^ Document,  
& System.int Traverseflag,  
& System.int Searchflag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Document

Traverseflag

Searchflag

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDocumentDependencies](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentDependencies2 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentDependencies2 Method (ISldWorks)

Gets all of the model dependencies for a document.

VB.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentDependencies2( _  
    ByVal Document As System.String, _  
    ByVal Traverseflag As System.Boolean, _  
    ByVal Searchflag As System.Boolean, _  
    ByVal AddReadOnlyInfo As System.Boolean _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Document As System.String  
Dim Traverseflag As System.Boolean  
Dim Searchflag As System.Boolean  
Dim AddReadOnlyInfo As System.Boolean  
Dim value As System.Object
```

```
value = instance.GetDocumentDependencies2(Document, Traverseflag, Searchflag, AddReadOnlyInfo)
```

C#

```
System.object GetDocumentDependencies2(  
    System.string Document,  
    System.bool Traverseflag,  
    System.bool Searchflag,  
    System.bool AddReadOnlyInfo  
)
```

C++/CLI

```
System.Object^ GetDocumentDependencies2(  
& System.String^ Document,  
& System.bool Traverseflag,  
& System.bool Searchflag,  
& System.bool AddReadOnlyInfo  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Document

Name of the document

Traverseflag

True if you want to traverse down into all dependent files, false if you want only the highest level within the dependencies

Searchflag

Set this argument to True if you want to use the search rules to find dependencies, false looks where the documents were last saved

AddReadOnlyInfo

True if you wish to have read-only information with the filenames; false if not

Return Value

Array of strings with two strings for each document returned in this list of dependent files:

- File name
- Filename with the complete pathname; this combination repeats itself for each dependent file found for this document

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::GetDocumentDependencies2](#).

Example

[Get Dependencies for Open and Unopened Documents \(VBA\)](#)
[Copy Document and Its Dependencies \(VBA\)](#)
[Copy Document and Its Dependencies \(VB.NET\)](#)
[Copy Document and Its Dependencies \(C#\)](#)

Remarks

As an example, calling this method on a drawing document returns a list of all the part and assemblies used in the drawing. If you set the `Traverseflag` to `True`, then each of the parts within the assembly file are also returned in this array of strings.

Another example would be calling this method with a derived mirror part. Because a derived mirror part is generated from another part, the list of model dependencies returned by this method would include the original part used to generate the derived mirror part.

Be aware that Library features are completely unassociated. They do not require the library nor do they update when changes are made to the Library feature. Therefore, this method would not return Library features.

If you use this method with an assembly that contains two documents, `Part1` and `SubAssem1`, an example of what might be returned is:

```
[ "Part1", "C:\temp\Part1.SLDPRT", "SubAssem1", "c:\temp\SubAssem1.SLDASM" ]
```

If `Traverseflag` is set to `True`, then all of the documents contained in `SubAssem1.ASM` are also returned. Suppressed components are recognized and returned by this method as a dependent file.

If the `AddReadOnlyInfo` flag is set to `True`, then a string of "Read-Only" is added to the list of strings. If `Part1` from were read-only, then the resulting set of strings would be:

```
[ "Part1", "C:\temp\Part1.SLDPRT", "Read-Only", "SubAssem1", "c:\temp\SubAssem1.SLDASM", "" ]
```

NOTE: If the `SearchFlag` is set to `True`, then the current directory is set to the directory of the document file. This replicates the interactive behavior of the **References** button in the File Open dialog window.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetDocumentDependencies2 Method](#)
[ISldWorks::GetDocumentDependenciesCount2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentDependenciesCount Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentDependenciesCount Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::GetDocumentDependenciesCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentDependenciesCount( _  
    ByVal Document As System.String, _  
    ByVal Traverseflag As System.Integer, _  
    ByVal Searchflag As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISldWorks  
Dim Document As System.String  
Dim Traverseflag As System.Integer
```



```
Dim Searchflag As System.Integer
Dim value As System.Integer

value = instance.GetDocumentDependenciesCount(Document, Traverseflag, Searchflag)
```

C#

```
System.int GetDocumentDependenciesCount(
    System.string Document,
    System.int Traverseflag,
    System.int Searchflag
)
```

C++/CLI

```
System.int GetDocumentDependenciesCount(
    & System.String^ Document,
    & System.int Traverseflag,
    & System.int Searchflag
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Document

Traverseflag

Searchflag

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::GetDocumentDependenciesCount](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocuments Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocuments Method (ISldWorks)

Gets the open documents in this SOLIDWORKS Design session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocuments() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Object

value = instance.GetDocuments()
```

C#

```
System.object GetDocuments()
```

C++/CLI

```
System.Object^ GetDocuments();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of open [documents](#) in this SOLIDWORKS Design session

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDocuments](#).

Example

[Get Paths of Open Documents \(C#\)](#)
[Get Paths of Open Documents \(VB.NET\)](#)
[Get Paths of Open Documents \(VBA\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::CloseDoc Method](#)
[ISldWorks::GetDocumentCount Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::IGetDocuments Method](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)
[ISldWorks::GetFirstDocument Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentTemplate Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentTemplate Method (ISldWorks)

Gets the name of document template that can be used in [ISldWorks::NewDocument](#) or [ISldWorks::INewDocument2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentTemplate( _  
    ByVal Mode As System.Integer, _  
    ByVal TemplateName As System.String, _  
    ByVal PaperSize As System.Integer, _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Mode As System.Integer  
Dim TemplateName As System.String  
Dim PaperSize As System.Integer  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.String  
  
value = instance.GetDocumentTemplate(Mode, TemplateName, PaperSize, Width, Height)
```

C#

```
System.string GetDocumentTemplate(  
    System.int Mode,  
    System.string TemplateName,  
    System.int PaperSize,  
    System.double Width,  
    System.double Height  
)
```

```

System.String^ GetDocumentTemplate(
& System.int Mode,
& System.String^ TemplateName,
& System.int PaperSize,
& System.double Width,
& System.double Height
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Mode

Document type as defined in [swDocumentTypes_e](#) (see **Remarks**)

TemplateName

Name of custom template including full directory path

PaperSize

Size of paper as defined in [swDwgPaperSizes_e](#)

Width

Width of paper; used only when paperSize is swDwgPapersUserDefined

Height

Height of paper; used only when paperSize is swDwgPapersUserDefined

Return Value

Name of the selected document template

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDocumentTemplate](#).

Example

[Get Locations and Names of Document Templates \(VBA\)](#)

Remarks

If type is...	Then...
swDocPART or swDocASSEMBLY	Remaining arguments are not used.
swDocDRAWING	Remaining arguments are used to determine which drawing template to use.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetTemplateSizes Method](#)
[ISldWorks::IGetTemplateSizes Method](#)
[ISldWorks::PreSelectDwgTemplateSize Method](#)

Availability

SOLIDWORKS 2001Plus SP4, Revision Number 10.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDocumentVisible Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetDocumentVisible Method (ISldWorks)

Gets the visibility of the document to open.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDocumentVisible( _  
    ByVal Type As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Type As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetDocumentVisible(Type)
```

C#

```
System.bool GetDocumentVisible(  
    System.int Type  
)
```

C++/CLI

```
System.bool GetDocumentVisible(  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type
Document type as defined by [swDocumentTypes_e](#)

Return Value

True if the document will be visible when opened, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetDocumentVisible](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEnvironment Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetEnvironment Method (ISldWorks)

Gets the [IEnvironment](#) object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEnvironment() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Object  
  
value = instance.GetEnvironment()
```

C#

```
System.Object GetEnvironment()
```

C++/CLI

```
System.Object^ GetEnvironment();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IEnvironment](#) object

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetEnvironment](#).

Example

[Analyze Text and Geometry in GTol Symbol \(C#\)](#)
[Analyze Text and Geometry in GTol Symbol \(VB.NET\)](#)
[Analyze Text and Geometry in GTol Symbol \(VBA\)](#)

Remarks

All numeric values returned from the IEnvironment object are relative to a unit text height of 1.0.; i.e., if a symbol has a text height of 0.15, then multiply the numeric values returned by 0.15.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::IGetEnvironment Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetErrorMessages Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetErrorMessages Method (ISldWorks)

Gets the last 20 messages issued in the current SOLIDWORKS Design session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetErrorMessages( _  
    ByRef Msgs As System.Object, _  
    ByRef MsgIDs As System.Object, _  
    ByRef MsgTypes As System.Object _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISldWorks  
Dim Msgs As System.Object  
Dim MsgIDs As System.Object  
Dim MsgTypes As System.Object  
Dim value As System.Integer
```

```
value = instance.GetErrorMessages(Msgs, MsgIDs, MsgTypes)
```

C#



```
System.int GetErrorMessages(
    out System.object Msgs,
    out System.object MsgIDs,
    out System.object MsgTypes
)
```

C++/CLI

```
System.int GetErrorMessages(
    & [Out] System.Object^ Msgs,
    & [Out] System.Object^ MsgIDs,
    & [Out] System.Object^ MsgTypes
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Msgs
Array of the last 20 messages issued in this SOLIDWORKS Design session
MsgIDs
Array of the resource IDs of the last 20 messages issued in this SOLIDWORKS Design session
MsgTypes
Array of the types of the last 20 messages issued in this SOLIDWORKS Design session (see **Remarks**)

Return Value

Number of messages issued in this SOLIDWORKS Design session

NOTE: The stack is cleared after calling this method.

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetErrorMessages](#).

Example

[Get Messages \(VBA\)](#)

Remarks

The elements of the MsgTypes array are bitmasks of the Microsoft message-box system constants.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetLastSaveError Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExecutablePath Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetExecutablePath Method (ISldWorks)

Gets the path to the SOLIDWORKS Design executable, **sldworks.exe**.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExecutablePath() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.String

value = instance.GetExecutablePath()
```

C#

```
System.string GetExecutablePath()
```

C++/CLI

```
System.String^ GetExecutablePath();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Path for **sldworks.exe**

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetExecutablePath](#).

Example

This subroutine illustrates how to use this method:

```
' -----
Option Explicit

Sub main()
    Dim swApp As SldWorks.SldWorks

    Set swApp = Application.SldWorks

    ' Gives directory name without trailing backslash
    Debug.Print "SldWorks Design executable = " & swApp.GetExecutablePath
End Sub
' -----
```

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCurrentMacroPathFolder Method](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::GetDataFolder Method](#)

Availability

SOLIDWORKS 2003 SP3, Revision Number 11.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExportFileData Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetExportFileData Method (ISldWorks)

Gets the data interface for the specified file type to which to export one or more drawing sheets.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetExportFileData( _  
    ByVal FileType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileType As System.Integer  
Dim value As System.Object  
  
value = instance.GetExportFileData(FileType)
```

C#

```
System.object GetExportFileData(  
    System.int FileType  
)
```

C++/CLI

```
System.Object^ GetExportFileData(  
& System.int FileType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

File Type

File type as defined in [swExportDataFileType_e](#)

Return Value

[Data interface](#) for the specified file type to which to export one or more drawing sheets

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetExportFileData](#).

Example

[Save File As PDF \(VBA\)](#)
[Save File as PDF \(C#\)](#)
[Save File as PDF \(VB.NET\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFilePLMID Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetFilePLMID Method (ISldWorks)

Gets the Product Lifecycle Management (PLM) ID of the specified file stored in 3DEXPERIENCE.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetFilePLMID( _  
    ByVal FilePath As System.String _  
    ) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePath As System.String  
Dim value As System.String  
  
value = instance.GetFilePLMID(FilePath)
```

C#

```
System.string GetFilePLMID(  
    System.string FilePath  
)
```

C++/CLI

```
System.String^ GetFilePLMID(  
& System.String^ FilePath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath
Name of file

Return Value

PLM ID

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetFilePLMID](#).

Remarks

This method is valid only for [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2022 SP03, Revision Number 30.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstDocument Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetFirstDocument Method (ISldWorks)

Gets the document opened first in this SOLIDWORKS Design session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstDocument() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Object

value = instance.GetFirstDocument()
```

C#

```
System.Object GetFirstDocument()
```

C++/CLI

```
System.Object^ GetFirstDocument();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Document](#) first opened

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetFirstDocument](#).

Example

[Determine If Document is Dirty \(VBA\)](#)
[Get Names of Open Documents \(VBA\)](#)
[Get Names of Components, Window Handles, and DIBSECTIONS \(C#\)](#)
[Get Names of Components, Window Handles, and DIBSECTIONS \(VB.NET\)](#)
[Get Names of Components, Window Handles, and DIBSECTIONS \(VBA\)](#)

Remarks

If the document first opened is an assembly, then this method returns the name of the first component document opened in that assembly.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::ActiveDoc Property](#)
[ISldWorks::IActiveDoc2 Property](#)
[ISldWorks::EnumDocuments2 Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::CloseDoc Method](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::GetDocumentCount Method](#)
[ISldWorks::GetDocuments Method](#)
[ISldWorks::IGetDocuments Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGtolFormatData Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetGtolFormatData Method (ISldWorks)

Gets the Gtol format and XML schema versions supported by this version of SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetGtolFormatData( _
    ByRef GtolFormat As System.Integer, _
    ByRef XmlSchemaversion As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim GtolFormat As System.Integer
Dim XmlSchemaversion As System.Integer

instance.GetGtolFormatData(GtolFormat, XmlSchemaversion)
```

C#

```
void GetGtolFormatData(
    out System.int GtolFormat,
    out System.int XmlSchemaversion
)
```

C++/CLI

```
void GetGtolFormatData(
    & [Out] System.int GtolFormat,
    & [Out] System.int XmlSchemaversion
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GtolFormat

Gtol format as defined by [swGtolFormatType_e](#)

XmlSchemaversion

XML schema version as defined by [swGtolFormatSchemaVersion_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetGtolFormatData](#).

Remarks

See [Gtol Frame XML Schema](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::GetGtolFrameXMLSchema Method \(\)](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGtolFrameXMLSchema Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetGtolFrameXMLSchema Method (ISldWorks)

Gets the XML schema for Gtol frame symbol XML.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGtolFrameXMLSchema() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.String

value = instance.GetGtolFrameXMLSchema()
```

C#

```
System.string GetGtolFrameXMLSchema()
```

C++/CLI

```
System.String^ GetGtolFrameXMLSchema();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

XML schema for Gtol Frame symbol XML

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetGtolFrameXMLSchema](#).

Remarks

See [Gtol Frame XML Schema](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IGtolFrame::GetSymbolXml Method \(\)](#)
[IGtolFrame::SetSymbolXml Method \(\)](#)
[ISldWorks::GetGtolFormatData Method \(\)](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHoleStandardsData Method (ISldWorks)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetHoleStandardsData Method (ISldWorks)

Gets the hole standards for the specified hole type.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleStandardsData( _  
    ByVal HoleTypeID As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim HoleTypeID As System.Integer  
Dim value As System.Object  
  
value = instance.GetHoleStandardsData(HoleTypeID)
```

C#

```
System.object GetHoleStandardsData(  
    System.int HoleTypeID  
)
```

C++/CLI

```
System.Object^ GetHoleStandardsData(  
&    System.int HoleTypeID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleTypeID

Hole Wizard hole type as defined in [swWzdGeneralHoleTypes_e](#)

Return Value

[IHoleStandardsData](#); null if HoleTypeID is 5 (swWzdLegacy)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetHoleStandardsData](#).

Example

[Get Hole Standards Data \(VBA\)](#)

[Get Hole Standards Data \(C#\)](#)

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[IHoleDataTable Interface](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImageSize Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetImageSize Method (ISldWorks)

Gets:

- small, medium, and large image sizes suitable for the current DPI setting of the display device.
- default image size for the current DPI setting of the display device for images that are not based on the SOLIDWORKS icon size setting.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImageSize( _  
    ByRef Small As System.Integer, _  
    ByRef Medium As System.Integer, _  
    ByRef Large As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Small As System.Integer  
Dim Medium As System.Integer  
Dim Large As System.Integer  
Dim value As System.Integer  
  
value = instance.GetImageSize(Small, Medium, Large)
```

C#

```
System.int GetImageSize(  
    out System.int Small,  
    out System.int Medium,  
    out System.int Large  
)
```

C++/CLI

```
System.int GetImageSize(  
& [Out] System.int Small,
```

```
& [Out] System.int Medium,  
& [Out] System.int Large  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Small

Small image size suitable for the current DPI setting of the display device

Medium

Medium image size suitable for the current DPI setting of the display device

Large

Large image size suitable for the current DPI setting of the display device

Return Value

Default image size for the current DPI setting of the display device for images that are not based on the SOLIDWORKS icon size setting as defined in [swImageSizeToUse](#) e

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetImageSize](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)

[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

You can use this method to determine the correct size for:

- buttons for your PropertyManager pages.
- icons for your macro features.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ICommandGroup::IconList Property \(\)](#)

[ICommandGroup::MainIconList Property \(\)](#)

[ICommandManager::CreateFlyoutGroup2 Method \(\)](#)

[IFlyoutGroup::IconList Property \(\)](#)

[IFlyoutGroup::MainIconList Property \(\)](#)

[IFrame::AddMenuPopupIcon3 Method \(\)](#)

[IPropertyManagerPageBitmapButton::SetBitmapsByName3 Method \(\)](#)

[ISldWorks::AddMenuItem5 Method \(\)](#)

[ISldWorks::AddToolBar5 Method \(\)](#)

[ITaskPaneView::AddCustomButton2 Method \(\)](#)

[ISldWorks::CreateTaskpaneView3 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportFileData Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetImportFileData Method (ISldWorks)

Gets the IGES or DXF/DWG import data for the specified file.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportFileData( _  
    ByVal FileName As System.String _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Object
```



```
value = instance.GetImportFileData(FileName)
```

C#

```
System.object GetImportFileData(  
    System.string FileName  
)
```

C++/CLI

```
System.Object^ GetImportFileData(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and name of the IGES or DXF/DWG file

Return Value

[IGES import data](#) or [DXF/DWG import data](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetImportFileData](#).

Example

[Import DXF File Into Part Sketch \(VBA\)](#)
[Import DXF File Into Drawing \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VB.NET\)](#)
[Insert DXF/DWG File and Add Dimensions \(C#\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

Remarks

Getting the interface object does not retrieve any information from the input file or set up defaults at this time. Instead, it sets up information such that when it is used in the import process, SOLIDWORKS will compute defaults on the fly.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::LoadFile4 Method](#)
[IFeatureManager::InsertDwgOrDxfFile2 Method](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInterfaceBrightnessThemeColors Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetInterfaceBrightnessThemeColors Method (ISldWorks)

Gets the theme and colors of the SOLIDWORKS background.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInterfaceBrightnessThemeColors( _  
    ByRef Colors As System.Object _
```

) As System.Integer

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim Colors As System.Object
Dim value As System.Integer

value = instance.GetInterfaceBrightnessThemeColors(Colors)
```

C#

```
System.int GetInterfaceBrightnessThemeColors(
    out System.object Colors
)
```

C++/CLI

```
System.int GetInterfaceBrightnessThemeColors(
    & [Out] System.Object^ Colors
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Colors

Array of nine RGB (Red, Green, Blue) decimal values corresponding to the nine color types of the SOLIDWORKS background as defined in [swInterfaceBrightnessColor_e](#)

Return Value

SOLIDWORKS background theme as defined in [swInterfaceBrightnessTheme_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetInterfaceBrightnessThemeColors](#).

Remarks

A SOLIDWORKS add-in can:

- use this method to determine the current theme and colors of the SOLIDWORKS background.
- be notified when the theme and colors in the SOLIDWORKS background change by registering for the [DSldWorksEvents](#) [InterfaceBrightnessThemeChangeEventHandler](#) event.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISwHtmlInterface::GetInterfaceBrightnessTheme](#)

Availability

SOLIDWORKS 2016 SP2, Revision Number 24.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLastSaveError Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetLastSaveError Method (ISldWorks)

Gets the last save error issued by Microsoft in the current session.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLastSaveError( _
    ByRef FilePath As System.Object, _
    ByRef ErrorCode As System.Object _
) As System.Object
```

```

Dim instance As ISldWorks
Dim FilePath As System.Object
Dim ErrorCode As System.Object
Dim value As System.Object

value = instance.GetLastError(FilePath, ErrorCode)

```

C#

```

System.object GetLastError(
    out System.object FilePath,
    out System.object ErrorCode
)

```

C++/CLI

```

System.Object^ GetLastError(
& [Out] System.Object^ FilePath,
& [Out] System.Object^ ErrorCode
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

Path name of the document causing the save error

ErrorCode

Error code of the save

Return Value

Text message of the save error

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetLastError](#).

Example

[Get Last Save Error \(VBA\)](#)
[Get Last Save Error \(VB.NET\)](#)
[Get Last Save Error \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetErrorMessages Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLastToolBarID Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetLastToolBarID Method (ISldWorks)

Gets the ID of the last toolbar added to the [CommandManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLastToolBarID() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISldWorks
Dim value As System.Integer

value = instance.GetLastToolBarID()
```

C#

```
System.int GetLastToolBarID()
```

C++/CLI

```
System.int GetLastToolBarID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ID of the last toolbar added to the CommandManager

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetLastToolBarID](#).

Remarks

See [CommandManager and CommandGroups](#) to learn how to create a CommandManager and add and remove CommandGroups.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetCommandID Method](#)
[ISldWorks::GetCommandManager Method](#)
[ICommandGroup Interface](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLatestSupportedFileVersion Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : GetLatestSupportedFileVersion Method (ISldWorks)

Gets the version number that this instance of SOLIDWORKS reads and writes.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLatestSupportedFileVersion() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Integer

value = instance.GetLatestSupportedFileVersion()
```

C#

```
System.int GetLatestSupportedFileVersion()
```

C++/CLI

```
System.int GetLatestSupportedFileVersion();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

File version number that this instance of SOLIDWORKS supports

SOLIDWORKS Release	Version Number
SOLIDWORKS 95	44
SOLIDWORKS 96	243
SOLIDWORKS 97	483
SOLIDWORKS 97Plus	629
SOLIDWORKS 98	822
SOLIDWORKS 98Plus	1008
SOLIDWORKS 99	1137
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000
SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000
SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000

Visual Basic for Applications (VBA) Syntax

See [SldWorks::GetLatestSupportedFileVersion](#).

Remarks

When opening a document whose version is less than the SOLIDWORKS latest supported file version, SOLIDWORKS converts the document to its latest supported file version.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0.0