

SOLIDWORKS API (NET VBA C#) — Reference (289/337): ISlicingData-ISMCornerReliefData

SOLIDWORKS API Documentation (converted from CHM)

ISlicingData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISlicingData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISlicingData Interface

Allows access to slicing tool data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISlicingData
```

Visual Basic (Usage)



```
Dim instance As ISlicingData
```

C#

```
public interface ISlicingData
```

C++/CLI

```
public interface class ISlicingData
```

Visual Basic for Applications (VBA) Syntax

See [SlicingData](#).

Example

'VBA

'Preconditions:

- ' 1. Open *Public_Documents\SOLIDWORKS\SOLIDWORKS 2020\samples\tutorial\apilcube.sldprt*.
- ' 2. Change units to MKS.
- ' 3. Open the Immediate window.

'Postconditions:

- ' 1. Selects **Front Plane** as the first slicing plane.
- ' 2. Gets the default slicing parameters.
- ' 3. Specifies new slicing parameters.
- ' 4. Performs slicing and adds **Slice1** to the FeatureManager design tree.
- ' 5. Inspect the graphics area and the Immediate window.
- ' NOTE: Because the model is used elsewhere, do not save changes to it.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim modDoc As SldWorks.ModelDoc2
Dim swFeatMgr As SldWorks.FeatureManager
Dim sliceData As SldWorks.SlicingData
Dim boolstatus As Boolean
Dim errors As Long
Dim vars As Variant
```

Option Explicit

Sub main()

```
    Set swApp = Application.SldWorks
    Set modDoc = swApp.ActiveDoc
    Set swFeatMgr = modDoc.FeatureManager
```

```

' Select the first slicing plane
boolstatus = modDoc.Extension.SelectByID2("Front Plane", "PLANE", 0, 0, 0, False, 0, Nothing, 0)
' Get default slicing parameters
Set sliceData = swFeatMgr.GetSlicingData()

Debug.Print "Default slicing values:"
Debug.Print ""
Debug.Print "Bounding box direction 1: " & sliceData.GetBoundingBoxDirection1
Debug.Print "Bounding box direction 2: " & sliceData.GetBoundingBoxDirection2
Debug.Print "Bounding box direction 3: " & sliceData.GetBoundingBoxDirection3
Debug.Print "Bounding box direction 4: " & sliceData.GetBoundingBoxDirection4
Debug.Print "Reverse direction? " & sliceData.ReverseDirection
Debug.Print "Number of slices: " & sliceData.NumberOfPlanes
Debug.Print "Distance between slices: " & sliceData.Offset
Debug.Print "Type of slicing as defined in swSlicingTypes_e: " & sliceData.SlicesToGenerate
Debug.Print "Add slicing planes and sketches to folder? " & sliceData.AddSlicingPlanesAndSketchesToFolder

sliceData.ReverseDirection = False
boolstatus = sliceData.SetBoundingBoxDirection1(0.1397)
boolstatus = sliceData.SetBoundingBoxDirection2(0.1397)
boolstatus = sliceData.SetBoundingBoxDirection3(-0.1397)
boolstatus = sliceData.SetBoundingBoxDirection4(-0.1397)
sliceData.NumberOfPlanes = 6
sliceData.Offset = 0.01
sliceData.SlicesToGenerate = swSlicingTypes_Rectangle
sliceData.AddSlicingPlanesAndSketchesToFolder = True

Debug.Print ""
Debug.Print "New values:"
Debug.Print ""
Debug.Print "Bounding box direction 1: " & sliceData.GetBoundingBoxDirection1
Debug.Print "Bounding box direction 2: " & sliceData.GetBoundingBoxDirection2
Debug.Print "Bounding box direction 3: " & sliceData.GetBoundingBoxDirection3
Debug.Print "Bounding box direction 4: " & sliceData.GetBoundingBoxDirection4
Debug.Print "Reverse direction? " & sliceData.ReverseDirection
Debug.Print "Number of slices: " & sliceData.NumberOfPlanes
Debug.Print "Distance between slices: " & sliceData.Offset
Debug.Print "Type of slicing as defined in swSlicingTypes_e: " & sliceData.SlicesToGenerate
Debug.Print "Add slicing planes and sketches to folder? " & sliceData.AddSlicingPlanesAndSketchesToFolder

vars = swFeatMgr.InsertSlicing(sliceData, errors)

Debug.Print ""
Debug.Print "Slicing error code as defined in swInsertSlicingError_e: " & errors
End Sub

```

Example

[Slice a Model \(C#\)](#)

Remarks

You must pre-select the first slicing plane before you can access the default bounding box directions for slicing.

[IFeatureManager::InsertSlicing](#) takes this data object and invokes the Slicing tool. The Slicing tool creates a parallel or radial series of slicing planes with sketches that intersect, or slice, the model.

For more information, see the **Slicing Tool** topics in the SOLIDWORKS Design user-interface help.

Accessors

[IFeatureManager::GetSlicingData](#)

Access Diagram

[SlicingData](#)

See Also

[ISlicingData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISlicingData Interface

The following tables list the members exposed by [ISlicingData](#).

 Public Properties

Name	Description
 AddSlicingPlanesAndSketchesToFolder	Gets or sets whether to add slicing planes and sketches to a folder in the FeatureManager design tree.
 NumberOfPlanes	Gets or sets the number of slicing planes.
 Offset	Gets or sets the linear or radial spacing between slicing planes.
 PlaneReferences	Sets the reference entities of the first slicing plane.
 ReverseDirection	Gets or sets whether to reverse the direction of slicing the model with respect to the initial reference plane.
 SlicesToGenerate	Gets or sets the slicing method.

[Top](#)

 Public Methods

Name	Description
 GetBoundingBoxDirection1	Gets bounding box direction 1 (top manipulator for both linear and radial slicing).
 GetBoundingBoxDirection2	Gets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).
 GetBoundingBoxDirection3	Gets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).
 GetBoundingBoxDirection4	Gets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).
 SetBoundingBoxDirection1	Sets bounding box direction 1 (top manipulator for both linear and radial slicing).
 SetBoundingBoxDirection2	Sets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).
 SetBoundingBoxDirection3	Sets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).
 SetBoundingBoxDirection4	Sets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).

[Top](#)

 See Also

[ISlicingData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISlicingData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISlicingData Interface

For a list of all members of this type, see [ISlicingData members](#).

 Public Methods

Name	Description
 GetBoundingBoxDirection1	Gets bounding box direction 1 (top manipulator for both linear and radial slicing).
 GetBoundingBoxDirection2	Gets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).
 GetBoundingBoxDirection3	Gets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).
 GetBoundingBoxDirection4	Gets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).
 SetBoundingBoxDirection1	Sets bounding box direction 1 (top manipulator for both linear and radial slicing).
 SetBoundingBoxDirection2	Sets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).
 SetBoundingBoxDirection3	Sets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).
 SetBoundingBoxDirection4	Sets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).

[Top](#)

See Also

[ISlicingData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISlicingData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISlicingData Interface

For a list of all members of this type, see [ISlicingData members](#).

Public Properties

Name	Description
 AddSlicingPlanesAndSketchesToFolder	Gets or sets whether to add slicing planes and sketches to a folder in the FeatureManager design tree.
 NumberOfPlanes	Gets or sets the number of slicing planes.
 Offset	Gets or sets the linear or radial spacing between slicing planes.
 PlaneReferences	Sets the reference entities of the first slicing plane.
 ReverseDirection	Gets or sets whether to reverse the direction of slicing the model with respect to the initial reference plane.
 SlicesToGenerate	Gets or sets the slicing method.

[Top](#)

See Also

[ISlicingData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddSlicingPlanesAndSketchesToFolder Property (ISlicingData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : AddSlicingPlanesAndSketchesToFolder Property (ISlicingData)

Gets or sets whether to add slicing planes and sketches to a folder in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property AddSlicingPlanesAndSketchesToFolder As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Boolean
```

```
instance.AddSlicingPlanesAndSketchesToFolder = value
```

```
value = instance.AddSlicingPlanesAndSketchesToFolder
```

C#

```
System.bool AddSlicingPlanesAndSketchesToFolder {get; set;}
```

C++/CLI

```
property System.bool AddSlicingPlanesAndSketchesToFolder {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to add slicing planes and sketches to a folder in the FeatureManager design tree, false to not

Visual Basic for Applications (VBA) Syntax

See [SlicingData::AddSlicingPlanesAndSketchesToFolder](#).

Example

See the [ISlicingData](#) example.

Remarks

If this property is set to true, then after slicing, a **Slice1** folder is created in the FeatureManager design tree from which you can explicitly select and edit the slicing sketches and reference plane

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBoundingBoxDirection1 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : GetBoundingBoxDirection1 Method (ISlicingData)

Gets bounding box direction 1 (top manipulator for both linear and radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBoundingBoxDirection1() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Double
```

```
value = instance.GetBoundingBoxDirection1()
```

C#

```
System.double GetBoundingBoxDirection1()
```

C++/CLI

```
System.double GetBoundingBoxDirection1();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

0.0 < top manipulator < 500.0

Visual Basic for Applications (VBA) Syntax

See [SlicingData::GetBoundingBoxDirection1](#).

Example

See the [ISlicingData](#) example.

Remarks

This method is only valid after you have pre-selected the first slicing plane.

Use these methods to get the slicing volume for including or excluding geometry for slicing:

- [ISlicingData::GetBoundingBoxDirection1](#)
- [ISlicingData::GetBoundingBoxDirection2](#)
- [ISlicingData::GetBoundingBoxDirection3](#)
- [ISlicingData::GetBoundingBoxDirection4](#)

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::SetBoundingBoxDirection1 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBoundingBoxDirection2 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : GetBoundingBoxDirection2 Method (ISlicingData)

Gets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBoundingBoxDirection2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Double
```

```
value = instance.GetBoundingBoxDirection2()
```

C#

```
System.double GetBoundingBoxDirection2()
```

C++/CLI

```
System.double GetBoundingBoxDirection2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

For linear slicing:

0.0 < right manipulator < 500.0

For radial slicing:

-500.0 < bottom manipulator < 0.0

Visual Basic for Applications (VBA) Syntax

See [SlicingData::GetBoundingBoxDirection2](#).

Example

See the [ISlicingData](#) example.

Remarks

This method is only valid after you have pre-selected the first slicing plane.

Use these methods to get the slicing volume for including or excluding geometry for slicing:

- [ISlicingData::GetBoundingBoxDirection1](#)
- [ISlicingData::GetBoundingBoxDirection2](#)
- [ISlicingData::GetBoundingBoxDirection3](#)
- [ISlicingData::GetBoundingBoxDirection4](#)

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::SetBoundingBoxDirection2 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBoundingBoxDirection3 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : GetBoundingBoxDirection3 Method (ISlicingData)

Gets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBoundingBoxDirection3() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Double
```

```
value = instance.GetBoundingBoxDirection3()
```

C#

```
System.double GetBoundingBoxDirection3()
```

C++/CLI

```
System.double GetBoundingBoxDirection3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

For linear slicing:

-500.0 < left manipulator < 0.0

For angular slicing:

0.0 < inner radius < outer radius

Visual Basic for Applications (VBA) Syntax

See [SlicingData::GetBoundingBoxDirection3](#).

Example

See the [ISlicingData](#) example.

Remarks

This method is only valid after you have pre-selected the first slicing plane.

Use these methods to get the slicing volume for including or excluding geometry for slicing:

- [ISlicingData::GetBoundingBoxDirection1](#)
- [ISlicingData::GetBoundingBoxDirection2](#)
- [ISlicingData::GetBoundingBoxDirection3](#)
- [ISlicingData::GetBoundingBoxDirection4](#)

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::SetBoundingBoxDirection3 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBoundingBoxDirection4 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : GetBoundingBoxDirection4 Method (ISlicingData)

Gets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBoundingBoxDirection4() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Double
```

```
value = instance.GetBoundingBoxDirection4()
```

C#

```
System.double GetBoundingBoxDirection4()
```

C++/CLI

```
System.double GetBoundingBoxDirection4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

For linear slicing:

-500.0 < bottom manipulator < 0

For radial slicing:

Inner radius < outer radius < user-interface maximum for this case

Visual Basic for Applications (VBA) Syntax

See [SlicingData::GetBoundingBoxDirection4](#).

Example

See the [ISlicingData](#) example.

Remarks

This method is only valid after you have pre-selected the first slicing plane.

Use these methods to get the slicing volume for including or excluding geometry for slicing:

- [ISlicingData::GetBoundingBoxDirection1](#)
- [ISlicingData::GetBoundingBoxDirection2](#)
- [ISlicingData::GetBoundingBoxDirection3](#)
- [ISlicingData::GetBoundingBoxDirection4](#)

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::SetBoundingBoxDirection4 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfPlanes Property (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : NumberOfPlanes Property (ISlicingData)

Gets or sets the number of slicing planes.

.NET Syntax

Visual Basic (Declaration)

```
Property NumberOfPlanes As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Integer  
  
instance.NumberOfPlanes = value  
value = instance.NumberOfPlanes
```

C#

```
System.int NumberOfPlanes {get; set;}
```

C++/CLI

```
property System.int NumberOfPlanes {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of slicing planes

Visual Basic for Applications (VBA) Syntax

See [SlicingData::NumberOfPlanes](#).

Example

See the [ISlicingData](#) example.

Remarks

The number of slicing planes cannot exceed 100.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::PlaneReferences Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Offset Property (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : Offset Property (ISlicingData)

Gets or sets the linear or radial spacing between slicing planes.

.NET Syntax

Visual Basic (Declaration)

Property Offset As System.Double

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim value As System.Double
```

```
instance.Offset = value
```

```
value = instance.Offset
```

C#

```
System.double Offset {get; set;}
```

C++/CLI

```
property System.double Offset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Linear spacing (meters) or radial spacing (radians) between slicing planes (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SlicingData::Offset](#).

Example

See the [ISlicingData](#) example.

Remarks

If [ISlicingData::PlaneReferences](#) specifies:

- a planar entity, then this property specifies linear spacing between slices.
- a linear entity and a point entity, then this property specifies radial spacing between slices.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlaneReferences Property (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : PlaneReferences Property (ISlicingData)

Sets the reference entities of the first slicing plane.

.NET Syntax

Visual Basic (Declaration)

```
WriteOnly Property PlaneReferences As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
  
instance.PlaneReferences = value
```

C#

```
System.object PlaneReferences {set;}
```

C++/CLI

```
property System.Object^ PlaneReferences {  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of reference entities (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SlicingData::PlaneReferences](#).

Remarks

Use this property to specify either:

- a planar entity (e.g., [IFace2](#), [IRefPlane](#)) to produce a linear pattern of parallel slices
- OR -
- a linear entity (e.g., [IEdge](#), [IRefAxis](#), [ISketchLine](#)) and a vertex ([IRefPoint](#), [IVertex](#)) to produce a radial pattern of slices whose axis is the linear entity.

Use [ISlicingData::NumberOfPlanes](#) to specify the number of slices and [ISlicingData::Offset](#) to specify the linear or radial spacing of the slices.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : ReverseDirection Property (ISlicingData)

Gets or sets whether to reverse the direction of slicing the model with respect to the initial reference plane.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

```
Dim instance As ISlicingData
Dim value As System.Boolean

instance.ReverseDirection = value

value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of adding slices, false to not

Visual Basic for Applications (VBA) Syntax

See [SlicingData::ReverseDirection](#).

Example

See the [ISlicingData](#) example.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBoundingBoxDirection1 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : SetBoundingBoxDirection1 Method (ISlicingData)

Sets bounding box direction 1 (top manipulator for both linear and radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBoundingBoxDirection1( _
    ByVal Direction As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ISlicingData
Dim Direction As System.Double
Dim value As System.Boolean

value = instance.SetBoundingBoxDirection1(Direction)
```

C#

```
System.bool SetBoundingBoxDirection1(  
    System.double Direction  
)
```

C++/CLI

```
System.bool SetBoundingBoxDirection1(  
& System.double Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

0.0 < top manipulator < 500.0 (see **Remarks**)

Return Value

True if direction 1 of bounding box successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [ISlicingData::SetBoundingBoxDirection1](#).

Example

See the [ISlicingData](#) example.

Remarks

Use these methods to adjust the slicing volume to include or exclude geometry for slicing:

- [ISlicingData::SetBoundingBoxDirection1](#)
- [ISlicingData::SetBoundingBoxDirection2](#)
- [ISlicingData::SetBoundingBoxDirection3](#)
- [ISlicingData::SetBoundingBoxDirection4](#)

This method fails when:

- Direction exceeds the specified limits.
- The bounding box cannot be created because [ISlicingData::PlaneReferences](#) has not been set.

See Also

[ISlicingData Interface](#)

[ISlicingData Members](#)

[ISlicingData::GetBoundingBoxDirection1 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetBoundingBoxDirection2 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : SetBoundingBoxDirection2 Method (ISlicingData)

Sets bounding box direction 2 (right manipulator for linear slicing, bottom manipulator for radial slicing).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBoundingBoxDirection2( _  
    ByVal Direction As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISlicingData
Dim Direction As System.Double
Dim value As System.Boolean

value = instance.SetBoundingBoxDirection2(Direction)
```

C#

```
System.bool SetBoundingBoxDirection2(
    System.double Direction
)
```

C++/CLI

```
System.bool SetBoundingBoxDirection2(
    & System.double Direction
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

For linear slicing:

0.0 < right manipulator < 500.0

For radial slicing:

-500.0 < bottom manipulator < 0.0

(see **Remarks**)

Return Value

True if direction 2 of bounding box successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SlicingData::SetBoundingBoxDirection2](#).

Example

See the [ISlicingData](#) example.

Remarks

Use these methods to adjust the slicing volume to include or exclude geometry for slicing:

- [ISlicingData::SetBoundingBoxDirection1](#)
- [ISlicingData::SetBoundingBoxDirection2](#)
- [ISlicingData::SetBoundingBoxDirection3](#)
- [ISlicingData::SetBoundingBoxDirection4](#)

This method fails when:

- Direction exceeds the specified limits.
- The bounding box cannot be created because [ISlicingData::PlaneReferences](#) has not been set.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::GetBoundingBoxDirection2 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBoundingBoxDirection3 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : SetBoundingBoxDirection3 Method (ISlicingData)

Sets bounding box direction 3 (left manipulator for linear slicing, inner radius for radial slicing).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetBoundingBoxDirection3( _  
    ByVal Direction As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim Direction As System.Double  
Dim value As System.Boolean  
  
value = instance.SetBoundingBoxDirection3(Direction)
```

C#

```
System.bool SetBoundingBoxDirection3(  
    System.double Direction  
)
```

C++/CLI

```
System.bool SetBoundingBoxDirection3(  
& System.double Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

For linear slicing:

-500.0 < left manipulator < 0.0

For radial slicing:

0.0 < inner radius < outer radius

(see **Remarks**)

Return Value

True if direction 3 of bounding box successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SlicingData::SetBoundingBoxDirection3](#).

Example

See the [ISlicingData](#) example.

Remarks

Use these methods to adjust the slicing volume to include or exclude geometry for slicing:

- [ISlicingData::SetBoundingBoxDirection1](#)
- [ISlicingData::SetBoundingBoxDirection2](#)
- [ISlicingData::SetBoundingBoxDirection3](#)
- [ISlicingData::SetBoundingBoxDirection4](#)

This method fails when:

- Direction exceeds the specified limits.
- The bounding box cannot be created because [ISlicingData::PlaneReferences](#) has not been set.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::GetBoundingBoxDirection3 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBoundingBoxDirection4 Method (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : SetBoundingBoxDirection4 Method (ISlicingData)

Sets bounding box direction 4 (bottom manipulator for linear slicing, outer radius for radial slicing).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetBoundingBoxDirection4( _  
    ByVal Direction As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISlicingData  
Dim Direction As System.Double  
Dim value As System.Boolean  
  
value = instance.SetBoundingBoxDirection4(Direction)
```

C#

```
System.bool SetBoundingBoxDirection4(  
    System.double Direction  
)
```

C++/CLI

```
System.bool SetBoundingBoxDirection4(  
& System.double Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

For linear slicing:

-500.0 < bottom manipulator < 0

For radial slicing:

Inner radius < outer radius < user-interface maximum for this case

(see **Remarks**)

Return Value

True if direction 4 of bounding box successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SlicingData::SetBoundingBoxDirection4](#).

Example

See the [ISlicingData](#) example.

Remarks

Use these methods to adjust the slicing volume to include or exclude geometry for slicing:

- [ISlicingData::SetBoundingBoxDirection1](#)
- [ISlicingData::SetBoundingBoxDirection2](#)
- [ISlicingData::SetBoundingBoxDirection3](#)

- `ISlicingData::SetBoundingBoxDirection4`

This method fails when:

- Direction exceeds the specified limits.
- The bounding box cannot be created because [ISlicingData::PlaneReferences](#) has not been set.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)
[ISlicingData::GetBoundingBoxDirection4 Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SlicesToGenerate Property (ISlicingData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlicingData Interface](#) : SlicesToGenerate Property (ISlicingData)

Gets or sets the slicing method.

.NET Syntax

Visual Basic (Declaration)

Property SlicesToGenerate As System.Integer

Visual Basic (Usage)



```
Dim instance As ISlicingData
Dim value As System.Integer

instance.SlicesToGenerate = value
value = instance.SlicesToGenerate
```

C#

```
System.int SlicesToGenerate {get; set;}
```

C++/CLI

```
property System.int SlicesToGenerate {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Slicing method as defined in [swSlicingTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [SlicingData::SlicesToGenerate](#).

Example

See the [ISlicingData](#) example.

See Also

[ISlicingData Interface](#)
[ISlicingData Members](#)

Availability

ISlotMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISlotMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISlotMateFeatureData Interface

Allows access to a slot mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISlotMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISlotMateFeatureData
```

C#

```
public interface ISlotMateFeatureData
```

C++/CLI

```
public interface class ISlotMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData](#).

Example

'VBA

' *****

' 1. Open *public_documents\samples\tutorial\api\Mechanical\Mates\slot_slot.sldasm*.

' 2. Run the macro.

' 3. Inspect the Mates folder of the FeatureManager design tree.

' *****

```
Dim swApp As SldWorks.SldWorks
```

```
Dim Part As SldWorks.ModelDoc2
```

```
Dim boolstatus As Boolean
```

```
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
```

```
    Set Part = swApp.ActiveDoc
```

```
    boolstatus = Part.Extension.SelectByRay(0.12649032355856, 0.133857958976421, 8.79467058769023E-03, 3.53905007657348E-02,  
0.579257713320296, 0.814375843216443, 2.14371287556113E-03, 2, True, 1, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(9.59257342875013E-02, 9.99222046038994E-02, -2.51429018803719E-02,  
3.53905007657348E-02, 0.579257713320296, 0.814375843216443, 2.14371287556113E-03, 2, True, 1, 0)
```

```
    ' Create SlotMateFeatureData
```

```
    Dim MateData As SldWorks.SlotMateFeatureData
```

```
    Set MateData = Part.CreateMateData(21)
```

```
    ' Set the entities to mate
```

```
    Dim EntitiesToMate(1) As Object
```

```
    Set EntitiesToMate(0) = Part.SelectionManager.GetSelectedObject6(1, -1)
```

```
    Set EntitiesToMate(1) = Part.SelectionManager.GetSelectedObject6(2, -1)
```

```
    Dim EntitiesToMateVar As Variant
```

```
    EntitiesToMateVar = EntitiesToMate
```

```
    MateData.EntitiesToMate = (EntitiesToMateVar)
```

```
    ' Set the mate alignment
```

```
    MateData.MateAlignment = 0
```

```
    ' Set the mate constraint
```

```
    MateData.Constraint = 0
```

```
' Create the mate
Dim MateFeature As SldWorks.Feature
Set MateFeature = Part.CreateMate(MateData)
Part.ClearSelection2 True
Part.EditRebuild3
End Sub
```

Example

[Create Slot Mate \(C#\)](#)

Remarks

A slot mate is a mate between:

- A bolt and either a straight slot or an arced slot.
- Two slots, straight or arced

[IMateFeatureData](#) is the parent of this mate interface.

To create a slot mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [ISlotMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectById2](#) to pre-select the entities using Mark = 1.
3. Specify other properties of the SlotMateFeatureData object, as required.

To edit a slot mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a SlotMateFeatureData object.
3. Modify the SlotMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this slot mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[SlotMateFeatureData](#)

See Also

[ISlotMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISlotMateFeatureData Interface Members

[See Also](#) [Properties](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISlotMateFeatureData Interface

The following tables list the members exposed by [ISlotMateFeatureData](#).

Public Properties

Name	Description
 Constraint	Gets or sets how to constrain the component in the slot of this slot mate.
 Distance	Gets or sets the distance from the end of the slot where to place the component axis in this slot mate.
 EntitiesToMate	Gets or sets the entities to mate in this slot mate feature.
 FlipDirection	Gets or sets whether to change the endpoint from where to measure distance.
 MateAlignment	Gets or sets the mate alignment of this slot mate.
 Percent	Gets or sets the percent of slot length where to place the component axis in this slot mate.

[Top](#)

See Also

[ISlotMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISlotMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISlotMateFeatureData Interface

For a list of all members of this type, see [ISlotMateFeatureData members](#).

Public Properties

Name	Description
 Constraint	Gets or sets how to constrain the component in the slot of this slot mate.
 Distance	Gets or sets the distance from the end of the slot where to place the component axis in this slot mate.
 EntitiesToMate	Gets or sets the entities to mate in this slot mate feature.
 FlipDirection	Gets or sets whether to change the endpoint from where to measure distance.
 MateAlignment	Gets or sets the mate alignment of this slot mate.
 Percent	Gets or sets the percent of slot length where to place the component axis in this slot mate.

[Top](#)

See Also

[ISlotMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Constraint Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : Constraint Property (ISlotMateFeatureData)

Gets or sets how to constrain the component in the slot of this slot mate.

.NET Syntax

Visual Basic (Declaration)

Property Constraint As System.Integer

Visual Basic (Usage)

 Copy Code

```
Dim instance As ISlotMateFeatureData
Dim value As System.Integer

instance.Constraint = value
value = instance.Constraint
```

C#

```
System.int Constraint {get; set;}
```

C++/CLI

```
property System.int Constraint {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Constraint option as defined in [swSlotMateConstraintOptions](#) e

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::Constraint](#).

Example

See the [ISlotMateFeatureData](#) example.

Remarks

If this property is set to `swSlotMateConstraintOptions_e`:

- `swSlotMateConstraintOption_Distance`, specify the [ISlotMateFeatureData::Distance](#) from the end of the slot where to place the component axis.
- `swSlotMateConstraintOption_Percent`, specify the distance as a [ISlotMateFeatureData::Percent](#) of the slot length where to place the component axis.

If this is a slot-to-slot mate, the only valid constraints are:

- `swSlotMateConstraintOptions_e.swSlotMateConstraintOption_Free`
- `swSlotMateConstraintOptions_e.swSlotMateConstraintOption_Centered`

To change the endpoint from which the distance is measured, set [ISlotMateFeatureData::FlipDirection](#) to true.

See Also

[ISlotMateFeatureData Interface](#)
[ISlotMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Distance Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : Distance Property (ISlotMateFeatureData)

Gets or sets the distance from the end of the slot where to place the component axis in this slot mate.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As ISlotMateFeatureData
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from the end of the slot

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::Distance](#).

Remarks

This property is valid only if [ISlotMateFeatureData::Constraint](#) is set to [swSlotMateConstraintOptions_e.swSlotMateConstraintOption_Distance](#).

To change the endpoint from which the distance is measured, set [ISlotMateFeatureData::FlipDirection](#) to true.

See Also

[ISlotMateFeatureData Interface](#)
[ISlotMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EntitiesToMate Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : EntitiesToMate Property (ISlotMateFeatureData)

Gets or sets the entities to mate in this slot mate feature.

.NET Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)



```
Dim instance As ISlotMateFeatureData  
Dim value As System.Object
```

```
instance.EntitiesToMate = value
```

```
value = instance.EntitiesToMate
```

C#

```
System.Object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of two entities to mate (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::EntitiesToMate](#).

Example

See the [ISlotMateFeatureData](#) example.

Remarks

Select the [face](#) of a straight or arced slot and another entity:

- Face of another straight or arced slot
- [Axis](#)
- Cylindrical face

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1. You can pre select mate entities during mate creation, but not during mate editing.

See Also

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipDirection Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : FlipDirection Property (ISlotMateFeatureData)

Gets or sets whether to change the endpoint from where to measure distance.

.NET Syntax

Visual Basic (Declaration)

Property FlipDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISlotMateFeatureData  
Dim value As System.Boolean
```

```
instance.FlipDirection = value
```

```
value = instance.FlipDirection
```

C#

```
System.bool FlipDirection {get; set;}
```

C++/CLI

```
property System.bool FlipDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to change the endpoint, false to not

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::FlipDirection](#).

See Also

[ISlotMateFeatureData Interface](#)
[ISlotMateFeatureData Members](#)
[ISlotMateFeatureData::Distance Property \(\)](#)
[ISlotMateFeatureData::Percent Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : MateAlignment Property (ISlotMateFeatureData)

Gets or sets the mate alignment of this slot mate.

.NET Syntax

```
Property MateAlignment As System.Integer
```



```
Dim instance As ISlotMateFeatureData
Dim value As System.Integer

instance.MateAlignment = value

value = instance.MateAlignment
```

```
System.int MateAlignment {get; set;}
```

```
property System.int MateAlignment {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::MateAlignment](#).

Example

See the [ISlotMateFeatureData](#) example.

See Also

[ISlotMateFeatureData Interface](#)
[ISlotMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

Percent Property (ISlotMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISlotMateFeatureData Interface](#) : Percent Property (ISlotMateFeatureData)

Gets or sets the percent of slot length where to place the component axis in this slot mate.

.NET Syntax

```
Property Percent As System.Double
```



```
Dim instance As ISlotMateFeatureData
Dim value As System.Double

instance.Percent = value

value = instance.Percent
```

C#

```
System.double Percent {get; set;}
```

C++/CLI

```
property System.double Percent {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Percent of slot length

Visual Basic for Applications (VBA) Syntax

See [SlotMateFeatureData::Percent](#).

Remarks

This property is valid only if [ISlotMateFeatureData::Constraint](#) is set to [swSlotMateConstraintOptions_e.swSlotMateConstraintOption_Percent](#). To change the endpoint from which the distance is measured, set [ISlotMateFeatureData::FlipDirection](#) to true.

See Also

[ISlotMateFeatureData Interface](#)
[ISlotMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

ISmartComponentFeatureData (Type)

ISmartComponentFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISmartComponentFeatureData Interface

Allows access to a Smart Component.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISmartComponentFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISmartComponentFeatureData
```

C#

```
public interface ISmartComponentFeatureData
```

C++/CLI

```
public interface class ISmartComponentFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SmartComponentFeatureData](#).

Example

[Delete Smart Feature \(VBA\)](#)
[Delete Smart Feature \(VB.NET\)](#)
[Delete Smart Feature \(C#\)](#)

Remarks

A Smart Component is defined by:

- Components
- Features
- Feature references

A Smart Component is created in a training assembly. When the Smart Component is saved, it is saved with the training assembly in a SOLIDWORKS part.

When the Smart Component is inserted or edited in a target assembly, the training assembly opens in a small preview window, and the PropertyManager page of the Smart Component displays.

See the SOLIDWORKS Help for more information about Smart Components.

Use...	To...
This interface	• Gain access to the training assembly of a Smart Component. • Gain access to the selection lists on the PropertyManager page of a Smart Component. • Insert features and components into a Smart Component. • Delete features and components from a Smart Component.
IComponent2::GetSmartComponentData	Get the current features, components, and feature references of a Smart Component.
IComponent2::SetSmartComponentData	Change which features and components to enable in a Smart Component and to insert Smart Features in a target assembly.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[SmartComponentFeatureData](#)

See Also

[ISmartComponentFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::ISmartComponent Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISmartComponentFeatureData Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISmartComponentFeatureData Interface

The following tables list the members exposed by [ISmartComponentFeatureData](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selection lists on the PropertyManager page of a Smart Component.
 ReleaseSelectionAccess	Releases access to the selection lists of a Smart Component.

[Top](#)

See Also

[ISmartComponentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::ISmartComponent Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISmartComponentFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISmartComponentFeatureData Interface

For a list of all members of this type, see [ISmartComponentFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selection lists on the PropertyManager page of a Smart Component.
 ReleaseSelectionAccess	Releases access to the selection lists of a Smart Component.

[Top](#)

See Also

[ISmartComponentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IComponent2::ISmartComponent Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ISmartComponentFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISmartComponentFeatureData Interface](#) : AccessSelections Method (ISmartComponentFeatureData)

Gains access to the selection lists on the PropertyManager page of a Smart Component.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal ShowPMP As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISmartComponentFeatureData  
Dim ShowPMP As System.Boolean
```



```
Dim value As System.Boolean

value = instance.AccessSelections(ShowPMP)
```

C#

```
System.bool AccessSelections(
    System.bool ShowPMP
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.bool ShowPMP
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowPMP

True to display the PropertyManager page, false to not (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SmartComponentFeatureData::AccessSelections](#).

Example

[Delete Smart Feature \(C#\)](#)
[Delete Smart Feature \(VB.NET\)](#)
[Delete Smart Feature \(VBA\)](#)

Remarks

ShowPMP only controls the display of the PropertyManager page. This method allows access to the PropertyManager page selection lists regardless of whether the PropertyManager page is displayed. The selection lists have marks as defined in [swSmartComponentSelectionTypes_e](#).

This method opens the training assembly in which this Smart Component is defined.

To delete a feature or component from a Smart Component:

1. Open the Smart Component in SOLIDWORKS.
2. Call [IFeature::GetDefinition](#) on the "Smart Feature" to get the [ISmartComponentFeatureData](#) object.
3. Call this method to open the training assembly of the Smart Component.
4. Call [ISldWorks::ActiveDoc](#) to set an assembly document variable.
5. To get a specific feature or component, call [ISelectionMgr::GetSelectedObject6](#)(index, mark), where mark is defined in [swSmartComponentSelectionTypes_e](#) and index is the position of the item in the selection list.
6. Select an already selected feature or component to delete it from its selection list. If the object returned by [ISelectionMgr::GetSelectedObject6](#) is a:
 - feature, call [IFeature::Select2](#) to delete that feature from the feature selection list.
 - component, call [IComponent2::Select4](#) to delete that component from the component selection list.
7. Close the training assembly and release access to the selection lists.

To insert a feature or component into a Smart Component:

1. Open the Smart Component in SOLIDWORKS.
2. Call [IFeature::GetDefinition](#) on the "Smart Feature" to get the [ISmartComponentFeatureData](#) object.
3. Call this method to open the training assembly of the Smart Component.
4. Call [ISldWorks::ActiveDoc](#) to point to the training assembly.
5. Call [IModelDocExtension::SelectByID2](#) to specify the feature or component you want to insert, setting Mark to an option in [swSmartComponentSelectionTypes_e](#).
6. Close the training assembly and release access to the selection lists.

To close the training assembly and release access to the selection lists on the PropertyManager page:

- Call [ISmartComponentFeatureData::ReleaseSelectionAccess](#) if you did not insert or delete features and components.
- Call [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) to rebuild the Smart Component if you inserted or deleted features and components.

See Also

[ISmartComponentFeatureData Interface](#)
[ISmartComponentFeatureData Members](#)

Availability

ReleaseSelectionAccess Method (ISmartComponentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISmartComponentFeatureData Interface](#) : ReleaseSelectionAccess Method (ISmartComponentFeatureData)

Releases access to the selection lists of a Smart Component.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISmartComponentFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SmartComponentFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISmartComponentFeatureData::AccessSelections](#) opens the training assembly in which this Smart Component is defined and allows access to the selection lists on the PropertyManager page of the SmartComponent.

To close the training assembly:

- Call this method if you did not insert or delete features and components.
- Call [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) to rebuild the Smart Component if you inserted or deleted features and components.

See Also

[ISmartComponentFeatureData Interface](#)
[ISmartComponentFeatureData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

ISMCornerReliefData (Type)

ISMCornerReliefData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMCornerReliefData Interface

Allows access to sheet metal corner relief data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISMCornerReliefData

Visual Basic (Usage)



Dim instance As [ISMCornerReliefData](#)

C#

public interface ISMCornerReliefData

C++/CLI

public interface class ISMCornerReliefData

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

For more information see the **SOLIDWORKS Design** user-interface help > Sheet Metal > Using Sheet Metal Tools > Corner Reliefs and Bend Transitions > Corner Relief **PropertyManager** topic.

Accessors

- [ICornerReliefFeatureData::AddNewCorner](#)
- [ICornerReliefFeatureData::CollectAllCorners](#)
- [ICornerReliefFeatureData::GetCornerAtIndex](#)
- [ICornerReliefFeatureData::GetCorners](#)

Access Diagram

[SMCornerReliefData](#)

See Also

- [ISMCornerReliefData Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

ISMCornerReliefData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMCornerReliefData Interface

The following tables list the members exposed by [ISMCornerReliefData](#).

Public Properties

Name	Description
 AddFilletedCorners	Gets and sets whether to fillet the corner relief corners.
 CenterOnBendLines	Gets and sets whether to center this corner relative to the bend lines.
 CornerFilletDiameter	Gets and sets the diameter of the filleted corner.
 CornerIndex	Gets the index of this corner in the corner relief feature.
 RatioToThickness	Gets and sets whether to use a ratio of length/width over sheet metal thickness to cut the bend area so that the body can be folded.
 ReliefType	Gets and sets the relief type of this corner.
 SlotLength	Gets and sets the length of this corner relief slot.
 SlotWidth	Gets and sets the width of this corner relief slot.
 SuitCaseType	Gets and sets the suitcase type of this corner relief slot.
 TangentToBend	Gets and sets whether to make the corner relief tangent to the inside bend edges.

[Top](#)

Public Methods

Name	Description
 GetFaces	Gets the faces used to create this sheet metal corner.

[Top](#)

See Also

[ISMCornerReliefData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISMCornerReliefData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMCornerReliefData Interface

For a list of all members of this type, see [ISMCornerReliefData members](#).

Public Methods

Name	Description
 GetFaces	Gets the faces used to create this sheet metal corner.

[Top](#)

See Also

[ISMCornerReliefData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISMCornerReliefData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMCornerReliefData Interface

For a list of all members of this type, see [ISMCornerReliefData members](#).

Public Properties

Name	Description
 AddFilletedCorners	Gets and sets whether to fillet the corner relief corners.
 CenterOnBendLines	Gets and sets whether to center this corner relative to the bend lines.
 CornerFilletDiameter	Gets and sets the diameter of the filleted corner.

	CornerIndex	Gets the index of this corner in the corner relief feature.
	RatioToThickness	Gets and sets whether to use a ratio of length/width over sheet metal thickness to cut the bend area so that the body can be folded.
	ReliefType	Gets and sets the relief type of this corner.
	SlotLength	Gets and sets the length of this corner relief slot.
	SlotWidth	Gets and sets the width of this corner relief slot.
	SuitCaseType	Gets and sets the suitcase type of this corner relief slot.
	TangentToBend	Gets and sets whether to make the corner relief tangent to the inside bend edges.

[Top](#)

See Also

[ISMCornerReliefData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddFillettedCorners Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : AddFillettedCorners Property (ISMCornerReliefData)

Gets and sets whether to fillet the corner relief corners.

.NET Syntax

Visual Basic (Declaration)

Property AddFillettedCorners As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData
Dim value As System.Boolean
```

```
instance.AddFillettedCorners = value
value = instance.AddFillettedCorners
```

C#

```
System.bool AddFillettedCorners {get; set;}
```

C++/CLI

```
property System.bool AddFillettedCorners {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fillet the corner relief corners, false to not

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::AddFillettedCorners](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e.swCornerRectangularRelief](#).

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)
[ISMCornerReliefData::CornerFilletDiameter Property \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenterOnBendLines Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : CenterOnBendLines Property (ISMCornerReliefData)

Gets and sets whether to center this corner relative to the bend lines.

Visual Basic Syntax

Visual Basic (Declaration)

Property CenterOnBendLines As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData  
Dim value As System.Boolean
```

```
instance.CenterOnBendLines = value
```

```
value = instance.CenterOnBendLines
```

C#

```
System.bool CenterOnBendLines {get; set;}
```

C++/CLI

```
property System.bool CenterOnBendLines {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to center relative to the bend lines, false to not

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::CenterOnBendLines](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if:

- [ICornerReliefFeatureData::CornerType](#) is set to [swCornerReliefBendType_e.swCornerReliefBendType_TwoBend](#)
- And -
- [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e](#):
 - swCornerCircularRelief
 - swCornerObroundRelief
 - swCornerRectangularRelief

See Also

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerFilletDiameter Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : CornerFilletDiameter Property (ISMCornerReliefData)

Gets and sets the diameter of the filleted corner.

.NET Syntax

Visual Basic (Declaration)

Property CornerFilletDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData  
Dim value As System.Double  
  
instance.CornerFilletDiameter = value  
value = instance.CornerFilletDiameter
```

C#

```
System.double CornerFilletDiameter {get; set;}
```

C++/CLI

```
property System.double CornerFilletDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::CornerFilletDiameter](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if:

- [ISMCornerReliefData::AddFilletCornerRadius](#) is true,
- And -
- [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e.swCornerRectangularRelief](#).

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

CornerIndex Property (ISMCornerReliefData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : CornerIndex Property (ISMCornerReliefData)

Gets the index of this corner in the corner relief feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CornerIndex As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData  
Dim value As System.Integer  
  
value = instance.CornerIndex
```

C#

```
System.int CornerIndex {get;}
```

C++/CLI

```
property System.int CornerIndex {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

One-based index of this corner

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::CornerIndex](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

GetFaces Method (ISMCornerReliefData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : GetFaces Method (ISMCornerReliefData)

Gets the faces used to create this sheet metal corner.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFaces( _  
    ByRef Face1 As System.Object, _
```

```

ByRef Face2 As System.Object, _
ByRef Face3 As System.Object _
)

```

Visual Basic (Usage)



```

Dim instance As ISMCornerReliefData
Dim Face1 As System.Object
Dim Face2 As System.Object
Dim Face3 As System.Object

instance.GetFaces(Face1, Face2, Face3)

```

C#

```

void GetFaces(
    out System.object Face1,
    out System.object Face2,
    out System.object Face3
)

```

C++/CLI

```

void GetFaces(
    & [Out] System.Object^ Face1,
    & [Out] System.Object^ Face2,
    & [Out] System.Object^ Face3
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Face1

First [IFace2](#) that defines this two- or three-bend corner

Face2

Second [IFace2](#) that defines this two- or three-bend corner

Face3

Third [IFace2](#) that defines this three-bend corner; valid only if [ICornerReliefFeatureData::CornerReliefBendType](#) is [swCornerReliefBendType_e.swCornerReliefBendType_ThreeBend](#); specify nu or Nothing for a two-bend corner

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::GetFaces](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ISMCornerReliefData Interface](#)

[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

RatioToThickness Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : RatioToThickness Property (ISMCornerReliefData)

Gets and sets whether to use a ratio of length/width over sheet metal thickness to cut the bend area so that the body can be folded.

.NET Syntax

Visual Basic (Declaration)

Property RatioToThickness As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData
Dim value As System.Boolean

instance.RatioToThickness = value

value = instance.RatioToThickness
```

C#

```
System.bool RatioToThickness {get; set;}
```

C++/CLI

```
property System.bool RatioToThickness {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use a ratio value to cut the bend area, false to not

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::RatioToThickness](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e](#):

- [swCornerCircularRelief](#)
- [swCornerObroundRelief](#)
- [swCornerRectangularRelief](#)

If [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e.swCornerRectangularRelief](#).

Then the calculated ratio(s) is(are)...

[swCornerCircularRelief](#)

slot length / thickness of sheet metal

[swCornerRectangularRelief](#)

slot length / thickness of sheet metal

[swCornerObroundRelief](#)

slot length / thickness of sheet metal

- And -

slot width / thickness of sheet metal

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefType Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : ReliefType Property (ISMCornerReliefData)

Gets and sets the relief type of this corner.

Visual Basic Syntax

Visual Basic (Declaration)

Property ReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData
Dim value As System.Integer

instance.ReliefType = value
value = instance.ReliefType
```

C#

System.int ReliefType {get; set;}

C++/CLI

```
property System.int ReliefType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner relief type as defined by [swCornerReliefType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ISMCornerReliefData::ReliefType](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SlotLength Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : SlotLength Property (ISMCornerReliefData)

Gets and sets the length of this corner relief slot.

Visual Basic Syntax

Visual Basic (Declaration)

Property SlotLength As System.Double

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData
Dim value As System.Double
```

```
instance.SlotLength = value  
value = instance.SlotLength
```

C#

```
System.double SlotLength {get; set;}
```

C++/CLI

```
property System.double SlotLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length

Visual Basic for Applications (VBA) Syntax

See [ISMCornerReliefData::SlotLength](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e](#):

- swCornerRectangularRelief
- swCornerObroundRelief

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SlotWidth Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : SlotWidth Property (ISMCornerReliefData)

Gets and sets the width of this corner relief slot.

.NET Syntax

Visual Basic (Declaration)

```
Property SlotWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData  
Dim value As System.Double  
  
instance.SlotWidth = value  
value = instance.SlotWidth
```

C#

```
System.double SlotWidth {get; set;}
```

C++/CLI

```
property System.double SlotWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner relief slot width (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::SlotWidth](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if [ISMCornerReliefData::ReliefType](#) is set to one of the following [swCornerReliefType_e](#) members. If...:

- swCornerCircularRelief, then this property returns a radial slot width value.
- swCornerObroundRelief, then this property returns a linear slot width value.

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SuitCaseType Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : SuitCaseType Property (ISMCornerReliefData)

Gets and sets the suitcase type of this corner relief slot.

.NET Syntax

Visual Basic (Declaration)

```
Property SuitCaseType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData  
Dim value As System.Integer  
  
instance.SuitCaseType = value  
  
value = instance.SuitCaseType
```

C#

```
System.int SuitCaseType {get; set;}
```

C++/CLI

```
property System.int SuitCaseType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner relief suitcase type as defined by [swCornerReliefSuitCaseType](#) e

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::SuitCaseType](#).

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

TangentToBend Property (ISMCornerReliefData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMCornerReliefData Interface](#) : TangentToBend Property (ISMCornerReliefData)

Gets and sets whether to make the corner relief tangent to the inside bend edges.

.NET Syntax

Visual Basic (Declaration)

```
Property TangentToBend As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMCornerReliefData
Dim value As System.Boolean
```

```
instance.TangentToBend = value
```

```
value = instance.TangentToBend
```

C#

```
System.bool TangentToBend {get; set;}
```

C++/CLI

```
property System.bool TangentToBend {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to make the corner relief tangent to the inside bend edges, false to not

Visual Basic for Applications (VBA) Syntax

See [SMCornerReliefData::TangentToBend](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

This property is valid only if:

- [ICornerReliefFeatureData::CornerType](#) is set to [swCornerReliefBendType_e](#).swCornerReliefBendType_TwoBend
- And -
- [ISMCornerReliefData::ReliefType](#) is set to [swCornerReliefType_e](#):
 - swCornerCircularRelief
 - swCornerRectangularRelief

See Also

[ISMCornerReliefData Interface](#)
[ISMCornerReliefData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30