

SOLIDWORKS API (NET VBA C#) — Reference

(290/337): ISMGussetFeatureData- ISMNormalCutFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISMGussetFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISMGussetFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMGussetFeatureData Interface

Allows access to a sheet metal gusset feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISMGussetFeatureData

Visual Basic (Usage)



Dim instance As [ISMGussetFeatureData](#)

C#

public interface ISMGussetFeatureData

C++/CLI

public interface class ISMGussetFeatureData

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData](#).

Example

'VBA

'-----
' Preconditions:
' 1. Open *public_documents\samples\tutorial\api\ISMGussetAPI.sldprt*.
' 2. Open an Immediate window.

' Postconditions:
' 1. Inserts **Sheet Metal Gusset1**.
' 2. Press F5 and observe the modified gusset.
' 3. Inspect the Immediate window for the flatten settings of the gusset.
' 4. Expand Flat-Pattern in the FeatureManager design tree, right-click
' **Flat-Pattern(1)**, and click Unsuppress.
' 5. Observe the center mark and profile of the gusset in its
' flattened state.

' NOTE: Because the model is used elsewhere, do not save changes.
'-----

```
Dim swApp As SldWorks.SldWorks
Dim Part As SldWorks.ModelDoc2
Dim myFeature As SldWorks.Feature
Dim swFeat As SldWorks.Feature
Dim swFeatData As SldWorks.SMGussetFeatureData
Dim boolstatus As Boolean
Option Explicit
Sub main()
    Set swApp = Application.SldWorks
    Set Part = swApp.ActiveDoc
```

```
    boolstatus = Part.Extension.SelectByID2("", "FACE", -5.38403893476698E-02, 3.6701308754914E-03, 0.05530817474488, False, 0, Nothing
0)
    boolstatus = Part.Extension.SelectByID2("", "FACE", -1.77780871801474E-02, -3.07393226379986E-02, 3.41128529187245E-02, True, 0,
Nothing, 0)
```

```
    Set swFeatData = Part.FeatureManager.CreateDefinition(swFeatureNameID_e.swFmSMGusset)
    swFeatData.UseOffset = True
    swFeatData.OffsetDistance = 0.05
```

```

swFeatData.FlipOffset = False
swFeatData.ProfileDimensionScheme = swSheetMetalGussetProfileDimType_e.swSheetMetalGussetProfileDimType_IndentDepth
swFeatData.IndentDepth = 0.01
swFeatData.ProfileLengthDim = 0#
swFeatData.UseAngleDimForProfile = False
swFeatData.ProfileHeightDim = 0#
swFeatData.ProfileAngleDim = 0#
swFeatData.FlipDimSides = False
swFeatData.IndentWidth = 0.01
swFeatData.GussetThickness = 0.003
swFeatData.DraftAngle = 3 * 0.0175
swFeatData.DraftSideFaces = True
swFeatData.FilletInnerCorners = True
swFeatData.InnerCornerFilletRadius = 0.002
swFeatData.FilletOuterCorners = True
swFeatData.OuterCornerFilletRadius = 0.001
swFeatData.GussetType = swSheetMetalRibGussetType_e.swSheetMetalRibGussetType_Rounded
swFeatData.FilletGussetEdges = False
swFeatData.EdgeFilletRadius = 0#
swFeatData.OverrideDocSettings = True
swFeatData.ShowProfile = True
swFeatData.ShowCenter = True

```

```

Set myFeature = Part.FeatureManager.CreateFeature(swFeatData)
Part.ClearSelection2 True

```

Stop

```

'Modify type, draft, and outer corner fillet properties of the gusset
boolstatus = Part.Extension.SelectByID2("Sheet Metal Gusset1", "BODYFEATURE", 0, 0, 0, False, 0, Nothing, 0)
Set swFeat = Part.SelectionManager.GetSelectedObject6(1, -1)

```

```

Set swFeatData = swFeat.GetDefinition
swFeatData.AccessSelections Part, Nothing
swFeatData.GussetType = swSheetMetalRibGussetType_e.swSheetMetalRibGussetType_Flat
swFeatData.DraftSideFaces = False
swFeatData.FilletOuterCorners = False
Debug.Print "Sheet Metal Gusset1 Flatten Settings"
Debug.Print " Override document flat pattern properties? " & swFeatData.OverrideDocSettings
Debug.Print " Show center marks of the gusset in its flattened state? " & swFeatData.ShowCenter
Debug.Print " Show profile of the gusset in its flattened state? " & swFeatData.ShowProfile

```

```

swFeat.ModifyDefinition swFeatData, Part, Nothing
swFeatData.ReleaseSelectionAccess

```

End Sub

Example

[Create Sheet Metal Gusset \(VB.NET\)](#)
[Create Sheet Metal Gusset \(C#\)](#)

Remarks

To create a sheet metal gusset feature:

1. Call [IFeatureManager::CreateDefinition](#) to instantiate this feature data object.
2. Pre-select faces, lines, edges, vertices, or points as follows:

To...	Call ModelDocExtension::SelectByID2 to select...
Specify the legs of the gusset feature	Two flat faces of a bend.
- Or -	
	Two flat faces adjacent to a cylindrical bend face.
- Or -	
	One cylindrical bend face.
- Or -	
	One flat face and one non-planar face adjacent to a toroidal bend.
- Or -	
	One toroidal bend face.

To...	Call IModelDocExtension::SelectByID2 to select...
Optionally orient the gusset section plane	One linear edge or sketch segment that is perpendicular to the gusset section plane. If you do not pre-select either entity, then the bend line adjacent to the gusset legs is used as the reference.
Optionally position the gusset section plane	One vertex, sketch point, or reference point. If you do not pre-select any of these entities, then you must set ISMGussetFeatureData::UseOffset to true and specify ISMGussetFeatureData::OffsetDistance to define the reference point. For insertion of the first gusset, the assumed reference point is on the end of the sheet metal bend. For second and subsequent gusset insertions, the assumed reference point is on the edge of the gusset last inserted.

3. Specify [ISMGussetFeatureData::ProfileDimensionScheme](#) and modify other properties on this feature data object as follows:

If ISMGussetFeatureData::ProfileDimensionScheme= swSheetMetalGussetProfileDimType_e. swSheetMetalGussetProfileDimType_ProfileDimensions, to dimension the gusset profile using...	
Specify ISMGussetFeatureData::...	
Both legs of the gusset	• ProfileLengthDim for d1 leg • ProfileHeightDim for d2 leg • UseAngleDimForProfile = false • FlipDimSides = true to swap d1 and d2 legs during dimensioning
d1 leg and the angle it forms with the gusset	• ProfileLengthDim for d1 leg • ProfileAngleDim of angle formed by gusset intersecting d1 leg • UseAngleDimForProfile = true • FlipDimSides = true to swap d1 and d2 legs during dimensioning
d2 leg and the angle it forms with the gusset	• ProfileHeightDim for d2 leg • ProfileAngleDim of angle formed by gusset intersecting d2 leg • UseAngleDimForProfile = true • FlipDimSides = true to swap d1 and d2 legs during dimensioning

4. Call [IFeatureManager::CreateFeature](#).

For more information, see the **SOLIDWORKS Design user-interface help > Sheet Metal > Using Sheet Metal Tools > Adding Sheet Metal Gussets > Sheet Metal Gusset PropertyManager** topic.

 Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

 Access Diagram

[SMGussetFeatureData](#)

 See Also

[ISMGussetFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalGussetFeature Method \(\)](#)
[IFeatureManager::InsertSheetMetalGussetFeature2 Method \(\)](#)

ISMGussetFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISMGussetFeatureData Interface

For a list of all members of this type, see [ISMGussetFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to a sheet metal gusset.
 ReleaseSelectionAccess	Releases access to the selections that define this sheet metal gusset feature.

[Top](#)

 See Also

[ISMGussetFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalGussetFeature Method \(\)](#)
[IFeatureManager::InsertSheetMetalGussetFeature2 Method \(\)](#)

ISMGussetFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMGussetFeatureData Interface

The following tables list the members exposed by [ISMGussetFeatureData](#).

Public Properties

Name	Description
DraftAngle	Gets or sets the angle by which to draft the side faces of this gusset.
DraftSideFaces	Gets or sets whether to draft the side faces of this gusset.
EdgeFilletRadius	Gets or sets the fillet radius of edges in this flat-back gusset.
FilletGussetEdges	Gets or sets whether to fillet the edges of this gusset.
FilletInnerCorners	Gets or sets whether to fillet the inner corners of this gusset.
FilletOuterCorners	Gets or sets whether to fillet the outer corners of this gusset.
FlipDimSides	Gets or sets whether to swap the gusset legs in the dimensioning scheme.
FlipOffset	Gets or sets whether to offset the gusset section plane on the opposite side of the specified reference point .
GussetThickness	Gets or sets the indent thickness of this gusset.
GussetType	Gets or sets the type of this gusset.
IndentDepth	Gets or sets the indent depth of this gusset.
IndentWidth	Gets or sets the indent width of this gusset.
InnerCornerFilletRadius	Gets or sets the fillet radius for the inner corners of this gusset.
OffsetDistance	Gets or sets the offset of the gusset's section plane from a specified reference point .
OuterCornerFilletRadius	Gets or sets the fillet radius for the outer corners of this gusset.
OverrideDocSettings	Gets or sets whether to override the document flat pattern properties.
ProfileAngleDim	Gets or sets the angle formed by the intersection of this gusset with one face adjacent to the bend of the sheet metal part.
ProfileDimensionScheme	Gets or sets the type of profile dimensioning scheme for this gusset.
ProfileHeightDim	Gets or sets the length of the d2 leg of this gusset.
ProfileLengthDim	Gets or sets the length of the d1 leg of this gusset.
ProfileType	Gets or sets the type of profile of this gusset feature.
ReferenceLine	Gets or sets the orientation reference for this gusset's section plane.
ReferencePoint	Gets or sets a position reference for this gusset.
ShowCenter	Gets or sets whether to display the center marks of the gusset in its flattened state.
ShowProfile	Gets or sets whether to display the profile of the gusset in its flattened state.
SupportingFaces	Gets or sets the legs of this gusset.
UseAngleDimForProfile	Gets or sets whether to dimension this gusset using an angle.
UseOffset	Gets or sets whether to offset the gusset section plane from a specified reference point .

[Top](#)

Public Methods

Name	Description
AccessSelections	Gains access to a sheet metal gusset.
ReleaseSelectionAccess	Releases access to the selections that define this sheet metal gusset feature.

[Top](#)

See Also

ISMGussetFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISMGussetFeatureData Interface

For a list of all members of this type, see [ISMGussetFeatureData members](#).

Public Properties

Name	Description
 DraftAngle	Gets or sets the angle by which to draft the side faces of this gusset.
 DraftSideFaces	Gets or sets whether to draft the side faces of this gusset.
 EdgeFilletRadius	Gets or sets the fillet radius of edges in this flat-back gusset.
 FilletGussetEdges	Gets or sets whether to fillet the edges of this gusset.
 FilletInnerCorners	Gets or sets whether to fillet the inner corners of this gusset.
 FilletOuterCorners	Gets or sets whether to fillet the outer corners of this gusset.
 FlipDimSides	Gets or sets whether to swap the gusset legs in the dimensioning scheme.
 FlipOffset	Gets or sets whether to offset the gusset section plane on the opposite side of the specified reference point .
 GussetThickness	Gets or sets the indent thickness of this gusset.
 GussetType	Gets or sets the type of this gusset.
 IndentDepth	Gets or sets the indent depth of this gusset.
 IndentWidth	Gets or sets the indent width of this gusset.
 InnerCornerFilletRadius	Gets or sets the fillet radius for the inner corners of this gusset.
 OffsetDistance	Gets or sets the offset of the gusset's section plane from a specified reference point .
 OuterCornerFilletRadius	Gets or sets the fillet radius for the outer corners of this gusset.
 OverrideDocSettings	Gets or sets whether to override the document flat pattern properties.
 ProfileAngleDim	Gets or sets the angle formed by the intersection of this gusset with one face adjacent to the bend of the sheet metal part.
 ProfileDimensionScheme	Gets or sets the type of profile dimensioning scheme for this gusset.
 ProfileHeightDim	Gets or sets the length of the d2 leg of this gusset.
 ProfileLengthDim	Gets or sets the length of the d1 leg of this gusset.
 ProfileType	Gets or sets the type of profile of this gusset feature.
 ReferenceLine	Gets or sets the orientation reference for this gusset's section plane.
 ReferencePoint	Gets or sets a position reference for this gusset.
 ShowCenter	Gets or sets whether to display the center marks of the gusset in its flattened state.
 ShowProfile	Gets or sets whether to display the profile of the gusset in its flattened state.
 SupportingFaces	Gets or sets the legs of this gusset.
 UseAngleDimForProfile	Gets or sets whether to dimension this gusset using an angle.
 UseOffset	Gets or sets whether to offset the gusset section plane from a specified reference point .

[Top](#)

See Also

[ISMGussetFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalGussetFeature Method \(\)](#)
[IFeatureManager::InsertSheetMetalGussetFeature2 Method \(\)](#)

AccessSelections Method (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : AccessSelections Method (ISMGussetFeatureData)

Gains access to a sheet metal gusset.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component for the feature

Return Value

True if the selections where successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::AccessSelections](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ISMGussetFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftAngle Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : DraftAngle Property (ISMGussetFeatureData)

Gets or sets the angle by which to draft the side faces of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.DraftAngle = value
```

```
value = instance.DraftAngle
```

C#

```
System.double DraftAngle {get; set;}
```

C++/CLI

```
property System.double DraftAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle in radians

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::DraftAngle](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::DraftSideFaces](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

DraftSideFaces Property (ISMGussetFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : DraftSideFaces Property (ISMGussetFeatureData)

Gets or sets whether to draft the side faces of this gusset.

.NET Syntax

Visual Basic (Declaration)

Property DraftSideFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Boolean
```

```
instance.DraftSideFaces = value
```

```
value = instance.DraftSideFaces
```

C#

```
System.bool DraftSideFaces {get; set;}
```

C++/CLI

```
property System.bool DraftSideFaces {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to draft the gusset side faces, false to not

Visual Basic for Applications (VBA) Syntax

See [ISMGussetFeatureData::DraftSideFaces](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

After setting this property to true, set [ISMGussetFeatureData::DraftAngle](#).

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

EdgeFilletRadius Property (ISMGussetFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : EdgeFilletRadius Property (ISMGussetFeatureData)

Gets or sets the fillet radius of edges in this flat-back gusset.

Visual Basic Syntax

Visual Basic (Declaration)

Property EdgeFilletRadius As System.Double

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.EdgeFilletRadius = value
```

```
value = instance.EdgeFilletRadius
```

C#

```
System.double EdgeFilletRadius {get; set;}
```

C++/CLI

```
property System.double EdgeFilletRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gusset edge fillet radius

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::EdgeFilletRadius](#).

Remarks

This property is valid only if [ISMGussetFeatureData::FilletGussetEdges](#) is true and [ISMGussetFeatureData::GussetType](#) is set to 1.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FilletGussetEdges Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : FilletGussetEdges Property (ISMGussetFeatureData)

Gets or sets whether to fillet the edges of this gusset.

Visual Basic Syntax

Visual Basic (Declaration)

Property FilletGussetEdges As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean
```

```
instance.FilletGussetEdges = value  
value = instance.FilletGussetEdges
```

C#

```
System.bool FilletGussetEdges {get; set;}
```

C++/CLI

```
property System.bool FilletGussetEdges {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fillet the edges of this gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [ISMGussetFeatureData::FilletGussetEdges](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::GussetType](#) is set to 1.

After setting this property, set [ISMGussetFeatureData::EdgeFilletRadius](#).

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FilletInnerCorners Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : FilletInnerCorners Property (ISMGussetFeatureData)

Gets or sets whether to fillet the inner corners of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property FilletInnerCorners As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean
```

```
instance.FilletInnerCorners = value
```

```
value = instance.FilletInnerCorners
```

C#

```
System.bool FilletInnerCorners {get; set;}
```

C++/CLI

```
property System.bool FilletInnerCorners {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fillet the inner corners of this gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::FilletInnerCorners](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

After setting this property, set [ISMGussetFeatureData::InnerCornerFilletRadius](#).

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::FilletOuterCorners Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FilletOuterCorners Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : FilletOuterCorners Property (ISMGussetFeatureData)

Gets or sets whether to fillet the outer corners of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property FilletOuterCorners As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean
```

```
instance.FilletOuterCorners = value
```

```
value = instance.FilletOuterCorners
```

C#

```
System.bool FilletOuterCorners {get; set;}
```

C++/CLI

```
property System.bool FilletOuterCorners {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fillet the outer corners of this gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::FilletOuterCorners](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

After setting this property, set [ISMGussetFeatureData::OuterCornerFilletRadius](#).

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::FilletInnerCorners Property_0](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlipDimSides Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : FlipDimSides Property (ISMGussetFeatureData)

Gets or sets whether to swap the gusset legs in the dimensioning scheme.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipDimSides As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean
```

```
instance.FlipDimSides = value
```

```
value = instance.FlipDimSides
```

C#

```
System.bool FlipDimSides {get; set;}
```

C++/CLI

```
property System.bool FlipDimSides {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to swap the gusset legs in the dimensioning scheme, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::FlipDimSides](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

[ISMGussetFeatureData::ProfileHeightDim](#) corresponds to the d2 leg and [ISMGussetFeatureData::ProfileLengthDim](#) corresponds to the d1 leg in the dimensioning scheme. This property allows you to swap the d2 and d1 legs in order to change the gusset dimension profile.

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ProfileAngleDim Property \(\)](#)
[ISMGussetFeatureData::ProfileDimensionScheme Property \(\)](#)
[ISMGussetFeatureData::UseAngleDimForProfile Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipOffset Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : FlipOffset Property (ISMGussetFeatureData)

Gets or sets whether to offset the gusset section plane on the opposite side of the specified [reference point](#).

.NET Syntax

Visual Basic (Declaration)

```
Property FlipOffset As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean  
  
instance.FlipOffset = value  
  
value = instance.FlipOffset
```

C#

```
System.bool FlipOffset {get; set;}
```

C++/CLI

```
property System.bool FlipOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the gusset section plane on the opposite side of the reference point, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::FlipOffset](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::UseOffset](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::OffsetDistance Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GussetThickness Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : GussetThickness Property (ISMGussetFeatureData)

Gets or sets the indent thickness of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property GussetThickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.GussetThickness = value
```

```
value = instance.GussetThickness
```

C#

```
System.double GussetThickness {get; set;}
```

C++/CLI

```
property System.double GussetThickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Indent thickness

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::GussetThickness](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 0.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GussetType Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : GussetType Property (ISMGussetFeatureData)

Gets or sets the type of this gusset.

.NET Syntax

Visual Basic (Declaration)

Property GussetType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Integer
```

```
instance.GussetType = value
```

```
value = instance.GussetType
```

C#

```
System.int GussetType {get; set;}
```

C++/CLI

```
property System.int GussetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of gusset as defined in [swSheetMetalRibGussetType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::GussetType](#).

Example

See the examples for [ISMGussetFeatureData](#).

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::EdgeFilletRadius Property \(\)](#)
[ISMGussetFeatureData::FilletGussetEdges Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

IndentDepth Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : IndentDepth Property (ISMGussetFeatureData)

Gets or sets the indent depth of this gusset.

.NET Syntax

Visual Basic (Declaration)

Property IndentDepth As System.Double

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.IndentDepth = value
```

```
value = instance.IndentDepth
```

C#

```
System.double IndentDepth {get; set;}
```

C++/CLI

```
property System.double IndentDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Indent depth

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::IndentDepth](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 0.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

IndentWidth Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : IndentWidth Property (ISMGussetFeatureData)

Gets or sets the indent width of this gusset.

.NET Syntax

Visual Basic (Declaration)

Property IndentWidth As System.Double

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.IndentWidth = value
```

```
value = instance.IndentWidth
```

C#

```
System.double IndentWidth {get; set;}
```

C++/CLI

```
property System.double IndentWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Indent width

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::IndentWidth](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 0.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InnerCornerFilletRadius Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : InnerCornerFilletRadius Property (ISMGussetFeatureData)

Gets or sets the fillet radius for the inner corners of this gusset.

.NET Syntax

Visual Basic (Declaration)

Property InnerCornerFilletRadius As System.Double

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Double

instance.InnerCornerFilletRadius = value

value = instance.InnerCornerFilletRadius
```

C#

```
System.double InnerCornerFilletRadius {get; set;}
```

C++/CLI

```
property System.double InnerCornerFilletRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Inner corner fillet radius

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData.InnerCornerFilletRadius](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData.FilletInnerCorners](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData.OuterCornerFilletRadius Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : OffsetDistance Property (ISMGussetFeatureData)

Gets or sets the offset of the gusset's section plane from a specified [reference point](#).

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gusset section plane offset

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::OffsetDistance](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::UseOffset](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::FlipOffset_Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OuterCornerFilletRadius Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : OuterCornerFilletRadius Property (ISMGussetFeatureData)

Gets or sets the fillet radius for the outer corners of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property OuterCornerFilletRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Double

instance.OuterCornerFilletRadius = value

value = instance.OuterCornerFilletRadius
```

C#

```
System.double OuterCornerFilletRadius {get; set;}
```

C++/CLI

```
property System.double OuterCornerFilletRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Outer corner fillet radius

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::OuterCornerFilletRadius](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::FilletOuterCorners](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::InnerCornerFilletRadius Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDocSettings Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : OverrideDocSettings Property (ISMGussetFeatureData)

Gets or sets whether to override the document flat pattern properties.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideDocSettings As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Boolean

instance.OverrideDocSettings = value
value = instance.OverrideDocSettings
```

C#

```
System.bool OverrideDocSettings {get; set;}
```

C++/CLI

```
property System.bool OverrideDocSettings {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the document flat pattern settings, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::OverrideDocSettings](#).

Example

See the [ISMGussetFeatureData](#) examples.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ShowCenter Property \(\)](#)
[ISMGussetFeatureData::ShowProfile Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileAngleDim Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ProfileAngleDim Property (ISMGussetFeatureData)

Gets or sets the angle formed by the intersection of this gusset with one face adjacent to the bend of the sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileAngleDim As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Double

instance.ProfileAngleDim = value
value = instance.ProfileAngleDim
```

C#

```
System.double ProfileAngleDim {get; set;}
```

C++/CLI

```
property System.double ProfileAngleDim {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle formed where gusset intersects the sheet metal part

Visual Basic for Applications (VBA) Syntax

See [ISMGussetFeatureData::ProfileAngleDim](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::UseAngleDimForProfile](#) is true and [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 1.

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ProfileHeightDim Property \(\)](#)
[ISMGussetFeatureData::ProfileLengthDim Property \(\)](#)
[ISMGussetFeatureData::FlipDimSides Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileDimensionScheme Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ProfileDimensionScheme Property (ISMGussetFeatureData)

Gets or sets the type of profile dimensioning scheme for this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileDimensionScheme As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Integer

instance.ProfileDimensionScheme = value

value = instance.ProfileDimensionScheme
```

C#

```
System.int ProfileDimensionScheme {get; set;}
```

C++/CLI

```
property System.int ProfileDimensionScheme {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of gusset profile dimensioning scheme as defined in [swSheetMetalGussetProfileDimType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ProfileDimensionScheme](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ProfileAngleDim Property \(\)](#)
[ISMGussetFeatureData::ProfileHeightDim Property \(\)](#)
[ISMGussetFeatureData::ProfileLengthDim Property \(\)](#)
[ISMGussetFeatureData::FlipDimSides Property \(\)](#)
[ISMGussetFeatureData::UseAngleDimForProfile Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileHeightDim Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ProfileHeightDim Property (ISMGussetFeatureData)

Gets or sets the length of the d2 leg of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileHeightDim As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.ProfileHeightDim = value
```

```
value = instance.ProfileHeightDim
```

C#

```
System.double ProfileHeightDim {get; set;}
```

C++/CLI

```
property System.double ProfileHeightDim {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of d2 leg

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ProfileHeightDim](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 1.

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ProfileAngleDim Property \(\)](#)
[ISMGussetFeatureData::ProfileLengthDim Property \(\)](#)
[ISMGussetFeatureData::FlipDimSides Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileLengthDim Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ProfileLengthDim Property (ISMGussetFeatureData)

Gets or sets the length of the d1 leg of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileLengthDim As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Double
```

```
instance.ProfileLengthDim = value
```

```
value = instance.ProfileLengthDim
```

C#

```
System.double ProfileLengthDim {get; set;}
```

C++/CLI

```
property System.double ProfileLengthDim {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of d1 leg

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ProfileLengthDim](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 1.

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::FlipDimSides Property\(\)](#)
[ISMGussetFeatureData::ProfileAngleDim Property\(\)](#)
[ISMGussetFeatureData::ProfileHeightDim Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileType Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ProfileType Property (ISMGussetFeatureData)

Gets or sets the type of profile of this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Integer
```

```
instance.ProfileType = value
```

```
value = instance.ProfileType
```

C#

```
System.int ProfileType {get; set;}
```

C++/CLI

```
property System.int ProfileType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of profile as defined in [swSheetMetalGussetProfileType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ProfileType](#).

Remarks

This property is valid only when editing an existing sheet metal gusset.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceLine Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ReferenceLine Property (ISMGussetFeatureData)

Gets or sets the orientation reference for this gusset's section plane.

.NET Syntax

Visual Basic (Declaration)

Property ReferenceLine As System.Object

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Object
```

```
instance.ReferenceLine = value
```

```
value = instance.ReferenceLine
```

C#

```
System.Object ReferenceLine {get; set;}
```

C++/CLI

```
property System.Object^ ReferenceLine {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line (e.g., [edge](#), [co-Edge](#), or [sketch segment](#)) that is perpendicular to this gusset's section plane

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ReferenceLine](#).

Example

See the [IFeatureManager::InsertSheetMetalGussetFeature3](#) examples.

Remarks

If you do not set this property, the assumed reference line is the bend line adjacent to the entities in [ISMGussetFeatureData::SupportingFaces](#).

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ReferencePoint Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferencePoint Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ReferencePoint Property (ISMGussetFeatureData)

Gets or sets a position reference for this gusset.

Visual Basic Syntax

Visual Basic (Declaration)

Property ReferencePoint As System.Object

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Object
```

```
instance.ReferencePoint = value
```

```
value = instance.ReferencePoint
```

C#

```
System.object ReferencePoint {get; set;}
```

C++/CLI

```
property System.Object^ ReferencePoint {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Point (e.g., [vertex](#), [sketch point](#), or [reference point](#)) where to position this gusset

Visual Basic for Applications (VBA) Syntax

See [ISMGussetFeatureData::ReferencePoint](#).

Example

See the [IFeatureManager::InsertSheetMetalGussetFeature3](#) examples.

Remarks

If you do not set this property, you must set [ISMGussetFeatureData::UseOffset](#) and [ISMGussetFeatureData::OffsetDistance](#) to offset the gusset from an assumed reference point. For insertion of the first gusset, the assumed reference point is on the end of the sheet metal bend. For second and subsequent gusset insertions, the assumed reference point is on the edge of the gusset last inserted.

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ReferenceLine Property \(\)](#)
[ISMGussetFeatureData::SupportingFaces Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

ReleaseSelectionAccess Method (ISMGussetFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ReleaseSelectionAccess Method (ISMGussetFeatureData)

Releases access to the selections that define this sheet metal gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ReleaseSelectionAccess](#).

Example

See the examples for [ISMGussetFeatureData](#).

Remarks

[ISMGussetFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did modify the feature.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

ShowCenter Property (ISMGussetFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ShowCenter Property (ISMGussetFeatureData)

Gets or sets whether to display the center marks of the gusset in its flattened state.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowCenter As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISMGussetFeatureData
Dim value As System.Boolean

instance.ShowCenter = value

value = instance.ShowCenter
```

C#

```
System.bool ShowCenter {get; set;}
```

C++/CLI

```
property System.bool ShowCenter {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the center marks of the flattened gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ShowCenter](#).

Example

See the [ISMGussetFeatureData](#) examples.

Remarks

This property is valid only if [ISMGussetFeatureData::OverrideDocSettings](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ShowProfile Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowProfile Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : ShowProfile Property (ISMGussetFeatureData)

Gets or sets whether to display the profile of the gusset in its flattened state.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowProfile As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISMGussetFeatureData
Dim value As System.Boolean

instance.ShowProfile = value
```

```
value = instance.ShowProfile
```

C#

```
System.bool ShowProfile {get; set;}
```

C++/CLI

```
property System.bool ShowProfile {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the profile of the flattened gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::ShowProfile](#).

Example

See the [ISMGussetFeatureData](#) examples.

Remarks

This property is valid only if [ISMGussetFeatureData::OverrideDocSettings](#) is true.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ShowCenter Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SupportingFaces Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : SupportingFaces Property (ISMGussetFeatureData)

Gets or sets the legs of this gusset.

.NET Syntax

Visual Basic (Declaration)

```
Property SupportingFaces As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Object
```

```
instance.SupportingFaces = value
```

```
value = instance.SupportingFaces
```

C#

```
System.object SupportingFaces {get; set;}
```

C++/CLI

```
property System.Object^ SupportingFaces {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of one or two [faces](#) to which this gusset is attached

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::SupportingFaces](#).

Example

See the [IFeatureManager::InsertSheetMetalGussetFeature3](#) examples.

Remarks

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::ReferenceLine Property \(\)](#)
[ISMGussetFeatureData::ReferencePoint Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseAngleDimForProfile Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : UseAngleDimForProfile Property (ISMGussetFeatureData)

Gets or sets whether to dimension this gusset using an angle.

.NET Syntax

Visual Basic (Declaration)

```
Property UseAngleDimForProfile As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData
Dim value As System.Boolean
```

```
instance.UseAngleDimForProfile = value
```

```
value = instance.UseAngleDimForProfile
```

C#

```
System.bool UseAngleDimForProfile {get; set;}
```

C++/CLI

```
property System.bool UseAngleDimForProfile {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use an angle to dimension this gusset, false to not

Visual Basic for Applications (VBA) Syntax

See [ISMGussetFeatureData::UseAngleDimForProfile](#).

Example

See the [ISMGussetFeatureData](#) examples.

Remarks

This property is valid only if [ISMGussetFeatureData::ProfileDimensionScheme](#) is set to 1.

After setting this property to true, set [ISMGussetFeatureData::ProfileAngleDim](#).

See the [ISMGussetFeatureData](#) Remarks.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseOffset Property (ISMGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMGussetFeatureData Interface](#) : UseOffset Property (ISMGussetFeatureData)

Gets or sets whether to offset the gusset section plane from a specified [reference point](#).

.NET Syntax

Visual Basic (Declaration)

```
Property UseOffset As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMGussetFeatureData  
Dim value As System.Boolean
```

```
instance.UseOffset = value
```

```
value = instance.UseOffset
```

C#

```
System.bool UseOffset {get; set;}
```

C++/CLI

```
property System.bool UseOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the gusset section plane, false to not

Visual Basic for Applications (VBA) Syntax

See [SMGussetFeatureData::UseOffset](#).

Example

See the [ISMGussetFeatureData](#) examples.

Remarks

After setting this property to true, set the [offset distance](#).

If a reference point is not set, the offset is applied to an assumed reference point. For insertion of the first gusset, the assumed reference point is on the end of the sheet metal bend. For second and subsequent gusset insertions, the assumed reference point is on the edge of the gusset last inserted.

See Also

[ISMGussetFeatureData Interface](#)
[ISMGussetFeatureData Members](#)
[ISMGussetFeatureData::FlipOffset Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

ISMNormalCutFeatureData (Type)

ISMNormalCutFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMNormalCutFeatureData Interface

Obsolete. Superseded by [ISMNormalCutFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISMNormalCutFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISMNormalCutFeatureData
```

C#

```
public interface ISMNormalCutFeatureData
```

C++/CLI

```
public interface class ISMNormalCutFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData](#).

Example

See the [IFeatureManager::AddSMNormalCutType](#) example.

Remarks

See the SOLIDWORKS documentation for more information about Normal Cut features.

Accessors

[IFeature::GetDefinition](#)

Access Diagram

[SMNormalCutFeatureData](#)

See Also

- [ISMNormalCutFeatureData Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IFeatureManager::AddSMNormalCut Method \(\)](#)
- [IFeatureManager::AddSMNormalCutType Method \(\)](#)
- [IFeatureManager::FinishSMNormalCut Method \(\)](#)

ISMNormalCutFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISMNormalCutFeatureData Interface

The following tables list the members exposed by [ISMNormalCutFeatureData](#).

Public Properties

Name	Description
 Offset	Obsolete. See ISMNormalCutFeatureData2 .

[Top](#)

Public Methods

Name	Description
 AccessSelections	Obsolete. See ISMNormalCutFeatureData2 .
 AddAGroupOffFaces	Obsolete. See ISMNormalCutFeatureData2 .
 GetNumberOfFaceGroups	Obsolete. See ISMNormalCutFeatureData2 .
 ReleaseSelectionAccess	Obsolete. See ISMNormalCutFeatureData2 .
 RemoveAGroupOffFaces	Obsolete. See ISMNormalCutFeatureData2 .

[Top](#)

See Also

[ISMNormalCutFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::AddSMNormalCut Method \(\)](#)
[IFeatureManager::AddSMNormalCutType Method \(\)](#)
[IFeatureManager::FinishSMNormalCut Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISMNormalCutFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISMNormalCutFeatureData Interface

For a list of all members of this type, see [ISMNormalCutFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Obsolete. See ISMNormalCutFeatureData2 .
 AddAGroupOffFaces	Obsolete. See ISMNormalCutFeatureData2 .
 GetNumberOfFaceGroups	Obsolete. See ISMNormalCutFeatureData2 .
 ReleaseSelectionAccess	Obsolete. See ISMNormalCutFeatureData2 .
 RemoveAGroupOffFaces	Obsolete. See ISMNormalCutFeatureData2 .

[Top](#)

See Also

[ISMNormalCutFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::AddSMNormalCut Method \(\)](#)
[IFeatureManager::AddSMNormalCutType Method \(\)](#)
[IFeatureManager::FinishSMNormalCut Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISMNormalCutFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISMNormalCutFeatureData Interface

For a list of all members of this type, see [ISMNormalCutFeatureData members](#).

Public Properties

Name	Description
 Offset	Obsolete. See ISMNormalCutFeatureData2 .

[Top](#)

See Also

AccessSelections Method (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : AccessSelections Method (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component for the feature

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::AccessSelections](#).

 Example

See the [IFeatureManager::AddSMNormalCutType](#) example.

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ISMNormalCutFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISMNormalCutFeatureData Interface](#)
[ISMNormalCutFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddAGroupOfFaces Method (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : AddAGroupOfFaces Method (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AddAGroupOfFaces( _  
    ByVal FaceArray As System.Object, _  
    ByRef Error As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
Dim FaceArray As System.Object  
Dim Error As System.Integer  
  
instance.AddAGroupOfFaces(FaceArray, Error)
```

C#

```
void AddAGroupOfFaces(  
    System.object FaceArray,  
    out System.int Error  
)
```

C++/CLI

```
void AddAGroupOfFaces(  
& System.Object^ FaceArray,  
& [Out] System.int Error  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceArray
Array of cut-extrude [faces](#)
Error
Error code as defined in [swSMNormalCutError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::AddAGroupOfFaces](#).

Example

See the [IFeatureManager::AddSMNormalCutType](#) example.

Remarks

FaceArray contains the non-normal side walls of a cut in a sheet metal part.

See Also

[ISMNormalCutFeatureData Interface](#)
[ISMNormalCutFeatureData Members](#)
[ISMNormalCutFeatureData::RemoveAGroupOfFaces Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNumberOfFaceGroups Method (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : GetNumberOfFaceGroups Method (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNumberOfFaceGroups() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
Dim value As System.Integer  
  
value = instance.GetNumberOfFaceGroups()
```

C#

```
System.int GetNumberOfFaceGroups()
```

C++/CLI

```
System.int GetNumberOfFaceGroups();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of face groups

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::GetNumberOfFaceGroups](#).

Example

See the [IFeatureManager::AddSMNormalCutType](#) example.

See Also

[ISMNormalCutFeatureData Interface](#)
[ISMNormalCutFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Offset Property (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : Offset Property (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

.NET Syntax

Visual Basic (Declaration)

Property Offset As System.Double

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
Dim value As System.Double
```

```
instance.Offset = value
```

```
value = instance.Offset
```

C#

```
System.double Offset {get; set;}
```

C++/CLI

```
property System.double Offset {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= offset <= 1.0

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::Offset](#).

Example

See the [IFeatureManager::AddSMNormalCutType](#) example.

Remarks

This property allows you to adjust the profile of the Normal Cut. Setting this property to 0.0 sets the profile to the circular edge on one side of the body. Setting it to 1.0 sets the profile to the circular edge on the opposite side of the body. A value in between 0.0 and 1.0 sets the profile to a circular edge somewhere in the middle of the body.

See Also

[ISMNormalCutFeatureData Interface](#)
[ISMNormalCutFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : ReleaseSelectionAccess Method (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISMNormalCutFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did modify the feature.

See Also

[ISMNormalCutFeatureData Interface](#)
[ISMNormalCutFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveAGroupOfFaces Method (ISMNormalCutFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISMNormalCutFeatureData Interface](#) : RemoveAGroupOfFaces Method (ISMNormalCutFeatureData)

Obsolete. See [ISMNormalCutFeatureData2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveAGroupOfFaces() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISMNormalCutFeatureData  
Dim value As System.Integer  
value = instance.RemoveAGroupOfFaces()
```

C#

```
System.int RemoveAGroupOfFaces()
```

C++/CLI

```
System.int RemoveAGroupOfFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Result code as defined in [swSMNormalCutError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SMNormalCutFeatureData::RemoveAGroupOfFaces](#).

See Also

[ISMNormalCutFeatureData Interface](#)

[ISMNormalCutFeatureData Members](#)

[ISMNormalCutFeatureData::AddAGroupOfFaces Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0