

SOLIDWORKS API (.NET VBA C#) — Reference

(292/337): ISplineParamData- ISplitBodyFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISplineParamData (Type)

ISplineParamData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplineParamData Interface

Allows access to the parameterization data of a spline.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISplineParamData
```

Visual Basic (Usage)

```
Dim instance As ISplineParamData
```

C#

```
public interface ISplineParamData
```

C++/CLI

```
public interface class ISplineParamData
```

Visual Basic for Applications (VBA) Syntax

See [SplineParamData](#).

Example

- [Get BCurve Spline Points \(C#\)](#)
- [Get BCurve Spline Points \(VB.NET\)](#)
- [Get BCurve Spline Points \(VBA\)](#)
- [Get P-Spline Parameterization Data \(C#\)](#)
- [Get P-Spline Parameterization Data \(VB.NET\)](#)
- [Get P-Spline Parameterization Data \(VBA\)](#)
- [Get Spline's Parameters \(C#\)](#)
- [Get Spline's Parameters \(VB.NET\)](#)
- [Get Spline's Parameters \(VBA\)](#)
- [Edit Spline \(VBA\)](#)

Accessors

- [ICurve::GetBCurveParams5](#)
- [ICurve::GetPCurveParams2](#)
- [ISketch::GetSplineParams4](#)
- [ISketchManager::CreateSplineParamData](#)

Access Diagram

[SplineParamData](#)

See Also

- [ISplineParamData Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

ISplineParamData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplineParamData Interface

For a list of all members of this type, see [ISplineParamData members](#).

Public Methods

Name	Description
 GetControlPoints	Gets the coordinates of all of the control points of the spline.
 GetKnotPoints	Gets the knot vector for the spline.
 GetSegments	Gets the coefficients of all of the piecewise polynomials of a spline.
 IGetControlPoints	Gets the coordinates of all of the control points of the spline.
 IGetKnotPoints	Gets all of the knot points of the spline.
 IGetSegments	Gets the coefficients of all of the piecewise polynomials of a spline.
 SetControlPoints	Sets the coordinates of all of the control points of a spline.
 SetKnotPoints	Sets the knot vector for a spline.

[Top](#)

See Also

[ISplineParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISplineParamData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplineParamData Interface

The following tables list the members exposed by [ISplineParamData](#).

Public Properties

Name	Description
 Color	Gets the color used to draw the spline.
 ControlPointsCount	Gets and sets the number of control points in the spline.
 Dimension	Gets and sets the dimension of the spline.
 KnotPointsCount	Gets the number of knots in the spline.
 Layer	Gets the index of the layer in which this spline is drawn.
 LayerOverride	Gets the spline's properties that override the default properties of the layer.
 LineStyle	Gets the line style used to draw the spline.
 LineWidth	Gets the line weight used to draw the spline.
 Order	Gets and sets the number of nearby control points that influence any given point on the curve.
 Periodic	Gets and sets the periodicity of the spline.
 Reserved	Not used.
 SegmentCount	Gets the number of segments in the spline.

[Top](#)

Public Methods

Name	Description
 GetControlPoints	Gets the coordinates of all of the control points of the spline.
 GetKnotPoints	Gets the knot vector for the spline.
 GetSegments	Gets the coefficients of all of the piecewise polynomials of a spline.
 IGetControlPoints	Gets the coordinates of all of the control points of the spline.
 IGetKnotPoints	Gets all of the knot points of the spline.

 IGetSegments	Gets the coefficients of all of the piecewise polynomials of a spline.
 SetControlPoints	Sets the coordinates of all of the control points of a spline.
 SetKnotPoints	Sets the knot vector for a spline.

[Top](#)

 See Also

[ISplineParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

ISplineParamData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplineParamData Interface

For a list of all members of this type, see [ISplineParamData members](#).

 Public Properties

Name	Description
 Color	Gets the color used to draw the spline.
 ControlPointsCount	Gets and sets the number of control points in the spline.
 Dimension	Gets and sets the dimension of the spline.
 KnotPointsCount	Gets the number of knots in the spline.
 Layer	Gets the index of the layer in which this spline is drawn.
 LayerOverride	Gets the spline's properties that override the default properties of the layer.
 LineStyle	Gets the line style used to draw the spline.
 LineWidth	Gets the line weight used to draw the spline.
 Order	Gets and sets the number of nearby control points that influence any given point on the curve.
 Periodic	Gets and sets the periodicity of the spline.
 Reserved	Not used.
 SegmentCount	Gets the number of segments in the spline.

[Top](#)

 See Also

[ISplineParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

Color Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Color Property (ISplineParamData)

Gets the color used to draw the spline.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer
```

```
value = instance.Color
```

C#

```
System.int Color {get;}
```

C++/CLI

```
property System.int Color {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value; -1 if not defined

Visual Basic for Applications (VBA) Syntax

See [SplineParamData.Color](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::LayerOverride Property](#)
[ISplineParamData::LineStyle Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ControlPointsCount Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : ControlPointsCount Property (ISplineParamData)

Gets and sets the number of control points in the spline.

.NET Syntax

Visual Basic (Declaration)

```
Property ControlPointsCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer  
  
instance.ControlPointsCount = value  
  
value = instance.ControlPointsCount
```

C#

```
System.int ControlPointsCount {get; set;}
```

C++/CLI

```
property System.int ControlPointsCount {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of control points

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::ControlPointsCount](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

The number of control points must be greater than or equal to the [order](#) of the spline.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetControlPoints Method](#)
[ISplineParamData::!GetControlPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Dimension Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Dimension Property (ISplineParamData)

Gets and sets the dimension of the spline.

.NET Syntax

Visual Basic (Declaration)

```
Property Dimension As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer
```

```
instance.Dimension = value
```

```
value = instance.Dimension
```

C#

```
System.int Dimension {get; set;}
```

C++/CLI

```
property System.int Dimension {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 1, if one-dimensional
- 2, if two-dimensional
- 3, if three-dimensional (non-rational)
- 4, if four-dimensional (rational)

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::Dimension](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetControlPoints Method](#)
[ISplineParamData::IGetControlPoints Method](#)
[ISplineParamData::GetKnotPoints Method](#)
[ISplineParamData::IGetKnotPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPoints Method (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : GetControlPoints Method (ISplineParamData)

Gets the coordinates of all of the control points of the spline.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPoints( _
    ByRef ControlPoints As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISplineParamData
Dim ControlPoints As System.Object
Dim value As System.Boolean

value = instance.GetControlPoints(ControlPoints)
```

C#

```
System.bool GetControlPoints(
    out System.object ControlPoints
)
```

C++/CLI



```
System.bool GetControlPoints(  
& [Out] System.Object^ ControlPoints  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ControlPoints
One-dimensional array of doubles (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::GetControlPoints](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

Control points determine the shape of a spline or curve. Starting with a set of control points, all other points of a spline can be calculated. A given point on the spline is calculated using the polynomial basis functions of its nearest control points. The [knot vector](#) determines which control point basis functions are in force for calculating each point along a curve.

The size of the ControlPoints array is based on the curve dimension:

- if [dimension](#) = 2, then each control point has 2 doubles (x, y)
- if [dimension](#) = 3, then each control point has 3 doubles (x, y, z)
- if [dimension](#) = 4, and the curve is closed or periodic, then each control point has 4 doubles (x, y, z, w), where w = weight
- if [dimension](#) = 4, and the curve is open or non-periodic, then each control point has 4 doubles (w*x, w*y, w*z, w), where w = weight

Size of ControlPoints array = [control points count](#) * [dimension](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::IGetControlPoints Method](#)
[ISplineParamData::SetControlPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetKnotPoints Method (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : GetKnotPoints Method (ISplineParamData)

Gets the knot vector for the spline.

.NET Syntax

Visual Basic (Declaration)

```
Function GetKnotPoints( _  
    ByRef KnotPoints As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData
Dim KnotPoints As System.Object
Dim value As System.Boolean

value = instance.GetKnotPoints(KnotPoints)
```

C#

```
System.bool GetKnotPoints(
    out System.object KnotPoints
)
```

C++/CLI

```
System.bool GetKnotPoints(
    & [Out] System.Object^ KnotPoints
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

KnotPoints
Array of double values between 0 and 1, inclusive (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::GetKnotPoints](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

Before calling this method, call [ISplineParamData::KnotPointsCount](#) to get the size of the KnotPoints array.

Together with [control points](#), knots determine the shape and smoothness of a spline. The knot vector divides the parametric space into intervals or knot spans. These intervals may be uniform or non-uniform. Each interval governs a different control point.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::IGetKnotPoints Method](#)
[ISplineParamData::SetKnotPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSegments Method (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : GetSegments Method (ISplineParamData)

Gets the coefficients of all of the piecewise polynomials of a spline.

.NET Syntax

```
Function GetSegments( _
    ByRef Segments As System.Object _
) As System.Boolean
```



```
Dim instance As ISplineParamData
Dim Segments As System.Object
Dim value As System.Boolean

value = instance.GetSegments(Segments)
```

```
System.bool GetSegments(
    out System.object Segments
)
```

```
System.bool GetSegments(
    & [Out] System.Object^ Segments
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Segments
Array of doubles (see Remarks)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::GetSegments](#).

Example

[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)

Remarks

This method works only with P-spline parameterization data. Before calling this method, call [ICurve::GetPCurveParams2](#) to obtain the P-spline parameterization data object for the curve.

Each pair of spline control points defines one segment of a curve. Each segment is typically represented by a cubic polynomial. This method returns a one-dimensional array containing doubles that are the coefficients of all of the piecewise cubic polynomials of the spline.

The segment coefficients are stored in the Segments array in order of increasing variable exponent:

(constants)(first degree coefficients)(second degree coefficients)(third degree coefficients) etc.

For example, if the spline segments are represented by cubic rational (dim=4) polynomials in parametric form,

$$p(t) = \frac{(w_0 \cdot a_0 + w_1 \cdot a_1 \cdot t + w_2 \cdot a_2 \cdot t^2 + w_3 \cdot a_3 \cdot t^3)}{(w_0 + w_1 \cdot t + w_2 \cdot t^2 + w_3 \cdot t^3)}$$

where w_0, w_1, w_2, w_3 are weighting coefficients and a_0, a_1, a_2, a_3 are vector coefficients, then the Segments array stores (dimension(4) X order(4)) = 16 coefficients:

(a_0x, a_0y, a_0z, w_0)(a_1x, a_1y, a_1z, w_1)(a_2x, a_2y, a_2z, w_2)(a_3x, a_3y, a_3z, w_3).

If the spline segments are represented by cubic non-rational (dim=3) polynomials, then the Segments array stores (dimension(3) X order(4)) = 12 coefficients:

(a_0x, a_0y, a_0z)(a_1x, a_1y, a_1z)(a_2x, a_2y, a_2z)(a_3x, a_3y, a_3z).

The total number of coefficients returned by this method is:

([segment count](#)) x ([order](#)) x ([dimension](#))

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::IGetSegments Method](#)
[ISplineParamData::SegmentCount Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetControlPoints Method (ISplineParamData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : IGetControlPoints Method (ISplineParamData)

Gets the coordinates of all of the control points of the spline.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetControlPoints( _  
    ByVal Count As System.Integer, _  
    ByRef ControlPoints As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim Count As System.Integer  
Dim ControlPoints As System.Double  
Dim value As System.Boolean  
  
value = instance.IGetControlPoints(Count, ControlPoints)
```

C#

```
System.bool IGetControlPoints(  
    System.int Count,  
    out System.double ControlPoints  
)
```

C++/CLI

```
System.bool IGetControlPoints(  
& System.int Count,  
& [Out] System.double ControlPoints  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of ControlPoints array

ControlPoints

- In-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if successful, false if not

Remarks

Before calling this method, call [ISplineParamData::ControlPointsCount](#) to populate the Count parameter.

Control points determine the shape of a spline or curve. Starting with a set of control points, all other points of a spline can be calculated. A given point on the spline is calculated using the polynomial basis functions of its nearest control points. The [knot vector](#) determines which control point basis functions are in force for calculating each point along a curve.

The size of the ControlPoints array is based on the curve dimension:

- if [dimension](#) = 2 then each control point has 2 doubles (x, y)
- if [dimension](#) = 3 then each control point has 3 doubles (x, y, z)
- if [dimension](#) = 4, and the curve is closed or periodic, then each control point has 4 doubles (x, y, z, w), where w = weight
- if [dimension](#) = 4, and the curve is open or non-periodic, then each control point has 4 doubles (w*x, w*y, w*z, w), where w = weight
- Size of ControlPoints array = [control points count](#) * [dimension](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetControlPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetKnotPoints Method (ISplineParamData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : IGetKnotPoints Method (ISplineParamData)

Gets all of the knot points of the spline.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetKnotPoints(  
    ByVal Count As System.Integer, _  
    ByRef KnotPoints As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim Count As System.Integer  
Dim KnotPoints As System.Double  
Dim value As System.Boolean
```

```
value = instance.IGetKnotPoints(Count, KnotPoints)
```

C#

```
System.bool IGetKnotPoints(  
    System.int Count,  
    out System.double KnotPoints  
)
```

C++/CLI

```
System.bool IGetKnotPoints(  
    & System.int Count,  
    & [Out] System.double KnotPoints  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of KnotPoints array

KnotPoints

- in-process, unmanaged C++: Pointer to an array of double values between 0 and 1, inclusive

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if successful, false if not

Remarks

Before calling this method, call [ISplineParamData::KnotPointsCount](#) to populate the Count parameter.

Together with [control points](#), knots determine the shape and smoothness of a spline. The knot vector divides the parametric space into intervals or knot spans. These intervals may be uniform or non-uniform. Each interval governs a different control point.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetKnotPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSegments Method (ISplineParamData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : IGetSegments Method (ISplineParamData)

Gets the coefficients of all of the piecewise polynomials of a spline.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSegments( _  
    ByVal Count As System.Integer, _  
    ByRef Segments As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim Count As System.Integer  
Dim Segments As System.Double  
Dim value As System.Boolean
```

```
value = instance.IGetSegments(Count, Segments)
```

C#

```
System.bool IGetSegments(  
    System.int Count,  
    out System.double Segments  
)
```

C++/CLI

```
System.bool IGetSegments(  
& System.int Count,  
& [Out] System.double Segments  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of Segments array

Segments

- in-process, unmanaged C++: Pointer to an array of doubles
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if successful, false if not

Remarks

This method works only with P-spline parameterization data. Before calling this method, call [ICurve::GetPCurveParams2](#) to obtain the P-spline parameterization data object for the curve.

Before calling this method, call [ISplineParamData::SegmentCount](#) to populate the Count parameter.

Each pair of spline control points defines one segment of a curve. Each segment is typically represented by a cubic polynomial. This method returns a one-dimensional array containing doubles that are the coefficients of all of the piecewise cubic polynomials of the spline.

The segment coefficients are stored in the Segments array in order of increasing variable exponent:

(constants)(first degree coefficients)(second degree coefficients)(third degree coefficients) etc.

For example, if the spline segments are represented by cubic rational (dim=4) polynomials in parametric form,

$$p(t) = \frac{(w_0 \cdot a_0 + w_1 \cdot a_1 \cdot t + w_2 \cdot a_2 \cdot t^2 + w_3 \cdot a_3 \cdot t^3)}{(w_0 + w_1 \cdot t + w_2 \cdot t^2 + w_3 \cdot t^3)}$$

where w0, w1, w2, w3 are weighting coefficients and a0, a1, a2, a3 are vector coefficients, then the Segments array stores (dimension(4) X order(4)) = 16 coefficients:

(a0x,a0y,a0z,w0)(a1x,a1y,a1z,w1)(a2x,a2y,a2z,w2)(a3x,a3y,a3z,w3).

If the spline segments are represented by cubic non-rational (dim=3) polynomials, then the Segments array stores (dimension(3) X order(4)) = 12 coefficients:

(a0x,a0y,a0z)(a1x,a1y,a1z)(a2x,a2y,a2z)(a3x,a3y,a3z0).

The total number of coefficients returned by this method is:

([segment count](#)) x ([order](#)) x ([dimension](#))

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetSegments Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KnotPointsCount Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : KnotPointsCount Property (ISplineParamData)

Gets the number of knots in the spline.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property KnotPointsCount As System.Integer

Visual Basic (Usage)

```
Dim instance As ISplineParamData  
Dim value As System.Integer
```

```
value = instance.KnotPointsCount
```

C#



```
System.int KnotPointsCount {get;}
```

C++/CLI

```
property System.int KnotPointsCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of knots.

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::KnotPointsCount](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

The number of knots depends on the periodicity of the spline:

If...	Then this method returns...
periodic =1	control points count + 1
periodic =0	control points count + order

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetKnotPoints Method](#)
[ISplineParamData::IGetKnotPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layer Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Layer Property (ISplineParamData)

Gets the index of the layer in which this spline is drawn.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Layer As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer
```

```
value = instance.Layer
```

C#

```
System.int Layer {get;}
```

C++/CLI

```
property System.int Layer {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index of layer of spline, -1 if layer not defined

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::Layer](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::LayerOverride Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LayerOverride Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : LayerOverride Property (ISplineParamData)

Gets the spline's properties that override the default properties of the layer.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LayerOverride As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer  
  
value = instance.LayerOverride
```

C#

```
System.int LayerOverride {get;}
```

C++/CLI

```
property System.int LayerOverride {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Properties that have been overridden or should be overridden as defined in [swLayerOverride_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::LayerOverride](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

Layers are only supported in drawing documents.

Splines can be created on a layer that has specific visual properties. By default, the spline takes on the visual properties defined by the layer. However, for a specific spline, these visual properties can be overridden (see [ISplineParamData::Color](#), [ISplineParamData::LineStyle](#), and [ISplineParamData::LineWidth](#)). This property gets or sets whether the default visual properties of the layer are used by this spline.

When the spline is not on any layer, the value this property returns is undefined. You can use the [ISplineParamData::Layer](#) property to determine the name of the layer, if any, that this spline is on. If an empty string is returned by the [ISplineParamData::Layer](#) property, then this property is not used.

When you get this property, the returned bit value indicates which property or properties have been overridden. The bit indicators are:

- color = 0x1
- style = 0x2
- width = 0x4

Therefore, if the value was returned as 3, you know color and style have been specifically set for this item and might not match the default value associated with this item's layer.

When you set this property, the input bit value indicates which property or properties should maintain their current override values. Therefore, if the value is passed as 0x4, we know width should keep its current override value, and that color and style should be reset to use the color and style settings for the item's layer. If you pass 0, all visual properties are reset to use the default settings of the item's layer.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::Layer Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LineStyle Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : LineStyle Property (ISplineParamData)

Gets the line style used to draw the spline.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LineStyle As System.Integer
```

```
Dim instance As ISplineParamData
Dim value As System.Integer

value = instance.LineStyle
```

C#

```
System.int LineStyle {get;}
```

C++/CLI

```
property System.int LineStyle {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line style as defined in [swLineStyles_e](#), -1 if not defined

Visual Basic for Applications (VBA) Syntax

See [SplineParamData.LineStyle](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData.Color Property](#)
[ISplineParamData.LayerOverride Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LineWidth Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : LineWidth Property (ISplineParamData)

Gets the line weight used to draw the spline.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LineWidth As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISplineParamData
Dim value As System.Integer

value = instance.LineWidth
```

C#

```
System.int LineWidth {get;}
```

C++/CLI

```
property System.int LineWidth {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line weight as defined in [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::LineWidth](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::Color Property](#)
[ISplineParamData::LineStyle Property](#)
[ISplineParamData::LayerOverride Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Order Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Order Property (ISplineParamData)

Gets and sets the number of nearby control points that influence any given point on the curve.

.NET Syntax

Visual Basic (Declaration)

```
Property Order As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim value As System.Integer
```

```
instance.Order = value
```

```
value = instance.Order
```

C#

```
System.int Order {get; set;}
```

C++/CLI

```
property System.int Order {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

The degree of the spline polynomial + 1

Visual Basic for Applications (VBA) Syntax

See [SplineParamData.Order](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

A spline of order...	is represented by a ...	of degree...
2	linear polynomial	1
3	quadratic polynomial	2
4	cubic polynomial	3

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetSegments Method](#)
[ISplineParamData::IGetSegments Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Periodic Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Periodic Property (ISplineParamData)

Gets and sets the periodicity of the spline.

.NET Syntax

Visual Basic (Declaration)

```
Property Periodic As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISplineParamData
Dim value As System.Integer
```

```
instance.Periodic = value
```

```
value = instance.Periodic
```

C#



```
System.int Periodic {get; set;}
```

C++/CLI

```
property System.int Periodic {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0 if an open spline, 1 if a closed spline

Visual Basic for Applications (VBA) Syntax

See [SplineParamData.Periodic](#).

Example

[Get BCurve Spline Points \(C#\)](#)
[Get BCurve Spline Points \(VB.NET\)](#)
[Get BCurve Spline Points \(VBA\)](#)
[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

The [number of knots](#) in the spline depends on the periodicity of the spline:

If this method returns...	Then the number of knots is...
---------------------------	--------------------------------

1	ControlPointsCount + 1
---	--

0	ControlPointsCount + Order
---	--

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Reserved Property (ISplineParamData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : Reserved Property (ISplineParamData)

Not used.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Reserved As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData
Dim value As System.Integer

value = instance.Reserved
```

C#

```
System.int Reserved {get;}
```

C++/CLI

```
property System.int Reserved {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SplineParamData.Reserved](#).

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SegmentCount Property (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : SegmentCount Property (ISplineParamData)

Gets the number of segments in the spline.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SegmentCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData
Dim value As System.Integer

value = instance.SegmentCount
```

C#

```
System.int SegmentCount {get;}
```

C++/CLI

```
property System.int SegmentCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of segments if a P-spline, -1 if not

Visual Basic for Applications (VBA) Syntax

See [ISplineParamData::SegmentCount](#).

Example

[Get P-Spline Parameterization Data \(C#\)](#)
[Get P-Spline Parameterization Data \(VB.NET\)](#)
[Get P-Spline Parameterization Data \(VBA\)](#)

Remarks

This method works only with P-spline parameter data. Before calling this method, call [ICurve::GetPCurveParams2](#) to generate P-spline parameterization data object for the curve.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetSegments Method](#)
[ISplineParamData::IGetSegments Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetControlPoints Method (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : SetControlPoints Method (ISplineParamData)

Sets the coordinates of all of the control points of a spline.

.NET Syntax

Visual Basic (Declaration)

```
Function SetControlPoints( _  
    ByVal ControlPoints As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplineParamData  
Dim ControlPoints As System.Object  
Dim value As System.Boolean  
  
value = instance.SetControlPoints(ControlPoints)
```

C#

```
System.bool SetControlPoints(  
    System.object ControlPoints  
)
```

C++/CLI

```
System.bool SetControlPoints(  
& System.Object^ ControlPoints  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ControlPoints
One-dimensional array of doubles (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ISplineParamData::SetControlPoints](#).

Example

[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

Control points determine the shape of a spline or curve. Starting with a set of control points, all other points of a spline can be calculated. A given point on the spline is calculated using the polynomial basis functions of its nearest control points. The [knot vector](#) determines which control point basis functions are in force for calculating each point along a curve.

The size of the ControlPoints array is based on the curve dimension:

- if [dimension](#) = 2 then each control point has 2 doubles (x, y)
- if [dimension](#) = 3 then each control point has 3 doubles (x, y, z)
- if [dimension](#) = 4, and the curve is closed or periodic, then each control point has 4 doubles (x, y, z, w), where w = weight
- if [dimension](#) = 4, and the curve is open or non-periodic, then each control point has 4 doubles (w*x, w*y, w*z, w), where w = weight
- Size of ControlPoints array = [control points count](#) * [dimension](#)

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetControlPoints Method](#)
[ISplineParamData::IGetControlPoints Method](#)
[ISketchSpline::ModifyControlPoint Method \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetKnotPoints Method (ISplineParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplineParamData Interface](#) : SetKnotPoints Method (ISplineParamData)

Sets the knot vector for a spline.

.NET Syntax

Visual Basic (Declaration)

```
Function SetKnotPoints( _  
    ByVal KnotPoints As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISplineParamData  
Dim KnotPoints As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetKnotPoints(KnotPoints)
```

C#

```
System.bool SetKnotPoints(  
    System.object KnotPoints  
)
```

C++/CLI

```
System.bool SetKnotPoints(  
& System.Object^ KnotPoints
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

KnotPoints

Array of doubles between 0 and 1, inclusive

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SplineParamData::SetKnotPoints](#).

Example

[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

Together with [control points](#) knots determine the shape and smoothness of a spline. The knot vector divides the parametric space into intervals of knot spans. These intervals may be uniform or non-uniform. Each interval governs a different control point.

See Also

[ISplineParamData Interface](#)
[ISplineParamData Members](#)
[ISplineParamData::GetKnotPoints Method](#)
[ISplineParamData::IGetKnotPoints Method](#)
[ISplineParamData::KnotPointsCount Property](#)
[ISketchSpline::ModifyKnot Method \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

ISplitBodyFeatureData (Type)

ISplitBodyFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitBodyFeatureData Interface

Allows access to a Split feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISplitBodyFeatureData
```

Visual Basic (Usage)

```
Dim instance As ISplitBodyFeatureData
```

C#

```
public interface ISplitBodyFeatureData
```

C++/CLI

```
public interface class ISplitBodyFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData](#).

Example

[Create Split Feature \(VBA\)](#)
[Create Split Feature \(VB.NET\)](#)
[Create Split Feature \(C#\)](#)

Remarks

[IFeature::GetTypeName2](#) and [IFeature::GetTypeName](#) return:

- Split** for a feature that was created by splitting a part into multiple parts by using either [IFeatureManager::PostSplitBody](#) or the **Split** feature in the user interface. You can access a split-body feature's data using the ISplitBodyFeatureData interface.
- SplitBody** for a body created by splitting a part and saving the body to a part. You cannot access the data of a split body saved to a part.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[SplitBodyFeatureData](#)

See Also

[ISplitBodyFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PreSplitBody Method](#)

ISplitBodyFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitBodyFeatureData Interface

For a list of all members of this type, see [ISplitBodyFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to a Split feature.
 GetSplitBodies	Gets the split bodies in this Split feature.
 GetSplitBodiesCount	Gets the number of split bodies in this Split feature.
 GetTrimToolsCount	Gets the number of trimming surfaces used as trim tools in this Split feature.
 IGetSplitBodies	Gets the split bodies for this Split feature.
 IGetTrimTools	Gets the trimming surfaces used as trim tools in this Split feature.
 ISetSplitBodies	Obsolete. Superseded by ISplitBodyFeatureData.SetSplitBodies2 .
 ISetTrimTools	Gets the trimming surfaces used as trim tools in this Split feature.
 ReleaseSelectionAccess	Releases access to the selections that define this Split feature.
 SetSplitBodies	Obsolete. Superseded by ISplitBodyFeatureData.SetSplitBodies2 .
 SetSplitBodies2	Edits the current split bodies in this Split feature.

[Top](#)

See Also

[ISplitBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PreSplitBody Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISplitBodyFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitBodyFeatureData Interface

The following tables list the members exposed by [ISplitBodyFeatureData](#).

Public Properties

Name	Description
 Consume	Gets or sets whether the bodies in this Split feature are consumed.
 OverrideDefaultTemplateSettings	Gets or sets whether to use an alternate template to apply to all new part or assembly files created during the split operation.
 TemplatePath	Gets or sets the template to use to make this Split feature.
 TrimTools	Gets the trimming surfaces used as trim tools in this Split feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to a Split feature.
 GetSplitBodies	Gets the split bodies in this Split feature.
 GetSplitBodiesCount	Gets the number of split bodies in this Split feature.
 GetTrimToolsCount	Gets the number of trimming surfaces used as trim tools in this Split feature.
 IGetSplitBodies	Gets the split bodies for this Split feature.
 IGetTrimTools	Gets the trimming surfaces used as trim tools in this Split feature.
 ISetSplitBodies	Obsolete. Superseded by ISplitBodyFeatureData.SetSplitBodies2 .
 ISetTrimTools	Gets the trimming surfaces used as trim tools in this Split feature.
 ReleaseSelectionAccess	Releases access to the selections that define this Split feature.

 SetSplitBodies	Obsolete. Superseded by ISplitBodyFeatureData::SetSplitBodies2
 SetSplitBodies2	Edits the current split bodies in this Split feature.

[Top](#)

 See Also

[ISplitBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PreSplitBody Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

ISplitBodyFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [ISplitBodyFeatureData Interface](#)

For a list of all members of this type, see [ISplitBodyFeatureData members](#).

 Public Properties

Name	Description
 Consume	Gets or sets whether the bodies in this Split feature are consumed.
 OverrideDefaultTemplateSettings	Gets or sets whether to use an alternate template to apply to all new part or assembly files created during the split operation.
 TemplatePath	Gets or sets the template to use to make this Split feature.
 TrimTools	Gets the trimming surfaces used as trim tools in this Split feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

 See Also

[ISplitBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::PreSplitBody Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

AccessSelections Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : AccessSelections Method (ISplitBodyFeatureData)

Gains access to a Split feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,
```

```
        Component2 Component
    )
```

C++/CLI

```
System.bool AccessSelections(
&    ModelDoc2^ TopDoc,
&    Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component for the feature

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISplitBodyFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Consume Property (ISplitBodyFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : Consume Property (ISplitBodyFeatureData)

Gets or sets whether the bodies in this Split feature are consumed.

.NET Syntax

Visual Basic (Declaration)

```
Property Consume As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData
Dim value As System.Boolean

instance.Consume = value

value = instance.Consume
```

C#

```
System.bool Consume {get; set;}
```

C++/CLI

```
property System.bool Consume {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the Split bodies are consumed, false if not

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::Consume](#).

Example

[Create Split Feature \(VBA\)](#)
[Create Split Feature \(VB.NET\)](#)
[Create Split Feature \(C#\)](#)

Remarks

Consumed means the split bodies are removed from the part and do not appear in the Solid Bodies folder of the FeatureManager design tree.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[IFeatureManager::PostSplitBody Method](#)
[IFeatureManager::PreSplitBody Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitBodies Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : GetSplitBodies Method (ISplitBodyFeatureData)

Gets the split bodies in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetSplitBodies(  
    ByRef BodyVar As System.Object, _  
    ByRef PathVar As System.Object, _  
    ByRef FlagVar As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As ISplitBodyFeatureData  
Dim BodyVar As System.Object  
Dim PathVar As System.Object  
Dim FlagVar As System.Object  
  
instance.GetSplitBodies(BodyVar, PathVar, FlagVar)
```

C#



```
void GetSplitBodies(
    out System.Object BodyVar,
    out System.Object PathVar,
    out System.Object FlagVar
)
```

C++/CLI

```
void GetSplitBodies(
    & [Out] System.Object^ BodyVar,
    & [Out] System.Object^ PathVar,
    & [Out] System.Object^ FlagVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyVar

Array of split [bodies](#)

PathVar

Array of paths and file names of the part documents to which BodyVar bodies are saved; empty string if not saved

FlagVar

Array of booleans indicating whether corresponding BodyVar bodies are consumed; true if removed from the original part, false if not

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::GetSplitBodies](#).

Remarks

Call this method before calling [ISplitBodyFeatureData::SetSplitBodies2](#) to change which split bodies to include in this Split feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)

[ISplitBodyFeatureData Members](#)

[ISplitBodyFeatureData::IGetSplitBodies Method](#)

[ISplitBodyFeatureData::GetSplitBodiesCount Method](#)

[IFeatureManager::PostSplitBody Method](#)

[IFeatureManager::PreSplitBody Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitBodiesCount Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : GetSplitBodiesCount Method (ISplitBodyFeatureData)

Gets the number of split bodies in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData
```

```
Dim value As System.Integer
```

```
value = instance.GetSplitBodiesCount()
```

C#

```
System.int GetSplitBodiesCount()
```

C++/CLI

```
System.int GetSplitBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of split bodies

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::GetSplitBodiesCount](#).

Remarks

Call this method before calling [ISplitBodyFeatureData::!GetSplitBodies](#) to determine the size of the array for that method.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::GetSplitBodies Method](#)
[ISplitBodyFeatureData::!SetSplitBodies Method](#)
[ISplitBodyFeatureData::SetSplitBodies Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimToolsCount Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : GetTrimToolsCount Method (ISplitBodyFeatureData)

Gets the number of trimming surfaces used as trim tools in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimToolsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim value As System.Integer  
  
value = instance.GetTrimToolsCount()
```

C#

```
System.int GetTrimToolsCount()
```

C++/CLI

```
System.int GetTrimToolsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of trimming surfaces used as trim tools in this Split feature

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::GetTrimToolsCount](#).

Remarks

Call this method before calling [ISplitBodyFeatureData::IGetTrimTools](#) to determine the size of the array for that method.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::TrimTools Property](#)
[ISplitBodyFeatureData::ISetTrimTools Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSplitBodies Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : IGetSplitBodies Method (ISplitBodyFeatureData)

Gets the split bodies for this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetSplitBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2, _  
    ByRef PathArr As System.String, _  
    ByRef FlagArr As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2  
Dim PathArr As System.String  
Dim FlagArr As System.Boolean
```

```
instance.IGetSplitBodies(Count, BodyArr, PathArr, FlagArr)
```

C#

```
void IGetSplitBodies(  
    System.int Count,  
    out Body2 BodyArr,  
    out System.string PathArr,  
    out System.bool FlagArr  
)
```

C++/CLI

```
void IGetSplitBodies(  
& System.int Count,  
& [Out] Body2^ BodyArr,  
& [Out] System.String^ PathArr,  
& [Out] System.bool FlagArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of split bodies (see **Remarks**)

BodyArr

- in-process, unmanaged C++: Pointer to an array of split [bodies](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

PathArr

- in-process, unmanaged C++: Pointer to an array of paths and file names of part documents to which to save BodyArr bodies
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

FlagArr

- in-process, unmanaged C++: Pointer to an array of booleans indicating whether corresponding BodyArr body is removed from the original part; true if removed, false if not
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISplitBodyFeatureData::GetSplitBodiesCount](#) to determine the value for Count. Call this method before calling [ISplitBodyFeatureData::SetSplitBodies2](#) to change which split bodies to include in this Split feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::GetSplitBodies Method](#)
[IFeatureManager::PreSplitBody2 Method \(\)](#)
[IFeatureManager::PostSplitBody Method \(\)](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTrimTools Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : IGetTrimTools Method (ISplitBodyFeatureData)

Gets the trimming surfaces used as trim tools in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimTools( _
    ByVal Count As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData
Dim Count As System.Integer
Dim value As System.Object

value = instance.IGetTrimTools(Count)
```

C#

```
System.object IGetTrimTools(
    System.int Count
)
```

C++/CLI

```
System.Object^ IGetTrimTools(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trimming surfaces used as trim tools in this Split feature

Return Value

- in-process, unmanaged C++: Pointer to an array of trimming surfaces used as trim tools:
 - Planar and non-planar faces
 - Reference planes
 - Reference surfaces
 - Sketches
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISplitBodyFeatureData::GetTrimToolsCount](#) before calling this method to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::TrimTools Property](#)
[ISplitBodyFeatureData::ISetTrimTools Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSplitBodies Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : ISetSplitBodies Method (ISplitBodyFeatureData)

Obsolete. Superseded by [ISplitBodyFeatureData::SetSplitBodies2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSplitBodies( _  
    ByVal Count As System.Integer, _  
    ByRef PathArr As System.String, _  
    ByRef FlagArr As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim Count As System.Integer  
Dim PathArr As System.String  
Dim FlagArr As System.Boolean
```

```
instance.ISetSplitBodies(Count, PathArr, FlagArr)
```

C#

```
void ISetSplitBodies(  
    System.int Count,  
    ref System.string PathArr,  
    ref System.bool FlagArr  
)
```

C++/CLI

```
void ISetSplitBodies(  
& System.int Count,  
& System.String^% PathArr,  
& System.bool% FlagArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of split bodies for this Split feature

PathArr

- in-process, unmanaged C++: Pointer to an array of paths and file names of the split bodies
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

FlagArr

- in-process, unmanaged C++: Pointer to an array of booleans indicating whether corresponding PathArr bodies are consumed; true indicates the body is removed from the original part, false otherwise
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ISplitBodyFeatureData Interface](#)

[ISplitBodyFeatureData Members](#)

[ISplitBodyFeatureData::SetSplitBodies Method](#)

[ISplitBodyFeatureData::GetSplitBodiesCount Method](#)

[ISplitBodyFeatureData::IGetSplitBodies Method](#)

[ISplitBodyFeatureData::GetSplitBodies Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTrimTools Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : ISetTrimTools Method (ISplitBodyFeatureData)

Gets the trimming surfaces used as trim tools in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetTrimTools( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetTrimTools(Count, DispArr)
```

C#

```
void ISetTrimTools(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetTrimTools(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of trimming surfaces used as trim tools

DispArr

- in-process, unmanaged C++: Pointer to an array of trimming surfaces used as trim tools :
 - Planar and non-planar faces
 - Reference planes
 - Reference surfaces

- Sketches
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::GetTrimToolsCount Method](#)
[ISplitBodyFeatureData::IGetTrimTools Method](#)
[ISplitBodyFeatureData::TrimTools Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultTemplateSettings Property (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : OverrideDefaultTemplateSettings Property (ISplitBodyFeatureData)

Gets or sets whether to use an alternate template to apply to all new part or assembly files created during the split operation.

.NET Syntax

Visual Basic (Declaration)

Property OverrideDefaultTemplateSettings As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData
Dim value As System.Boolean

instance.OverrideDefaultTemplateSettings = value

value = instance.OverrideDefaultTemplateSettings
```

C#

```
System.bool OverrideDefaultTemplateSettings {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultTemplateSettings {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use an alternate template, false to use the default template

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::OverrideDefaultTemplateSettings](#).

Remarks

Use [ISplitBodyFeatureData::TemplatePath](#) to specify the alternate template.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : ReleaseSelectionAccess Method (ISplitBodyFeatureData)

Releases access to the selections that define this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::ReleaseSelectionAccess](#).

Remarks

[ISplitBodyFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSplitBodies Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : SetSplitBodies Method (ISplitBodyFeatureData)

Obsolete. Superseded by [ISplitBodyFeatureData::SetSplitBodies2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSplitBodies( _  
    ByVal PathVar As System.Object, _  
    ByVal FlagVar As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitBodyFeatureData  
Dim PathVar As System.Object  
Dim FlagVar As System.Object  
  
instance.SetSplitBodies(PathVar, FlagVar)
```

C#

```
void SetSplitBodies(  
    System.object PathVar,  
    System.object FlagVar  
)
```

C++/CLI

```
void SetSplitBodies(  
& System.Object^ PathVar,  
& System.Object^ FlagVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathVar

Array of full paths and file names of the split bodies

FlagVar

Array of Booleans indicating whether to include a body in this split-body feature

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::SetSplitBodies](#).

See Also

[ISplitBodyFeatureData Interface](#)

[ISplitBodyFeatureData Members](#)

[ISplitBodyFeatureData::ISetSplitBodies Method](#)

[ISplitBodyFeatureData::GetSplitBodies Method](#)

[ISplitBodyFeatureData::GetSplitBodiesCount Method](#)

[ISplitBodyFeatureData::IGetSplitBodies Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSplitBodies2 Method (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : SetSplitBodies2 Method (ISplitBodyFeatureData)

Edits the current split bodies in this Split feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSplitBodies2( _  
    ByVal PathVar As System.Object, _
```

```

    ByVal FlagVar As System.Object, _
    ByVal BodyOrigin As System.Object _
)

```

Visual Basic (Usage)



```

Dim instance As ISplitBodyFeatureData
Dim PathVar As System.Object
Dim FlagVar As System.Object
Dim BodyOrigin As System.Object

instance.SetSplitBodies2(PathVar, FlagVar, BodyOrigin)

```

C#

```

void SetSplitBodies2(
    System.object PathVar,
    System.object FlagVar,
    System.object BodyOrigin
)

```

C++/CLI

```

void SetSplitBodies2(
    & System.Object^ PathVar,
    & System.Object^ FlagVar,
    & System.Object^ BodyOrigin
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathVar

Array of paths and file names of the part documents to which to save the split bodies in this Split feature

FlagVar

Array of booleans indicating whether to consume each corresponding PathVar body; true to remove it from the original part, false to not

BodyOrigin

Array of sketch points, vertices, or reference points indicating the origins of each PathVar body; null elements are also permitted

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::SetSplitBodies2](#).

Remarks

Call this method after calling [ISplitBodyFeatureData::GetSplitBodies](#) or [ISplitBodyFeatureData::IGetSplitBodies](#) to change which split bodies to include in this Split feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)

[ISplitBodyFeatureData Members](#)

[IFeatureManager::PreSplitBody2](#)

[IFeatureManager::PostSplitBody](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TemplatePath Property (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : TemplatePath Property (ISplitBodyFeatureData)

Gets or sets the template to use to make this Split feature.

.NET Syntax

```
Property TemplatePath As System.String
```



```
Dim instance As ISplitBodyFeatureData
Dim value As System.String

instance.TemplatePath = value

value = instance.TemplatePath
```

```
System.string TemplatePath {get; set;}
```

```
property System.String^ TemplatePath {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and file name of the template

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::TemplatePath](#).

Remarks

Set this property only if [ISplitBodyFeatureData::OverrideDefaultTemplateSettings](#) is set to true.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

TrimTools Property (ISplitBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitBodyFeatureData Interface](#) : TrimTools Property (ISplitBodyFeatureData)

Gets the trimming surfaces used as trim tools in this Split feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

```
Property TrimTools As System.Object
```



```
Dim instance As ISplitBodyFeatureData
Dim value As System.Object

instance.TrimTools = value
```

```
value = instance.TrimTools
```

C#

```
System.Object TrimTools {get; set;}
```

C++/CLI

```
property System.Object^ TrimTools {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of trimming surfaces used as trim tools:

- Planar and non-planar faces
- Reference planes
- Reference surfaces
- Sketches

Visual Basic for Applications (VBA) Syntax

See [SplitBodyFeatureData::TrimTools](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitBodyFeatureData Interface](#)
[ISplitBodyFeatureData Members](#)
[ISplitBodyFeatureData::GetTrimToolsCount Method](#)
[ISplitBodyFeatureData::!GetTrimTools Method](#)
[ISplitBodyFeatureData::!SetTrimTools Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0