

SOLIDWORKS API (.NET, VBA, C#) — Reference

(293/337): ISplitLineFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ISplitLineFeatureData (Type)

ISplitLineFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitLineFeatureData Interface

Allows access to a split line feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISplitLineFeatureData
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
```

C#

```
public interface ISplitLineFeatureData
```

C++/CLI

```
public interface class ISplitLineFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData](#).

Example

[Create Projection Split Line Feature \(VBA\)](#)
[Create Projection Split Line Feature \(VB.NET\)](#)
[Create Projection Split Line Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[SplitLineFeatureData](#)

See Also

[ISplitLineFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSplitLineIntersect Method](#)
[IModelDoc2::InsertSplitLineProject Method](#)
[IModelDoc2::InsertSplitLineSil Method](#)

ISplitLineFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitLineFeatureData Interface

For a list of all members of this type, see [ISplitLineFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to a split line feature.

	GetContoursCount	Gets the number of selected contours for this split line feature.
	GetFacesCount	Gets the number of faces split by this split line.
	GetSplitTargetsCount	Gets the number of faces or bodies to split.
	GetSplitToolsCount	Gets the number of tools used to make the split.
	GetType	Gets the type of split line feature.
	IGetContours	Gets the selected contours for this split line feature.
	IGetFaces	Gets the faces split by the split line.
	IGetSplitTargets	Gets the faces or bodies to split.
	IGetSplitTools	Gets the tools to use to make the split.
	ISetContours	Sets the selected contours for this split line feature.
	ISetFaces	Sets the faces split by the split line.
	ISetSplitTargets	Sets the faces or bodies to split.
	ISetSplitTools	Sets the tools used to make the split.
	ReleaseSelectionAccess	Releases access to the selections that define this split line feature.

[Top](#)

 See Also

[ISplitLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSplitLineIntersect Method](#)
[IModelDoc2.InsertSplitLineProject Method](#)
[IModelDoc2.InsertSplitLineSil Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISplitLineFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitLineFeatureData Interface

The following tables list the members exposed by [ISplitLineFeatureData](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle by which to project the split line feature.
 Contours	Gets or sets the contours for this split line feature.
 Faces	Gets or sets the faces to split by the split line.
 PullDirectionBase	Gets or sets the entity indicating the direction of pull of this split line feature.
 PullDirectionType	Gets the type of entity indicating the direction of pull for this split line feature.
 ReverseDirection	Gets or sets whether to reverse the direction of pull of this split line.
 SingleDirection	Gets or sets whether the projection split line is in a single direction.
 Sketch	Gets the seed sketch for this split line feature.
 SplitAll	Gets or sets whether to split all targets.
 SplitTargets	Gets or sets the faces or bodies to split.
 SplitTools	Gets or sets the tools used to make the split.
 SplitType	Gets or sets the type of split.

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Gains access to a split line feature.

	GetContoursCount	Gets the number of selected contours for this split line feature.
	GetFacesCount	Gets the number of faces split by this split line.
	GetSplitTargetsCount	Gets the number of faces or bodies to split.
	GetSplitToolsCount	Gets the number of tools used to make the split.
	GetType	Gets the type of split line feature.
	IGetContours	Gets the selected contours for this split line feature.
	IGetFaces	Gets the faces split by the split line.
	IGetSplitTargets	Gets the faces or bodies to split.
	IGetSplitTools	Gets the tools to use to make the split.
	ISetContours	Sets the selected contours for this split line feature.
	ISetFaces	Sets the faces split by the split line.
	ISetSplitTargets	Sets the faces or bodies to split.
	ISetSplitTools	Sets the tools used to make the split.
	ReleaseSelectionAccess	Releases access to the selections that define this split line feature.

[Top](#)

 See Also

[ISplitLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSplitLineIntersect Method](#)
[IModelDoc2::InsertSplitLineProject Method](#)
[IModelDoc2::InsertSplitLineSil Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISplitLineFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISplitLineFeatureData Interface

For a list of all members of this type, see [ISplitLineFeatureData members](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle by which to project the split line feature.
 Contours	Gets or sets the contours for this split line feature.
 Faces	Gets or sets the faces to split by the split line.
 PullDirectionBase	Gets or sets the entity indicating the direction of pull of this split line feature.
 PullDirectionType	Gets the type of entity indicating the direction of pull for this split line feature.
 ReverseDirection	Gets or sets whether to reverse the direction of pull of this split line.
 SingleDirection	Gets or sets whether the projection split line is in a single direction.
 Sketch	Gets the seed sketch for this split line feature.
 SplitAll	Gets or sets whether to split all targets.
 SplitTargets	Gets or sets the faces or bodies to split.
 SplitTools	Gets or sets the tools used to make the split.
 SplitType	Gets or sets the type of split.

[Top](#)

 See Also

[ISplitLineFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSplitLineIntersect Method](#)

AccessSelections Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : AccessSelections Method (ISplitLineFeatureData)

Gains access to a split line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component for the feature

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::AccessSelections](#).

Example

See the [ISplitLineFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you modified the feature
- [ISplitLineFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : Angle Property (ISplitLineFeatureData)

Gets or sets the angle by which to project the split line feature.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians by which to project the split line feature

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::Angle](#).

Remarks

This property is valid only if [ISplitLineFeatureData::GetType](#) is set to [swSplitLineFeatureType_e.swSplitLineFeatureType_Draft](#).

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::SplitType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Contours Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : Contours Property (ISplitLineFeatureData)

Gets or sets the contours for this split line feature.

.NET Syntax

Visual Basic (Declaration)

Property Contours As System.Object

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Object
```

```
instance.Contours = value
```

```
value = instance.Contours
```

C#

```
System.object Contours {get; set;}
```

C++/CLI

```
property System.Object^ Contours {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of contours of one of the following types:

- [Sketch contour](#)
- [Sketch region](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::Contours](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetContoursCount Method](#)
[ISplitLineFeatureData::IGetContours Method](#)
[ISplitLineFeatureData::ISetContours Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Faces Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : Faces Property (ISplitLineFeatureData)

Gets or sets the faces to split by the split line.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Faces](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::Faces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetFacesCount Method](#)
[ISplitLineFeatureData::IGetFaces Method](#)
[ISplitLineFeatureData::ISetFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetContoursCount Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : GetContoursCount Method (ISplitLineFeatureData)

Gets the number of selected contours for this split line feature.

.NET Syntax

Visual Basic (Declaration)

Function GetContoursCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Integer

value = instance.GetContoursCount()
```

C#

```
System.int GetContoursCount()
```

C++/CLI

```
System.int GetContoursCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of selected contours

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::GetContoursCount](#).

Remarks

Call this method before calling [ISplitLineFeatureData::IGetContours](#) to determine the size of the array for that method.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetContours Method](#)
[ISplitLineFeatureData::Contours Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesCount Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : GetFacesCount Method (ISplitLineFeatureData)

Gets the number of faces split by this split line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Integer

value = instance.GetFacesCount()
```

C#

```
System.int GetFacesCount()
```

C++/CLI

```
System.int GetFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [ISplitLineFeatureData::GetFacesCount](#).

Remarks

Call this method before calling [ISplitLineFeatureData::IGetFaces](#) to determine the size of the array for that method.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetFaces Method](#)
[ISplitLineFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitTargetsCount Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : GetSplitTargetsCount Method (ISplitLineFeatureData)

Gets the number of faces or bodies to split.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitTargetsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Integer  
  
value = instance.GetSplitTargetsCount()
```

C#

```
System.int GetSplitTargetsCount()
```

C++/CLI

```
System.int GetSplitTargetsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces or bodies to split

Visual Basic for Applications (VBA) Syntax

See [ISplitLineFeatureData::GetSplitTargetsCount](#).

Remarks

Call this method before calling [ISplitLineFeatureData::IGetSplitTargets](#) to get the size of the array for that method.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetSplitTargets Method](#)
[ISplitLineFeatureData::SplitTargets Property](#)
[ISplitLineFeatureData::SplitAll Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitToolsCount Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : GetSplitToolsCount Method (ISplitLineFeatureData)

Gets the number of tools used to make the split.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitToolsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Integer  
  
value = instance.GetSplitToolsCount()
```

C#

```
System.int GetSplitToolsCount()
```

C++/CLI

```
System.int GetSplitToolsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of tools used to make the split

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::GetSplitToolsCount](#).

Remarks

Call this method before calling [ISplitLineFeatureData::ISetSplitTargets](#) to determine the size of the array for that method.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetSplitTargets Method](#)
[ISplitLineFeatureData::SplitTargets Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (ISplitLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : GetType Method (ISplitLineFeatureData)

Gets the type of split line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Integer  
  
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of split line feature as defined in [swSplitLineFeatureType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::GetType](#).

Example

[Get Type of Split Line \(VBA\)](#)
[Get Type of Split Line \(VB.NET\)](#)
[Get Type of Split Line \(C#\)](#)

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::SplitType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetContours Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : IGetContours Method (ISplitLineFeatureData)

Gets the selected contours for this split line feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetContours( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim value As System.Object
```

```
value = instance.IGetContours(Count)
```

C#

```
System.object IGetContours(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetContours(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of selected contours

Return Value

- in-process, unmanaged C++: Pointer to an array of contours of these types:
 - [Sketch contour](#)
 - [Sketch region](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISplitLineFeatureData::GetContoursCount](#) before calling this method to determine the size of the array for this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetContours Method](#)
[ISplitLineFeatureData::Contours Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : IGetFaces Method (ISplitLineFeatureData)

Gets the faces split by the split line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim value As Face2
```

```
value = instance.IGetFaces(Count)
```

C#

```
Face2 IGetFaces(  
    System.int Count  
)
```

C++/CLI

```
Face2^ IGetFaces(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of faces to split

Return Value

- in-process, unmanaged C++: Pointer to an array of split [faces](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISplitLineFeatureData::GetFacesCount](#) to determine the size of the array for this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetFaces Method](#)
[ISplitLineFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSplitTargets Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : IGetSplitTargets Method (ISplitLineFeatureData)

Gets the faces or bodies to split.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSplitTargets( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetSplitTargets(Count)
```

C#

```
System.object IGetSplitTargets(  
    System.int Count  
)
```

C++/CLI



```
System.Object^ IGetSplitTargets(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of faces or bodies to split

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) or [bodies](#) to split
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISplitLineFeatureData::GetSplitTargetsCount](#) before calling this method to determine the size of the array for this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetSplitTargets Method](#)
[ISplitLineFeatureData::SplitTargets Property](#)
[ISplitLineFeatureData::SplitAll Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSplitTools Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : IGetSplitTools Method (ISplitLineFeatureData)

Gets the tools to use to make the split.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSplitTools(  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetSplitTools(Count)
```

C#

```
System.object IGetSplitTools(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetSplitTools(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of tools used to make the split

Return Value

- in-process, unmanaged C++: Pointer to an array of tools used to make the split (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

[Reference planes](#), [planar model faces](#), and [bodies](#) are valid tools to make a split. Call [ISplitLineFeatureData::GetSplitToolsCount](#) before calling this method to determine the size of the array for this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ISetSplitTools Method](#)
[ISplitLineFeatureData::SplitTools Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetContours Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : ISetContours Method (ISplitLineFeatureData)

Sets the selected contours for this split line feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetContours(  
    ByVal Count As System.Integer, _  
    ByRef Contours As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim Contours As System.Object  
  
instance.ISetContours(Count, Contours)
```

C#

```
void ISetContours(  
    System.int Count,  
    ref System.object Contours  
)
```

C++/CLI

```
void ISetContours(  
& System.int Count,  
& System.Object^% Contours  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of contours

Contours

- in-process, unmanaged C++: Pointer to an array of contours of these types:
 - [Sketch contour](#)
 - [Sketch region](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData.GetContoursCount Method](#)
[ISplitLineFeatureData.GetContours Method](#)
[ISplitLineFeatureData::Contours Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFaces Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : ISetFaces Method (ISplitLineFeatureData)

Sets the faces split by the split line.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim EntIn As Face2  
  
instance.ISetFaces(Count, EntIn)
```

C#

```
void ISetFaces(  
    System.int Count,  
    ref Face2 EntIn  
)
```

C++/CLI

```
void ISetFaces(  
& System.int Count,  
& Face2^% EntIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

EntIn

- in-process, unmanaged C++: Pointer to an array of split [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::ISetFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetFacesCount Method](#)
[ISplitLineFeatureData::GetFaces Method](#)
[ISplitLineFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSplitTargets Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : ISetSplitTargets Method (ISplitLineFeatureData)

Sets the faces or bodies to split.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSplitTargets( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetSplitTargets(Count, DispArr)
```

C#

```
void ISetSplitTargets(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetSplitTargets(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces or bodies to split

DispArr

- in-process, unmanaged C++: Pointer to an array of [faces](#) or [bodies](#) to split
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::ISetSplitTargets](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetSplitTargetsCount Method](#)
[ISplitLineFeatureData::ISetSplitTargets Method](#)
[ISplitLineFeatureData::SplitTargets Property](#)
[ISplitLineFeatureData::SplitAll Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSplitTools Method (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : ISetSplitTools Method (ISplitLineFeatureData)

Sets the tools used to make the split.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSplitTools( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetSplitTools(Count, DispArr)
```

C#

```
void ISetSplitTools(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetSplitTools(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of tools used to make the split

DispArr

- in-process, unmanaged C++: Pointer to an array of tools used to make the split (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::ISetSplitTools](#).

Remarks

[Reference planes](#), [planar model faces](#), and [bodies](#) are valid tools for a split.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetSplitToolsCount Method](#)
[ISplitLineFeatureData::ISetSplitTools Method](#)
[ISplitLineFeatureData::SplitTools Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirectionBase Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : PullDirectionBase Property (ISplitLineFeatureData)

Gets or sets the entity indicating the direction of pull of this split line feature.

.NET Syntax

Visual Basic (Declaration)

Property PullDirectionBase As System.Object

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Object
```

```
instance.PullDirectionBase = value
```

```
value = instance.PullDirectionBase
```

C#

```
System.Object PullDirectionBase {get; set;}
```

C++/CLI

```
property System.Object^ PullDirectionBase {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entity indicating the direction of pull: [axis](#), [edge](#), [face](#), or [plane](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::PullDirectionBase](#).

Remarks

This property is only valid when [ISplitLineFeatureData::GetType](#) is set to [swSplitLineFeatureType_e.swSplitLineFeatureType_Draft](#).
After calling this property, call [ISplitLineFeatureData::PullDirectionType](#) to determine the type of entity.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ReverseDirection Property](#)
[ISplitLineFeatureData::SingleDirection Property](#)
[ISplitLineFeatureData::SplitType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PullDirectionType Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : PullDirectionType Property (ISplitLineFeatureData)

Gets the type of entity indicating the direction of pull for this split line feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PullDirectionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Integer  
  
value = instance.PullDirectionType
```

C#

```
System.int PullDirectionType {get;}
```

C++/CLI

```
property System.int PullDirectionType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of entity as defined in [swSelectType_e](#):

- swSelDATUMAXES
- swSelEDGES
- swSelFACES
- swSelDATUMPLANES
- swSelDATUMPOINT
- swSelVERTICES

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::PullDirectionType](#).

Remarks

Before calling this property, call [ISplitLineFeatureData::PullDirectionBase](#) to get the entity that indicates the pull direction.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::ReverseDirection Property](#)
[ISplitLineFeatureData::SingleDirection Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISplitLineFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : ReleaseSelectionAccess Method (ISplitLineFeatureData)

Releases access to the selections that define this split line feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::ReleaseSelectionAccess](#).

Example

See the [ISplitLineFeatureData](#) examples.

Example

[Get Type of Split Line \(VBA\)](#)

Remarks

[ISplitLineFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISplitLineFeatureData)

[See Also](#)



Gets or sets whether to reverse the [direction of pull](#) of this split line.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse direction, false to not

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::ReverseDirection](#).

Example

See the [ISplitLineFeatureData](#) examples.

Remarks

If creating a projection split line, then [ISplitLineFeatureData::SingleDirection](#) must be set to true to access this property.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::PullDirectionBase Property](#)
[ISplitLineFeatureData::PullDirectionType Property](#)
[ISplitLineFeatureData::SingleDirection Property](#)
[ISplitLineFeatureData::SplitType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SingleDirection Property (ISplitLineFeatureData)

[See Also](#)



Gets or sets whether the projection split line is in a single direction.

.NET Syntax

```
Property SingleDirection As System.Boolean
```



```
Dim instance As ISplitLineFeatureData
Dim value As System.Boolean

instance.SingleDirection = value

value = instance.SingleDirection
```

```
System.bool SingleDirection {get; set;}
```

```
property System.bool SingleDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if single direction, false if not

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::SingleDirection](#).

Example

See the [ISplitLineFeatureData](#) examples.

Remarks

This property is valid only if [ISplitLineFeatureData::GetType](#) is set to [swSplitLineFeatureType_e.swSplitLineFeatureType_Projection](#).

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::PullDirectionBase Property](#)
[ISplitLineFeatureData::PullDirectionType Property](#)
[ISplitLineFeatureData::ReverseDirection Property](#)
[ISplitLineFeatureData::SplitType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Sketch Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : Sketch Property (ISplitLineFeatureData)

Gets the seed sketch for this split line feature.

.NET Syntax

```
Property Sketch As Sketch
```



```
Dim instance As ISplitLineFeatureData
Dim value As Sketch

instance.Sketch = value

value = instance.Sketch
```

C#

```
Sketch Sketch {get; set;}
```

C++/CLI

```
property Sketch^ Sketch {
    Sketch^ get();
    void set ( & Sketch^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::Sketch](#).

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitAll Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : SplitAll Property (ISplitLineFeatureData)

Gets or sets whether to split all targets.

.NET Syntax

Visual Basic (Declaration)

```
Property SplitAll As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Boolean

instance.SplitAll = value

value = instance.SplitAll
```

C#

```
System.bool SplitAll {get; set;}
```

C++/CLI

```
property System.bool SplitAll {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to split all targets, false to not

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::SplitAll](#).

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetSplitTargetsCount Method](#)
[ISplitLineFeatureData::!GetSplitTargets Method](#)
[ISplitLineFeatureData::!SetSplitTargets Method](#)
[ISplitLineFeatureData::SplitTargets Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitTargets Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : SplitTargets Property (ISplitLineFeatureData)

Gets or sets the faces or bodies to split.

.NET Syntax

Visual Basic (Declaration)

Property SplitTargets As System.Object

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Object
```

```
instance.SplitTargets = value
```

```
value = instance.SplitTargets
```

C#

```
System.Object SplitTargets {get; set;}
```

C++/CLI

```
property System.Object^ SplitTargets {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) or [bodies](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::SplitTargets](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetSplitTargetsCount Method](#)
[ISplitLineFeatureData::!GetSplitTargets Method](#)
[ISplitLineFeatureData::!SetSplitTargets Method](#)
[ISplitLineFeatureData::SplitAll Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitTools Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : SplitTools Property (ISplitLineFeatureData)

Gets or sets the tools used to make the split.

.NET Syntax

Visual Basic (Declaration)

Property SplitTools As System.Object

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData  
Dim value As System.Object
```

```
instance.SplitTools = value
```

```
value = instance.SplitTools
```

C#

```
System.Object SplitTools {get; set;}
```

C++/CLI

```
property System.Object^ SplitTools {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of tools used to make the split

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::SplitTools](#).

Remarks

[Reference planes](#), [planar model faces](#), and [bodies](#) are valid tools for a split.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetSplitToolsCount Method](#)
[ISplitLineFeatureData::!GetSplitTools Method](#)
[ISplitLineFeatureData::!SetSplitTools Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitType Property (ISplitLineFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISplitLineFeatureData Interface](#) : SplitType Property (ISplitLineFeatureData)

Gets or sets the type of split.

.NET Syntax

Visual Basic (Declaration)

Property SplitType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISplitLineFeatureData
Dim value As System.Integer

instance.SplitType = value
value = instance.SplitType
```

C#

```
System.int SplitType {get; set;}
```

C++/CLI

```
property System.int SplitType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of split as defined in [swSplitLineFeatureType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SplitLineFeatureData::SplitType](#).

See Also

[ISplitLineFeatureData Interface](#)
[ISplitLineFeatureData Members](#)
[ISplitLineFeatureData::GetType Method](#)