

SOLIDWORKS API (.NET VBA C#) — Reference (294/337): ISpring-IStatusBarPane

SOLIDWORKS API Documentation (converted from CHM)

ISpring (Type)

ISpring Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISpring Interface

Allows access to the geometry of a spring.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISpring

Visual Basic (Usage)



Dim instance As [ISpring](#)

C#

public interface ISpring

C++/CLI

public interface class ISpring

Visual Basic for Applications (VBA) Syntax

See [Spring](#).

Accessors

[IModeler::CreateSpring](#)

Access Diagram

[Spring](#)

See Also

[ISpring Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMacroFeatureData Interface](#)

ISpring Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISpring Interface

For a list of all members of this type, see [ISpring members](#).

Public Methods

Name	Description
GetProfilePoints	Gets the points for creating the profile sketch.
GetSpringBody	Gets the spring body.

[Top](#)

See Also

ISpring Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISpring Interface

The following tables list the members exposed by [ISpring](#).

Public Properties

Name	Description
BaseProfile	Gets or sets the base profile of the spring.
Clockwise	Gets or sets the direction of the coils of the spring.
DefineType	Gets or sets how the number of revolutions, pitch, and height of the spring are defined.
EndingEndLength	Gets or sets the ending end length of a torsion spring.
EndingEndType	Gets or sets the ending end type for either an extension spring or a torsion spring.
EndingPitch	Gets or sets pitch of the end section of a compression spring.
EndingRevolution	Gets or sets the number of revolutions for the end section of a compression spring.
GroundType	Gets or sets whether the ends of compression spring are ground to a flat surface or have the same pitch as the coil.
Height	Gets or sets the height of the spring.
Pitch	Gets or sets the pitch of the spring.
ProfileParameters	Gets or sets the section profile parameters for the spring.
ProfileType	Gets or sets the section profile type of the spring.
ReverseDirection	Gets or sets the direction of a compression, extension, or torsion spring.
Revolution	Gets or sets the number of revolutions for the spring.
SectionProfile	Gets or sets the section profile for the spring.
SectionProfileCenter	Gets or sets the center point of the section profile of the spring.
SpringType	Gets or sets the type of parameters that define the spring.
StartingEndLength	Gets or sets the starting end length of a torsion spring.
StartingEndType	Gets or sets the starting end type for either an extension spring or a torsion spring.
StartingPitch	Gets the pitch of the starting section of a compression spring.
StartingRevolution	Gets or sets the number of revolutions for the starting section of a compression spring.
TaperAngle	Gets or sets the angle by which to taper a compression spring.
TaperOutward	Gets or sets the direction by which to taper the helix of a compression spring.
Tolerance	Gets or sets the precision of the helical curve.

[Top](#)

Public Methods

Name	Description
GetProfilePoints	Gets the points for creating the profile sketch.
GetSpringBody	Gets the spring body.

[Top](#)

See Also

ISpring Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISpring Interface

For a list of all members of this type, see [ISpring members](#).

Public Properties

Name	Description
 BaseProfile	Gets or sets the base profile of the spring.
 Clockwise	Gets or sets the direction of the coils of the spring.
 DefineType	Gets or sets how the number of revolutions, pitch, and height of the spring are defined.
 EndingEndLength	Gets or sets the ending end length of a torsion spring.
 EndingEndType	Gets or sets the ending end type for either an extension spring or a torsion spring.
 EndingPitch	Gets or sets pitch of the end section of a compression spring.
 EndingRevolution	Gets or sets the number of revolutions for the end section of a compression spring.
 GroundType	Gets or sets whether the ends of compression spring are ground to a flat surface or have the same pitch as the coil.
 Height	Gets or sets the height of the spring.
 Pitch	Gets or sets the pitch of the spring.
 ProfileParameters	Gets or sets the section profile parameters for the spring.
 ProfileType	Gets or sets the section profile type of the spring.
 ReverseDirection	Gets or sets the direction of a compression, extension, or torsion spring.
 Revolution	Gets or sets the number of revolutions for the spring.
 SectionProfile	Gets or sets the section profile for the spring.
 SectionProfileCenter	Gets or sets the center point of the section profile of the spring.
 SpringType	Gets or sets the type of parameters that define the spring.
 StartingEndLength	Gets or sets the starting end length of a torsion spring.
 StartingEndType	Gets or sets the starting end type for either an extension spring or a torsion spring.
 StartingPitch	Gets the pitch of the starting section of a compression spring.
 StartingRevolution	Gets or sets the number of revolutions for the starting section of a compression spring.
 TaperAngle	Gets or sets the angle by which to taper a compression spring.
 TaperOutward	Gets or sets the direction by which to taper the helix of a compression spring.
 Tolerance	Gets or sets the precision of the helical curve.

[Top](#)

See Also

[ISpring Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMacroFeatureData Interface](#)

BaseProfile Property (ISpring)

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : BaseProfile Property (ISpring)

Gets or sets the base profile of the spring.

.NET Syntax

Visual Basic (Declaration)

Property BaseProfile As Body2

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As Body2  
  
instance.BaseProfile = value  
value = instance.BaseProfile
```

C#

```
Body2 BaseProfile {get; set;}
```

C++/CLI

```
property Body2^ BaseProfile {  
    Body2^ get();  
    void set ( & Body2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Body](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [Spring::BaseProfile](#).

Remarks

This body references an edge that sets the overall diameter of the spring. The profile of the coil (called a section profile) is swept around the radius of this circular edge.

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::GetProfilePoints Method](#)
[ISpring::ProfileParameters Property](#)
[ISpring::ProfileType Property](#)
[ISpring::SectionProfile Property](#)
[ISpring::SectionProfileCenter Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Clockwise Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : Clockwise Property (ISpring)

Gets or sets the direction of the coils of the spring.

.NET Syntax

Visual Basic (Declaration)

```
Property Clockwise As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Boolean
```

```
instance.Clockwise = value  
value = instance.Clockwise
```

C#

```
System.bool Clockwise {get; set;}
```

C++/CLI

```
property System.bool Clockwise {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to set the direction of the coils of the spring clockwise, false to set their direction counter-clockwise

Visual Basic for Applications (VBA) Syntax

See [Spring.Clockwise](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefineType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : DefineType Property (ISpring)

Gets or sets how the number of revolutions, pitch, and height of the spring are defined.

.NET Syntax

Visual Basic (Declaration)

```
Property DefineType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Integer  
  
instance.DefineType = value  
value = instance.DefineType
```

C#

```
System.int DefineType {get; set;}
```

C++/CLI

```
property System.int DefineType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

How the number of revolutions, pitch, and height of spring are defined as defined in [swSpringDefineType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Spring::DefineType](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::SpringType Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndingEndLength Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : EndingEndLength Property (ISpring)

Gets or sets the ending end length of a torsion spring.

.NET Syntax

Visual Basic (Declaration)

Property EndingEndLength As System.Double

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.EndingEndLength = value
value = instance.EndingEndLength
```

C#

```
System.double EndingEndLength {get; set;}
```

C++/CLI

```
property System.double EndingEndLength {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ending end length

Visual Basic for Applications (VBA) Syntax

See [Spring::EndingEndLength](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingEndType Property](#)
[ISpring::StartingEndLength Property](#)
[ISpring::StartingEndType Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

EndingEndType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : EndingEndType Property (ISpring)

Gets or sets the ending end type for either an extension spring or a torsion spring.

.NET Syntax

Visual Basic (Declaration)

Property EndingEndType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Integer

instance.EndingEndType = value
value = instance.EndingEndType
```

C#

```
System.int EndingEndType {get; set;}
```

C++/CLI

```
property System.int EndingEndType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ending end type as defined in [swSpringExtensionEndType_e](#) for an extension spring or [swSpringTorsionEndType_e](#) for a torsion spring

Visual Basic for Applications (VBA) Syntax

See [Spring::EndingEndType](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::StartingEndType Property](#)
[ISpring::StartingEndLength Property](#)
[ISpring::EndingEndLength Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

EndingPitch Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : EndingPitch Property (ISpring)

Gets or sets pitch of the end section of a compression spring.

.NET Syntax

Visual Basic (Declaration)

Property EndingPitch As System.Double

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.EndingPitch = value

value = instance.EndingPitch
```

C#

```
System.double EndingPitch {get; set;}
```

C++/CLI

```
property System.double EndingPitch {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch of the end section

Visual Basic for Applications (VBA) Syntax

See [Spring::EndingPitch](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingRevolution Property](#)
[ISpring::Height Property](#)
[ISpring::Pitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::StartingPitch Property](#)
[ISpring::StartingRevolution Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndingRevolution Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : EndingRevolution Property (ISpring)

Gets or sets the number of revolutions for the end section of a compression spring.

.NET Syntax

Visual Basic (Declaration)

```
Property EndingRevolution As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.EndingRevolution = value

value = instance.EndingRevolution
```

C#

```
System.double EndingRevolution {get; set;}
```

C++/CLI

```
property System.double EndingRevolution {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of revolutions for the end section

Visual Basic for Applications (VBA) Syntax

See [Spring::EndingRevolution](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::StartingRevolution Property](#)
[ISpring::StartingPitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::Pitch Property](#)
[ISpring::Height Property](#)
[ISpring::EndingPitch Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetProfilePoints Method (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : GetProfilePoints Method (ISpring)

Gets the points for creating the profile sketch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfilePoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Object

value = instance.GetProfilePoints()
```

C#

```
System.object GetProfilePoints()
```

C++/CLI

```
System.Object^ GetProfilePoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of points for creating the profile sketch

Visual Basic for Applications (VBA) Syntax

See [Spring::GetProfilePoints](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::BaseProfile Property](#)
[ISpring::ProfileParameters Property](#)
[ISpring::ProfileType Property](#)
[ISpring::SectionProfile Property](#)
[ISpring::SectionProfileCenter Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSpringBody Method (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : GetSpringBody Method (ISpring)

Gets the spring body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSpringBody() As Body2
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As Body2  
  
value = instance.GetSpringBody()
```

C#

```
Body2 GetSpringBody()
```

C++/CLI

```
Body2^ GetSpringBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Body](#)

Visual Basic for Applications (VBA) Syntax

See [Spring::GetSpringBody](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GroundType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : GroundType Property (ISpring)

Gets or sets whether the ends of compression spring are ground to a flat surface or have the same pitch as the coil.

.NET Syntax

Visual Basic (Declaration)

Property GroundType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Integer

instance.GroundType = value

value = instance.GroundType
```

C#

```
System.int GroundType {get; set;}
```

C++/CLI

```
property System.int GroundType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0 for ends to be ground to a flat surface, 1 for ends to have same pitch as the coil

Visual Basic for Applications (VBA) Syntax

See [Spring::GroundType](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : Height Property (ISpring)

Gets or sets the height of the spring.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Double

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.Height = value

value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height

Visual Basic for Applications (VBA) Syntax

See [Spring::Height](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingPitch Property](#)
[ISpring::EndingRevolution Property](#)
[ISpring::Pitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::StartingPitch Property](#)
[ISpring::StartingRevolution Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Pitch Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : Pitch Property (ISpring)

Gets or sets the pitch of the spring.

.NET Syntax

Visual Basic (Declaration)

```
Property Pitch As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Double
```

```
instance.Pitch = value
```

```
value = instance.Pitch
```

C#

```
System.double Pitch {get; set;}
```

C++/CLI

```
property System.double Pitch {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch

Visual Basic for Applications (VBA) Syntax

See [Spring::Pitch](#).

 See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::StartingRevolution Property](#)
[ISpring::StartingPitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::Height Property](#)
[ISpring::EndingRevolution Property](#)
[ISpring::EndingPitch Property](#)

 Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileParameters Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : ProfileParameters Property (ISpring)

Gets or sets the section profile parameters for the spring.

 .NET Syntax

Visual Basic (Declaration)

Property ProfileParameters As System.Object

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Object  
  
instance.ProfileParameters = value  
value = instance.ProfileParameters
```

C#

```
System.object ProfileParameters {get; set;}
```

C++/CLI

```
property System.Object^ ProfileParameters {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of three doubles (see [Remarks](#))

 Visual Basic for Applications (VBA) Syntax

See [Spring::ProfileParameters](#).

 Remarks

The values of the array depend on the type of profile.

Type of profile	Values
Circular	[<i>diameter</i> , 0, 0]
Square	[<i>height</i> , <i>width</i>]

Trapezoid

[*height, bottom, top*]

Use [ISpring::ProfileType](#) to set the spring's type of profile.

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::BaseProfile Property](#)
[ISpring::GetProfilePoints Method](#)
[ISpring::SectionProfile Property](#)
[ISpring::SectionProfileCenter Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : ProfileType Property (ISpring)

Gets or sets the section profile type of the spring.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Integer  
  
instance.ProfileType = value  
value = instance.ProfileType
```

C#

```
System.int ProfileType {get; set;}
```

C++/CLI

```
property System.int ProfileType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Section profile type as defined in [swSpringProfileType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Spring::ProfileType](#).

Remarks

Use [ISpring::ProfileParameters](#) to set the spring's section profile parameters.

See Also

[ISpring Interface](#)
[ISpring Members](#)

[ISpring::BaseProfile Property](#)
[ISpring::GetProfilePoints Method](#)
[ISpring::SectionProfile Property](#)
[ISpring::SectionProfileCenter Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : ReverseDirection Property (ISpring)

Gets or sets the direction of a compression, extension, or torsion spring.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction, false to not

Visual Basic for Applications (VBA) Syntax

See [Spring::ReverseDirection](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Revolution Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : Revolution Property (ISpring)

Gets or sets the number of revolutions for the spring.

.NET Syntax

Property Revolution As System.Double



```
Dim instance As ISpring
Dim value As System.Double

instance.Revolution = value

value = instance.Revolution
```

```
System.double Revolution {get; set;}
```

```
property System.double Revolution {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of revolutions

Visual Basic for Applications (VBA) Syntax

See [Spring::Revolution](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingPitch Property](#)
[ISpring::EndingRevolution Property](#)
[ISpring::Height Property](#)
[ISpring::Pitch Property](#)
[ISpring::StartingPitch Property](#)
[ISpring::StartingRevolution Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SectionProfile Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : SectionProfile Property (ISpring)

Gets or sets the section profile for the spring.

.NET Syntax

Property SectionProfile As Body2



```
Dim instance As ISpring
Dim value As Body2

instance.SectionProfile = value

value = instance.SectionProfile
```

C#

```
Body2 SectionProfile {get; set;}
```

C++/CLI

```
property Body2^ SectionProfile {  
    Body2^ get();  
    void set ( & Body2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Body](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [Spring::SectionProfile](#).

Remarks

The profile refers to the body associated with a circular edge that determines the base diameter of the spring. For example, to create a spring or a circular sketch, use [ISketch::GetContourEdges](#) or [ISketch::IGetContours](#) and [IEdge::GetBody](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::BaseProfile Property](#)
[ISpring::GetProfilePoints Method](#)
[ISpring::ProfileParameters Property](#)
[ISpring::ProfileType Property](#)
[ISpring::SectionProfileCenter Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SectionProfileCenter Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : SectionProfileCenter Property (ISpring)

Gets or sets the center point of the section profile of the spring.

.NET Syntax

Visual Basic (Declaration)

```
Property SectionProfileCenter As MathPoint
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As MathPoint  
  
instance.SectionProfileCenter = value  
  
value = instance.SectionProfileCenter
```

C#

```
MathPoint SectionProfileCenter {get; set;}
```

C++/CLI

```
property MathPoint^ SectionProfileCenter {  
    MathPoint^ get();
```

```
void set ( & MathPoint^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Center point](#)

Visual Basic for Applications (VBA) Syntax

See [Spring::SectionProfileCenter](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::BaseProfile Property](#)
[ISpring::GetProfilePoints Method](#)
[ISpring::ProfileParameters Property](#)
[ISpring::ProfileType Property](#)
[ISpring::SectionProfile Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SpringType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : SpringType Property (ISpring)

Gets or sets the type of parameters that define the spring.

.NET Syntax

Visual Basic (Declaration)

```
Property SpringType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Integer  
  
instance.SpringType = value  
  
value = instance.SpringType
```

C#

```
System.int SpringType {get; set;}
```

C++/CLI

```
property System.int SpringType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of parameters that define the spring as defined in [swSpringType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Spring::SpringType](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::DefineType Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingEndLength Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : StartingEndLength Property (ISpring)

Gets or sets the starting end length of a torsion spring.

.NET Syntax

Visual Basic (Declaration)

```
Property StartingEndLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Double  
  
instance.StartingEndLength = value  
  
value = instance.StartingEndLength
```

C#

```
System.double StartingEndLength {get; set;}
```

C++/CLI

```
property System.double StartingEndLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting end length

Visual Basic for Applications (VBA) Syntax

See [Spring::StartingEndLength](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingEndLength Property](#)
[ISpring::EndingEndType Property](#)
[ISpring::StartingEndType Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingEndType Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : StartingEndType Property (ISpring)

Gets or sets the starting end type for either an extension spring or a torsion spring.

.NET Syntax

Visual Basic (Declaration)

Property StartingEndType As System.Integer

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Integer

instance.StartingEndType = value
value = instance.StartingEndType
```

C#

```
System.int StartingEndType {get; set;}
```

C++/CLI

```
property System.int StartingEndType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting end type as defined in [swSpringExtensionEndType_e](#) for an extension spring or [swSpringTorsionEndType_e](#) for a torsion spring

Visual Basic for Applications (VBA) Syntax

See [Spring::StartingEndType](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::StartingEndLength Property](#)
[ISpring::EndingEndLength Property](#)
[ISpring::EndingEndType Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingPitch Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : StartingPitch Property (ISpring)

Gets the pitch of the starting section of a compression spring.

.NET Syntax

Visual Basic (Declaration)

Property StartingPitch As System.Double

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.StartingPitch = value

value = instance.StartingPitch
```

C#

```
System.double StartingPitch {get; set;}
```

C++/CLI

```
property System.double StartingPitch {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch of the starting section

Visual Basic for Applications (VBA) Syntax

See [Spring::StartingPitch](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingPitch Property](#)
[ISpring::EndingRevolution Property](#)
[ISpring::Height Property](#)
[ISpring::Pitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::StartingRevolution Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

StartingRevolution Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : StartingRevolution Property (ISpring)

Gets or sets the number of revolutions for the starting section of a compression spring.

.NET Syntax

Visual Basic (Declaration)

```
Property StartingRevolution As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.StartingRevolution = value

value = instance.StartingRevolution
```

C#

```
System.double StartingRevolution {get; set;}
```

C++/CLI

```
property System.double StartingRevolution {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of revolutions for the starting section

Visual Basic for Applications (VBA) Syntax

See [Spring::StartingRevolution](#).

See Also

[ISpring Interface](#)
[ISpring Members](#)
[ISpring::EndingPitch Property](#)
[ISpring::EndingRevolution Property](#)
[ISpring::Height Property](#)
[ISpring::Pitch Property](#)
[ISpring::Revolution Property](#)
[ISpring::StartingPitch Property](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

TaperAngle Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : TaperAngle Property (ISpring)

Gets or sets the angle by which to taper a compression spring.

.NET Syntax

Visual Basic (Declaration)

```
Property TaperAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.TaperAngle = value

value = instance.TaperAngle
```

C#

```
System.double TaperAngle {get; set;}
```

C++/CLI

```
property System.double TaperAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle by which to taper the spring

Visual Basic for Applications (VBA) Syntax

See [Spring::TaperAngle](#).

Remarks

Use [ISpring::TaperOutward](#) to set the direction of the taper outward or inward.

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

TaperOutward Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : TaperOutward Property (ISpring)

Gets or sets the direction by which to taper the helix of a compression spring.

.NET Syntax

Visual Basic (Declaration)

```
Property TaperOutward As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISpring  
Dim value As System.Boolean  
  
instance.TaperOutward = value  
value = instance.TaperOutward
```

C#

```
System.bool TaperOutward {get; set;}
```

C++/CLI

```
property System.bool TaperOutward {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to taper the helix outward, false to tape inward

Visual Basic for Applications (VBA) Syntax

See [Spring::TaperOutward](#).

Remarks

Use [ISpring::TaperAngle](#) to set the angle by which to taper a spring.

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Tolerance Property (ISpring)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISpring Interface](#) : Tolerance Property (ISpring)

Gets or sets the precision of the helical curve.

.NET Syntax

Visual Basic (Declaration)

Property Tolerance As System.Double

Visual Basic (Usage)



```
Dim instance As ISpring
Dim value As System.Double

instance.Tolerance = value
value = instance.Tolerance
```

C#

```
System.double Tolerance {get; set;}
```

C++/CLI

```
property System.double Tolerance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tolerance

Visual Basic for Applications (VBA) Syntax

See [Spring::Tolerance](#).

Remarks

Tolerance applies to the extension, torsion, and spiral springs only; tolerance does not apply to springs with variable pitches such as compression springs.

See Also

[ISpring Interface](#)
[ISpring Members](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

IStackedBalloonOptions (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IStackedBalloonOptions Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStackedBalloonOptions Interface

Allows access to stacked balloon options.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IStackedBalloonOptions

Visual Basic (Usage)



Dim instance As [IStackedBalloonOptions](#)

C#

public interface IStackedBalloonOptions

C++/CLI

public interface class IStackedBalloonOptions

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions](#).

Example

[Insert BOM Table and Stacked Balloon \(C#\)](#)
[Insert BOM Table and Stacked Balloon \(VB.NET\)](#)
[Insert BOM Table and Stacked Balloon \(VBA\)](#)

Remarks

To create a stack of balloons:

1. Select an item to create the first balloon in the stack.
2. Call [IModelDocExtension::CreateStackedBalloonOptions](#) to create an IStackedBalloonOptions object.
3. Set the properties on the IStackedBalloonOptions object.
4. Pass the IStackedBalloonOptions object in a call to [IModelDocExtension::InsertStackedBalloon2](#).
5. Select one or more items to add to the stack.

Accessors

[IModelDocExtension::CreateStackedBalloonOptions](#)

Access Diagram

[StackedBalloonOptions](#)

See Also

[IStackedBalloonOptions Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAutoBalloonOptions Interface](#)
[IBalloonOptions Interface](#)
[I>Note::MakeStackedBalloon Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IStackedBalloonOptions Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IStackedBalloonOptions](#).

Public Properties	
Name	Description
 BalloonsPerLine	Gets and sets the number of stacked balloons per line.
 CustomSize	Gets and sets the user-defined size of the balloons.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.
 ItemOrder	Gets and sets item ordering.
 Layername	Gets and sets the name of the layer on which to create the balloon stack.
 LowerText	Gets and sets the lower text of the balloons.
 LowerTextContent	Gets and sets the style of the lower text of the balloons.
 QuantityDenotationText	Gets and sets the label of BOM item quantities.
 QuantityOverride	Gets and sets whether to override the BOM item quantities.
 QuantityOverrideValue	Gets and sets the override value for BOM item quantities.
 QuantityPlacement	Gets and sets the placement of a BOM item quantity with respect to its balloon.
 ShowQuantity	Gets and sets whether to display the BOM item quantities.
 Size	Gets and sets the size of the balloons.
 StackDirection	Gets and sets the direction in which to stack balloons.
 Style	Gets and sets the style of the balloons.
 UpperText	Gets and sets the upper text of the balloons.
 UpperTextContent	Gets and sets the style of the upper text of the balloons.

[Top](#)

See Also

[IStackedBalloonOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAutoBalloonOptions Interface](#)
[IBalloonOptions Interface](#)
[INote::MakeStackedBalloon Method \(\)](#)

IStackedBalloonOptions Interface Properties

[See Also](#)

For a list of all members of this type, see [IStackedBalloonOptions members](#).

Public Properties	
Name	Description
 BalloonsPerLine	Gets and sets the number of stacked balloons per line.
 CustomSize	Gets and sets the user-defined size of the balloons.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.
 ItemOrder	Gets and sets item ordering.
 Layername	Gets and sets the name of the layer on which to create the balloon stack.
 LowerText	Gets and sets the lower text of the balloons.
 LowerTextContent	Gets and sets the style of the lower text of the balloons.

 QuantityDenotationText	Gets and sets the label of BOM item quantities.
 QuantityOverride	Gets and sets whether to override the BOM item quantities.
 QuantityOverrideValue	Gets and sets the override value for BOM item quantities.
 QuantityPlacement	Gets and sets the placement of a BOM item quantity with respect to its balloon.
 ShowQuantity	Gets and sets whether to display the BOM item quantities.
 Size	Gets and sets the size of the balloons.
 StackDirection	Gets and sets the direction in which to stack balloons.
 Style	Gets and sets the style of the balloons.
 UpperText	Gets and sets the upper text of the balloons.
 UpperTextContent	Gets and sets the style of the upper text of the balloons.

[Top](#)

See Also

[IStackedBalloonOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAutoBalloonOptions Interface](#)
[IBalloonOptions Interface](#)
[INote::MakeStackedBalloon Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BalloonsPerLine Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : BalloonsPerLine Property (IStackedBalloonOptions)

Gets and sets the number of stacked balloons per line.

.NET Syntax

Visual Basic (Declaration)

Property BalloonsPerLine As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.Integer
```

```
instance.BalloonsPerLine = value
```

```
value = instance.BalloonsPerLine
```

C#

```
System.int BalloonsPerLine {get; set;}
```

C++/CLI

```
property System.int BalloonsPerLine {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of balloons per line; specify a number >= 2

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::BalloonsPerLine](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomSize Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : CustomSize Property (IStackedBalloonOptions)

Gets and sets the user-defined size of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property CustomSize As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Double  
  
instance.CustomSize = value  
  
value = instance.CustomSize
```

C#

```
System.double CustomSize {get; set;}
```

C++/CLI

```
property System.double CustomSize {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

User-defined size of the balloons; valid only when [IStackedBalloonOptions::Size](#) is set to [swBalloonFit_e.swBF_UserDef](#)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::CustomSize](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemNumberIncrement Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : ItemNumberIncrement Property (IStackedBalloonOptions)

Gets and sets the item number increment.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemNumberIncrement As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer
```

```
instance.ItemNumberIncrement = value
```

```
value = instance.ItemNumberIncrement
```

C#

```
System.int ItemNumberIncrement {get; set;}
```

C++/CLI

```
property System.int ItemNumberIncrement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item number increment

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::ItemNumberIncrement](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

ItemNumberStart Property (IStackedBalloonOptions)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : ItemNumberStart Property (IStackedBalloonOptions)

Gets and sets the starting item number.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemNumberStart As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.Integer

instance.ItemNumberStart = value

value = instance.ItemNumberStart
```

C#

```
System.int ItemNumberStart {get; set;}
```

C++/CLI

```
property System.int ItemNumberStart {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting item number

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::ItemNumberStart](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

ItemOrder Property (IStackedBalloonOptions)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : ItemOrder Property (IStackedBalloonOptions)

Gets and sets item ordering.

.NET Syntax

Visual Basic (Declaration)

Property ItemOrder As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer  
  
instance.ItemOrder = value  
  
value = instance.ItemOrder
```

C#

```
System.int ItemOrder {get; set;}
```

C++/CLI

```
property System.int ItemOrder {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item ordering as defined in [swBalloonItemNumbersOrder_e](#)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::ItemOrder](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Layername Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : Layername Property (IStackedBalloonOptions)

Gets and sets the name of the layer on which to create the balloon stack.

.NET Syntax

Visual Basic (Declaration)

Property Layername As System.String

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.String

instance.Layername = value

value = instance.Layername
```

C#

```
System.string Layername {get; set;}
```

C++/CLI

```
property System.String^ Layername {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::Layername](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerText Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : LowerText Property (IStackedBalloonOptions)

Gets and sets the lower text of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property LowerText As System.String
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.String

instance.LowerText = value

value = instance.LowerText
```

C#

```
System.string LowerText {get; set;}
```

C++/CLI

```
property System.String^ LowerText {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Lower text of the balloons (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::LowerText](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

This property is valid only when [IStackedBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#). See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerTextContent Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : LowerTextContent Property (IStackedBalloonOptions)

Gets and sets the style of the lower text of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property LowerTextContent As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer
```

```
instance.LowerTextContent = value
```

```
value = instance.LowerTextContent
```

C#

```
System.int LowerTextContent {get; set;}
```

C++/CLI

```
property System.int LowerTextContent {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the lower text of the balloons as defined in [swBalloonTextContent_e](#); specify -1 to use the document default lower text style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::LowerTextContent](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

This property is valid only when [IStackedBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#).

To get or set document default values for LowerTextContent...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityDenotationText Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : QuantityDenotationText Property (IStackedBalloonOptions)

Gets and sets the label of BOM item quantities.

.NET Syntax

Visual Basic (Declaration)

Property QuantityDenotationText As System.String

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.String
```

```
instance.QuantityDenotationText = value
```

```
value = instance.QuantityDenotationText
```

C#

```
System.string QuantityDenotationText {get; set;}
```

C++/CLI

```
property System.String^ QuantityDenotationText {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Label of BOM item quantities

Visual Basic for Applications (VBA) Syntax

See [IStackedBalloonOptions::QuantityDenotationText](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityOverride Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : QuantityOverride Property (IStackedBalloonOptions)

Gets and sets whether to override the BOM item quantities.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.Boolean
```

```
instance.QuantityOverride = value
```

```
value = instance.QuantityOverride
```

C#

```
System.bool QuantityOverride {get; set;}
```

C++/CLI

```
property System.bool QuantityOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override BOM item quantities, false to not

Visual Basic for Applications (VBA) Syntax

See [IStackedBalloonOptions::QuantityOverride](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

QuantityOverrideValue Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : QuantityOverrideValue Property (IStackedBalloonOptions)

Gets and sets the override value for BOM item quantities.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityOverrideValue As System.String
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.String  
  
instance.QuantityOverrideValue = value  
value = instance.QuantityOverrideValue
```

C#

```
System.string QuantityOverrideValue {get; set;}
```

C++/CLI

```
property System.String^ QuantityOverrideValue {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

BOM item quantity override value; valid only when [IStackedBalloonOptions::QuantityOverride](#) is true

Visual Basic for Applications (VBA) Syntax

See [IStackedBalloonOptions::QuantityOverrideValue](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityPlacement Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : QuantityPlacement Property (IStackedBalloonOptions)

Gets and sets the placement of a BOM item quantity with respect to its balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityPlacement As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer  
  
instance.QuantityPlacement = value  
  
value = instance.QuantityPlacement
```

C#

```
System.int QuantityPlacement {get; set;}
```

C++/CLI

```
property System.int QuantityPlacement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Placement of BOM item quantity value as defined in [swBalloonQuantityPlacement_e](#); only swBalloonQuantityPlacement_e.swBalloonQuantityPlacement_Top and swBalloonQuantityPlacement_e.swBalloonQuantityPlacement_Bottom are valid options for stacked balloons

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::QuantityPlacement](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowQuantity Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : ShowQuantity Property (IStackedBalloonOptions)

Gets and sets whether to display the BOM item quantities.

.NET Syntax

Visual Basic (Declaration)

Property ShowQuantity As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Boolean
```

```
instance.ShowQuantity = value
```

```
value = instance.ShowQuantity
```

C#

```
System.bool ShowQuantity {get; set;}
```

C++/CLI

```
property System.bool ShowQuantity {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show BOM item quantities, false to not

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::ShowQuantity](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

Size Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : Size Property (IStackedBalloonOptions)

Gets and sets the size of the balloons.

 .NET Syntax

Visual Basic (Declaration)

Property Size As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions
Dim value As System.Integer

instance.Size = value

value = instance.Size
```

C#

```
System.int Size {get; set;}
```

C++/CLI

```
property System.int Size {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Balloon size as defined in [swBalloonFit_e](#); specify -1 to use the document default balloon size (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::Size](#).

 Example

See [IStackedBalloonOptions](#) examples.

 Remarks

To get or set document default values for Size...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)

See the SOLIDWORKS Help for additional details about stacked balloons.

 See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StackDirection Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : StackDirection Property (IStackedBalloonOptions)

Gets and sets the direction in which to stack balloons.

.NET Syntax

Visual Basic (Declaration)

Property StackDirection As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer
```

```
instance.StackDirection = value
```

```
value = instance.StackDirection
```

C#

```
System.int StackDirection {get; set;}
```

C++/CLI

```
property System.int StackDirection {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Stack direction as defined in [swStackedBalloonDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::StackDirection](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IStackedBalloonOptions)

[See Also](#)



Gets and sets the style of the balloons.

 .NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer  
  
instance.Style = value  
  
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Balloon style as defined in [swBalloonStyle_e](#); specify -1 to use the document default balloon style

 Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::Style](#).

 Example

See [IStackedBalloonOptions](#) examples.

 Remarks

To get or set document default values for Style...	Use...
Get	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified)
Set	IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonStyle_e.<Value>)

See the SOLIDWORKS Help for additional details about stacked balloons.

 See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

 Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : UpperText Property (IStackedBalloonOptions)

Gets and sets the upper text of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property UpperText As System.String
```

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.String  
  
instance.UpperText = value  
  
value = instance.UpperText
```

C#

```
System.string UpperText {get; set;}
```

C++/CLI

```
property System.String^ UpperText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Upper text of the balloons

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions.UpperText](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpperTextContent Property (IStackedBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStackedBalloonOptions Interface](#) : UpperTextContent Property (IStackedBalloonOptions)

Gets and sets the style of the upper text of the balloons.

.NET Syntax

Visual Basic (Declaration)

Property UpperTextContent As System.Integer

Visual Basic (Usage)



```
Dim instance As IStackedBalloonOptions  
Dim value As System.Integer  
  
instance.UpperTextContent = value  
value = instance.UpperTextContent
```

C#

```
System.int UpperTextContent {get; set;}
```

C++/CLI

```
property System.int UpperTextContent {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the upper text as defined in [swBalloonTextContent_e](#); specify -1 to use the document default upper text style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StackedBalloonOptions::UpperTextContent](#).

Example

See [IStackedBalloonOptions](#) examples.

Remarks

To get or set document
default values for
UpperTextContent...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See the SOLIDWORKS Help for additional details about stacked balloons.

See Also

[IStackedBalloonOptions Interface](#)
[IStackedBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IStatusBarPane (Type)

IStatusBarPane Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStatusBarPane Interface

Controls user-created status bar panes in the lower-right corner of the SOLIDWORKS status bar.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStatusBarPane
```

Visual Basic (Usage)



```
Dim instance As IStatusBarPane
```

C#

```
public interface IStatusBarPane
```

C++/CLI

```
public interface class IStatusBarPane
```

Visual Basic for Applications (VBA) Syntax

See [StatusBarPane](#).

Remarks

To use a status bar pane in a project, declare it in your project and manage it during the life cycle of the client application and release just before the client application disconnects from SOLIDWORKS. You can create up to five (5) panes.

Accessors

[IFrame::GetStatusBarPane](#)

Access Diagram

[StatusBarPane](#)

See Also

[IStatusBarPane Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IStatusBarPane Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStatusBarPane Interface

The following tables list the members exposed by [IStatusBarPane](#).

Public Properties

Name	Description
 Text	Gets or sets the text for this pane.
 Visible	Shows or hides this pane.

[Top](#)

See Also

[IStatusBarPane Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IStatusBarPane Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStatusBarPane Interface

For a list of all members of this type, see [IStatusBarPane members](#).

Public Properties

Name	Description
 Text	Gets or sets the text for this pane.
 Visible	Shows or hides this pane.

[Top](#)

See Also

[IStatusBarPane Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Text Property (IStatusBarPane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStatusBarPane Interface](#) : Text Property (IStatusBarPane)

Gets or sets the text for this pane.

.NET Syntax

Visual Basic (Declaration)

```
Property Text As System.String
```

Visual Basic (Usage)



```
Dim instance As IStatusBarPane  
Dim value As System.String
```

```
instance.Text = value
```

```
value = instance.Text
```

C#

```
System.string Text {get; set;}
```

C++/CLI

```
property System.String^ Text {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Status bar pane text

Visual Basic for Applications (VBA) Syntax

See [StatusBarPane::Text](#).

See Also

[IStatusBarPane Interface](#)
[IStatusBarPane Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (IStatusBarPane)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStatusBarPane Interface](#) : Visible Property (IStatusBarPane)

Shows or hides this pane.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStatusBarPane  
Dim value As System.Boolean
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the pane, false hides it

Visual Basic for Applications (VBA) Syntax

See [StatusBarPane.Visible](#).

See Also

[IStatusBarPane Interface](#)
[IStatusBarPane Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0