

SOLIDWORKS API (.NET VBA C#) — Reference

(295/337): IStraightElementData- IStructuralMemberFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IStraightElementData (Type)

IStraightElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStraightElementData Interface

Allows access to the data of a simple hole element in an Advanced Hole.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStraightElementData
```

Visual Basic (Usage)

```
Dim instance As IStraightElementData
```

C#

```
public interface IStraightElementData
```

C++/CLI

```
public interface class IStraightElementData
```

Visual Basic for Applications (VBA) Syntax

See [StraightElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IAdvancedHoleFeatureData::GetFarSideElements](#)
[IAdvancedHoleFeatureData::GetNearSideElements](#)

Access Diagram

[StraightElementData](#)

See Also

[IStraightElementData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

IStraightElementData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IStraightElementData](#).

Public Properties

Name	Description
 ClassificationType	Gets or sets the classification type of this straight hole element.
 DrillPointAngle	Gets or sets the drill point angle of this straight hole element.
 DrillPointAngleOverride	Gets or sets whether to override the drill point angle of this straight hole element.
 EndShape	Gets or sets the end shape for this straight hole element.
 Filter	Gets or sets the filter for this straight hole element.
 FitType	Gets or sets the fit type for this straight hole element.
 HoleFit	Gets or sets the hole fit for this straight hole element.
 ShaftFit	Gets or sets the shaft fit for this straight hole element.

[Top](#)

See Also

[IStraightElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

IStraightElementData Interface Properties

[See Also](#)

For a list of all members of this type, see [IStraightElementData members](#).

Public Properties

Name	Description
 ClassificationType	Gets or sets the classification type of this straight hole element.
 DrillPointAngle	Gets or sets the drill point angle of this straight hole element.
 DrillPointAngleOverride	Gets or sets whether to override the drill point angle of this straight hole element.
 EndShape	Gets or sets the end shape for this straight hole element.
 Filter	Gets or sets the filter for this straight hole element.
 FitType	Gets or sets the fit type for this straight hole element.
 HoleFit	Gets or sets the hole fit for this straight hole element.
 ShaftFit	Gets or sets the shaft fit for this straight hole element.

[Top](#)

See Also

[IStraightElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

ClassificationType Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : ClassificationType Property (IStraightElementData)

Gets or sets the classification type of this straight hole element.

.NET Syntax

Visual Basic (Declaration)

Property ClassificationType As System.Integer

Visual Basic (Usage)



```
Dim instance As IStraightElementData
Dim value As System.Integer

instance.ClassificationType = value
value = instance.ClassificationType
```

C#

```
System.int ClassificationType {get; set;}
```

C++/CLI

```
property System.int ClassificationType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Classification type as defined in [swStraightHoleClassificationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::ClassificationType](#).

Remarks

This property is valid only if [IAdvancedHoleElementData::FastenerType](#) is set to [swWzdHoleStandardFastenerTypes_e.swStandard*DowelHoles](#).

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DrillPointAngle Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : DrillPointAngle Property (IStraightElementData)

Gets or sets the drill point angle of this straight hole element.

.NET Syntax

Visual Basic (Declaration)

Property DrillPointAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.Double
```

```
instance.DrillPointAngle = value
```

```
value = instance.DrillPointAngle
```

C#

```
System.double DrillPointAngle {get; set;}
```

C++/CLI

```
property System.double DrillPointAngle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Drill point angle

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::DrillPointAngle](#).

Remarks

This property is valid only if [IStraightElementData::EndShape](#) is set to [swEndShape_e.swEndShape_DrillPoint](#) and [IStraightElementData::DrillPointAngleOverride](#) is set to true.

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DrillPointAngleOverride Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : DrillPointAngleOverride Property (IStraightElementData)

Gets or sets whether to override the drill point angle of this straight hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property DrillPointAngleOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.Boolean
```

```
instance.DrillPointAngleOverride = value
```

```
value = instance.DrillPointAngleOverride
```

C#

```
System.bool DrillPointAngleOverride {get; set;}
```

C++/CLI

```
property System.bool DrillPointAngleOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the drill point angle, false to not

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::DrillPointAngleOverride](#).

Remarks

This property is valid only if [IStraightElementData::EndShape](#) is set to [swEndShape_e.swEndShape_DrillPoint](#).

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)
[IStraightElementData::DrillPointAngle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndShape Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : EndShape Property (IStraightElementData)

Gets or sets the end shape for this straight hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property EndShape As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStraightElementData
Dim value As System.Integer
```

```
instance.EndShape = value
```

```
value = instance.EndShape
```

C#

```
System.int EndShape {get; set;}
```

C++/CLI

```
property System.int EndShape {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End shape as defined in [swEndShape_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::EndShape](#).

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)
[IStraightElementData::DrillPointAngle Property \(\)](#)
[IStraightElementData::DrillPointAngleOverride Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Filter Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : Filter Property (IStraightElementData)

Gets or sets the filter for this straight hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property Filter As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.Integer  
  
instance.Filter = value  
  
value = instance.Filter
```

C#

```
System.int Filter {get; set;}
```

C++/CLI

```
property System.int Filter {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Filter as defined in [swStraightHoleFilter_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::Filter](#).

Remarks

This property is valid only if [IAdvancedHoleElementData::Standard](#) is set to [swWzdHoleStandards_e](#):

- swStandardPEMInch
- OR -
- swStandardPEMMetric

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FitType Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : FitType Property (IStraightElementData)

Gets or sets the fit type for this straight hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property FitType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.Integer
```

```
instance.FitType = value
```

```
value = instance.FitType
```

C#

```
System.int FitType {get; set;}
```

C++/CLI

```
property System.int FitType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fit type as defined in [swStraightHoleFitType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::FitType](#).

Remarks

This property is valid only if [IAdvancedHoleElementData::FastenerType](#) is set to [swWzdHoleStandardFastenerTypes_e.swStandard*ScrewClearances](#).

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

HoleFit Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : HoleFit Property (IStraightElementData)

Gets or sets the hole fit for this straight hole element.

Visual Basic Syntax

Visual Basic (Declaration)

Property HoleFit As System.String

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.String
```

```
instance.HoleFit = value
```

```
value = instance.HoleFit
```

C#

```
System.string HoleFit {get; set;}
```

C++/CLI

```
property System.String^ HoleFit {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole fit (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::HoleFit](#).

Remarks

This property is valid only if [AdvancedHoleElementData::FastenerType](#) is set to [swWzdHoleStandardFastenerTypes_e.swStandard*DowelHoles](#).

Set this property to one of the following:

C8, C9, C11, D8, D9, D10, D11, E7, E8, E9, F6, F7, F8, F9, G5, G6, G7, G8, G9, G10, H5, H6, H7, H8, H9, H10, H11, H12, H13, J6, J7, J8, J9, J10, J11, K6, K7, K8, M6, M7, M8, N6, N7, N8, N9, N10, N11, P6, P7, R7, S6, S7, T6, T7, U6, U7, V6, V7, X6, X7

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShaftFit Property (IStraightElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightElementData Interface](#) : ShaftFit Property (IStraightElementData)

Gets or sets the shaft fit for this straight hole element.

Visual Basic Syntax

Visual Basic (Declaration)

Property ShaftFit As System.String

Visual Basic (Usage)



```
Dim instance As IStraightElementData  
Dim value As System.String
```

```
instance.ShaftFit = value
```

```
value = instance.ShaftFit
```

C#

```
System.string ShaftFit {get; set;}
```

C++/CLI

```
property System.String^ ShaftFit {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Shaft fit (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [StraightElementData::ShaftFit](#).

Remarks

This property is valid only if [IAdvancedHoleElementData::FastenerType](#) is set to [swWzdHoleStandardFastenerTypes_e.swStandard*DowelHoles](#).

Set this property to one of the following:

c8, c9, c11, d8, d9, d10, d11, e7, e8, e9, f6, f7, f8, g4, g5, g6, g7, h5, h6, h7, h8, h9, h10, h11, h12, h13, j5, j6, j7, j8, j9, j10, j11, k5, k6, k7, k8, k9, k10, k11, m5, m6, m7, n5, n6, n7, p5, p6, p7, r5, r6, r7, s5, s6, s7, t5, t6, t7, u5, u6, u7, v5, v6, v7, x5, x6, x7

See Also

[IStraightElementData Interface](#)
[IStraightElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IStraightTapElementData (Type)

IStraightTapElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStraightTapElementData Interface

Allows access to the data of a straight tap hole element in an Advanced Hole.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStraightTapElementData
```

Visual Basic (Usage)

```
Dim instance As IStraightTapElementData
```

C#

```
public interface IStraightTapElementData
```

C++/CLI

```
public interface class IStraightTapElementData
```

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IAdvancedHoleFeatureData::GetFarSideElements](#)
[IAdvancedHoleFeatureData::GetNearSideElements](#)

Access Diagram

[StraightTapElementData](#)

See Also

[IStraightTapElementData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

IStraightTapElementData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IStraightTapElementData](#).

 Public Properties

Name	Description
 CustomSizing	Gets or sets the custom sizing for this straight tap hole element.
 DrillPointAngle	Gets or sets the drill point angle of this straight tap hole element.
 DrillPointAngleOverride	Gets or sets whether to override the drill point angle of this straight tap hole element.
 EndShape	Gets or sets the end shape for this straight tap hole element.
 Equation	Gets or sets the equation for the blind depth or offset distance of this straight tap hole element.
 ThreadClass	Gets or sets the thread class for this straight tap hole element.
 ThreadClassOverride	Gets or sets whether to override the thread class of this straight tap hole element.

[Top](#)

 See Also

[IStraightTapElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

IStraightTapElementData Interface Properties

[See Also](#)



For a list of all members of this type, see [IStraightTapElementData members](#).

 Public Properties

Name	Description
 CustomSizing	Gets or sets the custom sizing for this straight tap hole element.
 DrillPointAngle	Gets or sets the drill point angle of this straight tap hole element.
 DrillPointAngleOverride	Gets or sets whether to override the drill point angle of this straight tap hole element.
 EndShape	Gets or sets the end shape for this straight tap hole element.
 Equation	Gets or sets the equation for the blind depth or offset distance of this straight tap hole element.
 ThreadClass	Gets or sets the thread class for this straight tap hole element.
 ThreadClassOverride	Gets or sets whether to override the thread class of this straight tap hole element.

[Top](#)

 See Also

[IStraightTapElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[ICountersinkElementData Interface](#)
[IStraightElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

CustomSizing Property (IStraightTapElementData)

[See Also](#)



Gets or sets the custom sizing for this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

Property CustomSizing As System.Integer

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Integer  
  
instance.CustomSizing = value  
value = instance.CustomSizing
```

C#

```
System.int CustomSizing {get; set;}
```

C++/CLI

```
property System.int CustomSizing {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Custom sizing as defined in [swStraightTapHoleCustomSizing_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::CustomSizing](#).

Example

See the [IStraightTapElementData](#) examples.

See Also

[IStraightTapElementData Interface](#)
[IStraightTapElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DrillPointAngle Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : DrillPointAngle Property (IStraightTapElementData)

Gets or sets the drill point angle of this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

Property DrillPointAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Double
```

```
instance.DrillPointAngle = value  
value = instance.DrillPointAngle
```

C#

```
System.double DrillPointAngle {get; set;}
```

C++/CLI

```
property System.double DrillPointAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Drill point angle

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::DrillPointAngle](#).

Remarks

This property is valid only if [IStraightTapElementData::EndShape](#) is set to [swEndShape_e.swEndShape_DrillPoint](#) and [IStraightTapElementData::DrillPointAngleOverride](#) is set to true.

See Also

[IStraightTapElementData Interface](#)
[IStraightTapElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DrillPointAngleOverride Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : DrillPointAngleOverride Property (IStraightTapElementData)

Gets or sets whether to override the drill point angle of this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property DrillPointAngleOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Boolean  
  
instance.DrillPointAngleOverride = value  
value = instance.DrillPointAngleOverride
```

C#

```
System.bool DrillPointAngleOverride {get; set;}
```

C++/CLI

```
property System.bool DrillPointAngleOverride {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the drill point angle, false to not

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::DrillPointAngleOverride](#).

Remarks

This property is valid only if [IStraightTapElementData::EndShape](#) is set to [swEndShape_e.swEndShape_DrillPoint](#).

See Also

[IStraightTapElementData Interface](#)
[IStraightTapElementData Members](#)
[IStraightTapElementData::DrillPointAngle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndShape Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : EndShape Property (IStraightTapElementData)

Gets or sets the end shape for this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property EndShape As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Integer
```

```
instance.EndShape = value
```

```
value = instance.EndShape
```

C#

```
System.int EndShape {get; set;}
```

C++/CLI

```
property System.int EndShape {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End shape as defined in [swEndShape_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::EndShape](#).

See Also

[IStraightTapElementData Interface](#)
[IStraightTapElementData Members](#)
[IStraightTapElementData::DrillPointAngle Property \(\)](#)
[IStraightTapElementData::DrillPointAngleOverride Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Equation Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : Equation Property (IStraightTapElementData)

Gets or sets the equation for the blind depth or offset distance of this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

Property Equation As System.Integer

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Integer
```

```
instance.Equation = value
```

```
value = instance.Equation
```

C#

```
System.int Equation {get; set;}
```

C++/CLI

```
property System.int Equation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Equation for the blind depth or offset distance as defined in [swStraightTapHoleEquation_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::Equation](#).

Remarks

If [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false, and:

- [IAdvancedHoleElementData::EndCondition](#) is set to [swEndConditions_e.swEndCondBlind](#), then this property specifies the equation for the depth of the Blind end condition. If this property is set to [swStraightTapHoleEquation_e.swStraightTapHoleEquation_UserDefinedValue](#), then use [IAdvancedHoleElementData::BlindDepth](#) to set the custom Blind depth of this hole element.
- [IAdvancedHoleElementData::EndCondition](#) is specifically set to anything other than Blind, then this property is not valid.

If [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to true, then:

- the end condition automatically becomes [swEndConditions_e.swEndCondOffsetFromSurface](#),
- and -
- this property specifies the equation for the offset distance. If this property is set to [swStraightTapHoleEquation_e.swStraightTapHoleEquation_UserDefinedValue](#), then use [IAdvancedHoleElementData::OffsetDistance](#) to set the custom offset distance of this hole element.

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadClass Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : ThreadClass Property (IStraightTapElementData)

Gets or sets the thread class for this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

Property ThreadClass As System.Integer

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData
Dim value As System.Integer

instance.ThreadClass = value
value = instance.ThreadClass
```

C#

```
System.int ThreadClass {get; set;}
```

C++/CLI

```
property System.int ThreadClass {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread class as defined in [swStraightTapHoleThreadClass_e](#)

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::ThreadClass](#).

Example

See the [IStraightTapElementData](#) examples.

Remarks

This property is valid only if [IStraightTapElementData::ThreadClassOverride](#) is set to true.

See Also

[IStraightTapElementData Interface](#)
[IStraightTapElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadClassOverride Property (IStraightTapElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStraightTapElementData Interface](#) : ThreadClassOverride Property (IStraightTapElementData)

Gets or sets whether to override the thread class of this straight tap hole element.

.NET Syntax

Visual Basic (Declaration)

Property ThreadClassOverride As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStraightTapElementData  
Dim value As System.Boolean
```

```
instance.ThreadClassOverride = value
```

```
value = instance.ThreadClassOverride
```

C#

```
System.bool ThreadClassOverride {get; set;}
```

C++/CLI

```
property System.bool ThreadClassOverride {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the thread class, false to not

Visual Basic for Applications (VBA) Syntax

See [StraightTapElementData::ThreadClassOverride](#).

Example

See the [IStraightTapElementData](#) examples.

See Also

[IStraightTapElementData Interface](#)

[IStraightTapElementData Members](#)

[IStraightTapElementData::ThreadClass Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IStructuralMemberFeatureData (Type)

IStructuralMemberFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberFeatureData Interface

Allows access to a structural member.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStructuralMemberFeatureData
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
```

C#

```
public interface IStructuralMemberFeatureData
```

C++/CLI

```
public interface class IStructuralMemberFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Set Profile for Structural Member \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[StructuralMemberFeatureData](#)

See Also

[IStructuralMemberFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEndCapFeatureData Interface](#)
[IGussetFeatureData Interface](#)
[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListFeature Interface](#)
[IFeatureManager::InsertStructuralWeldment3 Method](#)
[IStructuralMemberGroup Interface](#)

IStructuralMemberFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberFeatureData Interface

The following tables list the members exposed by [IStructuralMemberFeatureData](#).

Public Properties

Name	Description
 AllowProtrusion	Gets or sets whether to allow protrusion.
 ApplyCornerTreatment	Gets or sets whether or not to apply a corner treatment to this structural member.
 ConfigurationName	Gets or sets the name of the configuration in the custom weldment profile for this structural member.
 ConnectedSegmentsOption	Gets or sets the connected segments option.
 ConnectionType	Gets or sets the type of corner treatment at the specified connection point of this structural member.
 CornerTreatmentType	Gets or sets the type of corner treatment for this structural member.
 Groups	Gets or sets the groups to use in this structural member.
 LibraryProfileMaterial	Gets the name of the material for the library profile for this structural member.
 LocateProfilePoint	Gets or sets the point to use to locate the profile for this structural member.
 PathSegments	Gets the path segments used or sets the path segments to use to create this structural member.
 RotationAngle	Gets or sets the angle by which the structural member turns relative to the adjacent structural member.
 TransferMaterial	Gets or sets whether to transfer the material properties of a library profile for this structural member.
 WeldmentProfilePath	Gets or sets the path for the profile for this structural member.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this structural member.
 GetConnectionPoints	Gets the connection points for this structural member.
 GetConnectionPointsCount	Gets the number of sketch points for this structural member.
 GetGroupsCount	Gets the number of structural-member groups for this structural member.
 GetPathSegmentAt	Gets the sketch segment associated with the body of this structural member.
 GetPathSegmentsCount	Gets the number of path segments for this structural member.
 GetSketchSegments	Gets the sketch segments that define the path of the specified structural member body.
 IGetConnectionPoints	Gets the connection points for this structural member.
 IGetGroups	Gets the structural-member groups in this structural member.
 IGetPathSegments	Gets the path segments used to create this structural member.
 ISetGroups	Sets the structural-member groups to use in this structural member.
 ISetPathSegments	Sets the path segments to use to create this structural member.
 ReleaseSelectionAccess	Releases access to the selections that define this structural member.

[Top](#)

See Also

[IStructuralMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEndCapFeatureData Interface](#)
[IGussetFeatureData Interface](#)
[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListFeature Interface](#)
[IFeatureManager::InsertStructuralWeldment3 Method](#)
[IStructuralMemberGroup Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructuralMemberFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberFeatureData Interface

For a list of all members of this type, see [IStructuralMemberFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this structural member.
 GetConnectionPoints	Gets the connection points for this structural member.
 GetConnectionPointsCount	Gets the number of sketch points for this structural member.
 GetGroupsCount	Gets the number of structural-member groups for this structural member.
 GetPathSegmentAt	Gets the sketch segment associated with the body of this structural member.
 GetPathSegmentsCount	Gets the number of path segments for this structural member.
 GetSketchSegments	Gets the sketch segments that define the path of the specified structural member body.
 IGetConnectionPoints	Gets the connection points for this structural member.
 IGetGroups	Gets the structural-member groups in this structural member.
 IGetPathSegments	Gets the path segments used to create this structural member.
 ISetGroups	Sets the structural-member groups to use in this structural member.
 ISetPathSegments	Sets the path segments to use to create this structural member.
 ReleaseSelectionAccess	Releases access to the selections that define this structural member.

[Top](#)

See Also

[IStructuralMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEndCapFeatureData Interface](#)
[IGussetFeatureData Interface](#)
[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListFeature Interface](#)
[IFeatureManager.InsertStructuralWeldment3 Method](#)
[IStructuralMemberGroup Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructuralMemberFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberFeatureData Interface

For a list of all members of this type, see [IStructuralMemberFeatureData members](#).

Public Properties

Name	Description
 AllowProtrusion	Gets or sets whether to allow protrusion.
 ApplyCornerTreatment	Gets or sets whether or not to apply a corner treatment to this structural member.
 ConfigurationName	Gets or sets the name of the configuration in the custom weldment profile for this structural member.
 ConnectedSegmentsOption	Gets or sets the connected segments option.
 ConnectionType	Gets or sets the type of corner treatment at the specified connection point of this structural member.
 CornerTreatmentType	Gets or sets the type of corner treatment for this structural member.
 Groups	Gets or sets the groups to use in this structural member.
 LibraryProfileMaterial	Gets the name of the material for the library profile for this structural member.
 LocateProfilePoint	Gets or sets the point to use to locate the profile for this structural member.
 PathSegments	Gets the path segments used or sets the path segments to use to create this structural member.
 RotationAngle	Gets or sets the angle by which the structural member turns relative to the adjacent structural member.
 TransferMaterial	Gets or sets whether to transfer the material properties of a library profile for this structural member.
 WeldmentProfilePath	Gets or sets the path for the profile for this structural member.

[Top](#)

See Also

[IStructuralMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEndCapFeatureData Interface](#)
[IGussetFeatureData Interface](#)
[IWeldmentCutListAnnotation Interface](#)
[IWeldmentCutListFeature Interface](#)
[IFeatureManager.InsertStructuralWeldment3 Method](#)
[IStructuralMemberGroup Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : AccessSelections Method (IStructuralMemberFeatureData)

Gains access to the selections that define this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component for the feature

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::AccessSelections](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Set Profile for Structural Member \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IStructuralMemberFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AllowProtrusion Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : AllowProtrusion Property (IStructuralMemberFeatureData)

Gets or sets whether to allow protrusion.

.NET Syntax

Visual Basic (Declaration)

Property AllowProtrusion As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Boolean
```

```
instance.AllowProtrusion = value
```

```
value = instance.AllowProtrusion
```

C#

```
System.bool AllowProtrusion {get; set;}
```

C++/CLI

```
property System.bool AllowProtrusion {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to allow protrusion, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::AllowProtrusion](#).

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

ApplyCornerTreatment Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ApplyCornerTreatment Property (IStructuralMemberFeatureData)

Gets or sets whether or not to apply a corner treatment to this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property ApplyCornerTreatment As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Boolean
```

```
instance.ApplyCornerTreatment = value
```

```
value = instance.ApplyCornerTreatment
```

C#

```
System.bool ApplyCornerTreatment {get; set;}
```

C++/CLI

```
property System.bool ApplyCornerTreatment {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply corner treatment, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::ApplyCornerTreatment](#).

Remarks

You must specify the [type corner treatment](#) before changing this property from false to true.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ConnectionType Property](#)
[IStructuralMemberFeatureData::CornerTreatmentType Property](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::GetConnectionPointsCount Method](#)
[IStructuralMemberFeatureData::IGetConnectionPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

ConfigurationName Property (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ConfigurationName Property (IStructuralMemberFeatureData)

Gets or sets the name of the configuration in the custom weldment profile for this structural member.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ConfigurationName As System.String
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.String

instance.ConfigurationName = value
value = instance.ConfigurationName
```

C#

```
System.string ConfigurationName {get; set;}
```

C++/CLI

```
property System.String^ ConfigurationName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the configuration in the custom weldment profile or an empty string (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::ConfigurationName](#).

Example

[Insert Structural Weldments Using Custom Weldment Profile \(C#\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VB.NET\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VBA\)](#)

Remarks

An empty string indicates that a configuration in a custom weldment profile was not used for this structural member.

See:

- [IFeatureManager::InsertStructuralWeldment5](#) for details about inserting a structural member using a configuration in a custom weldment profile.
- SOLIDWORKS Help for details about custom weldment profiles.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConnectedSegmentsOption Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ConnectedSegmentsOption Property (IStructuralMemberFeatureData)

Gets or sets the connected segments option.

Visual Basic Syntax

Visual Basic (Declaration)

Property ConnectedSegmentsOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Integer

instance.ConnectedSegmentsOption = value

value = instance.ConnectedSegmentsOption
```

C#

```
System.int ConnectedSegmentsOption {get; set;}
```

C++/CLI

```
property System.int ConnectedSegmentsOption {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Connected segments option as defined in [swConnectedSegmentsOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::ConnectedSegmentsOption](#).

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConnectionType Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ConnectionType Property (IStructuralMemberFeatureData)

Gets or sets the type of corner treatment at the specified connection point of this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property ConnectionType( _
    ByVal AtPoint As SketchPoint _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim AtPoint As SketchPoint
Dim value As System.Integer

instance.ConnectionType(AtPoint) = value

value = instance.ConnectionType(AtPoint)
```

C#

```
System.int ConnectionType(  
    SketchPoint AtPoint  
) {get; set;}
```

C++/CLI

```
property System.int ConnectionType {  
    System.int get(SketchPoint^ AtPoint);  
    void set (SketchPoint^ AtPoint, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[AtPoint](#)
[Connect point](#)

Property Value

Type of corner treatment as defined in [swSolidworksWeldmentEndCondOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::ConnectionType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ApplyCornerTreatment Property](#)
[IStructuralMemberFeatureData::CornerTreatmentType Property](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::GetConnectionPointsCount Method](#)
[IStructuralMemberFeatureData::IGetConnectionPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerTreatmentType Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : CornerTreatmentType Property (IStructuralMemberFeatureData)

Gets or sets the type of corner treatment for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property CornerTreatmentType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim value As System.Integer
```

```
instance.CornerTreatmentType = value
```

```
value = instance.CornerTreatmentType
```

C#

```
System.int CornerTreatmentType {get; set;}
```

C++/CLI

```
property System.int CornerTreatmentType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of corner treatment as defined in [swSolidworksWeldmentEndCondOptions](#) e

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::CornerTreatmentType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ApplyCornerTreatment Property](#)
[IStructuralMemberFeatureData::ConnectionType Property](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::GetConnectionPointsCount Method](#)
[IStructuralMemberFeatureData::IGetConnectionPoints Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConnectionPoints Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : GetConnectionPoints Method (IStructuralMemberFeatureData)

Gets the connection points for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConnectionPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Object

value = instance.GetConnectionPoints()
```

C#

```
System.object GetConnectionPoints()
```

C++/CLI

```
System.Object^ GetConnectionPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch points](#) representing the connection points

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetConnectionPoints](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::GetConnectionPointsCount Method](#)
[IStructuralMemberFeatureData::ApplyCornerTreatment Property](#)
[IStructuralMemberFeatureData::ConnectionType Property](#)
[IStructuralMemberFeatureData::CornerTreatmentType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConnectionPointsCount Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : GetConnectionPointsCount Method (IStructuralMemberFeatureData)

Gets the number of sketch points for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConnectionPointsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim value As System.Integer  
  
value = instance.GetConnectionPointsCount()
```

C#

```
System.int GetConnectionPointsCount()
```

C++/CLI

```
System.int GetConnectionPointsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch points

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetConnectionPointsCount](#).

Remarks

Call this method before calling [IStructuralMemberFeatureData::GetConnectionPoints](#) to get the size of the array for that method.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::ApplyCornerTreatment Property](#)
[IStructuralMemberFeatureData::ConnectionType Property](#)
[IStructuralMemberFeatureData::CornerTreatmentType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGroupsCount Method (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : GetGroupsCount Method (IStructuralMemberFeatureData)

Gets the number of structural-member groups for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGroupsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Integer

value = instance.GetGroupsCount()
```

C#

```
System.int GetGroupsCount()
```

C++/CLI

```
System.int GetGroupsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of structural-member groups

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetGroupsCount](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Create Structural-Member Group \(VBA\)](#)
[Create Structural-Member Group \(VB.NET\)](#)
[Create Structural-Member Group \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::Groups Property](#)
[IStructuralMemberFeatureData::IGetGroups Method](#)
[IStructuralMemberFeatureData::ISetGroups Method](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPathSegmentAt Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : [GetPathSegmentAt Method \(IStructuralMemberFeatureData\)](#)

Gets the sketch segment associated with the body of this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathSegmentAt( _  
    ByVal PBodyIn As Body2 _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim PBodyIn As Body2  
Dim value As SketchSegment  
  
value = instance.GetPathSegmentAt(PBodyIn)
```

C#

```
SketchSegment GetPathSegmentAt(  
    Body2 PBodyIn  
)
```

C++/CLI

```
SketchSegment^ GetPathSegmentAt(  
& Body2^ PBodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBodyIn
[Body](#)

Return Value

[Sketch segment](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetPathSegmentAt](#).

Remarks

The body generated by this feature is not available when the feature is rolled back. Therefore, it is not necessary to call [IStructuralMemberFeatureData::AccessSelections](#) or [IStructuralMemberFeatureData::ReleaseSelectionAccess](#) before or after calling this method.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetPathSegmentsCount Method](#)
[IStructuralMemberFeatureData::IGetPathSegments Method](#)
[IStructuralMemberFeatureData::ISetPathSegments Method](#)
[IStructuralMemberFeatureData::PathSegments Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : GetPathSegmentsCount Method (IStructuralMemberFeatureData)

Gets the number of path segments for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPathSegmentsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Integer

value = instance.GetPathSegmentsCount()
```

C#

```
System.int GetPathSegmentsCount()
```

C++/CLI

```
System.int GetPathSegmentsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of path segments

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetPathSegmentsCount](#).

Remarks

Call this method before calling [IStructuralMemberFeatureData::GetPathSegments](#) to get the size of the array for that method.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::PathSegments Property](#)
[IStructuralMemberFeatureData::SetPathSegments Method](#)
[IStructuralMemberFeatureData::GetPathSegmentAt Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchSegments Method (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : GetSketchSegments Method (IStructuralMemberFeatureData)

Gets the sketch segments that define the path of the specified structural member body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchSegments( _  
    ByVal PBodyIn As Body2 _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim PBodyIn As Body2
Dim value As System.Object

value = instance.GetSketchSegments(PBodyIn)
```

C#

```
System.object GetSketchSegments(
    Body2 PBodyIn
)
```

C++/CLI

```
System.Object^ GetSketchSegments(
    & Body2^ PBodyIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBodyIn
[IBody2](#) whose path sketch segments to get

Return Value

Array of [ISketchSegment](#)s

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::GetSketchSegments](#).

Example

[Get Structural Member Body Sketch Segments \(VBA\)](#)
[Get Structural Member Body Sketch Segments \(VB.NET\)](#)
[Get Structural Member Body Sketch Segments \(C#\)](#)

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Groups Property (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : Groups Property (IStructuralMemberFeatureData)

Gets or sets the groups to use in this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property Groups As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Object

instance.Groups = value

value = instance.Groups
```

C#

```
System.Object Groups {get; set;}
```

C++/CLI

```
property System.Object^ Groups {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IStructuralMemberGroup](#) objects

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::Groups](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Create Structural-Member Group \(VBA\)](#)
[Create Structural-Member Group \(VB.NET\)](#)
[Create Structural-Member Group \(C#\)](#)

Remarks

This method works only for features that support groups. A feature supports groups only if [IStructuralMemberFeatureData::GetGroupsCount](#) > 0

Call [IFeatureManager::CreateStructuralMemberGroup](#) to create groups.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::IGetGroups Method](#)
[IStructuralMemberFeatureData::ISetGroups Method](#)
[IStructuralMemberGroup Interface](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConnectionPoints Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : IGetConnectionPoints Method (IStructuralMemberFeatureData)

Gets the connection points for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConnectionPoints( _
    ByVal Count As System.Integer _
```

) As SketchPoint

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim Count As System.Integer  
Dim value As SketchPoint  
  
value = instance.IGetConnectionPoints(Count)
```

C#

```
SketchPoint IGetConnectionPoints(  
    System.int Count  
)
```

C++/CLI

```
SketchPoint^ IGetConnectionPoints(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of connection points

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch points](#) representing the connection points
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IStructuralMemberFeatureData::GetConnectionPointsCount](#) before this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetConnectionPoints Method](#)
[IStructuralMemberFeatureData::ApplyCornerTreatment Property](#)
[IStructuralMemberFeatureData::ConnectionType Property](#)
[IStructuralMemberFeatureData::CornerTreatmentType Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetGroups Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : IGetGroups Method (IStructuralMemberFeatureData)

Gets the structural-member groups in this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetGroups( _  
    ByVal Count As System.Integer _  
) As StructuralMemberGroup
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim Count As System.Integer
Dim value As StructuralMemberGroup

value = instance.IGetGroups(Count)
```

C#

```
StructuralMemberGroup IGetGroups(
    System.int Count
)
```

C++/CLI

```
StructuralMemberGroup^ IGetGroups(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of structural-member groups

Return Value

- in-process, unmanaged C++: Pointer to an array of [structural-member groups](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IStructuralMemberFeatureData::GetGroupsCount](#) to set the Count parameter.

This method works only for features that support groups. A feature supports groups only if [IStructuralMemberFeatureData::GetGroupsCount](#) > 0

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ISetGroups Method](#)
[IStructuralMemberFeatureData::Groups Property](#)
[IStructuralMemberGroup Interface](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPathSegments Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : IGetPathSegments Method (IStructuralMemberFeatureData)

Gets the path segments used to create this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPathSegments( _
    ByVal Count As System.Integer _
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim Count As System.Integer
```

```
Dim value As SketchSegment

value = instance.IGetPathSegments(Count)
```

C#

```
SketchSegment IGetPathSegments(
    System.int Count
)
```

C++/CLI

```
SketchSegment^ IGetPathSegments(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of path segments

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IStructuralMemberFeatureData::GetPathSegmentsCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::PathSegments Property](#)
[IStructuralMemberFeatureData::ISetPathSegments Method](#)
[IStructuralMemberFeatureData::GetPathSegmentsCount Method](#)
[IStructuralMemberFeatureData::GetPathSegmentAt Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetGroups Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ISetGroups Method (IStructuralMemberFeatureData)

Sets the structural-member groups to use in this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetGroups( _
    ByVal Count As System.Integer, _
    ByRef SegGroups As StructuralMemberGroup _
)
```

Visual Basic (Usage)

```
Dim instance As IStructuralMemberFeatureData
Dim Count As System.Integer
Dim SegGroups As StructuralMemberGroup

instance.ISetGroups(Count, SegGroups)
```



C#

```
void ISetGroups(  
    System.int Count,  
    ref StructuralMemberGroup SegGroups  
)
```

C++/CLI

```
void ISetGroups(  
& System.int Count,  
& StructuralMemberGroup^% SegGroups  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of structural-member groups

SegGroups

- In-process, unmanaged C++: Pointer to an array of [structural-member groups](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method works only for features that support groups. A feature supports groups only if [IStructuralMemberFeatureData::GetGroupsCount](#) > 0

Call [IFeatureManager::CreateStructuralMemberGroup](#) to create groups.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::IGetGroups Method](#)
[IStructuralMemberFeatureData::Groups Property](#)
[IStructuralMemberGroup Interface](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPathSegments Method (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ISetPathSegments Method (IStructuralMemberFeatureData)

Sets the path segments to use to create this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetPathSegments( _  
    ByVal Count As System.Integer, _  
    ByRef SegArr As SketchSegment _  
)
```

Visual Basic (Usage)

```
Dim instance As IStructuralMemberFeatureData  
Dim Count As System.Integer  
Dim SegArr As SketchSegment  
  
instance.ISetPathSegments(Count, SegArr)
```

C#



```
void ISetPathSegments(
    System.int Count,
    ref SketchSegment SegArr
)
```

C++/CLI

```
void ISetPathSegments(
    & System.int Count,
    & SketchSegment^% SegArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of path segments

SegArr

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetPathSegmentAt Method](#)
[IStructuralMemberFeatureData::GetPathSegmentsCount Method](#)
[IStructuralMemberFeatureData::IGetPathSegments Method](#)
[IStructuralMemberFeatureData::PathSegments Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LibraryProfileMaterial Property (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : LibraryProfileMaterial Property (IStructuralMemberFeatureData)

Gets the name of the material for the library profile for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LibraryProfileMaterial As System.String
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.String

value = instance.LibraryProfileMaterial
```

C#

```
System.string LibraryProfileMaterial {get;}
```

C++/CLI

```
property System.String^ LibraryProfileMaterial {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the material for this library profile

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::LibraryProfileMaterial](#).

Example

[Insert Structural Weldments Using Custom Weldment Profile \(C#\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VB.NET\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VBA\)](#)

Remarks

You can [transfer material properties](#) of a library profile:

- when you use it as a structural member.
- that has a configuration-specific material.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ConfigurationName Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LocateProfilePoint Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : LocateProfilePoint Property (IStructuralMemberFeatureData)

Gets or sets the point to use to locate the profile for this structural member.

.NET Syntax

Visual Basic (Declaration)

Property LocateProfilePoint As SketchPoint

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As SketchPoint
```

```
instance.LocateProfilePoint = value
```

```
value = instance.LocateProfilePoint
```

C#

```
SketchPoint LocateProfilePoint {get; set;}
```

C++/CLI

```
property SketchPoint^ LocateProfilePoint {
    SketchPoint^ get();
    void set ( & SketchPoint^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Point](#) to use to locate the profile

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::LocateProfilePoint](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::WeldmentProfilePath Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PathSegments Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : PathSegments Property (IStructuralMemberFeatureData)

Gets the path segments used or sets the path segments to use to create this structural member.

.NET Syntax

Visual Basic (Declaration)

Property PathSegments As System.Object

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim value As System.Object
```

```
instance.PathSegments = value
```

```
value = instance.PathSegments
```

C#

```
System.object PathSegments {get; set;}
```

C++/CLI

```
property System.Object^ PathSegments {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [path segments](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::PathSegments](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::GetPathSegmentAt Method](#)
[IStructuralMemberFeatureData::GetPathSegmentsCount Method](#)
[IStructuralMemberFeatureData::IGetPathSegments Method](#)
[IStructuralMemberFeatureData::ISetPathSegments Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : ReleaseSelectionAccess Method (IStructuralMemberFeatureData)

Releases access to the selections that define this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::ReleaseSelectionAccess](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

Remarks

[IStructuralMemberFeatureData::AccessSelections](#) puts the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotationAngle Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : RotationAngle Property (IStructuralMemberFeatureData)

Gets or sets the angle by which the structural member turns relative to the adjacent structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property RotationAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData  
Dim value As System.Double
```

```
instance.RotationAngle = value
```

```
value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::RotationAngle](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransferMaterial Property (IStructuralMemberFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : TransferMaterial Property (IStructuralMemberFeatureData)

Gets or sets whether to transfer the [material properties of a library profile](#) for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property TransferMaterial As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberFeatureData
Dim value As System.Boolean

instance.TransferMaterial = value

value = instance.TransferMaterial
```

C#

```
System.bool TransferMaterial {get; set;}
```

C++/CLI

```
property System.bool TransferMaterial {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to transfer the material properties of a library profile, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::TransferMaterial](#).

Example

[Insert Structural Weldments Using Custom Weldment Profile \(C#\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VB.NET\)](#)
[Insert Structural Weldments Using Custom Weldment Profile \(VBA\)](#)

Remarks

You can transfer material properties of a library profile:

- when you use it as a structural member.
- that has a configuration-specific material.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::ConfigurationName Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WeldmentProfilePath Property (IStructuralMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberFeatureData Interface](#) : WeldmentProfilePath Property (IStructuralMemberFeatureData)

Gets or sets the path for the profile for this structural member.

.NET Syntax

Visual Basic (Declaration)

```
Property WeldmentProfilePath As System.String
```

Visual Basic (Usage)

```
Dim instance As IStructuralMemberFeatureData
Dim value As System.String
```



```
instance.WeldmentProfilePath = value  
value = instance.WeldmentProfilePath
```

C#

```
System.string WeldmentProfilePath {get; set;}
```

C++/CLI

```
property System.String^ WeldmentProfilePath {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Full path and filename for the profile (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberFeatureData::WeldmentProfilePath](#).

Remarks

Weldment profiles are located in *install_dir\lang\lang\weldment profiles* subfolders and are named *filename.sldflp*.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IStructuralMemberFeatureData Interface](#)
[IStructuralMemberFeatureData Members](#)
[IStructuralMemberFeatureData::LocateProfilePoint Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0