

SOLIDWORKS API (.NET VBA C#) — Reference

(296/337): IStructuralMemberGroup- IStructureSystemMemberFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IStructuralMemberGroup (Type)

IStructuralMemberGroup Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberGroup Interface

Allows access to a weldment structural-member group.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStructuralMemberGroup
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
```

C#

```
public interface IStructuralMemberGroup
```

C++/CLI

```
public interface class IStructuralMemberGroup
```

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Create Structural-Member Group \(VBA\)](#)
[Create Structural-Member Group \(VB.NET\)](#)
[Create Structural-Member Group \(C#\)](#)

Accessors

[IFeatureManager::CreateStructuralMemberGroup](#)

[IStructuralMemberFeatureData::Groups](#)

[IStructuralMemberFeatureData::IGetGroups](#)

Access Diagram

[StructuralMemberGroup](#)

See Also

[IStructuralMemberGroup Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IStructuralMemberGroup Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberGroup Interface

The following tables list the members exposed by [IStructuralMemberGroup](#).

Public Properties

Name	Description
 AlignAxis	Gets and sets the axis on which to align this structural-member group.
 AlignmentVector	Gets and sets a reference vector for this structural-member group.
 Angle	Gets and sets the rotational angle of this structural-member group.
 ApplyCornerTreatment	Gets and sets whether or not to apply a corner treatment to this structural-member group.
 CornerTreatmentType	Gets and sets the type of corner treatment for this structural-member group.
 GapForOtherGroups	Gets and sets the gap between segments in different structural-member groups.
 GapWithinGroup	Gets and sets the gap between connected segments within this structural-member group.
 LocateProfilePoint	Gets and sets the point to use to locate the profile for this structural-member group.
 MergeArcSegmentBodies	Gets or sets whether to merge arc segment bodies with adjacent bodies in this structural-member group.
 MirrorProfile	Gets and sets whether to mirror the profile of this structural-member group.
 MirrorProfileAxis	Gets and sets the axis about which to mirror the profile of this structural-member group.
 MiterMergeCondition	Get or set whether to merge miter trimmed bodies in this structural-member group.
 Segments	Gets and sets the sketch segments to use in this structural-member group.

[Top](#)

Public Methods

Name	Description
 GetSegmentsCount	Gets the number of segments in this structural-member group.
 IGetSegments	Gets the sketch segments in this structural-member group.
 ISetSegments	Sets the sketch segments to use in this structural-member group.

[Top](#)

See Also

[IStructuralMemberGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructuralMemberGroup Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberGroup Interface

For a list of all members of this type, see [IStructuralMemberGroup members](#).

Public Methods

Name	Description
 GetSegmentsCount	Gets the number of segments in this structural-member group.
 IGetSegments	Gets the sketch segments in this structural-member group.
 ISetSegments	Sets the sketch segments to use in this structural-member group.

[Top](#)

See Also

[IStructuralMemberGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructuralMemberGroup Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructuralMemberGroup Interface

For a list of all members of this type, see [IStructuralMemberGroup members](#).

Public Properties

Name	Description
 AlignAxis	Gets and sets the axis on which to align this structural-member group.
 AlignmentVector	Gets and sets a reference vector for this structural-member group.
 Angle	Gets and sets the rotational angle of this structural-member group.
 ApplyCornerTreatment	Gets and sets whether or not to apply a corner treatment to this structural-member group.
 CornerTreatmentType	Gets and sets the type of corner treatment for this structural-member group.
 GapForOtherGroups	Gets and sets the gap between segments in different structural-member groups.
 GapWithinGroup	Gets and sets the gap between connected segments within this structural-member group.
 LocateProfilePoint	Gets and sets the point to use to locate the profile for this structural-member group.
 MergeArcSegmentBodies	Gets or sets whether to merge arc segment bodies with adjacent bodies in this structural-member group.
 MirrorProfile	Gets and sets whether to mirror the profile of this structural-member group.
 MirrorProfileAxis	Gets and sets the axis about which to mirror the profile of this structural-member group.
 MiterMergeCondition	Get or set whether to merge miter trimmed bodies in this structural-member group.
 Segments	Gets and sets the sketch segments to use in this structural-member group.

[Top](#)

See Also

[IStructuralMemberGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlignAxis Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : AlignAxis Property (IStructuralMemberGroup)

Gets and sets the axis on which to align this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Property AlignAxis As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Integer

instance.AlignAxis = value

value = instance.AlignAxis
```

C#

```
System.int AlignAxis {get; set;}
```

C++/CLI

```
property System.int AlignAxis {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Axis as defined in [swMirrorProfileOrAlignmentAxis_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::AlignAxis](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlignmentVector Property (IStructuralMemberGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : AlignmentVector Property (IStructuralMemberGroup)

Gets and sets a reference vector for this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property AlignmentVector As System.Object

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Object

instance.AlignmentVector = value

value = instance.AlignmentVector
```

C#

```
System.object AlignmentVector {get; set;}
```

C++/CLI

```
property System.Object^ AlignmentVector {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Object in the model that provides location and direction in aligning this structural-member group

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::AlignmentVector](#).

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : Angle Property (IStructuralMemberGroup)

Gets and sets the rotational angle of this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rotational angle in radians

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::Angle](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Create Structural Member Group \(VBA\)](#)
[Create Structural Member Group \(VB.NET\)](#)
[Create Structural Member Group \(C#\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplyCornerTreatment Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



Gets and sets whether or not to apply a corner treatment to this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property ApplyCornerTreatment As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Boolean
```

```
instance.ApplyCornerTreatment = value
```

```
value = instance.ApplyCornerTreatment
```

C#

```
System.bool ApplyCornerTreatment {get; set;}
```

C++/CLI

```
property System.bool ApplyCornerTreatment {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply corner treatment, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::ApplyCornerTreatment](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::CornerTreatmentType Property \(\)](#)
[IStructuralMemberGroup::MiterMergeCondition Property \(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerTreatmentType Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IStructuralMemberGroup Interface : CornerTreatmentType Property (IStructuralMemberGroup)

Gets and sets the type of corner treatment for this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property CornerTreatmentType As System.Integer

Visual Basic (Usage)

```
Dim instance As IStructuralMemberGroup
Dim value As System.Integer

instance.CornerTreatmentType = value

value = instance.CornerTreatmentType
```

C#

```
System.int CornerTreatmentType {get; set;}
```

C++/CLI

```
property System.int CornerTreatmentType {
    System.int get();
    void set ( &    System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of corner treatment as defined in [swSolidworksWeldmentEndCondOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::CornerTreatmentType](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

Remarks

This property is only available when [IStructuralMemberGroup::ApplyCornerTreatment](#) is true.

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::MiterMergeCondition Property\(\)](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GapForOtherGroups Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : GapForOtherGroups Property (IStructuralMemberGroup)

Gets and sets the gap between segments in different structural-member groups.

.NET Syntax

Visual Basic (Declaration)

```
Property GapForOtherGroups As System.Double
```

Visual Basic (Usage)

```
Dim instance As IStructuralMemberGroup
Dim value As System.Double

instance.GapForOtherGroups = value
```

```
value = instance.GapForOtherGroups
```

C#

```
System.double GapForOtherGroups {get; set;}
```

C++/CLI

```
property System.double GapForOtherGroups {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap in meters between segments in different groups

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::GapForOtherGroups](#).

Example

[Merge Arc Segment Bodies With Adjacent Bodies \(C#\)](#)
[Merge Arc Segment Bodies With Adjacent Bodies \(VB.NET\)](#)
[Merge Arc Segment Bodies With Adjacent Bodies \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::GapWithinGroup Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GapWithinGroup Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : GapWithinGroup Property (IStructuralMemberGroup)

Gets and sets the gap between connected segments within this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Property GapWithinGroup As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim value As System.Double
```

```
instance.GapWithinGroup = value
```

```
value = instance.GapWithinGroup
```

C#

```
System.double GapWithinGroup {get; set;}
```

C++/CLI

```
property System.double GapWithinGroup {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap in meters between connected segments within group

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::GapWithinGroup](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::GapForOtherGroups Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSegmentsCount Method (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : GetSegmentsCount Method (IStructuralMemberGroup)

Gets the number of segments in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSegmentsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim value As System.Integer
```

```
value = instance.GetSegmentsCount()
```

C#

```
System.int GetSegmentsCount()
```

C++/CLI

```
System.int GetSegmentsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of segments

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::GetSegmentsCount](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)

[Insert Structural Weldment \(VBA\)](#)
[Create Structural-Member Group \(VBA\)](#)
[Create Structural-Member Group \(VB.NET\)](#)
[Create Structural-Member Group \(C#\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::IGetSegments Method](#)
[IStructuralMemberGroup::ISetSegments Method](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSegments Method (IStructuralMemberGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : IGetSegments Method (IStructuralMemberGroup)

Gets the sketch segments in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSegments( _  
    ByVal Count As System.Integer _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim Count As System.Integer  
Dim value As SketchSegment  
  
value = instance.IGetSegments(Count)
```

C#

```
SketchSegment IGetSegments(  
    System.int Count  
)
```

C++/CLI

```
SketchSegment^ IGetSegments(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch segments

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Before using this method, call [IStructuralMemberGroup::GetSegmentsCount](#) to populate the *Count* parameter.

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::ISetSegments Method](#)
[IStructuralMemberGroup::Segments Property](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSegments Method (IStructuralMemberGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : ISetSegments Method (IStructuralMemberGroup)

Sets the sketch segments to use in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSegments( _  
    ByVal Count As System.Integer, _  
    ByRef SegArr As SketchSegment _  
)
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim Count As System.Integer  
Dim SegArr As SketchSegment  
  
instance.ISetSegments(Count, SegArr)
```

C#

```
void ISetSegments(  
    System.int Count,  
    ref SketchSegment SegArr  
)
```

C++/CLI

```
void ISetSegments(  
& System.int Count,  
& SketchSegment^% SegArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of sketch segments

SegArr

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before using this method, call [IStructuralMemberGroup::GetSegmentsCount](#) to populate the *Count* parameter.

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::IGetSegments Method](#)
[IStructuralMemberGroup::Segments Property](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

LocateProfilePoint Property (IStructuralMemberGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : LocateProfilePoint Property (IStructuralMemberGroup)

Gets and sets the point to use to locate the profile for this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property LocateProfilePoint As SketchPoint

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim value As SketchPoint
```

```
instance.LocateProfilePoint = value
```

```
value = instance.LocateProfilePoint
```

C#

```
SketchPoint LocateProfilePoint {get; set;}
```

C++/CLI

```
property SketchPoint^ LocateProfilePoint {  
    SketchPoint^ get();  
    void set ( & SketchPoint^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Point](#) to use to locate the profile

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::LocateProfilePoint](#).

Remarks

This property can be set only after creating the structural-member group.

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

MergeArcSegmentBodies Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : MergeArcSegmentBodies Property (IStructuralMemberGroup)

Gets or sets whether to merge arc segment bodies with adjacent bodies in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property MergeArcSegmentBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Boolean

instance.MergeArcSegmentBodies = value

value = instance.MergeArcSegmentBodies
```

C#

```
System.bool MergeArcSegmentBodies {get; set;}
```

C++/CLI

```
property System.bool MergeArcSegmentBodies {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge arc segment bodies with adjacent bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::MergeArcSegmentBodies](#).

Example

[Merge Arc Segment Bodies With Adjacent Bodies \(C#\)](#)
[Merge Arc Segment Bodies With Adjacent Bodies \(VB.NET\)](#)
[Merge Arc Segment Bodies With Adjacent Bodies \(VBA\)](#)

Remarks

This property is valid for curved entities only. The arc segment and adjacent bodies must be tangent to merge.

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorProfile Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : MirrorProfile Property (IStructuralMemberGroup)

Gets and sets whether to mirror the profile of this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property MirrorProfile As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Boolean

instance.MirrorProfile = value

value = instance.MirrorProfile
```

C#

```
System.bool MirrorProfile {get; set;}
```

C++/CLI

```
property System.bool MirrorProfile {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to mirror the profile, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::MirrorProfile](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::MirrorProfileAxis Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MirrorProfileAxis Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : MirrorProfileAxis Property (IStructuralMemberGroup)

Gets and sets the axis about which to mirror the profile of this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Property MirrorProfileAxis As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Integer

instance.MirrorProfileAxis = value

value = instance.MirrorProfileAxis
```

C#

```
System.int MirrorProfileAxis {get; set;}
```

C++/CLI

```
property System.int MirrorProfileAxis {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Axis as defined in [swMirrorProfileOrAlignmentAxis_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::MirrorProfileAxis](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup Members](#)
[IStructuralMemberGroup::MirrorProfile Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MiterMergeCondition Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : MiterMergeCondition Property (IStructuralMemberGroup)

Get or set whether to merge miter trimmed bodies in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

```
Property MiterMergeCondition As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup  
Dim value As System.Boolean
```

```
instance.MiterMergeCondition = value
```

```
value = instance.MiterMergeCondition
```

C#

```
System.bool MiterMergeCondition {get; set;}
```

C++/CLI

```
property System.bool MiterMergeCondition {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge miter trimmed bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::MiterMergeCondition](#).

Example

[Merge Miter Trimmed Bodies \(C#\)](#)
[Merge Miter Trimmed Bodies \(VB.NET\)](#)
[Merge Miter Trimmed Bodies \(VBA\)](#)

Remarks

This property is only available when [StructuralMemberGroup::CornerTreatmentType](#) is [swSolidworksWeldmentEndCondOptions_e.swEndConditionMiter](#).

See Also

[IStructuralMemberGroup Interface](#)
[StructuralMemberGroup Members](#)
[StructuralMemberGroup::ApplyCornerTreatment Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Segments Property (IStructuralMemberGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructuralMemberGroup Interface](#) : Segments Property (IStructuralMemberGroup)

Gets and sets the sketch segments to use in this structural-member group.

.NET Syntax

Visual Basic (Declaration)

Property Segments As System.Object

Visual Basic (Usage)



```
Dim instance As IStructuralMemberGroup
Dim value As System.Object
```

```
instance.Segments = value
```

```
value = instance.Segments
```

C#

```
System.object Segments {get; set;}
```

C++/CLI

```
property System.Object^ Segments {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [sketch segments](#)

Visual Basic for Applications (VBA) Syntax

See [StructuralMemberGroup::Segments](#).

Example

[Insert Structural Weldment \(C#\)](#)
[Insert Structural Weldment \(VB.NET\)](#)
[Insert Structural Weldment \(VBA\)](#)
[Create Structural-Member Group \(VBA\)](#)
[Create Structural-Member Group \(VB.NET\)](#)
[Create Structural-Member Group \(C#\)](#)

See Also

[IStructuralMemberGroup Interface](#)
[IStructuralMemberGroup.Members](#)
[IStructuralMemberGroup::IGetSegments Method](#)
[IStructuralMemberGroup::ISetSegments Method](#)

Availability

SOLIDWORKS 2009 SP5, Revision Number 17.5

IStructureSystemFolder (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemFolder Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemFolder Interface

Allows access to a structure system folder.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStructureSystemFolder
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemFolder
```

C#

```
public interface IStructureSystemFolder
```

C++/CLI

```
public interface class IStructureSystemFolder
```

Visual Basic for Applications (VBA) Syntax

See [StructureSystemFolder](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This interface accesses the top-level folder of a structure system in the FeatureManager design tree. The structure system folder contains one or more profile group folders. Each profile group folder contains profile references and structure system members.

When a structure system is created in the user interface, the Corner Management PropertyManager opens automatically. When structure systems are created using the API, a Corner ManagementX folder is automatically created for each structure system in the FeatureManager design tree.

A structure system and its corner management folder appears similar to the following in the FeatureManager design tree. In parentheses are the APIs that you use to access the corresponding item:

- **Structure System1** (IStructureSystemFolder accessors)
- **Structure System Grid1**
- **<ansi inch> <c channel><3 x 5> (1)** ([IProfileGroupFolder](#) accessors)
 - **Plane2** (profile reference plane - [IProfileGroupFolder::GetPlane](#))
 - **Sketch11** (profile sketch - [IProfileGroupFolder::GetSketch](#))
 - **Member1** (structure system member - [IProfileGroupFolder::GetStructureSystemMembers](#))
- **Corner Management1** ([ICornerManagementFolder](#) accessors)
- **Complex Corner Group1** ([ICornerTreatmentGroupFolder](#) accessors)
 - **Corner5** ([ICornerTreatmentFeatureData](#) accessors and then cast to [IComplexCornerTreatmentFeatureData](#))

- more corners...

(Each corner in a complex corner group contains multiple corner members. If you edit a corner to open a Corner Management PropertyManager in the user interface, on the Complex tab are three boxes that list corner members for Trim Tool, Body Trim, and Planar Trim. Use [ICornerMember](#) to access these corner members.)

- **Two member Corner Group1** (ICornerTreatmentGroupFolder accessors)

- **Corner1** (ICornerTreatmentFeatureData accessors and then cast to [ITwoMemberCornerTreatmentFeatureData](#))

- more corners...

(Each corner in a two member corner group contains two corner members, one for Trim Tool, and one for Body Trim. Use ICornerMember to access these corner members.)

- **Simple Corner Group1** (ICornerTreatmentGroupFolder accessors)

- **Corner9** (ICornerTreatmentFeatureData accessors and then cast to [ISimpleCornerTreatmentFeatureData](#))

- more corners...

To create a structure system:

1. Create an [IStructureSystemMemberFeatureData](#) object for every primary and secondary structure system member you intend to create.
2. Create [IStructureSystemSplitMember](#) objects as needed. Use [IStructureSystemMemberFeatureData::IsSplit](#) to indicate that split members exist.
3. Create one or more [IStructureSystemMemberProfile](#) objects as the number of different profiles is needed.
4. Cast the IStructureSystemMemberFeatureData objects to [IPrimaryStructuralMemberFeatureData](#) objects and [ISecondaryStructuralMemberFeatureData](#) objects as needed.
5. Create specific primary member feature data objects by casting IPrimaryStructuralMemberFeatureData objects to:
 - [IPrimaryMemberFacePlaneIntersectionFeatureData](#)
 - [IPrimaryMemberPathSegmentFeatureData](#)
 - [IPrimaryMemberPointLengthFeatureData](#)
 - [IPrimaryMemberRefPlaneFeatureData](#)
6. Create specific secondary member feature data objects by casting ISecondaryStructuralMemberFeatureData objects to:
 - [ISecondaryMemberBetweenPointsFeatureData](#)
 - [ISecondaryMemberSupportPlaneFeatureData](#)
7. Use the methods and properties on the specific primary and secondary member feature data objects to detail the structure system members.
8. Call [IModelDocExtension::CreateStructureSystem\(primaryFDArray, secondaryFDArray\)](#), where *primaryFDArray* is an array of primary IStructureSystemMemberFeatureData objects and *secondaryFDArray* is an array of secondary IStructureSystemMemberFeatureData objects created in step 1.

To edit a structure system:

1. Get the structure system folder feature, which is returned by IModelDocExtension::CreateStructureSystem in step 8 above. Then call the accessor of this interface, IFeature::GetSpecificFeature2.
(Or call both accessors of this interface.)
2. Use [IStructureSystemFolder::GetProfileGroupFolders](#) to access the profile group folders in a structure system folder.
3. Use IProfileGroupFolder methods and properties to get the sketch, reference plane, and structure system members in each profile group folder.
4. Use [IStructureSystemMemberFeatureData::StructureSystemMemberType](#) to determine whether a structure system member retrieved in step 3 is a primary or a secondary member.
5. Call [IStructureSystemMemberFeatureData::AccessSelections](#) before editing the selections used to create the structure system.
Call [IStructureSystemMemberFeatureData::ReleaseSelectionAccess](#) after editing.
6. Cast IStructureSystemMemberFeatureData objects to their subclass feature data objects (see create steps 5 and 6).
7. If you need to change a structure member's profile, use [IStructureSystemMemberFeatureData::MemberProfile](#) to get the IStructureSystemMemberProfile object for each structure member.
8. Complete the structure system edit by calling [IStructureSystemMemberFeatureData::GetFeature](#), calling methods and properties on objects retrieved in previous steps as required, and finally calling [IFeature::ModifyDefinition](#).

Use the examples as models to create and edit structure systems in your own applications.

For more information, read the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System** topics.

Accessors

[ICircularPatternFeatureData::StructureSystemToPatternArray](#)

[ICornerManagementFolder::GetStructureSystemFolder](#) and then [IFeature::GetSpecificFeature2](#)

[IFeatureManager::GetStructureSystemFolders](#) and then [IFeature::GetSpecificFeature2](#)

[ILinearPatternFeatureData::StructureSystemToPatternArray](#)

[IMirrorSolidFeatureData::StructureSystemToPatternArray](#)

Access Diagram

[StructureSystemFolder](#)

See Also

[IStructureSystemFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

Public Methods

Name	Description
 GetCornerManagementFolder	Gets the corner management folder in this structure system folder.
 GetFeature	Gets the feature for this structure system folder.
 GetProfileGroupFolders	Gets the profile group folders in this structure system folder.
 GetProfileGroupFoldersCount	Gets the number of profile groups in this structure system folder.

[Top](#)

See Also

[IStructureSystemFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemFolder Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemFolder Interface

The following tables list the members exposed by [IStructureSystemFolder](#).

Public Methods

Name	Description
 GetCornerManagementFolder	Gets the corner management folder in this structure system folder.
 GetFeature	Gets the feature for this structure system folder.
 GetProfileGroupFolders	Gets the profile group folders in this structure system folder.
 GetProfileGroupFoldersCount	Gets the number of profile groups in this structure system folder.

[Top](#)

See Also

[IStructureSystemFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCornerManagementFolder Method (IStructureSystemFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemFolder Interface](#) : GetCornerManagementFolder Method (IStructureSystemFolder)

Gets the corner management folder in this structure system folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCornerManagementFolder() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemFolder  
Dim value As System.Object  
  
value = instance.GetCornerManagementFolder()
```

C#

```
System.object GetCornerManagementFolder()
```

C++/CLI

```
System.Object^ GetCornerManagementFolder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemFolder::GetCornerManagementFolder](#).

Remarks

After calling this method to get the IFeature, use [IFeature::GetSpecificFeature2](#) to get an [ICornerManagementFolder](#).

See Also

[IStructureSystemFolder Interface](#)
[IStructureSystemFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IStructureSystemFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemFolder Interface](#) : GetFeature Method (IStructureSystemFolder)

Gets the feature for this structure system folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemFolder  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemFolder::GetFeature](#).

See Also

[IStructureSystemFolder Interface](#)
[IStructureSystemFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileGroupFolders Method (IStructureSystemFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemFolder Interface](#) : GetProfileGroupFolders Method (IStructureSystemFolder)

Gets the profile group folders in this structure system folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileGroupFolders() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemFolder
Dim value As System.Object

value = instance.GetProfileGroupFolders()
```

C#

```
System.Object GetProfileGroupFolders()
```

C++/CLI

```
System.Object^ GetProfileGroupFolders();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IProfileGroupFolders](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemFolder::GetProfileGroupFolders](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemFolder Interface](#)
[IStructureSystemFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileGroupFoldersCount Method (IStructureSystemFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemFolder Interface](#) : GetProfileGroupFoldersCount Method (IStructureSystemFolder)

Gets the number of profile groups in this structure system folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileGroupFoldersCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemFolder  
Dim value As System.Integer  
  
value = instance.GetProfileGroupFoldersCount()
```

C#

```
System.int GetProfileGroupFoldersCount()
```

C++/CLI

```
System.int GetProfileGroupFoldersCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of profile groups

Visual Basic for Applications (VBA) Syntax

See [StructureSystemFolder::GetProfileGroupFoldersCount](#).

Example

See the [ICornerManagementFolder](#) examples.
See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.
See the [IPrimaryMemberPointLengthFeatureData](#) examples.
See the [IPrimaryMemberPathSegmentFeatureData](#) examples.
See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemFolder Interface](#)
[IStructureSystemFolder Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

IStructureSystemMemberFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IStructureSystemMemberFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberFeatureData Interface

Allows access to a structure system member.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IStructureSystemMemberFeatureData
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData
```

C#

```
public interface IStructureSystemMemberFeatureData
```

C++/CLI

```
public interface class IStructureSystemMemberFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See the [ISecondaryMemberBetweenPointsFeatureData](#) examples.

Remarks

This interface is the superclass of [IPrimaryStructuralMemberFeatureData](#) and [ISecondaryStructuralMemberFeatureData](#).

See the [IStructureSystemFolder](#) Remarks.

For more information about structure system members, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Primary Member PropertyManager** and **Secondary Member PropertyManager** topics.

Accessors

[IComplexCornerTreatmentFeatureData::GetBodyTrimMembers](#)

[IComplexCornerTreatmentFeatureData::GetPlanarTrimMembers](#)

[ICornerMember::GetUnderlyingMemberFeature](#) and then [IFeature::GetSpecificFeature2](#)

[IModelDocExtension::CreateStructureSystemMemberData](#)

[IProfileGroupFolder::GetStructureSystemMembers](#)

[ISecondaryMemberBetweenPointsFeatureData::GetMemberPairs](#)

[ISecondaryMemberSupportPlaneFeatureData::GetMemberPairs](#)

[ISecondaryMemberUpToMembersFeatureData::GetFromPointMembers](#)

[ISecondaryMemberUpToMembersFeatureData::GetPointMemberPairs](#)

 Access Diagram

[StructureSystemMemberFeatureData](#)

 See Also

[IStructureSystemMemberFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemMemberFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberFeatureData Interface

The following tables list the members exposed by [IStructureSystemMemberFeatureData](#).

 Public Properties

Name	Description
 IsSplit	Gets and sets whether this structure system member is split.
 MemberProfile	Gets the profile of this structure system member.
 StartEndExtendD1	Gets and sets the distance in Direction 1 to extend this structure system member.
 StartEndExtendD2	Gets and sets the distance in Direction 2 to extend this structure system member.
 StructureSystemMemberType	Gets the type of this structure system member.

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the structure system member feature.
 GetBody	Gets the body of this structure system member.
 GetFeature	Gets the feature for this structure system member.
 GetSplitMember	Gets the split member object for this structure system member.
 ReleaseSelectionAccess	Releases access to the selections used to define this structure system member feature.

[Top](#)

 See Also

[IStructureSystemMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IStructureSystemMemberFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberFeatureData Interface

For a list of all members of this type, see [IStructureSystemMemberFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the structure system member feature.
 GetBody	Gets the body of this structure system member.
 GetFeature	Gets the feature for this structure system member.
 GetSplitMember	Gets the split member object for this structure system member.
 ReleaseSelectionAccess	Releases access to the selections used to define this structure system member feature.



[Top](#)

See Also

[IStructureSystemMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IStructureSystemMemberFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IStructureSystemMemberFeatureData Interface

For a list of all members of this type, see [IStructureSystemMemberFeatureData members](#).

Public Properties

Name	Description
 IsSplit	Gets and sets whether this structure system member is split.
 MemberProfile	Gets the profile of this structure system member.
 StartEndExtendD1	Gets and sets the distance in Direction 1 to extend this structure system member.
 StartEndExtendD2	Gets and sets the distance in Direction 2 to extend this structure system member.
 StructureSystemMemberType	Gets the type of this structure system member.

[Top](#)

See Also

[IStructureSystemMemberFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : AccessSelections Method (IStructureSystemMemberFeatureData)

Gains access to selections used to define the structure system member feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top level document (see **Remarks**)

Component

Component for the feature (see **Remarks**)

Return Value

True if selections successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IStructureSystemMemberFeatureData::ReleaseSelectionAccess](#) if you did not modify the feature

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBody Method (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : GetBody Method (IStructureSystemMemberFeatureData)

Gets the body of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim value As System.Object  
  
value = instance.GetBody()
```

C#

```
System.object GetBody()
```

C++/CLI

```
System.Object^ GetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBody2](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::GetBody](#).

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : GetFeature Method (IStructureSystemMemberFeatureData)

Gets the feature for this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim value As Feature
```

```
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::GetFeature](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSplitMember Method (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : GetSplitMember Method (IStructureSystemMemberFeatureData)

Gets the split member object for this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSplitMember() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim value As System.Object  
  
value = instance.GetSplitMember()
```

C#

```
System.object GetSplitMember()
```

C++/CLI

```
System.Object^ GetSplitMember();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IStructureSystemSplitMember](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::GetSplitMember](#).

Example

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSplit Property (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : IsSplit Property (IStructureSystemMemberFeatureData)

Gets and sets whether this structure system member is split.

.NET Syntax

Visual Basic (Declaration)

Property IsSplit As System.Boolean

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData
Dim value As System.Boolean

instance.IsSplit = value
value = instance.IsSplit
```

C#

```
System.bool IsSplit {get; set;}
```

C++/CLI

```
property System.bool IsSplit {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this structure system member is split, false if not

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::IsSplit](#).

Example

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

Remarks

If this property is true, then use [IStructureSystemMemberFeatureData::GetSplitMember](#) to access the split member.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

MemberProfile Property (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : MemberProfile Property (IStructureSystemMemberFeatureData)

Gets the profile of this structure system member.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property MemberProfile As System.Object

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData
Dim value As System.Object

value = instance.MemberProfile
```

C#

```
System.Object MemberProfile {get;}
```

C++/CLI

```
property System.Object^ MemberProfile {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IStructureSystemMemberProfile](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData.MemberProfile](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : ReleaseSelectionAccess Method (IStructureSystemMemberFeatureData)

Releases access to the selections used to define this structure system member feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::ReleaseSelectionAccess](#).

Remarks

[IStructureSystemMemberFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartEndExtendD1 Property (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : StartEndExtendD1 Property (IStructureSystemMemberFeatureData)

Gets and sets the distance in Direction 1 to extend this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
Property StartEndExtendD1 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData
Dim value As System.Double

instance.StartEndExtendD1 = value
value = instance.StartEndExtendD1
```

C#

```
System.double StartEndExtendD1 {get; set;}
```

C++/CLI

```
property System.double StartEndExtendD1 {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Extend distance in Direction 1

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::StartEndExtendD1](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartEndExtendD2 Property (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : StartEndExtendD2 Property (IStructureSystemMemberFeatureData)

Gets and sets the distance in Direction 2 to extend this structure system member.

.NET Syntax

Visual Basic (Declaration)

Property StartEndExtendD2 As System.Double

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim value As System.Double
```

```
instance.StartEndExtendD2 = value
```

```
value = instance.StartEndExtendD2
```

C#

```
System.double StartEndExtendD2 {get; set;}
```

C++/CLI

```
property System.double StartEndExtendD2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Extend distance in Direction 2

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::StartEndExtendD2](#).

Example

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

StructureSystemMemberType Property (IStructureSystemMemberFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IStructureSystemMemberFeatureData Interface](#) : StructureSystemMemberType Property (IStructureSystemMemberFeatureData)

Gets the type of this structure system member.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property StructureSystemMemberType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IStructureSystemMemberFeatureData  
Dim value As System.Integer  
  
value = instance.StructureSystemMemberType
```

C#

```
System.int StructureSystemMemberType {get;}
```

C++/CLI

```
property System.int StructureSystemMemberType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of structure system member as defined by [swStructureSystemMemberType_e](#)

Visual Basic for Applications (VBA) Syntax

See [StructureSystemMemberFeatureData::StructureSystemMemberType](#).

Example

See the [ICornerManagementFolder](#) examples.

See the [IPrimaryMemberFacePlaneIntersectionFeatureData](#) examples.

See the [IPrimaryMemberPointLengthFeatureData](#) examples.

See the [IPrimaryMemberPathSegmentFeatureData](#) examples.

See the [IPrimaryMemberRefPlaneFeatureData](#) examples.

See Also

[IStructureSystemMemberFeatureData Interface](#)
[IStructureSystemMemberFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30